



Cisco NX-OS FCoE Configuration Guide for Nexus 7000 Series and MDS 9000

First Published: 2011-07-12

Last Modified: 2016-02-12

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com go trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2011–2015 Cisco Systems, Inc. All rights reserved.



CONTENTS

PREFACE

Preface	vii
Audience	vii
Document Conventions	vii
Documentation Feedback	viii
Communications, Services, and Additional Information	viii

CHAPTER 1

New and Changed Information	1
------------------------------------	----------

CHAPTER 2

Overview	3
Information About Fibre Channel Over Ethernet	3
Fibre Channel Forwarder	3
Fibre Channel Bridge	4

CHAPTER 3

Preparing the Switch for Configuring FCoE	5
Information About FCoE	5
FCoE and FIP	5
FCoE Initiation Protocol	5
FIP Virtual Link Instantiation	6
FCoE Frame Format	6
VLAN Tagging for FCoE Frames	6
FIP Ethernet Frame Format	6
DCBX	7
Data Center Bridging Exchange Protocol	7
Lossless Ethernet	7
Logical Link Up/Down	8
Converged Network Adapters	8

STP Lite	8
Default Settings for FCoE	9
Guidelines and Limitations	9
Enabling and Disabling FCoE	9
Configuring the FC-Map	9
Configuring the Fabric Priority	10
Setting the Advertisement Interval	10
Disabling LAN Traffic on an FCoE Link	11
Additional References for FCoE	12

CHAPTER 4	Configuring FCoE VLANs and Virtual Fibre Channel Interfaces	13
	Information About Virtual Fibre Channel (VFC) Interfaces	13
	VF Port	13
	VE Port	13
	VNP Ports	14
	Default Settings for FCoE	14
	Guidelines and Limitations	14
	Configuring Virtual Interfaces	14
	Mapping a VSAN to a VLAN	14
	Creating a Virtual Fibre Channel Interface	16
	Creating a Virtual Fibre Channel Port Channel Interface	17
	Associating a Virtual Fibre Channel Interface to a VSAN	18
	Enabling VE Loopback Configuration	19
	Verifying the Virtual Fibre Channel Interface	20
	Example: Mapping VSANs to VLANs	22
	Verifying the FCoE Configuration	23
	Additional References for FCoE	24

CHAPTER 5	Storage VDC	27
	Information About Storage VDC	27
	Licensing Requirements for FCoE	28
	Configuring FCoE VDCs	28
	Licensing an FCoE Module	28
	Creating a Dedicated Storage VDC	29

Allocating the FCoE VLAN Range	31
Allocating Shared Interfaces	32
Example: Storage VDC Configuration	34

APPENDIX A	Feature History by Platform	37
-------------------	------------------------------------	-----------

APPENDIX B	Guidelines and Limitations	39
-------------------	-----------------------------------	-----------



Preface

The preface contains the following sections:

- [Audience, on page vii](#)
- [Document Conventions, on page vii](#)
- [Documentation Feedback, on page viii](#)
- [Communications, Services, and Additional Information, on page viii](#)

Audience

This publication is for network administrators who configure and maintain Cisco Nexus devices.

Document Conventions



Note

As part of our constant endeavor to remodel our documents to meet our customers' requirements, we have modified the manner in which we document configuration tasks. As a result of this, you may find a deviation in the style used to describe these tasks, with the newly included sections of the document following the new format.

Command descriptions use the following conventions:

Convention	Description
bold	Bold text indicates the commands and keywords that you enter literally as shown.
<i>Italic</i>	Italic text indicates arguments for which the user supplies the values.
[x]	Square brackets enclose an optional element (keyword or argument).
[x y]	Square brackets enclosing keywords or arguments separated by a vertical bar indicate an optional choice.
{x y}	Braces enclosing keywords or arguments separated by a vertical bar indicate a required choice.

Convention	Description
[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
<i>variable</i>	Indicates a variable for which you supply values, in context where italics cannot be used.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Examples use the following conventions:

Convention	Description
<code>screen font</code>	Terminal sessions and information the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



Note Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to: .

We appreciate your feedback.

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).

- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



CHAPTER 1

New and Changed Information



CHAPTER 2

Overview

This chapter contains the following sections:

- [Information About Fibre Channel Over Ethernet, on page 3](#)
- [Fibre Channel Forwarder, on page 3](#)
- [Fibre Channel Bridge, on page 4](#)

Information About Fibre Channel Over Ethernet

Fibre Channel over Ethernet (FCoE) allows Fibre Channel traffic to be encapsulated over a physical Ethernet link. FCoE and FIP frames use a unique EtherType so that FCoE traffic and standard Ethernet traffic can be carried on the same link.

Classic Ethernet is a best-effort protocol, which means that in a congested network, Ethernet discards packets and relies on higher level protocols to provide retransmission and other reliability mechanisms.

Fibre Channel traffic requires a lossless transport layer; as a data storage protocol, it is unacceptable to lose a single data packet. Native Fibre Channel implements a lossless service at the transport layer using a buffer-to-buffer credit system.

Ethernet links on Cisco NX-OS switches provide two mechanisms to ensure lossless transport for FCoE traffic: link-level flow control and priority flow control.

IEEE 802.3x link-level flow control allows a congested receiver to signal the far end to pause the data transmission for a short period of time. The pause functionality is applied to all traffic on the link.

The priority flow control (PFC) feature on Cisco NX-OS platforms applies pause functionality to specific classes of traffic on the Ethernet link. For example, PFC can provide lossless service for the FCoE traffic and best-effort service for the standard Ethernet traffic using IEEE 802.1p traffic classes.

Fibre Channel Forwarder

Fibre Channel traffic requires a lossless transport layer, which means that it requires a data storage protocol that does not lose a single data packet. A FCoE Forwarder (FCF) communicates with FCoE end devices, such as converged network adapters (CNAs). The FCF accepts the Fibre Channel frame that is encapsulated in an Ethernet packet and forwards that packet over a VLAN across an Ethernet network to a remote FCoE end device. The FCF has a unique FC-MAC address in the FCoE network. An FCF can also assign FC address IDs to the CNAs. An FCF can assign Fabric Provide MAC Addresses (FPMA) to the CNAs consisting of the FC-Map Value for the Fabric and the Fibre Channel IDs (FC IDs) assigned during Fabric Login.

Fibre Channel Bridge

A Fibre Channel Bridge connects an FCoE network to a Fibre Channel network. A Fibre Channel Bridge decapsulates an FCoE frame and sends the Fibre Channel frame to the Fibre Channel network. A Fibre Channel Bridge also encapsulates FC frames from a Fibre Channel network and forwards them to the FCoE network.



CHAPTER 3

Preparing the Switch for Configuring FCoE

- [Information About FCoE, on page 5](#)
- [Default Settings for FCoE, on page 9](#)
- [Guidelines and Limitations, on page 9](#)
- [Enabling and Disabling FCoE, on page 9](#)
- [Configuring the FC-Map , on page 9](#)
- [Configuring the Fabric Priority, on page 10](#)
- [Setting the Advertisement Interval, on page 10](#)
- [Disabling LAN Traffic on an FCoE Link, on page 11](#)
- [Additional References for FCoE, on page 12](#)

Information About FCoE

FCoE provides a method of transporting Fibre Channel traffic over a physical Ethernet connection. FCoE requires the underlying Ethernet to be full duplex and to provide lossless behavior for Fibre Channel traffic.



Note Lossless behavior on Ethernet is provided by using a priority flow control (PFC) mechanism that prevents packet loss during congestion conditions.

The Cisco NX-OS software supports T11-compliant FCoE on all 10-Gigabit and 40-Gigabit Ethernet interfaces.

FCoE and FIP

FCoE Initiation Protocol

The FCoE Initialization Protocol (FIP) allows the switch to discover and initialize FCoE-capable entities that are connected to an Ethernet LAN. Cisco NX-OS switches support the Converged Enhanced Ethernet Data Center Bridging Exchange (CEE-DCBX) protocol for T11-compliant Generation 2 CNAs.

The following switches do not support Pre-FIP on Generation 1 CNAs:

FIP Virtual Link Instantiation

FIP is used to perform device discovery, initialization, and link maintenance. FIP performs the following tasks:

- FIP VLAN discovery— Discovers the FCoE VLAN that will be used by all other FIP protocols as well as by the FCoE encapsulation for Fibre Channel payloads on the established virtual link. FIP VLAN discovery occurs in the native VLAN used by the initiator or target to exchange Ethernet traffic. The FIP VLAN discovery protocol is the only FIP protocol running on the native VLAN; all other FIP protocols run on the discovered FCoE VLANs.
- FIP FCF discovery—When a FCoE device is connected to the fabric, it sends a Discovery Solicitation message. A Fibre Channel Forwarder (FCF) or a switch responds to the message with a Solicited Advertisement that provides an FCF MAC address to use for subsequent logins.
- FCoE virtual link instantiation— FIP defines the encapsulation of fabric login (FLOGI), fabric discovery (FDISC), logout (LOGO), and exchange link parameter (ELP) frames along with the corresponding reply frames. The FCoE devices use these messages to perform a fabric login.
- FCoE virtual link maintenance— FIP periodically sends maintenance messages between the switch and the CNA to ensure that the connection is still valid.

FCoE Frame Format

FCoE is implemented when the switch encapsulates a Fibre Channel frame in an Ethernet packet with a dedicated Ethernet type, 0x8906. The packet has a 4-bit version field. The other header fields in the frame (the source and destination MAC addresses, VLAN tags, and frame markers) are all standard Ethernet fields. Reserved bits pad the FCoE frame to the IEEE 802.3 minimum packet length of 64 bytes.

A Fibre Channel frame consists of 36 bytes of headers and up to 2112 bytes of data for a total maximum size of 2148 bytes. The encapsulated Fibre Channel frame has all the standard headers, which allow it to be passed to the storage network without further modification. To accommodate the maximum Fibre Channel frame in an FCoE frame, the class-fcoe is defined with a default Maximum Transmission Unit (MTU) of 2240 bytes.

VLAN Tagging for FCoE Frames

The Ethernet frames that are sent by the switch to the adapter include the IEEE 802.1Q tag. This tag includes a field for the class of service (CoS) value used by the priority flow control (PFC). The IEEE 802.1Q tag also includes a VLAN field.

The switch expects frames from a FIP T11-compliant CNA to be tagged with the VLAN tag for the FCoE VLAN. Frames that are not correctly tagged are discarded.



Note You cannot map VLAN 1 or the native VLAN to an FCoE VSAN.

FIP Ethernet Frame Format

FIP is encapsulated in an Ethernet packet with a dedicated EtherType, 0x8914. The packet has a 4-bit version field. Along with the source and destination MAC addresses, the FIP packet also contains a FIP operation code and a FIP operation subcode. The following table describes the FIP operation codes and subcodes.

Table 1: FIP Operation Codes

FIP Operation Code	FIP Subcode	FIP Operation
0x0001	0x01	Discovery Solicitation
	0x02	Discovery Advertisement
0x0002	0x01	Virtual Link Instantiation Request
	0x02	Virtual Link Instantiation Reply
0x0003	0x01	FIP Keepalive
	0x02	FIP Clear Virtual Links
0x0004	0x01	FIP VLAN Request
	0x02	FIP VLAN Notification

DCBX

Data Center Bridging Exchange Protocol

The Data Center Bridging Exchange (DCBX) protocol is an extension of the Link Layer Discovery Protocol (LLDP). DCBX end points exchange request and acknowledgment messages. For flexibility, parameters are coded in a type-length-value (TLV) format. Cisco NX-OS switches support the Converged Enhanced Ethernet Data Center Bridging Exchange (CEE-DCBX) is supported on all T11-compliant Generation 2 CNAs.

DCBX runs on the physical Ethernet link between the switch and the CNA. By default, DCBX is enabled on Ethernet interfaces. When an Ethernet interface is brought up, the switch automatically starts to communicate with the CNA.

During the normal operation of FCoE between the switch and the CNA, DCBX provides link-error detection.

DCBX is also used to negotiate capabilities between the switch and the CNA and to send configuration values to the CNA.

The CNAs that are connected to a switch are programmed to accept the configuration values that are sent by the switch, allowing the switch to distribute configuration values to all attached CNAs, which reduces the possibility of configuration errors and simplifies CNA administration.

Lossless Ethernet

Standard Ethernet is a best-effort medium which means that it lacks any form of flow control. In the event of congestion or collisions, Ethernet drops packets. The higher level protocols detect the missing data and retransmit the dropped packets.

To properly support Fibre Channel, Ethernet has been enhanced with a priority flow control (PFC) mechanism.

Logical Link Up/Down

On a native Fibre Channel link, some configuration actions (such as changing the VSAN) require that you reset the interface status. When you reset the interface status, the switch disables the interface and then immediately reenables the interface.

Caution:

If an Ethernet link provides FCoE service, do not reset the physical link because this action is disruptive to all traffic on the link.

The logical link up/down feature allows the switch to reset an individual virtual link. The logical link down is signaled with a FIP Clear Virtual Link message.

Caution:

If the CNA does not support the logical link level up/down feature, the CNA resets the physical link, which means that all traffic on the Ethernet interface is disrupted.

Converged Network Adapters

Cisco NX-OS switches support the following CNA types:

- Hardware adapter
 - Works with the existing Fibre Channel host bus adapter (HBA) driver and Ethernet Network Interface Card (NIC) driver in the server.
 - Server operating system view of the network is unchanged; the CNA presents a SAN interface and a LAN interface to the operating system.
- FCoE software stack
 - Runs on existing 10-Gigabit Ethernet adapters.

The following Cisco NX-OS series and platforms support Generation 2 CNAs that use the FIP to exchange information about its available capabilities and to negotiate the configurable values with the switch:

To reduce configuration errors and simplify administration, the switch distributes the configuration data to all the connected adapters.

STP Lite

FCoE does not require full Spanning Tree Protocol (STP) because FCoE has no bridging functionality, which means that no STP loops are created in the network. STP Lite on FCoE interfaces ensures rapid convergence across the network by sending an agreement Bridge Protocol Data Unit (BPDU) whenever it receives a proposal BPDU. The FCoE link sends the identical agreement BPDU in response to either a Multiple Spanning Tree (MST) or a Per VLAN Rapid Spanning Tree Plus (PVRST+) proposal BPDU. Additionally, STP Lite suppresses the MAC address flushing function for FCoE VLANs.

STP Lite is enabled automatically by default across the entire device for FCoE VLANs as soon as the first FCoE VLAN comes up. At the same time, the system automatically converts all FCoE links as the STP-type normal ports. This feature runs only in FCoE VLANs.

Default Settings for FCoE

This table lists the default settings for FCoE parameters.

Table 2: Default FCoE Parameter Settings

Parameters	Default
FCoE feature	Not installed, disabled
FC-Map	0E.FC.00
Fabric priority	128
Advertisement interval	8 seconds

Guidelines and Limitations

Enabling and Disabling FCoE

Configuring the FC-Map

You can prevent data corruption due to cross-fabric talk by configuring an FC-Map that identifies the Fibre Channel fabric for this switch. When the FC-Map is configured, the switch discards the MAC addresses that are not part of the current fabric. An FCF can assign Fabric Provide MAC Addresses (FPMA) to the CNAs consisting of the FC-Map Value for the Fabric and the Fibre Channel ID (FCID) assigned during Fabric Login



Note In most deployments, changing the fc-map is not needed. We recommend that you use VSAN to VLAN mapping. For more information, see the [Mapping a VSAN to a VLAN](#) chapter.

Step 1 **configure terminal**

Example:

```
fcoe# configure terminal
fcoe(config)#
```

Enters configuration mode.

Step 2 **fcoe fcmap fabric-map**

Example:

```
fcoe(config)# fcoe fcmap 0x0efc2a
```

Configures the global FC-Map. The default value is 0x0EFC00. The range is from 0x0EFC00 to 0x0EFCFF. Use the **no fcoe map** command to reset to the default value.

Example

Configuring the Fabric Priority

The FCoE switch advertises its priority. The priority is used by the CNAs in the fabric to determine the best switch to connect to.

Step 1 **configure terminal**

Example:

```
fcoe# configure terminal
fcoe(config)#
```

Enters configuration mode.

Step 2 **fcoe fcf-priority fabric-priority**

Example:

```
fcoe(config)# fcoe fcf-priority 42
```

Configures the global fabric priority. The default value is 128. The range is from 0 (higher) to 255 (lower). Use the **no fcoe fcf-priority** command to reset the global fabric priority to the default value.

Example

Setting the Advertisement Interval

You can configure the interval for Fibre Channel fabric advertisement on the switch.

Step 1 **configure terminal**

Example:

```
fcoe# configure terminal
fcoe(config)#
```

Enters configuration mode.

Step 2 **fcoe fka-adv-period interval**

Example:

```
fcoe(config)# fcoe fka-adv-period 8
fcoe#
```

Configures the advertisement interval for the fabric. The default value is 8 seconds. The range is from 4 to 60 seconds.

Example

Disabling LAN Traffic on an FCoE Link

You can disable LAN traffic on an FCoE link.

DCBX allows the switch to send a LAN Logical Link Status (LLS) message to a directly-connected CNA. Enter the **shutdown lan** command to send an LLS-Down message to the CNA. This command causes all VLANs on the interface that are not enabled for FCoE to be brought down. If a VLAN on the interface is enabled for FCoE, it continues to carry SAN traffic without any interruption.

Step 1 **configure terminal**

Example:

```
switch# configure terminal
switch(config)#
```

Enters configuration mode.

Step 2 **interface ethernet *slot/port***

Example:

```
switch(config)# interface e 2/1
switch(config-if)#
```

Specifies an interface to configure, and enters interface configuration mode. Use ? to view a list of supported interfaces.

Step 3 **shutdown lan**

Example:

```
switch(config-if)# shutdown lan
```

Shuts down Ethernet traffic on the interface. If the interface is part of an FCoE VLAN, the shutdown has no impact on the FCoE traffic. Use **no shutdown lan** to reenable Ethernet traffic on this interface.

Step 4 (Optional) **show interface**

Example:

```
switch(config-if)# show interface
```

Displays information about the interface.

Step 5 (Optional) **copy running-config startup-config**

Example:

```
switch(config-if)# copy running-config startup-config
```

Copies the running configuration to the startup configuration.

Additional References for FCoE

Related Documents

Related Topic	Document Title
Command reference	Cisco NX-OS FCoE Command Reference Guide, Nexus 7000 and MDS 9500
Configuration guide	
Cisco NX-OS licensing	

Standards and RFCs

Standard/RFC	Title
T11 FC BB-5	Fibre Channel Backbone 5

MIBs

MB	MIBs Link
	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	http://www.cisco.com/support



CHAPTER 4

Configuring FCoE VLANs and Virtual Fibre Channel Interfaces

- [Information About Virtual Fibre Channel \(VFC\) Interfaces, on page 13](#)
- [Default Settings for FCoE, on page 14](#)
- [Guidelines and Limitations, on page 14](#)
- [Configuring Virtual Interfaces, on page 14](#)
- [Verifying the Virtual Fibre Channel Interface , on page 20](#)
- [Example:Mapping VSANs to VLANs , on page 22](#)
- [Verifying the FCoE Configuration, on page 23](#)
- [Additional References for FCoE, on page 24](#)

Information About Virtual Fibre Channel (VFC) Interfaces

Fibre Channel over Ethernet (FCoE) allows Fibre Channel and Ethernet traffic to be carried on the same physical Ethernet connection between the switch and the servers.

The Fibre Channel portion of FCoE is configured as a virtual Fibre Channel interface. Logical Fibre Channel features (such as interface mode) can be configured on virtual Fibre Channel interfaces.

A virtual Fibre Channel (vfc) interface must be bound to an interface before it can be used. The binding is to a physical Ethernet interface when the converged network adapter (CNA) is directly connected to the switch or port channel when the CNA connects to the Fibre Channel Forwarder (FCF) over a virtual port channel (vPC).

VF Port

A virtual fabric (VF) port in an FCoE network acts as a fabric port that connects to a peripheral device (host or disk) operating as an N port. A VF port can be attached to only one N port.

VE Port

A virtual expansion (VE) port acts as an expansion port in an FCoE network. VE ports can connect multiple FCoE switches together in the network. You can bind a VE port to a physical ethernet port or a port channel.

Traffic is load balanced across equal cost E_Ports and VE_Ports based on SID, DID, and OXID. Traffic across members of a port channel that a VE_Port is bound to is load balanced based on SID, DID, and OXID.

VNP Ports

Connectivity from an FCoE NPV bridge to the FCF is supported only over point-to-point links. These links can be individual Ethernet interfaces or port channel interfaces. For each FCF connected to an Ethernet/port-channel interface, a vFC interface must be created and bound to it. These vFC interfaces must be configured as VNP ports.

On the VNP port, the FCoE NPV bridge emulates an FCoE-capable host with multiple FCoE nodes (ENodes), each with a unique ENodes MAC address. By default, the VNP port is enabled in trunk mode.

Multiple VSANs can be configured on the VNP port. The FCoE VLANs that correspond to the VNP port VSANs must be configured on the bound Ethernet interface.

Default Settings for FCoE

This table lists the default settings for FCoE parameters.

Table 3: Default FCoE Parameter Settings

Parameters	Default
FCoE feature	Not installed, disabled
FC-Map	0E.FC.00
Fabric priority	128
Advertisement interval	8 seconds

Guidelines and Limitations

Configuring Virtual Interfaces

Mapping a VSAN to a VLAN

A unique, dedicated VLAN must be configured at every converged access switch to carry traffic for each virtual fabric (VSAN) in the SAN (for example, VLAN 1002 for VSAN 10, VLAN 1003 for VSAN 2, and so on). If you enable MST, you must use a separate Multiple Spanning Tree (MST) instance for FCoE VLANs.

Before you begin

- Ensure you have installed the correct license for FCoE.
- Ensure you have enabled FCoE.

Step 1 **configure terminal****Example:**

```
switch# configure terminal
switch(config)#
```

Enters configuration mode.

Step 2 **vsan database****Example:**

```
switch(config)# vsan database
switch(config-vsan-db)#
```

Enters VSAN database configuration mode.

Step 3 **vsan *vsan-id*****Example:**

```
switch(config-vsan-db)# vsan 200
```

Defines the VSAN. The VSAN number range is from 1 to 4094.

Step 4 **vlan *vlan-id*****Example:**

```
switch(config-vsan-db)# vlan 200
switch(config-vlan)#
```

Enters VLAN configuration mode. The VLAN number range is from 1 to 4096.

Step 5 **fcoe [*vsan vsan-id*]****Example:**

```
switch(config-vlan)# fcoe vsan 200
```

Enables FCoE for the specified VLAN and configures the mapping from this VLAN to the specified VSAN. If you do not specify a VSAN number, a mapping is created from this VLAN to the VSAN with the same number.

Step 6 **exit****Example:**

```
switch(config-vlan)# exit
switch(config)#
```

Step 7 (Optional) **show vlan fcoe****Example:**

```
switch(config-vlan)# show vlan fcoe
```

Displays information about the FCoE configuration for a VLAN.

Step 8 (Optional) **copy running-config startup-config****Example:**

```
switch(config-vlan)# copy running-config startup-config
```

Copies the running configuration to the startup configuration.

Example

Creating a Virtual Fibre Channel Interface

To use FCoE, you must first create Virtual Fibre Channel (VFC) interfaces. Then, you must bind the VFC interfaces to physical interfaces before FCoE can be used.

Before you begin

- Ensure you have installed the correct license for FCoE.
 - Ensure you have enabled FCoE.
-

Step 1 **configure terminal**

Example:

```
switch# configure terminal
switch(config)#
```

Enters configuration mode.

Step 2 **interface vfc vfc-id**

Example:

```
switch(config)# interface vfc 4
switch(config-if)#
```

Creates a virtual Fibre Channel interface (if it does not already exist) and enters interface configuration mode. The *vfc-id* range is from 1 to 8192.

Step 3 **switchport mode mode**

Example:

```
switch(config-if)# switchport mode e
```

Configures the switchport mode for a virtual Fibre Channel interface. The *mode* is E or F. The default is F mode.

Step 4 **bind {interface {ethernet slot/port | ethernet-port-channel number}}**

Example:

```
switch(config-if)# bind interface ethernet 1/4
```

Binds the virtual Fibre Channel interface to the specified interface. Use ? to see the supported interfaces and port channels. Use the **no** form of this command to unbind the virtual Fibre Channel interface from the specified interface.

Step 5 (Optional) **show interface vfc**

Example:

```
switch(config-if)# show interface vfc
```

Displays information about the virtual Fibre Channel interfaces.

Step 6 (Optional) **copy running-config startup-config**

Example:

```
switch(config)# copy running-config startup-config
```

Copies the running configuration to the startup configuration.

Example

This example shows how to bind a virtual Fibre Channel interface to an Ethernet interface:

```
switch# configure terminal
switch(config)# interface vfc 4
switch(config-if)# bind interface ethernet 1/4
```

This example shows how to delete a virtual Fibre Channel interface:

```
switch# configure terminal
switch(config)# no interface vfc 4
```

Creating a Virtual Fibre Channel Port Channel Interface

You can create a virtual Fibre Channel port channel interface that automatically binds to the port channel with the same interface number.

Step 1 **configure terminal**

Example:

```
switch# configure terminal
switch(config)#
```

Enters configuration mode.

Step 2 **interface vfc-port-channel *int-number***

Example:

```
switch(config)# interface vfc-port-channel 2
switch(config-if)#
```

Creates a virtual Fibre Channel interface (if it does not already exist) that is bound to the port channel with the same interface number and enters interface configuration mode.

The default switchport mode for this interface is E.

Step 3 **switchport mode *mode***

Example:

```
switch(config-if)# switchport mode e
```

Configures the switchport mode for a virtual Fibre Channel interface. The *mode* is E or F. The default is F mode.

Step 4 (Optional) **show interface vfc-port-channel** *int-number*

Example:

```
switch(config-if)# show interface vfc-port-channel 2
```

Displays information about the virtual Fibre Channel interfaces bound to port channel interfaces.

Step 5 (Optional) **copy running-config startup-config**

Example:

```
switch(config)# copy running-config startup-config
[#####] 100%
Copy complete.
```

Copies the running configuration to the startup configuration.

Step 6 (Optional) **show running-config interface vfcid/slot**

Example:

```
awitch# show running-config interface vfc-po540
!Command: show running-config interface vfc-po540
!Time: Fri Dec 2 15:36:07 2016
```

```
version 7.3(0)D1(1)
```

```
interface vfc-po540
bind interface ethernet-port-channel1540
switchport mode E
no shutdown
```

Displays the virtual Fibre Channel interface configuration information.

Associating a Virtual Fibre Channel Interface to a VSAN

You must configure unique, dedicated VLAN at every converged access switch to carry traffic for each Virtual Fabric (VSAN) in the SAN (for example, VLAN 1002 for VSAN 1, VLAN 1003 for VSAN 2, and so on). If you enable MST, you must use a separate MST instance for FCoE VLANs.

Step 1 **configure terminal**

Example:

```
switch# configure terminal
switch(config)#
```

Enters configuration mode.

Step 2 **vsan database**

Example:

```
switch(config)# vsan database
switch(config-vsan-db)#
```

Enters VSAN configuration mode.

Step 3 (Optional) **vsan vsan-id**

Example:

```
switch(config-vsan-db)# vsan 2
```

Creates the VSAN. The *vsan-id* range is from 1 to 4094 and must map to a VLAN on the physical Ethernet interface that is bound to the virtual Fibre Channel interface.

Step 4 Enter one of the following commands:

- **vsan** *vsan-id* **interface vfc** *vfc-id*
- **vsan** *vsan-id* **interface vfc-port-channel** *vfc-id*

Example:

```
switch(config-vsan-db)# vsan 2 interface vfc 4
```

Configures the association between the VSAN and virtual Fibre Channel interface or virtual Fibre Channel port channel. The *vsan-id* range is from 1 to 4094 and must map to a VLAN on the physical Ethernet interface or port channel that is bound to the virtual Fibre Channel interface or virtual Fibre Channel port channel. The *vfc-id* range is from 1 to 8192. Use the **no** form of this command to disassociate the connection between the VSAN and virtual Fibre Channel interface or virtual Fibre Channel port channel.

Step 5 (Optional) **show vsan**

Example:

```
switch(config-vsan-db)# show vsan
```

Displays information about the VSAN.

Step 6 (Optional) **copy running-config startup-config**

Example:

```
switch(config-vsan-db)# copy running-config startup-config
```

Copies the running configuration to the startup configuration.

Example

This example shows how to associate a virtual Fibre Channel interface to a VSAN:

```
switch# configure terminal
switch(config)# vsan database
switch(config-vsan-db)# vsan 2 interface vfc 4
```

Enabling VE Loopback Configuration

The VFID check verifies that the VSAN configuration is correct on both ends of a VE link. You can turn off the VFID check for VE ports to allow VE loopback configuration between to VE ports on the same switch.

Step 1 **configure terminal**

Example:

```
fcoe# configure terminal
fcoe(config)#
```

Enters configuration mode.

Step 2 fcoe vloopback

Example:

```
fcoe(config)# fcoe vloopback
```

Enables the VFID check for all VE ports.

Example

Verifying the Virtual Fibre Channel Interface

To display configuration information about virtual Fibre Channel interfaces, perform one of the following tasks:

Command	Purpose
show interface vfc <i>vfc-id</i>	Displays the detailed configuration of the specified Fibre Channel interface.
show interface brief	Displays the status of all interfaces.
show vlan fcoe	Displays the mapping of FCoE VLANs to VSANs.

This example shows how to display a virtual Fibre Channel interface bound to an Ethernet interface:

```
switch# show interface vfc 3
```

```
vfc3 is up
```

```
Bound interface is Ethernet1/37
```

```
Hardware is Virtual Fibre Channel
```

```
Port WWN is 20:02:00:0d:ec:6d:95:3f
```

```
Admin port mode is F, trunk mode is on
```

```
snmp link state traps are enabled
```

```
Port mode is F, FCID is 0x490100
```

```
Port vsan is 931
```

```
1 minute input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
```

```
1 minute output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
```

```
0 frames input, 0 bytes
```

```
0 discards, 0 errors
```

```
0 frames output, 0 bytes
```

```
0 discards, 0 errors
```

```
Interface last changed at Thu May 21 04:44:42 2009
```

This example shows how to display the status of all the interfaces on the switch (some output has been removed for brevity):

```
switch# show interface brief
```

```
-----
```

Interface	Vsan	Admin Mode	Admin Trunk Mode	Status	SFP	Oper Mode	Oper Speed (Gbps)	Port Channel
fc3/1	1	auto	on	trunking	sw1	TE	2	--
fc3/2	1	auto	on	sfpAbsent	--	--		--
...								
fc3/8	1	auto	on	sfpAbsent	--	--		--

```
-----
```

```
-----
```

Interface	Status	IP Address	Speed	MTU	Port Channel
Ethernet1/1	hwFailure	--	--	1500	--
Ethernet1/2	hwFailure	--	--	1500	--
Ethernet1/3	up	--	10000	1500	--
...					
Ethernet1/39	sfpIsAbsen	--	--	1500	--
Ethernet1/40	sfpIsAbsen	--	--	1500	--

```
-----
```

```
-----
```

Interface	Status	IP Address	Speed	MTU
mgmt0	up	172.16.24.41	100	1500

```
-----
```

```
-----
```

Interface	Vsan	Admin Mode	Admin Trunk Mode	Status	SFP	Oper Mode	Oper Speed (Gbps)	Port Channel
vfc 1	1	F	--	down	--	--		--
...								

```
-----
```

This example shows how to display the mapping between the VLANs and VSANs on the switch:

```
switch# show vlan fcoe
```

```
VLAN      VSAN      Status
```

```

-----  -----  -----
15      15      Operational
20      20      Operational
25      25      Operational
30      30      Non-operational

```

Example: Mapping VSANs to VLANs

The following example shows how to configure the FCoE VLAN and a virtual Fibre Channel interface:

Step 1 Enable the associated VLAN and map the VLAN to a VSAN.

```

switch(config)# vlan 200
switch(config-vlan)# fcoe vsan 200
switch(config-vlan)# exit

```

Step 2 Configure the VLAN on a physical Ethernet interface.

```

switch# configure terminal
switch(config)# interface ethernet 1/4
switch(config-if)# spanning-tree port type edge trunk
switch(config-if)# switchport mode trunk
switch(config-if)# switchport trunk allowed vlan 1,200
switch(config-if)# exit

```

Step 3 Create a virtual Fibre Channel interface and bind it to a physical Ethernet interface.

```

switch(config)# interface vfc 4
switch(config-if)# bind interface ethernet 1/4

```

Note By default, all virtual Fibre Channel interfaces reside on VSAN 1. If the VLAN to VSAN mapping is to a VSAN other than VSAN 1, then proceed to Step 4.

Step 4 Associate the virtual Fibre Channel interface to the VSAN.

```

switch(config)# vsan database
switch(config-vsan)# vsan 200 interface vfc 4
switch(config-vsan)# exit

```

Step 5 (Optional) Display membership information for the VSAN.

```

switch# show vsan 200 membership
vsan 200 interfaces
    vfc 4

```

Step 6 (Optional) Display the interface information for the virtual Fibre Channel interface.

```

switch# show interface vfc 4

vfc4 is up

```



```

Bound interface is Ethernet1/4
Hardware is Virtual Fibre Channel
Port WWN is 20:02:00:0d:ec:6d:95:3f
Port WWN is 20:02:00:0d:ec:6d:95:3f
snmp link state traps are enabled
Port WWN is 20:02:00:0d:ec:6d:95:3f
APort WWN is 20:02:00:0d:ec:6d:95:3f
snmp link state traps are enabled
Port mode is F, FCID is 0x490100
Port vsan is 200
1 minute input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
1 minute output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
0 frames input, 0 bytes 0 discards, 0 errors
0 frames output, 0 bytes 0 discards, 0 errors
Interface last changed at Thu Mar 11 04:44:42 2010

```

Verifying the FCoE Configuration

To display FCoE configuration information, perform one of these tasks in the context of storage VDC:

Command	Purpose
show fcoe	Displays whether FCoE is enabled on the switch.
show fcoe database	Displays the contents of the FCoE database. Note This command is effective when interfaces are configured.
show interface vfc [number]	Displays information about the vFC interfaces.
show interface [interface number] fcoe	Displays the FCoE settings for an interface or all interfaces.

This example shows how to verify that the FCoE capability is enabled:

```

switch# show fcoe
Global FCF details
  FCF-MAC is 00:0d:ec:6d:95:00
  FC-MAP is 0e:fc:00
  FCF Priority is 128
  FKA Advertisement period for FCF is 8 seconds

```

This example shows how to display the FCoE database:

```
switch# show fcoe database
```

```
-----
INTERFACE          FCID          PORT NAME          MAC ADDRESS
-----
vfc3                0x490100     21:00:00:1b:32:0a:e7:b8 00:c0:dd:0e:5f:76
```

This example shows how to display the FCoE settings for an interface.

```
switch# show interface ethernet 1/37 fcoe
Ethernet1/37 is FCoE UP
  vfc3 is Up
    FCID is 0x490100
    PWWN is 21:00:00:1b:32:0a:e7:b8
    MAC addr is 00:c0:dd:0e:5f:76
```

Additional References for FCoE

Related Documents

Related Topic	Document Title
Command reference	Cisco NX-OS FCoE Command Reference Guide, Nexus 7000 and MDS 9500
Configuration guide	
Cisco NX-OS licensing	

Standards and RFCs

Standard/RFC	Title
T11 FC BB-5	Fibre Channel Backbone 5

MIBs

MB	MIBs Link
	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	http://www.cisco.com/support



CHAPTER 5

Storage VDC

This chapter contains the following sections:

- [Information About Storage VDC, on page 27](#)
- [Licensing Requirements for FCoE, on page 28](#)
- [Configuring FCoE VDCs, on page 28](#)
- [Example: Storage VDC Configuration, on page 34](#)

Information About Storage VDC

You use a storage virtual device context (VDC) to separate LAN and SAN traffic on the same switch. A VDC allows you to maintain one physical infrastructure but separate logical data paths.

To achieve this configuration, you must perform the following tasks:

- Create a dedicated storage VDC.
- Allocate physical ports to the storage VDC. These can be either ports dedicated to only the storage VDC or ports that are shared between the storage VDC and one other VDC. Dedicated ports can be used to create either VFC E ports (VE ports) or F ports (VF ports). Shared ports can only be used for VFC F ports (VF ports).

Once you share the port to the storage VDC you can create a VFC F-port on top of the shared interface. You cannot modify some details of that port because it must match the underlying shared physical port. If you move the source port to another VDC or delete the VDC, the shared ports are deleted and you must reconfigure them.



Note If the storage VDC restarts or is suspended, any shared Ethernet ports are shut down in the corresponding VDC. These ports come up automatically once the storage VDC is operational.

Licensing Requirements for FCoE

Product	License
Cisco Nexus 7000 Series	Each F Series module that runs FCoE requires an FCoE license. FCoE enabled in a nondefault VDC does not require the Advanced Services License. By default, FCoE does not require an additional VDC and is enabled in the storage VDC. For a complete explanation of the Cisco NX-OS licensing scheme and how to obtain and apply licenses, see the Cisco NX-OS Licensing Guide .

Configuring FCoE VDCs

Licensing an FCoE Module

You must associate an FCoE license with an FCoE module to configure FCoE. You need one license for each module configured for FCoE.

Before you begin

Ensure you have installed the correct license for FCoE.

SUMMARY STEPS

1. **configure terminal**
2. **license fcoe module** *module-number*
3. (Optional) **show license usage** *module-name*
4. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters configuration mode.
Step 2	Required: license fcoe module <i>module-number</i> Example: <pre>switch(config)# license fcoe module 2</pre>	Associates an FCoE license to a module.

	Command or Action	Purpose
Step 3	(Optional) show license usage <i>module-name</i> Example: swtich(config)# show license usage FCOE-N7K-F132XP	Displays the line card usage used by a storage VDC. For details on license packages, see Cisco NX-OS Licensing Guide .
Step 4	(Optional) copy running-config startup-config Example: swtich(config)# copy running-config startup-config	Copies the running configuration to the startup configuration.

Creating a Dedicated Storage VDC



Note Commands from step 1 to step 7 are performed in the admin VDC.
Commands from step 8 to step 11 are performed in the storage VDC.

Before you begin

- Ensure you have installed the correct license for FCoE.



Note VE ports must exist on dedicated interfaces. VF ports can exist on either dedicated or shared interfaces.

SUMMARY STEPS

1. **configure terminal**
2. **install feature-set fcoe**
3. **system qos**
4. **service-policy type network-qos *policy-map name***
5. **vdc *vdc-name* type storage**
6. **allocate interface ethernet *int-numb***
7. **switchto vdc *vdc-name***
8. **feature lldp**
9. (Optional) **feature lacp**
10. (Optional) **show feature-set**
11. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example:	Enters configuration mode.

	Command or Action	Purpose
	<pre>switch# configure terminal switch(config)#</pre>	
Step 2	<p>install feature-set fcoe</p> <p>Example:</p> <pre>switch(config)# install feature-set fcoe</pre>	Installs the FCoE feature-set.
Step 3	<p>system qos</p> <p>Example:</p> <pre>switch(config)# system qos switch(config-sys-qos)#</pre>	Enters system qos mode.
Step 4	<p>service-policy type network-qos <i>policy-map name</i></p> <p>Example:</p> <pre>switch(config-sys-qos)#service-policy type network-qos default-nq-7e-policy</pre>	<p>Enables no drop queue for FCoE class.</p> <p>Note The Cisco MDS 9250i Multiservice Fabric Switch follows a different naming convention which reflects how many ingress queues and egress queues are there in a policy. The name is different, but it is same as the MDS policy. 7e policy is default in MDS and Cisco MDS 9250i Multiservice Fabric Switch, hence it is not shown in show running-config command. The 7e policy is not default in Cisco Nexus 7000 Series Switches, hence it is shown in the show running-config command.</p>
Step 5	<p>vdc <i>vdc-name</i> type storage</p> <p>Example:</p> <pre>switch(config)# vdc fcoe-vdc type storage switch(config-vdc)#</pre>	<p>Creates a dedicated storage VDC and enters VDC configuration mode. You can only enable storage features in a storage VDC. You do not need to allow the feature-set or enable it in the storage VDC because this process is handled automatically for a storage VDC.</p> <p>Note It is expected that, if feature-set fex is not enabled, "allocate share fex" will fail, on VDC reload. User has to un-configure the share and configure it back .</p>
Step 6	<p>allocate interface ethernet <i>int-numb</i></p> <p>Example:</p> <pre>switch(config-vdc)# allocate interface ethernet 2/1-2 switch(config-if)#</pre>	Allocates interfaces to the storage VDC as a dedicated FCoE port. You must allocate all interfaces in the port group. You must configure these interfaces in switchport trunk mode as Spanning Tree Protocol (STP) edge ports.
Step 7	<p>switchto vdc <i>vdc-name</i></p> <p>Example:</p> <pre>switch(config-vdc)# switchto vdc fcoe-vdc switchport switch-fcoe-vdc#</pre>	Switches to the storage VDC.

	Command or Action	Purpose
Step 8	feature lldp Example: switch(config)# feature lldp	Enables the LLDP feature in the storage VDC.
Step 9	(Optional) feature lacp Example: switch(config)# feature lacp	Enables the LACP feature in the storage VDC.
Step 10	(Optional) show feature-set Example: switch# show feature-set Feature Set Name ID State ----- fcoe 2 enabled fex 3 disabled switch#	Displays the status information about the feature-sets in this VDC.
Step 11	(Optional) copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.

Allocating the FCoE VLAN Range

Before you begin

- Ensure you have installed the correct license for FCoE.
- Ensure you are in the correct VDC.

SUMMARY STEPS

1. **configure terminal**
2. **vdc vdc-name type storage**
3. **allocate fcoe-vlan-range vlan-range [from vdc vdc-name]**
4. (Optional) **show vdc fcoe-vlan-range**
5. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters configuration mode.

	Command or Action	Purpose
Step 2	vdc vdc-name type storage Example: switch(config)# vdc fcoe-vdc type storage switch(config-vdc) #	Enters VDC configuration mode. You can only enable storage feature in a storage VDC. You do not need to allow the feature-set or enable it in the storage VDC because this process is handled automatically for a storage VDC.
Step 3	allocate fcoe-vlan-range vlan-range [from vdc vdc-name] Example: switch(config-vdc) # allocate fcoe-vlan-range 10-30	Allows the VLAN to be used in the storage VDC-I; and allocates the VLANs that can be used for FCoE and mapped to a VSAN. You can optionally allocate the VLANs from another VDC.
Step 4	(Optional) show vdc fcoe-vlan-range Example: switch(config-vdc) # show vdc fcoe-vlan-range	Displays information about the VLAN range allocated for FCoE.
Step 5	(Optional) copy running-config startup-config Example: switch(config-vdc) # copy running-config startup-config	Copies the running configuration to the startup configuration.

Allocating Shared Interfaces

You can share interfaces between a storage VDC and another VDC.

Before you begin

- Ensure you have installed the correct license for FCoE.
- Ensure you are in the correct VDC.
- Ensure any shared interfaces are from an F-series module.
- Ensure you have allocated the FCoE VLAN range.
- Interfaces can only be shared between the storage VDC and one other VDC.



Note

- For shared interface, ensure that LLDP feature is enabled in parent VDC also.
- Only VF ports can exist on shared interfaces. VE ports must be on dedicated interfaces.

SUMMARY STEPS

1. **configure terminal**
2. **interface if-range**
3. **switchport mode trunk**

4. **spanning-tree port type edge trunk**
5. **no shutdown**
6. **vdc vdc-name type storage**
7. **allocate shared interface if-range**
8. (Optional) **show vdc shared membership**
9. (Optional) **switchto vdc vdc-name**
10. **configure terminal**
11. **feature lldp**
12. **interface if-range**
13. **no shutdown**
14. (Optional) **show interface if-range**
15. (Optional) **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters configuration mode.
Step 2	interface if-range Example: <pre>switch(config)# interface ethernet 2/1</pre>	Enters interface configuration mode for the interface in the Ethernet VDC.
Step 3	switchport mode trunk Example: <pre>switch(config-if)# switchport mode trunk</pre>	Puts the Ethernet interface into trunk mode.
Step 4	spanning-tree port type edge trunk Example: <pre>switch(config-if)# spanning-tree port type edge trunk</pre>	Sets the interface to STP-type edge port to support STP Lite for loop prevention.
Step 5	no shutdown Example: <pre>switch(config-if)# no shutdown</pre>	Administratively enables the Ethernet shared interface.
Step 6	vdc vdc-name type storage Example: <pre>switch(config-if)# vdc fcoe-vdc type storage switch(config-vdc)#</pre>	Enters VDC configuration mode.
Step 7	allocate shared interface if-range Example: <pre>switch(config-vdc)# allocate shared interface ethernet 2/1</pre>	Allocates interfaces that are shared with another VDC for FCoE traffic. You must allocate the shared interfaces to one of the VDC included in the FCoE VLAN allocation. You can only use the shutdown or the switchport trunk

	Command or Action	Purpose
		allowed vlan commands on shared interfaces in the storage VDC.
Step 8	(Optional) show vdc shared membership Example: switch(config-vdc)# show vdc shared membership	Displays the interfaces that are shared for FCoE.
Step 9	(Optional) switchto vdc vdc-name Example: switch(config-vdc)# switchto vdc fcoe-vdc switch-fcoe-vdc#	Switches to the storage VDC.
Step 10	configure terminal Example: switch-fcoe-vdc# configure terminal switch-fcoe-vdc(config)#	Enters configuration mode.
Step 11	feature lldp Example: switch-fcoe-vdc(config)# feature lldp	Enables the LLDP feature in the storage VDC.
Step 12	interface if-range Example: switch-fcoe-vdc(config)# interface ethernet 2/1	Enters interface configuration mode for the shared interface in the storage VDC.
Step 13	no shutdown Example: switch-fcoe-vdc(config-if)# no shutdown	Administratively enables the FCoE shared interface.
Step 14	(Optional) show interface if-range Example: switch-fcoe-vdc(config-if)# show interface ethernet 2/1	Displays information about the shared interface.
Step 15	(Optional) copy running-config startup-config Example: switch-fcoe-vdc(config-if)# copy running-config startup-config	Copies the running configuration to the startup configuration.

Example: Storage VDC Configuration

Ethernet VDC Configuration

```
!Enable the interface to share:
switch(config-sys-qos)# interface ethernet 2/1
```

```
!Initially ethernet 2/1 is allocated to ethernet VDC
switch(config-if)# switchport
switch(config-if)# switchport mode trunk

!Allocate resources in admin VDC:
Switch(conf)# vdc storage fcoe_vdc
switch(config-if)# allocate fcoe-vlan-range 10-20 from vdc switch
switch(config-vdc)# allocate shared interface ethernet 2/1
Switch(conf)# show vdc shared membership

!Switch to storage VDC and bring up the shared interface:
switch(config-vdc)# switchto vdc fcoe_vdc
switch-fcoe_vdc# configure terminal
switch-fcoe_vdc(config)# interface ethernet 2/1
switch-fcoe_vdc(config-if)# no shutdown

!A VFC interface is created on top of Ethernet interface. The VFC interface can be created
in 2 ways: implicit and explicit.

!Implicit:
switch-fcoe_vdc(config)# interface vfc 2/1
switch-fcoe_vdc(config-if)# switchport mode f

!Explicit:
switch-fcoe_vdc(config)# interface vfc2
switch-fcoe_vdc(config-if)# bind interface eth2/1
switch-fcoe_vdc(config-if)# switchport mode f
```



Note Ethernet 2/1 must be from an F-series module.



APPENDIX **A**

Feature History by Platform

This chapter contains the following sections:



APPENDIX **B**

Guidelines and Limitations

This chapter includes the following sections:

