



# Cisco TelePresence IP VCR 2200 Series Getting started

---

61-0003-07

---

# Contents

General information .....	3
About the Cisco TelePresence IP VCR .....	3
Package contents .....	3
Port and LED location .....	3
LED behavior .....	4
Connecting the VCR .....	6
Before you start .....	6
Step one: Connect power .....	6
Step two: Connect to Ethernet Port A .....	6
Initial configuration .....	7
Step one: Connect to the console port .....	7
Step two: Configure Ethernet Port A settings .....	7
Step three: Assign an IP address to the VCR (optional) .....	8
Step four: Discover the IP address of the VCR .....	8
Configuring the VCR .....	9
Step one: Log in to the VCR .....	9
Step two: Using an H.323 gatekeeper or SIP registrar (optional) .....	9
Step three: Add endpoints (optional) .....	10
Using the VCR .....	11
Checking for updates .....	12
Troubleshooting and technical support information .....	13
Using the event log to help solve a problem .....	13
Getting more help .....	13
Technical specifications .....	14
Antistatic precautions .....	14
Disclaimers and notices .....	15

## General information

### About the Cisco TelePresence IP VCR

The Cisco TelePresence IP VCR 2200 Series uses the latest purpose-built technology to record video and data from standard video conferencing equipment. The recordings can either be streamed live or played back on demand at multiple bit rates to a PC or any video conferencing endpoint.

### Package contents


The following items are included with the Video Conferencing Recorder (VCR). Verify that you have these items before installing the device:

- ▶ Cisco TelePresence IP VCR unit
- ▶ Console cable (blue)
- ▶ Power cable
- ▶ Rack mounting kit

### Port and LED location

Figure 1 shows the position of ports and LEDs on the VCR.

Figure 1: VCR front panel



## LED behavior

Table 1 describes the behavior of the LEDs.

Table 1: VCR LED behavior

LED	Color	Indicates
Compact Flash Activity	Flashing green	One of: <ul style="list-style-type: none"> <li>▶ the VCR is booting</li> <li>▶ a configuration change has been made</li> <li>▶ the configuration is being transferred by FTP</li> </ul>
Status	Green	The VCR is operating normally
Alarm	Red	The VCR is booting or has developed a fault, for example: <ul style="list-style-type: none"> <li>▶ temperature is outside normal limits</li> <li>▶ fan failure</li> <li>▶ battery failure of the internal clock</li> </ul> Refer to the web interface for more information about the problem (go to <b>Status &gt; Health</b> )
Hard Disk Activity	Flashing green	The VCR is reading from or writing to its hard disk
Hard Disk Recording	Red	The VCR is recording

Table 1: VCR LED behavior (continued)

<b>LED</b>	<b>Color</b>	<b>Indicates</b>
System Load	Green	The VCR is processing conference data. The LEDs represent the media processing load of the VCR. The column numbered 1 represents audio load. The other columns represent video DSP load. Media processing load is also displayed in the web interface: go to <b>Status &gt; General</b>
Ethernet Port Status, for each Ethernet port:		
FDX	Green	The link has been negotiated as a full-duplex link
Act	Green	Packets are being transmitted on this port
Link	Green	The speed of the link from this port, which is either 10, 100, or 1000 Mbps
Power	Blue	The VCR is receiving power

## Connecting the VCR

### Before you start



**IMPORTANT:** Before installing the VCR, you must read the safety information at <http://www.cisco.com/go/telepresence/safety>.

### Step one: Connect power

Connect the power connector on the rear of the unit to the power supply using the supplied power cable. (There is no On/Off switch.)

### Step two: Connect to Ethernet Port A

Connect an Ethernet cable from Ethernet Port A to an Ethernet switch (rather than a hub, to minimize interference from other devices on the network). The Ethernet port is a 10/100/1000 Mbps auto-sensing connection.



Only connect to Ethernet Port B if you need to connect the VCR to a second subnet.



Do not connect Ethernet Port A and Ethernet Port B to the same subnet.

## Initial configuration

### Step one: Connect to the console port

- 1 Ensure power is connected to the VCR and the Status LED is green.
- 2 Connect the console port of the VCR to the serial port of your PC using the blue RJ45 to DB9 cable supplied.
- 3 Use a serial terminal program, such as SecureCRT or HyperTerminal, to connect to the VCR. Set your terminal software to the following settings:
  - Baud rate: 38400
  - Data bits: 8
  - Parity: none
  - Stop bits: 1
  - Flow control: none
- 4 Press Enter and the following command prompt appears on the terminal:  
**IPVCR:>**

### Step two: Configure Ethernet Port A settings

The default setting for the VCR Ethernet ports is auto-sensing mode. If the switch ports to which you connect the VCR are not also set to auto-sensing mode, then you need to configure the VCR Ethernet ports to use the same speed and duplex mode.



Only connect to Ethernet Port B if you need to connect the VCR to a second subnet.



Both ends of the Ethernet connection must be configured in the same way. For example, either configure both ends of the link to be auto-sensing or configure both ends to operate at the same speed and duplex.



To establish a 1000Mbps connection, both ends of the link must be configured as auto-sensing.

- ▶ To configure Ethernet Port A, enter the following for auto-sensing mode:  
**etherstype auto**  
or to configure a speed and duplex, use the following command:  
**etherstype <10|100> <half|full>**
- ▶ To display the current configuration and status of the Ethernet ports, enter:  
**status**

For example, to configure a full-duplex 100Mbps link, enter:

```
etherstype 100 full
```



To establish a 1000Mbps connection, both ends of the link must be configured as auto-sensing.

### Step three: Assign an IP address to the VCR (optional)

The default setting for the VCR is to use DHCP to obtain an IP address. You can assign a static IP address if you prefer or if a DHCP server is not available.

If you want the IP address of the VCR to be assigned by your DHCP server, omit this step.

- ▶ To assign a static IP address, use the following command:  
**static <IP address> <netmask> <default gateway address>  
<DNS server address>**



If you do not have a DNS server, use 0.0.0.0 as the DNS server IP address.

For example, to assign an address of 192.168.1.2 where the default gateway is at 192.168.1.1, enter:

```
static 192.168.1.2 255.255.255.0 192.168.1.1 0.0.0.0
```

- ▶ To return to using DHCP after setting a static address, use the following command:  
**dhcp**

### Step four: Discover the IP address of the VCR

- 1 To display the current status of the IP address, enter: **status**  
If you have DHCP enabled on your network and you are allowing the VCR to acquire its address using DHCP, the IP address that has been acquired by Ethernet Port A will be shown; if you have assigned a static IP address, that is the address that will be shown.
- 2 Make a note of the IP address. You will use this to access the web interface of the unit.

## Configuring the VCR

### Step one: Log in to the VCR

All administration of the VCR is performed via the web interface.

To log in to the web interface of the VCR:

- 1 Use your browser to navigate to the IP address of the VCR (to discover the IP address, refer to the previous section).
- 2 Click **Click here to log in**, and then click **Change log in** and enter the user name **admin** with no password.



Cisco recommends that you change the admin account to use a password as soon as possible. To do that, go to **Users**, click the **admin** link, and provide the required user information.

### Step two: Using an H.323 gatekeeper or SIP registrar (optional)

Using an H.323 gatekeeper makes it easier for H.323 end-users to watch and make recordings using directory numbers rather than requiring them to know the IP address or host name of the VCR. Likewise, a SIP registrar makes it easier for SIP users to watch and make recordings.

To configure the VCR to use an H.323 gatekeeper:

- 1 In the web interface of the VCR, go to **Settings > Gatekeeper**.
- 2 Enable **H.323 gatekeeper usage** and configure the settings you require, using the online help for further assistance.
- 3 Click **Apply changes**.

To configure the VCR to use a SIP registrar:

- 1 In the web interface, go to **Settings > SIP**.
- 2 Configure the settings you require, using the online help for further assistance.
- 3 Click **Apply changes**.



Before you configure the VCR to use, and register recordings to, a SIP registrar, you must set up the VCR and its recordings on that SIP registrar.

## Step three: Add endpoints (optional)

You can define pre-configured endpoints. This means that when an end-user calls in to the VCR from an endpoint to watch a recording, the VCR will use the correct settings for that endpoint. It also means that when calling out to endpoints from the VCR, you choose the pre-configured endpoints from a list, rather than entering endpoint details every time.

To define pre-configured endpoints:

- 1 In the web interface of the VCR, go to **Endpoints**:
  - To add a H.323 endpoint, click **Add H.323**
  - To add a SIP endpoint, click **Add SIP**
- 2 Configure the endpoint settings you require, using the online help for further assistance.
- 3 Click **Add endpoint**.

## Using the VCR

There are a number of ways to create a recording:

- ▶ Call in to the VCR's auto attendant and select **Record this session** to record yourself. Refer to the online help for information on calling the auto attendant
- ▶ Call out and record. The VCR, via its web interface, calls out to an H.323 or SIP endpoint and records its media streams
- ▶ Call in to the VCR after it has been configured to record incoming calls by default. The setting for the default incoming call action is in **Settings > Connections**
- ▶ Call a specific gatekeeper ID or registered SIP extension that has been configured to trigger recording
- ▶ Call another endpoint through the VCR (a point-to-point call) via a prefix the VCR has registered with a gatekeeper or with a SIP registrar. This has the same effect as calling that endpoint directly, except that the VCR is also in the call and records both endpoints' media streams

Equally there are a number of ways to play back a recording:

- ▶ Call out and play. The VCR, via its web interface, calls out to a H.323 or SIP endpoint and plays back a recording to it
- ▶ Stream the recording to a user's desktop via a player application such as QuickTime
- ▶ Call in to the VCR's auto attendant and select the recording for play back
- ▶ Register the recording with a gatekeeper or SIP registrar and play it back by calling its registered gatekeeper ID or SIP extension

For further information about creating and viewing recordings, refer to the online help which is accessible from the VCR web interface and to the documentation on the web site.

## Checking for updates

It is a good idea to regularly check for updates to the main VCR software image. This section describes how to upgrade the VCR using the web. Note that you can also upgrade the VCR using FTP; this can be more reliable if you are upgrading the device remotely. Upgrading your device via FTP is described in the release notes that are available alongside the software images in the support section of the web site.

To check for, and download, updates:

- 1 Log in to the VCR web interface and go to **Status > General**.
- 2 Make a note of the software version that is currently installed.
- 3 Go to the support section of the web site and check if a more recent release is available for the VCR.
- 4 If a more recent release is available, download it and save it locally.

To upgrade the VCR:

- 1 Unzip the software release file that you downloaded.
- 2 In the VCR web interface, go to **Settings > Upgrade**.
- 3 In the **Main software image** section, click **Browse** and locate the unzipped file.
- 4 Click **Upload software image**. The browser begins uploading the file to the VCR, and a new browser window opens to indicate the progress of the upload. When finished, the browser window refreshes and indicates that the software upgrade is complete.
- 5 Go to **Settings > Shutdown** and shut down and restart the VCR.

## Troubleshooting and technical support information

### Using the event log to help solve a problem

You can use the event log to produce debugging information to assist technical support in solving any problems. Event logging capture filter topics are set by default to **Errors, warnings and information**. Do not change the capture filter topic level without the guidance of technical support.

### Getting more help

Cisco recommends registering your product at <http://www.tandberg.com/services/video-conferencing-product-registration.jsp> in order to receive notifications about the latest software and security updates. New feature and maintenance releases are published regularly, and we recommend that the VCR's software is always kept up to date.

If you experience any problems when configuring or using the VCR, consult the online help (available within the UI of your VCR) for an explanation of how its individual features and settings work. If you cannot find the answer you need, check on the web site at <http://www.tandberg.com/support> to make sure that the VCR is running the most up-to-date software and for further relevant documentation.

You or your reseller can get help from our support team by raising a case at <http://www.tandberg.com/support/video-conferencing-online-support.jsp>. Make sure you have the following information ready:

- ▶ The serial number and product model number of the unit
- ▶ The software build number which can be found on the product user interface
- ▶ Your contact email address or telephone number
- ▶ A full description of the problem

## Technical specifications

### Power requirements

Table 2: VCR ratings

Rating	Value
Nominal voltage	115V to 230V 50/60 Hz
Current rating	2A Maximum
Supply voltage range	100 to 240V 50/60 Hz

### Over-current protection

Ensure the supply to this unit is protected by a branch circuit protector rated by a maximum of 20A.



Caution — over-current devices must meet applicable national and local electrical safety codes and be approved for the intended application.

### Operating environment

The VCR must only be used within the following environmental conditions:

Table 3: Operating environment

Environment	Temperature	Humidity
Operating environment	0°C to 35°C	10% to 95% (non-condensing)
Non-operating environment	-10°C to 60°C	10% to 95% (non-condensing)
Optimum operating environment	21°C to 23°C	45% to 50% (non-condensing)

### Antistatic precautions

When servicing or removing components or connections, first attach an antistatic wrist strap to an appropriate Earth point.

## Disclaimers and notices

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© November 2010, Cisco Systems, Inc. All rights reserved.