

Cisco OptoStar II

Network Management System (NMS)

Installation and Operation Guide

Explanation of Warning and Caution Icons



Avoid personal injury and product damage! Do not proceed beyond any A 🕀 🔺 symbol until you fully understand the indicated conditions.

> The following warning and caution icons alert you to important information about the safe operation of this product:

This symbol indicates important operating or maintenance instructions.

You may find this symbol affixed to the product. This symbol indicates a live terminal where a dangerous voltage may be present; the tip of the flash points to the terminal device.

 $\left(\frac{1}{2}\right)$ You may find this symbol affixed to the product. This symbol indicates a protective ground terminal.

A You may find this symbol affixed to the product. This symbol indicates a chassis terminal (normally used for equipotential bonding).

<u>/</u><u>%</u>\ You may find this symbol affixed to the product. This symbol warns of a potentially hot surface.

You may find this symbol affixed to the product and in this document. This symbol indicates an infrared laser that transmits intensity-modulated light and emits invisible laser radiation or an LED that transmits intensitymodulated light.

Important

Please read this entire guide. If this guide provides installation or operation instructions, give particular attention to all safety statements included in this guide.

Trademark Acknowledgments

Cisco, Cisco Systems, the Cisco logo, the Cisco Systems logo, and ROSA are trademarks or registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries. To view a list of cisco trademarks, go to this URL: www.cisco.com/go/trademarks.

Third party trademarks mentioned are the property of their respective owners.

Publication Disclaimer

Cisco Systems, Inc. assumes no responsibility for errors or omissions that may appear in this publication. We reserve the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

Copyright

© 2013-2014 Cisco Systems, Inc. All rights reserved. Published in China.

Information in this publication is subject to change without notice. No part of this publication may be reproduced or transmitted in any form, by photocopy, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, for any purpose, without the express permission of Cisco Systems, Inc.

Contents

Chapter 1	Introduction	
Introduction	٦	1-3
	Description	
Chapter 2	Installation and Configuration	
Configuratio	on Requirements	2-2
	System Structure	
System Insta	allation	
	Database Installation	2-3
	Web Server Installation	2-4
	System Requirements	2-4
	Installation Procedures	2-4
	Polling Server Installation	2-7
	System Requirements	2-7
	Installation Procedures	2-7
Appendix I		
	Enable IIS in Windows 7	
Appendix II	[
	To Enable Remote Connections in SQL Server	2-12
Chapter 3	Operation	
Before You	Begin	
	Before You Begin	
	Start	
Functions		
	System Login	
	System Main Interface	
	Topology Management	
	Topology Tree	
	Alarm Management	
	Untreated Alarm Management	
	History Alarm Management	
	Performance Management	
	Configuration Management	
	Device Name Configuration	

Alarm Level Definition	
Host Server Management	
Security Management	
User Management	
Role Management	
System Management	
System Log Management	
Monitoring Interfaces	
Optical Platform	
Intelligent Communications Interface Module (ICIM)	3-26
Basic Parameter	
Power Supply Module	
Basic Parameter	
1310 nm Forward Transmitter Module	3-30
Basic Parameter	3-30
Setup Parameters	3-32
Reverse Receiver Module	3-33
Basic Parameter	
Setup Parameters	
Forward Receiver Module	3-35
Basic Parameter	
Setup Parameters	3-36
1550 nm DWDM Forward Direct Modulation Transmitter	3-37
Basic Parameter	
Setup Parameters	
1550 nm Optical Amplifier Module	
Basic Parameter	
Forward Driver Amplifier Module	
Basic Parameter	
Setup Parameters	
Optical Switch Module	
Basic Parameter	
Setup Parameters	3-45

	RF Switch Module	3-46
	Basic Parameter	3-46
	Setup Parameters	3-47
Chapter 4	Troubleshooting	
General Troub	pleshooting Information	.4-2
	Error 1	.4-2
	Error Description	.4-2
	Troublesgooting	.4-2
	Error 2	.4-4
	Error Description	.4-4
	Troublesgooting	.4-5
	Additional Assistance	.4-7
Chapter 5	Customer Support Information	
Obtaining Pro	oduct Support	. 5-2
	Support Telephone Numbers	.5-2
Return for Rej	pairing	.5-4
	Introduction	.5-4
	Obtain RMA number and mailing address	.5-4
	Packaging and mailing	. 5-5

Chapter 1 Introduction

Overview

The OptoStar II optical platform is an advanced transmission system, designed to optimize network architectures and increase reliability, scalability, and cost effectiveness.

This chapter provides an introduction to the OptoStar II network management system (NMS).

Purpose

This document provides information about the installation and operation of the OptoStar II network management system.

Who Should Use This Document

This document is intended for authorized service personnel who have experience working with similar equipment. The service personnel should have appropriate background and knowledge to complete the procedures described in this document.

Qualified Personnel

<u>/!</u> CAUTION:

Allow only qualified and skilled personnel to install and operate this software. Otherwise, equipment damage may occur.

Only appropriately qualified and skilled personnel should attempt to install and operate this software.

Scope

This document discusses the following topics.

- Program Installation
- Program Operation

Document Version

This is the third release of this document.

In This Chapter

Topic	See Page
Introduction	1 - 2

Introduction

Description

The OptoStar II network management system (NMS) is an integrated remote management system for the Cisco OptoStar II optical platform. It provides service providers with a centralized management solution for monitoring and configuring CATV related equipment.

The NMS provides functions such as topology management, alarm management, performance management, configuration management, system logs, and security management.

Chapter 2 Installation

Overview

This chapter provides instructions for installing the OptoStar II network management system (NMS).

Qualified Personnel

Only appropriately qualified and skilled personnel should attempt to install and operate this software. Otherwise, equipment damage may occur.

In This Chapter

Topic	Page
Configuration Requirements	2 - 2
System Installation	2 - 3
Appendix I	2 - 10
Appendix II	2 - 12

This section introduces the procedures to install the OptoStar II NMS software.

System Structure



System Installation

The installation of the NMS contains three sections: database installation, Web server installation, and polling server installation.

Note: It is recommended to install these 3 programs (database, polling server, and Web server) on different computers.

Database Installation

The OptoStar II NMS requires Microsoft SQL Server as the operating background database.

Note: Microsoft SQL Server can be purchased from Microsoft.

For the SQL Server configuration for installing Microsoft SQL Server, see *Appendix II* (on page 2-12).

Web Server Installation

System Requirements

- **Supported operation system:** Windows 7, Windows Vista, and Windows Server 2003
- **Processor:** 400 MHz Pentium or equivalent processor (minimum configuration); 1 GHz Pentium or equivalent processor (recommended configuration)
- **Memory:** 96 MB (minimum configuration); 256 MB (recommended configuration)
- Hard drive: 500 MB free space required
- Monitor: 800 x 600, 256-color (minimum configuration); 1024 x 768 high color, 32-bit (recommended configuration)

Installation Procedures

- 1. Verify if the IIS 6.0 or higher has been installed. For enabling IIS in Windows 7, see *Appendix I* (on page 2-10).
- 2. Run the installer CISCO_NMS_Web.exe, and follow the installation wizard.





System Installation, Continued

3. Fill in the database login information.

etwork Management Syste Database Server Login	m Teb - InstallShield Tizard	2
Select database server and a	uthentication method	
	Database server that you are installing to: [local] Connect using: ● Windows authentication ● SQL Server authentication using Login ID and password below Login ID: sa Password:	28
InstallShield	< Back Next > Ca	ancel

- a. Enter the IP address where the database is located. (Note: "local" stands for the local machine.)
- b. Select the account to log in the database.
 - Windows authentication
 - SQL Server authentication (Login ID and password required)
- c. Click Next.



Click Finish to complete the installation.

System Installation, Continued

4. Verify if the installation is successful (taking Windows 7 as an example): start
-> Control Panel -> Administrative Tools -> Internet Information Services (IIS), as shown below:

🕞 Internet Information Services (IIS) M	lanager				3.3		
COO ILICHANG-WS	 Application Pools 						🔛 🔤 🔂 🔞 -
File View Help							
Connections Image: Second Se	Applicatio This page lets you view a associated with worker pr applications.	n Poo nd manag ocesses,	IS ge the list of ap contain one or	plication pools on t more applications,	he server. Application p and provide isolation a	pools are mong different	Actions Add Application Pool Set Application Pool Defaults Help Online Help
	Filter:	* 68	Go - 🕁 Show	Manager All Group by: 1	No Grouping	▼ Ann linetions	
	Contraction of the second seco	Started Started Started	v4.0 v4.0 v4.0	Integrated Classic Integrated	ApplicationPoolId ApplicationPoolId	0 0 1	
<)	۲ ا	tent View				•	
Ready							6

- a. Expand the left list, select App-Pool, and look for ASP.NET v4.0 and ASP.NET v4.0 Classic on its right side. If they're missing, see *Error 1 in the Troubleshooting chapter* (on page 4-2).
- b. Check if the NMS_WEB node has been created on the left. If not, reinstall the program.
- c. Verify if the new site has been enabled. See the illustration below.
- 5. Test web connection.

Launch a web browser (this software doesn't support IE6 or IE7). Enter the IP address of the NMS Web server. The following login screen shows that the site has been successfully created (initial username and password: admin).



Polling Server Installation

System Requirements

- **Supported operation system:** Windows 7, Windows Vista, Windows Server 2003, and Windows XP
- **Processor:** 400 MHz Pentium or equivalent processor (minimum configuration); 1GHz Pentium or equivalent processor (recommended configuration)
- **Memory:** 96 MB (minimum configuration); 256 MB (recommended configuration)
- Hard drive: 500 MB of free space required
- Monitor: 800 x 600, 256-color (minimum configuration); 1024 x 768 high color, 32-bit (recommended configuration)

Installation Procedures

1. Run the installer CISCO_NMS_Server.exe, and follow the installation wizard.



Click Next.

System Installation, Continued

Setup will install Network Management System Server in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder C:\Program Files\NMS Polling Host\ Browse

2. Select destination folder for the installation. To install to the default folder, click Next.

Note: The default installation folder is C:\Program Files\NMS Polling Host\.

Network Management Sys	stem Server - InstallShield Vizard	
Database Server Login Select database server and auth	pentication method	
	Database server that you are installing to:	
		*
		B <u>r</u> owse
	Connect using: Windows authentication SQL Server authentication using Login ID and password below Login ID: sa Password:	
InstallShield	< Back Next >	Cancel

- a. Enter the IP address where the database is located. (Note: "local" stands for the local machine.)
- b. Select the account to log in the database.
 - Windows authentication
 - SQL Server authentication (Login ID and password required)
- c. Click Next.

System Installation, Continued



Check the "Launch Network Management System Server" check box and click Finish to complete the installation.

3. Run the program after installation is complete.

Note: To launch the polling server program automatically when the system starts up, right click the program icon and check "Run on Windows Startup" as shown below.



Note: Due to the User Account Control (UAC) restriction in Windows 7, the program will not run on Windows startup. Reboot the computer and run Network Management System.exe in the installation folder.

Enable IIS in Windows 7

1. Click Start, and select Control Panel -> Programs -> Turn Windows features on or off.



2. Check the "Internet Information Services" check box and keep the sub-nodes remaining in their default statuses.



Continued on next page

3. Go to Control Panel -> System and Security -> Administrative Tools, and look for Internet Information Services (IIS) Manager as shown below.

- Farradara	Name	Date modified	Туре	Size	
Pavorites	A Component Services	2000/7/14 12:57	Shoutout	סע כ	
Desktop	Component Services	2009/7/14 12:57	Shortcut		
Becent Diaces	Data Sources (ODBC)	2009/7/14 12:54	Shortcut	2 KB	
ma necent Places	Figure Viewer	2003/7/14 12:55	Shortcut	2 KB	
Libraries	Therest Information Services (IIS) Manager	2013/9/23 15:40	Shortcut	2 KB	
Documents	SCSUnitiator	2019/3/23 13:48	Shortcut	2 KB	
A Music	Local Security Policy	2013/4/18 13:05	Shortcut	2 KB	
Pictures	Performance Monitor	2009/7/14 12:53	Shortcut	2 KB	
Videos	🛱 Print Management	2013/4/18 13:05	Shortcut	2 KB	
	Services	2009/7/14 12:54	Shortcut	2 KB	
📮 Computer	📰 System Configuration	2009/7/14 12:53	Shortcut	2 KB	
🏭 System (C:)	R Task Scheduler	2009/7/14 12:54	Shortcut	2 KB	
🚗 678394 (D:)	Windows Firewall with Advanced Security	2009/7/14 12:54	Shortcut	2 KB	
	Windows Memory Diagnostic	2009/7/14 12:53	Shortcut	2 KB	
📮 Network	😹 Windows PowerShell Modules	2009/7/14 13:32	Shortcut	3 KB	

4. Click to launch Internet Information Services (IIS) Manager, and configure the IIS as shown below.

😋 Internet Information Services (IIS) M	anager						X
COO D LILCHANG-WS	Application Pools						🖸 🛛 🟠 🔞 🗸
File View Help							
Connections	Annliantia		La.				Actions
ILICHANG-WS (CISCO\lilchat G Sites F Default Web Site	This page lets you view ar associated with worker pr applications.	n POO nd manag ocesses, i	IS ge the list of ap contain one or	plication pools on t more applications,	he server. Application p and provide isolation a	pools are mong different	Add Application Pool Set Application Pool Defaults Help Online Help
	Filter:	- 66	Go 👻 🥁 Shov	∾ All Group by: ↑	No Grouping	•	
	Name	Status	.NET Fram	Managed Pipel	Identity	Applications	
	ASP.NET v4.0	Started	v4.0	Integrated	ApplicationPoolId	0	
	ASP.NET v4.0 Classic	Started	∨4.0	Classic	ApplicationPoolId	0	
	✓ DefaultAppPool	Started	v4.U	Integrated	ApplicationPoolid	1	
۰ III ا	Features View 📑 Cont	tent View					
Ready							•

To Enable Remote Connections in SQL Server

This section takes SQL Server 2008 as an example. SQL Server 2008 doesn't allow remote connections by default, and "sa" account is disabled by default. To enable local connections to SQL Server 2008 on a remote server using SSMS, two parts of configuration need to be performed:

- 1. SQL Server Management Studio (SSMS)
- SQL Server Configuration Manager (SSCM) Step 1: Launch SSMS on the computer where SQL Server 2008 is installed. Connect to the database using Windows identity. Once logged in, right click and select Properties.



Step 2: Select Security on the left, then "SQL Server and Windows	3
Authentication mode" on the right.	

Server Properties - PC2013081218	D1\SQLEXPRESS			- • ×
Select apage General Hemory Freessors Security Connections Database Settings Advanced Fermissions	Script - L Help Server authentication Windows Authentication mode SQL Server and Windows Authen Login auditing	ntication mode		
	 None Failed logins only Successful logins only Both failed and successful logins Server proxy account Enable server proxy account Proxy account: 	bgins		
Connection Server: PC201306121801\SQLEXFRESS Connection: PC201306121801\Administrator Yiew connection properties Progress Ready Ready	Password: Options Enable C2 audit tracing Cross database ownership chai	ining		
			ОК	Cancel



Select a page	C Script - B Help
🚰 General	
Memory Processors	Constantions
Security	Connections
Connections	Maximum number of concurrent connections (0 = unlimited):
Database Settings	
] Advanced ♥ Permissions	
-	Use query governor to prevent long-running queries
	Default connection options:
	implicit transactions
	🔲 cursor close on commit
	ansi warnings
	ansi padding
	arithmetic abort
	arithmetic ignore
	🔽 quoted identifier 🔹
onnection	Remote server connections
Server:	
PC201308121801 (SQLEXPRESS	🕼 Allow remote connections to this server
Connection:	Remote query timeout (in seconds, $0 = no$ timeout):
PC201308121801\Administrator	600
View connection properties	
	Require distributed transactions for server-to-server communication
rogress	
Beady	
	Configured values
	Lancel AU

Continued on next page

Step 4: Expand Security -> Logins -> sa, and right click to select Properties.



Step 5: Click General on the left and select "SQL Server authentication" on the right to set up password.

📋 Login Properties - sa				- • • ×
Select a page	🔄 Script 🔻 🚺 Help			
I General Server Roles Wir Mapping Status	Login name: Windows authentication SQL Server authentication	54		Search
	Password: Confirm password:	*******		
	Specify old password Old password Old password W Enforce password polic Enforce password expir User must change passw Mapped to certificate Mapped to asymetric key	y ation ord at next login		×
	Mapped Credentials	Credential	Provider	Add Add
Connection Server: PC201308121801\SQLEXPRESS Connection: PC201308121801\Administrator ? Yiew connection properties				
Progress Ready	Default database:	master		Remove
	Default language:	English		•
			OK	Cancel



Step 6: Click Status, select Enabled, and click OK.



Step 7: Right click the database and select Facets.

elect a page	🖺 Script 👻 📑 Help	
General		
	Facet: Server Configuration	•
		f the Server recording the configuration settings of the server
	Description: Exposes properties of	i the server regarding the configuration settings of the server.
	Facet properties:	
	NestedTriggersEpobled	True
	NetworkPacketSize	4096
	OleAutomationEnabled	False
	OpenObjects	0
	OptimizeAdhocWorkloads	False
	PrecomputeRank	False
	PriorityBoost	False
	ProtocolHandlerTimeout	60
	QueryGovernorCostLimit	0
	QueryWait	-1
	RecoveryInterval	0
onnection	RemoteAccessEnabled	Irue 💽
PC201308121801\SOLEXPR	Remotel oginTimeout	20
ESS	inclusion contraction in the second sec	20
iew connection properties	RemoteAccessEnabled	
ogress	Gets the Boolean property value that sp	pecifies whether the remote access configuration option is
Page Ready	enabled.	
Ready		Export Current State as Policy

Step 8: Set "RemoteAccessEnabled" to "True", and click OK.

Step 9: The SSMS configuration has been completed. Exit and log in using "sa". If successful, the "sa" account will be enabled.

	ZL SEI VEI 2008
Server <u>t</u> ype:	Database Engine 🗸
<u>S</u> erver name:	PC201308121801\SQLEXPRESS -
<u>A</u> uthentication:	SQL Server Authentication -
Login:	sa 🗸
<u>P</u> assword:	****
	Remember password

Step 10: To configure SSCM: click "SQL Server Services" on the left, and verify if "SQL Server" and "SQL Server Browser" on the right are running.



Step 11: TCP/IP is set to Disabled by default. Right click it to change it to Enabled as shown below.

Sql Server Configuration Manager	- 11 / M	INCI AND -	AREA IN THE	ALC: AND C	
File Edit View Help					
 SQL Server Configuration Manager (Loc. SQL Server Services SQL Server Network Configuration Protocols for SQLEXPRESS SQL Native Client 10.0 Configuration 	Protocol Name Shared Memory TCP/IP VIA	Status Enabled Disabled Disabled			



Step 12: The configuration has now been completed. Restart SQL Server 2008.

Chapter 3 Operation

Overview

This chapter provides information about the operation of the OptoStar II Network Management System (NMS).

Qualified Personnel

Only appropriately qualified and skilled personnel should attempt to install and operate this software. Otherwise, equipment damage may occur.

In This Chapter

Topic	Page
Before You Begin	3 - 2
Functions	3 - 3
Monitoring Interfaces	3 - 24

Before You Begin

This section introduces the procedures to operate the OptoStar II NMS.

Before You Begin

- Database server
- Web server
- Polling server

Start

- 1. Make sure that the fiber and RF cables of relevant modules of the OptoStar II platform are connected.
- 2. Turn the front panel switch of the OptoStar II power supply module to ON position. The power supply module and other modules will initialize for about 5 seconds, and the ICIM will start loading for about 25 seconds.
- 3. When the device initialization is complete, connect to the Ethernet with the RJ-45 connector on the rear panel of the ICIM. Connect the PC to the Ethernet. The illustration below shows the connection method.



4. Log into the OptoStar II NMS system.

Functions

System Login

 First enter the address of the OptoStar II NMS in a web browser (Google Chrome is recommended). For example: <u>http://192.168.1.1</u>. The NMS system login screen will display as shown below.



2. Then enter the default username: admin, and the default password: admin. Select language (English or Simplified Chinese) to log in the NMS system.

System Main Interface

Once the user has successfully logged in, it will display the main interface of the system as shown below.

admin ■ Log Off CISCO OptoStar II Topology Management ~ Alarm Management ~ Performance ~ Configuration ~ Security Management ~ System Management ~
IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII
COPYRIGHT @ 2014 CISCO SYSTEMS, INC. ALL RIGHTS RESERVED.
• The OptoStar II NMS system provides following information:
On top of the screen there are username button (📥 admin), exit button
(I log Off), and function buttons such as topology management, alarm
management, performance management, configuration management, security management, and system logs. The user can select each menu to access corresponding management function.
II. The user can click the username button (📥 admin) to modify user profile.
Note: When there is alarm, the Alarm Management menu turns to red. The system interface is shown as below.
Continued on next page



COPYRIGHT @ 2014 CISCO SYSTEMS, INC. ALL RIGHTS RESERVED.

Topology Management

Topology Tree

Topology tree provides centralized monitoring and management functions on one interface, where the node information, statistics, and equipment online status in all the areas can be viewed. See the screenshot below.

UIIIII CISCO OptoStar II	admin ≇Log Off Network Management System Topology Management ◇ Alarm Management ◇ Performance ◇ Configuration ◇ Security Management ◇ System Management ◇
Image: China Image: China Image: Shanghai Image: China Image: China Image: China	III CISCO OptoStar II WELCOME
	COPYRIGHT © 2014 CISCO SYSTEMS, INC. ALL RIGHTS RESERVED.

The nodes in topology tree include text nodes (\bigcirc) and equipment nodes ($\stackrel{\text{lin}}{\longrightarrow}$). Click text nodes to expand their sub-nodes; and click equipment nodes to display detailed parameters of the equipment on the right. Three icons are used in the tree folder to stand for different equipment online statuses: online ($\stackrel{\text{lin}}{\longrightarrow}$), offline ($\stackrel{\text{lin}}{\longrightarrow}$), and unknown ($\stackrel{\text{lin}}{\longrightarrow}$).

- See operation procedures below:
- 1. To add a folder/equipment: right click any blank area in the topology tree, and the following menu will display:

	Property		
Ð	Add	4	Manual
	Remove		Search
	View Alarm		
2	Refresh		

Select Add -> Manually, and the following dialog box will display:

Add Node		×
Directory Node Type Node Title	Root Text Node V	
	Save Close	

In the Node Type dropdown list, select the node type to add. The default is Text Node, i.e., folder node.

See the flux house white white below.

Add Node		×
Directory Node Type	Root Device Node V	
Node Title	*	
Device IP	*	
Interval	1 Minute 🗸	
Polling	Enabled	
Host Server	<none></none>	
Location		
Contact		
Phone Number		
Manufacture		
	Save Close	

The IP address entered into the IP Address field must be compliant with its format criteria. In the Polling Server dropdown list, select one server to perform polling for that IP.

2. To search equipment: right click any blank area in the tree topology folder, and the following menu will display:

	Property		
Ð	Add	•	Manual
	Remove		Search
	View Alarm		
2 Refresh			
Search Device			
---------------	-----	------------	-----------
	To	public Sea	rch
DeviceType	OID	IpAddress	Operation

Select Add -> Search, and the following dialog box will display:

Enter the IP address range and SNMP string ("public" as default), and click Search to start searching.

3. To view node property: move cursor to the node you want to view, right click and the following menu will display:



Select Property to display detailed information about that node, as shown below:

E Node Prope	rty	×
Node Proper	ty Snmp Property	
Directory Node Title	Shanghai 🚖 <u>Change</u> OptoStar II	.
Device IP	192.168.4.205	
Device Type	OptoStarII	
Interval	1 Minute V	
Polling	Enabled	
Host Server	A157100000329 🗸	
Location		
Contact		
Phone Number		
Manufacture		
	Save Close	

4. To delete a node: move cursor to the node you want to delete, right click and the following menu will display:



Select Remove to delete that node. If a node folder is selected, then all the sub-folders and equipment nodes in that folder will be deleted.

5. To view the node alarm: move cursor to the node you want to view the node alarm, right click and the following menu will display:

E	Property
	Add
×	Remove
	View Alarm
2	Refresh

Select View Alarm to display alarm information about that node, as shown below:

Confirm © Device 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81	DateTime 23/04/2014 16:31:22 23/04/2014 16:31:22 23/04/2014 16:04:35 23/04/2014 16:04:12 23/04/2014 16:04:08 23/04/2014 16:04:08 23/04/2014 16:04:03 23/04/2014 16:04:02	Content EYDFA Optical Output Power High Resume, Current Value: 22 dBm EYDFA Optical Input Power High Resume, Current Value: 7 dBm EYDFA Optical Input Power High, Current Value: 65 dBm EYDFA Optical Input Power Low Resume, Current Value: -46 dBm EYDFA Optical Input Power Low, Current Value: -64 dBm	Type Warning Warning Warning Warning Warning	
Device 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81	DateTime 23/04/2014 16:31:22 23/04/2014 16:04:35 23/04/2014 16:04:12 23/04/2014 16:04:08 23/04/2014 16:04:03 23/04/2014 16:04:02	Content EYDFA Optical Output Power High Resume, Current Value: 22 dBm EYDFA Optical Input Power High Resume, Current Value: 7 dBm EYDFA Optical Input Power High, Current Value: 65 dBm EYDFA Optical Input Power Low Resume, Current Value: -64 dBm	Type Warning Warning Warning Warning	
192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81	23/04/2014 16:31:22 23/04/2014 16:04:35 23/04/2014 16:04:12 23/04/2014 16:04:08 23/04/2014 16:04:03 23/04/2014 16:04:02	EYDFA Optical Output Power High Resume, Current Value: 22 dBm EYDFA Optical Input Power High Resume, Current Value: 7 dBm EYDFA Optical Input Power High, Current Value: 65 dBm EYDFA Optical Input Power Low Resume, Current Value: -66 dBm EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning Warning Warning Warning Warning	
192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81	23/04/2014 16:04:35 23/04/2014 16:04:12 23/04/2014 16:04:08 23/04/2014 16:04:03 23/04/2014 16:04:03	EYDFA Optical Input Power High Resume, Current Value: 7 dBm EYDFA Optical Input Power High, Current Value: 65 dBm EYDFA Optical Input Power Low Resume, Current Value: 46 dBm EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning Warning Warning Warning	
192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81	23/04/2014 16:04:12 23/04/2014 16:04:08 23/04/2014 16:04:03 23/04/2014 16:04:02	EYDFA Optical Input Power High, Current Value: 65 dBm EYDFA Optical Input Power Low Resume, Current Value: -46 dBm EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning Warning Warning	
192.168.5.81 192.168.5.81 192.168.5.81 192.168.5.81	23/04/2014 16:04:08 23/04/2014 16:04:03 23/04/2014 16:04:02	EYDFA Optical Input Power Low Resume, Current Value: -46 dBm EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning Warning	
192.168.5.81 192.168.5.81 192.168.5.81	23/04/2014 16:04:03 23/04/2014 16:04:02	EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning	
192.168.5.81 192.168.5.81	23/04/2014 16:04:02			
192.168.5.81		EYDFA Optical Input Power Low Resume, Current Value: -54 dBm	Warning	
	23/04/2014 16:03:49	EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning	
192.168.5.81	23/04/2014 15:57:29	EYDFA Optical Input Power Low Resume, Current Value: -54 dBm	Warning	
192.168.5.81	23/04/2014 12:13:10	EYDFA Internal Temperature High Resume, Current Value: 29 °C	Normal	
192.168.5.81	23/04/2014 12:11:51	EYDFA Internal Temperature High, Current Value: 29 °C	Warning	

6. To refresh the tree folder: right click any blank area in the tree topology folder, and the following menu will display:

Ð	Add Remove	Þ
	View Alarm	
2	Refresh	

Select Refresh to refresh the entire tree folder view.

Alarm Management

Untreated Alarm Management

The Untreated Alarm screen displays all the alarms received by the polling server. See the illustration below.

IP		Date: From	To Type ALL V Q Query	Export -	
V	Confirm 🤤 De	lete			
	Device	DateTime	Content	Туре	
	192.168.4.131	22/05/2014 09:46:18	test string	Normal	
1	192.168.4.131	22/05/2014 09:46:15	test string	Normal	
	192.168.4.131	22/05/2014 09:46:12	test string	Normal	
	192.168.5.81	23/04/2014 16:31:22	EYDFA Optical Output Power High Resume, Current Value: 22 dBm	Warning	
	192.168.5.81	23/04/2014 16:04:35	EYDFA Optical Input Power High Resume, Current Value: 7 dBm	Warning	
	192.168.5.81	23/04/2014 16:04:12	EYDFA Optical Input Power High, Current Value: 65 dBm	Warning	
	192.168.5.81	23/04/2014 16:04:08	EYDFA Optical Input Power Low Resume, Current Value: -46 dBm	Warning	
	192.168.5.81	23/04/2014 16:04:03	EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning	
	192.168.5.81	23/04/2014 16:04:02	EYDFA Optical Input Power Low Resume, Current Value: -54 dBm	Warning	
	192.168.5.81	23/04/2014 16:03:49	EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning	
	192.168.5.81	23/04/2014 15:57:29	EYDFA Optical Input Power Low Resume, Current Value: -54 dBm	Warning	
	127.0.0.1	23/04/2014 15:14:13	Administrator 127.0.0.1	Warning	
	192.168.5.81	23/04/2014 12:13:10	EYDFA Internal Temperature High Resume, Current Value: 29 °C	Normal	
٦	192.168.5.81	23/04/2014 12:11:51	EYDFA Internal Temperature High, Current Value: 29 °C	Warning	

- See operation procedures below:
- 1. To confirm an alarm: the administrator can select one or more alarm items

and click the confirm button (Confirm) to confirm and remove the alarm from the Pending Alarm list.

- To delete an alarm: select one or more alarm items and click the delete button (^{ODelete}).
- 3. To query an alarm: fill in all the query condition fields, such as IP Address, Date, and Alarm Type, and click Query.
- 4. Paging: in the toolbar at the bottom of the page, you can go to the previous/next page, and set up the number of alarms to be displayed.

20 V I Page 1 of 1 V V C

Displaying 1 to 14 of 14 items

History Alarm Management

History Alarm displays all the alarm items confirmed or deleted from the Pending Alarm list. See the screenshot below.

Histo	ory Alarm						
IP [(2) G - 2	Date: From	To Type ALL V Query	Export -			
0	Delete						
	Device	DateTime	Content	Туре	Confirm State	Confirm User	
	192.168.4.131	22/05/2014 09:46:18	test string	Normal	Confirmed	admin	
	192.168.4.131	22/05/2014 09:46:15	test string	Normal	Confirmed	admin	
	192.168.4.131	22/05/2014 09:46:12	test string	Normal	Confirmed	admin	
	192.168.5.81	23/04/2014 16:31:40	EYDFA Optical Input Power Low, Current Value: -6.5 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:31:22	EYDFA Optical Output Power High Resume, Current Value: 22 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:30:48	EYDFA Optical Output Power High, Current Value: 22 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:25:26	EYDFA Optical Output Power High Resume, Current Value: 220 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:18:49	EYDFA Optical Input Power Low Resume, Current Value: 6 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:04:35	EYDFA Optical Input Power High Resume, Current Value: 7 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:04:12	EYDFA Optical Input Power High, Current Value: 65 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:04:08	EYDFA Optical Input Power Low Resume, Current Value: -46 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:04:03	EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:04:02	EYDFA Optical Input Power Low Resume, Current Value: -54 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 16:03:49	EYDFA Optical Input Power Low, Current Value: -64 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 15:57:29	EYDFA Optical Input Power Low Resume, Current Value: -54 dBm	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 15:16:01	EYDFA Internal Temperature High Resume, Current Value: 28 °C	Normal	Confirmed	admin	
	127.0.0.1	23/04/2014 15:14:13	Administrator 127.0.0.1	Warning	Confirmed	admin	
	192.168.5.81	23/04/2014 12:13:10	EYDFA Internal Temperature High Resume, Current Value: 29 °C	Normal	Confirmed	admin	
	192.168.5.81	23/04/2014 12:11:51	EYDFA Internal Temperature High, Current Value: 29 °C	Warning	Confirmed	admin	~
20	- IA A	Page 1 of 1	ИО			Displaying 1 to 19	of 19 items

• See operation procedures below:

See the procedures of Untreated Alarm.

Performance Management

Performance Management displays equipment parameters regularly received by the polling server. These parameters can be queried, deleted, or shown in charts. See the screenshot below (taking the power supply module as an example).

IP	. Date From	1	Го		Serial Number	S	lot	
Table 📈	Plot							
Power Supply dat	ta							
🔍 🔍 Query 🛛 🖨	Delete 前 Clear	🖹 Export 👻						
Device IP	Serial Number	DateTime	Slot	Output Voltage (V)	Output Current (mA)	Output Power (W)	Temperature (°C)	
192.168.5.123	AOI0000003	11/04/2013 12:30:05	9	24.1	1875	45	39	~
192.168.5.123	AOI0000003	11/04/2013 12:31:05	9	24	1458	35	39	
192.168.5.123	AOI0000003	11/04/2013 12:32:05	9	24	1458	35	39	
192.168.5.123	AOI0000003	11/04/2013 12:33:05	9	24	1458	35	39	
192.168.5.123	AOI0000003	11/04/2013 12:34:05	9	24	1541	37	39	
192.168.5.123	AOI0000003	11/04/2013 12:35:05	9	24	1916	46	39	
192.168.5.123	AOI0000003	11/04/2013 12:36:05	9	24	1458	35	39	
192.168.5.123	AOI0000003	11/04/2013 12:37:05	9	24	1458	35	39	
192.168.5.123	AOI0000003	11/04/2013 12:38:05	9	24	1458	35	39	
192.168.5.123	AOI0000003	11/04/2013 12:39:05	9	24	1541	37	39	
192.168.5.123	AOI0000003	11/04/2013 12:40:05	9	24	1666	40	39	
192.168.5.123	AOI0000003	11/04/2013 12:41:05	9	24	1541	37	39	
192.168.5.123	AOI0000003	11/04/2013 12:42:05	9	24	1916	46	39	
192.168.5.123	AOI0000003	11/04/2013 12:43:05	9	24	1541	37	39	
192.168.5.123	AOI0000003	11/04/2013 12:44:05	9	24	1625	39	39	
192.168.5.123	AOI0000003	11/04/2013 12:45:05	9	24	1916	46	39	
192.168.5.123	AOI0000003	11/04/2013 12:46:05	9	24	1666	40	39	~
	Page 1 of 324	4 F H O					Display	ing 1 to 20 of 6464 items

- See operation procedures below:
- To query data: enter the query conditions, such as IP Address, Date, S/N, and Slot ID, and click the query button (Query) to display the results.
- 2. To delete data: Select the data item to delete, and click the delete button

(Delete) to delete it.

- 3. To empty data: this operation will empty all the data please use with caution.
- 4. To show in charts: Enter the mandatory query condition (the dates), and optional conditions such as IP Address, S/N, and Slot ID, check the

parameters to display, and click the Query button (Query) for results.



Continued on next page

OL-29665-03

Configuration Management

Device Name Configuration

The system provides default device names. This function can be used to rename the device. See the screenshot below.

Find 🔍	English Name	ICIM	
CoptoStarll OptoStarll OptoStarll Optical Amplifier CIM Forward Receiver Statumer and the second se	Chinese (Simplified) Name		
			Save

- See operation procedures below:
- 1. Select the device to rename on the left, enter the new name in the text box on the right, and click the Save button on the lower right corner to save the change.

Alarm Level Definition

The system provides six default alarm levels, including Normal, Warning, Minor, Major, Critical and Undefined. The user can set up the level as required. See the screenshot below.

ind 🔍	Device Alarm Level Definition	
a 🔄 OptoStarll	Description	Alarm Type
Optical Amplifier	Power Supply status is normal	Normal 🗸
E Forward Receiver	Power Supply output DC voltage Low	Critical 🗸
E 1310 nm Transmitter	Power Supply output DC voltage High	Critical
E Optical Switch	Power Supply FAN fault	Warning 🗸
Power Supply Forward Driver Amplifier	Power Supply module temperature high	Major
	Power Supply power OFF	Normal V
= 1550nm DMT	Power Supply power ON	Normal V
	20 V H 4 Page 1 of 1 1 H C	Displaying 1 to 7 of 7 iten

Host Server Management

Host server management displays statuses for all the servers, including Identity, Name, Status, Trap Receive, Email Alert, and Trap IP Filter List. See the illustration below.

Host Server List					
🕨 Enable 🥥 Disa	able 🏾 🝸 Trap Filter	🔤 Email Alert Options		Name	9
Identity	Name	Status	Trap IP Filter List	Trap Receive	Email Alert
326f2570-ec65-489c-{	A157100000329	Fault	192.168.1.1,192.168.1.2	Normal	Stopped
65721157-1254-435e	global-Irzpgsum	Normal		Normal	Stopped
Od6bddec-95f9-473b-l	r1-n8kw2wahy94q	Fault		Stopped	Stopped
	Page 1 of 1 🕨	N Ø		Dis	playing 1 to 3 of 3 items

- See operation procedures below:
- 1. To set host status: double click or right click the item to set, and the following window will display:

E Settings-global-Irzpgsum				
Host Name Trap Receive Email Alert	global-Irzpgsum ★ ✓ Enabled □ Enabled			
Filter List	IP Address			
	Save Close			

You may set Host Name, Trap Receive, Email Alert, and Filter List in this window. Enter multiple IP addresses in the Filter List, divided by Enter key.

When the setup is completed, click the Save button to save the change.

- To set alarm on/off: use the " Enable Olisable " button in the toolbar to enable/disable all the server alarms.
- 3. To set alarm filter: use the " **Trap Filter** " button in the toolbar to set filter IP list of all the server alarms. When the setup is completed, the server will no longer receive alarms from the filter IP list.

Security Management

User Management

Use the user management function to manage all the users who are using the NMS, including adding, deleting, or changing the users. See the illustration below.

User List			
🗿 New 🥥 Dele	ete		Username
Username	Role	Description	State
admin	Administrator	Default User	Normal
test_user	TEST_ROLE		Normal
test123456	Administrator		Disabled
20 🗸 🖂 🕯	Page 1 of 1	N Ó	Displaying 1 to 3 of 3 items
	I ugo I OI I P		Displaying 1 to 3 of 3 items

- See operation procedures below:
- 1. To create a new user: click the New button (New) in the toolbar as shown below:

📰 Create a ne	w user	×
UserName		*
Password		*
Confirm Password		*
Role	Administrator 🗸	
State	Enable	
Phone		
Email		
Description		
	Save Close	

The Username, Password, Confirm Password, and Role fields are mandatory.

When the State is disabled, the user cannot use the NMS; when it is enabled, the user can use the NMS.

Click the Save button to save the change.

2. To delete a user: select the user to delete, and click the Delete button

Delete) in the toolbar to delete it.

The default user "admin" cannot be deleted.

Functions, Continued

3. To modify user information: double click or right click the user to modify, and a window will display as shown below:

E Settings		×
UserName	admin	
Password	•••••	×
Confirm Password	•••••	×
Role	Administrator V	
State	Enable	
Phone		
Email		
Description	Default User	
	Save Close	

When the modification is completed, click the Save button to save the change.

Role Management

Use the role management function to show and set all the roles. See the illustration below.

Role List	
📀 New 🤤 Delete	RoleName 🔍
RoleName Description	
Administrator Default Role	
TEST_ROLE	
20 V H 4 Page 1 of 1 > H O	Displaying 1 to 2 of 2 items

- See operation procedures below:
- 1. To create a new role: click the New button (New) in the toolbar as shown below:

Name	Privilege	Region Privilege	
Description	Administrator Administrator Alarm Management Alarm Management Allow to view alarm data only Allow to acadirm/data alarm data	 ▲ China ▲ Shanghai Ξ OptoStar II Ξ 021585 5 211 	
	Allow to committerere alarm de	E 192.168.5.198	
	 Allow to view performance data Allow to delete performance data Allow to setup topology tree 	E 192.100.4.90	
	 Allow to setup device indentity narr Allow to setup alarm levels System log Management 		
	 Allow to view system log data or Allow to delete system log data 		

Fill in the Role Name and Description fields, and check the Privilege and Region Privilege lists.

In the Region Privilege list, a node without being checked means its users have no permission to access the equipment information in that region; when it is checked, its users can read and set the equipment in that region.

- To delete a role: select the role to delete, and click the Delete (Delete) button in the toolbar to delete it. The default role "admin" cannot be deleted.
- 3. To edit a role: double click the role to edit and the following window will display. Click the Save button when the edit is completed.

E Settings			×
Name Administrator Description Default Role	Privilege Administrator Administrator Alarm Management Alarm Value to view alarm data only Allow to view parformance data Allow to view performance data Allow to setup topology tree Allow to setup device indentity nam Allow to setup alarm levels Allow to setup alarm levels Allow to view system log data or Allow to delete system log data or Allow to setup polling hosts	Region Privilege	
		Save	Close

System Management

System Log Management

System log management displays the following contents: errors found in the polling server during the polling process, user login information, and user's setup records for the equipment. See the screenshot below.

Sys	tem Log						
6	Delete Date From		То	LogType ALL	🗸 🔍 Query	📑 Export 👻	
	DateTime	Event Source	Content	Туре			
	05/09/2013 15:11:12	admin	Login from 192.168.7.202	System			
	05/09/2013 14:20:46	admin	Login from 192.168.7.202	System			
	05/09/2013 14:19:59	admin	Login from 192.168.7.202	System			
	05/09/2013 13:49:37	admin	Login from 192.168.7.202	System			
	05/09/2013 13:49:36	admin	Login from 192.168.7.202	System			
	05/09/2013 12:06:36	admin	Login from ::1	System			
	03/09/2013 15:41:38	admin	Login from ::1	System			
	03/09/2013 13:48:01	admin	Login from 192.168.4.66	System			
	03/09/2013 08:12:23	admin	Login from 192.168.4.66	System			
	02/09/2013 16:47:37	admin	Login from 192.168.4.66	System			
	02/09/2013 16:33:49	admin	Login from 192.168.4.66	System			
	02/09/2013 14:12:33	admin	Login from 192.168.4.95	System			
	02/09/2013 14:10:15	admin	Login from 192.168.4.66	System			
	02/09/2013 13:34:47	admin	Login from 192.168.4.66	System			
	02/09/2013 13:28:15	test_user	Login from 192.168.4.66	System			
	02/09/2013 13:27:48	admin	Login from 192.168.4.66	System			
	02/09/2013 13:25:28	admin	Login from 192.168.4.66	System			
	02/09/2013 13:15:58	admin	Login from 192.168.4.66	System			
	02/09/2013 12:24:10	admin	Login from 192.168.4.66	System			
	02/09/2013 11:26:37	admin	Login from 192.168.4.66	System			
20	V II I Page	1 of 4581 🕨	Ю				Displaying 1 to 20 of 91602 item

- See operation procedures below:
- 1. To delete a log: select the log to delete, and click the Delete (Delete) button in the toolbar to delete it.
- 2. Log query: enter query conditions: Date and Log Type, and click the Query button.

Optical Platform

The default startup interface:

Alarm List Installation Info Confirm Content Type Device DateTime Content Type	CISCO CISCO Anne Cisco Anne Cisco	e of other	Liter Liter	Larry Cisco	Lawr Lawr Lawr Travesther	Listo	Liter	Auerone Receivers Constructions	Liston	Aunova and a second and a secon	All isolations	Aunova and a second and a secon	rilialia CISCO Perer Porwed Receiver	CISCO CISCO Perer Aumor Forward Receiver	
	Alarm	List Install onfirm 🤤 Del vice	Dai	leTime	C	ontent	Туре	3							

- The upper part of the interface shows current online statuses of the equipment;
- The lower part of the interface shows alarm information and installation information of the current equipment;
- The lower part of the interface also shows parameters of each module in corresponding slot.

Intelligent Communications Interface Module (ICIM)

Basic Parameter

Click to select the OptoStar II intelligent communications interface module in the interface which shows all the local modules. The parameter interface of the intelligent communications interface module will display as illustrated below.

CITITIT CISCO Anno Anno Anno Anno Anno Anno Anno Ann	elisto Porto P	e o or		All I i i i i i i i i i i i i i i i i i i	Aarn Receivers Receivers Receivers	rtin Cis Power Meren Record				Lawr Lawr Lawr Transmitter	List Cisco	Ilititi CISCO Pere Pere Reseiver	Torward Receiver	Free Booler	IIIIIIII
ICIM o	on 192.168.4.2	205													
Module	e Information						FAN								
	S	erial Number:	AC	017120	004		Fan1 Status:				tatus:	Normal			
	Firm	ware Version:		٧	/2.0						Fan2 S	tatus:			Normal
		Temperature:			36	°C	Fan3 Status: Normal								
RESET							Fan4 Status: N						Normal		
				COLTI	NC		Fan5 Status: Norma						Normal		
	JOWINONICATIO	MINIERROFT		ESETTI	NG.		Fan6 Status: Norma						Normal		
		RESET					Fan7 Status: Normal								
											Fan8 S	tatus:			Normal

Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II intelligent communications interface module.

Basic Parameter	Description				
Module Basic Information					
Module Node Location	Shows the node IP where the modules are located				
S/N	Shows module serial number				
Module Firmware Version	Shows firmware version				
Module Temperature	Shows the current module temperature (°C)				
Fan Status					
8 Chassis Fans Statuses	Shows if the statuses of 8 chassis fans are normal				
Module Factory Reset					
Reset Key	Factory reset				

Power Supply Module

Basic Parameter

Click to select the OptoStar II power supply module in the interface which shows all the local modules. The parameter setting interface of the power supply module will display as illustrated below.

Litititi CISCO Press Anne Malay Mala	ritation CISCO Porton P	vitation Power Supply Compared to the second seco	y Res				II. CISCO CISCO Law Jack and Jack and Jack and Jack and Jack and J			Lever	Alter Provide	Alter Becalver		
Bower		92 168 5	9 (192	9 (9 0		•		•	•	•	0	•	Θ
Module	e Information	32.100.3.	192											
	9	erial Numb	er:	0123	8456789		Output Voltage:				ige:		1 V	
		Slot	ID:		2		Output Current:			ent:	1869		9 mA	
	Firm	ware Versio	on:		V2.0		Output Power:				ver:		5 W	
		Temperatu	ire:		45	°C				FAN Stat	tus:		Norma	d

Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II power supply module.

Basic Parameter	Description
Module Basic Information	
Module Node Location	Shows the node IP where the modules are located
S/N	Shows module serial number
Slot ID	Shows the slot ID the module is placed
Module Firmware Version	Shows firmware version
Module Temperature	Shows the current module temperature (°C)
Output Voltage	Shows module output voltage (V)
Output Current	Shows module output current (mA)
Output Power	Shows module output power (W)
Fan Status	Shows if the power supply fan status is normal

1310 nm Forward Transmitter Module

Basic Parameter

Click to select the OptoStar II 1310 nm forward transmitter module in the interface which shows all the local modules. The parameter setting interface of the 1310 nm forward transmitter module will display as illustrated below.

-t[[1:1]]. CISCO	HILLIN CISCO Prance Power Supply Cisco Cis	Power St Power St Owner St		LILIE	Autor Cisco	Prese Prese		Law Control Co	Interest of the second	Lever Constant of the second s	Later J310 om Transverter	Prese Prese Parsend Receiver	Prest	Pore Press	Iliiii Cisco Perre Arres Recever
۲	00	٠	٠	۲	٠	٠	•	۲	۲	٠	٠	۲	۲	•	•
1310n	m Transmitte	r on 19	2.168	.5.192											
Module	Information					1	nput RF								
	Serial N	umber:	1	011712	0009				Input F	RF Level:			11.2	dBmV	
	:	Slot ID:			13			Ga	in Contr	ol Mode:	AG	С	-		Save
	Firmware V	ersion:			V2.0			Inp	ut RF At	tenuator:			0	dB	Save
	Tempe	erature:			37.3	°C									
Laser															
	La	er Type:	1.1	D	FB-13			Las	er Outpu	ut Power:			13.1	dBm	
	Laser Temp	erature:	1		27.6	°C		La	ser Bias	Current	1		67	mA	
	Laser Way	Laser Wavelength: 1310 nm Laser TEC				Current			-133	mA					
								Lase	er On/Of	f Control	ON		~		Save
Comme	nt														
Comme	nt 1: Type Co	omment [*]	Text H	ere											Save
	The second		- serie II												Carto

Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II 1310 nm forward transmitter module.

Basic Parameter	Description
Module Basic Information	
Module Node Location	Shows the node IP where the modules are located
S/N	Shows module serial number
Slot ID	Shows the slot ID the module is placed
Module Firmware Version	Shows firmware version
Module Temperature	Shows the current module temperature (°C)
RF Input Information	
RF Input Level	Shows RF input level (dBmV)
Laser Information	
Laser Type	Shows laser type
Laser Temperature	Shows laser temperature (°C)
Wavelength	Shows wavelength (nm)
Optical Output Power	Shows optical output power (dBm)
Bias Current	Shows laser bias current (mA)
Cooling Current	Shows cooling current (mA)

Setup Parameters

The table below lists the setup parameters of the OptoStar II 1310 nm forward transmitter module.

Setup Parameters	Description	Factory Default
RF Input Informa	ation	
Gain Control Mode Selection	Shows / sets AGC or MGC gain control mode	AGC mode
RF Attenuator	Shows / sets RF attenuation (dB) (In AGC mode the field is grayed out; In MGC mode the function is available: gain range -5 to +5 dB, with 0.5 dB step)	0 dB (In AGC mode)
Laser Information	n	
Laser Status	Shows / sets laser status: ON/OFF	Laser status: ON
Comment		
Comment	None	

Reverse Receiver Module

Basic Parameter

Click to select the OptoStar II reverse receiver module in the interface which shows all the local modules. The parameter setting interface of the reverse receiver module will display as illustrated below.

-t[1:1]: CISCO Pare Carlos Area Carlos Model Model Model Model USB () () () () () () () () () () () () ()	Peer Suppr Of Control of Control			ILIIII CISCO Prove Reverse Rev	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII		Lune Transmitter		Preserver Preser	Poser	
Ð	•	•		((•	۲	•	•	⊕	•
Rever	se Receive	rs on 192.16	8.4.205								
Module	Information				an orananan an Literatura	Comment					
		Serial Number:	AOI	171200)11	Co	Comment 1: Type Comment Text Here.				
		Slot ID:			6	Co	Comment 2:		Type Comment Text Here.		
	Fir	mware Version:		V	2.0	Co	mment 3:	Type Con	nment Text He	re.	Save
		Temperature:			37 °C	Co	Comment 4: Type Comment Text Here.				
Module	1					Module 2					
Ir	nput Power:		-7.1	dBm		Inpu	t Power:		-6.9	dBm	L. S. F. S. S.
Ir	nput Status:		Normal			Inpu	t Status:		Normal		
Gain Co	ontrol Mode:	AGC 🗸 -1	10 OFF	dB	Save	Gain Contr	ol Mode:	AGC 🗸	0 OFF	dB	Save
Module	3					Module 4					
Ir	nput Power:		-7.1	dBm		Inpu	t Power:		-6.9	dBm	LANS NO.
Ir	nput Status:		Normal			Inpu	t Status:		Normal		
Gain Co	ontrol Mode:	AGC 🗸	0 OFF	dB	Save	Gain Contr	ol Mode:	AGC 🗸	0 OFF	dB	Save

Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II reverse receiver module.

Basic Parameter	Description
Module Basic Information	
Module Node Location	Shows the node IP where the modules are located
S/N	Shows module serial number
Module Firmware Version	Shows module firmware version
Slot ID	Shows slot ID
Module Temperature	Shows the current module temperature (°C)
Parameters for Each Module	
Optical Input Power	Shows optical input power (dBm)
Optical Input Status	Shows optical input status: Normal/Fault

Setup Parameters

The table below lists the setup parameters of the OptoStar II reverse receiver module.

Setup Parameters	Description	Factory Default
Parameters for Ea	ich Module	
	Shows/sets AGC or MGC gain control mode	AGC mode for all four modules
Gain Control Mode	Shows/sets gain (In AGC mode the field is grayed out; In MGC mode the function is available: gain range -20 to 0 dB, turn-off at -30 dB, with 1 dB step)	0 dB (In AGC mode)
Comment		
Comment	You may add applicable comments as required.	None

Forward Receiver Module

Basic Parameter

Click to select the OptoStar II forward receiver module in the interface which shows all the local modules. The parameter setting interface of the forward receiver module will display as illustrated below.

I I I I I I I I I I I I I I I I I I I	e o or	CISCO Plants Poer Suppy Cisco	IIIIII	rilitilit CISCO Puer Anno Receivers Receivers Receivers	etilitelite CISCO Pour P Auto Receivers Receivers Receivers Receivers	rilialia Cisco Paure Receiver Receiver Receiver	LEFE CISCO	LANK CISCO	Lever Cisco	International and a second sec	Liliiilii Cisco Puer P Aan P Forward Receiver	Puere Parent Portand	Puese P	I I I I I I I I I I I I I I I I I I I
⊕	•	•	۲	⊕	۲	•	•	۲	۲	۲	⊕	•	⊕	۲
Forwa	rd Receiver o	n 192.168.6.	91											
Module	Information													
	S	Serial Number:	A	0117250	052			Inpu	t Power:			0.3	dBm	
		Slot ID:			15			Inpu	t Status:		1	Vormal		
	Firm	nware Version:		1	/3.1		Ga	in Contr	ol Mode:	AG	С	~		
		Temperature:			36	Ċ	Outp	ut RF At	tenuator:			0 OFF	dB	Save
Comme	nt													
Comme	nt 1: Type C	omment Text	Here.											Save

The table below lists the basic parameters of the OptoStar II forward receiver module.

Basic Parameter	Description
Module Basic Information	
Module Node Location	Shows the node IP where the modules are located
S/N	Shows module serial number
Module Firmware Version	Shows firmware version
Module Temperature	Shows the current module temperature (°C)
Optical Input Power	Shows optical input power (dBmV)
Optical Input Status	Shows optical input status: Normal/Fault

Setup Parameters

The table below lists the setup parameters of the OptoStar II forward receiver module.

Setup Parameters	Description	Factory Default
RF Output Inform	nation	
Gain Control Mode Selection	Shows / sets AGC or MGC gain control mode	AGC mode
RF Attenuator	Shows / sets RF attenuation (dB) (In AGC mode the field is grayed out; In MGC mode the function is available: gain range -20 to 0 dB, turn-off at -30 dB, with 1 dB step)	0 dB (In AGC mode)
Comment		
Comment You may add applicable comments as required.		None

1550 nm DWDM Forward Direct Modulation Transmitter Module

Basic Parameter

Click to select the OptoStar II 1550 nm DWDM forward direct modulation transmitter module in the interface which shows all the local modules. The parameter setting interface of the 1550 nm DWDM forward direct modulation transmitter module will display as illustrated below.

<pre>shoth: csco csco csco csco csco csco csco csc</pre>	empty efforts of effor	empt	y empty	empty	empty	empty	empty	empty			empty
Module Information			Input RF								
Serial Number:	A0I17200005	-	input Ki		Input R	F Level:			15.2	dBmV	
Slot ID:	7			Gai	in Contro	Mode:	AG	0	-		Save
Firmware Version:	V2.0			Inpu	t RF Att	enuator:			-2	dB	Save
Temperature:	35	τ									
Laser				-	-	-		-			
Laser Type:	DFB-10			Las	er Outpu	t Power:	1.1		10.1	dBm	
Laser Temperature:	24	r		La	ser Bias	Current	11		73	mA	
Laser Wavelength:	1550.12	nm		La	ser TEC	Current:	1		-127	mA	
				Lase	r On/Off	Control	ON				Save
Comment											
Comment 1: Type Comment	Text Here										Save
oonment t. Type comment	TOALINID.									_	Save

Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II 1550 nm DWDM forward direct modulation transmitter module.

Basic Parameter	Description
Module Basic Information	
Module Node Location	Shows the node IP where the modules are located
S/N	Shows module serial number
Slot ID	Shows the slot ID the module is placed
Module Firmware Version	Shows firmware version
Module Temperature	Shows the current module temperature (°C)
RF Input Information	
RF Input Level	Shows RF input level (dBmV)
Laser Information	
Laser Type	Shows laser type
Laser Temperature	Shows laser temperature (°C)
Wavelength	Shows ITU wavelength
Optical Output Power	Shows optical output power (dBm)
Bias Current	Shows laser bias current (mA)
Cooling Current	Shows cooling current (mA)

Setup Parameters

The table below lists the setup parameters of the OptoStar II 1550 nm DWDM forward direct modulation transmitter module.

Setup Parameters	Description	Factory Default
RF Input Informa	ation	
Gain Control Mode Selection	Shows / sets AGC or MGC gain control mode	AGC mode
RF Attenuator	Shows / sets RF attenuation (dB) (In AGC mode the field is grayed out; In MGC mode the function is available: gain range -5 to +5 dB, with 0.5 dB step)	0 dB (In AGC mode)
Laser Information	n	
Laser Status	Shows / sets laser status: ON/OFF	Laser status: ON
Comment		
Comment	None	

1550 nm Optical Amplifier Module

Basic Parameter

Click to select the OptoStar II 1550 nm optical amplifier module in the interface which shows all the local modules. The parameter setting interface of the 1550 nm optical amplifier module will display, for the parameter setting interface of one pump is shown as below.



The parameter setting interface of two pumps is shown as below.

Image: Construction Image: Construction Image: Construction Image: Construction	empty cisco cisco manufactoria base base base base cisco cis	empty empty em		empty		I I I I I I I I I I I I I I I I I I I	empty	empty	empty	empty	
Optical Amplifier During Control During 4						-	-				
Serial Number:		AOI17260016	AOI17260016		Laser Temperature:				38		
	11		Laser Bias Current:			ent:	C) mA		
Firmware Version:		V1.0		Laser TEC Current:			ent:	-452		2 mA	
Temperature:		37	°C	Pump 2							
Optical Input Power:		-12	dBm	Laser Temperature:			ire:	40) °C	
Optical Output Power:		0	dBm		Laser B	ias Curre	ent:		() mA	
Comment					Laser T	EC Curre	ent:		-156	6 mA	
Comment 1: Type Co	omment Text	Here.	Save								

Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II 1550 nm optical amplifier module.

Basic Parameter	Description				
Module Basic Information					
Module Node Location	Shows the node IP where the modules are located				
S/N	Shows module serial number				
Slot ID	Shows the slot ID the module is placed				
Module Firmware Version	Shows firmware version				
Module Temperature	Shows the current module temperature (°C)				
Optical Power Information					
Optical Input Power	Shows optical input power (dBm)				
Optical Output Power	Shows optical output power (dBm)				
Laser Information					
Laser Temperature	Shows laser temperature (°C)				
Drive Current	Shows laser drive current (mA)				
Cooling Current	Shows cooling current (mA)				

Forward Driver Amplifier Module

Basic Parameter

Click to select the OptoStar II forward driver amplifier module in the interface which shows all the local modules. The parameter setting interface of the forward driver amplifier module will display as illustrated below.



Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II forward driver amplifier module.

Basic Parameter	Description					
Module Basic Information						
Module Node Location	Shows the node IP where the modules are located					
S/N	Shows module serial number					
Slot ID	Shows the slot ID the module is placed					
Module Firmware Version	Shows firmware version					
Module Temperature	Shows the current module temperature (°C)					

Setup Parameters

The table below lists the alarm parameters of the OptoStar II forward driver amplifier module.

Setup Parameters	Description	Factory Default					
RF Input Information							
Output Tilt	Set output tilt (range: 0 to 9 dB)	0 dB					
Output Gain	Set output gain (range: -9 to 0 dB)	0 dB					
Comment							
Comment	You may add applicable comments as required.	None					

Optical Switch Module

Basic Parameter

Click to select the OptoStar II optical switch module in the interface which shows all the local modules. The parameter setting interface of the optical switch module will display as illustrated below.

-ilicility -ilicility empt -ilicility -ilicility -ilicility empt	y empty	empty 1 Cisco New 1 New		tilli sco empty	etiletalite CISCO Para I Francisco Francisco Francisco Angelite			empty	empty	empty
Optical Switch on 192.16	8.5.211									
Module Information Comment										
Serial 1	Serial Number:		AOI17190012		Comment 1: Type Comment			Here.		Save
Slot ID:		12		Comm	Comment 2: Type Comment Text Her			Here.		Save
Firmware	V1.	.0			- 16					
Temperature:		2	28 °C		Switch Mode:		e: Ma	nual	-	Save
						Switch State	e: Pat	th B		Save
Path A				Path B						
Inpu	Norma	al		Input Status:			-	Normal		
Input Power:		15.	0 dBm	Input Power:				15.	2 dBm	
Monitoring Interfaces, Continued

The table below lists the basic parameters of the OptoStar II optical switch module.

Basic Parameter	Description			
Module Basic Information				
Module Node Location	Shows the node IP where the modules are located			
S/N	Shows module serial number			
Slot ID	Shows the slot ID the module is placed			
Module Firmware Version	Shows firmware version			
Module Temperature	Shows the current module temperature (°C)			
Optical Input Power Information				
Optical Input Power in Channel A/B	Shows optical input power in channel A/B (dBm)			

Setup Parameters

The table below lists the setup parameters of the OptoStar II optical switch module.

Setup Parameters	Description	Factory Default			
Optical Signal In	Optical Signal Input Information				
Switching Mode Selection	Shows/sets Auto/Manual switching mode	Auto switching mode			
Channel A/B Selection	Shows/sets channel A/B	Channel A			
Comment					
Comment	You may add applicable comments as required.	None			

RF Switch Module

Basic Parameter

Click to select the OptoStar II RF switch module in the interface which shows all the local modules. The parameter setting interface of the RF switch module will display as illustrated below.

• ellecht- CISCO • ellecht- CISCO • ellecht- CISCO • ellecht- CISCO • ellecht- CISCO • ellecht- CISCO • ellecht- CISCO • ellech	riticație CISCO CISCO CISCO CARANTA CARANTA CISCO CARANTA CARANTA CISCO CARANTA CARANTA CISCO CARANTA	sty emp	Aty clicitic cisco cisco me for the second s			empty	empty		
RF Switch on 192.168.6.91									
Module Information			Comment						
Serial Number:	AOI17190030		Comment 1:	Type Cor	mmen	t Text H	lere.		Save
Slot ID:	4		Comment 2:	Type Cor	mmen	t Text H	lere.		Save
Firmware Version:	V1.1								
Temperature:	32	°C	5	Switch M	/lode:	Man	ual	~	Save
				Switch S	State:	Path	A	~	Save
Path A			Path B						
RF Input Status:		Normal		1	RF Inp	ut Statu	S:		Normal
RF Input Level:	9.9	dBmV							

Monitoring Interfaces, Continued

Basic Parameter	Description
Module Basic Information	
Module Node Location	Shows the node IP where the modules are located
S/N	Shows module serial number
Slot ID	Shows the slot ID the module is placed
Module Firmware Version	Shows firmware version
Module Temperature	Shows the current module temperature (°C)
RF Input Information	
RF Input Status in Channel A/B	Shows RF input status in channel A/B

The table below lists the basic parameters of the OptoStar II RF switch module.

Setup Parameters

The table below lists the setup parameters of the OptoStar II RF switch module.

Setup Parameters	Description	Factory Default				
RF Input Informa	RF Input Information					
Switching Mode Selection	Shows/sets Auto/Manual switching mode	Auto switching mode				
Channel A/B Selection	Shows/sets channel A/B	Channel A				
Comment						
Comment	You may add applicable comments as required.	None				

Chapter 4 Troubleshooting

Overview

This chapter describes the troubleshooting procedures for the OptoStar II network management system (NMS).

Qualified Personnel

Only appropriately qualified and skilled personnel should attempt to install and operate this software. Otherwise, equipment damage may occur.

In This Chapter

Торіс	See Page
General Troubleshooting Information	4-2

This troubleshooting information describes the most common errors and gives typical troubleshooting procedures.

Error 1

The installation order of IIS and .NET Framework

Error Description

Microsoft .Net Framework 4.0 must be installed after the installation of IIS. Otherwise the asp.net interface cannot be resolved properly. If Microsoft .Net Framework 4.0 has been installed before the installation of IIS, please follow the instructions below (taking Windows 7 as an example):

Troubleshooting

1. Click Start -> All Programs -> Accessories -> right click Command prompt, and then select Run as administrator.



General Troubleshooting Information, Continued

- For 32-bit system, enter
 C:\Windows\Microsoft.NET\Framework\v4.0.30319\aspnet_regiis.exe
 -i, and press the return key to confirm;
- For 64-bit system, enter
 C:\Windows\Microsoft.NET\Framework64\v4.0.30319\aspnet_regiis.ex
 e -i, and press the return key to confirm;

Take 64-bit system as an example as illustrated below:

Administrator: C:\Windows\system32\cmd.exe	
Microsoft Windows [Version 6.1.7600] Copyright (c) 2009 Microsoft Corporation. All rights reserved.	<u>^</u>
C:\Users\Administrator>C:\Windows\Microsoft.NET\Framework64\u4.0.3031 giis.exe —i Start installing ASP.NET (4.0.30319).	9\aspnet_re
Finished installing ASP.NET <4.0.30319>.	
C:\Users\Administrator>_	
	~

Error 2

User "NT AUTHORITY\NETWORK SERVICE" login failed.

Error Description

See the screenshot below.

(会) (益 http://192.168.4.215/Account/L P * 20 益 Can not open database ×	6 🕁 🖲
Server Error in '/' Application.	
Can not open the database "web_nms_db". Login failed. User 'NT AUTHORITY'NETWORK SERVICE' login failed. Description: A unhandled exception occurred duing the execution of the current web request. Please review the stack trace for more information about the error and where it originated in the code.	
Exception Details: System Data SqlClant SqlException: Can not open the database "web_nms_db", Login failed. User NT AUTHORITYNETWORK SERVICE' login failed.	
Source Error:	
An unhandled exception was generated during the execution of the current web request. Information regarding the origin and location o identified using the exception stack trace below.	of the exception can be
Stack Trace:	
[SqlException (0x80331904): Can not open the database "web_mms_db". Login failed. User 'NT AUTHORTY/NETWORK SERVICE' login failed.] System. Data.Sql[inet.Sql]internalConnection.Gmfror(SqlException exception, Boolean breakCannection):s538927 System. Data.Sql[inet.Sql]internalConnection(SclException exception); Boolean breakCannection):s538927 System. Data.Sql[inet.Sql]internalConnection(Sc.Completeiogui(Boolean endisoternal exception); Boolean treakCannection); Boolean redirectedUserInstance, SqlCorn System. Data.Sql[internalConnection(SclException); Boolean endisoternalConnection(SclException); Boolean redirectedUserInstance, SqlCorn System. Data.Sql[internalConnection(SclException); Boolean endisoternalConnection(SclException); Boolean redirectedUserInstance, SqlCorn System. Data.SqlCient.SqlInternalConnection(SclException); Boolean endisoternalConnection(SclException); Boolean redirectedUserInstance, SqlCorn System. Data.SqlCient.SqlInternalConnection(SclException); Boolean endisoternalConnection(SclException); Boolean redirectedUserInstance, SqlCorn System. Data.SqlCient.SqlInternalConnection(SclException); Boolean endisoternalConnection(SclException); Boolean redirectedUserInstance, SqlCorn System.Data.SqlCient.SqlInternalConnection(SclException); Boolean endisoternalConnection(DeConnection); Boolean endisoternol,	ndler, TdsParserStateObjec meti na omingObjeck, SaC metion, Zring newPassword, Sa Konnection owingConnectio tions) +49 Konnection, String excepti
<pre>[EntityException: The underlying provider failed on Open.] System.Data.EntityExtention: The Underlying provider failed on Open.] System.Data.Detect.Object.Object.Dobject.Object.Dobject.O</pre>	Connection, String exception
	>

Troubleshooting

- Start SQL Server Management Studio on the machine installed with SQL Server 2008, and connect to the database with Windows identity.
- 2. When logged in, point to Security -> Login in the left list, and right-click to select New.



General Troubleshooting Information, Continued

3. In the Login – New dialog box, enter "NT AUTHORITY\NETWORK SERVICE" as shown below:

🗄 Login - New			_ D X
Select a page	Script 🔻 🚺 Help		
General			
Server holes	Login name:	NT AUTHORITY\NETWORK SERVICE	Search
Securables	Windows authentication		
T Status	SQL Server authentication	ı	
	Password:		
	Confirm password:		
	Specify old password		
	Old password:		
1	✓ Enforce password polic	IY	
	🖌 Enforce password expir	ation	
	📝 User must change passw	vord at next login	
	Mapped to certificate		-
	Mapped to asymmetric key		-
	🥅 Map to Credential		▼ Add
	Mapped Credentials	Credential Provider	
Connection			
Server: PC201308121801\SQLEXPRESS			
Connection:			
View connection properties			
Progress			
Ready			Remove
and the second s	Default database:	master	•
	Default language:	<pre> default></pre>	•
		OK	Cancel

General Troubleshooting Information, Continued

4. On the User Mapping page, check web_nms_db and db_owner as shown below:

Select a page	.			
P General	🔄 Script 🔻 🎦 Help			
Server Roles	Users mapped to this log	in:		
Securales	Map Database master model msdb tempdb web_mms_db Guest account enabled	User NT AUTHORITY\NET	Default Schema	
Connection	Database role membership	for: web_nms_db		
Server .	db_accessadmin db_backupoperator			
PC201308121801\SQLEXPRESS Connection: PC201308121801\Administrator View connection properties rogress Ready Ready	 db.datareader db.datareader db.datadnin db.datadnin db.danydatareader db.denydatareader db.denydatareader db.genority db.genorityadmin y public 			

5. Click OK.

Additional Assistance

If you need additional assistance, telephone one of our customer support or your local service center. See *Customer Support Information* (on page 5-1) for more details.

Chapter 5 Customer Support Information

Overview

This chapter contains information on obtaining product support.

In This Chapter

Topic	Page
Obtaining Product Support	5 - 2
Return for Repairing	5 - 4

IF	THEN
you have general questions about this product	Contact your distributor or sales agent for product information or refer to product data sheets on www.cisco.com.
you have technical questions about this product	Call the nearest Technical Service center or Cisco office.
you have customer service questions or need a return material authorization (RMA) number	Call the nearest Customer Service center or Cisco office.

Support Telephone Numbers

This table lists the Technical Support and Customer Service numbers for your area.

Region	Centers	Telephone and Fax Numbers
North America	Atlanta, Georgia United States	For Technical Support, call:
		Toll-free: 1-800-722-2009
		Local: 678-277-1120 (Press 2 at the prompt)
		For <i>Customer Service</i> , call:
		Toll-free: 1-800-722-2009
		Local: 678-277-1120 (Press 3 at the prompt)
		Fax: 770-236-5477
		E-mail: customer-service@cisco.com
Europe, Middle East, Africa	Belgium	For Technical Support, call:
		Telephone: 32-56-445-197 or 32-56-445-155
		Fax: 32-56-445-061
		For <i>Customer Service</i> , call:
		Telephone: 32-56-445-444
		Fax: 32-56-445-051
		E-mail: service-elc@cisco.com
Japan	Japan	Telephone: 82-2-3429-8800
		Fax: 82-2-3452-9748
		E-mail: songk@cisco.com

Obtaining Product Support, Continued

Region	Centers	Telephone and Fax Numbers
Korea	Korea	Telephone: 82-2-3429-8800
		Fax: 82-2-3452-9748
		E-mail: songk@cisco.com
China (mainland)	China	Telephone: 86-21-2401-4433
		Fax: 86-21-2401-4455
		E-mail: repaircentercn@external.cisco.com
All other Asia-Pacific countries & Australia	Hong Kong	Telephone: 852-2588-4746
		Fax: 852-2588-3139
		E-mail: support.apr@sciatl.com
Brazil	Brazil	Telephone: 11-55-08-9999
		Fax: 11-55-08-9998
		E-mail: fattinl@cisco.com or ecavalhe@cisco.com
Mexico, Central America, Caribbean	Mexico	For <i>Technical Support</i> , call:
		Telephone: 52-3515152599
		Fax: 52-3515152599
		For <i>Customer Service</i> , call:
		Telephone: 52-55-50-81-8425
		Fax: 52-55-52-61-0893
All other Latin America countries	Argentina	For Technical Support, call:
		Telephone: 54-23-20-403340 ext 109
		Fax: 54-23-20-403340 ext 103
		For Customer Service, call:
		Telephone: 770-236-5662
		Fax: 770-236-5888
		E-mail: keillov@cisco.com

Return for Repairing

Introduction

Before returning your product, you must obtain a Return Material Authorization (RMA) number. Call the nearest Customer Service center and follow their instructions.

Procedures of returning your product to Cisco for repairing:

- Obtain RMA number and mailing address
- Package and mail the product to be repaired

Obtain RMA number and mailing address

Before return your products, you must obtain a RMA number.

RMA number is valid for 60 days. If your RMA number expires, you must call your customer service representative to update it before returning your equipment. You can return your product after updating the RMA number. Otherwise, your RMA application may be postponed.

Follow the procedures below to obtain your RMA number and mailing address:

- 1. Contact your customer service representative to apply for a new RMA number, or update an existing RMA number. Obtain customer service numbers for your area in *Obtaining Product Support* (on Page 5-2).
- 2. Provide the following information to your customer service representative:

• Company name, contact person, telephone number, e-mail address and fax number.

- Product name, model, part number, SN (if any)
- Number of returned products
- Return reason and Repairing/Maintenance Permissions
- Any related service detail
- 3. When your customer service representative sends a RMA number to you, you will be required to fill in a purchase order or make advance payment to cover estimated repair costs.

Note: Users who pay by credit card or cash will receive a proforma invoice after the repair work is completed, which lists breakdown of repair costs.

Within 15 days upon your receipt of the proforma invoice, the customer service center must receive a purchase order number. During the warranty period, product subject to destruction, misuse, modification, or no problems found would generate costs. The product with additional generated costs will not be returned to the customer until valid P/O number is received.

 Users can confirm receipt of the RMA number via e-mail or fax. The RMA will list details such as RMA number, verified products to be returned and number of returned products, mailing address and RMA clauses.
 Note: Also, users can obtain and complete a RMA application form, and send it to customer service representative via fax, or e-mail: <u>repaircentercn@external.cisco.com</u>

Packaging and Mailing

Follow the steps below to package and return your product to Cisco.

Do you have the original packaging boxes and packaging materials?

- Yes: use the original packaging boxes and packaging materials to package your product
- No: use sturdy corrugated cardboard box meeting transportation requirements to package your product, and fill with packing materials.

Important: Users are responsible for safely mailing products to Cisco without any damage. Products with damage caused during transportation and due to improper packaging will be refused and returned to the user. In such case, the costs will be borne by the user.

Note: Do not return any power cable, accessory cable, or other accessories. Your customer service representative will provide specific instructions on how to order and replace any power cable, accessory cable, or other accessories.

Please fill in the following information on the external surface of the shipping box:

- RMA number
- User name
- Full address of the user
- Telephone number of the user
- "Attention: Factory Service"

Important: RMA number must be clearly marked on all returned products, packaging boxes, and accompanying documents. If the RMA number received by the factory service department is illegible, the RMA handling procedures will be delayed. The recipient for all returned products must be "Factory Services".

Returned products must be mailed to the address specified on the confirmation email or fax sent by the customer service representative.

Note: Cisco does not accept Freight Collect. Make sure that you choose freight prepaid method and purchase transportation insurance. The user should bear both freights to Cisco and all related import and export tariffs for any returned product, whether it's within the warranty period or not. For the product within the warranty period, Cisco will pay the freight when shipping repaired product to the user.

International Transportation: Fill in Cisco as International Transport Recipient, and state the notified party on the waybill as "international freight transport clearance contact".

Upon delivery of the equipment with complete RMA number, the receiving department will notify the user via fax or e-mail, and confirm the received products and the quantity. Please carefully check the confirmation letter to ensure that the products and the quantity received by Cisco are consistent with your shipment information.



Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000 800 553-6387 Fax: 408 527-0883

This document includes various trademarks of Cisco Systems, Inc. Please see the Notices section of this document for a list of the Cisco Systems, Inc. trademarks used in this document. Product and service availability are subject to change without notice. © 2013-2014 Cisco and/or its affiliates. All rights reserved.

July 2014

Part Number OL-29665-03