

Cisco OptoStar II Optical Switch Module (Optical Switch)

Installation and Operation Guide

For Your Safety

Explanation of Warning and Caution Icons



Avoid personal injury and product damage! Do not proceed beyond any A 🕒 🛦 symbol until you fully understand the indicated conditions.

> The following warning and caution icons alert you to important information about the safe operation of this product:



This symbol indicates important operating or maintenance instructions.

You may find this symbol affixed to the product. This symbol indicates a live terminal where a dangerous voltage may be present; the tip of the flash points to the terminal device.

You may find this symbol affixed to the product. This symbol indicates a protective ground terminal.

You may find this symbol affixed to the product. This symbol indicates a chassis terminal (normally used for equipotential bonding).

You may find this symbol affixed to the product. This symbol warns of a potentially hot surface.

You may find this symbol affixed to the product and in this document. This symbol indicates an infrared laser that transmits intensity-modulated light and emits invisible laser radiation or an LED that transmits intensitymodulated light.

Important

Please read this entire guide. If this guide provides installation or operation instructions, give particular attention to all safety statements included in this guide.

Notices

Trademark Acknowledgments

Cisco, Cisco Systems, the Cisco logo, the Cisco Systems logo, and ROSA are trademarks or registered trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries. To view a list of cisco trademarks, go to this URL: www.cisco.com/go/trademarks.

Third party trademarks mentioned are the property of their respective owners.

Publication Disclaimer

Cisco Systems, Inc. assumes no responsibility for errors or omissions that may appear in this publication. We reserve the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

Copyright

© 2013-2014 Cisco Systems, Inc. All rights reserved. Published in China.

Information in this publication is subject to change without notice. No part of this publication may be reproduced or transmitted in any form, by photocopy, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, for any purpose, without the express permission of Cisco Systems, Inc.

Contents

Important Sa	afety Instructions	vi
	y	
Chapter 1	Introduction	
Introduction	n	1-3
	Description	1-3
	Features	1-3
	Block Diagram	1-3
Structure		1-4
	Dimension	1-4
	Module Parts	1-4
	Panel Illustration	1-5
	Panel Functions	1-6
Chapter 2	Installation and Configuration	
Before You	begin	2-2
	Tools	2-2
	Unpacking and Inspecting the Module	2-2
Installing th	ne Chassis	
	Chassis Location in Rack	2 - 3
	Operating Temperature	2 - 3
	Verify Rack Dimensions	
Installing/F	Removing the Modules	2-4
O.	To Install the Module	2-4
	To Remove the Module	2-5
Connectors		2-6
	Fiber Connections	2-6
Care and Cl	leaning of Optical Connectors	
	Cleaning of Optical Connectors Overview	
	Recommended Equipment	
	Tips for Optimal Optical Connector Performance	
	To Clean Optical Connectors	

Chapter 3 Operation Starting up the Module3-2 Signal Inspection 3-2 Keypad Operations 3-4 Sub-Menu 2 -- Channel Control......3-8 Sub-Menu 3 -- Optical Wavelength Select......3-10 Sub-Menu 5 -- Alarm Information3-12 Operating using Console Software......3-14 Before You Begin......3-14 Software Main Interface 3-16

Contents, Continued

Chapter 4	Troubleshooting	
Maintenanc	re	4-2
	Maintenance Record	4-2
General Tro	oubleshooting Information	4-3
	Equipment Needed	4-3
	Additional Assistance	4-3
	Troubleshooting	4-4
Chapter 5	Customer Support Information	
Obtaining P	Product Support	5-2
	Support Telephone Numbers	5-2
Return for r	epairing	5-4
	Introduction	5-4
	Obtain the RMA number and mailing address	5-4
	Packaging and Mailing	

Important Safety Instructions

Read and Retain Instructions

Carefully read all safety and operating instructions before operating this equipment, and retain them for future reference.

Follow Instructions and Heed Warnings

Follow all operating instructions. Pay attention to all warnings and cautions in the operating instructions, as well as those that are affixed to this equipment.

Terminology

The terms defined below are used in this document. The definitions given are based on those found in safety standards.

Service Personnel-The term service personnel applies to trained and qualified individuals who are allowed to install, replace, or service electrical equipment. The service personnel are expected to use their experience and technical skills to avoid possible injury to themselves and others due to hazards that exist in service and restricted areas.

User and Operator-The terms user and operator apply to persons other than service personnel.

Ground(ing) and Earth(ing)-The terms ground(ing) and earth(ing) are synonymous. This document uses ground(ing) for clarity, but it can be interpreted as having the same meaning as earth(ing).

Electric Shock Hazard

This equipment meets applicable safety standards. Refer to this equipment's data sheet for details about regulatory compliance approvals.



🔼 WARNING:

Avoid electric shock! Opening or removing the equipment cover may expose you to dangerous voltages. Refer all servicing to qualified service personnel only.

Electric shock can cause personal injury or even death. Avoid direct contact with dangerous voltages at all times.

Know the following safety warnings and guidelines:

- Only qualified service personnel are allowed to perform equipment installation or replacement.
- Only qualified service personnel are allowed to remove equipment covers and access any of the components inside the chassis.

Grounding

- Do not violate the protective grounding by using an extension cable, power cable, or autotransformer without a protective ground conductor.
- Take care to maintain the protective grounding of this equipment during service or repair and to re-establish the protective grounding before putting this equipment back into operation.

Installation Site

When selecting the installation site, comply with the following:

- **Protective grounding** The protective ground lead of the building's electrical installation should comply with national and local requirements.
- Environment Condition The installation site should be dry, clean, and ventilated. Do not use this equipment where it could be at risk of contact with water. Ensure that this equipment is operated in an environment that meets the requirements as stated in this equipment's technical specifications, which may be found on this equipment's data sheet.

Installation Requirements



Allow only qualified service personnel to install this equipment. The installation must conform to all local codes and regulations.

Equipment Placement



WARNING:

Avoid personal injury and damage to this equipment. An unstable mounting surface may cause this equipment failure.

To protect against equipment damage or injury to personnel, comply with the following:

- Install this equipment in a restricted access location.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other equipment (including amplifiers) that produce heat.
- Place this equipment close enough to a mains AC outlet to accommodate the length of this equipment's power cord.
- Route all power cords so that people cannot walk on, place objects on, or lean objects against them. This may pinch or damage the power cords. Pay particular attention to power cords at plugs, outlets, and the points where the power cords exit this equipment.
- Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with this equipment.
- Make sure the mounting surface or rack is stable and can support the size and weight of this equipment.
- The mounting surface or rack should be appropriately anchored according to manufacturer's specifications. Ensure this equipment is securely fastened to the mounting surface or rack where necessary to protect against damage due to any disturbance and subsequent fall.

Ventilation

This equipment has openings for ventilation to protect it from overheating. To ensure equipment reliability and safe operation, do not block or cover any of the ventilation openings. Install the equipment in accordance with the manufacturer's instructions.

Rack Mounting Safety Precautions

Mechanical Loading

Make sure that the rack is placed on a stable surface. If the rack has stabilizing devices, install these stabilizing devices before mounting any equipment in the rack.



WARNING:

Avoid personal injury and damage to this equipment. Mounting this equipment in the rack should be such that a hazardous condition is not caused due to uneven mechanical loading.

Reduced Airflow

When mounting this equipment in the rack, do not obstruct the cooling airflow through the rack. Be sure to mount the blanking plates to cover unused rack space. Additional components such as combiners and net strips should be mounted at the back of the rack, so that the free airflow is not restricted.



A CAUTION:

Installation of this equipment in a rack should be such that the amount of airflow required for safe operation of this equipment is not compromised.

Elevated Operating Ambient Temperature

Only install this equipment in a humidity- and temperature-controlled environment that meets the requirements given in this equipment's technical specifications.



🔼 CAUTION:

If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient temperature. Therefore, install this equipment in an environment compatible with the manufacturer's maximum rated ambient temperature.

Handling Precautions

When moving a cart that contains this equipment, check for any of the following possible hazards:



WARNING:



Avoid personal injury and damage to this equipment! Move any equipment and cart combination with care. Quick stops, excessive force, and uneven surfaces may cause this equipment and cart to overturn.

- Use caution when moving this equipment/cart combination to avoid injury from tip-over.
- If the cart does not move easily, this condition may indicate obstructions or cables that may need to be disconnected before moving this equipment to another location.
- Avoid quick stops and starts when moving the cart.
- Check for uneven floor surfaces such as cracks or cables and cords.

Grounding

This section provides instructions for verifying that the equipment is properly grounded.

Safety Plugs (USA Only)

This equipment is equipped with either a 3-terminal (grounding-type) safety plug or a 2-terminal (polarized) safety plug. The wide blade or the third terminal is provided for safety. Do not defeat the safety purpose of the grounding-type or polarized safety plug.

To properly ground this equipment, follow these safety guidelines:

• **Grounding-Type Plug -** For a 3-terminal plug (one terminal on this plug is a protective grounding pin), insert the plug into a grounded mains, 3-terminal outlet.

Note: This plug fits only one way. If this plug cannot be fully inserted into the outlet, contact an electrician to replace the obsolete 3-terminal outlet.

• **Polarized Plug -** For a 2-terminal plug (a polarized plug with one wide blade and one narrow blade), insert the plug into a polarized mains, 2-terminal outlet in which one socket is wider than the other.

Note: If this plug cannot be fully inserted into the outlet, try reversing the plug. If the plug still fails to fit, contact an electrician to replace the obsolete 2-terminal outlet.

Grounding Terminal

If this equipment is equipped with an external grounding terminal, attach one end of an 18-gauge wire (or larger) to the grounding terminal; then, attach the other end of the wire to a ground, such as a grounded equipment rack.

Safety Plugs (European Union)

• Class I Mains Powered Equipment - Provided with a 3-terminal AC inlet and requires connection to a 3-terminal mains supply outlet via a 3-terminal power cord for proper connection to the protective ground.

Note: The equipotential bonding terminal provided on some equipment is not designed to function as a protective ground connection.

• Class II Mains Powered Equipment - Provided with a 2-terminal AC inlet that may be connected by a 2-terminal power cord to the mains supply outlet. No connection to the protective ground is required as this class of equipment is provided with double or reinforced and/or supplementary insulation in addition to the basic insulation provided in Class I equipment.

Note: Class II equipment, which is subject to EN 50083-1, is provided with a chassis mounted equipotential bonding terminal. See the section titled Equipotential Bonding for connection instructions.

Equipotential Bonding

If this equipment is equipped with an external chassis terminal marked with the IEC 60417-5020 chassis icon (), the installer should refer to CENELEC standard EN 50083-1 or IEC standard IEC 60728-11 for correct equipotential bonding connection instructions.

AC Power

Important: If this equipment is a Class I equipment, it must be grounded.

- If this equipment plugs into an outlet, the outlet must be near this equipment, and must be easily accessible.
- Connect this equipment only to the power sources that are identified on the equipment-rating label normally located close to the power inlet connector(s).
- This equipment may have two power sources. Be sure to disconnect all power sources before working on this equipment.
- If this equipment does not have a main power switch, the power cord connector serves as the disconnect device.
- Always pull on the plug or the connector to disconnect a cable. Never pull on the cable itself.
- Unplug this equipment when unused for long periods of time.

Connection to -48 V DC/-60 V DC Power Sources

If this equipment is DC-powered, refer to the specific installation instructions in this manual or in companion manuals in this series for information on connecting this equipment to nominal -48 V DC/-60 V DC power sources.

Circuit Overload

Know the effects of circuit overloading before connecting this equipment to the power supply.



A CAUTION:

Consider the connection of this equipment to the supply circuit and the effect that overloading of circuits might have on overcurrent protection and supply wiring. Refer to the information on the equipment-rating label when addressing this concern.

General Servicing Precautions



WARNING:

Avoid electric shock! Opening or removing the equipment cover may expose you to dangerous voltages. Refer all servicing to qualified service personnel only.



CAUTION:

These servicing precautions are for the guidance of qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than contained in the operating instructions unless you are qualified to do so. Refer all servicing to qualified service personnel.

Be aware of the following general precautions and guidelines:

- Servicing Servicing is required when this equipment has been damaged in any
 way, such as power supply cord or plug is damaged, liquid has been spilled or
 objects have fallen into this equipment, this equipment has been exposed to rain or
 moisture, does not operate normally, or has been dropped.
- Wristwatch and Jewelry For personal safety and to avoid damage of this equipment during service and repair, do not wear electrically conducting objects such as a wristwatch or jewelry.
- **Lightning** Do not work on this equipment, or connect or disconnect cables, during periods of lightning.
- **Labels** Do not remove any warning labels. Replace damaged or illegible warning labels with new ones.
- Covers Do not open the cover of this equipment and attempt service unless instructed to do so in the instructions. Refer all servicing to qualified service personnel only.
- **Moisture** Do not allow moisture to enter this equipment.
- Cleaning Use a damp cloth for cleaning.
- **Safety Checks** After service, assemble this equipment and perform safety checks to ensure it is safe to use before putting it back into operation.

Electrostatic Discharge

Electrostatic discharge (ESD) results from the static electricity buildup on the human body and other objects. This static discharge can degrade components and cause failures.

Take the following precautions against electrostatic discharge:

- Use an anti-static bench mat and a wrist strap or ankle strap designed to safely ground ESD potentials through a resistive element.
- Keep components in their anti-static packaging until installed.
- Avoid touching electronic components when installing a module.

Fuse Replacement

To replace a fuse, comply with the following:

- Disconnect the power before changing fuses.
- Identify and clear the condition that caused the original fuse failure.
- Always use a fuse of the correct type and rating. The correct type and rating are indicated on this equipment.

Continued on next page

xii Safety OL-29670-02

Batteries

This product may contain batteries. Special instructions apply regarding the safe use and disposal of batteries:

Safety

- Insert batteries correctly. There may be a risk of explosion if the batteries are incorrectly inserted.
- Do not attempt to recharge 'disposable' or 'non-reusable' batteries.
- Please follow instructions provided for charging 'rechargeable' batteries.
- Replace batteries with the same or equivalent type recommended by manufacturer.
- Do not expose batteries to temperatures above 100°C (212°F).

Disposal

- The batteries may contain substances that could be harmful to the environment
- Recycle or dispose of batteries in accordance with the battery manufacturer's instructions and local/national disposal and recycling regulations.









• The batteries may contain perchlorate, a known hazardous substance, so special handling and disposal of this product might be necessary. For more information about perchlorate and best management practices for perchlorate-containing substance, see www.dtsc.ca.gov/hazardouswaste/perchlorate.

Modifications

This equipment has been designed and tested to comply with applicable safety, laser safety, and EMC regulations, codes, and standards to ensure safe operation in its intended environment. Refer to this equipment's data sheet for details about regulatory compliance approvals.

Do not make modifications to this equipment. Any changes or modifications could void the user's authority to operate this equipment.

Modifications have the potential to degrade the level of protection built into this equipment, putting people and property at risk of injury or damage. Those persons making any modifications expose themselves to the penalties arising from proven non-compliance with regulatory requirements and to civil litigation for compensation in respect of consequential damages or injury.

Accessories

Use only attachments or accessories specified by the manufacturer.

Electromagnetic Compatibility Regulatory Requirements

This equipment meets applicable electromagnetic compatibility (EMC) regulatory requirements. Refer to this equipment's data sheet for details about regulatory compliance approvals. EMC performance is dependent upon the use of correctly shielded cables of good quality for all external connections, except the power source, when installing this equipment.

• Ensure compliance with cable/connector specifications and associated installation instructions where given elsewhere in this manual.

Otherwise, comply with the following good practices:

- Multi-conductor cables should be of single-braided, shielded type and have conductive connector bodies and backshells with cable clamps that are conductively bonded to the backshell and capable of making 360° connection to the cable shielding. Exceptions from this general rule will be clearly stated in the connector description for the excepted connector in question.
- Ethernet cables should be of single-shielded or double-shielded type.
- Coaxial cables should be of the double-braided shielded type.

Restriction of Hazardous Substances Directive (RoHS) Requirements

The equipment conforms to the restriction of hazardous substances directive in electrical and electronic equipment (RoHS) requirements.

xiv Safety OL-29670-02

Laser Power and Warning Labels

Warning Labels

The following labels are located on this product.







Location of Labels on Equipment

The following illustrations display the location of warning labels on this equipment.







Chapter 1 Introduction

Overview

The OptoStar II optical platform is an advanced transmission system, designed to optimize network architectures and increase reliability, scalability, and cost effectiveness.

This chapter introduces the features and structure of the OptoStar II optical switch module.

Purpose

This document provides information about the installation, configuration, operation, and troubleshooting of the OptoStar II optical switch module.

Who Should Use This Document

This document is intended for authorized service personnel who have experience working with similar equipment. The service personnel should have appropriate background and knowledge to complete the procedures described in this document.

Qualified Personnel



Allow only qualified and skilled personnel to install, operate, maintain, and service this product. Otherwise, personal injury or equipment damage may occur.

Only appropriately qualified and skilled personnel should attempt to install, operate, maintain, and service this product.

Scope

This guide discusses the following topics.

- Optical switch module description
- Installation and configuration
- Operating instructions
- Troubleshooting
- Customer support information

Document Version

This is the second release of this document.

Overview, Continued

In This Chapter

Topic	Page
Introduction	1 - 3
Structure	1 - 4

Introduction

Description


The OptoStar II optical switch module uses a standard 19-in OptoStar II chassis. The flexibility of the platform is greatly improved by the fact that a single chassis can hold both the optical switch module and other OptoStar II modules. 14 optical switch modules can be placed in one standard 3 RU OptoStar II chassis. In many modern optical systems, optical receivers and optical transmitters can be set up in backup mode, with a main module and a backup module. In the OptoStar II platform, the optical switch module can be used to control, switch, and backup optical signal, in order to improve network reliability.

Features

- 2X1 switching
- Support 1270 to 1610 nm optical wavelength
- Wide dynamic range of power: -15 ~ +25 dBm
- Automatic and manual optical port switching
- Front panel LED indicates module status and alarm status
- Intelligent Communications Interface Module (ICIM) provides various configuration and control options
 - Local monitoring and control on the ICIM LCD screen
 - Local monitoring and control with ICIM Mini-USB interface connecting to the console on PC
 - Remote status monitoring (SNMP) with ICIM RJ-45 interface
- Firmware is upgradeable
- Hot-swap capability

Block Diagram


The following block diagram shows the signal pathway of the OptoStar II optical switch module.



Structure

Dimension

The dimensions of the OptoStar II optical switch module are shown below. (Unit: mm)




Module Parts

The following table lists the parts of the OptoStar II optical switch module.

Part	Function
Module Housing	Includes side panels, front panel, and rear panel.
Front Panel	Includes LEDs, optical input/output ports, and mounting screw.
Rear Panel	Includes a 30-pin Connector.

Panel Illustration

The following illustration shows the panels of the OptoStar II optical switch module.



Structure, Continued

Panel Functions

The following table lists the functions of the front panel indicators on the OptoStar II optical switch module.

Description	Function	
Power LED	Red/Green Indicator	Blinks in red and green: when the module is starting up
		Green: normal power supply
	Red/Green Indicator	Green: module is in normal working condition
Alarm LED		Red: module is not working properly, and alarm occurs

The following table lists other functions of the OptoStar II optical switch module front panel.

Description	Function	
Optical Input/Output	Optical inport/output with SC/APC connector	
Mounting Screws	Mounts the module in the chassis	

The following table shows the functions of the OptoStar II optical switch module rear panel.

Description	Function
30-pin Connector	Power and communication connecter of the module, and provides module ID information.

Chapter 2 Installation and Configuration

Overview

This chapter provides instructions for installing the OptoStar II optical switch module.

Qualified Personnel

Only appropriately qualified and skilled personnel should attempt to install, operate, maintain, and service this product. Otherwise, personal injury or equipment damage may occur.

In This Chapter

Topic	Page
Before You Begin	2 - 2
Installing the Chassis	2 - 3
Installing/Removing the Modules	2 - 4
Connections	2 - 6
Care and Cleaning of Optical Connector	2 - 7

Before You Begin

Before you begin the installation procedure, make sure you have all the tools and the module ready.

Tools

The following tools and equipment are needed to install the module.

- Flat-head or round-head screws and washers
- Flat-head or Phillips-head screwdriver

Unpacking and Inspecting the Module

Please follow the steps below to unpack and inspect the module for any damage:

- 1. Inspect the shipping boxes for any damage;
- 2. Unpack all boxes and confirm that the contents are complete. Remove the module;

Note: Items in the packaging box include:

- One OptoStar II optical switch module
- One factory test report
- One Mounting Instruction
- 3. Inspect the appearance of the module for any shipping damage. In case of damage, document it and inform the shipping company and our customer support. See *Customer Support Information* (on page 5-1) for details.
- 4. Keep the shipping boxes and their inserts for any future reshipment for upgrade or repair.

Note: In the event that the module must be returned to the manufacturer, any shipment damage resulting from improper packaging will be the responsibility of the customer. Inspect the boxes and equipment for any damage upon receipt.

Installing the Chassis

Mount the empty chassis in the equipment rack, using flat or round head screws and washers in the four front panel corner mounting locations. This enables a secure mount of the unit on the chassis. You must use screws matching your rack.

Chassis Location in Rack

The chassis can be placed anywhere within the rack. Hot air discharged from other equipment must not be directed at the chassis front panel. Dust from the surrounding environment should not be ingested in the input airflow. The chassis can be mounted without any gap, directly above or below another chassis or other equipment that does not discharge hot air directly at the front panel of the chassis.

Operating Temperature

Make sure the unit is operated in a temperature and humidity-controlled environment. See the temperature specifications in the datasheet.

Note: The maximum operating ambient temperature is 50°C (122°F).

Long-term reliability is best obtained with consistently cool environments. Never place a unit near a heat source. Do not install a unit in areas of high humidity or where there is any chance of water or condensation dripping into or on the unit.

Verify Rack Dimensions

It is important to verify the rack dimensions to guarantee proper installation of the chassis. The minimum Telco rack dimensions needed for installation are as follows.

• The chassis weighs 6.6 kg and can be installed into a 19-in. rack. The maximum width of the chassis is 481 mm, and the width without mounting ears is 437 mm.

Installing/Removing the Modules

To Install the Module

Install the ICIM module and power supply module first. See *Cisco OptoStar II*Intelligent Communications Interface Module (ICIM) Installation and Operation
Guide, part number: OL-29660 and Cisco OptoStar II Chassis (CH) and Power
Supply (PS) Installation and Operation Guide, part number: OL-29659 for details.

Now you may start to install the OptoStar II optical switch module. Connect it to the rear panel connector of the chassis. Install the optical switch module as shown in the following illustration.




- 1. Select Slot 4 Slot 17.
- 2. Inspect all pins on the rear panel and confirm that they are not bent.
- 3. Hold module vertically with module front toward you.
- 4. Align the rib on lower side of the module with a guide slot in the chassis and align top rib with matching guide slot in the top of the chassis.
- 5. Slide module in smoothly until you feel slight resistance, then continue to push gently until the module connector seats completely.
 - **Note:** Check alignment if you feel significant resistance. Do not press hard, otherwise the connector may be damaged. When installing the module in the slot, ensure the proper connector alignment.
- 6. Tighten the mounting screws on the lower front panel of the module by hand or screwdriver, to secure the module in the chassis.
 - **Note:** The torque of mounting screw is 5 6 kgf·cm.
- 7. Repeat the steps above if more modules need to be installed.
- 8. Connect the fiber.


Installing/Removing the Modules, Continued

To Remove the Module

- 1. Remove the fiber connector from the front panel of the module, and cover the fiber and module connector with dust caps immediately.
- 2. Loosen the mounting screws on lower front panel of the module by hand or screwdriver, to release the module from the chassis.
- 3. Pull the module slightly to unseat the connector.
- 4. Hold the module and gently remove it from the chassis.

Note: Do not use the mounting screws as a handle when removing the module. Follow the steps as shown in the following illustration.





Connections

Fiber Connections

Although the modules may be hot-swapped when service must be restored, it is recommended that the chassis and modules are installed prior to powering up the chassis.

It is also recommended to connect fibers to the front panel before powering up the system. If fibers must be removed, it is recommended to disconnect power prior to removal to minimize possible exposure to laser radiation.

CAUTION:


Use only SC/APC terminated fiber to connect to modules. Clean the connector using recognized industry practices before connecting to any module to prevent performance degradation.

For fiber cleaning information, see *Care and Cleaning of Optical Connectors* (page 2-7).

CAUTION:

Optical transmitters may be powered on once installed in a powered chassis. Do not remove the dust cap on the front panel optical output port until it is ready to terminate the fiber, in order to reduce the risk of unintentional access to laser output.

See the illustration below for fiber connections.



Care and Cleaning of Optical Connector

Cleaning of Optical Connector Overview

Cleaning optical connectors can help prevent interconnect problems and maintain system performance. When optical connectors are disconnected or reconnected, the fiber surface can become dirty or scratched. The purpose of cleaning the optical connector is to remove all dusts and contaminants without leaving any residue.

Recommended Equipment

The following equipment is recommended to clean the mating surface of fiber connectors.

- CLETOP or OPTIPOP ferrule cleaner (CLETOP Type A for SC connectors, and Type B for LC connectors)
- Compressed air (also called "canned air")
- Lint-free wipes moistened with optical-grade (99%) isopropyl alcohol
- Bulkhead swabs for LC or SC connectors (choose the appropriate type)
- Optical connector scope

Tips for Optimal Optical Connector Performance

Follow the instructions below to ensure stable performance from optical connectors.

- Do not connect or disconnect optical connectors with optical power present.
- Always use compressed air before cleaning the optical connectors.
- Always install end caps on connectors when they are not in use.
- Always use compressed air to clean the connector end caps.
- If you have any degraded signal problems, clean the optical connector.
- Advance a clean portion of the ferrule cleaner reel for each cleaning.
- Turn off optical power before making or breaking optical connections to avoid microscopic damage to fiber mating surfaces.

Care and Cleaning of Optical Connector, Continued

To Clean Optical Connector

Warning:

Avoid personal injury. Use of controls, adjustments, or procedures other than those specified herein may result in hazardous radiation exposure.

Avoid personal injury. The laser light source on this module or the fiber cables connected to this module emits invisible laser radiation.

Avoid personal injury. Viewing the laser output or fiber with optical instruments (such as eye loupes, magnifiers, or microscopes) may pose an eye hazard.

- Do not apply power to this equipment if the fiber is unmated or unterminated.
- Do not stare into an unmated fiber or at any mirror-like surface that could reflect light emitted from an unterminated fiber.
- Do not view the fiber in use with optical instruments (such as eye loupes, magnifiers, or microscopes).
- Use safety-approved fiber cable to maintain compliance with applicable laser safety requirements.

Important: Ensure that no optical power is present prior to this procedure.

- 1. Turn optical power off from the connector.
- 2. Inspect the connector for scratches, burns, or other signs of damage using an optical connector scope.
 - **Note:** If the connector is damaged, replace the jumper.
- 3. If the connector requires cleaning, swipe it across the surface of appropriate ferrule cleaner several times.
 - **Result:** This will remove dust and some films.
 - **Note:** You may hear a slight "squeak" while cleaning the connector, indicating that it is clean.
- 4. Inspect the connector again. If the connector requires further cleaning, clean it using 99% isopropyl alcohol and a lint-free wipe.
- 5. Swipe the connector across the surface of the appropriate ferrule cleaner several more times to remove any film left by the alcohol.
- 6. Repeat all the steps above as needed until the connector is clean.

Chapter 3 Operation

Overview

This chapter provides information on the 3 options to operate the OptoStar II optical switch module.

- Using the OptoStar II ICIM LCD to configure.
- Using the OptoStar II console to configure on PC.
- Using the OptoStar II network management system to configure on PC.

Qualified Personnel

Only appropriately qualified and skilled personnel should attempt to install, operate, maintain, and service this product. Otherwise, personal injury or equipment damage may occur.

In This Chapter

Topic	Page
Starting up the Module	3 - 2
Operating using ICIM LCD	3 - 3
Operating using Console Software	3 - 14
Operating using NMS Software	3 - 20

Starting up the Module

Initialization

When the OptoStar II optical switch module is powered on, the module will perform a self-test.

Follow these steps to perform the self-test:

- 1. Turn the front panel switch of the OptoStar II power supply module to ON position.
- 2. When the optical switch module starts up, it will perform a booting initialization for about 5 seconds.
- 3. During the initialization, the power LED and the alarm LED on the front panel will be illuminated, and the communication status is shut off.
- 4. Once the initialization is completed, the status indicator will return to normal. Communication is enabled and the module is operational.

CAUTION:

- The module must be initialized; any equipment that cannot be initialized must be returned to the manufacturer for repair.
- When everything becomes stable, the module still needs to warm up for at least one hour, to make sure that its performance is normal.

Signal Inspection

Check whether the A/B optical input power is between -15dBm and +25dBm with an optical power meter. Also use a power meter to check whether the optical output power is within the specifications.

Operating using ICIM LCD


This section describes how to use the OptoStar II ICIM LCD to operate the OptoStar II optical switch module.

Start

- 1. Make sure that the fiber cables of the OptoStar II optical switch module are connected.
- 2. Turn the front panel switch of the OptoStar II power supply module to ON position. The power supply module and the optical switch module will initialize for about 5 seconds, and the ICIM will load for about 25 seconds.

Note: The system will achieve optimal working condition after one hour's warm-up.

The LCD now displays ICIM loading screen as shown below.



3. When the device initialization is complete, remove the ICIM display and begin operation.

Operating using ICIM LCD, Continued

Standby Screen

OptoStar II ICIM uses a 4.3-inch color LCD screen. Below is the standby screen after the module has loaded.




Keypad Operations

The table below lists each key on the OptoStar II ICIM screen and its function.


Button	Function	
	In menu view, mode selection and function switch screens	Moves the cursor up
•	In reading configuration screen	Increases numerical readings
•	In menu view, mode selection and function switch screens	Moves the cursor down
	In reading configuration screen	Decreases numerical readings
◄	Moves to the previous page/Moves the cursor to the left	
>	Moves to the next page/Moves the cursor to the right	
SET	Configure/Save/Enter	
EXIT	Cancel/Return	

Module Main Menu

The illustration below shows the module main menu of the OptoStar II ICIM:



As shown in the illustration, all the local modules are located on the left side of the screen, you can press ▶ button to move to the next page, and view modules in other slots. The statuses of 8 fans are located on the right side of the screen.




Press ▼ button to move the cursor down to Optical Switch (OptoStar II optical switch module), and press the SET button to enter the sub-menu of the Optical Switch.

Operating using ICIM LCD, Continued

Module Sub-Menu


The illustration below shows the sub-menu of the OptoStar II optical switch module.



- The left side of the screen shows the sub-menus of the OptoStar II optical switch module. By default the cursor is on sub-menu 1. Press ▼ button to move the cursor down. Press SET button to enter the item on the sub-menu.
- The right side of the screen shows basic information of the module, including firmware version, chassis ID, S/N, module temperature, and alarm code.

Sub-Menu 1 -- Optical Input Information

The illustration below shows sub-menu 1 of the OptoStar II optical switch module - Optical Input Information.




By default, the optical input power switching threshold lower limit is -15 dBm, upper limit is 25 dBm. The setup range is -15 dBm to +25 dBm, with 0.1 dB step. The cursor stays in the "Low" field.

- To configure the lower limit of the optical power switching threshold (minimum output power is no less than -15 dBm):
 - 1. Press SET button to start the configuration;
 - 2. Press ▲ ▼ buttons to change the value, and press SET button to confirm;
 - 3. Press ▶ button to move the cursor to "Set";
 - 4. Press SET button to save the configuration.
- To configure the upper limit of optical power switching threshold (maximum output power is no more than 25 dBm):
 - 1. Press ▼ button to move the cursor to the "High" field;
 - 2. Press SET button to start the configuration;
 - 3. Press ▲ ▼ buttons to change the value, and press SET button to confirm;
 - 4. Press ▶ button to move the cursor to "Set";
 - 5. Press SET button to save the configuration.

The optical input power values of channel A and channel B can be viewed on the right side of the screen.

Sub-Menu 2 -- Channel Control

The illustration below shows sub-menu 2 of the OptoStar II optical switch module - Channel Control.



Factory default sets switching mode to Auto and channel A is set as the main channel for optical input. By default, the cursor is set on the Auto option and the module is set to work in auto switching mode. Press $\blacktriangle \blacktriangledown$ button to select auto or manual switching mode.

- To select auto switching mode:
 - 1. Press ▲ ▼ button to keep the symbol on "Auto" option;
 - 2. Press ▶ button to move the cursor to "Set";
 - 3. Press SET button to save the configuration.
- To select manual switching mode:
 - 1. Press ▲ ▼ button to keep the symbol on "Manual" option;
 - 2. Press ▶ button to move the cursor to "Set";
 - 3. Press SET button to start the configuration;

To switch between channel A and B manually, "Manual" must be selected in the Mode Selection screen, otherwise channel switching will be unavailable in auto switching mode.

- 1. Press ▲ ▼ button to keep the symbol on Channel A or Channel B option;
- 2. Press ▶ button to move the cursor to "Set";
- 3. Press SET button to save the configuration.


When the optical power switching threshold has been set up, the module will automatically compare the monitored optical input power in channel A and channel B with the optical input power switching threshold. If the optical input power in either channel A or channel B is out of the threshold, it will issue an alarm. The table below lists auto switching status under different conditions in the auto mode (1 stands for alarm; 0 stands for normal).

Itom	Alarm Status		Switching	Description	
Item A		В	Status	Description	
1	0	0	A	Working in channel A	
2	0	1	A	Working in channel A	
3*	1	0	В	Working in channel B	
4	1	1	A/B	Staying in the previous working channel	

Note: In item 3*, if the optical input in channel A is normal, it will switch to channel A automatically, with 1dB of delay.

Sub-Menu 3 -- Optical Wavelength Select

The illustration below shows sub-menu 3 of the OptoStar II optical switch module - Optical Wavelength Select.



The default input optical wavelength is 1310nm (1270 ~ 1410). Press ▲ ▼ button to select the required optical wavelength.


To select 1550nm optical wavelength:

- 1. Press ▼ button to keep the symbol on 1550nm (1410 ~ 1610) option;
- 2. Press ▶ button to move the cursor to "Set";
- 3. Press SET button to save the configuration.

You should set up this option according to the actual input optical wavelength, to avoid module error. If the optical wavelength is between 1270nm and 1410nm, select 1310nm (1270 \sim 1410). If the optical wavelength is between 1410nm and 1610nm, select 1550nm (1410 \sim 1610).

Sub-Menu 4 -- Alarm ON/OFF

The illustration below shows sub-menu 4 of the OptoStar II optical switch module - Alarm ON/OFF.




By default, the alarm is set to ON, and the cursor stays on "Set".

To change the alarm ON/OFF:

- 1. Press ▲ ▼ buttons to select alarm ON or OFF. The cursor always stays on "Set" on the right side of the screen;
- 2. Press SET button to save the configuration.


Sub-Menu 5 -- Alarm List

The illustration below shows sub-menu 5 of the OptoStar II optical switch module - Alarm List.



You can view the alarm information of the OptoStar II optical switch module.

- If there is no alarm, the Alarm List shows "None".
- If there is any alarm, the Alarm List shows alarm information and its code, as shown in the illustration below. See *Alarm Code List* (on page 3-13) for detailed alarm codes.



Alarm Code List

The table below lists the alarm information of the OptoStar II optical switch module.

Code	Item	Condition	LED
001	Low Optical Input Power in Channel A	Optical input power in channel A lower than -15dBm	Alarm LED is red
002	High Optical Input Power in Channel A	Optical input power in channel A higher than 25dBm	Alarm LED is red
003	Low Optical Input Power in Channel B	Optical input power in channel B lower than -15dBm	Alarm LED is red
004	High Optical Input Power in Channel B	Optical input power in channel B higher than 25dBm	Alarm LED is red
006	High Module Temperature	Module temperature higher than 85°C	Alarm LED is red

Operating using Console Software

This section introduces the procedures to use the OptoStar II console to manage the OptoStar II optical switch module.

Before You Begin

- One PC
- Mini-USB data cable
- OptoStar II console software installation package

System Requirements


- **Supported operation system:** Windows 7, Windows Vista, Windows Server 2003, and Windows XP
- **Processor:** 400 MHz Pentium or equivalent processor (minimum requirement); 1 GHz Pentium or equivalent processor (recommended)
- Memory: 96 MB (minimum requirement); 256 MB (recommended)
- Hard drive: 500 MB free space required
- **Monitor:** 800 x 600, 256-color (minimum requirement); 1024 x 768 high color, 32-bit (recommended)

Start

- 1. Make sure that the fiber and RF cable of the OptoStar II optical switch module are connected.
- 2. Turn the front panel switch of the OptoStar II power supply module to ON position. The power supply module and the optical switch module will initialize for about 5 seconds, and the ICIM will load for about 25 seconds.

Note: The system will achieve optimal working condition after one hour's warm-up.


3. When the device initialization is complete, connect the Mini-USB side of the USB cable provided with the ICIM to the Mini-USB interface of the ICIM front panel. The other side of the USB cable should be connected to the USB interface on the PC. Now the LCD screen shows USB connected, and the keypads below the LCD screen are temporarily unavailable. The illustration below shows the connection method.



4. Install and start the OptoStar II console software. See *Cisco OptoStar II Console Installation and Operation Guide*, P/N OL-29664 for detailed installation procedures.

Software Main Interface


The illustration below shows the main interface of the OptoStar II console.



The OptoStar II console main interface shows the software name, menus, menu shortcuts, local module tree view, system information, chassis fan status, and local module view.


Local Module View

Click to select the OptoStar II optical switch module in the Local Module Tree View on the left side of the screen, or in the Local Module View on the bottom of the screen. The parameter setting window of the optical switch module will pop up as shown below.



View Basic Parameters

The illustration below shows the parameter setting interface of the OptoStar II optical switch module.



The table below lists the basic parameters of the OptoStar II optical switch module.

Basic Parameter	Description
Module Name and Firmware Version	Shows the module name and its firmware version
Optical Input Power in Channel A/B	Shows optical input power in Channel A/B (dBm)
Module Temperature	Shows the current module temperature (°C)
S/N	Shows module serial number
Rack ID	Shows the ID of the rack where the chassis is placed
Slot ID	Shows the ID of the slot where the module is placed
Alarm Code	Shows the current module alarm code; See <i>Alarm Code List</i> (on page 3-13)

Setup Parameters

The table below lists the setup parameters of the OptoStar II optical switch module.

Setup Parameters	Description	Factory Default
Optical Alarm Threshold	Shows/sets optical alarm upper limit and lower limit	Lower limit: - 15 dBm Upper limit: + 25 dBm
Auto/Manual Switching Mode Selection	Shows/sets Auto/Manual switching mode	Auto switching mode
Channel A/B Selection	Shows/sets channel A/B	Channel A
Optical Wavelength Setup	Sets input optical wavelength	1310nm (1270nm ~ 1410nm)
Alarm ON/OFF	Shows/sets module alarm status: ON/OFF	Alarm status: ON

Operating using NMS Software

This section introduces the procedures to use the OptoStar II network management system (OptoStar II NMS) to manage the OptoStar II optical switch module.

Before You Begin

- One PC
- A network cable
- OptoStar II NMS software installation package

System Requirements


- Supported operation system: Windows 7, Windows Server 2008, Windows Vista, and Windows Server 2003
- **Processor:** 400 MHz Pentium or equivalent processor (minimum requirement); 1 GHz Pentium or equivalent processor (recommended)
- Memory: 512 MB (minimum requirement); 1GB (recommended)
- Hard drive: 500 MB free space required
- **Monitor:** 800 x 600, 256-color (minimum requirement); 1024 x 768 high color, 32-bit (recommended)

Start

- 1. Make sure that the fibers of the OptoStar II optical switch module are connected.
- 2. Turn the front panel switch of the OptoStar II power supply module to ON position. The power supply module and the optical switch module will initialize for about 5 seconds, and the ICIM will load for about 25 seconds.

Note: The system will achieve optimal working condition after one hour's warm-up.


3. When the device initialization is complete, connect to the Ethernet with the RJ-45 connector on the rear panel of the ICIM. Connect the PC to the Ethernet. The illustration below shows the connection method.



4. Install and start the OptoStar II NMS software. See *Cisco OptoStar II NMS Installation and Operation Guide*, P/N OL-29665 for detailed installation procedures.

Software Main Interface


The illustration below shows the main interface of the OptoStar II NMS.




The OptoStar II NMS main interface shows the software name, menus, node tree view, and welcome screen.

Local Module View

Select the topology tree view and view the corresponding node. The interface shows all the local modules as illustrated below.




Note: When there is alarm, the Alarm Management menu turns to red. The system interface is shown as below.



View Basic Parameters

Click to select the OptoStar II optical switch module in the interface which shows all the local modules. The parameter setting interface of the optical switch module will display as illustrated below.



The table below lists the basic parameters of the OptoStar II optical switch module.

Basic Parameter	Description	
Module Basic Information		
Module Node Location	Shows the IP of the node where the module is located	
S/N	Shows module serial number	
Slot ID	Shows the ID of the slot where the module is placed	
Module Firmware Version	Shows module firmware version	
Module Temperature	Shows the current module temperature (°C)	
Optical Power Input Information		
Optical Input Power in Channel A/B	Shows optical input power in Channel A/B (dBm)	

Setup Parameters

The table below lists the setup parameters of the OptoStar II optical switch module.

Setup Parameters	Description	Factory Default		
Optical Signal Input Ir	Optical Signal Input Information			
Switching Mode Selection	Shows/sets auto/manual switching mode	Auto switching mode		
A/B Channel Switch	Shows/sets A/B channel	Channel A		
Comment				
Comment	You may add applicable comments as required.	None		

Chapter 4 Troubleshooting

Overview

This chapter provides instructions for maintaining and repairing the OptoStar II optical switch module.

Qualified Personnel

Only appropriately qualified and skilled personnel should attempt to install, operate, maintain, and service this product. Otherwise, personal injury or equipment damage may occur.

In This Chapter

Topic	Page
Maintenance	4 - 2
General Troubleshooting Information	4 - 3

Maintenance

The following maintenance is recommended to ensure optimal performance.

Frequency	Maintenance Required	
Yearly	Check all parameters and test points	
	Make sure all cables are mated properly	
	Inspect cables for stress and deformation	
	Make sure all retaining screws are tight	
	Ensure good ventilation	
	Record data	
When Needed	Carefully clean the module with a soft cloth	

Maintenance Record

It may be helpful to establish a maintenance record or log for this module. You may want to record RF input signal, RF output signal, and module temperature.

Significant variation in any of the parameters above should be investigated to prevent failure.

General Troubleshooting Information

This troubleshooting information describes the most common alarms and gives typical troubleshooting procedures and causes.

Equipment Needed

You may need the following equipment to troubleshoot the module.

- Optical power meter
- Fiber connector cleaning materials

Additional Assistance

If you need additional assistance, please contact our customer support team or your local service center. See *Customer Support Information* (on page 5-1) for more details.

General Troubleshooting Information, Continued

Troubleshooting

If the red alarm indicator on the front panel of the module is illuminated, check the OptoStar II ICIM display, the OptoStar II console, or the OptoStar II NMS for alarm code. See *Alarm Code List* (on page 3-13) to determine the cause of the alarm. See the table below.

Alarm	Possible Cause	Servicing Instruction
High Module Temperature	 High ambient temperature leading to insufficient heat dissipation Poor chassis ventilation Chassis fan failure 	 Ensure good ventilation Put the chassis in a place with good ventilation In case of fan failure, repair or replace the fan, or contact the manufacturer for servicing
Low or High Optical Input Power in Channel A/B	 Optical connector mismatch Optical connector contains dusts or contaminants 	 Check whether the optical connector matches Make sure all the mating surfaces of the fiber are clean Check whether the optical input power is between -15 dBm and 25 dBm with an optical power meter. If the problem persists, contact the manufacturer for servicing

Chapter 5 Customer Support Information

Overview

This chapter contains information on obtaining product support.

In This Chapter

Topic	Page
Obtaining Product Support	5 - 2
Return for Repairing	5 - 4

Obtaining Product Support

IF	THEN
you have general questions about this product	Contact your distributor or sales agent for product information or refer to product data sheets on www.cisco.com.
you have technical questions about this product	Call the nearest Technical Service center or Cisco office.
you have customer service questions or need a return material authorization (RMA) number	Call the nearest Customer Service center or Cisco office.

Support Telephone Numbers

This table lists the Technical Support and Customer Service numbers for your area.

Region	Centers	Telephone and Fax Numbers
North America	Atlanta, Georgia United States	For Technical Support, call:
		Toll-free: 1-800-722-2009
		Local: 678-277-1120 (Press 2 at the prompt)
		For Customer Service, call:
		Toll-free: 1-800-722-2009
		Local: 678-277-1120 (Press 3 at the prompt)
		Fax: 770-236-5477
		E-mail: customer-service@cisco.com
Europe,	Belgium	For Technical Support, call:
Middle East, Africa		Telephone: 32-56-445-197 or 32-56-445-155
Titted		Fax: 32-56-445-061
		For Customer Service, call:
		Telephone: 32-56-445-444
		Fax: 32-56-445-051
		E-mail: service-elc@cisco.com
Japan	Japan	Telephone: 82-2-3429-8800
		Fax: 82-2-3452-9748
		E-mail: songk@cisco.com

Obtaining Product Support, Continued

Region	Centers	Telephone and Fax Numbers
Korea	Korea	Telephone: 82-2-3429-8800
		Fax: 82-2-3452-9748
		E-mail: songk@cisco.com
China (mainland)	China	Telephone: 86-21-2401-4433
		Fax: 86-21-2401-4455
		E-mail: repaircentercn@external.cisco.com
All other Asia-Pacific countries & Australia	Hong Kong	Telephone: 852-2588-4746
		Fax: 852-2588-3139
		E-mail: support.apr@sciatl.com
Brazil	Brazil	Telephone: 11-55-08-9999
		Fax: 11-55-08-9998
		E-mail: fattinl@cisco.com or ecavalhe@cisco.com
Mexico, Central America, Caribbean	Mexico	For Technical Support, call:
		Telephone: 52-3515152599
		Fax: 52-3515152599
		For Customer Service, call:
		Telephone: 52-55-50-81-8425
		Fax: 52-55-52-61-0893
All other Latin America countries	Argentina	For Technical Support, call:
		Telephone: 54-23-20-403340 ext 109
		Fax: 54-23-20-403340 ext 103
		For Customer Service, call:
		Telephone: 770-236-5662
		Fax: 770-236-5888
		E-mail: keillov@cisco.com

Return for Repairing

Introduction

Before returning your product, you must obtain a Return Material Authorization (RMA) number. Call the nearest Customer Service center and follow their instructions.

Procedures of returning your product to Cisco for repairing:

- Obtain RMA number and mailing address
- Package and mail the product to be repaired

Obtain RMA number and mailing address

Before return your products, you must obtain a RMA number.

RMA number is valid for 60 days. If your RMA number expires, you must call your customer service representative to update it before returning your equipment. You can return your product after updating the RMA number. Otherwise, your RMA application may be postponed.

Follow the procedures below to obtain your RMA number and mailing address:

- 1. Contact your customer service representative to apply for a new RMA number, or update an existing RMA number. Obtain customer service numbers for your area in *Obtaining Product Support* (on Page 5-2).
- 2. Provide the following information to your customer service representative:
 - Company name, contact person, telephone number, e-mail address and fax number.
 - Product name, model, part number, SN (if any)
 - Number of returned products
 - Return reason and Repairing/Maintenance Permissions
 - Any related service detail
- 3. When your customer service representative sends a RMA number to you, you will be required to fill in a purchase order or make advance payment to cover estimated repair costs.

Note: Users who pay by credit card or cash will receive a proforma invoice after the repair work is completed, which lists breakdown of repair costs.

Within 15 days upon your receipt of the proforma invoice, the customer service center must receive a purchase order number. During the warranty period, product subject to destruction, misuse, modification, or no problems found would generate costs. The product with additional generated costs will not be returned to the customer until valid P/O number is received.

Return for Repairing, Continued

4. Users can confirm receipt of the RMA number via e-mail or fax. The RMA will list details such as RMA number, verified products to be returned and number of returned products, mailing address and RMA clauses.

Note: Also, users can obtain and complete a RMA application form, and send it to customer service representative via fax, or e-mail: repaircentercn@external.cisco.com

Packaging and Mailing

Follow the steps below to package and return your product to Cisco.

Do you have the original packaging boxes and packaging materials?

- Yes: use the original packaging boxes and packaging materials to package your product
- No: use sturdy corrugated cardboard box meeting transportation requirements to package your product, and fill with packing materials.

Important: Users are responsible for safely mailing products to Cisco without any damage. Products with damage caused during transportation and due to improper packaging will be refused and returned to the user. In such case, the costs will be borne by the user.

Note: Do not return any power cable, accessory cable, or other accessories. Your customer service representative will provide specific instructions on how to order and replace any power cable, accessory cable, or other accessories.

Please fill in the following information on the external surface of the shipping box:

- RMA number
- User name
- Full address of the user
- Telephone number of the user
- "Attention: Factory Service"

Important: RMA number must be clearly marked on all returned products, packaging boxes, and accompanying documents. If the RMA number received by the factory service department is illegible, the RMA handling procedures will be delayed. The recipient for all returned products must be "Factory Services".

Returned products must be mailed to the address specified on the confirmation email or fax sent by the customer service representative.

Return for Repairing, Continued

Note: Cisco does not accept Freight Collect. Make sure that you choose freight prepaid method and purchase transportation insurance. The user should bear both freights to Cisco and all related import and export tariffs for any returned product, whether it's within the warranty period or not. For the product within the warranty period, Cisco will pay the freight when shipping repaired product to the user.

International Transportation: Fill in Cisco as International Transport Recipient, and state the notified party on the waybill as "international freight transport clearance contact".

Upon delivery of the equipment with complete RMA number, the receiving department will notify the user via fax or e-mail, and confirm the received products and the quantity. Please carefully check the confirmation letter to ensure that the products and the quantity received by Cisco are consistent with your shipment information.



Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000 800 553-6387 Fax: 408 527-0883

This document includes various trademarks of Cisco Systems, Inc. Please see the Notices section of this document for a list of the Cisco Systems, Inc. trademarks used in this document.

Product and service availability are subject to change without notice.

© 2013-2014 Cisco and/or its affiliates. All rights reserved.

July 2014 Part Number OL-29670-02