



## **Troubleshooting Guide for Cisco Unified Videoconferencing 5200 Series MCU Release 7.1**

March 2010

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

Text Part Number: OL-22141-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Nurse Connect, Cisco Pulse, Cisco SensorBase, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, Flip Gift Card, and One Million Acts of Green are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Lumin, Cisco Nexus, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Follow Me Browsing, GainMaker, iLYNX, IOS, iPhone, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, SenderBase, SMARTnet, Spectrum Expert, StackWise, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0910R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

*Troubleshooting Guide for Cisco Unified Videoconferencing 5200 Series MCU Release 7.1*  
© 2010 Cisco Systems, Inc. All rights reserved.



## CONTENTS

---

### CHAPTER 1

#### **Troubleshooting the Cisco Unified Videoconferencing 5200 Series MCU 1-1**

Resolving MCU Failure to Register with the Gatekeeper 1-2

Resolving Front Panel LED Issues 1-2

Resolving MCU Conference Initiation Failure 1-3

Resolving Conference Access Failure 1-3

Resolving Cascading Failure 1-4

Resolving Quality Issues in Cascaded Conferences 1-4

Resolving Endpoint Disconnection Issues 1-5

Resolving Unexpected Conference Termination 1-5

Resolving Presentation Issues 1-5

Resolving Unexpected SIP Call Disconnection 1-6

Recovering the Password 1-6





# CHAPTER 1

## Troubleshooting the Cisco Unified Videoconferencing 5200 Series MCU

---

- [Resolving MCU Failure to Register with the Gatekeeper, page 1-2](#)
- [Resolving Front Panel LED Issues, page 1-2](#)
- [Resolving MCU Conference Initiation Failure, page 1-3](#)
- [Resolving Conference Access Failure, page 1-3](#)
- [Resolving Cascading Failure, page 1-4](#)
- [Resolving Quality Issues in Cascaded Conferences, page 1-4](#)
- [Resolving Endpoint Disconnection Issues, page 1-5](#)
- [Resolving Unexpected Conference Termination, page 1-5](#)
- [Resolving Presentation Issues, page 1-5](#)
- [Resolving Unexpected SIP Call Disconnection, page 1-6](#)
- [Recovering the Password, page 1-6](#)

## Resolving MCU Failure to Register with the Gatekeeper

This section describes what to do if the MCU fails to register with the Cisco IOS H.323 Gatekeeper.

Possible Causes	Verification Steps
The gatekeeper address is set incorrectly.	Verify the gatekeeper IP address settings.
TCP/IP setup issue.	<p>Verify that the MCU is assigned a unique IP address.</p> <p>Verify that the subnet mask and default gateway subnet mask are set correctly.</p> <p>Attempt to ping the MCU from the gatekeeper to verify whether the MCU is reachable.</p> <p>Ensure the IP address assigned to the MCU is unique and not duplicated anywhere on the network.</p>
LAN or cable problem	<p>Verify the switch port settings.</p> <p>Verify that the Ethernet cable is straight through.</p> <p>Try another Ethernet cable.</p> <p>Verify if the switch port LEDs show Link and Activity.</p>

## Resolving Front Panel LED Issues

This section describes what to do if MCU module front panel LEDs are off at all times, including during the power off, power on cycle.

**Problem** Front panel LEDs are off at all times.

**Solution** Check the AC cable and fuse, and then verify that the power supply LED is green.

**Solution** Check the AC cable is inserted correctly in the Cisco chassis, or that the back plane pins are not bent as follows:

### Procedure

- 
- Step 1** Open the telecom latch screws and extract the MCU module from its slot.
  - Step 2** Verify that there are no bent pins on the back plane (using a flashlight, if necessary).
  - Step 3** Re-insert the MCU module carefully closing the latches.
-

## Resolving MCU Conference Initiation Failure

This section describes what to do if MCU conference initiation fails.

Possible Causes	Verification Steps
The MCU is set to work with an external authorization server, but no authorization server is configured.	Verify that the External conference authorization policy option is set to None in Maintenance > Advanced parameters > External conference policy authorization.
The MCU is set to work with an external authorization server, but the authorization server is not configured properly to work with the MCU.	Verify that the MCU IP address is correctly configured in the authorization server.
There are not enough MCU resources available for the desired conference.	Verify that current calls are not utilizing all resources by checking the available MCU capacity and then trying to disconnect other calls in order to find the problem.


## Resolving Conference Access Failure

This section describes what to do if an endpoint cannot be invited to a conference or dial into the conference.

Possible Causes	Verification Steps
The MCU is configured to work with an authorization server, but the endpoint is not authorized and therefore the authorization server rejects the call.	Check if the endpoint is authorized in the authorization server.
The endpoint is currently in a call.	Confirm that the endpoint is not busy/in a call.
There are not enough MCU resources available for the desired conference.	Remove one of the current participants to verify that the endpoint can join successfully. Verify whether cascading is enabled and if the meeting is scheduled for cascading.

## Resolving Cascading Failure

This section describes what to do if MCU conference cascading fails.

Possible Causes	Verification Steps
The invited conference does not exist, and the remote MCU is not in Ad Hoc (Scheduler, Web, Control API and dial-in) mode.	If ad hoc conferencing is not allowed for the remote MCU, and the remote conference does not exist, create the conference and then cascade it (web/dial invite).
Service prefixes are not unique and there is service prefix conflict.	Verify that all cascaded MCU modules have unique service prefixes.
The remote MCU module is not registered with its gatekeeper.	Verify proper registration of all MCU modules with their respective gatekeepers.
Not enough ports are available to accomplish cascading.	Check on the Status web page that the number of free ports on each MCU used is not zero.
 <b>Note</b> Cascading requires one port from each conference.	
Services are not synchronized.	Verify that service definitions do not include differences such as H.235 being enabled on one conference only.

## Resolving Quality Issues in Cascaded Conferences

This section describes what to do if a cascaded conference suffers long delays or bad lip synchronization.

Possible Causes	Verification Steps
Unsuitable topology used (for example, chain topology used unnecessarily).	<p>One single central MCU should invite all other cascaded MCUs.</p> <p>We recommend that you do not have more than one level of cascaded MCUs.</p> <p>Use a star topology, where the central MCU is in the center of the star, and other cascaded MCU modules are on the arms of the star.</p>



## Resolving Endpoint Disconnection Issues

This section describes what to do if endpoints unexpectedly drop out of the MCU conference.

Possible Causes	Verification Steps
Unreliable network link.	Check network link quality (round trip time should be less than 300 msec).

## Resolving Unexpected Conference Termination

This section describes what to do if a conference on the MCU unexpectedly terminates.

Possible Causes	Verification Steps
The Ad hoc conferences terminate when option at <b>Configuration &gt; Conferences</b> is set to Conference creator leaves and the conference creator has left the conference.	Set the Ad hoc conferences terminate when option at <b>Configuration &gt; Conferences</b> to <b>Last participant leaves</b> .

## Resolving Presentation Issues

This section describes what to do if you cannot start or receive a presentation during a conference.

Possible Causes	Verification Steps
H.239 functionality is not enabled on your endpoint.	Verify that H.239 is enabled on the endpoint. Make a point-to-point call to another endpoint and verify that you can start a presentation.
Presentation is not configured in the MCU service used in your conference.	Configure the service to support presentation at <b>Configuration &gt; Conferences &gt; Services list &gt; More &gt; Enable presentation views</b> .
MCU presentation definitions in the service are not supported by your endpoint (frame rate, frame size, codec).	Check that your endpoint supports the frame size, frame rate and video codec as defined in the service.

## Resolving Unexpected SIP Call Disconnection

This section describes what to do if a SIP call unexpectedly disconnects after 30 seconds.

Possible Causes	Verification Steps
DNS is not fully configured on the MCU and user agents.	Verify that DNS is configured on user agent and MCU.

## Recovering the Password

If you forget your password, you can recover it. For operational information, see the ‘Changing the Global User Name and Password’ section in the *Installation Guide for Cisco Unified Videoconferencing 5200 Series MCU Release 7.1*.