





Common Phone Tasks

Place call	Press  or Call . You can do this before or after dialing.
Answer call	Press  or Answer .
End call	Press End Call .
Redial	Press the Redial .
Mute conference station	Press  on the Sound base, DCU or microphone.
View call history	Press Apps and select Call History . To dial, highlight a listing, and then press Dial .
Hold/Resume call	Press Hold . To resume a call, press  or Resume .
Transfer call to a new number	Press Transfer , enter the number, and then press Transfer .
Start a standard (ad hoc) conference call	Press Conference , dial a participant, and press Conference .
Forward all calls	Press Fwd All .
Join	From a connected call, press Conference and then press Calls to view a call list for join.



Cisco, Cisco Systems, the Cisco logo, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

© 2016 Cisco Systems, Inc. All rights reserved.



QUICK REFERENCE













Cisco Unified IP Conference Phone 8831 and 8831NR

Common Phone Tasks
 Softkey Definitions
 Phone Screen Icons
 Phone Buttons
 Phone Connections






Softkey Definitions

Answer	Answer incoming call
Apps	Access phone applications and phone settings menus
Call	Place call to dialed number
Callback	Receive notification when a busy extension becomes available
Calls	List connected calls
Cancel	Stop current operation
Conf	Create conference call
ConfList	View conference participants
Contacts	Enter contacts menu to view corporate or personal address book contacts
Divert	Redirect call
End Call	End active call
Fwd All	Forward all incoming calls
Hold	Place active call on hold
Messages	Set up, check, or listen to voice messages
More	Display additional softkeys
New Call	Place new call without disconnecting from current call
Park	Park call and display its details
Redial	Redial the most recently dialed number
Resume	Resume on-hold call
Speed Dial	Place call to selected entry
Transfer	Transfer call


Phone Screen Icons

Line and Call States	
	Call on hold
	Connected call
	Incoming call
	On-hook
	Off-hook
	Shared line in use
Other Features	
	Selected option
	Linked mode
	Encrypted
	Microphone on

Phone Buttons

	Call
	2-way Navigation Bar
	Select
	Volume
	Mute

Phone Connections



Bottom view of the Sound Base

1	Network cable port.
2	External power connection.
3	Display Control Unit USB port. Connects the DCU to the base. Note: Press firmly to seat ferrite bead between cord posts.
4	Wired extension microphone jack.
5	Daisy chain cable port. Connects two Sound Base units in Linked Mode.

Note: The Cisco Unified IP Conference Phone 8831 supports wired and wireless microphones. The Cisco Unified IP Conference Phone 8831NR supports only wired microphones.