

Provision the DS3, STS1/DS3, and VT1.5 Circuit on a DS3XM–12 Card

Document ID: 70918

Contents

Introduction

Prerequisites

- Requirements

- Components Used

- Conventions

Topology

DS3XM–12 Card and Connection Overview

- Specific Card and Port Information

Configuration and Data Flow

Related Information

Introduction

This document describes how to provision the DS3, STS1/DS3, and VT1.5 circuit on a DS3XM–12 card on the ONS 15454.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- Cisco ONS 15454
- DS3XM–12 card

Components Used

The information in this document is based on all versions of Cisco ONS 15454.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.


Conventions

Refer to Cisco Technical Tips Conventions for more information on document conventions.

Topology

This document uses a lab setup with two ONS 15454s as Figure 1 shows. They are named Node 91 and Node 90.


Figure 1 Topology



This list details the setup:


- Two cards on Node 90 are used in the configuration process. One is the OC-3 card in slot 12 (see arrow A in Figure 2), and the other is the DS3XM-12 card in slot 5 (see arrow B in Figure 2).

Figure 2 Shelf View of Node 90



- Two cards on Node 91 are used in the configuration process. They are the OC-3 card in slot 6 (see arrow A in Figure 3) and the DS-3 card in slot 1 (see arrow B in Figure 3).


Figure 3 Shelf View of Node 91



DS3XM–12 Card and Connection Overview

There are three columns of ports on the DS3XM–12 card as Figure 4 shows. The first column is 1 through 12 which represent the electrical DS3 ports on the rear of the shelf. The second column (13 at the top and 35 at the bottom) is the odd numbered ports. These are the VT crossconnect ports in that row (1 – 13 – 14, 2 – 25 – 26, and so forth). The third column (14 at the top and 36 at the bottom) is the crossconnect point for a DS3 embedded in an STS1.

Figure 4



Specific Card and Port Information

This list provides specific information about the DS3XM–12 and its ports:

1. An STS crossconnect to a DS3 port is an STS1 with VT1.5s.
2. An STS crossconnect to an STS port is an STS1 with a DS3.
3. DS3 connections are on ports 1 through 12.
4. STS connections are the even numbered ports between 13 and 36.
5. When you use a DS3 port, the adjacent two ports (see port 5) are disabled when it is placed in service (IS).
6. When you use an STS port, the adjacent DS3 port is disabled (see port 14) when it is placed in service (IS).
7. Crossconnects to the VTs in a DS3 where the DS3 port is enabled (IS) go to the same numbered port. For example, port 5 is enabled (IS) so crossconnects to the VTs in that DS3 go to port 5.
8. Crossconnects to the VTs in an STS with an embedded DS3 go to the middle port adjacent to the enabled (IS) STS port. For example, port 14 is enabled (IS) so crossconnects to the VTs in the DS3 go to port 13.

Configuration and Data Flow

Node 90 and Node 91 are physically connected through the OC–3 card (slot 12) of Node 90 and the OC–3 card (slot 6) of Node 91.

Three circuits are configured in the configuration:

1. Two–way circuit from Node 90, slot 5 (s5), port 5 (p5), STS–1 (S1), VT1.1 (V1–1) to Node 90, slot 5 (s5), port 13 (p13), STS–1 (S1), VT1.1 (V1–1) pointed by arrow A in Figure 5.

2. Two-way circuit from Node 91, slot 1 (s1), port 1 (p1), STS-1 (S1) to Node 91, slot 6 (s6), port 1 (p1), STS-1 (S1) pointed by arrow B in Figure 5.
3. Two-way circuit from Node 90, slot 12 (s12), port 1 (p1), STS-1 (S1) to Node 90, slot 5 (s5), port 14 (p14), STS-1 (S1) pointed by arrow C in Figure 5.

Circuit VT_node .90::70 (see arrow A in Figure 5) and circuit STS_node .90::69 (see arrow C in Figure 5) show an STS/DS3 from an OC-3 card connected to the STS port 14 and a VT1.5 from that STS connected to the DS3 in port 5.

Figure 5 Configured Circuits

Circuit Name	Type	Size	Dir	Status	Source	Destination
VT_node .90:70	VT	VT1.5	2-way	DISCOVERED	node .90/s5/p5/S1/V1-1	node .90/s5/p13/S1/V1-1
STS_node .91:6	STS	STS-1	2-way	DISCOVERED	node .91/s1/p1/S1	node .91/s6/p1/S1
STS_node .90:69	STS	STS-1	2-way	DISCOVERED	node .90/s12/p1/S1	node .90/s5/p14/S1

This is the data flow from Node 90 to Node 91:

1. DS3 MUX to port 5 on DS3XM-12 (slot 5) of Node 90
2. Port 5 on DS3XM-12 (slot 5) of Node 90 to port 13 on DS3XM-12 (slot 5) of Node 90
3. Port 13 on DS3XM-12 (slot 5) of Node 90 to port 14 on DS3XM-12 (slot 5) of Node 90
4. Port 14 on DS3XM-12 (slot 5) of Node 90 to OC3 (slot 12) of Node 90
5. OC3 (slot 12) of Node 90 to OC3 (slot 6) of Node 91
6. OC3 (slot 6) of Node 91 to DS3 (slot 1) on Node 91
7. DS3 (slot 1) on Node 91 to DS3 MUX

When you reverse this sequence, it represents the data flow from Node 91 to Node 90.

Related Information

- [Technical Support & Documentation – Cisco Systems](#)

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2013 – 2014 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Sep 08, 2006

Document ID: 70918