

Troubleshooting Physical Layer Alarms on SONET and SDH Links

Document ID: 16154

Contents

Introduction

Prerequisites

- Requirements
- Components Used
- Conventions

Alarms at SONET's Layers

Alarm Indicators

Troubleshooting

Troubleshoot with loopback Commands

- Configure an Interface for Internal Loopback
- Configure an Interface for Line Loopback

Configure SONET Delay Triggers

- Line and Section Triggers
- Path Level Triggers

SONET MIB

Related Information

Introduction

This document explains common SONET alarms and how to troubleshoot them.

Alarm surveillance uses two terms:

- State Condition that is reported or detected. A SONET device enters a state when the device detects the occurrence of an event. A SONET device exits that state when the device no longer detects the event. This document discusses the loss of signal (LOS) and loss of frame (LOF) states.
- Indication Prompted by a change of state. This indicates the presence of a condition. This document discusses the alarm indication signal (AIS), remote defect indicator (RDI), and far end receive failure (FERF) indications.

Active alarms or defects keep an interface in the down/down state. The process used to troubleshoot down/down SONET interfaces is similar to that for digital interfaces, such as T1 and T3.

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

This document is not restricted to specific software and hardware versions.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

Refer to Cisco Technical Tips Conventions for more information on document conventions.

Alarms at SONET's Layers

SONET equipment detects events and alarms at each of SONET's three layers — section, line and path. Typically, a SONET device sends alarms both upstream and downstream in order to notify other devices of the problem condition.

Issue the **pos report** command in order to configure the alarms that the packet over SONET (POS) interface can activate.

```
RTR12410-1(config)#interface pos 2/1
  RTR12410-1(config-if)#pos report ?
  all          all Alarms/Signals
  b1-tca       B1 BER threshold crossing alarm
  b2-tca       B2 BER threshold crossing alarm
  b3-tca       B3 BER threshold crossing alarm
  lais         Line Alarm Indication Signal
  lrldi        Line Remote Defect Indication
  pais         Path Alarm Indication Signal
  plopp        Path Loss of Pointer
  prldi        Path Remote Defect Indication
  rdool        Receive Data Out Of Lock
  sd-ber       LBIP BER in excess of SD threshold
  sf-ber       LBIP BER in excess of SF threshold
  slof         Section Loss of Frame
  slo          Section Loss of Signal
```

The **show controllers** command displays the number of times that an alarm is declared and whether any alarms are active on a POS and ATM over SONET interface. This output was captured on a Gigabit Switch Router (GSR). The Active Defects section indicates what the local interface sees. The Active Alarms section indicates what the upstream device reports.

```
RTR12410-1#show controller pos 1/0
POS1/0
SECTION
  LOF = 1          LOS = 1          BIP(B1) = 31165
LINE
  AIS = 1          RDI = 0          FEBE = 0          BIP(B2) = 0
PATH
  AIS = 1          RDI = 1          FEBE = 0          BIP(B3) = 25614
  LOP = 0          NEWPTR = 1        PSE = 0          NSE = 0
Active Defects: SLOF SLOS B1-TCA LAIS PAIS PRDI B3-TCA
Active Alarms: SLOS B1-TCA B3-TCA
Alarm reporting enabled for: SF SLOS SLOF B1-TCA B2-TCA PLOP B3-TCA
```

This sample output was also captured from a GSR. The LINK-3-UPDOWN message indicates that the physical-layer is up and that all active alarms are now clear. The LINEPROTO-5-UPDOWN message indicates that the line protocol is up; the line protocol on POS interfaces is Frame Relay, High-Level Data Link Control (HDLC) or Point-to-Point Protocol (PPP).

```
Aug  7 05:14:37 BST: %LINK-3-UPDOWN: Interface POS4/7, changed state
to up
```

```

Aug 7 05:14:38 BST: %LINEPROTO-5-UPDOWN: Line protocol on Interface
POS4/7,changed state to up
Aug 7 05:14:49 BST: %SONET-4-ALARM: POS4/7: LRDI cleared
Aug 7 05:14:52 BST: %SONET-4-ALARM: POS4/7: LRDI
Aug 7 05:15:02 BST: %LINEPROTO-5-UPDOWN: Line protocol on Interface
POS4/7, changed state to down

```

```

! --- Router receives the Line Remote Defect Indicator (LRDI)
! --- and brings down the line protocol.

```

```

Aug 7 05:15:13 BST: %SONET-4-ALARM: POS4/7: LRDI cleared
Aug 7 05:16:42 BST: %SONET-4-ALARM: POS4/7: LRDI
Aug 7 05:16:45 BST: %SONET-4-ALARM: POS4/7: SLOS
Aug 7 05:16:47 BST: %LINK-3-UPDOWN: Interface POS4/7, changed state
to down
Aug 7 05:16:56 BST: %SONET-4-ALARM: POS4/7: LRDI cleared
Aug 7 05:16:56 BST: %SONET-4-ALARM: POS4/7: PRDI
Aug 7 05:17:49 BST: %SONET-4-ALARM: POS4/7: LRDI

```

Note: In order to capture granular timestamps on log messages, configure the **service timestamps log datetime msec** command.

A router with ATM over SONET interfaces also reports active alarms with these log messages:

```

Feb 18 16:34:22.309: %SONET-4-ALARM: ATM5/0: ~SLOF SLOS LAIS ~LRDI PAIS PRDI ~PLOP

```

The "~" character indicates that the particular alarm is not active, and the absence of the ~ character indicates that the alarm is active. In this sample output, ~SLOF indicates that there are no section loss of frame errors. However, the interface experiences several other active alarms which include section loss of signal (SLOS) and line alarm indication signal (LAIS).

Alarm Indicators

Typically, a failure condition detected by a SONET device results in one or more error conditions sent both upstream and downstream on the network. An AIS is sent in order to alert downstream devices of a problem and in order to prevent consequential downstream failures or alarms from being raised. An RDI alarm is sent upstream as a control and feedback mechanism for the network. RDI was previously referred to as FERF.

The RDI is different from remote error indicator (REI). The REI communicates performance monitoring values, such as bit error rates.

Troubleshooting

Use this table in order to isolate and troubleshoot SONET alarms. Note the SONET layer at which errors and alarms are detected, when you troubleshoot. For example, perform an extended test of the end-to-end link if the POS interfaces report path-layer errors only. Also note what the upstream and remote devices see.

| Alarm Type and Severity | Conditions That Cause Alarm to Occur | Recommendation |
|--|---|---|
| Section Loss of Signal (SLOS) <i>Critical</i> | A SONET-4-ALARM must see a certain number of digital bit transitions (from 1 to 0 and 0 | <ol style="list-style-type: none"> 1. Check the fiber optic cable in order to make sure it is plugged in. 2. Verify that the local fiber optic cable is not damaged. Look for breaks or |

| | | |
|---|---|---|
| | <p>to 1) in order to ensure proper synchronization. LOS is declared when no bit transitions are detected on the incoming signal (before descrambling) for 2.3 to 100 microseconds. The LOS defect is cleared after a 125–microsecond interval (one frame) during which no LOS defect is detected.</p> <p>Note: LOS typically occurs in back–to–back lab setups because the receiver is saturated with too much light, particularly when long–reach single mode interfaces are used. Try to attenuate the signal.</p> | <p>physical abnormalities.</p> <ol style="list-style-type: none"> 3. Make sure that the remote end of the fiber optic cable is connected, undamaged and that the remote port is configured properly. 4. Try a soft loopback with the loopback internal command. 5. Try a hard loopback. Connect the transmit to receive with a single fiber strand. 6. Determine whether the POS interface simply receives too little or too much light. |
| <p>Section Loss of Frame (SLOF) <i>Critical</i></p> | <p>The A1 and A2 bytes in the section overhead provide frame alignment with a particular bit pattern. A receiving interface declares LOF after it detects errors in the framing pattern for three milliseconds. LOF is cleared when two consecutive valid A1/A2 framing patterns are received.</p> | <ol style="list-style-type: none"> 1. Check the fiber optic cable in order to make sure the cable is plugged in and is not damaged. 2. Ensure the framing format on the port matches the format configured on the line: <pre>router(config-if)# [no] pos framing-sdh</pre> |
| <p>Alarm Indicate</p> | <p>LAIS is sent by the section</p> | |

| | | |
|--|--|--|
| <p>Signal – Line (LAIS) <i>Major</i></p> | <p>terminating equipment (STE) to alert the downstream line terminating equipment (LTE) that a LOS or LOF defect has been detected on the incoming SONET section. Upstream STE generates line AIS to downstream LTE by setting bits 6, 7, and 8 of the K2 byte to 111.</p> | <ol style="list-style-type: none"> 1. Verify that the remote configuration is correct. 2. Check the line status at the remote end of the link. |
| <p>Remote Defect Indication – Line (LRDI) <i>Major</i></p> | <p>RDI alarms are always reported upstream from the detecting device. LRDI specifically comes back in the K2 bits 6–8 and overrides any existing Automatic Protection Switching (APS) modes: (APS 1+1) or APS status (BLSR). AIS–L is also sent in bits 6–8 and is generally sent from a SONET regenerator or other STE.</p> | <p>RDI Line problems arise from the remote interface. Check the remote site for alarm conditions.</p> |
| <p>Alarm Indicate Signal – Path (PAIS) <i>Minor</i></p> | <p>An upstream LTE that receives LAIS then sends path AIS to the downstream PTE by setting H1 and H2 bytes. The purpose is to alert the downstream PTE of a defect on the upstream LTE's incoming line signal.</p> | <p>This is sent by a site that has received LAIS. This is a minor warning, and no action needs to be taken except to monitor the far end. If the alarms are persistent, verify the interface configurations on both ends of the trunk.</p> |

| | | |
|---|--|--|
| Remote Defect Indication – Path (PRDI) <i>Minor</i> | Path Remote Defect Indicator (PRDI) is used only at the path level. A problem at the path layer prompts PAIS to be sent downstream and PRDI to be sent back upstream to let the traffic provider know that there is a problem with their circuit downstream. | A PRDI alarm usually indicates a problem two sites away. If the alarm is persistent, check the alarm status of neighboring sites, beginning with the nearest neighbor. |
|---|--|--|

Troubleshoot with loopback Commands

The loopback test allows you to test the connection between the OC-3 interface and a remote device in order to troubleshoot, detect, and isolate equipment malfunctions.. The **loopback** command places an interface in internal loopback (also called local loopback) or line loopback mode, which enables test packets that are generated from the **ping** command to loop through a remote device or a cable. If the packets complete the loop, the connection is good. If not, you can isolate a fault to the remote device or the cable in the path of the loopback test.

With internal loopback, note:

- When you configure a loopback, ensure that you configure the interface for internal clocking with the **clock source internal** command. The framer waits for incoming valid frames with which to synchronize and uses these frames to time its transmission, when configured for clock source line. With no receive frames, you have no timing to send frames.
- If you do a hardware loop — in other words, you just loop the fiber back onto the interface — make sure that you use an attenuator if you use a single mode interface. If you do not, you could blast the interface with too much power or even damage the optics on the card if it is a Long Reach card or if the transmit sends higher than its rated levels.

Configure an Interface for Internal Loopback

The default loopback setting is for no loopback. With internal (or local) loopback, packets from the router are looped back in the framer. Outgoing data is looped back to the receiver without actually being transmitted. Internal loopback is useful when you want to check that the POS interface works. In order to configure an interface for internal loopback, issue the **loop internal** command:

```
Router(config)#interface pos 3/0
Router(config-if)#loop internal
```

Configure an Interface for Line Loopback

The default loopback setting is for no loopback. With line loopback, the receive (Rx) fiber is logically connected to the transmit (Tx) optical fiber cable, so that packets from the remote router are looped back to it. Incoming data is looped around and retransmitted without actually being received. In order to configure an

interface for line loopback, issue the **loop line** command:

```
Router(config)#interface pos 3/0  
Router(config-if)#loop line
```

Note: The **loopback line** command loops the signal before the SONET framer.

Configure SONET Delay Triggers

A trigger is an alarm which, when asserted, causes the line protocol to go down. These sections discuss line triggers and path triggers, which you configure with the **pos delay triggers** command.

```
RTR12410-1(config)#interface pos 1/0  
RTR12410-1(config-if)#pos delay triggers ?  
line Specify delay for SONET LINE level triggers (S-LOS, S-LOF, L-AIS)  
path Enable SONET PATH level triggers (P-AIS, P-RDI), with optional delay  
RTR12410-1(config-if)#pos delay triggers line ?  
<0-511> Holdoff time, in msec  
<cr>
```

Line and Section Triggers

You use the **pos delay triggers line** command for Internet router POS interfaces connected to internally-protected Dense Wavelength Division Multiplexing (DWDM) systems (documented under CSCdm36033 and CSCdp65436 on Cisco 12000 series routers and CSCdr72941 on Cisco 7200 and 7500 series routers). This command is invalid for interfaces that are configured as APS working or protected. Normally, even a few microseconds of line- or section-level alarms (SLOS, SLOF, or LAIS) brings down the link until the alarm has been clear for ten seconds. If you configure holdoff, this link-down trigger is delayed for 100 ms. If the alarm stays up for more than 100 ms, the link is brought down as it is now. If the alarm clears before 100 ms, the link is not brought down.

By default, these line and section alarms are triggers for the line protocol to go down:

- Section loss of signal
- Section loss of frame
- Line alarm indication signal

The line protocol of the interface goes down without a delay when one or more of these alarms is asserted. You can issue the **pos delay triggers line** command in order to delay the line protocol of the interface from going down. You can set the delay from 0 to 511 ms. The default delay is set to 100 ms if you do not specify a time interval.

Path Level Triggers

These path alarms are not triggers by default. You can configure these path alarms as triggers and also specify a delay:

- Path alarm indication signal
- Path remote defect indication
- Path loss of pointer

You can issue the **pos delay triggers path** command in order to configure various path alarms as triggers and in order to specify an activation delay between 0 and 511 ms. The default delay value is 100 ms.

The `pos delay triggers path` configuration can also bring down the line protocol when the higher of the B2 and B3 error rates is compared with the signal failure (SF) threshold. If the SF threshold is crossed, then the line protocol of the interface goes down.

The **`pos delay triggers path`** command was introduced in Cisco IOS® Software Release 12.0(16)S.

SONET MIB

Cisco SONET interfaces also support the SONET MIB, which is defined in Request for Comments (RFC) 1595 [\[3\]](#). The RFC uses the same terminology in order to describe error conditions on a SONET circuit as ANSI standards for SONET and on a Synchronous Digital Hierarchy (SDH) circuit by the International Telecommunications Union (ITU-T) G.783 specification.

For SONET MIB support on Cisco POS and ATM over SONET interfaces, refer to these resources:

- Cisco MIBs Lists the supported MIBs per platform as well as the object ID strings and the .my files for the SONET MIB.
- Cisco 7000 Family and 12000 Series Release Notes for Release 12.0 S – Describes enhancements to Cisco support for the SONET MIB.

Related Information

- [Optical Hardware Support Pages](#)
- [Optical Technology Support Pages](#)
- [Technical Support – Cisco Systems](#)

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2014 – 2015 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Oct 24, 2006

Document ID: 16154
