

Configure DHCP Server/Relay on FTD Using Firepower Management Center (FMC)

Contents

[Introduction](#)

[Prerequisites](#)

[Requirements](#)

[Components Used](#)

[Background Information](#)

[Configure DHCP Server](#)

[Enable DHCP Server/Configure the DHCP Pool](#)

[Configure the DNS/WINS Server](#)

[Configure the Advanced Parameters](#)

[Configure DHCP Relay](#)

[Configure the DHCP Relay Agent](#)

[Configure External DHCP Server](#)

[Monitor And Troubleshoot](#)

[Related Information](#)

Introduction

This document describes the configuration of DHCP server and DHCP relay services in Firepower Threat Defense (FTD) through FMC.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- Knowledge of Firepower technology
- Basic Knowledge of ASA (Adaptive Security Appliance)
- Knowledge of DHCP Server/ DHCP Relay

Components Used

The information in this document is based on these software and hardware versions:

- ASA Firepower Threat Defense Image for ASA (5506X/5506H-X/5506W-X, ASA 5508-X, ASA 5516-X) running software version 6.0.1 and above
- ASA Firepower Threat Defense Image for ASA (5515-X, ASA 5525-X, ASA 5545-X, ASA

5555-X, ASA 5585-X) running software version 6.0.1 and above

- FMC version 6.0.1 and above

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Note: FTD appliance should be registered to the FMC. Click the [Register a Device with a FireSIGHT Management Center](#) in order to register the FTD to the FMC.

Background Information

Dynamic Host Control Protocol (DHCP) provides network configuration parameters automatically such as IP addresses, DNS server details and other parameters to the DHCP clients. FTD routed interface can act as DHCP server to provide the IP addresses to the clients.

FTD provides the DHCP relay services to the internal client wherein client are connected to one of the interfaces of the FTD and the external DHCP server is connected to the other. The relay service operation is transparent to the clients.

Configure DHCP Server

In order to configure the DHCP server, log in to the FMC GUI and navigate to **Devices > Device Management**, click the **edit** button of the FTD appliance. Navigate to **DHCP** tab and click the **DHCP Server** tab.

The screenshot displays the FMC GUI configuration for a DHCP Server. The top navigation bar includes tabs for Devices, Routing, NAT, Interfaces, Inline Sets, and DHCP. The DHCP tab is active, and the DHCP Server configuration page is shown. The configuration includes the following fields:

- Ping Timeout: 50 (10 - 10000 ms)
- Lease Length: 3600 (300 - 10,48,575 sec)
- Auto-Configuration:
- Interface*: Inside-2
- Override Auto Configured Settings: (Red text)
- Domain Name: (Empty field)
- Primary DNS Server: (Empty field)
- Secondary DNS Server: (Empty field)
- Primary WINS Server: (Empty field)
- Secondary WINS Server: (Empty field)

At the bottom, there is a table with columns for Interface, Address Pool, and Enable DHCP Server. The table shows one entry for the Inside interface with an address pool of 192.168.10.3-192.168.10.7 and the DHCP server enabled (indicated by a green checkmark).

Interface	Address Pool	Enable DHCP Server
Inside	192.168.10.3-192.168.10.7	✓


In order to configure DHCP server, perform three steps.

Step1. Enable DHCP server/ Configure the DHCP Pool.

Step2. Configure the advanced parameters.

Step3. Configure the DNS/ WINS Server.

Note: Ensure that the IP address and logical name must be configured on the interfaces before you start DHCP configuration.



Interface	Logical Name	Type	Security Zone	Mac Address(Active/Standby)	IP Address
GigabitEthernet0/0	Outside	Physical	Outside		10.83.182.22/24(Static)
GigabitEthernet0/1	Inside	Physical	Inside		192.168.10.1/24(Static)
GigabitEthernet0/2	Inside-2	Physical	Inside-2		
Diagnostic0/0	diagnostic	Physical			
GigabitEthernet0/3	MGMT	Physical	MGMT		192.168.0.1/24(Static)
GigabitEthernet0/4		Physical			

Enable DHCP Server/Configure the DHCP Pool


You can use any routed interface as the DHCP server and interface's IP address acts as the gateway for the end client. Hence, you just need to define the IP address range.

In order to enable the DHCP server on any interface, click the **Add** button in **Server** tab.

Interface: Specify the interface from the drop-down list where you want to enable the DHCP server.

Address Pool: Specify the IP address range.

Enable DHCP Server: Enable the checkbox to enable the DHCP server on this interface.



Server Advanced

Interface Address Pool Enable DHCP Server

Add Server

Interface* Inside

Address Pool* 192.168.20.10-192.168.20.20 (2.2.2.10-2.2.2.20)

Enable DHCP Server

OK Cancel

Click **OK** to save the DHCP configuration.

Configure the DNS/WINS Server

DHCP Server provides the DNS/ WINS/Domain name parameters along with IP address details to the end client. These parameters help in the name resolution. Therefore, it is important to configure these parameters correctly.

There are two options to configure this:

First, if any of FTD's interface is configured as DHCP client then you can choose option **Auto-Configuration**. This method takes the configuration of DNS/ WINS/ domain name information from the DHCP server and provides the same information to the DHCP client.

Second, you can set your own DNS/ WINS domain name parameters, which are provided to the end client.

In order to configure this, navigate to **DHCP** tab.

- **Ping Timeout:** To avoid address conflicts, the FTD sends two ICMP ping packets to an address before it assigns that address to a DHCP client. This command specifies the timeout value for those packets
- **Lease Length:** This lease equals the amount of time (in seconds) the client can use its allocated IP address before the lease expires
- **Auto Configuration:** Enable this checkbox to configure the auto configuration for DNS/WINS/Domain Name
- **Interface:** Specify the interface which acts as a DHCP client

Override Auto Configured Setting: Configure this option, if you want to assign your own DNS/WINS/Domain Name to the end client.

Domain Name: Specify the domain name.

Primary DNS Server: Specify the primary DNS server. Either you can select the network object from the drop-down list or click the **plus (+)** icon and create a network object for primary DNS server.

Secondary DNS Server: Specify the secondary DNS server. Either you can select the network object from the drop-down list or click the **plus (+)** icon and create a network object for secondary DNS server.

Primary WINS Server: Specify the secondary DNS server. Either you can select the network object from the drop-down list or click the **plus (+)** icon and create a network object for secondary DNS server.

Secondary WINS Server: Specify the secondary DNS server. Either you can select the network object from the drop-down list or click the **plus (+)** icon and create a network object for secondary DNS server.


Ping Timeout	<input type="text" value="50"/>	(10 - 10000 ms)
Lease Length	<input type="text" value="3600"/>	(300 - 10,48,575 sec)
Auto-Configuration	<input checked="" type="checkbox"/>	
Interface*	<input type="text" value="Outside"/>	
Override Auto Configured Settings:		
Domain Name	<input type="text" value="example.com"/>	
Primary DNS Server	<input type="text" value="DNS1"/>	<input type="text" value="SERVER_2008"/>
Secondary DNS Server	<input type="text"/>	<input type="text"/>

Configure the Advanced Parameters

FTD interface's DHCP server has the ability to include DHCP codes and options. For example, Cisco IP phones can send a request with option (150/ 66) to the DHCP server to obtain the IP address of TFTP server so that the phones can download the firmware from the TFTP server.

In order to configure this, navigate to **DHCP > Advanced** option and click **Add**.

- **Option Code:** Specify the option code as per listed in RFC 2132, RFC 2562, RFC 5510
- **Type:** Specify the type from the drop-down
- **IP Address 1:** If you choose type option as IP then specify the IP address of first TFTP server
- **IP Address 2:** If you choose type option as IP then specify the IP address of first TFTP server
- **ASCII:** If you choose type option as ASCII then specify the ASCII value
- **HEX:** If you choose type option as HEX, then specify the HEX value



Click **OK** to save the configuration.

Click the **Save** button to save the platform setting. Navigate to **Deploy** option, select the FTD appliance where you want to apply the changes & click the **Deploy** button to start deployment of platform setting.

Click the **Save** button to save the platform setting. Navigate to **Deploy** option, select the FTD appliance where you want to apply the changes & click the **Deploy** button to start deployment of platform setting.

Configure DHCP Relay

FTD interface operates as DHCP Relay agent between client and external DHCP server. Interface listens for the client request and adds vital configuration data, such as client's links information which is needed by DHCP server to allocate the address for the client. When DHCP server responds, interface forwards the reply packet back to the DHCP client.

The configuration of DHCP Relay has mainly two configuration steps.

Step 1. Configure the DHCP Relay Agent.

Step 2. Configure External DHCP Server.


Configure the DHCP Relay Agent

Navigate to **Devices > Device Management**, click the **edit** button of the FTD appliance. Navigate to **DHCP > DHCP Relay** option. Click the **Add** button.

Interface: Specify the interface from the drop-down list where interface listens for the client request. DHCP client should connect directly to this interface for IP address request.

Enable DHCP Relay: Enable the checkbox to enable the DHCP relay service.

Set Route: Enable the check box to set the interface IP address as the default gateway.



Click the **OK** button to save the DHCP relay agent configuration.


Configure External DHCP Server

You need to specify the IP address of external DHCP server where client request is forwarded.

To specify the DHCP server, navigate to **DHCP Server** and click **Add** .

Server: Specify the IP address of DHCP server. Either you can select the network object from the drop-down list or click the **plus (+)** icon and create a network object for DHCP server.

Interface: Specify the interface where DHCP server connects.



Click **OK** to save the configuration.

Click the **Save** button to save the platform setting. Navigate to **Deploy** option, select the FTD appliance where you want to apply the changes & click the **Deploy** button to start deployment of

platform setting.

Monitor And Troubleshoot

- Ensure that the FTD is registered to the FMC before you start configuring the DHCP Server/Relay
- Verify the connectivity to DHCP server in DHCP Relay configuration

```
> system support diagnostic-cli
Attaching to ASA console ... Press 'Ctrl+a then d' to detach.
Type help or '?' for a list of available commands.
```

```
><Press Enter>
```

```
firepower# ping <DHCP_SERVER_IP>
```

- Verify the DHCP related configuration in FTD CLI. You can login to FTD CLI to management interface and run the command

```
firepower# show running-config dhcpd
dhcpd auto_config Inside-2
!
dhcpd address 192.168.10.3-192.168.10.7 Inside
!
```

- Ensure that the policy deployment is applied successfully
- Ensure that you configure the correct DNS/WINS server entry either by Auto-Configuration or by Manual configuration
- IP address pool should be in the same subnet of the Interface IP address
- Ensure that the IP address and logical name should be configured on the interfaces
- You can take the packet capture on the FTD routed interface to troubleshoot the issue wherein client are not getting an IP address. In the packet captures, we can verify the DORA process of the DHCP server. You can follow [ASA Packet Captures with CLI and ASDM Configuration Example](#) to take the packet capture
- Verify the DHCP statistics from the command line

```
firepower# show dhcpd statistics
```

- Verify the DHCP binding information from the CLI

```
firepower# show dhcpd binding
```

- Enable the appropriate logging at **Device > Platform Setting > FTD Policy > System logging** and deploy the platform setting to the FTD. Log in to FTD CLI and run the command to check the Syslog messages

```
Attaching to ASA console ... Press 'Ctrl+a then d' to detach.
Type help or '?' for a list of available commands.
```

```
firepower# show logging
```

Related Information

- [Cisco Firepower Threat Defense Quick Start Guide for the ASA](#)
- [Technical Support & Documentation - Cisco Systems](#)