# Configure Simple Network Time Protocol (SNTP) Authentication Settings on a Switch

## **Objective**

Simple Network Time Protocol (SNTP) is the simplified version of Network Time Protocol (NTP). NTP is the protocol that is used to synchronize the clocks on a network. It provides time within 100 milliseconds of the accurate time, but does not authenticate traffic.

The SNTP authentication page of the switch allows the administrator to configure Network Time Protocol (NTP) authentication keys to verify a time source. SNTP authentication should be used only in situations where strong authentication is not required as it does not provide the complex filtering mechanisms of NTP.

This document explains how to define SNTP Authentication on a switch.

## **Applicable Devices**

- Sx250 Series
- Sx300 Series
- Sx350 Series
- SG350X Series
- Sx500 Series
- Sx550X Series

### **Software Version**


- 1.4.7.05 Sx300, Sx500
- 2.2.8.04 Sx250, Sx350, SG350X, Sx550X

## **Configure SNTP Authentication**

- Step 1. Log in to the web-based utility of the switch.
- Step 2. Choose **Advanced** from the Display Mode drop-down list.



Step 3. Choose Administration > Time Settings > SNTP Authentication.



Step 4. Check the SNTP Authentication **Enable** check box.



Step 5. Click **Apply** to update the switch.



Step 6. Click Add.

SNT	SNTP Authentication Key Table						
	Authe	ntication Key ID	Authentication Key (Encrypted)	Trusted Key			
0 results found.							
	Add	Edit	Delete D	isplay Sensitive [	Data as Plaintext		

Step 7. Enter the number used to identify this SNTP authentication key in the *Authentication Key ID* field.

Authentication Key ID:	121110	(Range: 1 - 4294967295)				
Authentication Key:	User Defined (Encrypted)					
•	User Defined (Plaintext)	12112010				
Trusted Key:	Enable					
Apply Close						

Note: In this example, 121110 is entered.

Step 8. Choose an Authentication Key. The options are:

- User Defined (Encrypted) This option encrypts the Authentication Key.
- User Defined (Plaintext) This option displays the Authentication Key in plain text.

Authentication Key ID: 121110	(Range: 1 - 4294967295)					
Authentication Key: User Defined (Encrypted)						
<ul><li>User Defined (Plaintext)</li></ul>	12112010					
Trusted Key:   Enable						
Apply Close						

**Note:** In this example, User Defined (Plaintext) is chosen.

Step 9. (Optional) Enter the key used for authentication in the Authentication Key field.



**Note:** In this example, 12112010 is entered.

Step 10. Check the Trusted Key **Enable** check box to allow the switch to receive synchronization information only from an SNTP server with the use of this authentication

#### key.



Step 11. Click Apply.



Step 12. (Optional) Click Save.



You should now have successfully configured SNTP Authentication settings on your switch.