Access Point as a Workgroup Bridge Configuration Example

Contents

Introduction **Prerequisites** Requirements **Components Used Background Information Configure Network Diagram Configurations** Configure the Workgroup Bridge **GUI Instructions CLI** Instructions Configure the Root AP **GUI Instructions CLI Instructions** Verify **Troubleshoot**

Introduction

This document provides a sample configuration that configures an access point (AP) to function as a workgroup bridge (WGB) with use of the GUI and the CLI.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- Configuration of basic parameters on Cisco standalone APs
- Basic wireless concepts

Components Used

The information in this document is based on these software and hardware versions:

- Cisco Aironet 3600 Series AP that runs Cisco IOS[®] Software Release 15.2(4)JB4 as a workgroup bridge
- Cisco Aironet 1260 Series AP that runs Cisco IOS Software Release 15.2(4)JB4 as a root access point

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Background Information

A WGB can provide a wireless infrastructure connection for Ethernet-enabled devices. Devices that do not have a wireless client adapter in order to connect to the wireless network can be connected to the WGB through the Ethernet port. The WGB connects up to eight Ethernet-enabled devices to a Wireless LAN (WLAN). The WGB associates to the root AP through the wireless interface. In this way, wired clients obtain access to the wireless network. A WGB can associate to:

- An AP
- A bridge (in AP mode)
- A controller through a lightweight AP
- An AP in repeater mode (if the repeater is associated with a root AP)

In WGB mode, the unit associates to another AP as a client. The unit provides a network connection for the devices that are connected to its Ethernet port. Some of the typical usage scenarios for a WGB are:

- A single printer connected to WGB
- A network extension for multiple devices that are physically separated from the main network
- In the manufacturing sector where it is not feasible to deploy wires and there is a requirement for less roaming and high reliability
- On vehicles such as buses and trains in order to provide uplink access

The WGB associates to an AP on the network. An AP in WGB mode can associate only to an Aironet AP or bridge (in AP mode). The AP to which a WGB associates can treat the WGB as an infrastructure device or as a simple client device. By default, APs and bridges treat WGBs as client devices. For increased reliability, you can configure APs and bridges to treat WGBs, not as client devices, but as infrastructure devices, like APs or bridges. When these devices treat a WGB as an infrastructure device, the AP reliably delivers multicast packets, which include Address Resolution Protocol (ARP) packets, to the WGB. In order to configure APs and bridges to treat WGBs as infrastructure devices, perform one of these two options on your root AP:

- CLI Issue the infrastructure-client configuration command under the radio interface on the AP.
- GUI Navigate to Network > Network Interface > Choose the correct interface > Settings and enable reliable multicast.

If you configure APs and bridges in order to treat a WGB as a client device, you allow more WGBs to associate to the same AP or to associate with the use of a Service Set Identifier (SSID) that is not an infrastructure SSID. The performance cost of reliable multicast delivery - in which the

duplication of each multicast packet is sent to each WGB - limits the number of infrastructure devices (which includes WGBs) that can associate to an AP or bridge. In order to increase the number of WGBs that can associate to the AP beyond 20, the AP must reduce the delivery reliability of multicast packets to WGBs. With reduced reliability, the AP cannot confirm whether multicast packets reach the intended WGB. So WGBs at the edge of the AP coverage area can lose IP connectivity.

Configure

Network Diagram



Wired Clients

Configurations

This setup uses two APs, with a 1262 AP that acts as a root AP and a 3602 AP configured as a Workgroup bridge. It uses an open SSID called **wgb** for the WGB to associate to the root AP. Wireless clients are associated to the root AP. Wired clients connect through a switch to the AP that is configured as a WGB.

Configure the Workgroup Bridge

GUI Instructions

1. In order to create the SSID on the WGB, navigate to **Security > SSID Manager**.

alialia cisco	HOME NETWORK ASSOCIATION WIRELESS SECUR	ITY SERVICES MANGEMENT SOFTWARE	EVENTLOS	Sage Configuration Bing Logout Befree
Security Admin Access Escryption Manager SSITUR Manager Server Manager AP Auth-decidion Intrusion Detection Lacal RADIUS Server Advance Security	Hostname wgb Security: Global SSID Menager SSID Properties			wyth wyritme is 1 weech, 9 hours, 18 militados
	Cerrent SSID List	SSID: VLAH: Band-Select: Interfact:		
	Deinte Client Astherrication Settings Methods Accepted: @ Open Astherrication: @ Web Astherrication: @ Shared Astherricat	Kotwark ID: < NO ADOMONi- Web Pass < NO ADOMONi-	() Pages - 602 / 179 ⁻⁴⁻⁴	

Make sure to choose the correct radio interface that is used to associate with the root AP.

Convert the AP into a workgroup bridge from the default mode of the root AP. In order to do
this, navigate to Network > Network Interface > Choose the correct radio interface >
Settings. Choose the role in the radio network to be the Workgroup Bridge.

cisco ge	OME METWORK ASSOCIATION WIRELESS	SECURITY SERVICES BANAGEMENT SOFTWARE	EVENT LOG	Sage Configuration Eng Lagout Refresh
	RADIO3-602.11N ^{2.40KZ} STATUS	DETAILED STATUS	SELLINGS CA	NNER BUSY TEST wyb uptime is 1 week, 9 bours, 38 minutes
Summery Adjacent Nodes	Network Interfaces: Radia0-882.11N ^{2.4CHz} Sett	ings		
Summary IP Address GlobbiPhernet0	Operating Mode:	Mixed		
Radio0-802.11n 2.40Hp Radio1-802.11n 50Hz	Enable Hadio: Carrent Status (Software/Hardware):	* Enable	O Disable Down	
	Role in Radio Hetwork:	Access Point Access Point (Access Point (Access Point (Palback to Rupeder) Repolar Repolar Rest Bridge Non-Rest Bridge Rest Bridge with Waveless Cherts Nan-Rest Bridge with Waveless Cherts		
		Workgooup Dridge Usevenal Workgooup Dridge Client MAC: Starwor Spectrum (Spectrum Information)	(110-01)-01001 10-040	
	11r Canfiguration:	© enable ≢ disable © over air © over do Reassociation time:	(20-1200 ms)	
	Data Rates:	Best Range Best Throughput Default		

CLI Instructions

1. In order to configure the SSID, enter:

wgb(config)#dot11 ssid wgb
wgb(config-ssid)#authentication open

2. In order to change the station role to the wokrgroup bridge under the the correct radio interface, enter:

Configure the Root AP

GUI Instructions

1. In order to create the SSID on the root AP, navigate to **Security > SSID Manager**. This procedure is the same as the one used to create the SSID on the workgroup bridge.

cisco	HOME NETWORK ASSOCIATION WIRELESS SEC	UNITY SERVICES MANAGEMENT SOFTWARE EN	Singe Configuration (Eng.) Lagout (Enfres
Security Admin Access Encryption Monager SSID Manager	Wastaame root	}	raat uptime in 1 week, 10 hours, 7 minutes
	Security: Global SSID Manager		
	SSID Properties		
AP Authentication	Corrent SSID List		
Intrusion Detection	s new >	SSID	inga
Advance Security		N.M.	< NONE > • Define VLAVia Elackum 1:
	+		Backap 2
			Backup 3:
		Band Select	Band Select
		Interface:	RedoDe022.11162-409ts
		Network ID:	(0-4096)
	Delete		
	Client Authentication Settings		
	Nothon's Accepted:		
	Open Authentication:	< NO ADDITION>	
	Web Authenticelien	Web Pass	
	E Phone Antonio Sector	a las aportants	

2. In order to configure the AP role as root, navigate to Network > Network Interface > Choose the correct radio interface > Settings. Choose the role in the radio network to be the AP as shown here:

cisco	HOME BETWORK ASSOCIATION WIRELESS	SECURITY SERVICES MANAGEMENT SOFTWA	NE EVENTLOS	_	Sage Configuration Bing Logent Befresh
NETWORK * NETWORK MAP Suranary Adjuant Nodes * NETWORK INTERFACE Suranary	RADIOD-882.11N ^{2.40HC} STATUS	DETAILED STATUS	92110405	CARRIER BUSY TEST	raol agtime is 1 week, 10 hours, 11 minutes
	Network Interfaces: Radiol-802.118 ^{2,424r} So	rtings			
Gipabit2thernet0 Radio0-002.11n 2.4GHz Radio1-002.11n 5GHz	Enable Radia: Current Status (Seffware/Handware):	* Enable Disabled	 Disable Down 		
	Role in Radio Hetwork:	Access Point Access Point Access Point (Falback to Radio Shutdown) Access Point, Falback to Reposter) Repeater			
		© Rost Bridge © Nos-Rost Bridge © Rost Bridge with Wineless Clients © Nos-Rost Bridge with Wineless Clients			
		© Workgroup Bridge © Universal Workgroup Bridge — Client MAC: [© Science © Spectrum@pecture.information	(*************************************		
	11r Configuration:	© enable ≇ disable © over-air © over-do Reassociation-time:	(20-1200 ms)		

CLI Instructions

1. In order to configure the SSID, enter:

```
root(config)#dot11 ssid wgb
root(config-ssid)#authentication open
```

The guest-mode command configures the SSID to be broadcasted by the root AP.

2. In order to configure the radio role to be the root and add the SSID under the radio, enter:

root(config)#interface dot11Radio 0
root(config-if)#station-role root
root(config-if)#ssid wgb

Verify

In order to look at the clients connected to the root AP, enter the **show dot11 associations** command. A sample ouput is shown here:

root#show dot11 associations
802.11 Client Stations on Dot11Radio0:
SSID [wgb] :
IPV6
MAC Address IP address address Device Name Parent State
4c00.82df.clad 10.105.132.173 :: WGB wgb self Assoc <-WGB
entry
68bc.0c5a.df01 10.105.132.174 :: WGB-client - 4c00.82df.clad Assoc <-Wired
client entry
6c41.6a78.d832 10.105.132.175 :: WGB-client - 4c00.82df.clad Assoc <-Wired
client entry</pre>

In order to verify the parent that the WGB connects to, enter the **show dot11 associations** command:

wgb#show dot11 associations

802.11 Client Stations on Dot11Radio0: SSID [wgb] : IPV6 MAC Address IP address address Device Name Parent State ccd5.39e3.b260 10.105.132.133 :: ap1260-Parent root - Assoc

There can be times when, even though the wired client is shown as associated, you are not be able to pass traffic to it. This could be because the WGB has removed the client entry from its forwarding table. This can happen if the wired client does not send any traffic for the timeout period. You can find the list of active clients with the **show bridge** command:

wgb# show	bridge	9						
Total of 300 station blocks, 292 free								
Codes: P - permanent, S - self								
Bridge Group 1:								
Address		Action	Interfac	ce Age	RX	count	ΤX	count
68bc.0c5a	a.df01	forward	ViO	0		43		20
6c41.6a78	3.d832	forward	Vi0	0		29		12

Troubleshoot

This section provides information you can use to troubleshoot your configuration. Complete these

checks if WGB does not associate to the AP.

- Check if the configurations match between the AP and the WGB. Make sure SSID, Security settings, and Data Rates match between them.
- Make sure that Radio Frequency (RF) environment between AP and WGB is free from interference. Refer to the <u>RF Impairments</u> section of **Troubleshooting Problems Affecting Radio Frequency Communication** for more information.

The **debug dot11dot11 0 trace print uplink** debug command is useful to use on the WGB. This command takes you through the join process of a WGB, from scanning (if there are multiple parents), selection process for the parent, association and dot1x/PSK authentication (if configured) phases. Here is some sample ouput:

```
*Aug 3 09:33:10.607: 16ED71A7-0 Uplink: Stop
*Aug 3 09:33:11.611: 16FCBED3-0 Interface up
*Aug 3 09:33:11.627: 16FCDDCE-0 Uplink: Wait for driver to stop
*Aug 3 09:33:11.627: 16FCDE3D-0 Uplink: Enabling active scan
*Aug 3 09:33:11.627: 16FCDE42-0 Uplink: Not busy, scan all channels
*Aug 3 09:33:11.627: 16FCDE46-0 Uplink: Scanning
*Aug 3 09:33:11.639: 16FD2D1B-0 Uplink: Rcvd response from ccd5.39e3.b260 channel 7 2615
*Aug 3 09:33:11.919: 17017B61-0 Uplink: no rsnie or ssnie chk
*Aug 3 09:33:11.919: 17017B6B-0 Uplink: ssid wgb auth open
*Aug 3 09:33:11.919: 17017B6F-0 Uplink: try ccd5.39e3.b260, enc 0 key 0, priv 0, eap 0
*Aug 3 09:33:11.919: 17017B6F-0 Uplink: Authenticating
*Aug 3 09:33:11.923: 1701835E-0 Uplink: Associating
*Aug 3 09:33:11.939: %DOT11-4-UPLINK_ESTABLISHED: Interface Dot11Radio0, Associated To AP root
ccd5.39e3.b260 [None]
```