

Configure Fluidity Parameters on Industrial Wireless Access Points in URWB Mode

Contents

[Introduction](#)

[Prerequisites](#)

[Requirements](#)

[Components Used](#)

[Background Information](#)

[CLI configuration of Fluidity parameters](#)

Introduction

This document describes the configuration of Fluidity parameters on IW9165 and IW9167 radios in URWB mode.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- Basic CLI navigation and commands
- Understanding of IW URWB mode radios

Components Used

The information in this document is based on these software and hardware versions:

- IW9165 and IW9167 radios

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, ensure that you understand the potential impact of any command.

Background Information

On the IW9165 and IW9167 radios in URWB mode, there are several parameters associated with a Fluidity setup. Fluidity networks are ones where there are Infrastructure radios which are stationary alongside Vehicle radios that are mobile.

The vehicle radios communicate with one Infrastructure radio at a time, which has the best signal strength.

These parameters can be configured over IoT OD with the Industrial Wireless service and over CLI as well.

CLI configuration of Fluidity parameters

Show commands:

These parameters can be executed from enable mode on the CLI of the devices.

1. Current configuration:

The current configuration of the Fluidity parameters on the device can be viewed with this command.

Radio1#show fluidity configuration

```
[ME_TRK_IW9167EH#show fluidity config
Fluidity enabled
Fluidity interface: 1
Infrastructure mode
Backhaul-check: disabled
Mesh-end backhaul-check: disabled
Color: enabled, current: 0
Network type: flat (layer 2)
Warmup time: 20000 ms
Wireless timeout: 800 ms
Wireless fastdrop: disabled
Frequency scan: disabled
Large network optimization: enabled
Routes: backhaul
Primary-pseudowire enforcement: disabled
Max number of clients: unlimited
DoP settings: limit 0, client 10, bias 0
Quadro telemetry: enabled
```

2. Current Fluidity network setup:

This command shows the current setup of the Fluidity network this device belongs to, including all the pseudowires formed and the overall network details.

Radio1#show fluidity network

```
ME_TRK_IW9167EH#show fluidity network
unit 5.246.2.0 infrastructure meshend primary
vehicles 2 total_mobiles 3
infrastructure 2 backbone 0 meshend 5.246.2.0
```

| Vehicle ID | Path | Infrastr.ID | via | Mobile ID | via | H/O Seq | H/O Age | #M | Primary ID | Secondary IDs |
|------------|------|-------------|-----|-------------|-----|---------|---------|----|-------------|---------------|
| 83935198 | 0 | 5.1.88.75 | R1 | 5.0.191.222 | R1 | 1816852 | 0.931 | 2 | 5.0.191.222 | 5.1.88.112 |
| 88261156 | 0 | 5.1.88.75 | R1 | 5.66.194.36 | R1 | 44805 | 8.751 | 1 | 5.66.194.36 | |

```
Typ  Infrastr.ID  #V  Vehicle IDs
-----
    5.1.88.75      2  88261156 83935198
* M  5.246.2.0      0
ME_TRK_IW9167EH#
```

Configuration commands:

3. Fluidity ID:

This parameter allows to set the role for the device. The ID for the device can be set to Infrastructure mode for static devices, Vehicle for mobile devices and Wireless relay for backhaul devices.

Under Vehicle configuration either an automatic ID can be assigned to all devices that belong to a single vehicle, or this can be manually configured as well.

Radio1#conf fluidity id infrastructure

Radio1# conf fluidity id wireless-relay

Radio1#conf fluidity id vehicle-auto

Radio1#conf fluidity id vehicle-id

```
ME_TRK_IW9167EH#conf fluidity id
  infrastructure set infrastructure mode
  vehicle-auto   set vehicle mode with automatic ID selection
  vehicle-id     set vehicle mode with manual ID selection
  wireless-relay set wireless-relay mode
```

```
ME_TRK_IW9167EH#conf fluidity id vehicle-id
WORD vehicle id, cannot be negative integer or a number starting with 0,
cannot include these characters: ' " ` $ = \ and whitespace
```

4. Fluidity handoff logic:

This parameter allows to specify the logic to be used when vehicle radio moves between one infrastructure to another.

The default value is standard logic, based on the best RSSI value.

Load-balancing allows to share the load between several infrastructure radios. Manual method disables any

automatic handoffs and v2v method is used when Vehicle to vehicle communication is needed.

Radio1#conf fluidity handoff standard

Radio1#conf fluidity handoff manual

Radio1#conf fluidity handoff load-balancing

Radio1#conf fluidity handoff v2v

```
[ME_TRK_IW9167EH#conf fluidity handoff
load-balancing enable load balancing handoff logic
manual          disable automatic handoff
standard        enable standard handoff logic
v2v             allow v2v handoff logic
```

5. Fluidity connect:

This parameter allows to force a manual connection from the vehicle radio to the infrastructure unit who's mesh ID is provided. For example this command forces a connection to the Infrastructure unit with Mesh ID 5.1.2.3.

Radio1#conf fluidity connect 5.1.2.3

```
[ME_TRK_IW9167EH#conf fluidity connect
WORD mesh-id of infrastructure unit to connect to (A.B.C.D)
```

6. Large Network Optimization:

This parameter allows to enable or disable LNO on the device.

Radio1#conf fluidity lno disabled

Radio1#conf fluidity lno enabled

```
ME_TRK_IW9167EH#conf fluidity lno
disabled disable fluidity large network optimization
enabled  enable fluidity large network optimization
```

7. Quadro telemetry:

This parameter allows to enable or disable Fluidity Quadro telemetry data.

Radio1#conf fluidity quadro disabled

Radio1#conf fluidity quadro enabled

```
[ME_TRK_IW9167EH#conf fluidity quadro
disabled  disable Quadro telemetry
enabled   enable  Quadro telemetry
```

8. Fluidity access:

This parameter helps with either allowing or blocking access to a certain device for a specified amount of time, on the specified radio interface.

Radio1#conf fluidity access allow <mesh ID> <intf>

Radio1#conf fluidity access block <mesh ID> <time in minutes> <intf>

```
[ME_TRK_IW9167EH#conf fluidity access block 5.1.2.3
<1-65535>  expiry timeout (s), default 5 minutes
R1         radio interface number 1
R2         radio interface number 2
```

```
ME_TRK_IW9167EH#conf fluidity access allow 5.1.2.3
R1  radio interface number 1
R2  radio interface number 2
```

9. Delta values :

This parameter allows to define the delta-high, delta-low and delta-threshold values of the signal strength parameter to be used for the handoff logic which determines handoff between infrastructure radios.

Delta-high refers to the optimum upper handoff hysteresis threshold, Delta-low refers to the optimum lower handoff hysteresis threshold and delta-threshold refers to the Fluidity handoff hysteresis low/high threshold.

Radio1#conf fluidity delta-high <int>

Radio1#conf fluidity delta-low <int>

Radio1#conf fluidity delta-threshold <int>

```
ME_TRK_IW9167EH#conf fluidity delta-high
<0-65535> handoff hysteresis high threshold
ME_TRK_IW9167EH#conf fluidity delta-low
<0-65535> handoff hysteresis low threshold
[ME_TRK_IW9167EH#conf fluidity delta-threshold
<0-65535> RSSI low/high zones threshold
```

10. Maximum clients :

This parameter defines the maximum number of vehicle radios each infrastructure radio can connect to. If set to 0, it allows the infrastructure radio to connect to unlimited number of vehicle radios.

Radio1#conf fluidity max-clients 5

```
ME_TRK_IW9167EH#conf fluidity max-clients
<0-65535> maximum number of clients (0 = unlimited)
```

11. Backhaul check:

This parameter allows to define the backhaul check feature on the radios.

If set to disabled, then the backhaul check is not performed.

Radio1#conf fluidity backhaul-check disabled

If set to handoff-inhibition, on an infrastructure device, the device is not considered as an option to handoff, if all the ethernet ports on it are down.

Radio1#conf fluidity backhaul-check handoff-inhibition

If set to relay-switch, the infrastructure device is temporarily switched to wireless relay if the ethernet port is down.

Radio1#conf fluidity backhaul-check relay-switch

```
[ME_TRK_IW9167EH#conf fluidity backhaul-check
disabled          backhaul-check disabled
handoff-inhibition inhibit handoff if all ethernet ports are down
me-check          if enabled, this infrastructure unit will not be eligible
                  for the handoff if the mesh-end is unreachable
relay-switch      switch to Infrastructure Wireless Relay mode if all
                  ethernet ports are down
```

12. Backhaul check meshend check:

This parameter allows to enable a secondary check on the existing backhaul check feature. While backhaul check feature only checks for the Ethernet port status, ME-check verifies if the infrastructure unit can actually reach the Mesh End of the network. If the me-check parameter is selected under backhaul check, further options can be specified.

If set to disabled, then me-check is not performed.

```
Radio1#conf fluidity backhaul-check me-check disabled
```

If set to handoff-inhibition on an infrastructure device, the device is not considered as an option to handoff if it cannot reach the Mesh End of the network.

```
Radio1#conf fluidity backhaul-check me-check handoff-inhibition
```

If set to relay-switch, the infrastructure device temporarily switches to wireless relay if the Mesh End is not reachable.

```
Radio1#conf fluidity backhaul-check me-check relay-switch
```

```
[ME_TRK_IW9167EH#conf fluidity backhaul-check me-check
disabled          disable mesh-end backhaul check
handoff-inhibition inhibit handoff if the mesh-end is unreachable
relay-switch      switch to Infrastructure Wireless Relay mode if the
                  mesh-end is unreachable
```

13. Degree of Preference (DoP):

This parameter allows to define the Degree of Preference value. The Degree of Preference (DoP) is a crucial adimensional metric in Fluidity network, used to assess the load level of each network units, whether mobile or infrastructure. DoP enables smart network management by using real-time load information to guide connection decisions.

For detailed info on the Degree of Preference parameter, please refer to this article:

[Configure Load Balancing on APs in CURWB Mode](#)

To define the dop bias :

Radio1#conf fluidity dop bias <int>

To define the dop limit :

Radio1#conf fluidity dop limit <int>

To define the dop per-client overhead :

Radio1#conf fluidity dop client <int>

```
[ME_TRK_IW9167EH#conf fluidity dop
bias      set DoP bias
client    set per-client DoP overhead
limit     set DoP upper limit
```

14. Fluidity scan :

This parameter allows to define the Frequency autoscan feature options.

To disable frequency autoscan:

Radio1#conf fluidity scan disabled

To initiate a frequency scan after the vehicle device is disconnected from infrastructure for a certain time.

Radio1#conf fluidity scan isolation <time in ms>

To define a list of frequencies to scan for other infrastructure units or to clear the list.

Radio1#conf fluidity scan list <list of channels>

Radio1#conf fluidity scan list clear

To initiate a live frequency scan

Radio1#conf fluidity scan live

To initiate a periodic frequency scan when the unit is idle and to disable it

Radio1#conf fluidity scan periodic <time in seconds>

Radio1#conf fluidity scan periodic disabled

To define the RSSI threshold to trigger a frequency autoscan and to disable it

Radio1#conf fluidity scan rssi-threshold <value in db>

Radio1#conf fluidity scan rssi-threshold disabled

To define if all units on the same vehicle are to use the same frequency or allowed to use different frequencies.

Radio1#conf fluidity scan vehicle-frequency locked

Radio1#conf fluidity scan vehicle-frequency open

```
[ME_TRK_IW9167EH#conf fluidity scan
disabled          disable frequency autoscan
isolation         scan when disconnected from the infrastructure for a
                  certain time (ms)
list              set list of frequencies to scan for other Fluidity units
live              do a frequency scan now
periodic          configure periodic autoscan when the unit is idle (s)
rssi-threshold    configure critical RSSI threshold for autoscan
vehicle-frequency choose whether mobile units on the vehicle can use
                  different frequencies or not
```

For further details on the frequency autoscan feature refer to this article :

[Configure Multi Frequency with Fluidity on APs in CURWB Mode](#)

15. MPO:

This parameter allows to define values for the Multi Path Operation feature.

To enable or disable MPO :

Radio1#conf fluidity mpo status enabled

Radio1#conf fluidity mpo status disabled

To enable MPO only on received traffic :

Radio1#conf fluidity mpo status rx-only

```
ME_TRK_IW9167EH#conf fluidity mpo status
disabled    disable mpo
enabled     enable mpo
rx-only     set mpo status as rx-only
```

To configure the CoS of the traffic for MPO :

Radio1#conf fluidity mpo cos <cos value 0 to 7>

```
[ME_TRK_IW9167EH#conf fluidity mpo cos
<0-7>  configure Class-of-Service to protect via MPO
```

To configure the maximum number of MPO paths allowed:

Radio1#conf fluidity mpo path max <1-4>

```
[ME_TRK_IW9167EH#conf fluidity mpo path max
<1-4>  maximum number of MPO links allowed, including the primary path
        (default 1)
```

To configure the minimum RSSI value to trigger MPO :

Radio1#conf fluidity mpo rssi min <rssi value>

```
ME_TRK_IW9167EH#conf fluidity mpo rssi min  
<0-96> minimum RSSI to establish MPO redundant links (default 20)
```

To enable or disable sending MPO Telemetry data :

Radio1#conf fluidity mpo telemetry enabled

Radio1#conf fluidity mpo telemetry disabled

```
ME_TRK_IW9167EH#conf fluidity mpo telemetry  
disabled disable additional mpo telemetry  
enabled enable additional mpo telemetry
```

16. Enforce Psuedowire Principal access :

This feature is used to either enable or disable access to onboard client devices from the Primary vehicle device.

Radio1#conf fluidity enforce-pws-primary enabled

Radio1#conf fluidity enforce-pws-primary disabled

```
ME_TRK_IW9167EH#conf fluidity enforce-pws-primary  
disabled allow on-board client devices to be connected to mobile secondary  
enabled force on-board client devices to be reached via the mobile primary
```

17. Wireless Fastdrop:

This parameter allows to configure the maximum number of consecutive packets that can be lost, before wireless fastdrop is triggered.

This allows the infrastructure devices to drop Vehicle radios once the configured number of consecutive packets are lost.

Radio1#conf fluidity fastdrop count <packet count>

```
[ME_TRK_IW9167EH#conf fluidity fastdrop count  
<0-65535> max number of consecutively lost packets (0 means fastdrop  
disabled)
```

18. Routes :

This parameter allows to define if only backhaul routes are to be advertised or both backhaul and vehicle routes are to be advertised.

This parameter needs to be set to all if Vehicle to Vehicle communication is needed.

Radio1#conf fluidity routes backhaul

Radio1#conf fluidity routes all

```
ME_TRK_IW9167EH#conf fluidity routes
all      advertise backhaul and vehicles routes
backhaul advertise backhaul routes
```

19. Timeout :

This parameter allows to defining the timeout value in ms within which if the Vehicle radio does not receive a signalling packet from an Infrastructure radio; it clears out the all the information associated with that Infrastructure unit.

Radio1#conf fluidity timeout <value in ms>

```
[ME_TRK_IW9167EH#conf fluidity timeout
<0-65535> timeout value (ms)
```

20. VLAN :

This parameter allows to add, show or clear VLAN data used in Layer 3 networks .

To add a VLAN :

Radio1#conf fluidity vlan <subnet> <netmask> <vlan id>

To clear VLANs :

Radio1#conf fluidity vlan clear

To show VLANs :

Radio1#conf fluidity vlan show

```
[ME_TRK_IW9167EH#conf fluidity vlan
add      add a new VLAN subnet
clear    clear VLAN subnet list
show     show VLAN subnet list
```

21. Warmup time :

This parameter allows to define the warmup time in ms on the device. If the device is in Infrastructure mode it does not accept any connections during this time. If the device is in Vehicle mode it does not initiate any connections during this time.

The warmup time counter is triggered during this sequence:

1. Whenever the device is rebooted/activated.
2. If the LAN port on the device is activated/deactivated.
3. When the device does the first RADIUS authentication.
4. When backhaul check is triggered.

Radio1#conf fluidity warmup <time in ms>

```
[ME_TRK_IW9167EH#conf fluidity warmup
<0-300000> warmup time (ms)
```