



APPENDIX **A**

Command Line Interface Reference

This appendix describes the command line interface for the Cisco Application Deployment Engine Operating System (ADE OS), version 1.2.

This appendix includes the following sections:

- [About the ADE OS CLI, page A-1](#)
- [EXEC Commands, page A-6](#)
- [Show Commands, page A-60](#)
- [Configuration Commands, page A-93](#)

About the ADE OS CLI

Cisco ANM Virtual Appliance runs on the Cisco Application Deployment Engine (ADE) operating system, version 1.2. The operating system includes its own IOS-like command line interface where you can perform basic setup and monitoring tasks for the virtual appliance.

This appendix describes the commands in the ADE OS CLI. Each command is accompanied by a brief description, syntax and usage guidelines, and one or more examples.

The commands are organized by mode, as follows:

- **EXEC**—Use the commands in this mode to perform system-level configuration. In addition, certain EXEC mode commands have ANM-specific abilities. See the [“EXEC Commands” section on page A-6](#) and [“Show Commands” section on page A-60](#).
- **Configuration**—Use the commands in this mode to perform additional configuration tasks for ANM Virtual Appliance. Use the EXEC mode system-level **configure** command to access the configuration mode (see the [“Configuration Commands” section on page A-93](#)).

ADE OS Commands Not Supported by ANM Virtual Appliance

ADE OS is designed for general networking management applications. The CLI includes several functions not intended for use with ANM Virtual Appliance and which are not documented in this appendix.

The ADE OS commands not intended for use with ANM Virtual Appliance include the following:

- **application install**
- **application remove**

User Accounts and Modes in ANM Virtual Appliance

As described in the “[User Accounts and Modes](#)” section on page 4-3, there are two different types of accounts available on ANM Virtual Appliance:

- Admin (administrator)
- Operator (user)

[Table A-1](#) lists the command privileges for each type of user account.

Table A-1 Command Privileges

Command	User Account	
	Admin	Operator (User)
anm-certificate install	P	—
anm-data-export audit	P	—
anm-data-export history	P	—
anm-license install	P	—
anm-tool configure	P	—
anm-tool restart	P	—
anm-tool load-inventory	P	—
access-setting accept-all	P	—
application commands	P	—
backup	P	—
backup-logs	P	—
cdp run	P	—
clock	P	—
configure terminal	P	—
copy commands	P	—
debug	P	—
debug-adclient	P	—
debug-log	P	—
delete	P	—
dir	P	—
end	P	—
exit	P	P
export-data	P	—
forceout	P	—
halt	P	—
hostname	P	—
icmp	P	—
import-data	P	—

Table A-1 Command Privileges (continued)

Command	User Account	
	Admin	Operator (User)
import-export-abort	P	—
import-export-status	P	—
interface	P	—
ip default-gateway	P	—
ip domain-name	P	—
ip name-server	P	—
ip route	P	—
kron	P	—
logging commands	P	—
mkdir	P	—
nslookup	P	P
ntp server	P	—
password policy	P	—
patch	P	—
ping	P	P
reload	P	—
replication	P	—
repository	P	—
reset-management-interface-certificate	P	—
restore commands	P	—
rmdir	P	—
service	P	—
show application	P	—
show backup	P	—
show cdp	P	P
show clock	P	P
show cpu	P	P
show debug-adclient	P	—
show debug-log	P	—
show disks	P	P
show icmp_status	P	P
show interface	P	P
show inventory	P	P
show ip route	P	—
show logging	P	P

Table A-1 Command Privileges (continued)

Command	User Account	
	Admin	Operator (User)
show logins	P	P
show memory	P	P
show ntp	P	P
show ports	P	P
show process	P	P
show repository	P	—
show restore	P	—
show running-configuration	P	—
show startup-configuration	P	—
show tac	P	—
show tech-support	P	—
show terminal	P	P
show timezone	P	P
show timezones	P	—
show udi	P	P
show uptime	P	P
show users	P	—
show version	P	P
snmp-server commands	P	—
ssh	P	P
ssh keygen	P	P
ssh rmkey	P	P
tech	P	—
telnet	P	P
terminal	P	P
traceroute	P	P
undebg	P	—
username	P	—
write	P	—

Information About Command Output Modifiers

This section describes the command output modifiers that are available with a number of the ADE OS commands, including all the **show** commands. The modifiers are a vertical bar (|) that allows you to filter the command output and an angle bracket (>) that allows you to redirect the command output.

For example, the syntax for the show command is as follows:

```
show keyword [| {begin pattern | count | end pattern | exclude pattern | include pattern | next |
prev}] [> {filename disk:[path/][filename] | ftp://server/path[/filename] |
sftp://[username@]server/path[/filename] | tftp://server[:port]/path[/filename]}]
```

The *keyword* argument represents a specific item to display, such as **application**, **interface**, or **running-config** (for details, see the **show** command). The command modifier syntax descriptions are as follows:

	(Optional) Enables an output modifier that filters the command output.
begin <i>pattern</i>	Begins with the line that matches the pattern that you specify.
count	Counts the number of lines in the output.
end <i>pattern</i>	Ends with the line that matches the pattern that you specify.
exclude <i>pattern</i>	Excludes the lines that match the pattern that you specify.
include <i>pattern</i>	Includes the lines that match the pattern that you specify.
next	Displays the lines next to the matching pattern that you specify.
prev	Displays the lines before the matching pattern that you specify.
>	(Optional) Enables an output modifier that redirects the command output to a file.
<i>filename</i>	Name of the file that the ACE saves the output to on the volatile: file system.
disk:	Specifies that the destination is the ANM disk: file system.
[<i>path/</i>][<i>filename</i>]	(Optional) Path and filename to the disk: file system. This path is optional because ANM prompts you for this information if you omit it.
ftp://server/path[/filename]	Specifies the File Transfer Protocol (FTP) network server and optional filename.
sftp://server/path[/filename]	Specifies the Secure File Transfer Protocol (SFTP) network server and optional filename. A single forward slash (/) after <i>server</i> makes the path relative to the user's home directory. Two forward slashes (//) after <i>server</i> makes the path relative to the root directory.
tftp://server[:port]/path[/filename]	Specifies the Trivial File Transfer Protocol (TFTP) network server and optional filename. A single forward slash (/) after <i>server</i> makes the path relative to the user's home directory. Two forward slashes (//) after <i>server</i> makes the path relative to the root directory.

EXEC Commands

This section lists and describes the EXEC commands. Each command includes a brief description of its use, command syntax, usage guidelines, and sample output.

Table A-2 provides a list of the EXEC commands. Each command provides a link to its details.

Table A-2 List of EXEC Commands

<ul style="list-style-type: none"> • anm-certificate install • anm-data-export audit from • anm-data-export history from • anm-license install • anm-sysinfo • anm-tool configure • anm-tool load-inventory • anm-tool restart • application install • application remove • application reset-config • application start • application stop • application upgrade • backup • backup-logs • clock set 	<ul style="list-style-type: none"> • configure terminal • copy • debug • delete • dir • exit • forceout • halt • help • mkdir • nslookup • patch install • ping • reload 	<ul style="list-style-type: none"> • restore • rmdir • show (see Show Commands) • ssh • tech dumptcp • telnet • terminal length • terminal session-timeout • terminal session-welcome • terminal terminal-type • traceroute • undebg • write
---	--	---

anm-certificate install

To install a third party server certificate/key pair for ANM Virtual Appliance, use the **anm-certificate install** command. The ANM VA software installation process includes a self-signed certificate/key pair for authenticating itself to browser clients; however, you can choose not to use it by installing a third party certificate/key pair.



Caution

Installing a third party certificate/key pair overwrites the self-signed certificate/key pair included with the ANM VA software. There is no documented way to revert to the self-signed certificate/key pair after you install a third party certificate/key pair.



Note

The **anm-certificate install** command is not used to load certificates used by managed devices to establish network traffic connections; device certificates are loaded from within the ANM web interface.

The syntax for this command is as follows:

```
anm-certificate install certificate-file key-file [passphrase]
```

Syntax Description

<i>certificate-file</i>	Certificate file should be a valid server certificate generated for this ANM Virtual Appliance. The file should reside at the <i>disk:</i> location of the file system of the virtual appliance. Use the copy command to move the file to the virtual appliance file system.
<i>key-file</i>	Private key associated with the certificate you are loading on ANM Virtual Appliance.
<i>passphrase</i>	(Optional) Encryption passphrase, which is required only if the key is encrypted. If the passphrase contains spaces, enclose it with double quotes (for example, "pass phrase"). If it contains a question mark symbol, press Ctrl-v before typing the question mark to override the help display.

Defaults

No default behavior or values.

Command Modes

EXEC

Examples

```
anm-va/admin# copy sftp://staging-server/certificates/myserver.cert disk:
anm-va/admin# copy sftp://staging-server/certificates/myserver.key disk:
anm-va/admin# anm-certificate install disk:myserver.cert disk: myserver.key
```

anm-data-export audit from

To export audit log information from ANM Virtual Appliance, use the **anm-data-export audit from** command in the EXEC mode.

This command generates an archive file that contains audit-related information for the ANM application. Audit log information consists of the information shown in the Device Audit and ANM Change Audit Log pages of the ANM web interface. It includes, for example, user login attempts and configuration deployments to devices.

The command generates an archive of audit logs that occurred within a date range you specify. The resulting archive is placed on the virtual appliance disk.

anm-data-export audit from *start* [*to end*] **disk:***file*

Syntax Description

<i>start</i>	Starting date of the range of information to be exported, where date is in YYYY-MM-DD format (for example, 2010-09-08 for September 8, 2010).
<i>to end</i>	(Optional) End date of the range of information to be exported, where date is in YYYY-MM-DD format (for example, 2010-11-09 for November 9, 2010). If this argument is omitted, all data newer than the starting date is exported.
disk: <i>file</i>	Filename to which the data will be exported. The final file name will be <i>file-audit.tgz</i> .

Defaults

No default behavior or values.

Command Modes

EXEC

Examples

```
anm-va/admin# anm-data-export audit from 2010-03-22 disk:/logfiles/marchlogs
```


anm-data-export history from

To export device history information from ANM Virtual Appliance, use the **anm-data-export history from** command in the EXEC mode. The command generates an archive of history logs that occurred within a date range you specify.

anm-data-export history from *start* [*to end*] **disk:***file*

Syntax Description

<i>start</i>	Starting date of the range of information to be exported, where date is in YYYY-MM-DD format (for example, 2010-09-08 for September 8, 2010).
to <i>end</i>	(Optional) End date of the range of information to be exported, where date is in YYYY-MM-DD format (for example, 2010-11-09 for November 9, 2010). If this argument is omitted, all data newer than the starting date is exported.
disk: <i>file</i>	Filename to which the data will be exported. The final file name will be <i>file</i> -history.tgz.

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

This command generates an archive file that contains information related to the activities of the devices managed by ANM. “History information” refers to events related to device resource usage, load balancing activities, and traffic processing. Specifically, this information is equivalent to that shown on these ANM web interface pages:

- Monitor > Devices > Resource Usage
- Monitor > Devices > Load Balancing
- Monitor > Devices > Traffic Summary

This command places an archive of the logs on the virtual appliance disk. From there, it can be copied to a remote system using the copy command. Note however, that the [backup-logs](#) command collects files that include the results of the anm-data-export operation. Therefore, the [backup-logs](#) command can be used to automate the transfer of exported audit and history data files to a remote location.

Examples

```
anm-va/admin# anm-data-export history from 2010-03-22 disk:/logfiles/marchlogs
```

anm-license install

To apply the site-specific license for the ANM application, use the **anm-license install** command. A valid license enables you to use ANM Virtual Appliance to manage network devices.

anm-license install *license-file*

Syntax Description

<i>license-file</i>	License file should be a valid license generated for this ANM Virtual Appliance. The license file should reside on the disk: file system of the virtual appliance. You can use the copy command to move the license to the virtual appliance file system.
---------------------	---

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Each ANM Virtual Appliance should have its own, MAC-address-bound license (for more information, see [“Acquiring a License for ANM Virtual Appliance”](#) section on page 3-3).

Examples

```
anm-va/admin# copy tftp://staging-server/licenses/anm-5.1-XXXXXX.lic disk:
anm-va/admin# anm-license install disk:anm-5.1-XXXXXX.lic
```

anm-sysinfo

To create the ANM lifeline file (anm-lifeline.tar.gz) under disk:, use the **anm-sysinfo** command. After you create the lifeline file, you can use the **copy** command to place a copy of the file on a remote server.

anm-sysinfo

Syntax Description

This command has no arguments or keywords.

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Create a Lifeline package after you encounter a problem that might require customer support assistance. The package is meant to be viewed by customer support and works as follows:

- Lifeline collects debug data from diagnostic generators based on priority - most important to least important. When the total data size reaches 200 MB, the collector stops collecting, and data from generators with lower priorities can be lost. For details on content, size, time, state, and any dropped data, see the Readme file included in each Lifeline package.
- Lifeline collects the last 25 MB of data from the file and truncates the beginning content.
- Lifelines are automatically packaged by the system in zip files. The naming convention for a lifeline package is "lifeline-yyMMdd-hhmmss.zip". For example, lifeline-07062-152140.zip is a Lifeline package created at 3:21:40 PM, June 22, 2007.
- Only one Lifeline package is created at a time. The system will reject a second request made before the first Lifeline has been packaged.
- Lifeline times out in 60 minutes.
- A maximum of 20 Lifeline packages are stored at a time.

Examples

```
anm-va/admin# anm-sysinfo
```

anm-tool configure

To modify the settings of the web server component of ANM Virtual Appliance, use the **anm-tool configure** command. **anm-tool configure** [advanced-options]

Syntax Description	advanced-options (Optional) Enables configuring of the web services attributes
---------------------------	---

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	EXEC
----------------------	------

Usage Guidelines	These settings specify whether the ANM web interface is accessible by HTTP or HTTPS. They also specify the listening ports for these protocols. These settings are typically configured upon initial setup of ANM Virtual Appliance. This command allows you to re-initiate the configuration sequence for the component.
-------------------------	---

When used with the optional **advanced-options** keyword, the configuration sequence includes prompts applicable to the web server that serves requests for the ANM Web Service API. The Web Service API provides SOAP-based programmatic access to the functionality of ANM. By default, it is disabled. You can enable it using this option.

The advanced options settings, along with their defaults, are as follows:

- HTTP Port of Web Services [8080]
- Enable HTTP for Web Services [false]
- HTTPS Port of Web Services [8443]
- Enable HTTPS for Web Services [false]
- Idle session timeout in msec [1800000]—Applies to user sessions for the ANM GUI. Users who are idle for an amount of time greater than this value are automatically logged off the application. By default, this setting is 1800000 milliseconds, or 30 minutes.
- Change the memory available to ANM process [low]—Adjusts amount of available memory for use by ANM. Check the available physical memory; if it is less than 3.5 G, then set the memory size to **low** (1 G), which is the default. If the available physical memory is greater than 3.5 G, set the memory size to **high** (2 G).



Note

To complete the configuration change, the ANM processes must be restarted, which may interfere with active sessions in the ANM web interface.

Examples

```
anm-tmp/admin# anm-tool configure
Configuring ANM
```

```
Checking ANM configuration files
Keep existing ANM configuration? [y/n]: n
Creating config file (/opt/CSCOanm/etc/cs-conf ig.properties)
```

```
Enable HTTP for Web Server [false]:
Inbound Port for HTTP traffic to AIIM Default [80]:
Enable HTTPS for Web Server [false]:
Inbound Port for HTTPS traffic to AIIM Default [443]: 10443

These are the values:
Enable HTTP for Web Server: false
Inbound Port for HTTP traffic to AIIM Default: 8080
Enable HTTPS for Web Server: true
Inbound Port for HTTPS traffic to AIIM Default: 10443

Commit these values? [y/n/q]: y
Committing values ... done
  Keeping existing configuration: /opt/CSCOanm/lib/java/thirdparty/ctm_config.txt

Stopping services
  Stopping monit services (/etc/monit.conf) ... (0)
  Stopping monit ... Stopped
  Stopping heartbeat ... Stopped

Installing system configuration files

Setting service attributes
  Enabling rnysql for SELinux
setsebool: SELinux is disabled.
  Service monit is started by OS at boot time

Starting mysql ... Started
Action detected configure
mysql status ... Ready

Configuring mysql
  Checking mysql user/password
  Setting mysql privileges
  Disabling mysql replication

Starting services
  Starting monit ...Starting monit daemon with http interface at [#:2812]
  Started
```

anm-tool load-inventory

To load the inventory of ANM devices on ANM VA using backup created on an ANM server, use the **anm-tool load-inventory** command.

anm-tool load-inventory disk:filename

Syntax Description	<i>filename</i>	Name of the backup file created on an ANM server.
---------------------------	-----------------	---

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	EXEC
----------------------	------

Examples	anm-tmp/admin# anm-tool load-inventory anmbackup
-----------------	---

anm-tool restart

To restart ANM services, use the **anm-tool restart** command. This command starts the ANM application services only and not those of the underlying operating system.

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-tmp/admin# anm-tool restart

Stopping services
  Stopping monit services (/etc/monit.conf) ... (0)
  Stopping monit ... Stopped
  Stopping heartbeat ... Stopped

Starting services
  Starting monit ...Starting monit daemon with http interface at [#:2812]
  Started
```

application install

This command is not supported by the Cisco ANM Virtual Appliance.

application remove

This command is not supported by the Cisco ANM Virtual Appliance.

application reset-config

To change the ANM admin password and reset the ANM application configuration to factory defaults, use the **application reset-config** command in the EXEC mode.

application reset-config *application-name*

Syntax Description	<i>application-name</i>	Name of the application to reset its configuration to factory defaults; ANM (in all capital letters) in the case of ANM Virtual Appliance.
---------------------------	-------------------------	---

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines This command allows you to reset the settings applicable to the web server component of the ANM application to their default states, as shown in [Table A-3](#).

Table A-3 ANM Web Server Components

Setting	Default
Enable HTTP for Web Server	false
Inbound Port for HTTP traffic to ANM Default	80
Enable HTTPS for Web Server	false
Inbound Port for HTTPS traffic to ANM Default	443
HTTP Port of Web Services	8080
Enable HTTP for Web Services	false
HTTPS Port of Web Services	8443
Enable HTTPS for Web Services	false
Idle session timeout in msec	1800000
Change the memory available to ANM process [low high]	low

Examples

```
anm-va/admin# application reset-config ANM
```

```
This will reset the configuration to default and prompt for the admin password
Proceed? yes/[no] yes
```

```
Enter the ANM admin user password:
Re-enter the ANM admin user password:
```

```
Creating config file (/opt/CSCOanm/etc/cs-config.properties)
Committing default values:
Enable HTTP for Web Server: false
Inbound Port for HTTP traffic to ANM Default: 80
```



```
Enable HTTPS for Web Server: true
Inbound Port for HTTPS traffic to ANM Default: 443
HTTP Port of Web Services: 8080
Enable HTTP for Web Services: false
HTTPS Port of Web Services: 8443
Enable HTTPS for Web Services: false
Idle session timeout in msec: 1800000
done

Stopping services
  Stopping monit services (/etc/monit.conf) ... (0)
  Stopping monit ... Stopped
  Stopping heartbeat ... Stopped

Installing system configuration files

Setting service attributes
  Enabling mysql for SELinux
setsebool: SELinux is disabled.
  Service monit is started by OS at boot time

Starting mysql ... Started
Action detected reset-config
mysql status ... Ready

Configuring mysql
  Checking mysql user/password
  Setting mysql privileges
  Disabling mysql replication

Starting services
  Starting monit ...Starting monit daemon with http interface at [*:2812]
  Started
Applying password changes
.....

Application successfully reset configuration
```

application start

To start the ANM processes, use the **application start** command in the EXEC mode with the **ANM** argument.



Note

ANM is the only application installed on ANM Virtual Appliance and therefore is the only application subject to this command.

application start *application-name*

Syntax Description

<i>application-name</i>	Name of the application that you want to enable; ANM (in all capital letters) in the case of ANM Virtual Appliance.
-------------------------	--

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Use this command to start the ANM application. You can use the **show application status ANM** command to verify that processes have started.

Examples

```
anm-va/admin# application start ANM
```

```
Starting services
```

```
Starting monit ...Starting monit daemon with http interface at [#:2812]
```

```
Started
```

application stop

To stop the ANM application processes, use the **application stop** command in the EXEC mode with the **ANM** argument.



Note

ANM is the only application installed on ANM Virtual Appliance and therefore is the only application subject to this command.

application stop *application-name*

Syntax Description

<i>application-name</i>	Name of the predefined application that you want to disable; ANM (in all capital letters) in the case of ANM Virtual Appliance.
-------------------------	--

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Use this command to stop the ANM application. You can use the **show application status ANM** command to verify that the processes have stopped.

Examples

```
anm-va/admin# application stop ANM

Stopping services
  Stopping monit services (/etc/monit.conf) ... (0)
  Stopping monit ... Stopped
  Stopping heartbeat ... Stopped
```

application upgrade

To upgrade the ANM application software, use the **application upgrade** command in the EXEC mode.

application upgrade *application-bundle remote-repository-name*

Syntax Description		
	<i>application-bundle</i>	Name of the application to be upgraded.
	<i>application-name</i>	Name of the remote repository where the application update bundle is located.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines Use this command to upgrade the application and preserve any configuration data.

Examples `anm-va/admin# application upgrade anmexpress myremoterepository`

backup

To perform a backup of the ANM application and operating system data, use the **backup** command in the EXEC mode. The command generates an archive of the backup and places it in a repository.

backup *backup-name* **repository** *repository-name* [**application** *appl-name*]

Syntax Description	
<i>backup_name</i>	Name of backup file. Enter a maximum of 100 alphanumeric characters.
repository	Repository command.
<i>repository_name</i>	Name of the repository where the files should be backed up to.
application <i>appl_name</i>	(Optional) Specifies that the backup consists of the application data only. For ANM Virtual Appliance, the value for <i>appl_name</i> is ANM.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines Use this command to perform a backup of the ANM configuration and operating system data and place the backup in a repository.

You can use the **show backup history** command to display the backup operations and determine whether they succeeded.

If the backup fails, you may be able to use the **show logging** command to view troubleshooting information.

Examples

```
anm-va/admin# backup mybackup repository myrepository
% Creating backup with timestamped filename: myback2-081007-2129.tar.gpg
```

backup-logs

To back up system logs, use the **backup-logs** command in the EXEC mode. To remove this function, use the **no** form of this command.

backup-logs *backup-name* **repository** *repository-name*

Syntax Description

<i>backup-name</i>	Name of one or more files to back up. Enter a maximum of 100 alphanumeric characters.
repository	Repository command.
<i>repository-name</i>	Location where files should be backed up to. Enter a maximum of 30 alphanumeric characters.

Defaults

Use this command to back up the following files:

- ANM Virtual Appliance log files.
- ANM debug, audit, and diagnostic files.
- Tomcat log files.
- Database log files.

Command Modes

EXEC

Usage Guidelines

Backs up system logs.

Examples

```
anm-va/admin# backup-logs mysyslogs repository myrepository
% Creating log backup with timestamped filename: mysyslogs-100728-1913.tar.gz
```

clock set

To set the system clock, use the **clock set** command in the EXEC mode.

```
clock set month day hh:min:ss yyyy
```

Syntax Description		
<i>month</i>		Current month of the year by name. This can be a maximum of three alphabetic characters. For example, Jan for January.
<i>day</i>		Current day (by date) of the month. Value = 0 to 31. Up to two numbers.
<i>hh:mm:ss</i>		Current time in hours (24-hour format), minutes, and seconds.
<i>yyyy</i>		Current year (no abbreviation).

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines Use this command to set the system clock. You must restart ANM Virtual Appliance for the changes to take effect.

The internal system clock is used for timestamps, scheduled tasks, and other purposes in the system. As a preferred alternative to setting the clock manually with this command, you can configure an NTP server, as described in “[ntp server](#)” section on page A-118.

Examples anm-va/admin# **clock set Jan 4 05:05:05 2010**

configure terminal

To enter the configuration mode, use the **configure** command in the EXEC mode.

configure terminal

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines Use this command to enter the configuration mode. Note that commands in this mode write to the running configuration file as soon as you enter them (press **Enter**).

To exit the configuration mode and return to the EXEC mode, enter **end**, **exit**, or press **Ctrl-z**.

To view the changes that you have made to the configuration, use the **show running-config** command in the EXEC mode.

Examples

```
anm-va/admin# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.
```


copy

To copy any file from a source to a destination, use the **copy** command in the EXEC mode. The **copy** command in ANM copies a running or startup configuration. Some variations of the command syntax are as follows:

```
copy running-configuration {protocol://hostname/location | startup-configuration}
copy startup-configuration {protocol://hostname/location | running-configuration}
copy protocol://hostname/location {running-configuration | startup-configuration}
copy logs protocol://hostname/location
```

Syntax Description

running-config	Specifies the current running configuration file.
startup-config	Specifies the configuration file used during initialization (startup).
<i>protocol</i>	(Optional) The protocol used for the file transfer. The option supported by the ANM VA is ftp. The syntax for this alias is: <code>ftp:[[/username [:password]@]location]/directory/filename</code>
<i>hostname</i>	Hostname of destination.
<i>location</i>	Location of destination.
logs	System log files.

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

The fundamental function of the **copy** command allows you to copy a file (such as a system image or configuration file) from one location to another location. The source and destination for the file can be a local disk location or a remote file location. The file system being used for the remote system dictates the syntax used in the command.

You can enter on the command line all the necessary source and destination information and the username and password to use; or, you can enter the **copy** command and have ANM Virtual Appliance prompt you for any missing information.



Timesaver

Aliases reduce the amount of typing that you need to do. For example, type **copy run start** (the abbreviated form of the **copy running-config startup-config** command).

The entire copying process might take several minutes and differs from protocol to protocol and from network to network.

Use the filename relative to the directory for file transfers.

Descriptions of the running and startup configurations are as follows:

- **Running Configuration**—The ANM active configuration is stored in RAM. Every configuration command you enter resides in the running configuration. If you reboot your ANM Virtual Appliance, you lose the configuration. If you make changes that you want to save, you must copy the running configuration to a safe location, such as a network server, or save it as the startup configuration.
- **Startup Configuration**—You cannot edit a startup configuration directly. All commands that you enter store themselves in the running configuration, which you can copy into the startup configuration.

In other words, when you boot an ANM Virtual Appliance, the startup configuration becomes the initial running configuration. As you modify the configuration, the two diverge:

- The startup configuration remains the same.
- The running configuration reflects the changes that you have made.

If you want to make your changes permanent, you must copy the running configuration to the startup configuration.

The following command lines show some of the **copy** command scenarios available:

- **copy running-configuration startup-configuration**

Copies the running configuration to the startup configuration. Replaces the startup-configuration with the running configuration.



Note If you do not save the running configuration, you will lose all your configuration changes during the next reboot of ANM Virtual Appliance. Once you are satisfied that the current configuration is correct, copy your configuration to the startup configuration with the preceding command.

- **copy startup-configuration running-configuration**

Copies the startup configuration to the running configuration. Merges the startup configuration on top of the running configuration.

- **copy protocol://hostname/location startup-configuration**

Copies but does not merge a remote file to the startup configuration.

- **copy protocol://hostname/location running-configuration**

Copies and merges a remote file to the running configuration.

- **copy startup-configuration protocol://hostname/location**

Copies the startup configuration to a remote system.

- **copy running-configuration protocol://hostname/location**

Copies the running configuration to a remote system.

- **copy logs protocol://hostname/location**

Copies log files from the system to another location.



Note The **copy** command is supported only for the local disk and not for a repository.

Examples**Example 1**

```
anm-va/admin# copy run start  
Generating configuration...
```

debug

To display verbose output for command operation, use the **debug** command in the EXEC mode. Debug mode produces extensive error and event information to the output screen, and can be useful for troubleshooting issues.

debug { **all** | **application** | **backup-restore** | **cdp** | **config** | **icmp** | **copy** | **locks** | **logging** | **snmp** | **system** | **transfer** | **user** | **utils** }

Syntax Description

all	Enables all debugging.
application	Specifies application files. <ul style="list-style-type: none"> • <i>all</i>—Enables all application debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>install</i>—Enables application install debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>operation</i>—Enables application operation debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>uninstall</i>—Enables application uninstall debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.
backup-restore	Specifies backs up and restores files. <ul style="list-style-type: none"> • <i>all</i>—Enables all debug output for backup-restore. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>backup</i>—Enables backup debug output for backup-restore. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>backup-logs</i>—Enables backup-logs debug output for backup-restore. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>history</i>—Enables history debug output for backup-restore. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>restore</i>—Enables restore debug output for backup-restore. Set the level between 0 and 7 with 0 as severe and 7 as all.
cdp	Specifies CDP configuration files. <ul style="list-style-type: none"> • <i>all</i>—Enables all CDP configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>config</i>—Enables configuration debug output for CDP. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>infra</i>—Enables infrastructure debug output for CDP. Set the level between 0 and 7 with 0 as severe and 7 as all.

config	<p>Specifies configuration files.</p> <ul style="list-style-type: none"> • <i>all</i>—Enables all configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>backup</i>—Enables backup configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>clock</i>—Enables clock configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>infra</i>—Enables configuration infrastructure debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>kron</i>—Enables command scheduler configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>network</i>—Enables network configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>repository</i>—Enables repository configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>service</i>—Enables service configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.
copy	<p>Specifies copy commands. Set level between 0 and 7 with 0 as severe and 7 as all.</p>
icmp	<p>Specifies ICMP echo response configuration.</p> <p><i>all</i>—Enables all logging configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.</p>
locks	<p>Specifies resource locking.</p> <ul style="list-style-type: none"> • <i>all</i>—Enables all resource locking debug output. Set the level between 0 and 7 with 0 being as and 7 as all. • <i>file</i>—Enables file locking debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.
logging	<p>Specifies logging configuration files.</p> <p><i>all</i>—Enables all logging configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.</p>
snmp	<p>Specifies SNMP configuration files.</p> <p><i>all</i>—Enables all SNMP configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.</p>
system	<p>Specifies system files.</p> <ul style="list-style-type: none"> • <i>all</i>—Enables all system files debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>id</i>—Enables system ID debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>info</i>—Enables system info debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. • <i>init</i>—Enables system init debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.
transfer	<p>Specifies file transfer. Set level between 0 and 7 with 0 as severe and 7 as all.</p>

user	Specifies user management. <ul style="list-style-type: none"> <i>all</i>—Enables all user management debug output. Set the level between 0 and 7 with 0 as severe and 7 as all. <i>password-policy</i>—Enables user management debug output for password-policy. Set the level between 0 and 7 with 0 as severe and 7 as all.
utils	Specifies utilities configuration files. <p><i>all</i>—Enables all utilities configuration debug output. Set the level between 0 and 7 with 0 as severe and 7 as all.</p>

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Use the **debug** command to identify various failures within ANM Virtual Appliance; for example, setup failures or configuration failures.

Examples

```
anm-va/admin# debug all
anm-va/admin# mkdir disk:/1
anm-va/admin# 6 [7178]: utils: vsh_root_stubs.c[2301]: mkdir operation success

anm-va/admin# rmdir disk:/1
anm-va/admin# 6 [7180]: utils: vsh_root_stubs.c[2171]: Invoked Remove Directory disk:/1
command 6 [7180]: utils: vsh_root_stubs.c[2228]: Remove Directory operation success

anm-va/admin# undebug all
anmvw-test8/admin# 7 [2826]: cdp:infra: ether-write.c[87]: WriteEther(): wrote len: 192
7 [2826]: cdp:infra: ether-write.c[112]: cdpd write succeed...
7 [2826]: cdp:infra: main.c[128]:
Writing with retransmissiontime 60...
```

delete

To delete a file from ANM Virtual Appliance, use the **delete** command in the EXEC mode.

```
delete disk:[/path/]filename
```

Syntax Description	<i>path</i>	(Optional) Path to the file.
	<i>filename</i>	Name of the file to delete. Enter a maximum of 80 alphanumeric characters.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines If you attempt to delete the configuration file or image, the system prompts you to confirm the deletion. Also, if you attempt to delete the last valid system image, the system prompts you to confirm the deletion.

Examples anm-va/admin# **delete myfile**

dir

To list files or directory contents on the ANM Virtual Appliance disk, use the **dir** command in the EXEC mode.

dir [*word*] [**recursive**]

Syntax Description	<i>word</i>	(Optional) Directory name. This can be a maximum of 80 alphanumeric characters. Requires disk:/ preceding the directory name.
	recursive	(Optional) Lists a local directory or filename recursively.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines The user-accessible disk space on the virtual appliance is referred to as *disk*: from the CLI. You can use this disk space for temporary storage of files generated from backups or for licenses, for example. In addition to printing the directory contents, you can use the `mkdir` and `rmdir` to make and remove directories.

Examples

Example 1

```
anm-va/admin# dir
```

```
Directory of disk:/
```

```
16384 Jul 02 2010 08:34:49 lost+found/
4096 Jul 16 2010 02:10:20 mytest/
4096 Jul 11 2010 09:12:12 save-config/
```

```
Usage for disk: filesystem
49741824 bytes total used
6815842304 bytes free
7233003520 bytes available
```

Example 2

```
anm-va/admin# dir disk:/mytest
```

```
Directory of disk:/mytest
```

```
Usage for disk: filesystem
49741824 bytes total used
6815842304 bytes free
7233003520 bytes available
```


Example 3

```
anm-va/admin# dir recursive

Directory of disk:/

   4096 Jul 16 2010 02:10:20 mytest/
  16384 Jul  2 2010 08:34:49 lost+found/
   4096 Jul 11 2010 09:12:12 save-config/

Directory of disk:/mytest

No files in directory

Directory of disk:/lost+found

No files in directory

Directory of disk:/save-config

   555 Jul 11 2010 09:12:12 running-config

Usage for disk: filesystem
      49741824 bytes total used
      6815842304 bytes free
      7233003520 bytes available
```

exit

To close an active terminal session by logging out of ANM Virtual Appliance or to move up one mode level from the configuration mode, use the **exit** command in the EXEC mode.

exit

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines Use the **exit** command in EXEC mode to exit an active session (log out of ANM Virtual Appliance) or to move up from the Configuration mode.

Examples `anm-va/admin(config) # exit`

forceout

To force users out of an active terminal session by logging them out of the command line environment, use the **forceout** command in the EXEC mode.

forceout *username*

Syntax Description	<i>username</i>	Name of the user. Enter a maximum of 31 alphanumeric characters.
---------------------------	-----------------	--

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	EXEC
----------------------	------

Usage Guidelines	Use the forceout command in EXEC mode to force a user from an active session.
-------------------------	--

Examples	<code>anm-va/admin# forceout user1</code>
-----------------	---

halt

To shut down the system, use the **halt** command in EXEC mode.

halt

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines This command turns off the ANM application as well as the host operating system. It is an alternative to shutting down the virtual appliance from the vSphere Client.

Before you run the **halt** command, ensure that ANM Virtual Appliance is not performing any backup, restore, installation, upgrade, or remove operation. If you run the halt command while ANM is performing any of these operations, you will get a warning message such as the following:

```
WARNING: A backup or restore is currently in progress! Continue with halt?
```

If you get any of these warnings, enter **YES** to halt the operation, or enter **NO** to cancel the halt.

If no processes are running when you use the **halt** command or you enter **YES** in response to the warning message displayed, ANM Virtual Appliance asks you to respond to the following option:

```
Do you want to save the current configuration ?
```

Enter **YES** to save the existing configuration. The following message is displayed:

```
Saved the running configuration to startup successfully
```



Note

To shut down the ANM processes only, leaving the operating system active, use the **application stop ANM** command.

Examples `anm-va/admin# halt`

help

To describe the interactive help system for ANM Virtual Appliance, use the **help** command in the EXEC mode.

help

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC
All configuration modes

Usage Guidelines The **help** command provides a brief description of the context-sensitive help system and allows you to do the following:

- List all commands available for a particular command mode, enter a question mark (?) at the system prompt.
- Obtain a list of commands that begin with a particular character string, enter the abbreviated command entry immediately followed by a question mark (?). This form of help is called word help, because it lists only the keywords or arguments that begin with the abbreviation that you entered.
- List the keywords and arguments associated with a command, enter a question mark (?) in place of a keyword or argument on the command line. This form of help is called command syntax help, because it lists the keywords or arguments that apply based on the command, keywords, and arguments that you have already entered.

Examples

```
anm-va/admin# help
```

Help may be requested at any point in a command by entering a question mark '?'. If nothing matches, the help list will be empty and you must backup until entering a '?' shows the available options.

Two styles of help are provided:

1. Full help is available when you are ready to enter a command argument (e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (e.g. 'show pr?').

mkdir

To create a new directory on ANM Virtual Appliance, use the **mkdir** command in the EXEC mode.

```
mkdir disk:/path
```

Syntax Description	disk:/path	Name of the directory or directories to create. This can be a maximum of 80 alphanumeric characters.
---------------------------	-------------------	--

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	EXEC
----------------------	------

Usage Guidelines	Use <i>disk:/path</i> with the directory name; otherwise, an error indicating that the <i>disk:/path</i> must be included appears. If you list multiple directories in the path, all the directories are created.
-------------------------	---

Examples	This example shows how to create a single directory:
-----------------	--

```
anm-va/admin# mkdir disk:/test/
anm-va/admin# dir
```

```
Directory of disk:/
```

```
 16384 Jun 28 2007 00:09:50 lost+found/
  4096 Jun 28 2007 14:34:27 test/
```

```
Usage for disk: filesystem
      88150016 bytes total used
 44585803776 bytes free
 47064707072 bytes available
```

The following example shows how to create multiple directories:

```
anm-va/admin# mkdir disk:/path/subpath/subsubpath
anm-va/admin# dir recursive
```

```
Directory of disk:/
```

```
209931008 Aug 24 2010 23:34:43 anm-cars-appbundle-5.1.tar.gz
    0 Aug 24 2010 21:04:57 ANM20100726172319309.lic
   383 Aug 18 2010 21:31:03 ANMDEMO20100818142602125.lic
  4096 Aug 25 2010 18:16:16 path/
  4096 Aug 25 2010 18:10:10 aa/
 16384 Aug 18 2010 13:52:39 lost+found/
```

```
Directory of disk:/path
```

```
  4096 Aug 25 2010 18:16:48 subpath/
```

```
Directory of disk:/path/subpath
```

```
4096 Aug 25 2010 18:16:48 subsubpath/
Directory of disk:/path/subpath/subsubpath
No files in directory
Directory of disk:/aa
No files in directory
Directory of disk:/lost+found
No files in directory
Usage for disk: filesystem
  356769792 bytes total used
  540755584 bytes free
  6078058496 bytes available
```

nslookup

To look up the hostname of a remote system ANM Virtual Appliance, use the **nslookup** command in the EXEC mode.

nslookup *word*

Syntax Description

<i>word</i>	IPv4 address or hostname of a remote system. Enter a maximum of 64 alphanumeric characters.
-------------	---

Defaults

No default behavior or values.

Command Modes

EXEC

Examples

Example 1

```
anm-va/admin# nslookup 1.2.3.4
Trying "4.3.2.1.in-addr.arpa"
Host 4.3.2.1.in-addr.arpa not found: 3(NXDOMAIN) Received 105 bytes from
209.165.200.225#53 in 5 ms
```

Example 2

```
anm-va/admin# nslookup 209.165.200.225
Trying "225.200.165.209.in-addr.arpa"
;; ->HEADER<<- opcode: QUERY, status: NOERROR, id: 15007 ;; flags: qr aa rd ra; QUERY: 1,
ANSWER: 1, AUTHORITY: 2, ADDITIONAL: 2

;; QUESTION SECTION:
;225.200.165.209.in-addr.arpa.      IN      PTR

;; ANSWER SECTION:
225.200.165.209.in-addr.arpa. 86400 IN      PTR      ANM.cisco.com.

;; AUTHORITY SECTION:
165.209.in-addr.arpa.      86400 IN      NS       ns2.cisco.com.
165.209.in-addr.arpa.      86400 IN      NS       ns1.cisco.com.

;; ADDITIONAL SECTION:
ns1.cisco.com.             86400 IN      A        209.165.200.225
ns2.cisco.com.             86400 IN      A        209.165.200.225

Received 146 bytes from 172.69.2.133#53 in 5 ms
```


patch install

To install a patch bundle on ANM Virtual Appliance, use the **patch install** command.

```
patch install patch-bundle-filename remote-repository-name
```

Syntax Description	
<i>patchfile</i>	Name of the file that contains the software patch.
<i>remote-repository-name</i>	Name of the remote repository that contains the patch file.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines A software patch provides a mechanism for modifying the ANM or ADE OS software in place, without having to redeploy the virtual machine.

With the **patch install** command, the patch file is retrieved from a remote repository. For more information on repositories, see the [repository](#) command.

Examples

Example 1: Successful Patch

```
anm-va/admin# patch install TestPatch.tar.gz test-repository
Do you want to save the current configuration? (yes/no) [yes] ?
Generating configuration...
Saved the running configuration to startup successfully
Patch successfully installed
```

Example 2: Unsuccessful Patch

```
anm-va/admin# patch install TestPatch.tar.gz test-repository
Do you want to save the current configuration? (yes/no) [yes] ?
Generating configuration...
Saved the running configuration to startup successfully
% Package not installed, patching disallowed.
```

ping

To diagnose basic network connectivity to a remote system, use the **ping** command in the EXEC mode.

```
ping ip-address | hostname [df df] [packetsize packetsize] [pingcount pingcount]
```

Syntax Description		
<i>ip-address</i>		IP address of the system to ping. Enter a maximum of 32 alphanumeric characters.
<i>hostname</i>		Hostname of the system to ping. Enter a maximum of 32 alphanumeric characters.
df		(Optional) Specifies packet fragmentation.
<i>df</i>		DF setting. Enter 1 to prohibit packet fragmentation, 2 to fragment the packets locally, or 3 to not set DF.
packetsize		(Optional) Specifies the size of the ping packet.
<i>packetsize</i>		Size of the ping packet; the value can be between 0 and 65507.
pingcount		(Optional) Specifies the number of ping echo requests.
<i>pingcount</i>		Number of ping echo requests; enter a value between 1 and 10.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines The **ping** command sends an echo request packet to an address, then awaits a reply. The ping output can help you evaluate path-to-host reliability, delays over the path, and whether you can reach a host.

Examples

```
anm-va/admin# ping 172.16.0.1 df 2 packetsize 10 pingcount 2
PING 172.16.0.1 (172.16.0.1) 10(38) bytes of data.
18 bytes from 172.16.0.1: icmp_seq=0 ttl=40 time=306 ms
18 bytes from 172.16.0.1: icmp_seq=1 ttl=40 time=300 ms

--- 172.16.0.1 ping statistics ---
2 packets transmitted, 2 received, 0% packet loss, time 1001ms
rtt min/avg/max/mdev = 300.302/303.557/306.812/3.255 ms, pipe 2
```

reload

To stop and restart the ANM operating system, use the **reload** command in the EXEC mode.

reload

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines The **reload** command stops and restarts the system. Before you run the **reload** command, ensure that ANM is not performing any backup, restore, installation, upgrade, or remove operation. If ANM performs any of these operations and you try to run the **reload** command, you will see any of the following warning messages:

```
WARNING: A backup or restore is currently in progress! Continue with reload?
```

```
WARNING: An install/upgrade/remove is currently in progress! Continue with reload?
```

If you get any of these warnings, enter **YES** to halt the operation, or enter **NO** to cancel the halt.

If no processes are running when you use the **reload** command or you enter **YES** in response to the warning message displayed, ANM asks you to respond to the following option:

```
Do you want to save the current configuration ?
```

Enter **YES** to save the existing ANM Virtual Appliance configuration. ANM displays the following message:

```
Saved the running configuration to startup successfully
```

Examples

```
anm-va/admin# reload  
Continue with reboot? [y/n] y
```

```
Broadcast message from root (pts/0) (Tue Oct 7 23:01:46 2008):
```

```
The system is going down for reboot NOW!
```

restore

To perform a restore of a previous backup, use the **restore** command in the EXEC mode. A restore operation restores data related to ANM Virtual Appliance as well as the ADE OS.

restore *filename* **repository** *repository-name*

Syntax Description	<i>filename</i>	Name of the backed-up file that resides in the repository. Enter a maximum of 120 alphanumeric characters.
	Note	You must add the .tar.gpg extension after the filename (for example, myfile.tar.gpg).
	repository <i>repository-name</i>	Specifies the name of the repository you want to restore from backup.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines When you use this command, ANM Virtual Appliance restarts automatically.

Examples `anm-va/admin# restore backup1.tar.gpg repository repository1`

rmdir

To remove an existing directory, use the **rmdir** command in the EXEC mode.

rmdir *word*

Syntax Description	<i>word</i>	Directory name. Enter a maximum of 80 alphanumeric characters.
--------------------	-------------	--

Defaults	No default behavior or values.
----------	--------------------------------

Command Modes	EXEC
---------------	------

Examples	<pre> anm-va/admin# mkdir disk:/test/ anm-va/admin# dir Directory of disk:/ 16384 Jun 28 2007 00:09:50 lost+found/ 4096 Jun 28 2007 14:34:27 test/ Usage for disk: filesystem 88150016 bytes total used 44585803776 bytes free 47064707072 bytes available CAM/admin# anm-va/admin# rmdir disk:/test anm-va/admin# dir Directory of disk:/ 16384 Jun 28 2007 00:09:50 lost+found/ Usage for disk: filesystem 88145920 bytes total used 44585807872 bytes free 47064707072 bytes available CAM/admin# </pre>
----------	---

show

To show the running system information, use the **show** command in the EXEC mode..

```
show keyword [| >]
```

Syntax Description	keyword	Item to display (see Table A-4 in Usage Guidelines).
		Command output modifiers (for details, see the “ Information About Command Output Modifiers ” section on page A-5).
	>	

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines For detailed information on all the **show** commands, see the “[Show Commands](#)” section on page A-60. All **show** commands require at least one keyword to function. The keyword argument represents the item to display as described in [Table A-4](#).

Table A-4 Summary of Show Commands

Command	Description
application	Status or version information for the installed ANM application.
backup history	Information about the backup operations performed on this virtual appliance.
cdp	Information related to Cisco Discovery Protocol (CDP) for the appliance’s interfaces or network neighbors.
clock	Day, date, time, time zone, and year of the system clock.
cpu	CPU information.
disks	File-system information of the disks.
icmp_status	ICMP echo response configuration information.
interface	Statistics for all the interfaces configured on the ADE OS.
inventory	Hardware inventory information.
ip	IP routing table information on the virtual appliance.
logging	System logging information.
logins	Login history.
memory	Memory usage by all running processes.
ntp	Status of the Network Time Protocol (NTP).
ports	Processes listening on the active ports.
process	Information about the active processes of ANM Virtual Appliance.
repository	File contents of a specific repository.

Table A-4 Summary of Show Commands (continued)

Command	Description
restore	Restore history on ANM Virtual Appliance.
running-config	Contents of the currently running configuration file on ANM Virtual Appliance.
startup-config	Contents of the startup configuration on ANM Virtual Appliance.
tech-support	System and configuration information that you can provide to the Cisco Technical Assistance Center (TAC) when reporting a problem.
terminal	Information about the terminal configuration parameter settings for the current terminal line.
timezone	Time zone of ANM Virtual Appliance.
timezones	Time zones available for use on ANM Virtual Appliance.
udi	Information about the system's Unique Device Identifier (UDI).
uptime	Length of time the system you are logged in to has been up and running.
users	Information for currently logged in users.
version	Version information for the ADE OS and ANM software.

Defaults

No default behavior or values.

Command Modes

EXEC

Usage GuidelinesAll **show** commands require at least one keyword to function.**Examples**

```
anm-va/admin# show application
<name>           <Description>
ANM               Cisco ANM
```

ssh

To start an encrypted session with a remote system, use the **ssh** command in the EXEC mode.



Note

An Admin or Operator (user) can use this command.

```
ssh {ip-address | hostname} username [port number] [version {1 | 2}]
```

```
ssh delete hostkey word
```

Syntax Description

<i>ip-address</i>	IP address of the remote system. Enter a maximum of 64 alphanumeric characters.
<i>hostname</i>	Hostname of the remote system. Enter a maximum of 64 alphanumeric characters.
<i>username</i>	Username of the user logging in through SSH.
port [<i>number</i>]	(Optional) Indicates the port number of the remote host. Enter a value from 0 to 65,535. Default is 22.
version {1 2}	(Optional) Indicates the version number. Default is 2.
delete hostkey	Deletes the SSH fingerprint of a specific host.
<i>word</i>	IPv4 address or hostname of a remote system. Enter a maximum of 64 alphanumeric characters.

Defaults

Disabled.

Command Modes

EXEC (Admin or Operator)

Usage Guidelines

The **ssh** command enables a system to make a secure, encrypted connection to another remote system or server. This connection provides functionality similar to that of an outbound Telnet connection except that the connection is encrypted. With authentication and encryption, the SSH client allows for secure communication over an insecure network.

Examples

Example 1

```
anm-va/admin# ssh delete hostkey mtm-sun8
```

Example 2

```
anm-va/admin# ssh anm2 admin
admin@anm2's password:
Last login: Wed Jul 11 05:53:20 2008 from ANM.cisco.com

anm2/admin#
```


tech dumptcp

To dump a Transmission Control Protocol (TCP) package to the console, use the **tech dumptcp** command in the EXEC mode.

tech dumptcp *gigabit-ethernet*

Syntax Description	<i>gigabit-ethernet</i> Gigabit Ethernet interface number 0 or 1.
Defaults	Disabled.
Command Modes	EXEC
Examples	<pre> anm-va/admin# tech dumptcp 0 140816:141088(272) ack 1921 win 14144 08:26:12.034630 IP ANM.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141088:141248(160) ack 1921 win 14144 08:26:12.034635 IP dhcp-64-102-82-153.cisco.com.2221 > ANM.cisco.com.ssh: . ack 139632 win 64656 08:26:12.034677 IP ANM.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141248:141520(272) ack 1921 win 14144 08:26:12.034713 IP ANM.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141520:141680(160) ack 1921 win 14144 08:26:12.034754 IP ANM.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141680:141952(272) ack 1921 win 14144 08:26:12.034756 IP dhcp-64-102-82-153.cisco.com.2221 > ANM.cisco.com.ssh: . ack 140064 win 65520 08:26:12.034796 IP ANM.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141952:142112(160) ack 1921 win 14144 1000 packets captured 1000 packets received by filter 0 packets dropped by kernel </pre>

telnet

To log in to a host that supports Telnet, use the **telnet** command in Operator (user) or EXEC mode.

```
telnet {ip-address | hostname} [port number]
```

Syntax Description		
	<i>ip-address</i>	IP address of the remote system.
	<i>hostname</i>	Hostname of the remote system. Enter a maximum of 64 alphanumeric characters.
	port number	(Optional) Indicates the port number of the remote host. Enter a value from 0 to 65535.

Defaults No default behavior or values.

Command Modes Operator
EXEC

Examples

```
anm-va/admin# telnet 172.16.0.11 port 23
ANM.cisco.com login: admin
password:
Last login: Mon Jul  2 08:45:24 on ttyS0
```

terminal length

To set the number of lines on the current terminal screen for the current session, use the **terminal length** command in the EXEC mode.

terminal length *integer*

Syntax Description	<i>integer</i>	Number of lines on the screen. Contains between 0 to 511 lines, inclusive. Zero (0) disables pausing between screens of output.
Defaults	24 lines	
Command Modes	EXEC	
Usage Guidelines	The system uses the length value to determine when to pause during multiple-screen output.	
Examples	anm-va/admin# terminal length 0	

terminal session-timeout

To set the inactivity timeout for all sessions, use the **terminal session-timeout** command in the EXEC mode.

terminal session-timeout *minutes*

Syntax Description	<i>minutes</i>	Number of minutes for the inactivity timeout. Enter a value from 0 to 525,600. Zero (0) disables the timeout.
---------------------------	----------------	---

Defaults	30 minutes
-----------------	------------

Command Modes	EXEC
----------------------	------

Usage Guidelines	Setting the terminal session-timeout command to zero (0) results in no timeout being set.
-------------------------	--

Examples	<code>anm-va/admin# terminal session-timeout 40</code>
-----------------	--

terminal session-welcome

To set a welcome message on the system for all users who log in to the system, use the **terminal session-welcome** command in EXEC mode.

terminal session-welcome *string*

Syntax Description	<i>string</i>	Welcome message. Enter a maximum of 2,048 alphanumeric characters.
---------------------------	---------------	--

Defaults	No default behavior or values.	
-----------------	--------------------------------	--

Command Modes	EXEC	
----------------------	------	--

Usage Guidelines	Specify a message using up to 2,048 characters.	
-------------------------	---	--

Examples	anm-va/admin# terminal session-welcome Welcome	
-----------------	---	--

terminal terminal-type

To specify the type of terminal connected to the current line for the current session, use the **terminal terminal-type** command in EXEC mode.

terminal terminal-type *type*

Syntax Description	<i>type</i>	Terminal name and type that permits terminal negotiation by hosts that provide that type of service. Enter a maximum of 80 alphanumeric characters.
---------------------------	-------------	---

Defaults	VT100
-----------------	-------

Command Modes	EXEC
----------------------	------

Usage Guidelines	Indicate the terminal type if it is different from the default of VT100.
-------------------------	--

Examples	anm-va/admin# terminal terminal-type vt220
-----------------	---

traceroute

To discover the routes that packets take when traveling to their destination address, use the **traceroute** command in EXEC mode.

```
traceroute { ip-address | hostname }
```

Syntax Description

<i>ip-address</i>	IP address of the remote system.
<i>hostname</i>	Hostname of the remote system. Enter a maximum of 32 alphanumeric characters.

Defaults

No default behavior or values.

Command Modes

EXEC

Examples

```
anm-va/admin# traceroute 172.16.0.1
traceroute to 172.16.0.1 (172.16.0.1), 30 hops max, 38 byte packets
 1 172.16.0.1 0.067 ms  0.036 ms  0.032 ms
```

undebug

To disable debugging functions, use the **undebug** command in EXEC mode.

```
undebug { all | application | backup-restore | cdp | config | copy | locks | logging | snmp | system
| transfer | user | utils } level
```

Syntax Description

all	Disables all debugging.
application	Specifies application files: <ul style="list-style-type: none"> • <i>all</i>—Disables all application debug output. • <i>install</i>—Disables application install debug output. • <i>operation</i>—Disables application operation debug output. • <i>uninstall</i>—Disables application uninstall debug output.
backup-restore	Specifies backs up and restores files: <ul style="list-style-type: none"> • <i>all</i>—Disables all debug output for backup-restore. • <i>backup</i>—Disables backup debug output for backup-restore. • <i>backup-logs</i>—Disables backup-logs debug output for backup-restore. • <i>history</i>—Disables history debug output for backup-restore. • <i>restore</i>—Disables restore debug output for backup-restore.
cdp	Specifies CDP configuration files: <ul style="list-style-type: none"> • <i>all</i>—Disables all CDP configuration debug output. • <i>config</i>—Disables configuration debug output for CDP. • <i>infra</i>—Disables infrastructure debug output for CDP.
config	Specifies configuration files: <ul style="list-style-type: none"> • <i>all</i>—Disables all configuration debug output. • <i>backup</i>—Disables backup configuration debug output. • <i>clock</i>—Disables clock configuration debug output. • <i>infra</i>—Disables configuration infrastructure debug output. • <i>kron</i>—Disables command scheduler configuration debug output. • <i>network</i>—Disables network configuration debug output. • <i>repository</i>—Disables repository configuration debug output. • <i>service</i>—Disables service configuration debug output.
copy	Specifies copy commands.
locks	Specifies resource locking: <ul style="list-style-type: none"> • <i>all</i>—Disables all resource locking debug output. • <i>file</i>—Disables file locking debug output.
logging	Specifies logging configuration files. <p><i>all</i>—Disables all debug output for logging configuration.</p>

snmp	Specifies SNMP configuration files. <i>all</i> —Disables all debug output for SNMP configuration.
system	Specifies system files: <ul style="list-style-type: none"> • <i>all</i>—Disables all system files debug output. • <i>id</i>—Disables system ID debug output. • <i>info</i>—Disables system info debug output. • <i>init</i>—Disables system init debug output.
transfer	Specifies file transfer.
user	Specifies user management: <ul style="list-style-type: none"> • <i>all</i>—Disables all user management debug output. • <i>password-policy</i>—Disables user management debug output for password-policy.
utils	Specifies utilities configuration files. <i>all</i> —Disables all utilities configuration debug output.
<i>level</i>	Specifies the priority level at which you set the undebug output. Set the level between 0 and 7 with 0 as severe and 7 as all.

Defaults

No default behavior or values.

Command Modes

EXEC

Examplesanm-va/admin# **undebug a11**

write

To copy, display, or erase ANM Virtual Appliance configurations, use the **write** command with the appropriate argument in the EXEC mode.

write {erase | memory | terminal}

Syntax Description		
erase	Erases the startup-configuration.	
memory	Copies running-configuration to startup-configuration.	
terminal	Copies the running-configuration to console.	

Defaults No default behavior or values.

Command Modes EXEC

Examples

Example 1

```
anm-va/admin# write memory
Generating configuration...
anm-va/admin#
```

Example 2

```
anm-va/admin# write terminal
Generating configuration...
!
hostname ANM
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
 ip address 209.165.200.225 255.255.255.224
!
interface GigabitEthernet 1
 shutdown
!
ip name-server 209.165.201.1
!
ip default-gateway 209.165.202.129
!
clock timezone UTC
!
username admin password hash $1$UMCQIJy1$8Z.9tkp01QzCo4zyc1jso0 role admin
!
service sshd
!
password-policy
 lower-case-required
 upper-case-required
 digit-required
 no-username
 disable-cisco-passwords
```

```
    min-password-length 6
    !
logging localhost
logging loglevel 6
!
anm-va/admin#
```

Show Commands

Each **show** command includes a brief description of its use, command syntax, usage guidelines, and sample output.

[Table A-5](#) lists the **show** commands in the EXEC mode that this section describes.

Table A-5 *List of EXEC show Commands*

• show application	• show ports
• show backup history	• show process
• show cdp	• show repository
• show clock	• show restore history
• show cpu	• show running-configuration
• show disks	• show startup-configuration
• show icmp-status	• show tech-support
• show interface	• show terminal
• show inventory	• show timezone
• show ip route	• show timezones
• show logging	• show udi
• show logins cli	• show uptime
• show memory	• show users
• show ntp	• show version



Note

The show commands include the vertical bar (|) and angle bracket (>) options for modifying the command output. For more information about these command modifiers, see the [“Information About Command Output Modifiers”](#) section on page A-5.

show application

To show application information of the installed application packages on the system, use the **show application** command in the EXEC mode.

```
show application [status | version app_name]
```

Syntax Description	
status	(Optional) Displays the status of the services of the ANM application.
version	(Optional) Displays the ANM application version.
<i>app_name</i>	(Optional) Name of the installed application. For ANM Virtual Appliance, this value must be ANM .

Defaults No default behavior or values.

Command Modes EXEC

Examples

Example 1

```
anm-va/admin# show application
<name>           <Description>
ANM               Cisco ANM
anm-va/admin#
```

Example 2

```
anm-va/admin# show application version ANM

5.1 (0)

anm-va/admin#
```

Example 3

```
anm-va/admin# show application status ANM

The monit daemon 4.9 uptime: 51m

Process 'dcm'           running
Process 'dal'           running
Process 'ip-disc'       running
Process 'licman'        running
Process 'anm-fw-mon'    running
Process 'mysql'         running
System 'anm-hostname'   running

Java Processes:
licman      : Running (3487) [2010-07-27 18:34:21]
dcm         : Running (3492) [2010-07-27 18:34:21]
dal         : Running (3496) [2010-07-27 18:34:21]
ip-disc     : Running (3494) [2010-07-27 18:34:21]
```

Other Processes:

```
anm-fw-mon   : Running (3456) [2010-07-27 18:34:21]
mysql        : Running (3701) [2010-07-27 18:34:25]
```

```
anm-va/admin#
```

show backup history

To display the backup history of the system, use the **show backup history** command in the EXEC mode.

show backup history

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

Example 1

```
anm-va/admin# show backup history
Wed Jul 18 12:55:21 UTC 2010: backup logs logs-0718.tar.gz to repository fileserver007:
success
Wed Jul 18 12:55:53 UTC 2010: backup full-0718.tar.gpg to repository fileserver007:
success
```

Example 2

```
anm-va/admin# show backup history
backup history is empty
```

show cdp

To display information about the enabled CDP interfaces, use the **show cdp** command in the EXEC mode.

```
show cdp {all | neighbors}
```

Syntax Description	all	Displays enabled CDP interfaces.
	neighbors	Displays CDP neighbors.

Defaults No default behavior or values.

Command Modes EXEC

Examples

Example 1

```
anm-va/admin# show cdp all
```

```
CDP protocol is enabled ...
    broadcasting interval is every 60 seconds.
    time-to-live of cdp packets is 180 seconds.

    CDP is enabled on port GigabitEthernet0.
```

Example 2

```
anm-va/admin# show cdp neighbors
```

```
CDP Neighbor : anm-test2
    Local Interface   : GigabitEthernet0
    Device Type       : cisco WS-C3560G-48PS
    Port              : GigabitEthernet0/36
    Address            : 209.165.200.225
```


show clock

To display the day, month, date, time, time zone, and year of the system software clock, use the **show clock** command in the EXEC mode.

show clock

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show clock
Tue Oct 7 20:13:22 UTC 2008
```



Note The **show clock** output in the example includes Coordinated Universal Time (UTC) or Greenwich Mean Time (GMT), Great Britain, or Zulu time (see Tables [A-9](#), [A-10](#), and [A-11](#) on pages A-94 and A-95 for sample time zones).

show cpu

To display CPU information, use the **show cpu** command in the EXEC mode.

```
show cpu [statistics]
```

Syntax Description	statistics (Optional) Displays CPU statistics.
---------------------------	---

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	EXEC
----------------------	------

Examples

Example 1

```
anm-va/admin# show cpu
processor : 0
model    : Intel(R) Core(TM)2 CPU          6400 @ 2.13GHz
speed(MHz): 2133.737
cache size: 2048 KB

processor : 1
model    : Intel(R) Core(TM)2 CPU          6400 @ 2.13GHz
speed(MHz): 2133.737
cache size: 2048 KB
```

Example 2

```
anm-va/admin# show cpu statistics
user time:           8312
kernel time:        3200
idle time:          15510748
i/o wait time:      5295
irq time:           972
```

show disks

To display file-system information about the disks, use the **show disks** command in the EXEC mode.

show disks

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines Only platforms that have a disk file system support the **show disks** command.

Examples

```
anm-va/admin# show disks
disk: 1% used (48564 of 7063480)
temp. space 2% used (35844 of 2031952)

Internal filesystems:
  all internal filesystems have sufficient free space
```

show icmp-status

To display file-system information about the disks, use the **show icmp-status** command in EXEC mode.

```
show icmp_status
```

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

Example 1

```
anm-va/admin# show icmp_status  
icmp echo response is turned on
```

Example 2

```
anm-va/admin# show icmp_status  
icmp echo response is turned off
```

show interface

To display the usability status of interfaces configured for IP, use the **show interface** command in the EXEC mode.

```
show interface [GigabitEthernet {0 | 1}]
```

Syntax Description	GigabitEthernet (Optional) Displays the Gigabit Ethernet interface. Either 0 or 1.
---------------------------	---

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	EXEC
----------------------	------

Examples	<pre> anm-va/admin# show interface eth0 Link encap:Ethernet HWaddr 00:50:56 :9D :04:07 inet addr:10.1.41.10 Bcast: 10.1.255.255 Mask:255.255.0.0 inet6 addr: fe80::250:56ff:fe9d:407/64 Scope:Link UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1 RX packets:27151 errors:0 dropped:0 overruns:0 frame:0 TX packets:2007 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:1000 RX bytes:6466949 (6.1 MiB) TX bytes:153368 (149.7 KiB) Interrupt:59 Base address:0x2000 lo Link encap:Local Loopback inet addr:127.0.0.1 Mask:255.0.0.0 inet6 addr: ::1/128 Scope:Host UP LOOPBACK RUNNING MTU:16436 Metric:1 RX packets:12880 errors:0 dropped:0 overruns:0 frame:0 TX packets:12880 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueue len:0 RX bytes:2823925 (2.6 MiB) TX bytes:2823925 (2.6 MiB) sit0 Link encap:IPv6-in-IPv4 NOARP MTU:1480 Metric:1 RX packets:0 errors:0 dropped:0 overruns:0 frame:0 TX packets:0 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen: 0 RX bytes:0 (0.0 b) TX bytes:0 (0.0 b) </pre>
-----------------	---

show inventory

To display information about the virtual hardware inventory, such as the memory capacity and interface information, use the **show inventory** command in the EXEC mode.

show inventory

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show inventory
NAME: "ANM-VA                chassis", DESCR: "ANM-VA                chassis"
PID: ANM-VA                , VID: V41 , SN: FFBDF3G4DON
Total RAM Memory: 2075524 kB
CPU Core Count: 1
CPU 0: Model Info: Intel(R) Xeon(R) CPU                E5504 @ 2.00GHz
Hard Disk Count(*): 1
Disk 0: Device Name: /dev/sda
Disk 0: Capacity: 134.20 GB
Disk 0: Geometry: 255 heads 63 sectors/track 16317 cylinders
NIC Count: 1
NIC 0: Device Name: eth0
NIC 0: HW Address: 00:50:56:8B:3A:53
NIC 0: Driver Descr: eth0: registered as PCnet/PCI II 79C970A
```

(*) Hard Disk Count may be Logical.

show ip route

To display the IP routing tables on ANM Virtual Appliance, use the **show ip route** command.

show ip route

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show ip route
Kernel IP routing table
Destination      Gateway         Genmask         Flags   Metric      Ref     Use Iface
10.1.0.0         0.0.0.0        255.255.0.0    U       0           0       0   eth0
0.0.0.0         10.1.0.1       0.0.0.0        UG      0           0       0   eth0
```

show logging

To display the state of system logging (syslog) and the contents of the standard system logging buffer, use the **show logging** command in the EXEC mode.

```
show logging { application [application-name] | system } [tail [count number]]
```

```
show logging internal
```

Syntax Description

application	Displays all application logs (ANM Virtual Appliance only).
<i>application-name</i>	(Optional) Application name. Displays specified application log (ANM Virtual Appliance only). Enter a maximum of 255 alphanumeric characters.
tail	(Optional) Tail message log.
count number	(Optional) Displays the specified number of messages. Enter a value from 0 to 4,294,967,295.
internal	Displays the syslogs configuration.
system	Displays the system syslogs.

Defaults

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

This command displays the state of syslog error and event logging, including host addresses, and for which, logging destinations (console, monitor, buffer, or host) logging is enabled.

Examples

Example 1

```
anm-va/admin# show logging system
ADEOS Platform log:
```

```
-----
```

```
Oct  7 13:24:41 localhost debugd[2050]: [2915]: config:network: main.c[238]: Set
up is complete
Oct  7 13:24:51 localhost debugd[2050]: hangup signal caught, configuration read
Oct  7 13:24:51 localhost debugd[2050]: successfully loaded debug config
Oct  7 13:24:51 localhost debugd[2050]: [3482]: icmp: icmputils_cli.c[139]: Generating
icmp echo response config
Oct  7 13:24:51 localhost debugd[2050]: [3482]: icmp: cars_icmpcfg.c[118]: Got the current
ICMP Echo response config as : enabled
Oct  7 13:24:51 localhost debugd[2050]: [3482]: icmp: icmputils_cli.c[160]: Got ICMP echo
config: on
Oct  7 13:24:51 localhost debugd[2050]: [3482]: icmp: icmputils_cli.c[167]: Finished icmp
echo response config generation
Oct  7 13:24:51 localhost debugd[2050]: [3482]: logging: logutils_cli.c[233]: Generating
logging config
Oct  7 13:24:51 localhost debugd[2050]: [3482]: logging: logutils_cli.c[253]: Got
Logserver: localhost
```



```
Oct 7 13:24:51 localhost debugd[2050]: [3482]: logging: logutils_cli.c[261]: Got
loglevel: 6
--More-- (press Spacebar to continue)
```

Example 2

```
anm-va/admin# show logging internal
```

```
log server:          localhost
Global loglevel:    6
Status:             Enabled
```

show logins cli

To display the status and history of system logins, use the **show logins cli** command in the EXEC mode.

show logins cli

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines Requires the **cli** keyword; otherwise, an error occurs.

Examples

```
anm-va/admin# show logins cli
admin pts/0 dhcp-64-102-82-1 Thu May 3 05:23 still logged in
admin pts/0 dhcp-64-102-82-1 Thu May 3 04:31 - 05:11 (00:39)
admin pts/0 dhcp-64-102-82-1 Thu May 3 04:16 - 04:17 (00:00)
admin pts/0 dhcp-64-102-82-1 Thu May 3 03:53 - 04:16 (00:22)

wtmp begins Tue Oct 7 13:21:14 2008
```

show memory

To display the memory usage of all the running processes, use the **show memory** command in the EXEC mode.

```
show memory
```

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show memory
total memory:    2074924 kB
free memory:    1687324 kB
cached:         162984 kB
swap-cached:    0 kB
```

show ntp

To show the status of the Network Time Protocol (NTP) associations, use the **show ntp** command in the EXEC mode.

```
show ntp
```

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show ntp  
Primary NTP   : 1.ntp.esl.cisco.com  
Secondary NTP : 2.ntp.esl.cisco.com  
  
synchronised to NTP server (209.165.202.129) at stratum 2  
  time correct to within 37 ms  
  polling server every 128 s
```

show ports

To display information about all the processes listening on active ports, use the **show ports** command in the EXEC mode.

show ports

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines When you run the **show ports** command, the port must have an associated active session.

Examples

```
anm-va/admin# show ports

Process : dbserv10 (9253)
         tcp: 0.0.0.0:2638, :::2638
Process : portmap (2615)
         tcp: 0.0.0.0:111
         udp: 0.0.0.0:111
Process : dbserv10 (10019)
         tcp: 0.0.0.0:43216, :::43216
Process : rt_daemon (9450)
         tcp: 172.23.245.28:49
         udp: 0.0.0.0:32771, 0.0.0.0:1812, 0.0.0.0:1813, 0.0.0.0:1645, 0.0.0.0:1646
Process : monit (6933)
         tcp: 127.0.0.1:2812
Process : java (9756)
         tcp: :::2020, ::ffff:127.0.0.1:8005, :::6666, :::2030, :::61616, :::80,
         ::ffff:127.0.0.1:51515, :::443
Process : sshd (2776)
         tcp: :::22
Process : java (10023)
         udp: :::20514
anm-va/admin#
```

show process

To display information about active processes, use the **show process** command in the EXEC mode.

```
show process
```

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines [Table A-6](#) describes the process fields that display in the command output.

Table A-6 Show Process Field Descriptions

Field	Description
USER	Logged-in user.
PID	Process ID.
TIME	The time the command was last used.
TT	Terminal that controls the process.
COMMAND	Type of process or command used.

Examples

```
anm-va/admin# show process

USER      PID      TIME TT      COMMAND
root      1 00:00:00 ?      init
root      2 00:00:00 ?      migration/0
root      3 00:00:00 ?      ksoftirqd/0
root      4 00:00:00 ?      migration/1
root      5 00:00:00 ?      ksoftirqd/1
root      6 00:00:00 ?      events/0
root      7 00:00:00 ?      events/1
root      8 00:00:00 ?      khelper
root      9 00:00:00 ?      kacpid
root     36 00:00:00 ?      kblockd/0
root     37 00:00:00 ?      kblockd/1
root     55 00:00:00 ?      pdflush
root     58 00:00:00 ?      aio/0
root     59 00:00:00 ?      aio/1
root     38 00:00:00 ?      khubd
root     57 00:00:00 ?      kswapd0
root    203 00:00:00 ?      kseriod
root    320 00:00:00 ?      ata/0
root    321 00:00:00 ?      ata/1
--More-- (press Spacebar to continue)
```

show repository

To display the file contents of the repository, use the **show repository** command in the EXEC mode.

```
show repository repository-name
```

Syntax Description	<i>repository-name</i>	Name of the repository whose contents you want to view. Enter a maximum of 30 alphanumeric characters.
---------------------------	------------------------	--

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	EXEC
----------------------	------

Examples	<pre>anm-va/admin# show repository myrepository back1.tar.gpg back2.tar.gpg anm-va/admin#</pre>
-----------------	--

show restore history

To display the restore history, use the **show restore history** command in the EXEC mode.

show restore history

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

Example 1

```
anm-va/admin# show restore history
Tue Sep 4 03:42:48 PDT 2008: restore 11backup_Local.File2.tar.gpg from repository
executeBackupRepo: success Tue Sep 4 03:46:15 PDT 2008: restore
11backup_Local.File2.tar.gpg from repository executeBackupRepo: success Tue Sep 4
03:51:07 PDT 2008: restore 11backup_Local.File2.tar.gpg from repository executeBackupRepo:
success Tue Sep 4 03:54:35 PDT 2008: restore 11backup_Local.File2.tar.gpg from repository
executeBackupRepo: success Wed Sep 5 12:31:21 UTC 2008: restore cdromRestore.tar.gpg from
repository cdrom1: success admin#
```

Example 2

```
anm-va/admin# show restore history
restore history is empty
```


show running-configuration

To display the contents of the currently running configuration file or the configuration, use the **show running-configuration** command in the EXEC mode.

show running-configuration

Syntax Description No arguments or keywords.

Defaults The **show running-configuration** command displays all of the configuration information.

Command Modes EXEC

Examples

```
anm-va/admin# show running-configuration

Generating configuration...
!
hostname anm-va
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
  ip address 10.1.41.10 255.255.0.0
!
ip name-server 10.1.0.2 10.1.1.10
!
ip default-gateway 10.1.0.1
!
clock timezone UTC
!
ntp server time.nist.gov
!
username admin password hash $1$YAjhzmfS$uNRmh.DxzEuGnQn.role admin
!
service sshd
!
repository myrepository
  url ftp://209.165.200.234/backup
  user repuser password secret
!
password-policy
  lower-case-required
  upper-case-required
  digit-required
  no-username
  disable-cisco-passwords
  min-password-length 6
!
logging localhost
logging loglevel 6
!
cdp timer 60
cdp holdtime 180
```

■ Show Commands

```
cdp run GigabitEthernet 0
!  
icmp echo on  
!
```

show startup-configuration

To display the contents of the startup configuration file or the configuration, use the **show startup-configuration** command in the EXEC mode.

show startup-configuration

Syntax Description No arguments or keywords.

Defaults The **show startup-configuration** command displays all of the startup configuration information.

Command Modes EXEC

Examples

```
anm-va/admin# show startup-configuration

Generating configuration...
!
hostname anm-va
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
  ip address 209.165.200.225 255.255.255.224
!
ip name-server 10.1.0.2 10.1.1.10
!
ip default-gateway 10.1.0.1
!
clock timezone UTC
!
!
username admin password hash $1$YAjhzmfS$uNRmh.DxzEuGnQn.role admin
!
service sshd
!
repository myrepository
  url ftp://209.165.200.234/backup
  user repuser password secret
!
--More-- (press Spacebar to continue)
```

show tech-support

To display technical support information, including e-mail, use the **show tech-support** command in the EXEC mode.

```
show tech-support [file word]
```

Syntax Description

file	(Optional) Saves any technical support data as a file in the local disk, which is disk: (do not include disk: in the command).
<i>word</i>	Filename to save. Enter a maximum of 80 alphanumeric characters.

Defaults

Passwords and other security information do not appear in the output.

Command Modes

EXEC

Usage Guidelines

The **show tech-support** command is useful for collecting a large amount of information about your ANM Virtual Appliance for troubleshooting purposes. You can then provide output to technical support representatives when reporting a problem.

Examples

```
anm-va/admin# show tech-support
#####
Application Deployment Engine(ADE) - Release 1.0
Technical Support Debug Info follows...
#####

*****
Checking dmidecode Serial Number(s)
*****
    0x0736C7F6
    0x0736C803
    0x0736C808
    0x0736C81F
    AZAX74601334

*****
Displaying System Uptime...
*****
    20:41:46 up  6:42,  1 user,  load average: 0.45, 0.20, 0.12

*****
Display Memory Usage(KB)
*****
            total      used      free      shared      buffers      cached
Mem:      4148032    2951612    1196420          0         59440        1873920
-/+ buffers/cache:    1018252    3129780
Swap:      8191992          0      8191992

*****
Displaying Processes(ax --forest)...
```

```
*****
PID TTY      STAT   TIME COMMAND
  1 ?        S       0:00 init [3]
  2 ?        S       0:00 [migration/0]
  3 ?        SN      0:00 [ksoftirqd/0]
  4 ?        S       0:00 [migration/1]
  5 ?        SN      0:00 [ksoftirqd/1]

--More-- (Press Enter or Spacebar.)
```

show terminal

To obtain information about the terminal configuration parameter settings, use the **show terminal** command in the EXEC mode.

show terminal

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines [Table A-7](#) describes the fields of the **show terminal** output.

Table A-7 Show Terminal Field Descriptions

Field	Description
TTY: /dev/pts/0	Displays standard output to type of terminal.
Type: "vt100"	Type of current terminal used.
Length: 24 lines	Length of the terminal display.
Width: 80 columns	Width of the terminal display, in character columns.
Session Timeout: 30 minutes	Length of time, in minutes, for a session, after which the connection closes.

Examples

```
anm-va/admin# show terminal
TTY: /dev/pts/0 Type: "vt100"
Length: 25 lines, Width: 80 columns
Session Timeout: 30 minutes
anm-va/admin#
```

show timezone

To display the time zone as set on the system, use the **show timezone** command in the EXEC mode.

show timezone

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show timezone
UTC
```

show timezones

To obtain a list of time zones from which you can select, use the **show timezones** command in the EXEC mode.

```
show timezones
```

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines See see the [clock timezone](#) command, for examples of the time zones available for ANM Virtual Appliance.

Examples

```
anm-va/admin# show timezones
PST8PDT
Hongkong
Etc/GMT-7
Etc/GMT-12
Etc/GMT-4
Etc/GMT-13
Etc/GMT-11
Etc/GMT-1
Etc/GMT+5
Etc/GMT-14
Etc/GMT+11
Etc/GMT+6
Etc/Zulu
Etc/GMT+7
Etc/Universal
Etc/GMT-2
Etc/GMT+10
Etc/GMT-8
Etc/GMT+8
Etc/GMT+1
Etc/GMT0
Etc/GMT+9
Etc/GMT+3
Etc/GMT-3
Etc/GMT
Etc/GMT-5
Etc/GMT-0
Etc/GMT-6
Etc/GMT+4
Etc/GMT-9
Etc/GMT+12
Etc/GMT+2
Etc/UCT
--More-- (Press Enter or Spacebar)
```


show udi

To display UDI information for ANM Virtual Appliance, use the **show udi** command in the EXEC mode.

show udi

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines This command returns information on the Serial Product ID (SPID), Version ID (VPID), and the appliance serial number. The actual UDI value is made up of the SPID and the serial number of the appliance, such as `Cisco-VM-SPIDG7123455`.

Examples

```
anm-va/admin# show udi
SPID: ANM-VA
VPID: V41
Serial: FFBDF3G4DON
```

show uptime

To display the length of time that you have been logged in to ANM Virtual Appliance, use the **show uptime** command in the EXEC mode.

show uptime

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show uptime
4 day(s), 16:36:58
```

show users

To display the list of users logged in to ANM Virtual Appliance, use the **show users** command in the EXEC mode.

show users

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Examples

```
anm-va/admin# show users
```

USERNAME	ROLE	HOST	TTY	LOGIN DATETIME
admin	Admin	209.165.200.225	pts/0	Tue Oct 7 19:21:00 2008

show version

To display information about the software version of the system, use the **show version** command in the EXEC mode.

show version

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes EXEC

Usage Guidelines This command displays information about the ADE OS software version running on ANM Virtual Appliance and the ANM version.

Examples

```
anm-va/admin# show version

Cisco Application Deployment Engine OS Release: 2.0
ADE-OS Build Version: 2.0.0.448
ADE-OS System Architecture i386

Copyright (c) 2005-2011 by Cisco Systems, Inc.
All rights reserved.
Hostname: anm-va

Version information of installed applications
-----

4.3 (0)
```

Configuration Commands

Each configuration command includes a brief description of its use, command syntax, usage guidelines, and sample output.

Configuration commands include **interface** and **repository**.


Note

Some of the configuration commands require you to enter the configuration submode to complete the command configuration.

To access the configuration mode, you must use the **configure** command in the EXEC mode.

[Table A-8](#) lists the configuration commands that this section describes.

Table A-8 *List of Configuration Commands*

• aaa authentication tacacs+	• ip domain-name
• backup-staging-url	• ip name-server
• cdp holdtime	• kron occurrence
• cdp run	• kron policy-list
• cdp timer	• logging
• clock timezone	• ntp server
• do	• password-policy
• end	• repository
• exit	• service sshd
• hostname	• snmp-server community
• icmp echo	• snmp-server contact
• interface GigabitEthernet	• snmp-server host
• ip address	• snmp-server location
• ip default-gateway	• username

aaa authentication tacacs+

To specify remote authentication for console users, use the **aaa authentication tacacs+** command. TACACS+ is a TCP-based protocol for remote authentication.

aaa authentication tacacs+ server *servername* key *sharedkey*

Syntax Description

server <i>servername</i>	Specifies the hostname or IP address of the remote TACACS+ authentication server.
key <i>sharedkey</i>	Specifies the security key that matches the security key on the remote server.

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

You can use this command to direct ANM Virtual Appliance to use a remote server to authenticate console users.

Usage Guidelines

```
anm-va/admin(config)# aaa authentication tacacs+ server 10.1.0.31 key secret1234
```

backup-staging-url

To allow you to configure a Network File System (NFS) location that backup and restore operations will use as a staging area to package and unpack backup files, use the **backup-staging-url** command in configuration mode.

backup-staging-url *word*

Syntax Description

<i>word</i>	NFS URL for staging area. Enter a maximum of 2048 alphanumeric characters. Use the format nfs://server:path where <i>server</i> is the server name and <i>path</i> refers to /subdir/subsubdir. Remember that a colon (:) is required after the server..
-------------	---

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

The URL is NFS only. The format of the command is **backup-staging-url nfs://server:path**.



Caution

Ensure that you secure your NFS server in such a way that the directory can be accessed only by the IP address of ANM Virtual Appliance.

Examples

```
anm-va/admin(config)# backup-staging-url nfs://loc-filer02a:/vol/local1/private1/jdoe
```

cdp holdtime

To specify the amount of time for which the receiving device should hold a CDP packet from ANM Virtual Appliance before discarding it, use the **cdp holdtime** command in the configuration mode. To revert to the default setting, use the **no** form of this command.

cdp holdtime *seconds*

no cdp holdtime *seconds*


Syntax Description	<i>seconds</i>	Specifies the hold time in seconds. Enter a value from 10 to 255 seconds.
Defaults	180 seconds	
Command Modes	Configuration	
Usage Guidelines	<p>CDP packets transmit with a time to live, or hold time, value. The receiving device will discard the CDP information in the CDP packet after the hold time has elapsed.</p> <p>The cdp holdtime command takes only one argument; otherwise, an error occurs.</p>	
Examples	<pre>anm-va/admin(config)# cdp holdtime 60</pre>	

cdp run

To enable Cisco Discovery Protocol (CDP) operation, use the **cdp run** command in configuration mode. To disable CDP, use the **no** form of this command.

```
cdp run [GigabitEthernet]
```

```
no cdp run [GigabitEthernet]
```

Syntax Description	GigabitEthernet (Optional) Specifies the GigabitEthernet interface on which to enable CDP.
Defaults	No default behavior or values.
Command Modes	Configuration
Usage Guidelines	The command has one optional argument, an interface name. Without an optional interface name, the command enables CDP on all interfaces.
 Note	The default for this command is on interfaces that are already up and running. When you are bringing up an interface, stop CDP first; then, start CDP again.
Examples	<pre>anm-va/admin(config)# cdp run GigabitEthernet 0</pre>

cdp timer

To specify how often ANM Virtual Appliance sends Cisco Discovery Protocol (CDP) updates, use the **cdp timer** command in configuration mode. To revert to the default setting, use the **no** form of this command.

cdp timer *seconds*

no cdp timer *seconds*

Syntax Description	<i>seconds</i>	Length of time, in seconds, that ANM Virtual Appliance sends CDP updates. Enter a value from 5 to 254 seconds.
---------------------------	----------------	--

Defaults	60 seconds
-----------------	------------

Command Modes	Configuration
----------------------	---------------

Usage Guidelines	CDP packets transmit with a time to live, or hold time, value. The receiving device will discard the CDP information in the CDP packet after the hold time has elapsed.
-------------------------	---

The **cdp timer** command takes only one argument; otherwise, an error occurs.

Examples	anm-va/admin(config)# cdp timer 60
-----------------	---

clock timezone

To set the time zone, use the **clock timezone** command in configuration mode. To disable this function, use the **no** form of this command.

clock timezone *timezone*

no clock timezone *timezone*

Syntax Description	<i>timezone</i>	Name of the time zone visible when in standard time. This can be a maximum of 64 alphanumeric characters.
Defaults	UTC	
Command Modes	Configuration	
Usage Guidelines	The system internally keeps time in UTC. If you do not know your specific time zone, you can enter the region, country, and city (see Tables A-9, A-10, and A-11 for sample time zones to enter on your system).	

Table A-9 Common Time Zones

Acronym or name	Time Zone Name
Europe	
GMT, GMT0, GMT-0, GMT+0, UTC, Greenwich, Universal, Zulu	Greenwich Mean Time, as UTC
GB	British
GB-Eire, Eire	Irish
WET	Western Europe Time, as UTC
CET	Central Europe Time, as UTC + 1 hour
EET	Eastern Europe Time, as UTC + 2 hours
United States and Canada	
EST, EST5EDT	Eastern Standard Time, as UTC -5 hours
CST, CST6CDT	Central Standard Time, as UTC -6 hours
MST, MST7MDT	Mountain Standard Time, as UTC -7 hours
PST, PST8PDT	Pacific Standard Time, as UTC -8 hours
HST	Hawaiian Standard Time, as UTC -10 hours

Table A-10 Australia Time Zones

Australia¹			
ACT ²	Adelaide	Brisbane	Broken_Hill
Canberra	Currie	Darwin	Hobart
Lord_Howe	Lindeman	LHI ³	Melbourne
North	NSW ⁴	Perth	Queensland
South	Sydney	Tasmania	Victoria
West	Yancowinna		

1. Enter the country and city together with a forward slash (/) between them; for example, Australia/Currie.
2. ACT = Australian Capital Territory.
3. LHI = Lord Howe Island
4. NSW = New South Wales

Table A-11 Asia Time Zones

Asia¹			
Aden ²	Almaty	Amman	Anadyr
Aqtou	Aqtobe	Ashgabat	Ashkhabad
Baghdad	Bahrain	Baku	Bangkok
Beirut	Bishkek	Brunei	Calcutta
Choibalsan	Chongqing	Columbo	Damascus
Dhakar	Dili	Dubai	Dushanbe
Gaza	Harbin	Hong_Kong	Hovd
Irkutsk	Istanbul	Jakarta	Jayapura
Jerusalem	Kabul	Kamchatka	Karachi
Kashgar	Katmandu	Kuala_Lumpur	Kuching
Kuwait	Krasnoyarsk		

1. The Asia time zone includes cities from East Asia, Southern Southeast Asia, West Asia, and Central Asia.
2. Enter the region and city or country together separated by a forward slash (/); for example, Asia/Aden.

**Note**

Several more time zones are available to you. On your ANM Virtual Appliance, enter **show timezones**. A list of all the time zones available in ANM Virtual Appliance appears. Choose the most appropriate one for your time zone.

Examples

```
anm-va/admin(config)# clock timezone EST
anm-va/admin(config)# exit
anm-va/admin# show timezone
EST
```

do

To execute an EXEC-level command from configuration mode or any configuration submode, use the **do** command in any configuration mode.

do arguments

Syntax Description	<i>arguments</i>	The EXEC command to execute (see Table A-12 in Usage Guidelines).
---------------------------	------------------	---

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Configuration or any configuration submode
----------------------	--

Usage Guidelines	Use this command to execute EXEC commands (such as show , clear , and debug commands) while configuring ANM. After the EXEC command executes, the system will return to the configuration mode you were using.
-------------------------	---

[Table A-12](#) lists the possible **do** command arguments.

Table A-12 Command Options for Do Command

Command	Description
anm-certificate install	Installs a security certificate for the ANM web application.
anm-data-export audit	Generates an archive containing audit-related log information.
anm-data-export history	Generates an archive containing audit-related log information.
anm-license install	Installs a license for the ANM web application.
anm-tool configure	Initiates the web application configuration sequence for the ANM application.
anm-tool restart	Restarts the ANM application processes.
application install	Installs a specific application. Not used with ANM Virtual Appliance.
application remove	Removes a specific application. Not used with ANM Virtual Appliance.
application start	Starts the ANM application.
application stop	Stops the ANM application.
application upgrade	Upgrades a specific application.
backup	Performs a backup of the ADE OS files and places the backup in a repository.
backup-logs	Performs a backup of all the logs on ANM Virtual Appliance to a remote location. Backs up the ANM-specific logs, such as audit and device-related activity logs, as well as the ADE OS logs.
clock	Sets the system clock on ANM Virtual Appliance.
configure	Enters Configuration mode.

Table A-12 Command Options for Do Command (continued)

Command	Description
copy	Copies any file from a source to a destination.
debug	Displays any errors or events for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and user management.
delete	Deletes a file on ANM Virtual Appliance.
dir	Lists files on ANM Virtual Appliance.
forceout	Forces the logout of all the sessions of a specific ANM Virtual Appliance user.
halt	Disables or shuts down ANM Virtual Appliance.
help	Describes the help utility and how to use it on ANM Virtual Appliance.
mkdir	Creates a new directory.
nslookup	Queries the IPv4 address or hostname of a remote system.
patch install	Applies a software patch to the system.
ping	Determines the network activity on a remote system.
reload	Reboots ANM Virtual Appliance.
restore	Performs a restore and retrieves the backup out of a repository.
rmdir	Removes an existing directory.
show	Provides information about ANM Virtual Appliance.
ssh	Starts an encrypted session with a remote system.
tech	Provides Technical Assistance Center (TAC) commands.
telnet	Telnets to a remote system.
terminal length	Sets terminal line parameters.
terminal session-timeout	Sets the inactivity timeout for all terminal sessions.
terminalsession-welcome	Sets the welcome message on the system for all terminal sessions.
terminal terminal-type	Specifies the type of terminal connected to the current line of the current session.
traceroute	Traces the route of a remote IP address.
undebug	Disables the output (display of errors or events) of the debug command for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and user management.
write	Copies, displays, or erases the running ANM Virtual Appliance information.

Examples

```

anm-va/admin(config)# do show run
Generating configuration...
!
hostname ems-lnx106
ip domain-name cisco.com
interface ethernet 0
    ip address 209.165.200.225 255.255.255.224

```

```
interface ethernet 1
  shutdown
ip name-server 209.165.201.1
ip default-gateway 209.165.202.129
clock timezone Cuba
!
!
username admin password hash $1$hB$MxIZHvecMiey/P9mM9PvN0 role admin
!
!
logging localhost
logging loglevel 6
!
```

end

To end the current configuration session and return to the EXEC mode, use the **end** command in configuration mode.

end

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes Configuration

Usage Guidelines This command brings you back to EXEC mode regardless of what configuration mode or submode you are in.

Use this command when you finish configuring the system and you want to return to EXEC mode to perform verification steps.

Examples `anm-va/admin(config)# end`

exit

To exit any configuration mode to the next-highest mode in the CLI mode hierarchy, use the **exit** command in configuration mode.

exit

Syntax Description No arguments or keywords.

Defaults No default behavior or values.

Command Modes Configuration

Usage Guidelines The **exit** command is used in ANM Virtual Appliance to exit the current command mode to the next highest command mode in the CLI mode hierarchy.

For example, use the **exit** command in Configuration mode to return to the EXEC mode. Use the **exit** command in the configuration submodes to return to Configuration mode. At the highest level, EXEC mode, the **exit** command exits the EXEC mode and disconnects from ANM Virtual Appliance (see [exit](#), page A-34, for a description of the **exit** (EXEC) command).

Examples `anm-va/admin(config)# exit`

hostname

To set the hostname of the system, use the **hostname** command in configuration mode. To delete the hostname from the system, use the **no** form of this command. This resets the system to localhost.

hostname *word*

Syntax Description

<i>word</i>	Name of the host. Enter 2 to 19 alphanumeric characters; dashes (-) are allowed. Spaces are not allowed.
-------------	--

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

A single instance type of command, **hostname** only occurs once in the configuration of the system. The hostname must contain one argument; otherwise, an error occurs.

Examples

```
anm-va/admin(config)# hostname myserver-1
Changing the hostname or IP may result in undesired side effects,
such as installed application(s) being restarted.
Are you sure you want to proceed? [y/n] y
```

icmp echo

To configure the Internet Control Message Protocol (ICMP) echo responses, use the **icmp echo** command in configuration mode.

```
icmp echo {off | on}
```

Syntax Description

off	Disables ICMP echo response
on	Enables ICMP echo response.

Defaults

The system will behave as if the ICMP echo response is on (enabled).

Command Modes

Configuration

Examples

```
anm-va/admin(config)# icmp echo off
```

interface GigabitEthernet

To configure an interface type and enter the interface configuration mode, use the **interface GigabitEthernet** command in configuration mode.

```
interface GigabitEthernet {0 | 1 | 2 | 3}
```

Syntax Description	0 1 2 3	Specifies the number of the Gigabit Ethernet port to configure.
---------------------------	----------------------	---

Defaults	No default behavior or values.
-----------------	--------------------------------

Command Modes	Configuration
----------------------	---------------

Usage Guidelines	<p>You can use this command to configure subinterfaces to support various requirements.</p> <p>After you enter the Gigabit Ethernet port number in the interface GigabitEthernet command, you enter the config-GigabitEthernet configuration submode (see the following syntax description).</p>
-------------------------	---

do	EXEC command. Allows you to perform any EXEC commands in this mode (see the do command).
end	Exits the config-GigabitEthernet submode and returns you to the EXEC mode.
exit	Exits the config-GigabitEthernet configuration submode.
ip	Sets the IP address and netmask for the Ethernet interface (see the ip address command).
no	Negates the command in this mode. Two keywords available: <ul style="list-style-type: none"> ip—Sets the IP address and netmask for the interface. shutdown—Shuts down the interface.
shutdown	Shuts down the interface.

Examples	<pre>anm-va/admin(config)# interface GigabitEthernet 0 anm-va/admin(config-GigabitEthernet)#</pre>
-----------------	---

ip address

To set the IP address and netmask for the Ethernet interface, use the **ip address** command in interface configuration mode. To remove an IP address or disable IP processing, use the **no** form of this command.

ip address *ip-address netmask*

no ip address *ip-address netmask*



Note

You can configure the same IP address on multiple interfaces. You might want to do this to limit the configuration steps required to switch from using one interface to another.

Syntax Description

<i>ip-address</i>	IPv4 version IP address.
<i>netmask</i>	Mask of the associated IP subnet.

Defaults

Enabled.

Command Modes

Interface configuration

Usage Guidelines

This command requires exactly one address and one netmask; otherwise, an error occurs.

Examples

```
anm-va/admin(config)# interface GigabitEthernet 0
anm-va/admin(config-GigabitEthernet)# ip address 209.165.200.227 255.255.255.224
IP Address was modified.
ANM is restarting and a new HTTP certificate will be generated.
Stopping ANM .....
Starting ANM ....
```

To verify that ANM processes are running, use the 'show application status ANM' command.

ip default-gateway

To define or set a default gateway with an IP address, use the **ip default-gateway** command in configuration mode. To disable this function, use the **no** form of this command.

ip default-gateway *ip-address*

no ip default-gateway *ip-address*

Syntax Description	<i>ip-address</i> IP address of the default gateway.
Defaults	Disabled.
Command Modes	Configuration
Usage Guidelines	If you enter more than one argument or no arguments at all, an error occurs.
Examples	anm-va/admin(config)# ip default-gateway 209.165.202.129

ip domain-name

To define a default domain name that ANM Virtual Appliance uses to complete hostnames, use the **ip domain-name** command in configuration mode. To disable this function, use the **no** form of this command.

ip domain-name *word*

no ip domain-name *word*

Syntax Description

<i>word</i>	Default domain name used to complete the hostnames. Enter 2 to 64 alphanumeric characters.
-------------	--

Defaults

Enabled.

Command Modes

Configuration

Usage Guidelines

If you enter more or fewer arguments, an error occurs.

Examples

```
anm-va/admin(config)# ip domain-name cisco.com
```

ip name-server

To set the Domain Name Server (DNS) servers for use during a DNS query, use the **ip name-server** command in configuration mode. To disable this function, use the **no** form of this command.

```
ip name-server ip-address [ip-address*
```

```
no ip name-server ip-address [ip-address*
```

Syntax Description

<i>ip-address</i>	Address of a name server.
<i>ip-address</i> *	(Optional) IP addresses of additional name servers. You can configure a maximum of three name servers.

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

The first name server added with the **ip name-server** command will occupy the first position and the system will first use that server in resolving the IP addresses.

You can add name servers to the system one at a time or all at once, until you reach the maximum (3). If you already configured the system with three name servers, you must remove at least one server to add additional name servers.

To place a name server in the first position so that the subsystem uses it first, you must remove all name servers with the **no** form of this command before you proceed.

Using the **no** form of this command removes all the name servers from the configuration. Using the **no** form of this command and one of the IP names removes only that IP name.



Note

When you enter the **ip name-server** command, a message appears that asks if you want to restart ANM now. The DNS changes still take effect even if you choose not to restart ANM.

Examples

```
anm-va/admin(config)# ip name-server 209.165.201.1
Name Server was modified. You must restart ANM.
Do you want to restart ANM now? (yes/no) yes
Stopping ANM .....
Starting ANM ....
```

To verify that ANM processes are running, use the 'show application status ANM' command.

```
anm-va/admin(config)#
```


ip route

To configure static routes, use the **ip route** command in configuration mode. To remove static routes, use the **no** form of this command.

```
ip route prefix mask gateway ip-address
```

```
no ip route prefix mask
```

Syntax Description

<i>prefix</i>	Specifies the IP route prefix for the destination.
<i>mask</i>	Specifies the prefix mask for the destination.
gateway ip-address	Specifies the IP address of the next hop that can be used to reach that network.

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

Static routes are manually configured. This makes them inflexible (they cannot dynamically adapt to network topology changes) but extremely stable. Static routes optimize bandwidth utilization, because no routing updates need to be sent to maintain them. They also make it easy to enforce routing policy.

Examples

```
anm-va/admin(config)# ip route 192.168.0.0 255.255.0.0 gateway 172.23.90.2
```

kron occurrence

To schedule one or more Command Scheduler commands to run at a specific date and time or a recurring level, use the **kron occurrence** command in configuration mode. To delete a schedule, use the **no** form of this command.

kron occurrence *occurrence-name*

no kron occurrence *occurrence-name*

Syntax Description

<i>occurrence-name</i>	Name of the occurrence. Enter a maximum of 80 alphanumeric characters.
------------------------	--



Note

After you enter the *occurrence-name* in the **kron occurrence** command, you enter the config-occurrence configuration submode (see the following syntax description).

at	Identifies that the occurrence is to run at a specified calendar date and time. Usage: at [<i>hh:mm</i>] [<i>day-of-week</i> <i>day-of-month</i> <i>month day-of-month</i>].
do	EXEC command. Allows you to perform any EXEC commands in this mode (see the do command).
end	Exits the kron-occurrence configuration submode and returns you to the EXEC mode.
exit	Exits the kron-occurrence configuration mode.
no	Negates the command in this mode. Three keywords available: <ul style="list-style-type: none"> • at—Usage: at [<i>hh:mm</i>] [<i>day-of-week</i> <i>day-of-month</i> <i>month day-of-month</i>]. • policy-list—Specifies a policy list to be run by the occurrence. This can be a maximum of 80 alphanumeric characters. • recurring—Execution of the policy lists should be repeated.
policy-list	Specifies a Command Scheduler policy list to be run by the occurrence.
recurring	Identifies that the occurrences run on a recurring basis.

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

Use the **kron occurrence** and **policy-list** commands to schedule one or more policy lists to run at the same time or interval.

Use the **kron policy-list** command in conjunction with the **cli** command to create a Command Scheduler policy containing EXEC CLI commands to be scheduled to run on ANM Virtual Appliance at a specified time. See the **kron policy-list** command.



Note When you run the **kron** command, backup bundles are created with a unique name (by adding a time stamp), to ensure that the files do not overwrite each other.

Examples

Example 1: Weekly Backup

```
anm-va/admin(config)# kron occurrence WeeklyBackup
anm-va/admin(config-Occurrence)# at 14:35 Monday
anm-va/admin(config-Occurrence)# policy-list SchedBackupPolicy
anm-va/admin(config-Occurrence)# recurring
anm-va/admin(config-Occurrence)# exit
anm-va/admin(config)#
```

Example 2: Daily Backup

```
anm-va/admin(config)# kron occurrence DailyBackup
anm-va/admin(config-Occurrence)# at 02:00
anm-va/admin(config-Occurrence)# exit
anm-va/admin(config)#
```

kron policy-list

To specify a name for a Command Scheduler policy and enter the kron-Policy List configuration submode, use the **kron policy-list** command in configuration mode. To delete a policy list, use the **no** form of this command.

kron policy-list *list-name*

no kron policy-list *list-name*

Syntax Description

<i>list-name</i>	Name of the policy list. Enter a maximum of 80 alphanumeric characters.
------------------	---



Note

After you enter the *list-name* in the **kron policy-list** command, you enter the config-Policy List configuration submode (see the following syntax description).

cli	Command to be executed by the scheduler. This can be a maximum of 80 alphanumeric characters.
do	EXEC command. Allows you to perform any EXEC commands in this mode (see the do command).
end	Exits from the config-Policy List configuration submode and returns you to the EXEC mode.
exit	Exits this submode.
no	Negates the command in this mode. One keyword available: <ul style="list-style-type: none"> cli—Command to be executed by the scheduler.

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

Use the **kron policy-list** command in conjunction with the **cli** command to create a Command Scheduler policy containing EXEC CLI commands to be scheduled to run on ANM Virtual Appliance at a specified time. Use the **kron occurrence** and **policy list** commands to schedule one or more policy lists to run at the same time or interval. See the **kron occurrence** command.

Examples

```
anm-va/admin(config)# kron policy-list SchedBackupMonday
anm-va/admin(config-Policy List)# cli backup SchedBackupMonday repository SchedBackupRepo
anm-va/admin(config-Policy List)# exit
anm-va/admin(config)#
```

logging

To enable the system to forward logs to a remote system or to configure the log level, use the **logging** command in configuration mode. To disable this function, use the **no** form of this command.

```
logging {ip-address | hostname} {loglevel level}
```

```
no logging {ip-address | hostname} {loglevel level}
```

Syntax Description		
<i>ip-address</i>		IP address of remote system to which you forward logs. .
<i>hostname</i>		Hostname of remote system to which you forward logs. Enter a maximum of 32 alphanumeric characters.
loglevel		Configures the log level for the logging command.
<i>level</i>		Number of the desired priority level at which you set the log messages. Priority levels are (enter the number for the keyword): <ul style="list-style-type: none"> • 0-emerg—Emergencies: System unusable. • 1-alert—Alerts: Immediate action needed. • 2-crit—Critical: Critical conditions. • 3-err—Error: Error conditions. • 4-warn—Warning: Warning conditions. • 5-notif—Notifications: Normal but significant conditions. • 6-inform—Informational messages. Default. • 7-debug—Debugging messages.

Defaults No default behavior or values.

Command Modes Configuration

Usage Guidelines This command requires an IP address or hostname or the **loglevel** keyword; an error occurs if you enter two or more of these arguments.

Examples

Example 1

```
anm-va/admin(config)# logging 209.165.200.225
```

Example 2

```
anm-va/admin(config)# logging loglevel 0
```

ntp server

To allow for software clock synchronization by the Network Time Protocol (NTP) server for the system, use the **ntp server** command in configuration mode. To disable this capability, use the **no** form of this command.

```
ntp server {ip-address | hostname} [ip-address2 | hostname2]
```

```
no ntp server {ip-address | hostname} [ip-address2 | hostname2]
```

Syntax Description

<i>ip-address</i> <i>hostname</i>	IP address or hostname of the server providing the clock synchronization. You can specify multiple IP addresses or hostnames. Arguments are limited to 255 alphanumeric characters.
<i>ip-address2</i> <i>hostname2</i>	(Optional) Second IP address or hostname of a server providing the clock synchronization. You can specify up to two IP addresses or hostnames.

Defaults

No servers are configured by default.

Command Modes

Configuration

Usage Guidelines

Use this command if you want to allow the system to synchronize with a specified server.

To terminate NTP service on a device, you must enter the **no ntp** command without keywords or arguments.

For example, if you previously ran the **ntp server** command and you now want to remove not only the server synchronization capability, but all NTP functions from the device, use the **no ntp** command without any keywords. This ensures that all NTP functions disable and that the NTP service also terminates.



Note

This command may display conflicting information during the sync process. The sync process can take up to 20 minutes to complete.

Examples

```
anm-va/admin(config)# ntp server 209.165.201.31
NTP Server was modified. You must restart ANM.
Do you want to restart ANM now? (yes/no) yes
Stopping ANM .....
Starting ANM .....
```

To verify that ANM processes are running, use the 'show application status ANM' command.

password-policy

To enable or configure the passwords on the system, use the **password-policy** command in configuration mode. To disable this function, use the **no** form of this command.

password-policy *option*

no password-policy *option*

Syntax Description



Note After you enter the **password-policy** command, you enter the config-password-policy configuration submode.

digit-required	Requires a digit in the password.
disable-repeat-characters	Disables the password's ability to contain more than four identical characters.
disable-cisco-password	Disables the ability to use the word Cisco or any combination as the password.
lower-case-required	Requires a lowercase letter in the password.
min-password-length	Specifies a minimum number of characters for a valid password. Integer length from 0 to 4,294,967,295.
no-previous-password	Prevents users from reusing a part of their previous password.
no-username	Prohibits users from reusing their username as a part of a password.
password-expiration-days	Number of days until a password expires. Integer length from 0 to 80.
password-expiration-enabled	Enables password expiration. Note You must enter the password-expiration-enabled command before the other password-expiration commands.
password-expiration-warning	Number of days before expiration that warnings of impending expiration begin. Integer length from 0 to 4,294,967,295.
password-lock-enabled	Locks a password after several failures.
password-lock-retry-count	Number of failed attempts before password locks. Integer length from 0 to 4,294,967,295.
upper-case-required	Requires an uppercase letter in the password.
special-required	Requires a special character in the password.

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

The **password-policy** command requires a policy option (see the syntax description).

You must enter the **password-expiration-enabled** command before the other password-expiration commands.

Examples

```
anm-va/admin(config) # password-policy
anm-va/admin(config-password-policy) # password-expiration-days 30
anm-va/admin(config-password-policy) # exit
anm-va/admin(config) #
```


repository

To enter the repository submode for configuration of backups, use the **repository** command in configuration mode.

repository *repository-name*

Syntax Description	<i>repository-name</i> Name of repository. Enter a maximum of 80 alphanumeric characters.
Defaults	No default behavior or values.
Command Modes	Configuration
Usage Guidelines	After you enter the name of the repository in the repository command, you enter the config-Repository configuration submode (see the Syntax Description section).
do	EXEC command. Allows you to perform any of the EXEC commands in this mode (see the do command).
end	Exits the config-Repository mode and returns you to the EXEC mode.
exit	Exits this mode.
no	Negates the command in this mode. Two keywords available: <ul style="list-style-type: none"> • url—Repository URL. • user—Repository username and password for access.
url	URL of the repository. This can be a maximum of 80 alphanumeric characters (see Table A-13).
user	Configure username and password for access. This can be a maximum of 30 alphanumeric characters.

Table A-13 **URL Keywords**

Keyword	Source of Destination
<i>word</i>	Enter repository URL, including server and path info. This can be a maximum of 80 alphanumeric characters.
cdrom:	Local CD-ROM drive (read only).

Table A-13 URL Keywords (continued)

Keyword	Source of Destination
disk:	<p>Local storage.</p> <p>All local repositories are created on the /localdisk partition. When you specify disk:// in the repository URL, the system creates directories in a path that is relative to /localdisk.</p> <p>For example, if you entered disk://backup, the directory is created at /localdisk/backup.</p> <p>You can run the show repository repository_name to view all the files in the local repository.</p>
ftp:	Source or destination URL for an FTP network server. Use url ftp://server/path ¹ .
nfs:	Source or destination URL for an NFS network server. Use url nfs://server:path ¹ .
sftp:	Source or destination URL for an SFTP network server. Use url sftp://server/path ¹ .
tftp:	Source or destination URL for a TFTP network server. Use url tftp://server/path ¹ .

1. Server is the server name and path refers to /subdir/subsubdir. Remember that a colon (:) is required after the server for an NFS network server.

Examples

```

anm-va/admin(config)# repository myrepository
anm-va/admin(config-Repository)# url sftp://starwars.test.com/repository/system1
anm-va/admin(config-Repository)# user luke password skywalker
anm-va/admin(config-Repository)# exit
anm-va/admin(config)#

```

service sshd

To specify a service to manage, use the **service sshd** command in configuration mode. To disable this function, use the **no** form of this command.

service sshd

no service sshd

Syntax Description This command has no arguments or keywords.

Defaults No default behavior or values.

Command Modes Configuration

Usage Guidelines The only service to manage is Secure Shell Daemon; the daemon program for SSH.

Examples `anm-va/admin(config)# service sshd`

snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** command in configuration mode. To disable this function, use the **no** form of this command.

snmp-server community *word* **ro**

no snmp-server community *word* **ro**

Syntax Description

<i>word</i>	Access string that functions much like a password, allowing access to SNMP. No blank spaces allowed. This can be a maximum of 255 alphanumeric characters.
ro	Specifies read-only access.

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

The **snmp-server community** command requires a community string and the **ro** argument; otherwise, an error occurs.

Examples

```
anm-va/admin(config)# snmp-server community new ro
```

snmp-server contact

To configure the SNMP contact MIB value on the system, use the **snmp-server contact** command in configuration mode. To remove the system contact information, use the **no** form of this command.

snmp-server contact *word*

no snmp-server contact *word*

Syntax Description

<i>word</i>	String that describes the system contact information of the node. Enter a maximum of 255 alphanumeric characters.
-------------	---

Defaults

No default behavior or values.

Command Modes

Configuration

Examples

```
anm-va/admin(config)# snmp-server contact Luke
```

snmp-server host

To send SNMP traps to a remote user, use the **snmp-server host** command in configuration mode. To remove trap forwarding, use the **no** form of this command.

```
snmp-server host {ip-address | hostname} version {1 | 2c} community
```

```
no snmp-server host {ip-address | hostname} version {1 | 2c} community
```

Syntax Description		
<i>ip-address</i>		IP address of the SNMP notification host.
<i>hostname</i>		Name of the SNMP notification host. Enter a maximum of 32 alphanumeric characters.
version { 1 2c }		(Optional) Specifies the version of the SNMP used to send the traps. The default is 1.
<i>community</i>		Password-like community string that is sent with the notification operation.

Defaults Disabled.

Command Modes Configuration

Usage Guidelines The command takes arguments as listed; otherwise, an error occurs.

Examples

```
anm-va/admin(config)# snmp-server community new ro 10
anm-va/admin(config)# snmp-server host 209.165.202.129 version 1 password
```

snmp-server location

To configure the SNMP location MIB value on the system, use the **snmp-server location** command in configuration mode. To remove the system location information, use the **no** form of this command.

snmp-server location *word*

no snmp-server location *word*

Syntax Description

<i>word</i>	String that describes the system's physical location information. Enter a maximum of 255 alphanumeric characters.
-------------	---

Defaults

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

We recommend that you use underscores (_) or hyphens (-) between the terms within the *word* string. If you use spaces between terms within the *word* string, you must enclose the string in quotation marks ("").

Examples**Example 1**

```
anm-va/admin(config)# snmp-server location Building_3/Room_214
```

Example 2


```
anm-va/admin(config)# snmp-server location "Building 3/Room 214"
```

username

To add a user who can access the command line, use the **username** command in configuration mode. If the user already exists, the password, the privilege level, or both change with this command. To delete the user from the system, use the **no** form of this command.

```
username username password {hash password | plain password | remote} role {admin | user}
[disabled] [email email-address]
```

Syntax Description

username	Name of the user. Enter a maximum of 31 alphanumeric characters. Spaces and quotation marks (“”) are not allowed and the word “Cisco” cannot be used.
password	<p>Specifies the password type as follows:</p> <ul style="list-style-type: none"> • hash <i>password</i> and plain <i>password</i>—Specifies the user password for local user authentication. If you have ANM configured to use a TACACS+ server for remote user authentication and the remote server cannot be accessed, user authentication is performed locally by ANM. The <i>password</i> argument is alphanumeric and can contain spaces and special characters such as brackets, ampersand, and so forth. The password must contain the following: <ul style="list-style-type: none"> – At least one lowercase letter. – At least one uppercase letter. – At least one digit. – At least 6 characters. <p> Note The password cannot contain the word “Cisco” as part of the password.</p> <p>You can change these default password requirements using the password-policy command (see the “password-policy” section on page A-119).</p> <ul style="list-style-type: none"> • remote—Specifies that user authentication is performed remotely by a TACACS+ server only. If the TACACS+ server cannot be accessed, users cannot log in to ANM. <p>For information about configuring ANM to use remote authentication, see the aaa authentication tacacs+ command.</p> <p>Enter a maximum of 40 alphanumeric characters. You must specify a password for all new users.</p>
role	<p>Specifies the user privilege level as follows:</p> <ul style="list-style-type: none"> • admin—Permits full access to the CLI functions. • user— Restricts access to the CLI functions (primarily show commands only).

disabled	(Optional) Disables the user account.
email <i>email-address</i>	(Optional) Specifies the user e-mail address. For example, <i>user1@mydomain.com</i> .

Defaults The initial user during setup.

Command Modes Configuration

Usage Guidelines The **username** command requires that the username and password keywords precede the hash | plain and the admin | user options.

Examples

Example 1

```
anm-va/admin(config)# username admin password hash ##### role admin
```

Example 2

```
anm-va/admin(config)# username admin password plain Secr3tp@swd role admin
```

Example 3

```
anm-va/admin(config)# username admin password plain Secr3tp@swd role admin email  
admin123@mydomain.com
```

