



Monitor and Troubleshoot

Following are some troubleshooting tips for installing and using the Cisco Smart PHY.

- [Monitor Host Resources, on page 1](#)
- [Debug RPD SSD on Cisco Smart PHY, on page 2](#)
- [Debug SSD on Cisco cBR-8, on page 6](#)
- [DEPI Latency Measurement in Service Template, on page 6](#)

Monitor Host Resources

Use the Grafana dashboard for monitoring host resources.


Step 1 Access the Grafana dashboard using the following URL: `https://grafana.<smartphy-ip>.nip.io/` or `https://grafana.<fqdn>/`

Step 2 Log in using the credentials used during the installation.




Step 3 Select **Dashboards > Manage**.

Step 4 Click the **cee-data** and then select **Host Details**.



Step 5 To view details of CPU, Memory, or Disk usage, select the **Host** on the top left corner of the screen.



Debug RPD SSD on Cisco Smart PHY

The SSD related logs in Cisco Smart PHY application are available at:
 /var/log/rpd-service-manager/rpd-service-manager.log.

Check SSD on NSO

The Cisco Network Services Orchestrator (NSO) supports the SSD profile from the iosNed 6.28.

1. Access the `robot-cfgsvc` container and check the SSD configuration on the NSO side.
2. Wait until the device moves into in-sync.

```
router# devices device _DEVICE_20.5.30.13 check-sync
result out-of-sync
info got: 4a0ba9b4ecdaa8710a9202e8656bfe82 expected: c22a63a573c84e40c1ad5e735888461c
router# devices device _DEVICE_20.5.30.13 check-sync
result in-sync
show running-config devices device _DEVICE_20.5.30.13 | begin ssd
ios:cable profile ssd 1
  ssd 12.2.2.2 tftp xxx
!
ios:cable profile ssd 2
```

```
description ssd 2
ssd 10.1.1.1 tftp abc
```

The SSD configuration on NSO must be the same as with the Cisco cBR-8 router.

Check SSD using RestAPI

1. Get the SSD profiles, which are read by NSO from the Cisco cBR-8 router, use the **query-core-details** command.

```
https://{controller}://{new-port}/rpd-service-manager/rpdorch/v2/core-topology/query-core-details
```

Output:

SSD profile info must be the same as that with the Cisco cBR-8 router.

Input:

```
{
  "ipAddress": "10.0.0.1"
}
```

Result:

```
{
  "status": "Success",
  "coreList": [
    {
      "ipAddressList": [
        "10.0.0.1"
      ],
      "uuid": "_DEVICE_10.0.0.1",
      "gpsLocation": {},
      "hostName": "NG03.cisco.com",
      "interfacesList": [...],
      "virtualSGs": [],
      "ndfProfiles": {},
      "ndrProfiles": {},
      "ssdProfiles": [
        {
          "id": 1,
          "name": "xxx"
        },
        {
          "id": 2,
          "name": "abc"
        },
        {
          "id": 3,
          "name": "aaa"
        },
        {
          "id": 4,
          "name": "abcdef"
        },
        {
          "id": 5,
          "name": "abbbc"
        },
        {
          "id": 6,
          "name": "acde"
        },
        {

```

```

        "id": 7,
        "name": "xxx"
    },
    {
        "id": 9,
        "name": null
    },
    {
        "id": 10,
        "name": "abcc"
    }
],
"state": "ONLINE",
"productType": "CBR-8-CCAP-CHASS",
"swVersion": "16.10.1f",
"vendorName": "Cisco",
"protectedLC": -1
}
]
}

```

2. Check the RPD pairing details, use the **query-rpd-pairing** command.

<https://{{controller}}:{{new-port}}/rpd-service-manager/rpdorch/v2/rpd-pairing/query-rpd-pairing>

Output:

The value of `ssidProfileId` must be correct.

Input:

```
{
}
```

Result:

```
{
  "status": "Success",
  "rpdPairingRspList": [
    {
      "macAddress": "aabb11112124",
      "name": "1",
      "serviceTemplate": "C02",
      "approvalState": "Approved",
      "assignedCores": [
        {
          "serviceType": "Data",
          "mgmtCore": "C02.cisco.com",
          "rpdConnectionInterface": "TenGigabitEthernet7/1/0",
          "primaryUsPort": 1
        }
      ],
      "pairingChangeTimestamp": 1563823890549,
      "description": "",
      "state": "ResourceAllocationError",
      "gpsLocation": {
        "latitude": 77,
        "longitude": 99,
        "genericLocation": "Shanghai"
      },
      "ssidProfileId": 1
    }
  ],
  "nextFrom": null
}
```

3. Verify the SSD profile ID and the image name in the **Edit** window of the RPD pairing





table.



RPD Name	MAC	Se...	Service Definition	SSD Profile	Principal Core	Principal Cor...	DS Port	US Port	DS Data Service ...
RPD_0010	a222.2222.2210	1x1	Test_171	1 - test	sphy-c2.cisco.com	TenGigabitEthernet8/1/6	0	0	DS08

4. Verify whether the RPD Details contain the SSD command.

```

RPD CLI
[172.22.9.171 2020-12-06 17:42:43.823]
cable rpd RPD_0010
identifier a222.2222.2210
core-interface Te8/1/6
principal
rpd-ds 0 downstream-cable 8/0/20 profile 1
rpd-us 0 upstream-cable 8/0/4 profile 1
r-dti 1
rpd-event profile 0
ssid 1
cable fiber-node 5
downstream Downstream-Cable 8/0/20
downstream sg-channel 0 23 downstream-Cable 8/0/20 rf-channel 0 23
upstream Upstream-Cable 8/0/4
upstream sg-channel 0 3 upstream-Cable 8/0/4 us-channel 0 3
service-group managed md 0 Cable 8/0/4
service-group profile ram_SG1
[172.22.9.171 2020-12-02 11:28:09.528]
cable rpd RPD_0010
identifier a222.2222.2210
core-interface Te8/1/6
principal
rpd-ds 0 downstream-cable 8/0/20 profile 1
rpd-us 0 upstream-cable 8/0/4 profile 1
r-dti 1

```

Check SSD on Cisco cBR-8

Run the following command to check the SSD on the Cisco cBR-8 router.

```

cable rpd PRPD
identifier a0f8.496f.6506
type shelf
rpd-ds 0 base-power 25

```

```

rpd-ds 1 base-power 25
core-interface Te9/1/6
principal
rpd-ds 0 downstream-cable 9/0/16 profile 100
rpd-us 0 upstream-cable 9/0/1 profile 4
r-dti 2
rpd-event profile 0
ssd 1
rpd-55d1-us-event profile 0

```

Debug SSD on Cisco cBR-8

Use the following command to check the upgrading state on the Cisco cBR-8 router.

```
cable rpd xxxx.xxxx.xxxx ssd status
```

DEPI Latency Measurement in Service Template

If a Service Template is already in use, you can update only the DLM fields (Static delay, DLM sampling value, Measure Only) and the existing behavior is maintained for all other fields.

Following operations are allowed when Service Template is already in use:

- If there is no existing DLM configuration in the service template, you can add `network-delay static <delay-val>`, `network-delay dlm <interval>`, and `network-delay dlm <interval><measure-only>`.
If the `network-delay static <delay-val>` is configured in the service template, the user can modify the `<delay-val>` for static.
- If the `network-delay dlm <interval>` is configured in the service template, the user can modify the `dlm <interval>` and `<measure-only>` parameters.
- If the `network-delay dlm <interval><measure-only>` is configured in the service template, the user can modify only the `dlm <interval>`.

The RPD detailed information contains the DLM command.

Before you update a Service Definition, you should check whether any Cisco cBR-8 line cards are in a high availability state an active secondary line card.

The DLM configuration gets automatically applied to all RPDs assigned to the Service Definition. However, the RPD configuration is rejected if the Cisco cBR-8 line card for DOCSIS controllers is in high availability mode. In addition, because this operation might take more time, you may see a network connectivity issue.

After updating a Service Definition, you should check the RPD service manager logs for errors. To recover an RPD with a configuration rejection or error, do the following:

- If the secondary line card is active:
 1. Revert to the primary line card.
 2. Wait until the primary line card is active
- For each RPD with a configuration rejection or error:
 1. From the **RPD Assignment** page, click **Edit** for that RPD.

2. On the **Edit** page, click **Save**.

Check New DLM Configuration on Cisco cBR-8

```
cable rpd <RPD Name>
  identifier a0f8.496f.6506
  type shelf
  rpd-ds 0 base-power 25
  rpd-ds 1 base-power 25
  core-interface Te9/1/6
  principal
  rpd-ds 0 downstream-cable 9/0/16 profile 100
  rpd-us 0 upstream-cable 9/0/1 profile 4
  network-delay dlm 100
  r-dti 2
  rpd-event profile 0
  ssd 1
  rpd-55d1-us-event profile 0
!
```

