



# Start Up Configuration of the Cisco cBR Router

This document describes the basic start up configuration tasks that must be completed on a Cisco cBR Series Converged Broadband Router.

- [Prerequisites for Configuring the Cisco CMTS, on page 2](#)
- [Booting and Logging onto the Cisco CMTS , on page 3](#)
- [First Time Boot Up with ROMMON, on page 3](#)
- [Configuration Register, on page 4](#)
- [Setting Environment Variables, on page 5](#)
- [Unsetting Environment Variables, on page 5](#)
- [Booting from the TFTP on the Cisco cBR, on page 6](#)
- [Listing Supported Devices, on page 6](#)
- [Booting from the Device on the Cisco cBR, on page 7](#)
- [Setting AUTOBOOT image in ROMMON, on page 7](#)
- [Verifying the ROMMON Version, on page 8](#)
- [Resetting the Cisco cBR, on page 8](#)
- [Configuring PTP, on page 9](#)
- [File Systems, on page 15](#)
- [Verification of Hardware Bring Up, on page 15](#)
- [Gigabit Ethernet Management Interface Overview, on page 23](#)
- [Gigabit Ethernet Port Numbering, on page 23](#)
- [IP Address Handling in ROMMON and the Management Ethernet Port, on page 24](#)
- [Gigabit Ethernet Management Interface VRF, on page 24](#)
- [Common Ethernet Management Tasks, on page 24](#)
- [Viewing the VRF Configuration, on page 24](#)
- [Setting a Default Route in the Management Ethernet Interface VRF, on page 25](#)
- [Setting the Management Ethernet IP Address, on page 25](#)
- [Telnetting over the Management Ethernet Interface, on page 25](#)
- [Pinging over the Management Ethernet Interface, on page 25](#)
- [Copy Using TFTP or FTP, on page 26](#)
- [NTP Server, on page 26](#)
- [SYSLOG Server, on page 26](#)
- [SNMP-Related Services, on page 26](#)
- [Domain Name Assignment, on page 27](#)
- [DNS service, on page 27](#)

- [RADIUS or TACACS+ Server, on page 27](#)
- [VTY lines with ACL, on page 27](#)
- [Configuring the AUX Port for Network Management , on page 27](#)
- [Preprovisioning the Supervisor in the Cisco cBR Chassis, on page 28](#)
- [Configuring the Gigabit Ethernet Interface for Network Management, on page 28](#)
- [Configuring the DTI Port on the Supervisor PIC, on page 29](#)
- [Configuring the TenGigabit Ethernet Interface for Network Management , on page 30](#)
- [Connecting the New Router to the Network , on page 31](#)
- [Setting Password Protection on the Cisco CMTS, on page 32](#)
- [Recovering Lost Password on the Cisco CMTS, on page 32](#)
- [Saving Your Configuration Settings, on page 35](#)
- [Reviewing Your Settings and Configurations, on page 35](#)
- [Recovering Unresponsive Modems, on page 35](#)

## Prerequisites for Configuring the Cisco CMTS

Complete these prerequisite steps before you power on and configure the Cisco CMTS:

- Ensure that your network supports reliable broadband data transmission. Your plant must be swept, balanced, and certified based on National Television Standards Committee (NTSC) or appropriate international cable plant recommendations. Ensure your plant meets all Data-over-Cable Service Interface Specifications (DOCSIS) downstream and upstream radio frequency (RF) requirements.
- Ensure that your Cisco CMTS is installed according to the instructions in the hardware installation guide available on Cisco.com.
- Ensure that all other required headend or distribution hub routing and network interface equipment is installed, configured, and operational (based on the supported services). This includes:
  - All routers
  - Servers ( Dynamic Host Configuration Protocol (DHCP) servers, Trivial File Transfer Protocol (TFTP) servers, and time-of-day (ToD) servers)
  - Network management systems
  - Other configuration or billing systems
- Ensure that DHCP and DOCSIS configuration files have been created and pushed to appropriate servers so that each CM, when initialized, can:
  - Transmit a DHCP request
  - Receive an IP address
  - Obtain TFTP and ToD server addresses
  - Download a DOCSIS configuration file (or updated software image if using Cisco uBR924 cable access routers or Cisco uBR910 cable data service units (DSUs) in your network)
- Ensure that customer premises equipment (CPE)—CMs or set-top boxes (STBs), PCs, telephones, or facsimile machines—meet requirements for your network and service offerings.
- Be familiar with your channel plan to assign appropriate frequencies. Outline your strategies for setting up bundling, if applicable to your headend or distribution hub. As appropriate, obtain:
  - Passwords
  - IP addresses
  - Subnet masks

- Device names

After these prerequisites are met, you are ready to configure the Cisco CMTS. This includes, at a minimum:

- Configuring a host name and password for the Cisco CMTS
- Configuring the CMTS to support IP over the cable plant and network backbone



**Note** If you plan to use service-class-based provisioning, the service classes must be configured at the CMTS before CMs attempt to make a connection.



**Note** Do not configure the **logging event link-status** command during system initialization. It may take long time or even stop the standby SUP from booting up.

## Booting and Logging onto the Cisco CMTS

The Cisco CMTS is administered using the Cisco command interpreter, called the EXEC. You must boot and log in to the router before you can enter an EXEC command.

**Step 1** [Connect to the console port on the Supervisor PIC](#) and the [Supervisor card](#).

**Step 2** Establish a terminal session. You can open terminal application (Hyper Terminal) on a PC as follows:

- Connect using: Direct to Com 1
- Set bits per second:9600
- Set data bits: 8
- Set parity: none
- Set stop bit: 1
- Set flow control: none

Type **no** when the following message is displayed:

```
Would you like to enter the initial dialog?[yes]: no
Router>
```

## First Time Boot Up with ROMMON

The Cisco cBR-8 boots up with ROMMON on the console with 9600 baud default configuration. It boots image either from TFTP or from local device. Local devices supported include the bootflash and USB.

Example of the boot up display:

```
Initializing Hardware ...~
```

```

System Bootstrap, Version 15.5(2r)S, RELEASE SOFTWARE
Copyright (c) 1994-2015 by cisco Systems, Inc.

Current image running: Boot ROM0

Last reset cause: PowerOn

CPUID: 0x000206d7
UCODE: 0x00000710_00000000
Viper version register: 0x14121111
Set Chassis Type to 13RU
Cisco cBR-8 platform with 50331648 Kbytes of main memory

rommon 1 >

```

## Configuration Register

The **confreg** ROMMON command displays the configuration and allows modification of the settings.

```

rommon > confreg

          Configuration Summary
(Virtual Configuration Register: 0x0)
enabled are:
[ 0 ] break/abort has effect
[ 1 ] console baud: 9600
boot: ..... the ROM Monitor

do you wish to change the configuration? y/n [n]: y
enable "diagnostic mode"? y/n [n]:
enable "use net in IP bcast address"? y/n [n]:
enable "load rom after netboot fails"? y/n [n]:
enable "use all zero broadcast"? y/n [n]:
disable "break/abort has effect"? y/n [n]:
enable "ignore system config info"? y/n [n]:
change console baud rate? y/n [n]:
change the boot characteristics? y/n [n]:

          Configuration Summary
(Virtual Configuration Register: 0x0)
enabled are:
[ 0 ] break/abort has effect
[ 1 ] console baud: 9600
boot: ..... the ROM Monitor
do you wish to change the configuration? y/n [n]:
Console baud rate options:
change console baud rate? y/n [n]: y
0=9600, 1=4800, 2=1200, 3=2400, 4=19200, 5=38400, 6=57600, 7=115200
enter rate [0]:
Boot characteristics options:
change the boot characteristics? y/n [n]: y

enter to boot:
0 = ROM Monitor
1 = the boot helper image
2-15 = boot system
[0]:

```

## Setting Environment Variables

No Environment variables are required to boot the Cisco IOS-XE image.

There are variables set by default. The ROMMON command **set** displays the default variables.

```
rommon > set
PS1=rommon ! >
?=0
rommon >
```

To set a variable, the format is VARIABLE="value".

The **set** command displays the new variable and the **sync** command saves the variable to NVRAM.



---

**Note** If the variable value has a space in between, specify the value within quotes.

---

```
rommon > set
PS1=rommon ! >
?=0
rommon > IP_ADDRESS=1.2.3.4
rommon > IP_SUBNET_MASK=255.255.255.128
rommon > DEFAULT_GATEWAY=1.2.9.10
rommon > TFTP_SERVER=1.2.3.6
rommon > sync
```

## Unsetting Environment Variables

The **unset** ROMMON command removes the Environment variables and the **sync** command saves the variable to NVRAM.

```
rommon 1 > set
PS1=rommon ! >
?=0
BSI=0
BOOT=bootflash:cbrsup-adventerprisek9.SSA.bin,12;
RANDOM_NUM=1357042312
RET_2_RTS=17:45:06 PDT Sat Dec 31 2011
RET_2_RCALTS=1325378706
rommon 2 > unset BOOT
rommon 3 > sync
rommon 4 > set
PS1=rommon ! >
?=0
BSI=0
RANDOM_NUM=1357042312
RET_2_RTS=17:45:06 PDT Sat Dec 31 2011
RET_2_RCALTS=1325378706
rommon 5 >
```

## Booting from the TFTP on the Cisco cBR

ROMMON boots up with default environment variables. The BinOS image is booted up from TFTP over the management port. This requires a minimum set of environment variables: IP\_ADDRESS, IP\_SUBNET\_MASK, DEFAULT\_GATEWAY, and TFTP\_SERVER.

**Step 1** Type the **set** command and define the required environment variables.

```
rommon > set
PS1=rommon ! >
?=0
rommon > IP_ADDRESS=1.2.3.4
rommon > IP_SUBNET_MASK=255.255.255.128
rommon > DEFAULT_GATEWAY=1.2.9.10
rommon > TFTP_SERVER=1.2.3.6
rommon > sync
```

**Step 2** Type the **sync** command to save the variables to NVRAM.

```
rommon 6 > sync
```

**Step 3** Type the **boot** command to load the image.

```
rommon 7 > boot tftp://tftpboot/username/cbrsup-universalk9.SSA.bin

IP_ADDRESS: 1.2.3.4
IP_SUBNET_MASK: 255.255.255.128
DEFAULT_GATEWAY: 1.2.9.10
TFTP_SERVER: 1.2.3.6
TFTP_FILE: /tftpboot/username/cbrsup-universalk9.SSA.bin
TFTP_MACADDR: c4:14:3c:17:e8:00
TFTP_VERBOSE: Progress
TFTP_RETRY_COUNT: 18
TFTP_TIMEOUT: 7200
TFTP_CHECKSUM: Yes
ETHER_PORT: 2

ETHER_SPEED_MODE: Auto Detect
link up.....
Receiving /tftpboot/username/cbrsup-universalk9.SSA.bin from 172.19.211.47
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
```

## Listing Supported Devices

The **dev** command lists the devices supported on the router.

```
rommon 1 > dev
Devices in device table:
  id name
  harddisk: Internal hard disk
  bootflash: Internal flash drive
  usb0: External USB drive 0
```

```
usb1: External USB drive 1
rommon 2 >
```

## Booting from the Device on the Cisco cBR

**Step 1** Type the **dir bootflash:** command.

```
rommon > dir bootflash:
File System: EXT2/EXT3

12          691955580 -rw-r--r--      cbrsup-xe315.SSA.bin
45          83475     -rw-r--r--      reload.log.20120103004502
```

**Step 2** Type the **boot bootflash:imagenam** command.

```
rommon > boot bootflash:cbrsup-xe315.bin
File size is 0x293e67bc
Located cbrsup-xe315.bin
Image size 691955644 inode num 145153, bks cnt 168935 blk size 8*512
#####
```

## Setting AUTOBOOT image in ROMMON

To set AUTOBOOT of an image from bootflash:, add the Environment Variable BOOT and then change the configuration register boot characteristics to boot and reset the system.

**Step 1** Type the **boot=bootflash:imagenam** command to load the image.

```
rommon > BOOT=bootflash:cbrsup-xe315-20150131.bin
```

**Step 2** Type the **sync** command to copy the variables to NVRAM.

```
rommon > sync
```

**Step 3** Type the **confreg** command to configure and modify the settings.

```
rommon > confreg

Configuration Summary
(Virtual Configuration Register: 0x0)
enabled are:
[ 0 ] break/abort has effect
[ 1 ] console baud: 9600
boot: ..... the ROM Monitor

do you wish to change the configuration? y/n [n]: y
enable "diagnostic mode"? y/n [n]:
enable "use net in IP bcast address"? y/n [n]:
enable "load rom after netboot fails"? y/n [n]:
enable "use all zero broadcast"? y/n [n]:
```

```

disable "break/abort has effect"? y/n [n]:
enable "ignore system config info"? y/n [n]:
change console baud rate? y/n [n]: n
change the boot characteristics? y/n [n]: y

enter to boot:
0 = ROM Monitor
1 = the boot helper image
2-15 = boot system
[0]: 2

Configuration Summary
(Virtual Configuration Register: 0x2)
enabled are:
[ 0 ] break/abort has effect
[ 1 ] console baud: 9600
boot: ..... image specified by the boot system commands or default to: cisco2-Cisco cBR-8

do you wish to change the configuration? y/n [n]:

You must reset or power cycle for new config to take effect

```

**Step 4** Type the **reset** command for the new configuration to take effect.

```
rommon > reset
```

---

### What to do next

## Verifying the ROMMON Version

Use the **showmon** command to display the version of ROMMON.

```

rommon > showmon
Current image running (0/1): Boot ROM0
System Bootstrap, Version 15.5(2r)S, RELEASE SOFTWARE
Copyright (c) 1994-2015 by cisco Systems, Inc.

Viper version register: 0x14121111
rommon >

```

## Resetting the Cisco cBR

Use the **reset** command to soft reset the Supervisor.

```

rommon > reset

Resetting .....

Initializing Hardware ...^

System Bootstrap, Version 15.5(2r)S, RELEASE SOFTWARE
Copyright (c) 1994-2015 by cisco Systems, Inc.

```



```
Current image running: Boot ROM0

Last reset cause: LocalSoftware

CPUID: 0x000206d7
UCODE: 0x00000710_00000000
Viper version register: 0x14121111
Set Chassis Type to 13RU
Cisco cBR-8 platform with 50331648 Kbytes of main memory

rommon >
```

## Configuring PTP

The Cisco cBR supports Precision Time Protocol (PTP) boundary or ordinary clock (OC) subordinate mode when connected to the Ethernet ports of the DPIC card or Supervisor PIC card. This topic provides you with an overview of PTP, configuration options, commands to verify the configuration settings, and configuration examples.

Cisco cBR supports DPIC PTP subordinate configuration with the following restraints:

- Only subordinate mode is supported.
- Only one-step timestamping is supported

## Overview of PTP

PTP is a packet-based two-way message exchange protocol for synchronizing clocks between nodes in a network, thereby enabling an accurate time distribution over a network. PTP support is based on the IEEE 1588-2008 standard.


IEEE Standard 1588-2008 defines a method for distributing time around a network using the Precision Time Protocol (PTP) version 2. IEEE 1588-2008 is designed to provide precise timing and synchronization over packet-based ethernet infrastructures without layer-1 support along the clocking path. PTP ensures that the best available clock is selected as the source of time (the grandmaster clock) for the network and that other clocks in the network are synchronized to the grandmaster.

PTP consists of two parts:

- The port state machine and best primary clock algorithm, which provides a method to determine which ports in the network will run as primary (providing time to other clocks to the network), which will run as subordinate (receiving time from other clocks in the network), and which will be passive (neither primary nor subordinate).
- Mechanisms for subordinate ports to calculate the difference between the time of their own clocks and the time of their primary clock. To calculate the differences, PTP uses a delay request/response mechanism and a peer delay mechanism.

An overview of clock synchronization is explained.

Figure 1: Clock synchronization



After the primary-subordinate clock hierarchy is established, the clock synchronization process starts. The message exchange occurs in this sequence:

1. The primary clock sends a Sync message. The time at which the Sync message leaves the primary is time-stamped as t1.
2. The subordinate clock receives the Sync message and is time-stamped as t2.
3. The subordinate sends the Delay request, which is time-stamped as t3 when it leaves the subordinate, and as t4 when the primary receives it.
4. The primary responds with a Delay request that contains the time stamp t4.

PTP employs a hierarchy of clock types to ensure that precise timing and synchronization is maintained between the source and the numerous PTP clients that are distributed throughout the network. The clock types are:

- Grandmaster clock

This is the highest-ranking clock within its PTP domain. PTP grandmasters can be deployed as either standalone devices or as plug in modules or “blades” that can be integrated into an existing synchronization supply unit (SSU) or building integrated timing supply (BITS) shelf. Grandmasters are the primary reference source (PRS) for all other PTP elements within their PTP domain.

- Primary clock

A PTP primary will have a very precise clock, from a PRC or GPS. This clock drives the timestamp engine to derive accurate timestamps. The primary hosts PTP sessions with a number of subordinates.

- Subordinate clock

The subordinate is a network element that can recover the (Frequency and phase) clock from the timestamps obtained by messages exchanged with the PTP primary clock.

- Boundary clock

The Boundary clock acts as both PTP primary and subordinate. It will be a subordinate to a grandmaster and derive the reference from the grandmaster. It then starts its own PTP sessions with a number of

downstream subordinates. The advantage of placing a boundary clock is that it mitigates the number of network hops and resulting delays that occur in the packet network between the grandmaster and subordinates.

- Transparent clock

They maintain precise internal clocking by measuring the exact time difference between the packet entry and exit and the correction field of PTP packet is updated accordingly. Hence, the delay introduced by the node will not affect the PTP subordinate.

## Configuring a PTP Subordinate Through DPIC

### Before you begin

You can configure the PTP ports on Cisco cBR through the DPIC. An [Overview of PTP](#), on page 9 is essential to have an understanding of the utility.

### Procedure

|               | Command or Action   | Purpose |
|---------------|---|---------|
| <b>Step 1</b> | <p>Configure the PTP subordinate using any of the following options:</p> <ul style="list-style-type: none"> <li>• Subordinate mode with single source</li> </ul> <pre> config t  ptp clock ordinary domain &lt;domain id&gt;  servo tracking-type R-DTI  clock-port &lt;name&gt; slave  delay-req interval &lt; Interval&gt;  sync interval &lt; Interval&gt;  sync one-step  transport &lt;ipv4/ipv6&gt; unicast interface  &lt;loopback name&gt; negotiation  clock source &lt;clock ip&gt; </pre> <ul style="list-style-type: none"> <li>• Subordinate mode with single source with profile G8275.2</li> </ul> <pre> config t  ptp clock ordinary domain &lt;domain id&gt;  servo tracking-type R-DTI  clock-port &lt;name&gt; slave profile g8275.2  delay-req interval &lt; Interval&gt;  sync interval &lt; Interval&gt;  sync one-step  transport &lt;ipv4/ipv6&gt; unicast interface  &lt;loopback name&gt; negotiation  clock source &lt;clock ip&gt; </pre> <ul style="list-style-type: none"> <li>• Subordinate mode with multiple clock source</li> </ul> <pre> config t  ptp clock ordinary domain &lt;domain id&gt;  servo tracking-type R-DTI  clock-port &lt;name&gt; slave  delay-req interval &lt; Interval&gt;  sync interval &lt; Interval&gt; </pre> |         |

|  | Command or Action   | Purpose |
|--|---|---------|
|  | <pre> sync one-step transport &lt;ipv4/ipv6&gt; unicast interface &lt;loopback name&gt; negotiation clock source &lt;clock ip&gt; clock source &lt;clock ip&gt; &lt;local priority&gt;  • Subordinate mode with multiple clock source with profile G8275.2  config t ptp clock boundary domain &lt;domain id&gt; servo tracking-type R-DTI clock-port &lt;name&gt; profile g8275.2 delay-req interval &lt; Interval&gt; sync interval &lt; Interval&gt; sync one-step transport ipv6 unicast interface &lt;loopback name&gt; negotiation clock source &lt;clock ip&gt; clock-port &lt;name&gt; profile g8275.2 delay-req interval &lt; Interval&gt; sync interval &lt; Interval&gt; sync one-step transport ipv6 unicast interface &lt;loopback name&gt; negotiation clock source &lt;clock ip&gt; </pre> |         |

## Verifying the PTP Subordinate Configuration

You can verify the PTP subordinate configuration by going through the following steps.

### Procedure

|               | Command or Action   | Purpose |
|---------------|---|---------|
| <b>Step 1</b> | <p>Verify the PTP configuration by running the <b>show run   se ptp</b> command. For example:</p> <p><b>Example:</b></p> <pre> router# show run   se ptp ptp clock ordinary domain 55 servo tracking-type R-DTI clock-port slave-from-903 slave delay-req interval -5 sync interval -5 sync one-step transport ipv4 unicast interface Lo1588 negotiation clock source 10.90.3.93 </pre> |         |
| <b>Step 2</b> | <p>To verify the PTP clock working state, use the <b>show ptp clock running</b> command. The state “PHASE_ALIGNED”, confirms a successful locking. For example:</p> <p><b>Example:</b></p>  |         |

|  | Command or Action   | Purpose |
|--|---|---------|
|  | <pre> router# show ptp clock running PTP Ordinary Clock [Domain 55] State      Ports      Pkts sent      Pkts rcvd      Redundancy Mode PHASE_ALIGNED 1          68938          138822 Hot standby PORT SUMMARY PTP Master Name      Tx Mode      Role      Transport State      Sessions      Port Addr slave-from-903 unicast      slave      Lo1588 Slave      1            10.90.3.93 L06# </pre> |         |

## PTP Subordinate Configuration Examples

The PTP subordinate example configurations are as follows:

- PTP subordinate mode with ipv4

```

config t
ptp clock ordinary domain 0
servo tracking-type R-DTI
clock-port slave-from-903 slave
delay-req interval -5
sync interval -5
sync one-step
transport ipv4 unicast interface Lo1588 negotiation
clock source 10.90.3.93

```

- PTP subordinate mode with ipv6

```

config t
ptp clock ordinary domain 0
servo tracking-type R-DTI
clock-port slave-from-903 slave
delay-req interval -4
sync interval -5
sync one-step
transport ipv6 unicast interface Lo1588 negotiation
clock source ipv6 2001:10:90:3::93

```

- PTP subordinate mode with ipv4 with profile G8275.2

```

config t
ptp clock ordinary domain 55
servo tracking-type R-DTI
clock-port slave-from-903 slave profile g8275.2
delay-req interval -4
sync interval -5
sync one-step
transport ipv4 unicast interface Lo1588 negotiation
clock source 10.90.3.93

```

- PTP subordinate mode with ipv6 with profile G8275.2

```

config t
ptp clock ordinary domain 55
servo tracking-type R-DTI

```

```

clock-port slave-from-903 slave profile g8275.2
delay-req interval -4
sync interval -5
sync one-step
transport ipv6 unicast interface Lo1588 negotiation
clock source ipv6 2001:10:90:3::93

```

- PTP subordinate mode with ipv4 with 2 clock sources

```

config t
ptp clock ordinary domain 0
servo tracking-type R-DTI
clock-port slave-from-903 slave
delay-req interval -5
sync interval -5
sync one-step
transport ipv4 unicast interface Lo1588 negotiation
clock source 10.90.3.93
clock source 10.1.1.1 2

```

- PTP subordinate mode with ipv6 with 2 clock sources and with profile G8275.2

```

config t
ptp clock boundary domain 55
servo tracking-type R-DTI
clock-port 22 profile g8275.2
delay-req interval -4
sync interval -5
sync one-step
transport ipv6 unicast interface Lo1588 negotiation
clock source ipv6 2001:10:90:3::93
clock-port 33 profile g8275.2
delay-req interval -4
sync interval -5
sync one-step
transport ipv6 unicast interface Lo1588 negotiation
clock source ipv6 2001:158:158:158::7

```

## Feature Information for PTP Subordinate

Use Cisco Feature Navigator to find information about the platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to the <https://cfnng.cisco.com/> link. An account on the Cisco.com page is not required.



**Note** The following table lists the software release in which a given feature is introduced. Unless noted otherwise, subsequent releases of that software release train also support that feature.

**Table 1: Feature Information for PTP Subordinate Through DPIC**

| Feature Name                 | Releases                    | Feature Information  |
|------------------------------|-----------------------------|--|
| PTP Subordinate Through DPIC | Cisco IOS-XE Release 16.8.1 | This feature was introduced in Cisco IOS-XE Release 16.8.1 on Cisco cBR Series Converged Broadband Router. |

# File Systems

The Cisco cBR-8 router runs on the Cisco IOS-XE image. Supported file systems include:

1. IOS File System (IFS) in IOS
2. ext2, vfs, jffs2, tmpfs, autofs, and such common file systems in Linux

Features of the File Systems:

1. Both the Harddisk and USB are hot pluggable.
2. Harddisk is not accessible under Rommon.
3. Bootflash and USB disk are accessible under Rommon.
4. The **dir**, **show**, **copy**, **delete**, **mkdir**, **rmdir**, and **fsck** commands are supported for bootflash, harddisk and USB.

## File System Table in the Supervisor

| Name      | Device          | Size        | Type | Visible   | Usage                 | Physical Description                   |
|-----------|-----------------|-------------|------|-----------|-----------------------|--|
| bootflash | /dev/bootflash1 | 7800705024  | ext2 | IOS/Binos | image,IOScrasinfo,etc | Partition1 of bootflash (eUSB flash).  |
| flash     | /dev/bootflash1 | 7800705024  | ext2 | IOS       | image                 | A copy of bootflash.                   |
| nvrnm     | /dev/bootflash2 | 32M         | N/A  | IOS       | configuration, etc    | Partition2 of bootflash (eUSB flash).  |
| harddisk  | /dev/harddisk1  | 98394218496 | ext2 | IOS/Binos | tracelog,corefile,etc | Partition1 of the 100G harddisk.       |
| usb0      | /dev/usb11      | 8G          | vfat | IOS/Binos | image                 | Two USBs can be inserted into one SUP. |

# Verification of Hardware Bring Up

## Monitoring the Cisco cBR Chassis Using CLI

- **show platform**—Verify if the installed cards are in **Ok** or **Inserted** state.

```
Router# show platform
```

```
Chassis type: CBR-8-CCAP-CHASS
```

```

Slot      Type                State                Insert time (ago)
-----
1         CBR-CCAP-LC-40G    ok                   03:22:58
1/1      CBR-RF-PIC         ok                   03:19:40
SUP0     CBR-CCAP-SUP-160G inserted            03:22:58
R0       ok, active
F0       ok, active
4        ok, active
4/1     CBR-SUP-8X10G-PIC ok                   03:20:30

```

```

P0          PWR-2KW-DC-V2      ok          03:21:20
P1          PWR-2KW-DC-V2      ok          03:21:20
P2          PWR-2KW-DC-V2      ok          03:21:20
P3          PWR-2KW-DC-V2      ok          03:21:20
P4          PWR-2KW-DC-V2      ok          03:21:20
P5          PWR-2KW-DC-V2      ok          03:21:20
P10         CBR-FAN-ASSEMBLY    ok          03:21:10
P11         CBR-FAN-ASSEMBLY    ok          03:21:10
P12         CBR-FAN-ASSEMBLY    ok          03:21:10
P13         CBR-FAN-ASSEMBLY    ok          03:21:10
P14         CBR-FAN-ASSEMBLY    ok          03:21:10

```

- **show platform hardware slot *slot* serdes status**—Verify if all the links are in **locked** state.

```
Router# show platform hardware slot F1 serdes status
```

```

Slot R1-Link A
  RX link locked
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 3-Link A
  RX link locked
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 5-Link A
  RX link locked
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 5-Link B
  RX link locked
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 5-Link C
  RX link locked
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 5-Link D
  RX link locked
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 5-Link E
  RX link Init
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

```



```

Slot 5-Link F
  RX link Init
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 5-Link G
  RX link Init
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

Slot 5-Link H
  RX link Init
  58-bit scrambler, 20 Gbps
  0 Overruns, 0 Underruns
  0 Reframe, 0 Disparity
  0 Out of band, 0 Illegal control codes

```

- **show environment all**—Verify the environmental status of each FRU after installation.

This command displays the system temperature, voltage, fan, and power supply conditions.

```
Router# show environment all
```

```

Sensor List: Environmental Monitoring

```

| Sensor         | Location | State  | Reading    |
|----------------|----------|--------|------------|
| AVCC&1P2: Sens | 4/1      | Normal | 81 mV      |
| AVCC&1P2: Vin  | 4/1      | Normal | 12600 mV   |
| AVCC&1P2: ADin | 4/1      | Normal | 0 mV       |
| VP1P35: Sens   | 4/1      | Normal | 8 mV       |
| VP1P35: Vin    | 4/1      | Normal | 12650 mV   |
| VP1P35: ADin   | 4/1      | Normal | 112 mV     |
| VP1P0: Sens    | 4/1      | Normal | 15 mV      |
| VP1P0: Vin     | 4/1      | Normal | 12625 mV   |
| VP1P0: ADin    | 4/1      | Normal | 0 mV       |
| MGTAVTT: Sens  | 4/1      | Normal | 21 mV      |
| MGTAVTT: Vin   | 4/1      | Normal | 12625 mV   |
| MGTAVTT: ADin  | 4/1      | Normal | 0 mV       |
| VP1P8: Sens    | 4/1      | Normal | 41 mV      |
| VP1P8: Vin     | 4/1      | Normal | 12600 mV   |
| VP1P8: ADin    | 4/1      | Normal | 0 mV       |
| VP3P3: Sens    | 4/1      | Normal | 39 mV      |
| VP3P3: Vin     | 4/1      | Normal | 12625 mV   |
| VP3P3: ADin    | 4/1      | Normal | 0 mV       |
| Temp: RTMAC    | 4/1      | Normal | 34 Celsius |
| Temp: INLET    | 4/1      | Normal | 29 Celsius |
| Temp: OUTLET   | 4/1      | Normal | 27 Celsius |
| Temp: MAX6697  | 4/1      | Normal | 50 Celsius |
| Temp: TCXO     | 4/1      | Normal | 37 Celsius |
| Temp: SUP_OUT  | 4/1      | Normal | 49 Celsius |
| Temp: 3882_1 P | 4/1      | Normal | 44 Celsius |
| Temp: 3882_2 P | 4/1      | Normal | 39 Celsius |
| Temp: 3882_3 P | 4/1      | Normal | 39 Celsius |
| VP5P0: Sens    | 4/1      | Normal | 6 mV       |
| VP5P0: Vin     | 4/1      | Normal | 12650 mV   |
| VP5P0: ADin    | 4/1      | Normal | 0 mV       |
| VP1P8: Sens    | 4/1      | Normal | 33 mV      |
| VP1P8: Vin     | 4/1      | Normal | 12625 mV   |
| VP1P8: ADin    | 4/1      | Normal | 0 mV       |
| 3P3&1P0: Sens  | 4/1      | Normal | 24 mV      |
| 3P3&1P0: Vin   | 4/1      | Normal | 12625 mV   |

```

3P3&1P0: ADin      4/1      Normal      0 mV
Temp: INLET PD    4/1      Normal      27 Celsius
Temp: OUTLETPD   4/1      Normal      36 Celsius
Temp: 6697-DC    4/1      Normal      38 Celsius
Temp: PHYOUT     4/1      Normal      49 Celsius
Temp: PHYIN      4/1      Normal      38 Celsius
Temp: SSD        4/1      Normal      40 Celsius
Temp: SFP+       4/1      Normal      36 Celsius
Temp: 3882_1PD   4/1      Normal      42 Celsius
3882_PC1_0: VO    4/1      Normal      1198 mV
3882_PC1_1: VO    4/1      Normal      999 mV
3882_PC2_0: VO    4/1      Normal      998 mV
3882_PC3_0: VO    4/1      Normal      1349 mV
PSOC-PC1_0: VO    4/1      Normal      3300 mV
PSOC-PC1_1: VO    4/1      Normal      12590 mV
PSOC-PC1_2: VO    4/1      Normal      6997 mV
PSOC-PC1_3: VO    4/1      Normal      5000 mV
PSOC-PC1_4: VO    4/1      Normal      3299 mV
PSOC-PC1_5: VO    4/1      Normal      1000 mV
PSOC-PC1_6: VO    4/1      Normal      1010 mV
PSOC-PC1_7: VO    4/1      Normal      1801 mV
PSOC-PC1_8: VO    4/1      Normal      2000 mV
PSOC-PC1_9: VO    4/1      Normal      1198 mV
PSOC-PC1_10: V    4/1      Normal      1798 mV
PSOC-PC1_11: V    4/1      Normal      2500 mV
PSOC-PC1_12: V    4/1      Normal      1353 mV
PSOC-PC1_13: V    4/1      Normal      1223 mV
PSOC-PC1_14: V    4/1      Normal      592 mV
PSOC-PC1_15: V    4/1      Normal      596 mV
3882_PDC_0: VO    4/1      Normal      1000 mV
3882_PDC_1: VO    4/1      Normal      3300 mV
PSOC-DC1_0: VO    4/1      Normal      4998 mV
PSOC-DC1_1: VO    4/1      Normal      3280 mV
PSOC-DC1_2: VO    4/1      Normal      1005 mV
PSOC-DC1_3: VO    4/1      Normal      1801 mV
PSOC-DC1_4: VO    4/1      Normal      2500 mV
12_CUR: Sens     9        Normal      14 mV
12_CUR: Vin      9        Normal      12650 mV
12_CUR: ADin     9        Normal      267 mV
G0_CUR: Sens     9        Normal      69 mV
G0_CUR: Vin      9        Normal      12550 mV
G0_CUR: ADin     9        Normal      0 mV
G1_CUR: Sens     9        Normal      69 mV
G1_CUR: Vin      9        Normal      12575 mV
G1_CUR: ADin     9        Normal      0 mV
LB_CUR: Sens     9        Normal      11 mV
LB_CUR: Vin      9        Normal      12525 mV
LB_CUR: ADin     9        Normal      0 mV
Temp: CAPRICA    9        Normal      40 Celsius
Temp: BASESTAR   9        Normal      47 Celsius
Temp: RAIDER     9        Normal      45 Celsius
Temp: CPU        9        Normal      31 Celsius
Temp: INLET     9        Normal      25 Celsius
Temp: OUTLET     9        Normal      35 Celsius
Temp: DIGITAL    9        Normal      31 Celsius
Temp: UPX       9        Normal      29 Celsius
Temp: LEOBEN1    9        Normal      31 Celsius
Temp: LEOBEN2    9        Normal      35 Celsius
Temp: 3.3-18     9        Normal      43 Celsius
Temp: BS_1V      9        Normal      45 Celsius
Freq: 5338-49    9        Normal      0 MHz
Freq: 5338-52    9        Normal      0 MHz
Freq: 5338-89    9        Normal      0 MHz
3882_1_0: VOUT   9        Normal      3299 mV

```

|                |    |        |            |
|----------------|----|--------|------------|
| 3882_1_1: VOUT | 9  | Normal | 1800 mV    |
| 3882_2_0: VOUT | 9  | Normal | 2500 mV    |
| 3882_2_1: VOUT | 9  | Normal | 1199 mV    |
| 3882_3_0: VOUT | 9  | Normal | 1419 mV    |
| 3882_4_0: VOUT | 9  | Normal | 1350 mV    |
| 3882_5_0: VOUT | 9  | Normal | 1000 mV    |
| 3882_6_0: VOUT | 9  | Normal | 1021 mV    |
| 3882_7_0: VOUT | 9  | Normal | 1199 mV    |
| 3882_7_1: VOUT | 9  | Normal | 1000 mV    |
| 3882_8_0: VOUT | 9  | Normal | 1000 mV    |
| 3882_9_0: VOUT | 9  | Normal | 999 mV     |
| V2978: VSENSE0 | 9  | Normal | 0 mV       |
| V2978: VSENSE1 | 9  | Normal | 0 mV       |
| V2978: VSENSE2 | 9  | Normal | 0 mV       |
| V2978: VSENSE3 | 9  | Normal | 6000 mV    |
| V2978: VSENSE4 | 9  | Normal | 2400 mV    |
| V2978: VSENSE5 | 9  | Normal | 0 mV       |
| V2978: VSENSE6 | 9  | Normal | 6598 mV    |
| V2978: VSENSE7 | 9  | Normal | 4998 mV    |
| V2978: VIN     | 9  | Normal | 25218 mV   |
| PSOC_2_0: VOUT | 9  | Normal | 12582 mV   |
| PSOC_2_1: VOUT | 9  | Normal | 4985 mV    |
| PSOC_2_2: VOUT | 9  | Normal | 3256 mV    |
| PSOC_2_3: VOUT | 9  | Normal | 1982 mV    |
| PSOC_2_4: VOUT | 9  | Normal | 1990 mV    |
| PSOC_2_5: VOUT | 9  | Normal | 1782 mV    |
| PSOC_2_6: VOUT | 9  | Normal | 1793 mV    |
| PSOC_2_7: VOUT | 9  | Normal | 1786 mV    |
| PSOC_2_8: VOUT | 9  | Normal | 1483 mV    |
| PSOC_2_9: VOUT | 9  | Normal | 1193 mV    |
| PSOC_2_10: VOU | 9  | Normal | 995 mV     |
| PSOC_2_11: VOU | 9  | Normal | 987 mV     |
| PSOC_2_12: VOU | 9  | Normal | 994 mV     |
| PSOC_2_13: VOU | 9  | Normal | 707 mV     |
| PSOC_2_14: VOU | 9  | Normal | 592 mV     |
| PSOC_2_15: VOU | 9  | Normal | 593 mV     |
| LTC4261: Power | 9  | Normal | 340 Watts  |
| PEM Iout       | P0 | Normal | 5 A        |
| PEM Vout       | P0 | Normal | 55 V DC    |
| PEM Vin        | P0 | Normal | 202 V AC   |
| Temp: INLET    | P0 | Normal | 26 Celsius |
| Temp: OUTLET   | P0 | Normal | 48 Celsius |
| PEM Iout       | P1 | Normal | 6 A        |
| PEM Vout       | P1 | Normal | 55 V DC    |
| PEM Vin        | P1 | Normal | 204 V AC   |
| Temp: INLET    | P1 | Normal | 30 Celsius |
| Temp: OUTLET   | P1 | Normal | 53 Celsius |
| PEM Iout       | P2 | Normal | 3 A        |
| PEM Vout       | P2 | Normal | 55 V DC    |
| PEM Vin        | P2 | Normal | 204 V AC   |
| Temp: INLET    | P2 | Normal | 25 Celsius |
| Temp: OUTLET   | P2 | Normal | 51 Celsius |
| PSOC-MB2_0: VO | R0 | Normal | 12758 mV   |
| PSOC-MB2_1: VO | R0 | Normal | 4998 mV    |
| PSOC-MB2_2: VO | R0 | Normal | 7082 mV    |
| PSOC-MB2_3: VO | R0 | Normal | 3287 mV    |
| PSOC-MB2_4: VO | R0 | Normal | 989 mV     |
| PSOC-MB2_5: VO | R0 | Normal | 1047 mV    |
| PSOC-MB2_6: VO | R0 | Normal | 1500 mV    |
| PSOC-MB2_7: VO | R0 | Normal | 1800 mV    |
| PSOC-MB2_8: VO | R0 | Normal | 914 mV     |
| PSOC-MB2_9: VO | R0 | Normal | 885 mV     |
| PSOC-MB2_10: V | R0 | Normal | 994 mV     |
| PSOC-MB2_11: V | R0 | Normal | 989 mV     |

|              |       |    |        |          |
|--------------|-------|----|--------|----------|
| PSOC-MB2_12: | V     | R0 | Normal | 1479 mV  |
| PSOC-MB2_13: | V     | R0 | Normal | 989 mV   |
| PSOC-MB2_14: | V     | R0 | Normal | 984 mV   |
| PSOC-MB2_15: | V     | R0 | Normal | 890 mV   |
| PSOC-MB2_16: | V     | R0 | Normal | 2485 mV  |
| PSOC-MB2_17: | V     | R0 | Normal | 1346 mV  |
| PSOC-MB2_18: | V     | R0 | Normal | 1458 mV  |
| PSOC-MB2_19: | V     | R0 | Normal | 1208 mV  |
| PSOC-MB2_20: | V     | R0 | Normal | 1791 mV  |
| PSOC-MB2_21: | V     | R0 | Normal | 3293 mV  |
| PSOC-MB2_22: | V     | R0 | Normal | 3250 mV  |
| PSOC-MB2_23: | V     | R0 | Normal | 3284 mV  |
| PSOC-MB2_24: | V     | R0 | Normal | 4970 mV  |
| PSOC-MB2_25: | V     | R0 | Normal | 4451 mV  |
| PSOC-MB3_0:  | VO    | R0 | Normal | 4983 mV  |
| PSOC-MB3_1:  | VO    | R0 | Normal | 4979 mV  |
| PSOC-MB3_2:  | VO    | R0 | Normal | 1500 mV  |
| PSOC-MB3_3:  | VO    | R0 | Normal | 1192 mV  |
| PSOC-MB3_4:  | VO    | R0 | Normal | 705 mV   |
| PSOC-MB3_5:  | VO    | R0 | Normal | 752 mV   |
| PSOC-MB3_6:  | VO    | R0 | Normal | 579 mV   |
| PSOC-MB3_7:  | VO    | R0 | Normal | 1500 mV  |
| PSOC-MB3_8:  | VO    | R0 | Normal | 1501 mV  |
| PSOC-MB3_9:  | VO    | R0 | Normal | 1250 mV  |
| PSOC-MB3_10: | V     | R0 | Normal | 1247 mV  |
| PSOC-MB3_11: | V     | R0 | Normal | 1260 mV  |
| PSOC-MB3_12: | V     | R0 | Normal | 1038 mV  |
| PSOC-MB3_13: | V     | R0 | Normal | 1343 mV  |
| PSOC-MB3_14: | V     | R0 | Normal | 670 mV   |
| PSOC-MB3_15: | V     | R0 | Normal | 1800 mV  |
| PSOC-MB3_16: | V     | R0 | Normal | 908 mV   |
| PSOC-MB3_17: | V     | R0 | Normal | 823 mV   |
| PSOC-MB3_18: | V     | R0 | Normal | 992 mV   |
| PSOC-MB3_19: | V     | R0 | Normal | 984 mV   |
| PSOC-MB3_20: | V     | R0 | Normal | 1046 mV  |
| PSOC-MB3_21: | V     | R0 | Normal | 1192 mV  |
| PSOC-MB3_22: | V     | R0 | Normal | 1169 mV  |
| PSOC-MB3_23: | V     | R0 | Normal | 1187 mV  |
| PSOC-MB3_24: | V     | R0 | Normal | 1796 mV  |
| PSOC-MB3_25: | V     | R0 | Normal | 1792 mV  |
| PSOC-MB3_26: | V     | R0 | Normal | 1787 mV  |
| PSOC-MB3_27: | V     | R0 | Normal | 1034 mV  |
| 3882_MB1_0:  | VO    | R0 | Normal | 1001 mV  |
| 3882_MB1_1:  | VO    | R0 | Normal | 1022 mV  |
| 3882_MB2_0:  | VO    | R0 | Normal | 1197 mV  |
| 3882_MB3_0:  | VO    | R0 | Normal | 1045 mV  |
| 3882_MB3_1:  | VO    | R0 | Normal | 996 mV   |
| 3882_MB4_0:  | VO    | R0 | Normal | 898 mV   |
| 3882_MB5_0:  | VO    | R0 | Normal | 1348 mV  |
| 3882_MB6_0:  | VO    | R0 | Normal | 1350 mV  |
| 3882_MB6_1:  | VO    | R0 | Normal | 3297 mV  |
| 3882_MB7_0:  | VO    | R0 | Normal | 998 mV   |
| 3882_MB8_0:  | VO    | R0 | Normal | 1501 mV  |
| 3882_MB8_1:  | VO    | R0 | Normal | 1551 mV  |
| 3882_MB9_0:  | VO    | R0 | Normal | 999 mV   |
| 3882_MB9_1:  | VO    | R0 | Normal | 3296 mV  |
| 15301_1:     | VOOUT | R0 | Normal | 2500 mV  |
| 15301_2:     | VOOUT | R0 | Normal | 1200 mV  |
| 15301_3:     | VOOUT | R0 | Normal | 1200 mV  |
| AS_VRM: Sens |       | R0 | Normal | 40 mV    |
| AS_VRM: Vin  |       | R0 | Normal | 12725 mV |
| AS_VRM: ADin |       | R0 | Normal | 0 mV     |
| Y0_VRM: Sens |       | R0 | Normal | 23 mV    |
| Y0_VRM: Vin  |       | R0 | Normal | 12675 mV |

|                |    |        |            |
|----------------|----|--------|------------|
| Y0_VRM: ADin   | R0 | Normal | 380 mV     |
| CPU_VCC: Sens  | R0 | Normal | 6 mV       |
| CPU_VCC: Vin   | R0 | Normal | 12725 mV   |
| CPU_VCC: ADin  | R0 | Normal | 0 mV       |
| 5P0_BIAS: Sens | R0 | Normal | 19 mV      |
| 5P0_BIAS: Vin  | R0 | Normal | 12700 mV   |
| 5P0_BIAS: ADin | R0 | Normal | 0 mV       |
| 7P0_BIAS: Sens | R0 | Normal | 45 mV      |
| 7P0_BIAS: Vin  | R0 | Normal | 12725 mV   |
| 7P0_BIAS: ADin | R0 | Normal | 0 mV       |
| 1P0_AA: Sens   | R0 | Normal | 37 mV      |
| 1P0_AA: Vin    | R0 | Normal | 12700 mV   |
| 1P0_AA: ADin   | R0 | Normal | 0 mV       |
| 1P0_RT: Sens   | R0 | Normal | 16 mV      |
| 1P0_RT: Vin    | R0 | Normal | 12725 mV   |
| 1P0_RT: ADin   | R0 | Normal | 0 mV       |
| 1P2: Sens      | R0 | Normal | 37 mV      |
| 1P2: Vin       | R0 | Normal | 12675 mV   |
| 1P2: ADin      | R0 | Normal | 0 mV       |
| 0P9_T0: Sens   | R0 | Normal | 7 mV       |
| 0P9_T0: Vin    | R0 | Normal | 12750 mV   |
| 0P9_T0: ADin   | R0 | Normal | 0 mV       |
| 1P05_CPU: Sens | R0 | Normal | 11 mV      |
| 1P05_CPU: Vin  | R0 | Normal | 12700 mV   |
| 1P05_CPU: ADin | R0 | Normal | 0 mV       |
| 1P0_CC: Sens   | R0 | Normal | 16 mV      |
| 1P0_CC: Vin    | R0 | Normal | 12700 mV   |
| 1P0_CC: ADin   | R0 | Normal | 0 mV       |
| 1P35_DDR: Sens | R0 | Normal | 6 mV       |
| 1P35_DDR: Vin  | R0 | Normal | 12725 mV   |
| 1P35_DDR: ADin | R0 | Normal | 0 mV       |
| 1P35_RLD: Sens | R0 | Normal | 0 mV       |
| 1P35_RLD: Vin  | R0 | Normal | 12675 mV   |
| 1P35_RLD: ADin | R0 | Normal | 2047 mV    |
| 3P3_CCC: Sens  | R0 | Normal | 16 mV      |
| 3P3_CCC: Vin   | R0 | Normal | 12700 mV   |
| 3P3_CCC: ADin  | R0 | Normal | 1375 mV    |
| 1P0_R: Sens    | R0 | Normal | 29 mV      |
| 1P0_R: Vin     | R0 | Normal | 12700 mV   |
| 1P0_R: ADin    | R0 | Normal | 0 mV       |
| 1P5_A0: Sens   | R0 | Normal | 41 mV      |
| 1P5_A0: Vin    | R0 | Normal | 12700 mV   |
| 1P5_A0: ADin   | R0 | Normal | 0 mV       |
| 1P5: Sens      | R0 | Normal | 34 mV      |
| 1P5: Vin       | R0 | Normal | 12675 mV   |
| 1P5: ADin      | R0 | Normal | 0 mV       |
| 2P5: Sens      | R0 | Normal | 5 mV       |
| 2P5: Vin       | R0 | Normal | 12700 mV   |
| 2P5: ADin      | R0 | Normal | 0 mV       |
| 1P8_A: Sens    | R0 | Normal | 10 mV      |
| 1P8_A: Vin     | R0 | Normal | 12675 mV   |
| 1P8_A: ADin    | R0 | Normal | 947 mV     |
| 1P0_BV: Sens   | R0 | Normal | 24 mV      |
| 1P0_BV: Vin    | R0 | Normal | 12700 mV   |
| 1P0_BV: ADin   | R0 | Normal | 0 mV       |
| 3P3: Sens      | R0 | Normal | 16 mV      |
| 3P3: Vin       | R0 | Normal | 12725 mV   |
| 3P3: ADin      | R0 | Normal | 0 mV       |
| 1P2_B: Sens    | R0 | Normal | 41 mV      |
| 1P2_B: Vin     | R0 | Normal | 12725 mV   |
| 1P2_B: ADin    | R0 | Normal | 0 mV       |
| ADM1075: Power | R0 | Normal | 329 Watts  |
| Temp: Y0_DIE   | R0 | Normal | 33 Celsius |
| Temp: BB_DIE   | R0 | Normal | 29 Celsius |

```

Temp: VP_DIE      R0      Normal      26 Celsius
Temp: RT-E_DIE   R0      Normal      31 Celsius
Temp: INLET_1    R0      Normal      23 Celsius
Temp: INLET_2    R0      Normal      22 Celsius
Temp: OUTLET_1   R0      Normal      25 Celsius
Temp: 3882_1     R0      Normal      46 Celsius
Temp: 3882_1A    R0      Normal      43 Celsius
Temp: 3882_1B    R0      Normal      43 Celsius
Temp: 3882_2     R0      Normal      41 Celsius
Temp: 3882_2A    R0      Normal      40 Celsius
Temp: 3882_2B    R0      Normal      41 Celsius
Temp: 3882_3     R0      Normal      37 Celsius
Temp: 3882_3A    R0      Normal      34 Celsius
Temp: 3882_3B    R0      Normal      33 Celsius
Temp: 3882_4     R0      Normal      46 Celsius
Temp: 3882_4A    R0      Normal      38 Celsius
Temp: 3882_4B    R0      Normal      35 Celsius
Temp: 3882_5     R0      Normal      32 Celsius
Temp: 3882_5A    R0      Normal      23 Celsius
Temp: 3882_5B    R0      Normal      23 Celsius
Temp: 3882_6     R0      Normal      37 Celsius
Temp: 3882_6A    R0      Normal      30 Celsius
Temp: 3882_6B    R0      Normal      32 Celsius
Temp: 3882_7     R0      Normal      38 Celsius
Temp: 3882_7A    R0      Normal      35 Celsius
Temp: 3882_7B    R0      Normal      35 Celsius
Temp: 3882_8     R0      Normal      47 Celsius
Temp: 3882_8A    R0      Normal      45 Celsius
Temp: 3882_8B    R0      Normal      41 Celsius
Temp: 3882_9     R0      Normal      37 Celsius
Temp: 3882_9A    R0      Normal      33 Celsius
Temp: 3882_9B    R0      Normal      32 Celsius
Temp: 8314_1     R0      Normal      40 Celsius
Temp: 8314_2     R0      Normal      36 Celsius
Temp: 3536_1A    R0      Normal      26 Celsius
Temp: 3536_1B    R0      Normal      26 Celsius
Temp: 15301_1A   R0      Normal      31 Celsius
Temp: 15301_1B   R0      Normal      32 Celsius
Temp: 15301_2A   R0      Normal      28 Celsius
Temp: 15301_2B   R0      Normal      34 Celsius
Temp: 15301_3A   R0      Normal      38 Celsius
Temp: 15301_3B   R0      Normal      45 Celsius
Temp: AS_DIE     R0      Normal      70 Celsius
Temp: XPT1_DTL   R0      Normal      42 Celsius
Temp: XPT1_DTR   R0      Normal      42 Celsius
Temp: XPT1_DBL   R0      Normal      42 Celsius
Temp: XPT1_DBR   R0      Normal      42 Celsius
Temp: XPT2_DTL   R0      Normal      42 Celsius
Temp: XPT2_DTR   R0      Normal      42 Celsius
Temp: XPT2_DBL   R0      Normal      42 Celsius
Temp: XPT2_DBR   R0      Normal      42 Celsius
Temp: XPT3_DTL   R0      Normal      42 Celsius
Temp: XPT3_DTR   R0      Normal      42 Celsius
Temp: XPT3_DBL   R0      Normal      42 Celsius
Temp: XPT3_DBR   R0      Normal      42 Celsius
Freq: MAX3674    R0      Normal      500 MHz
Freq: SQ420D     R0      Normal      24 MHz

```

- **show facility-alarm status** —Verify the chassis status.

```
Router# show facility-alarm status
```

```
System Totals Critical: 4 Major: 1 Minor: 8
```

| Source                                   | Time                 | Severity | Description [Index] |
|--|----------------------|----------|---------------------|
| -----                                    | -----                | -----    | -----               |
| slot 3/0<br>OIR Alarm [0]                | Apr 13 2015 16:25:58 | CRITICAL | Active Card Removed |
| Power Supply Bay 3<br>Module Missing [0] | Apr 13 2015 13:41:56 | CRITICAL | Power Supply/FAN    |
| Power Supply Bay 4<br>Module Missing [0] | Apr 13 2015 13:41:56 | CRITICAL | Power Supply/FAN    |
| Power Supply Bay 5<br>Module Missing [0] | Apr 13 2015 13:41:56 | CRITICAL | Power Supply/FAN    |
| Cable3/0/15-US0<br>Down [0]              | Apr 13 2015 17:32:53 | MINOR    | Physical Port Link  |
| Cable3/0/15-US1<br>Down [0]              | Apr 13 2015 17:32:53 | MINOR    | Physical Port Link  |
| Cable3/0/15-US2<br>Down [0]              | Apr 13 2015 17:32:53 | MINOR    | Physical Port Link  |
| Cable3/0/15-US3<br>Down [0]              | Apr 13 2015 17:32:53 | MINOR    | Physical Port Link  |
| Cable3/0/15-US4<br>Down [0]              | Apr 13 2015 17:32:53 | MINOR    | Physical Port Link  |

## Gigabit Ethernet Management Interface Overview

The purpose of this interface is to allow users to perform management tasks on the router; it is basically an interface that should not and often cannot forward network traffic but can otherwise access the router, often via Telnet and SSH, and perform most management tasks on the router.

The following aspects of the Management Ethernet interface should be noted:

- Each SUP has a Management Ethernet interface, but only the active SUP has an accessible Management Ethernet interface (the standby SUP can be accessed using the console port, however).
- IPv4, IPv6, and ARP are the only routed protocols supported for the interface.
- The interface provides a method of access to the router even when some software processes are down.
- The Ethernet Management Interface cannot be used as a Lawful Intercept MD source interface.
- The Management Ethernet interface is part of its own VRF.

## Gigabit Ethernet Port Numbering

The Gigabit Ethernet Management port is always GigabitEthernet0.

In a dual SUP configuration, the Management Ethernet interface on the active SUP will always be Gigabit Ethernet 0, while the Management Ethernet interface on the standby SUP will not be accessible using the Cisco IOS-XE CLI in the same telnet session. The standby SUP can be telnetted to through the console port, however.

The port can be accessed in configuration mode like any other port on the Cisco cBR Series Routers:

```
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#interface gigabitethernet0
Router(config-if)#
```

# IP Address Handling in ROMMON and the Management Ethernet Port

Assuming the IOS-XE process has not begun running on the Cisco cBR Series Router, the IP address that was set in ROMMON acts as the IP address of the Management Ethernet interface. In cases where the IOS-XE process is running and has taken control of the Management Ethernet interface, the IP address specified when configuring the Gigabit Ethernet 0 interface in the IOS-XE CLI becomes the IP address of the Management Ethernet interface. The ROMMON-defined IP address is only used as the interface address when the IOS-XE process is inactive.

For this reason, the IP addresses specified in ROMMON and in the IOS-XE CLI can be identical and the Management Ethernet interface will function properly in single SUP configurations.

In dual SUP configurations, however, users should never configure the IP address in the ROMMON on either SUP0 or SUP1 to match each other or the IP address as defined by the IOS-XE CLI. Configuring matching IP addresses introduces the possibility for an active and standby Management Ethernet interface having the same IP address with different MAC addresses, which will lead to unpredictable traffic treatment.

## Gigabit Ethernet Management Interface VRF

Placing the management Ethernet interface in its own VRF has the following effects on the Management Ethernet interface:

- Many features must be configured or used inside the VRF, so the CLI may be different for certain Management Ethernet functions on the Cisco cBR Series Routers than on Management Ethernet interfaces on other routers.
- The VRF prevents route leakage and avoids unnecessary traffic through the management port.

The Management Ethernet interface VRF supports both IPv4 and IPv6 address families.

## Common Ethernet Management Tasks

Because users can perform most tasks on a router through the Management Ethernet interface, many tasks can be done by accessing the router through the Management Ethernet interface.

This section documents tasks that might be common or slightly tricky on the Cisco cBR Series Routers. It is not intended as a comprehensive list of all tasks that can be done using the Management Ethernet interface.

## Viewing the VRF Configuration

The VRF configuration for the Management Ethernet interface is viewable using the **show running-config vrf** command.

This example shows the default VRF configuration:

```
Router# show running-config vrf
```



```
Building configuration...

Current configuration : 351 bytes
vrf definition Mgmt-intf
!
address-family ipv4
exit-address-family
!
address-family ipv6
exit-address-family
!
(some output removed for brevity)
```

## Setting a Default Route in the Management Ethernet Interface VRF

To set a default route in the Management Ethernet Interface VRF, use the **ip route vrf Mgmt-intf 0.0.0.0 0.0.0.0 next-hop-IP-address** command.

## Setting the Management Ethernet IP Address

The IP address of the Management Ethernet port is set like the IP address on any other interface.

Below are two simple examples of configuring an IPv4 address and an IPv6 address on the Management Ethernet interface.

### IPv4 Example

```
Router(config)# interface GigabitEthernet 0
Router(config-if)# ip address A.B.C.D A.B.C.D
```

### IPv6 Example

```
Router(config)# interface GigabitEthernet 0
Router(config-if)# ipv6 address X:X:X:X::X /prefix-length
```

## Telnetting over the Management Ethernet Interface

Telnetting can be done through the VRF using the Management Ethernet interface.

In the following example, the router telnets to 172.17.1.1 through the Management Ethernet interface VRF:

```
Router# telnet 172.17.1.1 /vrf Mgmt-intf
```

## Pinging over the Management Ethernet Interface

Pinging other interfaces using the Management Ethernet interface is done through the VRF.

In the following example, the router pings the interface with the IP address of 172.17.1.1 through the Management Ethernet interface:

```
Router# ping vrf Mgmt-intf 172.17.1.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.17.1.1, timeout is 2 seconds:
.!!!!
Success rate is 80 percent (4/5), round-trip min/avg/max = 1/1/1 ms
```

## Copy Using TFTP or FTP

To copy a file using TFTP through the Management Ethernet interface, the **ip tftp source-interface GigabitEthernet 0** command must be entered before entering the **copy tftp** command because the **copy tftp** command has no option of specifying a VRF name.

Similarly, to copy a file using FTP through the Management Ethernet interface, the **ip ftp source-interface GigabitEthernet 0** command must be entered before entering the **copy ftp** command because the **copy ftp** command has no option of specifying a VRF name.

### TFTP Example

```
Router(config)# ip tftp source-interface gigabitEthernet 0
```

### FTP Example

```
Router(config)# ip ftp source-interface gigabitEthernet 0
```

## NTP Server

To allow the software clock to be synchronized by a Network Time Protocol (NTP) time server over the Management Ethernet interface, enter the **ntp server vrf Mgmt-intf** command and specify the IP address of the device providing the update.

The following CLI provides an example of this procedure.

```
Router(config)# ntp server vrf Mgmt-intf 172.17.1.1
```

## SYSLOG Server

To specify the Management Ethernet interface as the source IP or IPv6 address for logging purposes, enter the **logging host ip-address vrf Mgmt-intf** command.

The following CLI provides an example of this procedure.

```
Router(config)# logging host ip-address vrf Mgmt-intf
```

## SNMP-Related Services

To specify the Management Ethernet interface as the source of all SNMP trap messages, enter the **snmp-server source-interface traps gigabitEthernet 0** command.

The following CLI provides an example of this procedure:

```
Router(config)# snmp-server source-interface traps gigabitEthernet 0
```

## Domain Name Assignment

The IP domain name assignment for the Management Ethernet interface is done through the VRF.

To define the default domain name as the Management Ethernet VRF interface, enter the **ip domain-name vrf Mgmt-intf domain** command.

```
Router(config)# ip domain-name vrf Mgmt-intf cisco.com
```

## DNS service

To specify the Management Ethernet interface VRF as a name server, enter the **ip name-server vrf Mgmt-intf IPv4/IPv6 address** command.

## RADIUS or TACACS+ Server

To group the Management VRF as part of a AAA server group, enter the **ip vrf forward Mgmt-intf** command when configuring the AAA server group.

The same concept is true for configuring a TACACS+ server group. To group the Management VRF as part of a TACACS+ server group, enter the **ip vrf forwarding Mgmt-intf** command when configuring the TACACS+ server group.

### RADIUS Server Group Configuration

```
Router(config)# aaa group server radius hello
Router(config-sg-radius)# ip vrf forwarding Mgmt-intf
```

### TACACS+ Server Group Configuration

```
Router(config)# aaa group server tacacs+ hello
Router(config-sg-tacacs)# ip vrf forwarding Mgmt-intf
```

## VTY lines with ACL

To ensure an access control list (ACL) is attached to vty lines that are and are not using VRF, use the **vrf-also** option when attaching the ACL to the vty lines.

```
Router(config)# line vty 0 4
Router(config-line)# access-class 90 in vrf-also
```

## Configuring the AUX Port for Network Management

- 
- Step 1** AUX port is used for IOSd command prompt. Type the **set** command at the rommon prompt.
- Step 2** Verify if **BOOT\_PARAM** is defined. It must not be defined.

- Step 3** If the `BOOT_PARAM` is defined, do the following:
- Type `unset BOOT_PARAM`.
  - Type `sync`.
  - Type `reset`.
- Step 4** Boot with the latest image. The AUX port will show IOS command prompt.

## Preprovisioning the Supervisor in the Cisco cBR Chassis

Preprovisioning on the Cisco cBR allows you to configure the Supervisors without their physical presence in the chassis.

### Procedure

|               | Command or Action  | Purpose   |
|---------------|--|---|
| <b>Step 1</b> | <code>enable</code><br><b>Example:</b><br>Router> <code>enable</code>  | Enables privileged EXEC mode.<br>Enter your password if prompted.   |
| <b>Step 2</b> | <code>configure terminal</code><br><b>Example:</b><br>Router# <code>configure terminal</code>                    | Enters global configuration mode.   |
| <b>Step 3</b> | <code>card slot/1 sup-pic-8x10g</code><br><b>Example:</b><br>Router(config)# <code>card 4/1 sup-pic-8x10g</code> | Preprovisions the Supervisor in the Cisco cBR chassis. <ul style="list-style-type: none"> <li><code>slot</code>—Identifies the chassis slot number for the Supervisor PIC. The valid values are 4 and 5.</li> </ul> |

## Configuring the Gigabit Ethernet Interface for Network Management

You must configure the GigabitEthernet0 interface and enable it to use the NME port.

### Procedure

|               | Command or Action   | Purpose   |
|---------------|---|---|
| <b>Step 1</b> | <code>enable</code><br><b>Example:</b><br>Router> <code>enable</code> | Enables privileged EXEC mode.<br>Enter your password if prompted. |
| <b>Step 2</b> | <code>configure terminal</code><br><b>Example:</b>                    | Enters global configuration mode.                                 |

|                | Command or Action  | Purpose  |
|----------------|--|--|
|                | Router# <code>configure terminal</code>  |  |
| <b>Step 3</b>  | <b>interface GigabitEthernet0</b><br><b>Example:</b><br>Router(config)# <code>interface GigabitEthernet0</code>                    | Enters the Gigabit Ethernet interface configuration mode.  |
| <b>Step 4</b>  | <b>vrf forwarding vrf-name</b><br><b>Example:</b><br>Router(config-if)# <code>vrf forwarding Mgmt-intf</code>                      | Associates a Virtual Routing and Forwarding (VRF) instance with the interface. <ul style="list-style-type: none"> <li>• <i>vrf-name</i>—The interface name to be associated with the specified VRF.</li> </ul>                         |
| <b>Step 5</b>  | <b>ip address ip-address subnet-mask</b><br><b>Example:</b><br>Router(config-if)# <code>ip address 192.71.0.1 255.255.255.0</code> | Sets the IP address of the Gigabit Ethernet interface. <ul style="list-style-type: none"> <li>• <i>ip-address</i>—IP address of the Gigabit Ethernet interface.</li> <li>• <i>subnet -mask</i>—Subnet mask for the network.</li> </ul> |
| <b>Step 6</b>  | <b>no shutdown</b><br><b>Example:</b><br>Router(config-if)# <code>no shutdown</code>   | Enables the Gigabit Ethernet interface.  |
| <b>Step 7</b>  | <b>speed 1000 [negotiate]</b><br><b>Example:</b><br>Router(config-if)# <code>speed 1000</code>                                     | Configures the speed for the Gigabit Ethernet interface.   |
| <b>Step 8</b>  | <b>duplex full</b><br><b>Example:</b><br>Router(config-if)# <code>duplex full</code>   | Configures full duplex operation on the Gigabit Ethernet interface.  |
| <b>Step 9</b>  | <b>negotiation auto</b><br><b>Example:</b><br>Router(config-if)# <code>negotiation auto</code>                                     | Selects the auto-negotiation mode.   |
| <b>Step 10</b> | <b>end</b><br><b>Example:</b><br>Router(config-if)# <code>end</code>   | Exits Gigabit Ethernet interface configuration mode. Returns to privileged EXEC mode.  |

## Configuring the DTI Port on the Supervisor PIC

The Cisco cBR router can run in standalone mode, which uses internal clock and does not require any external reference clock source. The Cisco cBR router also supports DTI server as an external clocking source. To use a DTI server as a reference clock source, you must enable the DTI port on the Supervisor PIC.

## Procedure

|               | Command or Action   | Purpose   |
|---------------|---|---|
| <b>Step 1</b> | <b>enable</b><br><b>Example:</b><br>Router> <b>enable</b>                           | Enables privileged EXEC mode.<br>Enter your password if prompted. |
| <b>Step 2</b> | <b>configure terminal</b><br><b>Example:</b><br>Router# <b>configure terminal</b>   | Enters global configuration mode.                                 |
| <b>Step 3</b> | <b>cable clock dti</b><br><b>Example:</b><br>Router(config)# <b>cable clock dti</b> | Configures the DTI clock reference mode for the Supervisor PIC.   |

## Configuring the TenGigabit Ethernet Interface for Network Management

You must configure the TenGigabitEthernet interface and enable it to use the NME port.

## Procedure

|               | Command or Action  | Purpose   |
|---------------|--|---|
| <b>Step 1</b> | <b>enable</b><br><b>Example:</b><br>Router> <b>enable</b>  | Enables privileged EXEC mode.<br>Enter your password if prompted.             |
| <b>Step 2</b> | <b>configure terminal</b><br><b>Example:</b><br>Router# <b>configure terminal</b>  | Enters global configuration mode.   |
| <b>Step 3</b> | <b>interface TenGigabitEthernet</b><br><b>Example:</b><br>Router(config)# <b>interface TenGigabitEthernet4/1/0</b>               | Enters the TenGigabit Ethernet interface configuration mode.                  |
| <b>Step 4</b> | <b>ip address <i>ip-address subnet-mask</i></b><br><b>Example:</b><br>Router(config-if)# <b>ip address 1.2.3.4 255.255.255.0</b> | Sets the IP address of the TenGigabit Ethernet interface.                     |
| <b>Step 5</b> | <b>load-interval <i>seconds</i></b><br><b>Example:</b><br>Router(config-if)# <b>load-interval 30</b>                             | Changes the length of time for which data is used to compute load statistics. |

|        | Command or Action   | Purpose  |
|--------|---|--|
| Step 6 | <b>no shutdown</b><br><b>Example:</b><br>Router(config-if) # <b>no shutdown</b> | Enables the TenGigabit Ethernet interface.   |
| Step 7 | <b>end</b><br><b>Example:</b><br>Router(config-if) # <b>end</b>                 | Exits TenGigabit Ethernet interface configuration mode. Returns to privileged EXEC mode. |

## Connecting the New Router to the Network

Connect the new router to the network using a n Ethernet interface. After the router successfully resolves its host name, new router sends a TFTP broadcast requesting the file name-config or name.cfg. The router name must be in all lowercase, even if the true host name is not. The file is downloaded to the new router, where the configuration commands take effect immediately. If the configuration file is complete, the new router should be fully operational.

To save the complete configuration to NVRAM, use the following commands in privileged EXEC mode:

### Procedure

|        | Command or Action                         | Purpose  |
|--------|---|--|
| Step 1 | <b>enable password</b>                    | Enters privileged mode on the new router.  |
| Step 2 | <b>copy running-config startup-config</b> | <p>Saves the information from the name-config file into your startup configuration. On most platforms, this step saves the configuration to NVRAM.</p> <p><b>Note</b> Verify that the existing and new routers (or access servers) are connected before entering the <b>copy running-config startup-config</b> EXEC command to save configuration changes. Use the <b>ping</b> EXEC command to verify connectivity. If an incorrect configuration file is downloaded, the new router will load NVRAM configuration information before it can enter AutoInstall mode.</p> <p>If the configuration file is a minimal configuration file, the new router comes up, but with only one interface operational. Use the following commands to connect to the new router and configure it.</p> |
| Step 3 | <b>telnet existing</b>                    | Establishes a Telnet connection to the existing router.  |
| Step 4 | <b>telnet newrouter</b>                   | From the existing router, establishes a Telnet connection to the new router.   |

|        | Command or Action | Purpose  |
|--------|-------------------|--|
| Step 5 | enable password   | Enters privileged EXEC mode.                   |
| Step 6 | setup             | Enters setup mode to configure the new router. |

## Setting Password Protection on the Cisco CMTS



**Note** For security purposes, the EXEC has two levels of access to commands: user EXEC mode and privileged EXEC mode. The commands available at the user level are a subset of those available at the privileged level.



**Tip** Because many privileged-level EXEC commands are used to set operating parameters, password-protect these commands to prevent unauthorized use.



**Note** An enable secret password can contain from 1 to 25 uppercase and lowercase alphanumeric characters. An enable password can contain any number of uppercase and lowercase alphanumeric characters. A number cannot be the first character. Spaces are valid password characters; for example, “two words” is a valid password. Leading spaces are ignored. Trailing spaces are recognized. Alphanumeric characters are recognized as uppercase or lowercase.

Passwords should be different for maximum security. If you enter the same password for both during the setup script, the system accepts it, but you receive a warning message indicating that you should enter a different password.

At the EXEC prompt, enter one of the following two commands to set password protection:

- **enable secret password**—a very secure encrypted password.
- **enable**—is a less secure and nonencrypted password.

To gain access to privileged-level commands, enter the desired password.

## Recovering Lost Password on the Cisco CMTS

Complete the following steps to recover or replace a lost enable, enable secret, or console login password:

- 
- Step 1** Attach an ASCII terminal to the console port on your Cisco CMTS.
- Step 2** Configure the terminal to operate at 9600 baud, 8 data bits, no parity, and 1 stop bits.
- Step 3** If you can log in to the router as a nonprivileged user, enter the **show version** command to display the existing configuration register value. Note the value for later use. If you cannot log in to the router at all, continue with the next step.



- Step 4** Press the **Break** key or send a **Break** from the console terminal.
- If Break is enabled, the router enters the ROM monitor, indicated by the ROM monitor prompt (rommon n>), where n is the number of the command line. Proceed to configuring the register.
  - If Break is disabled, power cycle the router (turn the router off or unplug the power cord, and then restore power). Within 60 seconds of restoring the power to the router, press the **Break** key or send a **Break**. This action causes the router to enter the ROM monitor and display the ROM monitor prompt (rommon 1>).

- Step 5** To set the configuration register on a Cisco CMTS, use the configuration register utility by entering the **confreg** command at the ROM monitor prompt as follows:

```
rommon 1> confreg
```

Answer **yes** to the *enable ignore system config info?* prompt and note the current configuration register settings.

- Step 6** Initialize the router by entering the **reset** command as follows:

```
rommon 2> reset
```

The router initializes, the configuration register is set to 0x142, the router boots the system image from Flash memory and enters the System Configuration dialog (setup), as follows:

```
--- System Configuration Dialog ---
```

- Step 7** Enter **no** in response to the System Configuration dialog prompts until the following message appears:

```
Press RETURN to get started!
```

- Step 8** Press **Return**. The user EXEC prompt appears as follows:

```
Router>
```

- Step 9** Enter the **enable** command to enter privileged EXEC mode.

- Step 10** Enter the **show startup-config** command to display the passwords in the configuration file as follows:

```
Router# show startup-config
```

- Step 11** Scan the configuration file display looking for the passwords; the enable passwords are usually near the beginning of the file, and the console login or user EXEC password is near the end. The passwords displayed will look something like this:

```
enable secret 5 $1$ORPP$s9syZt4uKn3SnpuLDrhuei
enable password 23skiddoo
.
.
line con 0
 password onramp
```

**Note** The enable secret password is encrypted and cannot be recovered; it must be replaced. The enable and console passwords can be encrypted text or clear text.

Proceed to the next step to replace an enable secret, console login, or enable password. If there is no enable secret password, note the enable and console login passwords if they are not encrypted and proceed to set the configuration register to the original value.

**Caution** Do not perform the next step unless you have determined that you must change or replace the enable, enable secret, or console login passwords. Failure to follow the steps as presented here could cause your router configuration to be erased.

**Step 12** (Optional) Enter the `configure memory` command to load the startup configuration file into running memory. This action allows you to modify or replace passwords in the configuration.

```
Router# configure memory
```

**Step 13** Enter the `configure terminal` command for configuration mode:

```
Router# configure terminal
```

**Step 14** To change all three passwords, enter the following commands:

```
Router(config)# enable secret newpassword1  
Router(config)# enable password newpassword2  
Router(config)# line con 0  
Router(config)# password newpassword3
```

Change only the passwords necessary for your configuration. You can remove individual passwords by using the `no` form of the previous commands. For example, entering the `no enable secret` command removes the enable secret password.

**Step 15** You must configure all interfaces to not be administratively shut down as follows:

```
Router(config)# interface gigabitethernet 0  
Router(config)# no shutdown
```

Enter the equivalent commands for all interfaces that were originally configured. If you omit this step, all interfaces are administratively shut down and unavailable when the router is restarted.

**Step 16** Use the `config-register` command to set the configuration register to the original value noted earlier.

**Step 17** Press `Ctrl-Z` or type `end` to exit configuration mode:

```
Router(config)# end
```

**Caution** Do not perform the next step unless you have changed or replaced a password. If you skipped changing or replacing the enable, enable secret, or console login passwords previously, then proceed now to reload. Failure to observe this sequence causes the system to erase your router configuration file.

**Step 18** Enter the `copy running-config startup-config` command to save the new configuration to nonvolatile memory:

```
Router# copy running-config startup-config
```

**Step 19** Enter the `reload` command to reboot the router:

```
Router# reload
```

**Step 20** Log in to the router with the new or recovered passwords.

---

## Saving Your Configuration Settings

To store the configuration or changes to your startup configuration in NVRAM, enter the **copy running-config startup-config** command at the *Router#* prompt.

This command saves the configuration settings you set using configuration mode, the Setup facility, or AutoInstall.



---

**Note** If you do not save your settings, your configuration will be lost the next time you reload the router.

---

### Example

```
Router# copy running-config startup-config
```

## Reviewing Your Settings and Configurations

- To view the current configuration of a Cisco CMTS, run the **show running-config** command at the command-line interface (CLI) prompt in EXEC mode or privileged EXEC mode.
- To review changes you make to the configuration, use the EXEC **show startup-config** command to display the information stored in NVRAM.

## Recovering Unresponsive Modems

If the cable modem does not respond to pings from the Cisco Converged Broadband Router, the modem DSBG, DSID, and the BPI index values on the Cisco Converged Broadband Router may be incorrect. To recover the unresponsive modem, run the **cable reconciliation enable** command to generate the correct DSBG, DSID, and the BPI index values. The following CLI provides an example of this procedure:

```
Router# configure terminal
Router# cable reconciliation enable
Router# end
```

To set the time when the **cable reconciliation enable** command should run, run the **cable reconciliation time hours** command, where *hours* is the time in the 24 hour format. The following CLI provides an example of this procedure:

```
Router# configure terminal
Router# cable reconciliation time 23
Router# end
```

