

Cisco Cloud Native Broadband Router Diagnosis

The Cisco cnBR provides a suite of in-built tools to diagnose and resolve common issues.

- Cable Modem Diagnosis Tool, on page 1
- Cable Modem Troubleshooting, on page 3
- Cisco cnBR Dashboards, on page 8
- KPI Alert Management, on page 44
- Customize Kibana Queries and Data Visualization, on page 52
- Log Aggregation and Management, on page 53

Cable Modem Diagnosis Tool

In a Data-over-Cable Systems Interface Standard (DOCSIS) environment, various elements can affect a modem's ability to maintain a connection and remain online. When a cable modem goes offline, it is difficult to diagnose the cause and identify the issues.

The Cisco cnBR includes a Cable Modem Diagnosis Tool to enable easy diagnosis of such issues. Checkpoints are created periodically for online modems, where information such as system logs, configuration details, and system statistics are saved. When a cable modem goes offline, this system information is analyzed from the saved checkpoints.

The Cable Modem Diagnosis Tool supports the following modes:

- On-demand mode: System logs related to a modem is collected with a single click, when needed.
- **Background mode**: Logs, health metrics and performance metrics are actively analyzed in the background to detect, diagnose, and report modem issues.

The Cable Modem Diagnosis Tool provides the following utilities:

- Detect malfunctioning modems.
- Enable debugging for malfunctioning modems and disable debugging when modems are recovered.
- Supports interactive enabling or disabling of per modem debugging.
- Display modem logs and telemetry on the Grafana dashboard.
- Download of modem logs containing modem log messages.

Configure Cable Modem Diagnosis Tool for On-Demand Diagnosis

On-Demand diagnosis allows debugging a cable modem from the Cisco Operations Hub dashboard. On-Demand diagnosis does not require any configuration changes.

Complete the following steps to enable On-Demand Diagnosis:

- Step 1 Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **Dashboard** to open the **Dashboard** page.
- **Step 4** Click **Find a Dashboard** to open the search pane.
- Step 5 Enter Cable Modem Verbose in the Search dashboards by name field and click the Cable Modem Verbose row to open the Cable Modem Verbose dashboard.
- **Step 6** Select the Cisco cnBR name and modem that you want to debug from the **cnBR Name** and **Cable Modem** drop-down lists.
- Step 7 Click Cable Modem Log From cnBR pane.
- Step 8 Click Debug.
- **Step 9** Click **Disable** to disable debugging.

Configure Cable Modem Diagnosis Tool for Background Diagnosis

The Background diagnosis utility runs periodically, and detects malfunctioning modems. The utility runs automatically in the background, and is enabled by default.

Using the Background diagnosis method, debug functions that collect modem logs are enabled. Complete the following steps to view the logs:

- Step 1 Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **Dashboard** to open the **Dashboard** page.
- **Step 4** Click **Find a Dashboard** to open the search pane.
- **Step 5** Enter **diagnosis** in the **Search dashboards by name** field and click the **Diagnosis** row to open the **Diagnosis** dashboard.

The debugging information is available in the **Diagnosis Job Summary**, **cnBR Debug CMD Control**, and **Cable Modem Online Anomaly Detection Job** tables.

Step 6 To view detailed information about these tables, expand the tables and click the **i** icon at the top-left corner.

Cable Modem Troubleshooting

The table lists the features, the Cisco cnBR version in which it was introduced, and also gives a short description of the feature.

Table 1: Feature History

Feature Name	Release Information	Feature Description
Cable modem troubleshooting	Cisco cnBR 20.3	The Cisco Operations Hub allows you to collect troubleshooting information for cable modems on-demand. You can also retrieve troubleshooting information that the Cisco Operations Hub automatically collects when it detects L3 ping failure.
Per-CM debugging through a single location	Cisco cnBR 20.4	The Cisco Operations Hub allows you to get more cable modem debug information from Cisco cnBR.

This section describes how to:

- Collect troubleshooting information for cable modems on-demand.
- Retrieve troubleshooting information that the Cisco Operations Hub automatically collects when it detects L3 ping failure.

The cnBR Manager gathers troubleshooting information from the Cisco cnBR on-demand and automatically. L3 ping failure detection triggers automatic gathering of troubleshooting information. The troubleshooting information includes a task ID, the cable modem MAC address, and results. Results include troubleshooting information that the cnBR Manager collects from different cnBR services. Troubleshooting information is saved in the debug_info field of the logs. Currently you can receive troubleshooting information for Ranging, Vector Packet Processor (VPP), Baseline Privacy Interface (BPI), Ping, and Data Plane Vector Packet Processor (DP-VPP).

On-Demand Generation of Troubleshooting Information

To generate on-demand troubleshooting information, complete the following steps:

- **Step 1** Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **Dashboard** to open the **Dashboard** page.
- **Step 4** Click **Find a Dashboard** to open the search pane.
- **Step 5** Enter Cable Modem Verbose in the Search dashboards by name field and click the Cable Modem Verbose row to open the Cable Modem Verbose dashboard.
- Step 6 Click Troubleshoot.

器 cnBR Manager / Ca	able Modem Verbose 👒) 🕞 🕑 Las	tt 1 hour v 🛛 🖓 10s v	•
cnBR Name cnBR_209 ~	cnBR ID 172.22.64.209.nip	.io ~	Cable Modem 001e.6bfc.	f324 ~									
cnBR Cluster > Cable N	vlodem Verbose												
Reset Delete	Troubleshoot												
i Cable Mod	lem Basic Info	i	Cable Modem R	NG Info		. 1	i Cable Mo	oden	n OFDM Info	ż	Cable Mo	dem Other Info	
MAC	001e.6bfc.f324		MaxCMPwr(1/100				OFDM Prof				DOCSIS Version	DOC3.0	
State	init(d)		MaxCMPwr(Norm) -				OFDM Unfit Prof(s)		-		Operational Version	DOC3.0	
SG Name	SG2VoiceConfig		MaxChPwr(1/100 d				OFDM MRC		-		QoS Version	DOC1.1	
SG	2		MaxChPwr(Norm)				OFDMA MTC		-		Sys Desc	-	
MD	1		Neq(1.6MHz TxCh)				OFDM Prof Supp		-		Net Access Disable	false	
IP	0.0.0.0		MinPwrLoad(1/100				OFDM QAM Mod		-		DBC Req Count	-	
IPv6			MinPwrLoad(Norm)				OFDMA QAM Mod		-		DBC Res OK	-	
VRF			Min DRW(1/4 dBmV) -				RxMER		Display		DBC Ack Count		
Prim SID	5		Min DRW(Norm) -								Ext Pktlen Capability	-	1
RCP	00 00 00 00 00		Max DRW(1/4 dBmV)								DS Lowerband Edge	-	
Prim DS CH	17		Max DRW(Norm) -								DS Upperband Edge		
DS CH	17	i	Ca	able Modem Sta	ate History				ŝ.		Cable Modem CPE List		
Init US CH	5		Time 🕶	State	Prim D	S CH	Init US CH		search		Search		~
US CH	5		2021-06-22 11:41:15	init(rc)	17		5						368
Prim DS SFID	10005		2021-06-22 11:41:15	init(d)	17		5						521898

Wait for the Troubleshoot button to turn from In Progress.. to Save.

Step 7 Click Save to save the TroubleshootingLogs-<mac-address>.txt file.

Example:

The following example is a sample output file: troubleshootingLogs-0053.5577.190c.txt

```
{
        "data": {
            "id": "f5d7fdd6-628b-4da8-917f-2487e3b8a640",
            "cm mac": "0053.5577.190c",
            "result": {
                "root_cause_analysis": "",
                "details": [
                    {
                        "service_name": "vswitch-vpp",
                        "root cause": "",
                        "debug_info": {
                            "log": "All interfaces are up"
                        }
                    },
                    {
                        "service name": "cmts-cp-bpi",
                        "root_cause": "",
                        "debug_info": {
                            "well known":
"{\"MacAddrStr\":\"0053.5577.190c\",\"SvcGrpID\":0,\"MacDomainID\":0,\"PrimSID\":3,\"BpiCurrKeySeq\":1,
\"BpiNextKeySeq\":2,
\"BpiOddKey\":\"ZbFZ/JfHIm4Hr+hZuD+j3Q==\",\"BpiOddIV\":\"efW3mAAKUwBBpjYtVC25Pw==\",
\"BpiEvenKey\":\"n6IfiC3JLxeV4LF5vOWA4g==\",
                                             \"BpiEvenIV\":\"SqqQOTaXpHVJi2D62Ci0ZQ==\"}"
                         }
                    },
                    {
                        "service name": "cmts-rt-ranging",
                        "root cause": "",
                        "debug info": {
```

\"Timinge Adjust\":1,\"Power Adjust\":0,\"Frequency Adjust\":561}, {\"Result\":\"!\", \"Time Elapsed\":13, \"Timinge Adjust\":1, \"Power Adjust\":0,\"Frequency Adjust\":585},{\"Result\":\"!\",\"Time Elapsed\":46,\"Timinge Adjust\":1,\"Power Adjust\":0,\"Frequency Adjust\" :571}]},{\"Id\":\"47474871-00fb-42fd-ba31-002c52b4ebc6\",\"Create Time\":\"2020-12-03 00:04:29.751182788 +0000 UTC m=+5253.045249807\", \"SG ID\":0,\"MD ID\":0,\"MAC Addr\":\"0053.5577.190c\",\"US Channel ID\":3,\"Repeat\":5,\"Verbose\":true,\"Done\":true,\"Hit\":5,\"Results\" :[{\"Result\":\"!\",\"Time Elapsed\":18,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":-7}, {\"Result\":\"!\",\"Time Elapsed\":13, \"Timinge Adjust\":0, \"Power Adjust\":-50, \"Frequency Adjust\":9},{\"Result\":\"!\",\"Time Elapsed\":12,\"Timinge Adjust\":0, \"Power Adjust\":-50,\"Frequency Adjust\":2},{\"Result\":\"!\",\"Time Elapsed\":13,\"Timinge Adjust\":0,\"Power Adjust\":-50, \"Frequency Adjust\":-12}, {\"Result\":\"!\",\"Time Elapsed\":46,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":2}]}, {\"Id\": \"ddb18370-d5b7-4063-9041-4b943bbcd0ab\",\"Create Time\":\"2020-12-03 00:04:29.751212482 +0000 UTC m=+5253.045279492\",\"SG ID\":0,\"MD ID\":0, \"MAC Addr\":\"0053.5577.190c\\",\"US Channel ID\":1,\"Repeat\":5,\"Verbose\":true,\"Done\":true,\"Hit\":5,\"Results\":[{\"Result\":\"!\", \"Time Elapsed\":18,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":415}, {\"Result\":\"!\",\"Time Elapsed\":13, \"Timinge Adjust\":0, \"Power Adjust\":0,\"Frequency Adjust\":419},{\"Result\":\"!\",\"Time Elapsed\":12,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\" :424}, {\"Result\":\"!\",\"Time Elapsed\":14,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":368},{\"Result\":\"!\", \"Time Elapsed\":47, \"Timinge Adjust\":0, \"Power Adjust\":0, \"Frequency Adjust\":424}]}, {\"Id\":\"b5273f03-5d79-4fe6-b8d3-0b054019357f\", \"Create Time\":\"2020-12-03 00:04:29.751218964 +0000 UTC m=+5253.045285972\",\"SG ID\":0,\"MD ID\":0,\"MAC Addr\":\"0053.5577.190c\", \"US Channel ID\":0, \"Repeat\":5, \"Verbose\":true, \"Hit\":5, \"Results\": [{\"Result\":\"!\", \"Time Elapsed\":18, \"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":251}, {\"Result\":\"!\", \"Time Elapsed\":14, \"Timinge Adjust\":0, \"Power Adjust\" :0, \"Frequency Adjust \":270}, { \"Result \": \"! \", \"Time Elapsed\":11,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":283}, {\"Result\":\"!\",\"Time Elapsed\":13,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":275}, {\"Result\":\"!\",\"Time Elapsed\" :47,\"Timinge Adjust\":0,\"Power Adjust\":0,\"Frequency Adjust\":234}]}]}", "well known": "{\"MacAddrIeee\":\"ACUuLXJ+\", "SvcGrpID\":0, \"MacDomainID\":0, \"PrimSID\":3, \"MacState\":25, \"MD-DS-SG-ID\":1, \"MD-US-SG-ID\":1,\"RnqIxchList\":[{\"USChID\":3,\"RnqQueue\":\"SIATION MIN Q\",\"RnqIxchState\":\"IXCH SI SIA MIN\",\"RnqPwrIevelReported\" :132, \"RngDynPwrWindow\":72, \"RngIxchSWR\":451850, \"RngIxchDataMER\":16777215}, {\"UsChID\":1, \"RngDueue\":\"SIATION MIN Q\", \"RngIxchState\" :\"IXCH SI SIA MIN\",\"RngPwrlevelReported\":132,\"RngDynPwrWindow\":72,\"RngIxchSNR\":420410,\"RngIxchDataMER\":16777215},{\"UsChID\":0,

\"RngQueue\":\"STATION MIN Q\", \"RngTxchState\":\"TXCH ST STA MIN\", \"RngPwrLevelReported\":130, \"RngDynPwrWindow\":74, \"RngTxchSNR\"

"show cmd": "{\"Ping

Addr\":\"0053.5577.190c\",\"US Channel ID\":2,\"Repeat\":5,\"Verbose\":true,

Adjust\":50,\"Frequency Adjust\":598},{\"Result\":\"!\",\"Time Elapsed\":12,

Elapsed\":18,\"Timinge Adjust\":1,\"Power Adjust\":0,\"Frequency Adjust\":583},

Results\":[{\"Id\":\"8f30cf6e-39cd-4a3b-a159-2f8816bd8580\",\"Create Time\":\"2020-12-03

+0000 UTC m=+5253.045291365\",\"SG ID\":0,\"MD ID\":0,\"MAC

\"Done\":true,\"Hit\":5,\"Results\":[{\"Result\":\"!\",\"Time

{\"Result\":\"!\",\"Time Elapsed\":14,\"Timinge Adjust\":1,\"Power

00:04:29.751224356

:420410, \"RngTxchDataMER\":16777215}, {\"USCHID\":2, \"RngQueue\":\"STATION MIN Q\", \"RngTxchState\":\"TXCH ST STA MIN\", \"RngPwrLevelReported\":129,\"RngDynPwrWindow\":75,\"RngTxchSNR\":420410,\"RngTxchDataMER\":16777215}]}" } }, "service name": "cmts-ping", "root cause": "", "debug_info": { "log": "{\"minRtt\":17,\"maxRtt\":65425,\"avgRtt\":289,\"sent\":240,\"received\":240,\"MAC Addr\":\"0053.5577.190c\", \"CmMacIeee\":\"ACUuLXJ+\",\"SvcGrp\":0,\"MacDomain\":0}", "well_known": "{\"MacAddrStr\":\"0053.5577.190c\",\"MacAddrIeee\":\"ACUuLXJ+\",\"SvcGrpID\":0,\"MacDomainID\":0}" } }, { "service name": "cmts-dp-macl3vpp-global", "root cause": "", "debug info": { "show cmd": "{\"drop_stats\":{\"name\":\"Global Drop Stats\",\"per cause drops\":[{\"id\":11,\"cause\":\"icpi inject bad cause\"},

{\"id\":27,\"cause\":\"cbl_fld_no_members\"}, {\"id\":56,\"cause\":\"dsmac_invalid_gg\"}]}, \"usmac_depi_stats\":{\"data_pw_uepi_pkt_ont\"

:298,\"data_pw_uepi_byte_cnt\":42822,\"rng_pw_uepi_pkt_cnt\":56,\"rng_pw_uepi_byte_cnt\":9408,\"uepi_phy_burst_cnt\":354,\

"total ccf seg cnt\":298,\"ccf seg no hcserr cnt\":298,\"pre30 doc no hcserr cnt\":56,\"sm rng good pkt cnt\":56}}"

```
},
{
    "service_name": "cmts-dp-macl3vpp-per-cm",
    "root_cause": "",
    "debug_info": {
        "show_cmd":
    }
}
```

"{\"dtrack_stats\":{\"dtrack_mac_addr\":\"00:25:2e:2d:72:7e\",\"dtrack_time_start\":1606953869,\"dtrack_time_stop\":1606953990,

\"dtrack epoch in\":3,\"dtrack epoch curr\":3,\"dtrack us input\":248,\"dtrack us xmit\":248,\"dtrack ds input\":248,\"dtrack ds xmit\":248,\"

\"srv flow stats\":[{\"id\":3,\"direction\":\"US\",\"pkts cnt\":248,\"bytes cnt\":15792,\"duration seconds\":120,\"throughput pps\":1050},

{\"id\":10003,\"direction\":\"DS\",\"pkts cnt\":248,\"bytes cnt\":15280,\"duration seconds\":120,\"throughput pps\":1016}]}"

}
}

/

/
status": 200,
"config": {
 "method": "GET",
 "transformRequest": [
 null
}

}

}

```
],
"transformResponse": [
    null
],
"jsonpCallbackParam": "callback",
"url": "https://opshubl.cisco.com/api/manager/v1/cable-modems/0053.5577.190c/debug",
"headers": {
    "Accept": "application/json, text/plain, */*"
    }
},
"statusText": "OK",
"xhrStatus": "complete"
```

Automatic Generation of Troubleshooting Information

When the cnBR Manager detects a cable modem ping failure, the cnBR Manager generates a request to get troubleshooting information from the Cisco cnBR. cnBR Manager stores the troubleshooting information responses that it receives from the Cisco cnBR.

- **Step 1** Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **Dashboard** to open the **Dashboard** page.
- **Step 4** Click **Find a Dashboard** to open the search pane.
- **Step 5** Enter **Cable Modem Verbose** in the **Search dashboards by name** field and click the **Cable Modem Verbose** row to open the **Cable Modem Verbose** dashboard.
- **Step 6** In the **Cable Modem** drop-down list, select the target cable modem MAC address.

This page lists the occurrences of L3 ping loss with timestamp.

Cable Modem IP Ping-Loss History				
Time 🔻		RTT	IP Loss	
2021-06-22 11:52:03		-	100.0%	
2021-06-22 11:51:03		-	100.0%	
2021-06-22 11:50:03		-	100.0%	
2021-06-22 11:49:03		-	100.0%	
	1 2 3 4 5	6 7 8 9		

Note You can view the top ten modems with IPv4 ping-loss from the **Top 10 IPv4 Ping-Loss Modems** panel in the **Service Group** dashboard.

https://<hostname>/opshub-data/api/idocsis/v1/idm/cm-debug/tasks

Step 7 Open the following link in a browser, or use the curl command to send a GET request.

Find the target cable modem using the MAC address to get the troubleshooting information.

Example:

https://opshubl.cisco.com/opshub-data/api/idocsis/v1/idm/cm-debug/tasks

Or

```
hostname#curl -k -L -X GET 'https://opshubl.cisco.com/opshub-data/api/idocsis/v1/idm/cm-debug/tasks'
```


See example in Step 3 for a sample response.

Step 8 Find the target cable modem MAC address, and ping failure timestamp from the information to get troubleshooting information for the ping failure.

Example:

In the following example, we can see the debug result for the cable modem 0053.2ed0.84a6.

Figure 1: JSON Data from a Cisco cnBR Response




Note If time zone settings are different, the time that is displayed in the cnBR Manager interface and the time in the Cisco cnBR response are different. The time stamp in the Cisco cnBR response is always in Greenwich Mean Time (GMT).

Cisco cnBR Dashboards

The **Dashboards** menu in the Cisco Operations Hub allows you to monitor the status of the Cisco cnBR router. Cisco Operations Hub receives metrics and telemetry data from Cisco cnBR. Based on the type of data, the data is saved in the Postgres or Prometheus databases. The dashboards later retrieve and display the data.


The following illustration shows the Dashboards framework.



Cisco cnBR Dashboards

The Grafana dashboard displays metrics and status of the DOCSIS network, DOCSIS devices, and CMTS performance status. The dashboard is based on a hierarchical structure, which matches the Cisco cnBR system deployment exactly.


The following illustration shows the hierarchical layout:



The Dashboard user interface (UI) has the following components:

Breadcrumbs Bar

The breadcrumbs bar is available on each dashboard. It shows the dashboard pages just visited. You click each link in the breadcrumbs and go to that specific dashboard.



Links

Links are marked using an underline. You click the underlined text and open the related page.

Cable Modern 👻	IPv4	IPv6	State
8011.1100.003b	•		init(rc)
3011.1100.003a	•	-	offline
8011.1100.0039	•		init(rc)
8011.1100.0037			init(rc)
8011.1100.0035			init(rc)
8011.1100.0034	90.90.7.200		w-online
8011.1100.0033			offline
8011.1100.0030			init(r2)
8011.1100.002f			init(rc)
8011.1100.002d	-	-	w-online


Tooltips

Tooltips are available on the dashboard to display information for each panel on the Grafana dashboard. To view a tooltip, hover your mouse over the \pm on the top-left corner of the panel.




Dashboard Refresh and Time Range

To set the refresh time for each dashboard, choose the time from the drop-down list on the top-right corner of the dashboard. The default refresh-time for the dashboard is 10 seconds.



If data is retrieved from the Prometheus database, choose the required value from the **Custom time range** drop-down list as shown in the following image.



Data Display on Dashboard

The table lists the features, the Cisco cnBR version in which it was introduced, and also gives a short description of the feature.

Feature Name	Release Information	Feature Description
Downstream and upstream channel utilization live graphs	Cisco cnBR 21.2	Downstream and upstream channel utilization live graphs are added in the traffic throughput section of the service group dashboard. You can view the utilization of the downstream and upstream channels under the service group in these live graphs.

Feature Name	Release Information	Feature Description
Modem type column	Cisco cnBR 21.2	A modem type column is added in the Cable Modem List table of the Cable Modem List dashboard. It shows the DOCSIS version of the cable modem.

The Dashboard panel provides a list of commonly used dashboards. The dashboard includes the cnBR Manager Overview, cnBR Summary, RPD List Summary, Service Group Summary, Service Groups List, Cable Modem Table List, and other recently used dashboards.

To access the Dashboard, click Cisco Operations Hub > Dashbboard.

You can alternatively search for dashboards by clicking Find a Dashboard.

For all dashboards available in the Cisco cnBR Manager application, data is represented using pie charts, tables, and live graphs.

cnBR Cluster

This Dashboard displays the following information:

Describes each panel in the cnBR Cluster dashboard

Panel Name	Description
cnBR health status	The pie chart shows Cisco cnBR performance status for each Cisco cnBR cluster.
Remote-PHY device (RPD) status	The pie chart shows the status of RPDs in each Cisco cnBR cluster.
Cable Modem status	The pie chart shows the status of cable modems in the Cisco cnBR cluster.
Summary of downstream traffic rate for all cnBR clusters	The graph shows how much download happened in the set time.
Summary of upstream traffic rate for all cnBR clusters	The graph shows how much upstream traffic happened in the set time.
Summary of RPDs in different states per cnBR cluster	The table shows how many RPDs are offline or online, and the following details:
	• cnBR Name: Name of the cluster
	• cnBR ID: The IP address to reach the Cisco cnBR router.
	• init-auth: Authorization status of the RPD
	• init-gcp: GCP provision status
	• init-clock: Clock synchronization status
	init-l2tp: L2VPN provisioning status
	• total: Total number of RPDs in the cluster

I

Panel Name	Description
Summary of modems in different states per cnBR cluster	The table shows a summary of the status of cable modems in the cluster, including the following details:
	Ranging: Number of ranging requests received.
	• DHCP: Number of DHCP requests received.
	ToD: Time-of-Day (ToD) requests received.
	• TFTP: Number of TFTP requests received.
	• Reg: Number of registration requests (REG-REQ) or multipart registration request (REG-REQ-MP) received.
	• BPI Err: Number of Baseline Privacy Interface (BPI) errors even if the cable modem is registered.
	• Offline: Number of modems which are offline.
	• Oper: Number of cable modems which are registered without enabling BPI.
	• BPI Oper: Number of cable modems with BPI.
Error log count history for all cnBR clusters	The live graph shows the history of the number of error logs generated for all Cisco cnBR clusters.
Error logs from all cnBR clusters	The live graph shows the error logs generated for all Cisco cnBR clusters.



cnBR Summary

The Dashboard displays the following information:

Panel Name	Description
RPD state summary per cnBR	The pie chart shows a summary of RPDs in different states under the current Cisco cnBR cluster:
	• online: Online state
	• init(l2tp): Layer Two Tunneling Protocol (L2TP) provision
	• init(clksync): Clock sync
	• init(gcp): GCP provision
	• init(auth): Authorization
	• offline: Offline state
Modem state summary per cnBR	The pie chart shows a summary of modems in different states under the current Cisco cnBR cluster:
	• oper: Modem that is registered without BPI enabled
	• bpi_oper: Modem that is registered with BPI enabled
	• bpi_error: Modem that is registered but BPI error
	• reg: REG-REQ or REG-REQ-MP was received
	• tod: TOD request received
	• tftp: Trivial File Transfer Protocol (TFTP) request received
	dhcp: DHCP request received
	ranging: Ranging request received
	offline: Offline state
RPD state count per SG	The table provides a summary of RPDs in different states per service group:
	• SG_ID: Service group id
	• auth: init(auth) state, authorization
	• gcp: init(gcp) state, GCP provision
	clock: init(clksync) state, clock sync
	l2tp: init (L2TP) state, L2TP provision
	• offline: offline state
	• online: online state

Describes each panel in the cnBR Summary dashboard

Panel Name	Description
Modem state count per SG	Summary of modems in different states per service group:
	• SG_ID: Service group ID
	ranging: Ranging request received
	• tod: TOD request received
	dhcp: DHCP request received
	• tftp: TFTP request received
	• reg: REG-REQ or REG-REQ-MP was received
	• bpi_err: Modem that is registered but BPI error
	• offline: Offline state
	• oper: Modem that is registered without BPI enabled
	• bpi_oper: Modem that is registered with BPI enabled
Traffic statistics for all service	Shows traffic statistics for the following:
Groups	DS Service Group Traffic Rate
	US Service Group Traffic Rate
RPD statistics	History summary of RPDs in different stats
RPD events	Latest 100 RPD state change events
Modem statistics	CM DOCSIS version summary
	CM Operational version summary
	CM QoS version summary
	CM models summary
Modem state summary history	Summary history of modems in different states
Modem events	Latest 100 modem state change events

Panel Name	Description
Modem list	A detailed modem state information list. Use the Search text box to filter modems by the MAC address, IPv4 address, or IPv6 address. The number of rows in the Modem List table is limited to 256. The total is the total number of modems that are filtered by clusterIp and the search text.
	Cable Modem: MAC address of the cable modem
	• IPv4: IPv4 address of the cable modem
	• IPv6: IPv6 address of the cable modem
	• State: State of the cable modem
	• SG: Service group ID of the cable modem
	• MD: MAC domain ID of the cable modem
	• Online Time: Last time when the cable modem transitioned to online
	Offline Time: Last time when the cable modem transitioned to offline
	• Last Update: Last time when the entry was updated.



Note Use the **Actions** drop-down option in this dashlet to reset or delete all offline cable modems for the selected Cisco cnBR cluster.



Service Group

The Dashboard displays the following information:

Panel Name	Description				
Cable modem status information	This section shows a summary of the status of cable modems in the specified service group by using a pie chart, a live graph, and the number of modems available with each service:				
	Ranging: Number of ranging requests received				
	• DHCP: Number of DHCP requests received				
	• TFTP: Number of TFTP requests received				
	• ToD: Time-of-Day (ToD) requests received				
	• Registration: Number of registration requests (REG-REQ) or multipart registration request (REG-REQ-MP) received				
	• Oper: Number of cable modems that are registered without enabling BPI				
	• BPI Oper: Number of cable modems with BPI				
	• BPI Error: Number of Baseline Privacy Interface (BPI) errors even if cable modem is registered				
	• Offline: Number of modems that are offline				
	• Unreachable: Number of modems that are unreachable				
Traffic throughput	Shows the traffic throughput for a selected service group. Provides following live graphs:				
	DS Traffic Throughput				
	• DS Channel Frequency & Utilization				
	• US Traffic Throughput				
	• US Channel Frequency & Utilization.				

Describes each panel in the Service Group dashboard


anel Name Description					
RPD information	The table shows a list of RPDs of this service group.				
	• MAC Address: MAC address of the RPD, link to RPD Verbose page.				
	• Name: Name of the RPD.				
	• SG Name: Service group name of the RPD.				
	• Service Group: Service group ID of the RPD.				
	• IPv4 Address: IPv4 address of the RPD.				
	• IPv6 Address: IPv6 address of the RPD.				
	• State: State of the RPD.				
	• online				
	• offline				
	• Role: Role of the RPD.				
	• principal				
	• auxiliary				
	• cnBR ID: cnBR cluster ID of the RPD.				
	• Online Timestamp: Timestamp when the RPD is online.				
Modem Statistics	This section contains pie charts for the following summaries:				
	CM DOCSIS version summary				
	CM QoS version summary				
	• CM OperVer summary				
	• CM models summary				
	Online CM Summary on Primary DS Chan				
	Online CM Summary per TCS and US Chan				

Panel Name	Description				
Cable Modem Table	Cable modem table for selected service group.				
	• Cable Modem: MAC address of the cable modem.				
	• IPv4: IPv4 address of the cable modem.				
	• IPv6: IPv6 address of the cable modem.				
	• State: State of the cable modem.				
	• SG: Service group of the cable modem.				
	• MD: MAC domain of the cable modem.				
	• SID: Service ID of the cable modem.				
	• DS Count: Downstream channel count of the cable modem.				
	• US Count: Upstream channel count of the cable modem				
	• CPE Count: CPE count of the cable modem				
	• Online Time: Timestamp when the modem online				
	• Offline Time: Timestamp when the cable modem offline.				
	You can do the following operations on cable modems for a selected Cisco cnBR and the service group from the Actions drop-down option.				
	Reset All Offline Modems				
	Reset All Searched Modems				
	Delete All Offline Modems				
	Delete All Searched Modems				
CM Reachability	Displays a graph and a table for the cable modems which are not reachable.				

Panel Name	Description				
Service Flow List	The Downstream Service Flow List and Upstream Service Flow List tables provide the following details:				
	• SF ID: Service Flow ID.				
	• CableModem: MAC address of the modem.				
	• Stage: Stage of service flow:				
	 PRE_REGISTRATION: Service flow is provisioned before REGISTRATION. 				
	• REGISTRATION: Service flow is provisioned in REGISTRATION.				
	• Frame Type:				
	• PRE_D30: Pre-3.0 DOCSIS concatenation and fragmentation.				
	• CCF_ON: Continous Concatenation and Fragmentation is enabled.				
	 CCF_OFF: Continous Concatenation and Fragmentation is disabled. 				
	• State: State of service flow				
	• Prov: Service flow is in provision.				
	• Adm: Service flow is in admit.				
	• Active: Service flow is active.				
	• Type: Primary, Secondary				
	• MdID: MAC Domain ID of the modem.				
	• SgId: Service group ID of the modem.				
MAC domain configuration	MAC domain configuration.				
	• MAC Domain: MAC domain ID. The link opens the CMTS Mac Domain page.				
	• cnBR: cnBR cluster.				
	Service Group ID: Service group ID.				
	• Primary DS channels: Primary downstream channels for this MAC domain.				
	• US channels: Upstream channels for this MAC domain.				

Panel Name	Description				
DS channel configs	Downstream channel configuration.				
	downstream channel ID: Downstream channel ID				
	• annex: Annex of the downstream channel				
	• AnnexA				
	• AnnexB				
	• frequency: Frequency of the downstream channel				
	• modulation: Modulation of this downstream channel				
	• qam64				
	• qam256				
	• interlevel: Interlever of the downstream channel				
	• poweradjust: Power adjustment of the downstream channel.				
OFDM channel configs	OFDM channel configuration.				
	• ofdm chan id: OFDM channel ID				
	• startfrequency: Start frequency				
	• width: Width of the OFDM channel				
	• plc: PHY Link Channel.				
	• rolloff: Rolloff of the OFDM channel				
	profilencp: Profile Next Codeword Pointer				
	• cyclicprefix: Cyclicprefix of the OFDM channel.				
	• pilotScaling: Pilot Scaling				
	• profiilecontrol: Profile control				
	• interleaverdepth: Interlever depth				
	• subcarrierspacing: Subcarrier Spacing				
	• profiles: Link to OFDM Channel Profile Data page.				

Panel Name	Description
US channel configs	Upstream channel configuration.
	• upstream channel id: Upstream channel ID
	slotsize: Minislot size
	• frequency: Frequency
	docsismode: DOCSIS Mode
	modulation: Modulation profile
	• powerlevel: Power level
	channelwidth: Channel width
	• sgid: Service group ID




CMTS MAC Domain

The Dashboard displays the following information:

Describes each panel in the CMTS MAC Domain dashboard

Panel Name	Description
MMM stats	Rate history of MAC management messages.
MDD stats	Rate history of MDD.



DS Channel

The Downstream (DS) Channel dashboard displays the following information:

Describes each panel in the DS Channel dashboard

Panel Name	Description
Modem state	Summary of modems in different states for the specific Cisco cnBR cluster.
Count	Downstream channel count of the cable modem.
Rate	Downstream traffic rate for the Cisco cnBR cluster.

I

opshub-data > DS Channel -		nh[* 🕑 (🖺 🌞 🖵 📀 Last 30 minutes 👻 Q 🎜 5s '
BR Name cnbr6 • cnBR ID 172.25.29.37.nip.io •	SG Name SG00 • SG ID 0 • DS CH ID 0 • Metric	All -	
BR Cluster > CMTS Mac Domain > DS Channel			
Nodem State			
CM State Summary +			
0	eurrent — bpLoper 72		
punt (16 panels) ate	d		
Ds_ch_ChannelMaxRate Rate	i Ds_ch_ChannelUtilization Rate	i Ds_ch_DataByteLowCnt Rate	i Ds_ch_DataByteMedCnt Rate
	0.40	3 K 2 K	0.5
	0.20 0	2K	0
	0.10	1 K 500	-0.5
22:20 22:30 22:40	0 22:20 22:30 22:40	0 22:20 22:30 22:40	-1.0 22:20 22:30 22:40
rate	- rate	- rate	- rate
Ds_ch_DataPktLowCnt Rate	i Ds_ch_DataPktMedCnt Rate	i Ds_ch_DirectedByteHighCnt Rate	i Ds_ch_DirectedByteLowCnt Rate
	0.5		0.5
	0		0

Modem US Channel

The Dashboard displays the following information:

Describes each panel in the Modem US Channel dashboard

Panel Name	Description
Data SNR and Codewords	SNR and Codeword information of the upstream channel for the cable modem.
Ranging	Ranging information of cable modems.

R Name	cnbr6 - cr	BR ID 172.	25.29.37.nip.io +	Cable Modem	602a.d0a6.4094 -	US CH ID All -						
BR Clu	ster > Modem	US Channel										
ata Si	IR and Codew	ords										
S Chan	nel 🔺	SID	Upstream Data	SNR (dB)	G	ood Codeword rx	Corrected C	odewords rx		Uncorrectable Co	odewords rx	
		506	45.15		1	1951 0			0			
		506	45.15		1	951	0			0		
		506	45.15		1	941	0			0		
		506	45.15		1	946	0			0		
angin												
angin												
S CH	Ranging Sta		eported Power(dBr		Ranging SNR(dB) A	Ranging RX Power(dBm		wer Level(dBmV)		ower(dBmV)		ng Offset(97.6 ns)
	STA_MTN STA_MTN			0.00		-1.00			270.00			
	STA_MTN		0.25		39.09	0	0.00		0		270.0	
	STA_MTN		1.75		42.04	0	0.00		0		270.0	
S CH	Report Pwr(1	(100 dBm\/)	- Report Ty	Pwr(Norm)	Cmd Pwr(1/4 dBmV	() Cmd TxPwr(Norm)	Min Pwr(1/100	dBmV) Min TxPw	r(Norm)	Pwr Load(1/10	0 dBm\/)	Pwr Load (Norm)
0.011	0		0	(itoili)	0	0	0	0		0	5 50((Y)	0
	0		0		0	0	0	0		0		0
			cy Adjust			Power Ad	ust			Time	Adjust	
					1.0			10				
-	141				0.5			6.5 0	_			-
13 19	647	1320	19.25 19.30	13 25		1315 1320 1	125 1330	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1215	13.20	1325	13.00 13.35

Cable Modem List

The Dashboard displays all Cable Modems in a list, based on the cluster, Service Group, Mac Domain, CM state and CM type.

Panel Name	Description			
Modem List	Detailed modem state information list. Use the search text box to filter modems by MAC address, IPv4 address, or IPv6 address. The number of rows in the Modem List table is limited to 256. The parameter Total denotes the total number of modems that are filtered by clusterIp and the search text.			
	Cable Modem: MAC address of the cable modem			
	• IPv4: IPv4 address of the cable modem			
	• IPv6: IPv6 address of the cable modem			
	• State: State of the cable modem			
	• Modem Type: DOCSIS version of cable modem, that is D3.1, D2.0, D1.0			
	• SG Name: Service group name of the cable modem			
	• SG: Service group ID of the cable modem			
	• MD: MAC domain ID of the cable modem			
	• cnBR ID: cnBR Identifier			
	• SID: Service ID of the cable modem			
	• DS Count: Downstream channel count of the cable modem			
	• US Count: Upstream channel count of the cable modem			
	• CPE Count: CPE count of the cable modem			
	• Online Time: Time stamp when the modem became online			
	• Offline Time: Time stamp when the cable modem became offline			
	• Last Update: Time stamp of the last entry			

Describes each panel in the Cable Modem List dashboard.

The **Download CSV** option allows you to download information for online and offline cable modems. However, the download option is limited to one Cisco cnBR cluster at a time. You can use the Cable Modem State History dashboard for historical information.

cnBR Manage	er / Cable N	Nodem List 👒											O	 Last 1 hou 	r ∨ Q C 10s ∨
BR Name All ~	cnBR ID	All ~ SG Name All ~	SG ID All -	MD ID	All ~	State	All ~	Modem Typ	e All s	·					
cnBR Cluster >(Cable Modem	List													
ownload CSV:	Online Off	ine													
							Cab	le Modem Li	st						
ac or ip address	Se	earch													
Cable Modem	IPv4	IPv6	State	Modem	SG	SG	MD	cnBR	SID	DS	US	CPE	Last Online Time	Last Update	cnBR ID
Cable Modem			State	Modem Type	SG Name	SG	MD	cnBR Name	SID	DS Count	US Count	CPE Count	Last Online Time		cnBR ID
Cable Modem	IPv4		State w-online(pt)			SG 11	MD 0		SID 7				Last Online Time 2021-05-27T01:45:01.778735Z	Last Update 2021-05-27 07:15:41	cnBR ID 172.25.29.123.nip.io
	IPv4 5.55.8.92	IPv6		Туре	Name			Name		Count	Count	Count		2021-05-27	

Cable Modem Verbose

The Dashboard displays the following information:

Describes each panel in the Cable Modem Verbose dashboard.

Panel Name	Description					
Modem Basic Info	Basic information about the cable modem.					
Modem RNG Info	Ranging information of the cable modem.					
Modem OFDM Info	OFDM information of the cable modem.					
Modem Other Info	Additional information of the cable modem:					
	DOCSIS Version: DOC1.0, DOC1.1, DOC2.0, DOC3.0, DOC3.1					
	• Operational Version: DOC1.0, DOC1.1, DOC2.0, DOC3.0, DOC3.1					
	• QoS Version: DOC1.0, DOC1.1					
	Sys Desc: System description					
	DBC Req Count: Count of DBC(Dynamic Bonding Change) requ					
	• DBC Res OK: Count of DBC response with OK					
	DBC Ack Count: Count of DBC ack					
	• Ext Pktlen Capability: External packet length capability					
	• DS Lowerband Edge: Downstream lower band edge					
	• DS Upperband Edge: Downstream upper band edge					
	• US Upperband Edge: Upstream upper band edge					
	• DTP Mode: DOCSIS time protocol mode					
	• DTP Performance: DOCSIS time protocol performance					
Modem State History	History of the cable modem status.					

Panel Name	Description					
Modem CPE List	CPE list of cable modem.					
	• MAC: CPE MAC address					
	• IP: IP address of the modem					
	Device Class: CPE device class					
	CPE device class:					
	• EROUTER					
	• EMTA					
	• SMTA					
	• ESTB					
	• EDVA					
	• ECM					
	• EPS					
Modem Ping Stats	History of cable modem IP pings.					
Service Flow Stats	Shows the details of upstream and downstream service flows.					
Channel Stats	You can view the following details:					
	• US CH RNG SNR History: History of upstream channel ranging SNR(Signal Noise Ratio).					
	• US CH RNG RX Power History: History of upstream channel ranging RX power(dBm).					
	• DS CH (RxPwr&SNR) History: History of downstream channel RX power and SNR by remote query.					
	• US CH (TxPwr&TxTimingOffset) History: History of upstream channel TX power and timing offset by remote query.					
	• Modem Timing Offset History: History of upstream channel timing offset of Cisco cnBR side.					
	• Modem Ranging State History: History of upstream channel ranging state.					
DBC Event	Shows the details of the Dynamic bonding change (DBC) events.					
Resiliency Event	History of upstream resiliency state.					

R Name cnbr6 -	cnBR ID 172.25.29.37.nip.io *	Cable Modem 602a.d0a6.4094 -									
nBR Cluster > Ser	vice Group > CMTS Mac Doma	in > DS Channel > Modern US Cha	nnel > Modems	List > Cab	le Modern	Verbose					
Reset Dele											
Reset Dele	le										
м	odem Basic Info	i Modem F	NG Info		i	Mode	m OFDM Info		i	Mod	em Other Info
MAC	602a.d0a6.4094	MaxCMPwr(1/100			OFD	IM Prof			DOCS	S Version	DOC3.0
State	w-online(pt)	MaxCMPwr(Norm) -			OFD	M Unfit Prof(s)			Operat	ional Version	DOC3.0
SG Name	SG12	MaxChPwr(1/100 d			OFD	MMRC			QoS V	ersion	DOC1.1
SG	12	MaxChPwr(Norm) -			OFD	MA MTC			Sys De	sc	Cisco DPC3010 DOCSIS 3.0
MD	0	Neq(1.6MHz TxCh)			OFD	OFDM Prof Supp -			Net Ac	cess Disable	true
IP	5.60.40.155	MinPwrLoad(1/100			OFD	M QAM Mod			DBC R	eq Count	•
IPv6	-	MinPwrLoad(Norm) -			OFD	OFDMA QAM Mod -			DBC R	es OK	•
Prim SID	506	Min DRW(1/4 dBmV) -			RxM	IER	Display		DBC A	ck Count	
RCP	00 10 18 80 62	Min DRW(Norm) -							Ext Pk	tlen Capability	-
Prim DS CH	0	Max DRW(1/4 dBmV)							DS Lo	verband Edge	·
DS CH	0,1,2,3,4,5,6,7	Max DRW(Norm)							DS Up	perband Edge	
Init US CH	<u>0</u>	i	Modem State	e History			i		Mo	dem CPE List	
US CH	0,1,2,3	Time 🕶	State	Prim DS 0	н	Init US CH	search	Sea	irch		
Prim DS SFID	10506	2020-07-18 16:14:41	online(pt)	0		0	MAC	IP		Device Cla	SS
DS SF Count	1	2020-07-18 11:22:19	online(pt)	0		0					
DS Packets	7912										
DS Bytes	865328								No	lata to show 🛛	
Prim US SFID	506										
US SE Count	1										
Modem Ping Stat	S (4 panels)										
Service Flow Stat	S (5 panels)										
Channel Stats (6	panels)										
DBC Event (2 pane	ls)										
Resiliency Event	(1 panel)										

Cable System Description Summary

The dashboard displays the Cable Modem versions and system summary. The following table lists the panel names and their descriptions.

The table contains information about the dashboard, and displays the Cable Modem versions and system summary.

Panel Name	Description
Vendor	The pie chart shows Cable Modem Vendor distribution.
HW Version	The pie chart shows Cable Modem Hardware Version distribution.
SW Version	The pie chart shows Cable Modem Software Version distribution.
Cable system Description	The table shows Cable Modem system information along with Power level and SNR

The Cisco cnBR Manager periodically queries Cable Modems to retrieve Cable Modem system information using SNMP. The default polling interval for a query is 15 minutes, and the default SNMP read-only community

string is *public*. You can change the default polling interval and community string by using Kubernetes ConfigMap APIs.

```
ConfigMap Name: cmts-hm-conf
NameSpace: cnbrmanager-data
Key:
    remote_query:
        interval: 900
        snmp:
            community : public
```


RPD List Summary

The Dashboard displays the following information:

Describes each panel in the RPD List Summary dashboard.

Panel Name	Description
RPD Summary	Shows the following details using pie charts:
	• RPD state: States of the RPDs in the Cisco cnBR cluster
	Software version: Software version running on the RPDs
	• SSD state: RPD secure software download status

Panel Name	Description
RPD Detail	The table shows details of the RPDs:
	• Name: Name of the RPD
	• MAC: MAC address of the RPD
	• SG: Service group
	• SG Name: Service group name of the RPD.
	• SG ID: Service group ID of the RPD.
	• IPv4 Address: IPv4 address of the RPD.
	• IPv6 Address: IPv6 address of the RPD.
	• State: State of the RPD.
	• online
	• offline
	• Role: Role of the RPD.
	• principal
	• auxiliary
	• cnBR Name: Name of the cluster
	SSD state: RPD secure software download status
	Software version: Software version running on the RPDs
	Online Time: RPD online timestamp



RPD Verbose

The Dashboard displays the following information:

Describes each panel in the RPD Verbose dashboard.

Panel Name	Description
Basic information	Shows basic information about the RPD.
	• MAC: MAC address of the RPD
	• Name: Name of the RPD
	• SG: Service group
	• IPv4: IPv4 address
	• IPv6: IPv6 address
	• State: init(auth), init(gcp), init(clksync), init(l2tp), online, offline
	GCP State: Generic control plane state
	• Role: principle, auxiliary
	cnBR ID: Cloud CMTS ID
	• Last State: The previous status of RPD
	Last GCP State: The previous generic control plane state
	• Auth Time: RPD authentication timestamp
	Online Time: RPD online timestamp

Panel Name	Description
RPD identification	Shows the basic RPD identification detials.
	RPD ID: RPD MAC address
	Vendor Name: Vendor name
	Vendor ID: Vendor ID
	• Model Number: Model number of the RPD
	• Sw Version: Current software version running on the RPD
	Boot ROM Sw Version: Boot read-only memory software version
	Device Description: Device description
	Device Alias: Device alias
	Serial Number: Serial number
	Rcp Protocol Ver: R-PHY control protocol version
	Rpd Rcp Protocol Ver: R-PHY control protocol version
	Rpd Rcp Schema Version: R-PHY control protocol schema version
	Hw Revision: Hardware revision
	• Asset Id: Asset ID of the RPD
	Vsp Selector: Vendor-Specific Preconfiguration.
	• Us Burst Receiver Vendor Id: Upstream burst receiver vendor ID
	• Us Burst Receiver Driver Version: Upstream burst receiver driver version

Panel Name	Description
RPD Capability	

Panel Name	Description
	Shows the basic capabilities.
	RPD ID: RPD MAC address
	Bidirection RF Ports: bidirectional radio frequency ports
	• DS RF Ports: Downstream radio frequency ports
	• US RF Ports: Upstream radio frequency ports
	• 10G Eth Ports: 10-Gigabit Ethernet port number
	• 1G Eth Ports: 1-Gigabit Ethernet port number
	• DS SC-QAM Channels Per Port: Downstream single carrier quadrature amplitude modulation (QAM) channels per port
	DS OFDM Channels Per Port: Downstream orthogonal frequency division multiplexing (OFDM) channels per port
	• US SC-QAM Channels Per Port: Upstream single carrier QAM channels per port
	US OFDMA Channels Per Port: Upstream OFDM channels per port
	DS SCTE-55-1 Channels Per Port: Downstream SCTE-55-1 channels per port
	US SCTE-55-1 Channels Per Port: Upstream SCTE-55-1 channels per port
	SCTE-55-2 Modules: SCTE-55-2 Modules
	• US SCTE-55-2 Demodulator Num: Upstream SCTE-55-2 demodulator numbers
	NDF Channels Per Port: Remote-PHY narrowband digital forward channels per port
	 NDR Channels Per Port: Remote-PHY narrowband digital return channels per port
	• UDP Encapsulation On L2TPv3: User datagram protocol (UDP) encapsulation on Layer 2 Tunneling Protocol version 3
	• DS Distinct PSP Flows: Downstream distinct packet streaming (DPS) protocol flows
	• US Distinct PSP Flows: Upstream DPS protocol flows
	Asyn MPEG Video Channels Per Port: Asynchronous MPEG video channels per port
	• Flow Tags support capability: Shows whether flow tags support is available or not.

Panel Name	Description
	Freq Tilt support: Shows whether frequency tilt is supported on the RPD
	Range of tilt setting: Range of tilt setting
	• ucd processing time: RPD upstream channel descriptor processing time
	• ucd change null grant time: RPD upstream channel descriptor change null grant time
	Buffer depth monitor alert support: Buffer depth monitor alert support
	Buffer depth config support: Buffer depth monitor configuration support
	• Multi section timing mer reporting support: Multiple section timings mer reporting support
	Max DS Psp Seg Count: Max Downstream packet streaming protocol seg count
	Direct DS Flow Queue Mapping: Direct downstream flow queue mapping
	• DS scheduler PhbId list: Downstream scheduler per hop behavio ID list
	Pending EvRep Queue Size: RPD pending event report queue size
	Local Event Log Size: RPD local event log size
	• Supported Optical Node RF: Shows whether optical node radio frequency is supported on the RPD
	MAX DS Freq: RPD maximum downstream frequency
	• MIN DS Freq: RPD minimum downstream frequency
	MAX Base Power: RPD maximum base power
	• MIN Tilt Value: RPD minimum tilt value
	 MIN Power Adjust for ScQam Chan: RPD minimum power adjust for single carrier quadrature amplitude modulation channels
	MAX Power Adjust for ScQam Chan: RPD maximum power adjust for single carrier quadrature amplitude modulation channel
	 MIN Power Adjust for OFDM Chan: RPD minimum power adjust for orthogonal frequency division multiplexing channels
	MAX Power Adjust for OFDM Chan: RPD maximum power adjust for orthogonal frequency division multiplexing channels

Panel Name	Description
Update history	Update history of the previous 50 RPDs.
	• MAC Address: MAC address of the RPD
	• State: Shows in which state the RPD is functioning:
	• init(auth)
	• init(gcp)
	• init(clksync)
	• init(l2tp)
	• online
	• offline
	• GCP State: offline, c1, c2 ready
	• TimeStamp: time stamp
show cable modem	The table provides basic details of the cable modem.
	Cable Modem: Cable modem MAC address
	• IPv4: IPv4 address of the modem
	• IPv6: IPv6 address of the modem
	• State: Shows in which state the modem is functioning:
	• init(auth)
	• init(gcp)
	• init(clksync)
	• init(l2tp)
	• online
	• offline
	• SG: Service group
	• MD: MAC domain
	cnBR ID: Cloud CMTS ID
	Online Time: RPD online time
	Offline Time: RPD offline time
	• Last Update: Last update time

Panel Name	Description
RPD configuration	The table shows the basic configuration of RPD.
	• Ds Channel: Downstream channel configuration
	DsChan Base Power: Base power of downstream channel
	DsChan Admin State: Admin state
	• Us Channel: Upstream channel configuration
	Fiber Node: Fiber node configuration
끎 cnBR Manager / RPD Verbose 《	الله الله
cnBR Name Baremetal_61 ~ cnBR ID 172.22.16.61.nip.io ~ SC	S Name All × SG ID All × RPD ID None × RPD Name None ×
RPD Verbose	
	Reset RPD
> Basic Information (5 panels)	

You can use the **Reset RPD** button to reboot all operations on the RPD.

Note

Resetting the RPD would affect all existing services.

Search for Dashboards

Follow this procedure to search for dashboards:

- Step 1 Click Cisco Operations Hub > Dashboards.
- **Step 2** On the navigation panel, click **Find a Dashboard**.

> RPD Configuration (2 panels)

> IUC Counters (6 panels)

Step 3 Enter the dashboard name in the **Search dashboards by name** field and select the target dashboard.

Alternatively, you can also click *Infrastructure*, *cnBR Manager*, or *Operations Hub* folders and browse for a specific dashboard.

Customize Dashboards

This table lists the features and the releases in which the feature was introduced and gives a small description of the feature.

Table 3: Feature History

Feature Name	Release Information	Feature Description
Customize Dashboards	Cisco cnBR 21.2	You can customize Cisco cnBR and Cisco Operations Hub dashboards to analyze and visualize your data the way you want to. You can use the real-time data or the historical data for this purpose.

Cisco Operations Hub and Cisco cnBR Manager include numerous prebuilt data-visualization dashboards.

Dashboards in cnBR Manager show information about the Cisco cnBR and the RPDs they serve. The dashboards provide the following information:

- A real-time look at the health and metrics (updated every 10 sec)
- · Historical data for visualizing trends over longer intervals

Cisco Operations Hub dashboards show information on the infrastructure and cloud software that powers Cisco cnBR and the Operations Hub.

The prebuilt dashboards are designed to meet the needs of most cable service providers. However, according to your requirement, you may customize the existing dashboards or create new dashboards. This section explains how to customize and create new dashboards.

Plan and Organize New Dashboards

You can create or customize dashboards based on your familiarity with Grafana and its data sources.

- If you are new to Grafana, you can create new dashboards using existing dashboards.
- If you are familiar with Grafana, you can create dashboards from scratch or export existing dashboards, modify them, and import them back into the Cisco Operations Hub.

Before customizing or creating new dashboards, you must do the following:

- · Identify data sources
- · Identify visualization panels
- Plan the layout

Create a New Dashboard

Step 1 From the Cisco Operations Hub main menu, click Dashboar	rds.
--	------

- **Step 2** Click Advanced > Manage in the left navigation menu of the Dashboards page.
- **Step 3** Click the **New Dashboard** button under the **Manage** tab.

Step 4 Click Add new panel.

- **Step 5** Configure the panel with the required data sources and visualization type.
- Step 6 Click Save.

You can rearrange the panel location within the dashboard by dragging the panel header to the correct location. You can also resize the panels by dragging the bottom-right corner of the panel.

Create a New Dashboard from an Existing Dashboard

- Step 1 Open the dashboard which you want to customize.
 Step 2 Click the Dashboard settings gear icon at the top of the dashboard page.
 Step 3 Click Save As... on the left side of the dashboard Settings page.
 Step 4 Enter a new dashboard name and choose a folder in the Save dashboard as... pop-up window.
 Step 5 Click Save.
 Step 6 Open this new dashboard, click the Panel Title, and click Edit to edit the panel properties. On the Edit Panel page, edit the panel properties in the three tabs: Panel, Field, and Overrides. You can also create a query, and set the transformations and alerts for the dashboard.
- **Step 7** Click **Save** at the top of the **Edit Panel** page.

You can rearrange the panel location within the dashboard by holding and dragging the panel title to the required location. You can also resize the panels by dragging the bottom-right corner of the panel.

Create New Dashboard Using Export and Import

The following process is recommended only for advanced users.

- **Step 1** Open the dashboard that you want to export.
- **Step 2** Click the share icon at the top of the page to the right of the dashboard name.
- **Step 3** Click the **Export** tab.
- Step 4 Click Save to file.
- **Step 5** Edit the JSON file.
- **Step 6** From the Cisco Operations Hub main menu, click **Dashboards** > **Advanced** > **Manage**.
- Step 7 Click Import.

Use one of the following options to import the dashboard file:

- Click Upload JSON file and choose the dashboard file.
- Enter a dashboard URL or ID in the Import via grafana.com text box and click Load.
- Enter a valid dashboard JSON model in the Import via panel json text area and click Load.

On the next page, add the required data and click Import.

What to do next

After you import a dashboard, you can customize it. For more details, see Customize Dashboard Panels, on page 43.

Customize Dashboard Panels

You can add new panels to a newly created dashboard.

- When you create a dashboard from an existing one, click the **Add panel** icon to open the **Edit Panel** page to add more panels.
- When you create a new dashboard using the **New Dashboard** option, click the **Add new panel** button to open the **Edit Panel** page.

The following tabs are available on the Edit Panel page using which you can edit all panel properties.

The table describes each tab in the Edit Panel

Tab	Description
Query	Allows you to create new queries, configure, and update existing data sources.
Transform	Allows you to calculate, reorder, and rename your query results before visualizing them.
Alert	Allows you to create rules, conditions, and notifications on the supported data sources.
Panel	Allows you to configure the visual properties of the panel. You can choose from the available visualization plug-ins.
Fields	Allows you to rename and configure fields appearing in the visualizations. In addition, you can link the current panel to other panels and dashboards using the Data Links option.
Overrides	Allows you to add rules for field overrides, which provide fine-grained control over how your data appears in the dashboard.

KPI Alert Management

The table lists the features, the Cisco cnBR version in which it was introduced, and also gives a short description of the feature.

Table 4: Feature History

Feature Name	Release Information	Feature Description
KPI Alert Management	Cisco cnBR 20.4	Expands the alerts in Subscriber, RF Plant, and Infra KPI Alert categories.

KPIs (Key Performance Indicator) of Cisco cnBR clusters help in getting information on the overall system stability and on the components that are not functioning normally and are impacting the system stability.

The cnBR Manager supports the following KPI Alert categories:

- Subscriber
- RF Plant
- Infra

Subscriber

This KPI Alert category provides an overview of the subscriber health status of the Cisco cnBR cluster. The following parameters are available in this KPI:

- **CMNotHealthyCMState**: If the percentage of online modems is higher than the configured threshold(95%), we can consider this parameter as healthy, otherwise, unhealthy.
- **CMNotHealthyPartialUS**: If the percentage of modems in upstream partial-service mode is less than the configured threshold(10%), we can consider this parameter as healthy, otherwise, unhealthy.
- **CMNotHealthyPartialDS**: If the percentage of modems in downstream partial-service mode is less than the configured threshold(10%), we can consider this parameter as healthy, otherwise, unhealthy.
- **CMNotHealthyPingLoss**: If the ping loss rate is less than the configured percentage threshold(20%), we can consider this parameter as healthy, otherwise, unhealthy.
- **CMNotHealthyPingLatency**: If the ping latency is less than the configured threshold(200 ms), we can consider this parameter as healthy, otherwise, unhealthy.
- **RPDNotHealthy**: If all the RPDs are online, we can consider this parameter as healthy, otherwise, unhealthy.

RF Plant

This KPI Alert category provides an overview of the RF plant health status of the Cisco cnBR cluster. The following parameters are available in this KPI:

- **DSCHNotHealthyMER**: If the primary downstream channel has a Modulation Error Ratio higher than the configured threshold(30 dB), we can consider the channel as healthy, otherwise, unhealthy.
- USCHNotHealthySNRRanging: If the primary upstream channel has an upstream ranging Signal to Noise Ratio (SNR) higher than the configured threshold(20 dB), we can consider the channel as healthy, otherwise, unhealthy.
- USCHNotHealthySNRData: If the primary upstream channel has a data-SNR higher than the configured threshold(30 dB), we can consider the channel as healthy, otherwise, unhealthy.
- **DSCHPartialNotHealthy**: If the percentage of modems in downstream partial-service mode is less than the configured threshold(10%), we can consider the channel as healthy, otherwise, unhealthy.
- **USCHPartialNotHealthy**: If the percentage of modems in upstream partial-service mode is less than the configured threshold(10%), we can consider the channel as healthy, otherwise, unhealthy.

Infra

This KPI Alert category provides the following information:

- An overview of the pod CPU, memory, and file descriptor usage status of the Cisco cnBR and the Cisco Operations Hub clusters.
- An overview of the node CPU, memory, and disk usage of the Cisco cnBR cluster.
- Cisco cnBR reachability and token refresh status.

The following parameters are available in this KPI:

- NodeNotHealthyMEMIssue: If the available memory of a node is higher than the configured threshold(10%), we can consider the node as healthy, otherwise, unhealthy. Available memory is an estimate of the memory available for starting new applications without swapping.
- NodeNotHealthyCPUIssue: If the 1-minute CPU load of a node is lower than the configured threshold(90%), we can consider the node as healthy, otherwise, unhealthy.
- NodeNotHealthyDiskIssue: If the disk usage of a node is less than the configured threshold(80%), we consider the node as healthy, otherwise, unhealthy.
- PodNotHealthy: If all pods of a node are ready, we consider the node as healthy, otherwise, unhealthy.
- **CriticalPodNotHealthy**: If all critical pods(configured in the config map) of a node are ready, we can consider the node as healthy, otherwise, unhealthy.
- **PodNotHealthyHighCPU**: If a pod is consuming fewer CPU cores than the configured limit, we can consider the pod as healthy, otherwise, unhealthy.
- PodNotHealthyHighMEM: If a pod is consuming less memory than the configured limit, we can consider the pod as healthy, otherwise, unhealthy.
- **PodNotHealthyTooManyOpenFileDescriptor**: If a pod has less open file descriptors than the configured limit(2048), we can consider the pod as healthy, otherwise, unhealthy.
- **cnBRNotReachable**: If the cnBR host is reachable from the Cisco Operations Hub, we can consider the Cisco cnBR as healthy, otherwise, unhealthy.

• **cnBRRefreshTokenFailure**: If the token refresh is working for a Cisco cnBR host, consider the host as healthy, otherwise, unhealthy.

Alert Management

The cnBR Manager Alert Management is based on the KPIs. Cisco cnBR records all alerts for users to view. You can configure the alert-manager to manage alerts.

Follow this procedure to view the KPI Alert Management dashboard:

- Step 1 Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **Dashboard** to open the **Dashboard** page.
- **Step 4** Click **Find a Dashboard** to open the search pane.
- Step 5 Enter KPI Alert Management in the Search dashboards by name field and click the KPI Alert Management row to open the KPI Alert Management dashboard.

Alert Definition

All alerts are built based on the KPI metrics and divided into several alert groups. Each KPI metric generates one alert that belongs to a predefined alert group. For example, KPI metrics: CM state (Summary of CM online state) generates one alert that is named CMNotHealthy, which is part of the Subscriber alert group. The Alert Management supports the following alerts and alert groups.

Alert groups	and	alerts	for	each	group
					0 r

Group	Alert
Subscriber	CMNotHealthy RPDNotHealthy
RF	USCHNotHealthy DSCHNotHealthy
Infra	NodeNotHealthy PodNotHealthy

Alert Record

Alert Management records all alerts that are generated in the Cisco cnBR router. The dashboards display an alert summary and detailed information about those alerts.

KPI Alert Summary

Alert summary dashboards show the number of current alerts and total resolved alerts. In addition, the dashboards display the distribution of alerts based on severity. Cisco cnBR supports two levels of alerts:

- critical
- warning

To view the KPI Alert Summary Dashboard, complete the following steps:

- 1. On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- 2. Click Dashboards > DAA Overview.

KPI Alert Information

The dashboard shows two lists: Firing Alerts and Resolved Alerts. The following details are available in these tables:

Attribute Name	Description
Firing Time	Alert fired time.
Name	Alert name.
Severity	Critical or warning.
cnBR ID	Cisco cnBR where the alert is fired.
Alert Group	Category of the KPI alert.
Acknowledge status	Shows whether acknowledged or not.
Action	Acknowledge or view an alert.
	Click the View link. The Alert Action pane on the right side shows the details of the alert.

The table describes attribute in the KPI Alert Information pane

You can view details and acknowledge firing alerts. For the resolved alerts, you can view the details of each alert.

		F	iring List (current)			
rch Search	8					
Firing Time +	Name	Severity	cnBR ID	Group	Acked	Action
2019-09-19 16:08:19	CMNotHealthy	critical	10.124.211.23.nip.io	Subscriber	false	ack
2019-09-19 16:08:19	CMNotHealthy	critical	10.124.211.23.nip.io	Subscriber	false	ack
2019-09-19 16:08:19	CMNotHealthy	critical	10.124.211.23.nip.io	Subscriber	false	ack
2019-09-19 16:02:19	CMNotHealthy	critical	10.79.193.206.nip.io	Subscriber	false	ack
2019-09-19 16:02:19	CMNotHealthy	critical	10.79.193.206.nip.io	Subscriber	false	ack
2019-09-19 16:02:19	CMNotHealthy	critical	10.75.199.64.nip.io	Subscriber	false	ack
1019-09-19 16:02:19	CMNotHealthy	eritical 1 2 R	10.75.199.64.nip.io 3 4 5 6 7 8 esolved List (total)	Subscriber	false	ack
2019-09-19 16:02:19 urch Search		1 2	3 4 5 6 7 8	Subscriber	false	268
		1 2	3 4 5 6 7 8	Subscriber	false Acked	ack Action
arch Search		1 2 R	3 4 5 6 7 8 esolved List (total)			
arch Search	Name	1 2 R Severity	a 4 5 6 7 8 esolved List (total) cnBR (D	Group	Acked	Action
srch	Name USCHNotHealthy	1 2 R Severity critical	3 4 5 6 7 8 esolved List (total) cn8R ID 10.75.199.64.nip.io	Group 65	Acked faise	Action view
srch	Name USCHNotHealthy CMNotHealthy	I 2 R Severity critical	3 4 5 6 7 8 esolved List (total) 0.75.199.64.nip.io 10.75.199.64.nip.io	Group RF Subscriber	Acked false false	Action view view
Irch	Name USCHNotHealthy CMNotHealthy DSCHNotHealthy	I 2 R Severity critical critical	3 4 5 6 7 8 esolved List (total)	Group RF Subscriber RF	Acked false false	Action View View
Inch	Name USCHNotHealthy CMNotHealthy DSCHNotHealthy DSCHNotHealthy	seventy entical entical entical entical	3 4 5 6 7 8 esolved List (total)	Group RF Subscriber RF RF	Acked false false false false	Action View View View View

Acknowledge KPI Alert

You can acknowledge the firing alerts. By default, every three hours, you are notified about the firing alerts by email. You can stop receiving the alert emails by setting the silence time, creator, and comments.

Configure Alerts

You can configure global alerts through Alert Management. For global configuration, update the SMTP (Simple Mail Transfer Protocol) settings. By default, this option is disabled.

On the **Global Configuration** pane, configure the notification channel. The **SMTP General Config** pane is available under the **KPI Global Configuration** pane of the **KPI Alert Configuration** dashboard.

Configure Alerts - Global Configuration pane

Field	Description		
SMTP From	The default SMTP From header field.		
SMTP Smarthost	The default SMTP smarthost used for sending emails, including the port number. The port number is 25 or 587 for SMTP over TLS (STARTTLS). Example: smtp.example.org:587		
SMTP Hello	The default hostname to identify to the SMTP server.		
SMTP TLS Require	The default SMTP TLS requirement (Default: false).		

KPI Alert Configuration

You can enable or disable an alert group and add or delete email addresses of receivers for each alert group. When you enable an alert group and add email addresses, those users are notified when an alert is generated in the respective group.

 KPI Alert Config 	uration								
8	Global Configuration	1		Alert Group List +		4 Group Co	nfiguration		
SMTP General Config		search	Search			Alert Group			
SMTP From 0	alertmanager@example.org	Name	Enabled	Send To List	Action	Name Subscriber	Enabled		
SMTP Smarthost O	localhost:25	Subscriber	true	['mengzwu@test.com']	Modify	Send To List			
SMTP Helio 0	localhost	RF	true		Modify	★ mengxwu@test.com			
SMTP TLS Require	00	Infra	true		Modify	+			
						-			
	_							_	905
	Config							Config	520905

KPI Alert Email

1 alert for	
View In AlertManager	
[1] Firing	
Labels	
alertname = NodeNotHealthy	
cluster = jiancheng-0	
cnbr = 10.124.211.230	
group = Infra	
instance = cmts-hm-clusterkpi-service.opshub-data.svc:3000	
job = kubernetes-probe-honor-labels-services	
monitor = prometheus	
namespace = cee-data	
path = /health/kube/node/cpu/	
pod = node-exporter-49vp6	
replica = jiancheng-0	
severity = critical	
Annotations	
description = On cnBR: 10.124.211.230, node is not healthy for more than 10 minutes, and	
KPI path: /health/kube/node/cpu/.	
summary = Node not Healthy	
type = Quality Of Service Alarm	
Source	

Monitor and Troubleshoot

The KPI of one Cisco cnBR-Core is displayed on this dashboard.

ordiR Name comts-alpha-sity * ordiR ID 172.25.13.69 *				III Feature Links
onitik Summary ¹ RPO State Summary Per cnitik			Haulth	
RPD State Summary Per child	CUR PERC - online 2 100.00%	Modem State Summary Per cell? = lipt,repr 29 202.0%	Feasth	
				520910

The state of each category is displayed on this dashboard.

KPI DOCSIS	Summary-v2 +				🔹 🕆 🖱 🔊 🐠	Q	O Last 30 minutes	Refresh every Ss	0, 0	1
collit Name comta-a	ligha-srv * cn8k ID 172.25.13.69 *	50 Name * 50 0 0 *								
- Health Summary	y									
i Suba	orber	Docais Infra	1	RF Plant	HSD		F	System Infra		
							(

This dashboard shows the details of the subscriber.



This dashboard shows the details of the RF.



Customize Kibana Queries and Data Visualization

The table lists the features, the Cisco cnBR version in which it was introduced, and also gives a short description of the feature.

Table 5: Feature History

Feature Name	Release Information	Feature Description
Customize Kibana Queries and Data Visualization	Cisco cnBR 21.2	You can create Kibana queries, retrieve data, and then customize how you want to present the queried data in Cisco cnBR.

To customize Kibana queries and data visualizations, use the following procedure:

- Create index patterns
- Discover data and save the query
- · Visualize data from the query

Create Index Patterns

Define the data for which you want to create the panel. Data is always generated from Elasticsearch indices. You can use an existing index or create a new one by providing a pattern.

- **Step 1** From the Cisco Operations Hub main menu, click **System** > **Logs**.
- **Step 2** Click **Advanced** > **Manage** in the left navigation menu.
- **Step 3** Click **Index Patterns** link in the Kibana **Management** panel.

You can search and create a new pattern based on your requirement.

Step 4 Click Create index pattern.

Follow the index pattern creation window.

Discover Data

After you identify or create an Index pattern, discover the relevant data and clean it.

- **Step 1** From the Cisco Operations Hub main menu, click **System** > **Logs**.
- **Step 2** Click **Advanced** > **Discover** in the left navigation menu.

The data query panel appears.

Step 3 Create search, add filters, and choose required data columns.

Step 4 Set up refresh intervals using the option in the top-right corner.

Step 5 After the data discovery, save the query with a valid name.

Next time when you view Advanced > Discover, this saved query appears.

Visualize Data from Query

After data discovery, you can present your data in different ways.

- **Step 1** From the Cisco Operations Hub main menu, click **System** > **Logs**.
- **Step 2** Click **Advanced** > **Visualize** in the left navigation menu.
- **Step 3** Click **Create visualization** or search for an existing configuration.
- **Step 4** In the **New Visualization** window, choose a visualization type, and then configure and save them.

Next time when you view the Visualizations window, the saved visualizations appear in the Visualization window.

Log Aggregation and Management

The table lists the features, the Cisco cnBR version in which it was introduced, and also gives a short description of the feature.

Table 6: Feature History

Feature Name	Release Information	Feature Description
Log Aggregation and Management	Cisco cnBR 21.1	The Cisco Operations Hub provides multiple log aggregation tools, various visualization techniques, and customizations that help you to view, debug, visualize, and customize your log information. The Cisco Operations Hub enables Log Aggregation and Management through the Audit Dashboard, Debug Dashboard, and a host of other utilities.

The Cisco Operations Hub provides the Audit Dashboard, Debug Dashboard, and a host of other utilities for log aggregation and management activities.

By using the various visualization techniques and customizations, you can search, visualize, and create dashboards to have macro and micro views.

Configure Operations Hub for Log Management

The following configuration steps are needed only when the Cisco cnBR is added in Cisco Operations Hub using Cisco Operations Hub UI or API. You can skip this section if you added the Cisco cnBR using Autodeployer.

During deployment, the Cisco Operations Hub is preconfigured to collect logs from all the components. However, to send the logs to Cisco Operations Hub, you must manually configure Cisco cnBR.

To manually configure the Cisco cnBR to send the logs to Cisco Operations Hub, complete the following steps:

- **Step 1** Log in to Cisco cnBR CEE Data OpsCenter CLI. Ensure that you provide a valid Cisco cnBR user ID and password. https://cli.cee-data-ops-center.<*cnBRIP*>.nip.io
- **Step 2** Key in these commands at the prompt:

```
logging fluent host fluentd.ccmts-infra
logging fluent port 24224
logging fluent disable-tls true
commit
end
```

Step 3 Log in to Cisco cnBR OpsCenter. Ensure that you provide a valid user ID and password.

https://cli.<cnBR NameSpace>-ops-center.<cnBRIP>.nip.io

Step 4 Key in these commands at the prompt:

```
logging forward kafka-blockers <OpsHub_IP>
commit
end
```

Working with Logs

The Cisco Operations Hub provides you with a host of utilities that helps you to view, debug, visualize, and customise your log information.

View Audit Logs

The Audit dashboard leverages Kibana to provide meaningful visualization and a search interface for the raw log data.

You can view the Audit Logs dashboard by completing these steps:

Step 1 Click Cisco Operations Hub > System > Logs.

Step 2 Click Audit Dashboard.

The Audit Dashboard provides the following information:

- A visualization of the count of audit logs against time. You can view this as a histogram.
- All user initiated events from UI or using API interface are logged and available as audit logs.
- For every log file, the Audit Dashboard provides the following facets of information:
 - Time: The time of logging the event.

- User: The user initiating the event.
- **API**: The API call used.
- Status: The HTTP response status code that returns when API was called.
- Response Time: The time taken by the API to execute.
- Method: The HTTP method the API used.
- Service Host: The application that served the request.

View Debug Logs

You can view the Debug logs dashboard by completing these steps:

Step 1 Click **Cisco Operations Hub** > **System** > **Logs**.

Step 2 Click Debug Dashboard.

The Debug Dashboard provides the following information:

- A visualisation of the count of logs from different components against time is provided as a histogram.
- All internal application events logged by respective services or software components are captured as debug logs.
- For every log file, the Debug Dashboard provides the following facets of information:
 - Time: The time of logging the event.
 - Source: The application where the event happened.
 - ContainerName: The applications microservice that generated the event.
 - LogLevel: The log level.
 - Message: The entire log content.

Discover Logs

The Discover option allows you to search and find logs based on custom search definitions.

You can view the Discover option by completing these steps:

- **Step 1** Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **System** > **Logs** to open **Logs** page.
- **Step 4** Click **Advanced** > **Discover** from the left navigation menu.
- **Step 5** Search for the log files.

You can perform basic text search, or advanced search by using KQL (Kibana Query Language) or Lucene search. Alternatively, you can also customize your search query based on time, debug-log type, selected fields, inspect option, and so on.

You can choose to save the search for later use from the dashboard.

Visualize Logs

You can create intuitive visualizations for your log data.

To create a visualization, complete these steps:

- **Step 1** Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **System** > **Logs** to open **Logs** page.
- **Step 4** Click **Advanced** > **Visualize** from the left navigation menu.

Step 5 Click Create visualisation.

- **Step 6** Choose one of these visualization type:
 - Area
 - Control
 - · Coordinate Map
 - Data Table
 - Gauge
 - Goal
 - Heat Map
 - · Horizontal Bar
 - Line
 - Markdown
 - Metric
 - Pie
 - Region Map
 - TSVB
 - Tag Cloud
 - Timelion
 - Vega
 - Vertical Bar

Step 7Choose a source type. You can choose from audit-log, debug-log, or logstash objects.You can choose to save the visualizations to generate panels when you Create Dashboards , on page 57.

Create Dashboards

The Dashboard option allows you to create a new dashboard by adding panels from the saved Discover Logs option or Visualize Logs option. You can also create a new Dashboard from scratch.

Complete these steps to create a Dashboard:

Step 1 Click Cisco Operations Hub > System > Logs.

- **Step 2** Click **Dashboard** > **Create dashboard**.
- Step 3 Click Add.
- **Step 4** On the Add panels menu, select the required searched and saved logs and visualizations.
- **Step 5** You can choose to change existing filters or add filters.
- **Step 6** Click **Create new** to choose a visualization type. You can choose from these visualization types:
 - Area
 - Control
 - Coordinate Map
 - Data Table
 - Gauge
 - Goal
 - Heat Map
 - · Horizontal Bar
 - Line
 - Markdown
 - Metric
 - Pie
 - Region Map
 - TSVB
 - Tag Cloud
 - Timelion
 - Vega
 - Vertical Bar

Step 7 Choose a source type. You can choose from audit-log, debug-log, or logstash objects.

You can view the saved dashboards on the dashboard list.

Manage Indices and Objects

The Management option allows you to manage your indices and index patterns, list your saved objects, and enables you to customize the logs with advanced options.

Complete these steps to use the Management option:

- **Step 1** Enter the Cisco Operations Hub URL https://{Hostname} in the web browser.
- **Step 2** On the Cisco Operations Hub, click the Cisco Operations Hub main menu button.
- **Step 3** Choose **System** > **Logs** to open **Logs** page.
- **Step 4** Click Advanced > Manage from the left navigation menu.

You can choose from these tools:

- Index Patterns: Lists all available patterns. The list includes all fields for the selected pattern and the field's associated core type as recorded by Elasticsearch.
- Saved Objects: Lists all saved objects. You can choose to delete saved objects and saved searches. You can also edit the raw data of saved objects.
- Advanced Settings: These are advanced settings, and must be handled with caution. For more detailed information, go through Kibana Advanced Settings.