



Preparing for the Installation

Before you install the Cisco Remote-PHY solution, consider the following:

- Power and cabling requirements that must be in place at your installation sites
- Equipment required to install the Cisco Remote-PHY solution
- Environmental conditions your installation site must meet to maintain normal operation



Note Do not unpack the equipment until you are ready to install it. Keep the equipment in the shipping container to prevent accidental damage until you determine an installation site.

- [Prerequisites and Preparation, on page 1](#)
- [Safety Guidelines, on page 2](#)
- [General Safety Warnings, on page 3](#)
- [Site Planning, on page 4](#)
- [Preventing Electrostatic Discharge Damage, on page 14](#)
- [Electrical Safety, on page 15](#)
- [Chassis-Lifting Guidelines, on page 16](#)
- [Tools and Equipment, on page 16](#)
- [Unpacking and Verifying Shipping Contents, on page 17](#)
- [Installation Checklist, on page 18](#)

Prerequisites and Preparation

Before you perform the procedures in this guide, we recommend that you:

- Read the safety guidelines in the next section and review the electrical safety and ESD-prevention guidelines in this guide.
- Ensure that you have all of the necessary tools and equipment.
- Ensure that the power and cabling requirements are in place at your installation site.
- Ensure that the equipment required to install the device is available.
- Ensure that your installation site meets the environmental conditions to maintain normal operation.

Before installing the device, you must consider power and cabling requirements that must be in place at your installation site, special equipment for installing the device, and the environmental conditions your installation site must meet to maintain normal operation.

The shipping package for the device is engineered to reduce the chances of product damage associated with routine material handling experienced during shipment:

- Device should always be transported or stored in its shipping package in the upright position.
- Keep the device in the shipping container until you have determined the installation site.



Note Inspect all items for shipping damage. If an item appears damaged, contact a Cisco customer service representative immediately.

Site Planning Checklist

Use the following checklist to perform and account for all the site-planning tasks described in this chapter:

- The site air conditioning system can compensate for the heat dissipation of the device.
- Electrical service to the site complies with the requirements.
- The electrical circuit servicing the device complies with the requirements.
- Consideration has been given to console port wiring and limitations of the cabling involved, according to TIA/EIA-232F.
- The Ethernet cabling distances are within limitations.
- The equipment rack in which you plan to install the chassis complies with requirements. Careful consideration has been given to safety, ease of maintenance, and proper airflow in selecting the location of the rack.

Safety Guidelines

Before you begin the installation or replacement procedure, review the safety guidelines in this section to avoid injuring yourself or damaging the equipment.



Note This section contains guidelines, and do not include every potentially hazardous situation. When you install the device, always use common sense and caution.

Safety Warnings

Safety warnings appear throughout this publication in procedures that, if performed incorrectly, might harm you. A warning symbol precedes each warning statement.

Before you install, configure, or perform maintenance on the device, review the documentation for the procedure you are about to perform, paying special attention to the safety warnings.



Note Do not unpack the device until you are ready to install it. Keep the chassis in the shipping container to prevent accidental damage until you determine an installation site. Use the appropriate unpacking documentation included with the device.

Read the installation instructions in this document before you connect the device to its power source. Failure to read and follow these guidelines could lead to an unsuccessful installation and possibly damage the device and components.

Safety Recommendations

The following guidelines will help to ensure your own safety and protect your Cisco equipment. This list does not cover all potentially hazardous situations, so *be alert*.

- Never attempt to lift an object that might be too heavy for you to lift by yourself.
- Always turn all power supplies off and unplug all power cables before opening the chassis.
- Always unplug the power cable before installing or removing a chassis.
- Keep the chassis area clear and dust free during and after installation.
- Keep tools and chassis components away from walk areas.
- Do not wear loose clothing, jewelry (including rings and chains), or other items that could get caught in the chassis. Fasten your tie or scarf and sleeves.
- The device operates safely when it is used in accordance with its marked electrical ratings and product-usage instructions.

General Safety Warnings

This section lists some of the safety warnings applicable to the Cisco Remote-PHY Compact Shelf. For the other applicable safety warnings, see *Regulatory Compliance and Safety Information for the Cisco Remote-PHY Compact Shelf*.



Warning **Statement 1073**—No User-Serviceable Parts

No user-serviceable parts inside. Do not open.



Warning **Statement 1005**—Double Pole Circuit Breaker

This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that the protective device is rated not greater than:

- AC: 20 A U.S. maximum
 - DC: 20 A U.S. maximum
-



Warning **Statement 1019**—Main Disconnecting Device

The plug-socket combination must be accessible at all times, because it serves as the main disconnecting device.



Warning **Statement 1086**—Power Terminals, Replace Cover

Hazardous voltage or energy may be present on power terminals. Always replace cover when terminals are not in service. Be sure uninsulated conductors are not accessible when covers is in place.

Site Planning

This section contains site-planning information, and will help you plan for the installation of the Cisco Remote-PHY Compact Device Shelf.

General Precautions

Observe the following general precautions when using and working with the Cisco Remote-PHY Compact Device Shelf:

- Keep your system components away from radiators and heat sources and do not block cooling vents.
- Do not spill food or liquids on your system components and never operate the product in a wet environment.
- Do not push any objects into the openings of your system components. Doing so can cause fire or electric shock by shorting out interior components.
- Position system cables and power supply cable carefully. Route system cables and power supply cable and plug such that they cannot be stepped on or tripped over. Be sure that nothing else rests on your system component cables or power cable.
- Do not modify power cables or plugs. Consult a licensed electrician or your power company for site modifications. Always follow your local and national wiring rules.
- If you turn off your system, wait at least 30 seconds before turning it on again to avoid system component damage.

Site Selection Guidelines

The Cisco Remote-PHY Compact Device Shelf require specific environmental operating conditions. Temperature, humidity, altitude, and vibration can affect the performance and reliability of the device. The following sections provide specific information to help you plan for a proper operating environment.

Site Environmental Requirements

Environmental monitoring protects the system and components from damage caused by excessive voltage and temperature conditions. To ensure normal operation and avoid unnecessary maintenance, plan and prepare your site configuration before installation. After installation, make sure the site maintains the environmental characteristics, as shown in the following table.

Environmental Requirements for the Cisco Remote-PHY Compact Shelf

The table below lists the operating and non-operating environmental site requirements. The ranges listed are those within which the equipment continues to operate; however, a measurement that is approaching the minimum or maximum of a range indicates a potential problem. You can maintain normal operation by anticipating and correcting environmental anomalies before they approach a maximum operating range.

Table 1: Specifications for Operating and Non-operating Environments for the Cisco Remote-PHY Compact Shelf

Specification	Minimum
Power Consumption	6*12: Typical 510W
	3*6: Typical 310W
Thermal Heat Dissipation	6*12: Typical 510W
	3*6: Typical 310W
Mean Time Between Failure (MTBF)	6*12: 121,480 hours
	3*6: 209,150 hours
Temperature Range	Operating: -40 to 140°F (-40 to 60°C)
	Non-operating: -40 to 185°F (-40 to 85°C)
Relative Humidity	5 to 90% non-condensing
Operating Altitude	0 to 10000 ft (0 to 3048 m)

Environmental Requirements for the Cisco CCAP RF Line Card

The table below lists the operating and non-operating environmental site requirements. The ranges listed are those within which the equipment continues to operate; however, a measurement that is approaching the minimum or maximum of a range indicates a potential problem. You can maintain normal operation by anticipating and correcting environmental anomalies before they approach a maximum operating range.

Table 2: Specifications for Operating and Non-operating Environments for the Cisco CCAP RF Line Card

Specification	Minimum
Power Consumption	211 W
Thermal Heat Dissipation	211 W
Mean Time Between Failure (MTBF)	360,870 hours
Temperature Range	Operating: 41 to 140°F (5 to 60°C)
	Non-operating: -4 to 149°F (-20 to 65°C)
Relative Humidity	Operating: 10 to 90% non-condensing
	Non-operating: 10 to 90%
Operating Altitude	-196 to 13,123 ft. (-60 to 4000 m)

Physical Characteristics

Be familiar with the physical characteristics of the Cisco Remote-PHY Compact Device Shelf to assist you in placing the system at a proper location.



Note For information regarding rack widths supported for the Cisco Remote-PHY Compact Device Shelf, see [General Rack-Selection Guidelines, on page 13](#).

The following table shows the weight and dimensions of the Cisco Remote-PHY Compact Device Shelf:

Table 3: Physical Characteristics of the Cisco Remote-PHY Compact Device Shelf

Characteristic	Cisco Remote-PHY Compact Device Shelf
Height	1.72 in. (43.69 mm)—1RU; rack-mount per EIA RS-310
Width	17.3 in. (439.42 mm)
Depth	21.78 in. (553.2 mm) Depth includes card handles, cable-management brackets, and power-supply handles
Weight	24 lb (11.3 kg)

The following list describes additional characteristics:

- Chassis height meets EIA-310 rack spacing 1RU (1.75 in. or 44.45 mm), universal rack mount
- Chassis width meets EIA-310 19 in. (17.3 in. or 439.42 mm) wide with rack brackets
- Ships with forward rack-mount brackets installed and an extra set included in the accessory kit

Site Power Guidelines

The Cisco Remote-PHY Compact Device Shelf has specific power and electrical wiring requirements. Adhering to these requirements ensures reliable operation of the system. Follow these precautions and recommendations when planning your site for the Cisco Remote-PHY Compact Device Shelf:

- The redundant power option provides a second, identical power supply to ensure that power to the chassis continues uninterrupted if one power supply fails or input power on one line fails.
- In systems configured with the redundant power option, connect each of the two power supplies to a separate input power source. If you fail to do this, your system might be susceptible to total power failure due to a fault in the external wiring or a tripped circuit breaker.
- To prevent a loss of input power, be sure the total maximum load on each circuit supplying the power supplies is within the current ratings of the wiring and breakers.
- Check the power at your site before installation, and periodically after installation, to ensure that you are receiving clean power. Install a power conditioner if necessary.
- Provide proper grounding to avoid personal injury and damage to the equipment due to lightning striking power lines or due to power surges. The chassis ground must be attached to a central office or other interior ground system.

**Caution**

This product requires short-circuit (overcurrent) protection to be provided as part of the building installation. Install only in accordance with national and local wiring regulations.

**Note**

The Cisco Remote-PHY Compact Device Shelf installation must comply with all applicable codes and is approved for use with copper conductors only. The ground bond fastening hardware should be of compatible material and preclude loosening, deterioration, and electrochemical corrosion of hardware and joined material. Attachment of the chassis ground to a central office or other interior ground system must be made with an AWG #6 gauge wire, copper ground conductor at a minimum.

Electrical Circuit Requirements

Each Cisco Remote-PHY Compact Device Shelf requires a dedicated electrical circuit. If you equip it with dual-power feeds, you must provide a separate circuit for each power supply to avoid compromising the power redundancy feature.

The Cisco Remote-PHY Compact Device Shelf can be powered by a DC or AC source. Ensure that equipment grounding is present and observe power-strip ratings. Make sure that the total ampere rating of all the products plugged into the power strip does not exceed 80 percent of the rating.

**Note**

The Cisco Remote-PHY Compact Device Shelf can support two AC or two DC power supplies. Do not install mixed AC and DC power supply units in the same chassis.

The following table contains specifications for DC-powered systems for the Cisco Remote-PHY Compact Device Shelf.

Table 4: Cisco Remote-PHY Compact Device Shelf DC Power Supply System Input Requirements

System Input Rating (Amps)	Circuit Breaker Rating (Amps)	AWG # Wire
12	20, double pole	10 or 12

The following table contains specifications for AC-powered systems for the Cisco Remote-PHY Compact Device Shelf.

Table 5: Cisco Remote-PHY Compact Device Shelf AC Power Supply System Input Requirements

System Input Rating (Amps)	Circuit Breaker Rating (Amps)
6	20, double pole



Note The Cisco Remote-PHY Compact Device Shelf AC power supply requires a 20 A circuit breaker.

The following table lists AC and DC power supply system rating requirements for the Cisco Remote-PHY Compact Device Shelf.

Table 6: AC and DC Power Supply Specifications for the Cisco Remote-PHY Compact Device Shelf

Description	Specification
Power supply voltage range	AC = 90–264 VAC DC = –40.5–72 VDC
Power supply declared ratings	AC = 100–240 VAC DC = –48/–60 VDC
Line frequency rating	50/60 Hz for AC power supplies

Site Cabling Guidelines

This section contains guidelines for wiring and cabling at your site. When preparing your site for network connections to the Cisco Remote-PHY Compact Device Shelf, consider the type of cable required for each component, and the cable limitations. Consider the distance limitations for signaling, EMI, and connector compatibility. Possible cable types are fiber, thick or thin coaxial, foil twisted-pair cabling, or unshielded twisted-pair cabling.

Also consider any additional interface equipment you need, such as transceivers, hubs, switches, modems, channel service units (CSUs), or data service units (DSUs).

Before you install the Cisco Remote-PHY Compact Device Shelf, have all the additional external equipment and cables at hand. For ordering information, contact a Cisco customer service representative.

The extent of your network and the distances between network interface connections depend in part on the following factors:

- Signal type
- Signal speed
- Transmission medium

The distance and rate limits referenced in the following sections are the IEEE-recommended maximum speeds and distances for signaling purposes. Use this information as guidelines when planning your network connections prior to installing the Cisco Remote-PHY Compact Device Shelf.

If wires exceed recommended distances, or if wires pass between buildings, give special consideration to the effect of a lightning strike in your vicinity. The electromagnetic pulse caused by lightning or other high-energy phenomena can easily couple enough energy into unshielded conductors to destroy electronic devices. If you have had problems of this sort in the past, you may want to consult experts in electrical surge suppression and shielding.

Console Port Connections

The Cisco Remote-PHY Compact Device Shelf provide console and auxiliary ports to connect a terminal or computer for local console access.

Both ports have RJ-45 connectors, support RS-232 asynchronous data, and have distance recommendations specified in the IEEE RS-232 standard.

Interference Considerations

When wires are run for a significant distance, there is a risk that stray signals will be induced on the wires as interference. If interference signals are strong, they can cause data errors or damage to the equipment.

The following sections describe sources of interference and how to minimize its effects on the Cisco Remote-PHY Compact Device Shelf.

Electromagnetic Interference

All the equipment powered by AC current can propagate electrical energy that can cause electromagnetic interference (EMI) and possibly affect the operation of other equipment. The typical sources of EMI are equipment power cords and power service cables from electric utility companies.

Strong EMI can destroy the signal drivers and receivers in the Cisco Remote-PHY Compact Device Shelf and even create an electrical hazard by causing power surges through power lines into installed equipment. These problems are rare, but could be catastrophic.

To resolve these problems, you need specialized knowledge and equipment, which could consume substantial time and money. However, you should ensure that you have a properly grounded and shielded electrical environment, paying special attention to the need for electrical surge suppression.

The following table lists electrode magnetic compliance standards for the Cisco Remote-PHY Compact Device Shelf.

Table 7: EMC and Safety Standards

EMC Standards	
----------------------	--

Electromagnetic Emissions Certification

- EN50083-2 - Europe
- KN 32 Class A - Korea
- FCC Part 15 Class A - United States
- ICES 003 Class A - Canada
- AS/NZS Class A - Australia
- CISPR 22 Class A - Europe
- EN55022 Class A - Europe
- VCCI Class A - Japan
- CNS13438 Class A - Taiwan
- IEC/EN61000-3-2 Power Line Harmonics - Europe
- IEC/EN61000-3-3 Voltage Fluctuations and Flicker - Europe

Immunity

- EN50083-2 - Europe
- CISPR 24 - Europe
- KN 35 - Korea
- IEC/EN61000-4-2 Electrostatic Discharge Immunity (8kV contact, 15kV air)
- IEC/EN61000-4-3 Radiated Immunity (10V/m)
- IEC/EN61000-4-4 Electrical Fast Transient Immunity (2kV power, 1kV signal)
- IEC/EN61000-4-5 Surge AC Port (4kV CM, 2kV DM)
- IEC/EN61000-4-5 Surge Signal Port (1kV)
- IEC/EN61000-4-5 Surge DC Port (1kV)
- IEC/EN61000-4-6 Immunity to Conducted Disturbances (10Vrms)
- IEC/EN61000-4-8 Power Frequency Magnetic Field Immunity (30A/m)
- IEC/EN61000-4-11 Voltage Dips, Short Interruptions, and Voltage Variations

European Telecommunication Standards Institute (ETSI)

- EN 300 386 Telecommunications Network Equipment (EMC)
- EN50083-2 Cable networks for television signals, sound signals and interactive services

	<ul style="list-style-type: none"> • EN55022 Information Technology Equipment (Emissions) • EN55024 Information Technology Equipment (Immunity) • EN61000-6-1 Generic Immunity Standard • EN61000-6-2 Generic Immunity Standard for Industrial Environments
Safety Standards	<ul style="list-style-type: none"> UL60950-1 CSA C22.2 No. 60950-1-03 EN 60950-1 IEC 60950-1 AS/NZS 60950.1 IEC 60825-1

Radio Frequency Interference

When electromagnetic fields act over a long distance, radio frequency interference (RFI) can be propagated. Building wiring can often act as an antenna, receiving the RFI signals and creating more EMI on the wiring.

If you use twisted-pair cable in your plant wiring with a good distribution of grounding conductors, the plant wiring is unlikely to emit radio interference. If you exceed the recommended distances, use a high-quality twisted-pair cable with one ground conductor for each data signal.

Lightning and AC Power Fault Interference

If signal wires exceed recommended cabling distances, or if signal wires pass between buildings, you should consider the effect that a lightning strike in your vicinity might have on the Cisco Remote-PHY Compact Device Shelf.

The electromagnetic pulse (EMP) generated by lightning or other high-energy phenomena can couple enough energy into unshielded conductors to damage or destroy electronic equipment. If you have previously experienced such problems, you should consult with RFI/EMI experts to ensure that you have adequate electrical surge suppression and shielding of signal cables in your Cisco Remote-PHY Compact Device Shelf operating environment.

Rack-Mounting Guidelines

This section describes guidelines on rack-mounting.

Precautions for Rack-Mounting

The following rack-mounting guidelines are provided to ensure your safety:

- Do not move large racks by yourself. Due to the height and weight of a rack, a minimum of two people are required to accomplish this task.
- Ensure that the rack is level and stable before extending a component from the rack.
- Ensure that proper airflow is provided to the components in the rack.

- Do not step or stand on any component or system when servicing other systems or components in a rack.
- When mounting the Cisco Remote-PHY Compact Device Shelf in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

General Rack-Selection Guidelines

The Cisco Remote-PHY Compact Device Shelf can be mounted in most two-post 19-in. equipment racks that comply with the Electronics Industries Association (EIA) standard for equipment racks (EIA-310-D 19-in.). The rack must have at least two posts with mounting flanges to mount the chassis.



Caution When mounting a chassis in any type of rack equipment, ensure that the inlet air to the chassis does not exceed 131°F (55°C).

The distance between the center lines of the mounting holes on the two mounting posts must be 18.31 in. ± 0.06 in. (46.50 cm ± 0.15 cm). The rack-mounting hardware included with the chassis is suitable for most 19-in. (48.3-cm) equipment racks.

Consider installing the Cisco Remote-PHY Compact Device Shelf in a rack with the following features:

- 19-in. (48.3-cm) wide rack.
- EIA or ETSI hole patterns in the mounting rails. Required mounting hardware is shipped with the Cisco Remote-PHY Compact Device Shelf. If the rack that you plan to install the system in has metric-threaded rails, you must provide your own metric-mounting hardware.
- Perforated top and open bottom for ventilation to prevent overheating.
- Leveling feet for stability.



Note The Cisco Remote-PHY Compact Device Shelf should not be installed in an enclosed rack because the chassis requires an unobstructed flow of cooling air to maintain acceptable operating temperatures for its internal components. Installing the device in any type of enclosed rack—even with the front and back doors removed—could disrupt the air flow, trap heat next to the chassis, and cause an overtemperature condition inside the device. If you use an enclosed rack, make certain that there are air vents on all sides of the rack and there is proper ventilation.

Equipment Rack Guidelines

The placement of racks can affect personnel safety, system maintenance, and the system's ability to operate within the environmental characteristics. Choose a proper location for the Cisco Remote-PHY Compact Device Shelf by following the guidelines below.

Locating for Safety

If the Cisco Remote-PHY Compact Device Shelf is the heaviest or the only piece of equipment in the rack, consider installing it at or near the bottom to ensure that the rack's center of gravity is as low as possible.

Locating for Easy Maintenance

Keep at least 3 feet of clear space in front of and behind the rack. This space ensures that you can remove the Cisco Remote-PHY Compact Device Shelf components and perform routine maintenance and upgrades easily.

Avoid installing the Cisco Remote-PHY Compact Device Shelf in a congested rack and consider how the routing of cables from other pieces of equipment in the same rack might affect access to the device.

The front and top of the chassis must remain unobstructed to ensure adequate airflow and prevent overheating inside the chassis.

Allow the following clearances for normal system maintenance:

- At the top of the chassis—At least 3 in. (7.6 cm)
- At the bottom of the chassis—At least 0.2 in. (5 mm)
- In front of the chassis and behind the chassis—3 to 4 ft (91.44 cm to 121.92 cm)

To avoid problems during installation and ongoing operation, follow these general precautions when you plan the equipment locations and connections:

- Use the **show environment all** and the **show facility-alarm status** commands regularly to check the internal system status. The environmental monitor continually checks the interior chassis environment; it provides warnings for high temperature and creates reports on any occurrences. If warning messages are displayed, take immediate action to identify the cause and correct the problem.
- Keep the Cisco Remote-PHY Compact Device Shelf off the floor and out of the areas that collect dust.
- Follow ESD-prevention procedures to avoid damage to equipment. Damage from static discharge can cause immediate or intermittent equipment failure.

Locating for Proper Airflow

Ensure that the location of the Cisco Remote-PHY Compact Device Shelf has enough airflow to keep the system operating within the environmental characteristics, and the air temperature is sufficient to compensate for the heat dissipated by the system.

Avoid locating the Cisco Remote-PHY Compact Device Shelf in a location in which the chassis air intake vents could draw in the exhaust air from adjacent equipment. Consider how the air flows through the device. The airflow direction is front to back with ambient air drawn in from the venting located on the chassis' front sides.

Preventing Electrostatic Discharge Damage

Electrostatic discharge (ESD) damage occurs when electronic cards or components are improperly handled resulting in complete or intermittent failures. Static electricity can harm delicate components inside your system. To prevent static damage, discharge static electricity from your body before you touch any of your system components, such as a microprocessor. As you continue to work on your system, periodically touch an unpainted metal surface on the computer chassis.

The following are guidelines for preventing ESD damage:

- Always use an ESD-preventive wrist or ankle strap and ensure that it makes good skin contact. Before removing a card from the chassis, connect the equipment end of the strap to the ESD plug at the bottom of the chassis below the power entry modules.

- Handle line cards by faceplates and carrier edges only; avoid touching the card components or connector pins.
- When removing a module, place the removed module component-side-up on an antistatic surface or in a static-shielding bag. If the module is to be returned to the factory, immediately place it in a static-shielding bag.
- Avoid contact between the modules and clothing. The wrist strap protects the card from ESD voltages only on the body; ESD voltages on clothing can still cause damage.
- When transporting a sensitive component, place it in an antistatic container or packaging.
- Handle all sensitive components in a static-safe area. If possible, use antistatic floor pads and workbench pads.

**Caution**

For safety, periodically check the resistance value of the antistatic strap. The measurement should be between 1 and 10 ohms.

**Caution**

Always tighten the captive installation screws on all the system components when you are installing them. These screws prevent accidental removal of the module, provide proper grounding for the system, and help ensure that the bus connectors are properly seated in the backplane.

Electrical Safety

All the system components are hot-swappable. They are designed to be removed and replaced while the system is operating, without presenting an electrical hazard or damage to the system.

Follow these basic guidelines when you are working with any electrical equipment:

- Before beginning any procedures requiring access to the chassis interior, locate the emergency power-off switch for the room in which you are working.
- Disconnect all power and external cables before installing or removing a chassis.
- Do not work alone when potentially hazardous conditions exist.
- Never assume that power has been disconnected from a circuit; always check.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe. Never install equipment that appears damaged.
- Carefully examine your work area for possible hazards such as moist floors, ungrounded power extension cables, and missing safety grounds.

In addition, use the following guidelines when working with any equipment that is disconnected from a power source, but is still connected to telephone wiring or other network cabling:

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.

- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.



Warning **Statement 1001—Work During Lightning Activity**

Do not work on the system or connect or disconnect cables during periods of lightning activity.

Chassis-Lifting Guidelines

The chassis is not intended to be moved frequently. Before you install the system, ensure that your site is properly prepared so that you can avoid having to move the chassis later to accommodate power sources and network connections.

Each time you lift the chassis or any heavy object, follow these guidelines:

- Ensure that your footing is solid, and balance the weight of the chassis between your feet.
- Lift the chassis slowly; never move suddenly or twist your body as you lift.
- Keep your back straight and lift with your legs, not your back. If you must bend down to lift the chassis, bend at the knees, not at the waist, to reduce the strain on your back muscles.
- Do not remove installed components from the chassis.
- Always disconnect all external cables before lifting or moving the chassis.

Tools and Equipment

The following tools and equipment are recommended as the minimum necessary equipment to install the Cisco Remote-PHY Compact Device Shelf. You may need additional tools and equipment to install associated equipment and cables. You may also require test equipment to check electronic and optical signal levels, power levels, and communications links.

- Phillips hand screwdriver
- 3.5-mm flat-blade screwdriver
- Tape measure (optional)
- Level (optional)
- Power drill
- 8-gauge wire
- Rack-mount brackets

You need the following tools to install and cable the Cisco CCAP RF line card:

- T-10 Torx driver tool

- 1/4-inch flathead screwdriver
- Blank Cisco cBR-8 slot cover (if required)
- ESD-preventive wrist strap
- Antistatic surface, such as a mat or antistatic bag

Unpacking and Verifying Shipping Contents

When you receive your chassis, perform the following steps and use the shipping contents checklist in the following section.

Procedure

-
- Step 1** Inspect the box for any shipping damage. (If there is damage, contact your Cisco service representative).
 - Step 2** Unpack the Cisco Remote-PHY Compact Device Shelf.
 - Step 3** Perform a visual inspection of the chassis.
 - Step 4** After you have unpacked the system, verify that you have received all of the required components, including all the accessory items. Using the packing list as a guide, verify that you have received all the equipment listed in your order, and ensure that the configuration matches the packing list.
-

Checking the Shipping Container Contents

Use the components list shown in the following table to check the contents of the Cisco Remote-PHY Compact Device Shelf shipping container. Do not discard the shipping container. You need the container if you move or have to ship the Cisco Remote-PHY Compact Device Shelf in the future.

Table 8: Cisco Remote-PHY Compact Device Shelf Shipping Container Contents

Component	Description
Chassis	Cisco Remote-PHY Compact Device Shelf are configured with dual AC or dual DC power supplies.
Accessories Kit	2 Rack-mount brackets and 1 grounding lug.
Note You must order the Accessories Kit separately if you order the Cisco Remote-PHY Compact Device Shelf chassis as a spare.	Two sets of screws, one each for: <ul style="list-style-type: none"> • Rack-mount brackets (12 flat head screws (silver)) • Grounding lug (2 screws (silver) with star washers)
Optional Equipment	Power cord if an AC power supply was shipped. There are none for the DC power supply units.

Installation Checklist

To assist you with your installation and to provide a historical record of what was done by whom, print or photocopy the Installation Checklist below. Use this to record when each procedure or verification is completed. When the checklist is completed, place it in your site log along with the other records for your new device.

Table 9: Installation Checklist

Task	Verified By	Date
Date chassis received		
Chassis and all accessories unpacked		
Types and numbers of interfaces verified		
Safety recommendations and guidelines reviewed		
Installation Checklist copied		
Site log established and background information entered		
Site power voltages verified		
Site environmental specifications verified		
Required passwords, IP addresses, device names, and so on, available		
Required tools available		
Network connection equipment available		
AC power cable(s) connected to AC source(s) and device		
DC power cable(s) connected to DC source(s) and device		
Network interface cables and devices connected		
System power turned on		
System boot complete (STATUS LED is on)		
Ethernet port adapters and NIMs (where applicable) are operational		
Correct hardware configuration displayed after system banner appears		

Task	Verified By	Date
Correct licenses installed on the device		

