

# Cisco Service Control Application for Broadband Download Guide,

#### Release 3.8.x

- 1 Overview
- 2 Compatibility Matrix
- 3 Downloading Software
- 4 Obtaining Documentation and Submitting a Service Request

#### 1 Overview

The following instructions explain how to download the various components of the Service Control Solution from the Cisco software download center.

The Cisco Service Control Solution is composed out of several components that are available on the Cisco center for customer download. These components are:

- Cisco Service Control Application for Broadband (SCA BB)
- Cisco Service Control Operating System (SCOS)
- Cisco Service Control Collection Manager (SCMS CM)
- Cisco Service Control Subscriber Manager (SCMS SM)

Before downloading new software, refer to the "Compatibility Matrix" section on page 3 below and read the release notes of the various components. The "Compatibility Matrix" section on page 3 provides information regarding the compatibility between various Service Control components and versions. These guidelines must be adhered to when installing new software.

After you have downloaded the new software, see the Installation Guide located in the SCA BB package for a step-by-step description of how to install the solution.

### **2** Compatibility Matrix

Table 1 provides compatibility information for the various components of the Service Control Solution for the 3.x release train and Table 2 provides compatibility information for the various components of the Service Control Solution for the 2.x release train. For each SCA BB revision, the list of compatible versions of the SCOS, SCMS CM, SCA Reporter and SCMS SM are listed. We recommend using the latest revision available for each category unless otherwise noted.



The Cisco SCE8000-32xGBE is only supported in cascade topology.

Table 1 SCA BB 3.x Release Train

	HW Platforms	SCOS	СМ	SM	SCA BB Reporter	Insight
SCA BB 3.8.5	SCE-1010-2XGBE	3.8.5	3.8.5	3.8.5	3.8.5	Insight V3.4
	SCE-2020-4XGBE					
	SCE-8000-4xTGBE					
	SCE-8000-2xTGBE					
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE-8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE-8000-32xGBE <sup>1</sup>					
	SCE-8000-Dual DPI					
SCA BB 3.8.0	SCE-1010-2XGBE	3.8.0	3.8.0	3.8.0	3.8.0	Insight V3.3
	SCE-2020-4XGBE		3.7.5	3.7.5		Insight V3.2
	SCE-8000-4xTGBE					
	SCE-8000-2xTGBE					
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE-8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE-8000-32xGBE <sup>2</sup>					
	SCE-8000-Dual DPI					
SCA BB 3.7.5	SCE-1010-2XGBE	3.7.5	3.7.5	3.7.1	3.7.5	Insight V3.2
	SCE-2020-4XGBE			3.7.2		
	SCE-8000-4xTGBE			3.7.5		
	SCE-8000-2xTGBE					
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE-8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE-8000-32xGBE <sup>3</sup>					
	SCE-8000-Dual DPI					

Table 1 SCA BB 3.x Release Train (continued)

	HW Platforms	scos	СМ	SM	SCA BB Reporter	Insight
SCA BB 3.7.2	SCE-1010-2XGBE	3.7.2	3.7.0	3.7.0	3.7.2	Insight V3
	SCE-2020-4XGBE		3.7.1	3.7.1		
	SCE-8000-4xTGBE		3.7.2	3.7.2		
	SCE-8000-2xTGBE					
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE-8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE-8000-32xGBE <sup>4</sup>					
	SCE-8000-Dual DPI					
SCA BB 3.7.1	SCE-1010-2XGBE	3.7.1	3.7.0	3.7.0	3.7.1	Insight V2
	SCE-2020-4XGBE		3.7.1	3.7.1		Insight V3
	SCE-8000-4xTGBE					
	SCE-8000-2xTGBE					
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE-8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE-8000-32xGBE <sup>5</sup>					
	SCE-8000-Dual DPI					
SCA BB 3.7.0	SCE-1010-2XGBE	3.7.0	3.6.0	3.6.0	3.7.0	Insight V1
	SCE-2020-4XGBE		3.6.5	3.6.5		Insight V2
	SCE-8000-4xTGBE		3.7.0	3.7.0		Insight V3
	SCE-8000-2xTGBE					
	SCE-8000-16xGBE					
	SCE-8000-32xGBE <sup>6</sup>					
	SCE-8000-Dual DPI					
SCA BB 3.6.5	SCE-1010-2XGBE	3.6.5	3.5.5	3.5.5	3.6.5	Insight V1
	SCE-2020-4XGBE		3.6.0	3.6.0		Insight V2
	SCE8000-4xTGBE		3.6.5	3.6.5		
	SCE8000-2xTGBE					
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE8000-32xGBE <sup>5</sup>					
	SCE8000-Dual DPI					

Table 1 SCA BB 3.x Release Train (continued)

	HW Platforms	scos	СМ	SM	SCA BB Reporter	Insight
SCA BB 3.6.0	SCE-1010-2XGBE	3.6.1	3.5.5	3.5.5	3.6.0	_
Build 454	SCE-2020-4XGBE		3.6.0	3.6.0		
	SCE8000-4xTGBE				Also packaged with SCA BB	
	SCE8000-2xTGBE				Console	
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE8000-32xGBE <sup>5</sup>					
	SCE8000-Dual DPI					
SCA BB 3.6.0	SCE-1010-2XGBE	3.6.0	3.5.5	3.5.5	3.6.0	_
	SCE-2020-4XGBE		3.6.0	3.6.0		
	SCE8000-4xTGBE				Also packaged with SCA BB	
	SCE8000-2xTGBE				Console	
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
	SCE8000-32xGBE <sup>5</sup>					
	SCE8000-Dual DPI					
SCA BB 3.5.5	SCE-1010-2xGBE 2U	3.5.5	3.5.5	3.5.5	3.5.5	_
	SCE-2020-4xGBE		3.5.0	3.5.0		
	SCE8000-2xTGBE		3.1.6	3.1.6	Also packaged with SCA BB	
	SCE8000-4xTGBE				Console	
	SCE8000-8xGBE					
	SCE8000-8xGBE + 1xTGBE					
	SCE8000-16xGBE					
	SCE8000-16xGBE + 2xTGBE					
SCA BB 3.5.0	SCE-1010-2xGBE 2U	3.5.0	3.5.5	3.5.5	3.5.0	_
	SCE-2020-4xGBE		3.5.0	3.5.0		
	SCE8000-2xTGBE		3.1.6	3.1.6	Also packaged with SCA BB	
	SCE8000-4xTGBE				Console	
SCA BB .3.1.7	SCE-1010-2xGBE 2U	3.1.7	3.5.5	3.5.5	3.1.6	_
	SCE-2020-4xGBE		3.5.0	3.5.0		
	SCE8000-2xTGBE		3.1.6	3.1.6	Also packaged with SCA BB	
	SCE8000-4xTGBE				Console	
SCA BB 3.1.6	SCE8000-2xTGBE	3.1.6\$	3.5.5	3.5.5	3.1.6	_
(PQI 3.1.6S)	SCE8000-4xTGBE		3.5.0	3.5.0		
,			3.1.6	3.1.6	Also packaged with SCA BB Console	

Table 1 SCA BB 3.x Release Train (continued)

	HW Platforms	scos	СМ	SM	SCA BB Reporter	Insight
SCA BB 3.1.6	SCE-1010-2xGBE 2U	3.1.6	3.5.5	3.5.5	3.1.6	_
	SCE-2020-4xGBE		3.5.0	3.5.0		
	SCE-2020-4/8xFE		3.1.6	3.1.6	Also packaged with SCA BB Console	
SCA BB 3.1.5	SCE-1010-2xGBE 2U	3.1.5	3.0.3 <sup>7</sup>	3.1.0	3.1.5	_
	SCE-2020-4xGBE		3.0.5	3.1.1		
	SCE-2020-4/8xFE		3.0.6	3.1.5		
			$3.1.0^{8}$	3.1.6		
			$3.1.5^{8}$	3.5.0	Also packaged with SCA BB	
			$3.1.6^{8}$		Console	
			3.5.0			
SCA BB 3.1.1	SCE-1010-2xGBE 2U	3.1.1	3.0.3 <sup>7</sup>	3.1.0	3.1.0	_
	SCE-2020-4xGBE		3.0.5	3.1.1		
	SCE-2020-4/8xFE		3.0.6	3.1.5		
			$3.1.0^{8}$	3.1.6		
			$3.1.5^{8}$	3.5.0	Also packaged with SCA BB	
			$3.1.6^{8}$		Console	
			3.5.0			
SCA BB 3.1.0	SCE-1010-2xGBE 2U	3.1.0	3.0.3 <sup>7</sup>	3.1.0	3.1.0	_
	SCE-2020-4xGBE		3.0.5	3.1.1		
	SCE-2020-4/8xFE		3.0.6	3.1.5		
			$3.1.0^{8}$		Also packaged with SCA BB	
			$3.1.5^{8}$		Console	
SCA BB 3.0.6	SCE-1010-2xGBE 2U	3.0.6	3.0.0	3.0.39	3.0.5	_
	SCE-1010-2xGBE 1.5U		$3.0.3^{7}$	3.0.5		
	SCE-2020-4xGBE		3.0.5	$3.0.6^{10}$		
	SCE-2020-4/8xFE		3.0.6	3.0.6A		
			3.1.0	3.1.0		
			$3.1.5^{8}$	3.1.1	Also packaged with SCA BB	
				3.1.5	Console	
SCA BB 3.0.5A	SCE-1010-2xGBE 2U	3.0.5	3.0.0	3.0.39	3.0.5	_
	SCE-1010-2xGBE 1.5U		$3.0.3^{7}$	3.0.5		
	SCE-2020-4xGBE		3.0.5	$3.0.6^{10}$		
	SCE-2020-4/8xFE		3.0.6	3.0.6A		
			3.1.0	3.1.0		
			$3.1.5^{8}$	3.1.1	Also packaged with SCA BB	
				3.1.5	Console	

Table 1 SCA BB 3.x Release Train (continued)

	HW Platforms	SCOS	СМ	SM	SCA BB Reporter	Insight
SCA BB 3.0.4	SCE-1010-2xGBE 2U	3.0.4	3.0.0	3.0.0	3.0.3	
	SCE-1010-2xGBE 1.5U		3.0.3 <sup>7</sup>	3.0.1		
	SCE-2020-4xGBE		3.0.5	$3.0.3^{9,11}$		
	SCE-2020-4/8xFE		3.0.6	3.0.5		
			3.1.0	$3.0.6^{10}$		
				3.0.6A	Also packaged with SCA BB	
				3.1.0	Console	
SCA BB 3.0.3	SCE-1010-2xGBE 2U	3.0.3	3.0.0	3.0.0	3.0.3	_
	SCE-1010-2xGBE 1.5U		$3.0.3^{7}$	3.0.1		
	SCE-2020-4xGBE		3.0.5	$3.0.3^9$		
	SCE-2020-4/8xFE		3.0.6	3.0.5		
			3.1.0	$3.0.6^{10}$		
				3.0.6A	Also packaged with SCA BB	
				3.1.0	Console	
SCA BB 3.0.1	SCE-1010-2xGBE 2U	3.0.1	3.0.0	3.0.0	3.0.0	_
	SCE-1010-2xGBE 1.5U			3.0.1		
	SCE-2020-4xGBE			$3.0.3^{9,11}$	Also packaged with SCA BB	
	SCE-2020-4/8xFE				Console	
SCA BB 3.0.0	SCE-1010-2xGBE 2U	3.0.0	3.0.0	3.0.0	3.0.0	_
	SCE-1010-2xGBE 1.5U			$3.0.3^{9,11}$		
	SCE-2020-4xGBE			3.0.6A	Also packaged with SCA BB	
	SCE-2020-4/8xFE				Console	

<sup>1.</sup> Only supported in cascade topology.

<sup>2.</sup> Only supported in cascade topology.

<sup>3.</sup> Only supported in cascade topology.

<sup>4.</sup> Only supported in cascade topology.

<sup>5.</sup> Only supported in cascade topology.

<sup>6.</sup> Only supported in cascade topology.

<sup>7.</sup> VoIP reporting capabilities are only supported with CM 3.0.3 and up.

<sup>8.</sup> Virtual Links reporting capabilities are only supported with CM 3.1.0 or higher.

<sup>9.</sup> Use SCMS-SM 3.0.3 patch for SM-cluster upgrades from SM3.0.x to SM3.0.3.

<sup>10.</sup> Legacy support only (replaced by 3.0.6A).

<sup>11.</sup> Using releases SCMS-SM 3.0.3 and up is recommended for these SCA BB releases due to a known limitation of previous SCMS-SM versions. See details of resolved issue CSCsd93885 in the SCMS-SM release notes.

Table 2 SCA BB 2.x Release Train

	<b>HW Platforms</b>	scos	SCMS CM	SCMS SM	SCA Reporter
SCA BB 2.5.10	SCE-1010-2xGBE 2U	2.5.10	2.5.5	2.5.5	2.5.5
	SCE-2020-4xGBE		2.5.8	2.5.6	
	SCE-2020-4/8xFE			2.5.7	
				2.5.7A	
				2.5.8	
				$3.0.6^{1}$	
				3.0.6A	
SCA BB 2.5.9	SCE-1010-2xGBE 2U	2.5.9	2.5.5	2.5.5	2.5.5
	SCE-2020-4xGBE		2.5.8	2.5.6	
	SCE-2020-4/8xFE			2.5.7	
				2.5.8	
SCA BB 2.5.8	SCE-1010-2xGBE 2U	2.5.8	2.5.5	2.5.5	2.5.5
	SCE-2020-4xGBE		2.5.8	2.5.6	
	SCE-2020-4/8xFE			2.5.7	
				2.5.8	
SCA BB 2.5.7	SCE-1010-2xGBE 2U	2.5.7	2.5.5	2.5.2	2.5.5
	SCE-2020-4xGBE			2.5.5	
	SCE-2020-4/8xFE			2.5.6	
				2.5.7	
				2.5.8	
SCA BB 2.5.6	SCE-1010-2xGBE 2U	2.5.6,	2.5.5	2.5.2	2.5.5
	SCE-1010-2xGBE 1.5U	2.5.5		2.5.5	
	SCE-2020-4xGBE			2.5.6	
				2.5.7	
				2.5.8	
SCA BB 2.5.5	SCE-1010-2xGBE 2U	2.5.5	2.5.5	2.5.2	2.5.5
	SCE-1010-2xGBE 1.5U			2.5.5	
	SCE-2020-4xGBE			2.5.7	
SCA BB 2.5.2	SCE-1010-2xGBE 2U	2.5.2	2.5.1	2.5.2	2.5
	SCE-1010-2xGBE 1.5U		2.5.5	2.5.5	
	SCE-2020-4xGBE				
SCA BB 2.1.8	SCE-1010-2xGBE 2U	2.1.8	2.0	2.0.3	2.1
	SCE-1010-2xGBE 1.5U		2.5.1	2.2.1	
	SCE-2020-4xGBE				

<sup>1.</sup> Legacy support only (replaced by 3.0.6A).

## **3** Downloading Software

Table 3 summarizes the contents of each software package.

Table 3 Software Package Contents Summary

Software Package	Content	Download Directory	Comment
SCA BB	<ul> <li>SCE Loadable Image (SCE PQI)</li> <li>SM Loadable Image (SM PQI)</li> <li>Client Software (Console, Reporter, &amp; Command line</li> </ul>	http://www.cisco.com/cgi-bin/table build.pl/scasbb	MIB files for release 3.0.3 and up can be downloaded from ftp://ftp.cisco.com/pub/mibs/  * Starting with release 3.0, QP-API is part of the SCE Subscriber API.
	utilities)  • Service Configuration API  • Quota Provisioning API *		
scos	<ul> <li>PKG File for each platform</li> <li>Image file</li> <li>Image used for bootrom upgrades</li> <li>FPGA and PROM files</li> <li>Configuration files</li> <li>EM Agent installation files</li> </ul>	<ul> <li>Prior to SCOS Rel 3.1.7:         http://www.cisco.com/cgi-bin/t ablebuild.pl/scos     </li> <li>SCOS Rel 3.1.7 and up:         http://www.cisco.com/cgi-bin/t ablebuild.pl/scos-cr     </li> </ul>	MIB files for release 3.0.3 and up can be downloaded from ftp://ftp.cisco.com/pub/mibs/
SCMS SM Release 2.x	<ul> <li>SM distribution</li> <li>SM installation scripts</li> <li>SM API (C &amp; Java)</li> <li>LEGs: <ul> <li>RDR DHCP LEG</li> <li>DHCP lease query LEG</li> <li>CNR LEG</li> </ul> </li> <li>SM Veritas agents</li> </ul>	http://www.cisco.com/cgi-bin/table build.pl/scsm	SCMS SM 2.x distribution is split into several parts in the CCO. Refer to readme.txt file (located in download directory) for a description of how to merge the distribution.
SCMS SM Release 3.x	<ul> <li>SM distributions (Solaris\Red-Hat Linux):</li> <li>SM server</li> <li>SM installation scripts</li> <li>Veritas Cluster Agents</li> <li>RADIUS Listener</li> <li>SM API (C &amp; Java)</li> <li>SCE Subscriber API</li> <li>LEGs:  – SCE-Sniffer DHCP LEG  – SCE-Sniffer RADIUS LEG  – DHCP lease query LEG  – CNR LEG  – MPLS-VPN BGP LEG</li> </ul>	http://www.cisco.com/cgi-bin/table build.pl/scsm	

Table 3 Software Package Contents Summary (continued)

Software Package	Content	Download Directory	Comment
SCMS CM	<ul> <li>CMS CM + Sybase software for Solaris</li> <li>SCMS CM + Sybase software for Linux</li> <li>SCMS CM for Solaris/Linux</li> </ul>	http://www.cisco.com/cgi-bin/table build.pl/sccm	SCMS CM distribution is split into several parts in the CCO. Refer to the readme.txt file (located in download directory) for a description of how to merge the distribution
SCA Reporter	Client software for MS-Windows, and command-line installer package for Redhat Linux	http://www.cisco.com/cgi-bin/table build.pl/scasbb	

Americas Headquarters Cisco Systems, Inc. San Jose, CA Asia Pacific Headquarters Cisco Systems (USA) Pte. Ltd. Singapore Europe Headquarters Cisco Systems International BV Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.

### 4 Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at: <a href="http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html">http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html</a>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <a href="https://www.cisco.com/go/trademarks">www.cisco.com/go/trademarks</a>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)