



Configuring Multi-Site

This chapter contains these sections:

- [About VXLAN EVPN Multi-Site, on page 1](#)
- [Dual RD Support for Multi-Site, on page 2](#)
- [RP Placement in the DCI Core, on page 2](#)
- [Interoperability with EVPN Multi-Homing Using ESI for Multi-Site Anycast BGW , on page 3](#)
- [Guidelines and Limitations for VXLAN EVPN Multi-Site, on page 3](#)
- [Enabling VXLAN EVPN Multi-Site, on page 7](#)
- [Configuring Dual RD Support for Multi-Site, on page 8](#)
- [Configuring VNI Dual Mode, on page 9](#)
- [Configuring Fabric/DCI Link Tracking, on page 10](#)
- [Configuring Fabric External Neighbors, on page 11](#)
- [Configuring VXLAN EVPN Multi-Site Storm Control, on page 12](#)
- [Verifying VXLAN EVPN Multi-Site Storm Control, on page 13](#)
- [Multi-Site with vPC Support, on page 14](#)
- [Configuration Example for Multi-Site with Asymmetric VNIs, on page 19](#)
- [TRM with Multi-Site, on page 20](#)

About VXLAN EVPN Multi-Site

The VXLAN EVPN Multi-Site solution interconnects two or more BGP-based Ethernet VPN (EVPN) sites/fabrics (overlay domains) in a scalable fashion over an IP-only network. This solution uses border gateways (BGWs) in anycast or vPC mode to terminate and interconnect two sites. The BGWs provide the network control boundary that is necessary for traffic enforcement and failure containment functionality.

In the BGP control plane for releases prior to Cisco NX-OS Release 9.3(5), BGP sessions between the BGWs rewrite the next hop information of EVPN routes and reoriginate them. Beginning with Cisco NX-OS Release 9.3(5), reorigination is always enabled (with either single or dual route distinguishers), and rewrite is not performed. For more information, see [Dual RD Support for Multi-Site, on page 2](#).

VXLAN Tunnel Endpoints (VTEPs) are only aware of their overlay domain internal neighbors, including the BGWs. All routes external to the fabric have a next hop on the BGWs for Layer 2 and Layer 3 traffic.

The BGW is the node that interacts with nodes within a site and with nodes that are external to the site. For example, in a leaf-spine data center fabric, it can be a leaf, a spine, or a separate device acting as a gateway to interconnect the sites.

The VXLAN EVPN Multi-Site feature can be conceptualized as multiple site-local EVPN control planes and IP forwarding domains interconnected via a single common EVPN control and IP forwarding domain. Every EVPN node is identified with a unique site-scope identifier. A site-local EVPN domain consists of EVPN nodes with the same site identifier. BGWs on one hand are also part of the site-specific EVPN domain and on the other hand a part of a common EVPN domain to interconnect with BGWs from other sites. For a given site, these BGWs facilitate site-specific nodes to visualize all other sites to be reachable only via them. This means:

- Site-local bridging domains are interconnected only via BGWs with bridging domains from other sites.
- Site-local routing domains are interconnected only via BGWs with routing domains from other sites.
- Site-local flood domains are interconnected only via BGWs with flood domains from other sites.

Selective Advertisement is defined as the configuration of the per-tenant information on the BGW. Specifically, this means IP VRF or MAC VRF (EVPN instance). In cases where external connectivity (VRF-lite) and EVPN Multi-Site coexist on the same BGW, the advertisements are always enabled.

Dual RD Support for Multi-Site

Beginning with Cisco NX-OS Release 9.3(5), VXLAN EVPN Multi-Site supports route reorigination with dual route distinguishers (RDs). This behavior is enabled automatically.

Each VRF or L2VNI tracks two RDs: a primary RD (which is unique) and a secondary RD (which is the same across BGWs). Reoriginated routes are advertised with the secondary type-0 RD (site-id:VNI). All other routes are advertised with the primary RD. The secondary RD is allocated automatically once the router is in Multi-Site BGW mode.

If the site ID is greater than 2 bytes, the secondary RD can't be generated automatically on the Multi-Site BGW, and the following message appears:

```
%BGP-4-DUAL_RD_GENERATION_FAILED: bgp- [12564] Unable to generate dual RD on EVPN multisite
border gateway. This may increase memory consumption on other BGP routers receiving
re-originated EVPN routes. Configure router bgp <asn> ; rd dual id <id> to avoid it.
```

In this case, you can either manually configure the secondary RD value or disable dual RDs. For more information, see [Configuring Dual RD Support for Multi-Site, on page 8](#).

RP Placement in the DCI Core

- PIM RP placement for DCI multicast underlay
 - PIM RP and multicast groups for fabric underlay and DCI underlay must be different.
 - DCI underlay group must not overlap with fabric underlay group.
 - Multicast groups and RPs in DCI and fabric networks should be distinct and configured based on specific ranges.
 - RP can be placed on any node in the DCI core, there can be one or more RPs.
- Direct BGW to BGW Peering Deployment
 - PIM RP should be set on BGWs with anycast PIM RP for redundancy.

- BGW to Cloud Model Deployment
 - PIM RP could be placed on the DCI underlay layer, such as core routers or superspines.

Interoperability with EVPN Multi-Homing Using ESI for Multi-Site Anycast BGW

Beginning Cisco NX-OS Release 10.2(2)F, EVPN MAC/IP routes (Type 2) with non-reserved as well as with reserved ESI (0 or MAX-ESI) values are evaluated for forwarding (ESI RX). The definition of the EVPN MAC/IP route resolution is defined in [RFC 7432 Section 9.2.2](#).

EVPN MAC/IP routes (Type 2) -

- with reserved ESI value (0 or MAX-ESI) are resolved solely by the MAC/IP route alone (BGP next-hop within Type 2).
- with non-reserved ESI value are resolved only if accompanied by a per-ES Ethernet Auto-Discovery route (Type 1, per-ES EAD) is present.

In addition to the MAC/IP route resolution as mentioned above, the Multi-Site BGW supports the forward, rewrite and re-originate of MAC/IP routes with reserved and non-reserved ESI values. In all these cases, the per-ES EAD route is re-originated by the Multi-Site BGW.

The EVPN MAC/IP route resolution with the different ESI values is supported on Cisco Nexus 9300-EX, -FX, -FX2, -FX3, and -GX Platform Switches in Anycast and vPC Border Gateway mode.

Guidelines and Limitations for VXLAN EVPN Multi-Site

VXLAN EVPN Multi-Site has the following configuration guidelines and limitations:

- The following switches support VXLAN EVPN Multi-Site:
 - Cisco Nexus 9300-EX and 9300-FX platform switches (except Cisco Nexus 9348GC-FXP platform switches)
 - Cisco Nexus 9300-FX2 platform switches
 - Cisco Nexus 9300-FX3 platform switches
 - Cisco Nexus 9300-GX platform switches
 - Cisco Nexus 9300-GX2 platform switches
 - Cisco Nexus 9500 platform switches with -EX or -FX or -GX line cards



Note

Cisco Nexus 9500 platform switches with -R/RX line cards don't support VXLAN EVPN Multi-Site.

- Beginning with Cisco NX-OS Release 10.2(3)F, the VXLAN EVPN Multi-Site is supported on the Cisco Nexus 9300-GX2 platform switches.

Switch or Port restrictions

- The **evpn multisite dci-tracking** is mandatory for anycast BGWs and vPC BGW DCI links.
- EVPN multisite DCI-tracking and EVPN multisite fabric-tracking are only supported on physical interfaces. Use on SVIs is not supported.
- Cisco Nexus 9332C and 9364C platform switches can be BGWs.

Deployment restrictions

- In a VXLAN EVPN Multi-Site deployment, when you use the ttag feature, make sure that the ttag is stripped (**ttag-strip**) on BGW's DCI interfaces attached to Non-NXOS gear.
- VXLAN EVPN Multi-Site and Tenant Routed Multicast (TRM) are supported between sources and receivers deployed across different sites.
- The Multi-Site BGW allows the coexistence of Multi-Site extensions (Layer 2 unicast/multicast and Layer 3 unicast) as well as Layer 3 unicast and multicast external connectivity.
- In TRM with multi-site deployments, all BGWs receive traffic from fabric. However, only the designated forwarder (DF) BGW forwards the traffic. All other BGWs drop the traffic through a default drop ACL. This ACL is programmed in all DCI tracking ports. Don't remove the **evpn multisite dci-tracking** configuration from the DCI uplink ports. If you do, you remove the ACL, which creates a nondeterministic traffic flow in which packets can be dropped or duplicated instead of deterministically forwarded by only one BGW, the DF.
- Prior to NX-OS 10.2(2)F only ingress replication was supported between DCI peers across the core. Beginning with Cisco NX-OS Release 10.2(2)F both ingress replication and multicast are supported between DCI peers across the core.
- The DCI underlay group and the fabric underlay group must be distinct, ensuring no overlap between DCI multicast and fabric multicast underlay groups.
- Bind NVE to a loopback address that is separate from loopback addresses that are required by Layer 3 protocols. A best practice is to use a dedicated loopback address for the NVE source interface (PIP VTEP) and multi-site source interface (anycast and virtual IP VTEP).
- Beginning with Cisco NX-OS Release 9.3(5), if you disable the **host-reachability protocol bgp** command under the NVE interface in a VXLAN EVPN Multi-Site topology, the NVE interface stays operationally down.
- Beginning with Cisco NX-OS Release 9.3(5), Multi-Site Border Gateways re-originate incoming remote routes when advertising to the site's local spine/leaf switches. These re-originated routes modify the following fields:
 - RD value changes to [Multisite Site ID:L3 VNID].
 - It is mandatory that Route-Targets are defined on all VTEP that are participating in a given VRF, this includes and is explicitly required for the BGW to extend the given VRF. Prior to Cisco NX-OS Release 9.3(5), Route-Targets from intra-site VTEPs were inadvertently kept across the site boundary, even if not defined on the BGW. Starting from Cisco NX-OS Release 9.3(5) the mandatory behavior is enforced. By adding the necessary Route-Targets to the BGW, the change from inadvertent Route-Target advertisement to explicit Route-Target advertisement can be performed.
 - Path type changes from external to local.

- For SVI-related triggers (such as shut/unshut or PIM enable/disable), a 30-second delay was added, allowing the Multicast FIB (MFIB) Distribution module (MFDM) to clear the hardware table before toggling between L2 and L3 modes or vice versa.
- Ensure that the **ip pim sparse-mode** is enabled on the Multi-Site VIP loopback interface.
- To improve the convergence in case of fabric link failure and avoid issues in case of fabric link flapping, ensure to configure multi-hop BFD between loopbacks of spines and BGWs.

In the specific scenario where a BGW node becomes completely isolated from the fabric due to all its fabric links failing, the use of multi-hop BFD ensures that the BGP sessions between the spines and the isolated BGW can be immediately brought down, without relying on the configured BGP hold-time value.
- In a VXLAN Multi-Site environment, a border gateway device that uses ECMP for routing through both a VXLAN overlay and an L3 prefix to access remote site subnets might encounter adjacency resolution failure for one of these routes. If the switch attempts to use this unresolved prefix, it will result in traffic being dropped.
- Following guidelines and limitations are applied when a multisite Border Gateway is put into Maintenance Mode:
 - BUM Traffic from remote Fabrics will still be attracted to the Border gateway that is in maintenance mode
 - Border Gateway in maintenance mode still participates in Designated Forwarder Election
 - Default Maintenance mode profile applies the command "ip pim isolate" and so the Border gateway is isolated from S,G tree towards the fabric direction. This leads to BUM traffic loss and hence an appropriate maintenance mode profile should be used for Border Gateways than the default.

vPC BGW restrictions

- BGWs in a vPC topology are supported.
- vPC mode can support only two BGWs.
- vPC mode can support both Layer 2 hosts and Layer 3 services on local interfaces.
- In vPC mode, BUM is replicated to either of the BGWs for traffic coming from the external site. Hence, both BGWs are forwarders for site external to site internal (DCI to fabric) direction.
- In vPC mode, BUM is replicated to either of the BGWs for traffic coming from the local site leaf for a VLAN using Ingress Replication (IR) underlay. Both BGWs are forwarders for site internal to site external (fabric to DCI) direction for VLANs using the IR underlay.
- In vPC mode, BUM is replicated to both BGWs for traffic coming from the local site leaf for a VLAN using the multicast underlay. Therefore, a decapper/forwarder election happens, and the decapsulation winner/forwarder only forwards the site-local traffic to external site BGWs for VLANs using the multicast underlay.
- In vPC mode, all Layer 3 services/attachments are advertised in BGP via EVPN Type-5 routes with their virtual IP as next hop. If the VIP/PIP feature is configured, they are advertised with PIP as the next hop.

Unsupported features

- Multicast Flood Domain between inter-site/fabric BGWs isn't supported.
- iBGP EVPN Peering between BGWs of different fabrics/sites isn't supported.
- PIM BiDir is not supported for fabric underlay multicast replication with VXLAN Multi-Site.
- FEX is not supported on a vPC BGW and Anycast BGW.

Anycast BGW restrictions

- Anycast mode can support up to six BGWs per site.
- Anycast mode can support only Layer 3 services that are attached to local interfaces.
- In Anycast mode, BUM is replicated to each border leaf. DF election between the border leafs for a particular site determines which border leaf forwards the inter-site traffic (fabric to DCI and conversely) for that site.
- In Anycast mode, all Layer 3 services are advertised in BGP via EVPN Type-5 routes with their physical IP as the next hop.
- If different Anycast Gateway MAC addresses are configured across sites, enable ARP suppression and ND suppression for all VLANs that have been extended.

Supported features

- Beginning with Cisco NX-OS Release 9.3(5), VTEPs support VXLAN-encapsulated traffic over parent interfaces if subinterfaces are configured. This feature is supported for VXLAN EVPN Multi-Site and DCI. DCI tracking can be enabled only on the parent interface.
- Beginning with Cisco NX-OS Release 9.3(5), VXLAN EVPN Multi-Site supports asymmetric VNIs. For more information, see Multi-Site with Asymmetric VNIs and [Configuration Example for Multi-Site with Asymmetric VNIs, on page 19](#).

• Dual RD

The following guidelines and limitations apply to dual RD support for Multi-Site:

- Dual RD are supported beginning with Cisco NX-OS Release 9.3(5).
- Dual RD is enabled automatically for Cisco Nexus 9332C, 9364C, 9300-EX, and 9300-FX/FX2 platform switches and Cisco Nexus 9500 platform switches with -EX/FX line cards that have VXLAN EVPN Multi-Site enabled.
- Beginning with Cisco NX-OS Release 10.2(3)F, the dual RD support for Multi-Site is supported on the Cisco Nexus 9300-FX3 platform switches.
- To use CloudSec or other features that require PIP advertisement for multi-site reoriginated routes, configure BGP additional paths on the route server if dual RD are enabled on the BGW, or disable dual RD.
- Sending secondary RD additional paths at the BGW node isn't supported.
- During an ISSU, the number of paths for the leaf nodes might double temporarily while all BGWs are being upgraded.

Guidelines and Limitations for VXLAN Multi-Site Anycast BGW Support on Cisco Nexus 9800 Series Switches

Enabling VXLAN EVPN Multi-Site

This procedure enables the VXLAN EVPN Multi-Site feature. Multi-Site is enabled on the BGWs only. The site-id must be the same on all BGWs in the fabric/site.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal</pre>	Enters global configuration mode.
Step 2	evpn multisite border-gateway <i>ms-id</i> Example: <pre>switch(config)# evpn multisite border-gateway 100</pre>	Configures the site ID for a site/fabric. The range of values for <i>ms-id</i> is 1 to 2,814,749,767,110,655. The <i>ms-id</i> must be the same in all BGWs within the same fabric/site.
Step 3	split-horizon per-site Example: <pre>switch(config-evpn-msite-bgw)# split-horizon per-site</pre>	Enables to receive packets encapsulated with DCI group from another border gateway on the same site and avoids duplication of packets. Note Use this command when DCI multicast underlay is configured on a site with anycast border gateway.
Step 4	interface nve 1 Example: <pre>switch(config-evpn-msite-bgw)# interface nve 1</pre>	Creates a VXLAN overlay interface that terminates VXLAN tunnels. Note Only one NVE interface is allowed on the switch.
Step 5	source-interface loopback <i>src-if</i> Example: <pre>switch(config-if-nve)# source-interface loopback 0</pre>	The source interface must be a loopback interface that is configured on the switch with a valid /32 IP address. This /32 IP address must be known by the transient devices in the transport network and the remote VTEPs. This requirement is accomplished by advertising it through a dynamic routing protocol in the transport network.
Step 6	host-reachability protocol bgp Example: <pre>switch(config-if-nve)# host-reachability protocol bgp</pre>	Defines BGP as the mechanism for host reachability advertisement.
Step 7	multisite border-gateway interface loopback <i>vi-num</i> Example:	Defines the loopback interface used for the BGW virtual IP address (VIP). The border-gateway interface must be a loopback interface that is configured on the switch with a

	Command or Action	Purpose
	<code>switch(config-if-nve)# multisite border-gateway interface loopback 100</code>	valid /32 IP address. This /32 IP address must be known by the transient devices in the transport network and the remote VTEPs. This requirement is accomplished by advertising it through a dynamic routing protocol in the transport network. This loopback must be different than the source interface loopback. The range of <i>vi-num</i> is from 0 to 1023.
Step 8	no shutdown Example: <code>switch(config-if-nve)# no shutdown</code>	Negates the shutdown command.
Step 9	exit Example: <code>switch(config-if-nve)# exit</code>	Exits the NVE configuration mode.
Step 10	interface loopback loopback-number Example: <code>switch(config)# interface loopback 0</code>	Configures the loopback interface.
Step 11	ip address ip-address Example: <code>switch(config-if)# ip address 198.0.2.0/32</code>	Configures the IP address for the loopback interface.

Configuring Dual RD Support for Multi-Site

Follow these steps if you need to manually configure the secondary RD value or disable dual RDs.

Before you begin

Enable VXLAN EVPN Multi-Site.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <code>switch# configure terminal</code> <code>switch(config)#</code>	Enters global configuration mode.
Step 2	router bgp as-num Example: <code>switch(config)# router bgp 100</code> <code>switch(config-router)#</code>	Configures the autonomous system number. The range for <i>as-num</i> is from 1 to 4,294,967,295.

	Command or Action	Purpose
Step 3	[no] rd dual id [2-bytes] Example: <pre>switch(config-router)# rd dual id 1</pre>	Defines the first 2 bytes of the secondary RD. The ID must be the same across the Multi-Site BGWs. The range is from 1 to 65535. Note If necessary, you can use the no rd dual command to disable dual RDs and fall back to a single RD.
Step 4	(Optional) show bgp evi evi-id Example: <pre>switch(config-router)# show bgp evi 100</pre>	Displays the secondary RD configured as part of the rd dual id [2-bytes] command for the specified EVI.

Example

The following example shows sample output for the **show bgp evi evi-id** command:

```
switch# show bgp evi 100
-----
L2VNI ID           : 100 (L2-100)
RD                 : 3.3.3.3:32867
Secondary RD       : 1:100
Prefixes (local/total) : 1/6
Created            : Jun 23 22:35:13.368170
Last Oper Up/Down  : Jun 23 22:35:13.369005 / never
Enabled            : Yes

Active Export RT list :
    100:100
Active Import RT list :
    100:100
```

Configuring VNI Dual Mode

This procedure describes the configuration of the BUM traffic domain for a given VLAN. Support exists for using multicast or ingress replication inside the fabric/site and ingress replication across different fabrics/sites.



Note If you have multiple VRFs and only one is extended to ALL leaf switches, you can add a dummy loopback to that one extended VRF and advertise through BGP. Otherwise, you'll need to check how many VRFs are extended and to which switches, and then add a dummy loopback to the respective VRFs and advertise them as well. Therefore, use the **advertise-pip** command to prevent potential user errors in the future.

For more information about configuring multicast or ingress replication for a large number of VNIs, see [Example of VXLAN BGP EVPN \(eBGP\)](#).

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal</pre>	Enters global configuration mode.
Step 2	interface nve 1 Example: <pre>switch(config)# interface nve 1</pre>	Creates a VXLAN overlay interface that terminates VXLAN tunnels. Note Only one NVE interface is allowed on the switch.
Step 3	member vni vni-range Example: <pre>switch(config-if-nve)# member vni 200</pre>	Configures the virtual network identifier (VNI). The range for <i>vni-range</i> is from 1 to 16,777,214. The value of <i>vni-range</i> can be a single value like 5000 or a range like 5001-5008. Note Enter one of the Step 4 or Step 5 commands.
Step 4	mcast-group ip-addr Example: <pre>switch(config-if-nve-vni)# mcast-group 255.0.4.1</pre>	Configures the NVE Multicast group IP prefix within the fabric.
Step 5	ingress-replication protocol bgp Example: <pre>switch(config-if-nve-vni)# ingress-replication protocol bgp</pre>	Enables BGP EVPN with ingress replication for the VNI within the fabric.
Step 6	multisite ingress-replication Example: <pre>switch(config-if-nve-vni)# multisite ingress-replication</pre>	Defines the Multi-Site BUM replication method for extending the Layer 2 VNI.

Configuring Fabric/DCI Link Tracking

This procedure describes the configuration to track all DCI-facing interfaces and site internal/fabric facing interfaces. Tracking is mandatory and is used to disable reorigination of EVPN routes either from or to a site if all the DCI/fabric links go down.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <code>switch# configure terminal</code>	Enters global configuration mode.
Step 2	interface ethernet port Example: <code>switch(config)# interface ethernet1/1</code>	Enters interface configuration mode for the DCI or fabric interface. Note Enter one of the following commands in Step 3 or Step 4.
Step 3	evpn multisite dci-tracking Example: <code>switch(config-if)# evpn multisite dci-tracking</code>	Configures DCI interface tracking.
Step 4	(Optional) evpn multisite fabric-tracking Example: <code>switch(config-if)# evpn multisite fabric-tracking</code>	Configures EVPN Multi-Site fabric tracking. The evpn multisite fabric-tracking is mandatory for anycast BGWs and vPC BGW fabric links.
Step 5	ip address ip-addr Example: <code>switch(config-if)# ip address 192.1.1.1</code>	Configures the IP address.
Step 6	no shutdown Example: <code>switch(config-if)# no shutdown</code>	Negates the shutdown command.

Configuring Fabric External Neighbors

This procedure describes the configuration of fabric external/DCI neighbors for communication to other site/fabric BGWs.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <code>switch# configure terminal</code>	Enters global configuration mode.
Step 2	router bgp as-num Example:	Configures the autonomous system number. The range for <i>as-num</i> is from 1 to 4,294,967,295.

	Command or Action	Purpose
	<code>switch(config)# router bgp 100</code>	
Step 3	neighbor <i>ip-addr</i> Example: <code>switch(config-router)# neighbor 100.0.0.1</code>	Configures a BGP neighbor.
Step 4	remote-as <i>value</i> Example: <code>switch(config-router-neighbor)# remote-as 69000</code>	Configures remote peer's autonomous system number.
Step 5	peer-type <i>fabric-external</i> Example: <code>switch(config-router-neighbor)# peer-type fabric-external</code>	Enables the next hop rewrite for Multi-Site. Defines site external BGP neighbors for EVPN exchange. The default for peer-type is fabric-internal. Note The peer-type fabric-external command is required only for VXLAN Multi-Site BGWs. It is not required for pseudo BGWs.
Step 6	address-family <i>l2vpn evpn</i> Example: <code>switch(config-router-neighbor)# address-family l2vpn evpn</code>	Configures the address family Layer 2 VPN EVPN under the BGP neighbor.
Step 7	rewrite-evpn-rt-asn Example: <code>switch(config-router-neighbor)# rewrite-evpn-rt-asn</code>	Rewrites the route target (RT) information to simplify the MAC-VRF and IP-VRF configuration. BGP receives a route, and as it processes the RT attributes, it checks if the AS value matches the peer AS that is sending that route and replaces it. Specifically, this command changes the incoming route target's AS number to match the BGP-configured neighbor's remote AS number. You can see the modified RT value in the receiver router.

Configuring VXLAN EVPN Multi-Site Storm Control

VXLAN EVPN Multi-Site Storm Control allows rate limiting of multdestination (BUM) traffic on Multi-Site BGWs. You can control BUM traffic sent over the DCI link using a policer on fabric links in the ingress direction.

Remote peer reachability must be only through DCI links. Appropriate routing configuration must ensure that remote site routes are not advertised over Fabric links.

Multicast traffic is policed only on DCI interfaces, while unknown unicast and broadcast traffic is policed on both DCI and fabric interfaces.

Cisco NX-OS Release 9.3(6) and later releases optimize rate granularity and accuracy. Bandwidth is calculated based on the accumulated DCI uplink bandwidth, and only interfaces tagged with DCI tracking are considered. (Prior releases also include fabric-tagged interfaces.) In addition, granularity is enhanced by supporting two

digits after the decimal point. These enhancements apply to the Cisco Nexus 9300-EX, 9300-FX/FX2/FX3, and 9300-GX platform switches.



Note For information on access port storm control, see the [Cisco Nexus 9000 Series NX-OS Layer 2 Configuration Guide](#).

SUMMARY STEPS

1. **configure terminal**
2. **[no] evpn storm-control {broadcast | multicast | unicast} {level level}**

DETAILED STEPS

Procedure		
	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	[no] evpn storm-control {broadcast multicast unicast} {level level} Example: <pre>switch(config)# evpn storm-control unicast level 10</pre> Example: <pre>switch(config)# evpn storm-control unicast level 10.20</pre>	Configures the storm suppression level as a number from 0–100. 0 means that all traffic is dropped, and 100 means that all traffic is allowed. For any value in between, the unknown unicast traffic rate is restricted to a percentage of available bandwidth. For example, a value of 10 means that the traffic rate is restricted to 10% of the available bandwidth, and anything above that rate is dropped. Beginning with Cisco NX-OS Release 9.3(6), you can configure the level as a fractional value by adding two digits after the decimal point. For example, you can enter a value of 10.20.

Verifying VXLAN EVPN Multi-Site Storm Control

To display EVPN storm control setting information, enter the following command:

Command	Purpose
slot 1 show hardware vxlan storm-control	Displays the status of EVPN storm control setting.



Note Once the Storm control hits the threshold, a message is logged as stated below:

BGWY-1 %ETHERPORT-5-STORM_CONTROL_ABOVE_THRESHOLD: Traffic in port Ethernet1/32 exceeds the configured threshold , action - Trap (message repeated 38 times)

Multi-Site with vPC Support

About Multi-Site with vPC Support

The BGWs can be in a vPC complex. In this case, it is possible to support dually-attached directly-connected hosts that might be bridged or routed as well as dually-attached firewalls or service attachments. The vPC BGWs have vPC-specific multihoming techniques and do not rely on EVPN Type 4 routes for DF election or split horizon.

Guidelines and Limitations for Multi-Site with vPC Support

Multi-Site with vPC support has the following configuration guidelines and limitations:

- 4000 VNIs for vPC are not supported.
- For BUM with continued VIP use, the MCT link is used as transport upon core isolation or fabric isolation, and for unicast traffic in fabric isolation.
- Beginning with Cisco NX-OS Release 10.1(2), TRM Multisite with vPC BGW is supported.
- The routes to remote Multisite BGW loopback addresses must always prioritize the DCI link path over the iBGP protocol between vPC Border Gateway switches configured using the backup SVI. The backup SVI should be used strictly in the event of a DCI link failure.

Configuring Multi-Site with vPC Support

This procedure describes the configuration of Multi-Site with vPC support:

- Configure vPC domain.
- Configure port channels.
- Configuring vPC Peer Link.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 2	feature vpc Example: <code>switch(config)# feature vpc</code>	Enables vPCs on the device.
Step 3	feature interface-vlan Example: <code>switch(config)# feature interface-vlan</code>	Enables the interface VLAN feature on the device.
Step 4	feature lacp Example: <code>switch(config)# feature lacp</code>	Enables the LACP feature on the device.
Step 5	feature pim Example: <code>switch(config)# feature pim</code>	Enables the PIM feature on the device.
Step 6	feature ospf Example: <code>switch(config)# feature ospf</code>	Enables the OSPF feature on the device.
Step 7	ip pim rp-address address group-list range Example: <code>switch(config)# ip pim rp-address 100.100.100.1 group-list 224.0.0/4</code>	Defines a PIM RP address for the underlay multicast group range.
Step 8	vpc domain domain-id Example: <code>switch(config)# vpc domain 1</code>	Creates a vPC domain on the device and enters vpn-domain configuration mode for configuration purposes. There is no default. The range is from 1 to 1000.
Step 9	peer switch Example: <code>switch(config-vpc-domain)# peer switch</code>	Defines the peer switch.
Step 10	peer gateway Example: <code>switch(config-vpc-domain)# peer gateway</code>	Enables Layer 3 forwarding for packets destined to the gateway MAC address of the vPC.
Step 11	peer-keepalive destination ip-address Example: <code>switch(config-vpc-domain)# peer-keepalive destination 172.28.230.85</code>	Configures the IPv4 address for the remote end of the vPC peer-keepalive link. Note The system does not form the vPC peer link until you configure a vPC peer-keepalive link. The management ports and VRF are the defaults.

	Command or Action	Purpose
Step 12	ip arp synchronize Example: <pre>switch(config-vpc-domain) # ip arp synchronize</pre>	Enables IP ARP synchronize under the vPC domain to facilitate faster ARP table population following device reload.
Step 13	ipv6 nd synchronize Example: <pre>switch(config-vpc-domain) # ipv6 nd synchronize</pre>	Enables IPv6 ND synchronization under the vPC domain to facilitate faster ND table population following device reload.
Step 14	Create the vPC peer-link. Example: <pre>switch(config) # interface port-channel 1 switch(config) # switchport switch(config) # switchport mode trunk switch(config) # switchport trunk allowed vlan 1,10,100-200 switch(config) # mtu 9216 switch(config) # vpc peer-link switch(config) # no shut switch(config) # interface Ethernet 1/1, 1/21 switch(config) # switchport switch(config) # mtu 9216 switch(config) # channel-group 1 mode active switch(config) # no shutdown</pre>	Creates the vPC peer-link port-channel interface and adds two member interfaces to it.
Step 15	system nve infra-vlans range Example: <pre>switch(config) # system nve infra-vlans 10</pre>	Defines a non-VXLAN-enabled VLAN as a backup routed path.
Step 16	vlan number Example: <pre>switch(config) # vlan 10</pre>	Creates the VLAN to be used as an infra-VLAN.
Step 17	Create the SVI. Example: <pre>switch(config) # interface vlan 10 switch(config) # ip address 10.10.10.1/30 switch(config) # ip router ospf process UNDERLAY area 0 switch(config) # ip pim sparse-mode switch(config) # no ip redirects switch(config) # mtu 9216 switch(config) # no shutdown</pre>	Creates the SVI used for the backup routed path over the vPC peer-link.
Step 18	(Optional) delay restore interface-vlan seconds Example: <pre>switch(config-vpc-domain) # delay restore interface-vlan 45</pre>	Enables the delay restore timer for SVIs. We recommend tuning this value when the SVI/VNI scale is high. For example, when the SCI count is 1000, we recommend that you set the delay restore to 45 seconds.

	Command or Action	Purpose
Step 19	evpn multisite border-gateway <i>ms-id</i> Example: <pre>switch(config)# evpn multisite border-gateway 100</pre>	Configures the site ID for a site/fabric. The range of values for <i>ms-id</i> is 1 to 281474976710655. The <i>ms-id</i> must be the same in all BGWs within the same fabric/site.
Step 20	interface nve 1 Example: <pre>switch(config-evpn-msite-bgw)# interface nve 1</pre>	Creates a VXLAN overlay interface that terminates VXLAN tunnels. Note Only one NVE interface is allowed on the switch.
Step 21	source-interface loopback <i>src-if</i> Example: <pre>switch(config-if-nve)# source-interface loopback 0</pre>	Defines the source interface, which must be a loopback interface with a valid /32 IP address. This /32 IP address must be known by the transient devices in the transport network and the remote VTEPs. This requirement is accomplished by advertising the address through a dynamic routing protocol in the transport network.
Step 22	host-reachability protocol bgp Example: <pre>switch(config-if-nve)# host-reachability protocol bgp</pre>	Defines BGP as the mechanism for host reachability advertisement.
Step 23	multisite border-gateway interface loopback <i>vi-num</i> Example: <pre>switch(config-if-nve)# multisite border-gateway interface loopback 100</pre>	Defines the loopback interface used for the BGW virtual IP address (VIP). The BGW interface must be a loopback interface that is configured on the switch with a valid /32 IP address. This /32 IP address must be known by the transient devices in the transport network and the remote VTEPs. This requirement is accomplished by advertising the address through a dynamic routing protocol in the transport network. This loopback must be different than the source interface loopback. The range of <i>vi-num</i> is from 0 to 1023.
Step 24	no shutdown Example: <pre>switch(config-if-nve)# no shutdown</pre>	Negates the shutdown command.
Step 25	exit Example: <pre>switch(config-if-nve)# exit</pre>	Exits the NVE configuration mode.
Step 26	interface loopback <i>loopback-number</i> Example: <pre>switch(config)# interface loopback 0</pre>	Configures the loopback interface.
Step 27	ip address <i>ip-address</i> Example:	Configures the primary IP address for the loopback interface.

	Command or Action	Purpose
	<code>switch(config-if)# ip address 198.0.2.0/32</code>	
Step 28	ip address <i>ip-address</i> secondary Example: <code>switch(config-if)# ip address 198.0.2.1/32 secondary</code>	Configures the secondary IP address for the loopback interface.
Step 29	ip pim sparse-mode Example: <code>switch(config-if)# ip pim sparse-mode</code>	Configures PIM sparse mode on the loopback interface.

Verifying the Multi-Site with vPC Support Configuration

To display Multi-Site with vPC support information, enter one of the following commands:

show vpc brief	Displays general vPC and CC status.
show vpc consistency-parameters global	Displays the status of those parameters that must be consistent across all vPC interfaces.
show vpc consistency-parameters vni	Displays configuration information for VNIs under the NVE interface that must be consistent across both vPC peers.

Output example for the **show vpc brief** command:

```
switch# show vpc brief
Legend:
```

(*) - local vPC is down, forwarding via vPC peer-link

```
vPC domain id           : 1
Peer status             : peer adjacency formed ok      (<--- peer up)
vPC keep-alive status   : peer is alive
Configuration consistency status : success (<----- CC passed)
Per-vlan consistency status : success                  (<----- per-VNI CCpassed)
Type-2 consistency status : success
vPC role                : secondary
Number of vPCs configured : 1
Peer Gateway            : Enabled
Dual-active excluded VLANs : -
Graceful Consistency Check : Enabled
Auto-recovery status    : Enabled, timer is off.(timeout = 240s)
Delay-restore status    : Timer is off.(timeout = 30s)
Delay-restore SVI status : Timer is off.(timeout = 10s)
Operational Layer3 Peer-router : Disabled
[...]
```

Output example for the **show vpc consistency-parameters global** command:

```
switch# show vpc consistency-parameters global
```

Legend:

Type 1 : vPC will be suspended in case of mismatch

Name	Type	Local Value	Peer Value
-----	----	-----	-----
[...]			
Nve1 Adm St, Src Adm St, Sec IP, Host Reach, VMAC Adv, SA, mcast l2, mcast l3, IR BGP, MS Adm St, Reo	1	Up, Up, 2.1.44.5, CP, TRUE, Disabled, 0.0.0.0, 0.0.0.0, Disabled, Up, 200.200.200.200	Up, Up, 2.1.44.5, CP, TRUE, Disabled, 0.0.0.0, 0.0.0.0, Disabled, Up, 200.200.200.200
[...]			

Output example for the **show vpc consistency-parameters vni** command:

```
switch(config-if-nve-vni)# show vpc consistency-parameters vni
```

Legend:

Type 1 : vPC will be suspended in case of mismatch

Name	Type	Local Value	Peer Value
-----	----	-----	-----
Nve1 Vni, Mcast, Mode, Type, Flags	1	11577, 234.1.1.1, Mcast, L2, MS IR	11577, 234.1.1.1, Mcast, L2, MS IR
Nve1 Vni, Mcast, Mode, Type, Flags	1	11576, 234.1.1.1, Mcast, L2, MS IR	11576, 234.1.1.1, Mcast, L2, MS IR
[...]			

Configuration Example for Multi-Site with Asymmetric VNIs

The following example shows how two sites with different sets of VNIs can connect to the same MAC VRF or IP VRF. One site uses VNI 200 internally, and the other site uses VNI 300 internally. Route-target auto no longer matches because the VNI values are different. Therefore, the route-target values must be manually configured. In this example, the value 222:333 stitches together the two VNIs from different sites.

The BGW of site 1 has L2VNI 200 and L3VNI 201.

The BGW of site 2 has L2VNI 300 and L3VNI 301.



Note This configuration example assumes that basic Multi-Site configurations are already in place.



Note You must have VLAN-to-VRF mapping on the BGW. This requirement is necessary to maintain L2VNI-to-L3VNI mapping, which is needed for reorigination of MAC-IP routes at BGWs.

Layer 3 Configuration

In the BGW node of site 1, configure the common RT 201:301 for stitching the two sites using L3VNI 201 and L3VNI 301:

```
vrf context vni201
vni 201
address-family ipv4 unicast
route-target both auto evpn
route-target import 201:301 evpn
route-target export 201:301 evpn
```

In the BGW node of site 2, configure the common RT 201:301 for stitching the two sites using L3VNI 201 and L3VNI 301:

```
vrf context vni301
  vni 301
  address-family ipv4 unicast
    route-target both auto evpn
    route-target import 201:301 evpn
    route-target export 201:301 evpn
```

Layer 2 Configuration

In the BGW node of site 1, configure the common RT 222:333 for stitching the two sites using L2VNI 200 and L2VNI 300:

```
evpn
  vni 200 l2
  rd auto
  route-target import auto
  route-target import 222:333
  route-target export auto
  route-target export 222:333
```

For proper reorigination of L3 labels of MAC-IP routes, associate the VRF (L3VNI) to the L2VNI:

```
interface Vlan 200
  vrf member vni201
```

In the BGW node of site 2, configure the common RT 222:333 for stitching the two sites using L2VNI 200 and L2VNI 300:

```
evpn
  vni 300 l2
  rd auto
  route-target import auto
  route-target import 222:333
  route-target export auto
  route-target export 222:333
```

For proper reorigination of L3 labels of MAC-IP routes, associate the VRF (L3VNI) to the L2VNI:

```
interface vlan 300
  vrf member vni301
```

TRM with Multi-Site

This section contains the following topics:

- [Information About Configuring TRM with Multi-Site, on page 21](#)
- [Guidelines and Limitations for TRM with Multi-Site, on page 23](#)
- [Configuring TRM with Multi-Site, on page 26](#)
- [Verifying TRM with Multi-Site Configuration, on page 28](#)

Information About Configuring TRM with Multi-Site

Tenant Routed Multicast (TRM) with Multi-Site enables multicast forwarding across multiple VXLAN EVPN fabrics that are connected via Multi-Site. This feature provides Layer 3 multicast services across sites for sources and receivers across different sites. It addresses the requirement of East-West multicast traffic between sites.

Each TRM site is operating independently. Border gateways on each site allow stitching across the sites. There can be multiple border gateways for each site. Multicast source and receiver information across sites is propagated by BGP on the border gateways that are configured with TRM. The border gateway on each site receives the multicast packet and re-encapsulates the packet before sending it to the local site. Beginning with Cisco NX-OS Release 10.1(2), TRM with Multi-Site supports both Anycast Border Gateway and vPC Border Gateway.


The border gateway that is elected as Designated Forwarder (DF) for the L3VNI forwards the traffic from fabric toward the core side. In the TRM Multicast-Anycast Gateway model, we use the VIP-R based model to send traffic toward remote sites. The IR destination IP is the VIP-R of the remote site. Each site that has the receiver gets only one copy from the source site. DF forwarding is applicable only on Anycast Border Gateways.



Note Only the DF sends the traffic toward remote sites.


On the remote site, the BGW that receives the inter-site multicast traffic from the core forwards the traffic toward the fabric side. The DF check is not done from the core to fabric direction because non-DF can also receive the VIP-R copy from the source site.

Figure 1: TRM with Multi-Site Topology, BL External Multicast Connectivity



Beginning with Cisco NX-OS Release 9.3(3), TRM with Multi-Site supports BGW connections to the external multicast network in addition to the BL connectivity, which is supported in previous releases. Forwarding occurs as documented in the previous example, except the exit point to the external multicast network can optionally be provided through the BGW.

Figure 2: TRM with Multi-Site Topology, BGW External Multicast Connectivity



307659

Guidelines and Limitations for TRM with Multi-Site

TRM with Multi-Site has the following guidelines and limitations:

- The following platforms support TRM with Multi-Site:
 - Cisco Nexus 9300-EX platform switches
 - Cisco Nexus 9300-FX/FX2/FX3 platform switches
 - Cisco Nexus 9300-GX platform switches
 - Cisco Nexus 9300-GX2 platform switches
 - Cisco Nexus 9500 platform switches with -EX/FX line cards
- Beginning with Cisco NX-OS Release 9.3(3), a border leaf and Multi-Site border gateway can coexist on the same node for multicast traffic.


- Beginning with Cisco NX-OS Release 9.3(3), all border gateways for a given site must run the same Cisco NX-OS 9.3(x) image.
- Cisco NX-OS Release 10.1(2) has the following guidelines and limitations:
 - You need to add a VRF lite link (per Tenant VRF) between the vPC peers in order to support the L3 hosts attached to the vPC primary and secondary peers.
 - Backup SVI is needed between the two vPC peers.
 - Orphan ports attached with L2 and L3 are supported with vPC BGW.
 - TRM multi-site with vPC BGW is not supported with vMCT.

For details on TRM and Configuring TRM with vPC Support, see [Configuring Tenant Routed Multicast](#).


- TRM multi-site with vPC BGW and with Anycast BGW are supported on Cisco Nexus 9300-EX, FX, FX2, and FX3 family switches. Beginning with Cisco NX-OS Release 10.2(1)F, TRM with vPC BGW and with Anycast BGW are supported on Cisco Nexus 9300-GX family switches.
- Beginning with Cisco NX-OS Release 10.2(1q)F, TRM with Multi-Site is supported on the Cisco Nexus N9K-C9332D-GX2B platform switches.
- Beginning with Cisco NX-OS Release 10.2(1q)F, the TRM multi-site with vPC BGW and with Anycast BGW are supported on the Cisco Nexus C9332D-GX2B platform switches.
- Beginning with Cisco NX-OS Release 10.2(2)F, multicast group configuration is used to encapsulate TRM and L2 BUM packets in the DCI core using the **multisite mcast-group** *dcf-core-group* command.
- Beginning with Cisco NX-OS Release 10.2(3)F, the TRM multi-site is supported on the Cisco Nexus 9364D-GX2A and 9348D-GX2A switches.
- TRM with Multi-Site supports the following features:
 - TRM Multi-Site with vPC Border Gateway.
 - PIM ASM multicast underlay in the VXLAN fabric
 - TRM with Multi-Site Layer 3 mode only
 - TRM with Multi-Site with Anycast Gateway
 - Terminating VRF-lite at the border leaf
 - The following RP models with TRM Multi-Site:
 - External RP
 - RP Everywhere
 - Internal RP
- Only one pair of vPC BGW can be configured on one site.
- A pair of vPC BGW and Anycast BGW cannot co-exist on the same site.
- Prior to NX-OS 10.2(2)F only ingress replication was supported between DCI peers across the core. Beginning with Cisco NX-OS Release 10.2(2)F both ingress replication and multicast are supported between DCI peers across the core.

- Border routers reoriginate MVPN routes from fabric to core and from core to fabric.
- Only eBGP peering between border gateways of different sites is supported.
- Each site must have a local RP for the TRM underlay.
- Keep each site's underlay unicast routing isolated from another site's underlay unicast routing. This requirement also applies to Multi-Site.
- MVPN address family must be enabled between BGWs.
- When configuring BGW connections to the external multicast fabric, be aware of the following:
 - The multicast underlay must be configured between all BGWs on the fabric side even if the site doesn't have any leafs in the fabric site.
 - Sources and receivers that are Layer-3 attached through VRF-Lite links to the BGW of a single site acting therefore also as Border Leaf (BL) node need to have reachability through the external Layer-3 network. If there's a Layer-3 attached source on BGW BL Node-1 and a Layer-3 attached receiver on BGW BL Node-2 for the same site, the traffic between these two endpoints flows through the external Layer-3 network and not through the fabric.
 - External multicast networks should be connected only through the BGW or BL. If a deployment requires external multicast network connectivity from both the BGW and BL at the same site, make sure that external routes that are learned from the BGW are preferred over the BL. To do so, the BGW must have a lower MED and a higher OSPF cost (on the external links) than the BL.

The following figure shows a site with external network connectivity through BGW-BLs and an internal leaf (BL1). The path to the external source should be through BGW-1 (rather than through BL1) to avoid duplication on the remote site receiver.



- The BGW supports VRF-lite hand-off and Multi-site configuration on the same physical interface as shown in the diagram.



- MED is supported for iBGP only.

Configuring TRM with Multi-Site

Before you begin

The following must be configured:

- VXLAN TRM
- VXLAN Multi-Site

This section provides the configuration procedure for Anycast BGW with TRM. For vPC BGW with TRM, vPC must be configured along with VxLAN TRM and VxLAN Multi-site.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal</pre>	Enters global configuration mode.
Step 2	interface nve1 Example: <pre>switch(config)# interface nve1</pre>	Configures the NVE interface.

	Command or Action	Purpose
Step 3	no shutdown Example: <pre>switch(config-if-nve)# no shutdown</pre>	Brings up the NVE interface.
Step 4	host-reachability protocol bgp Example: <pre>switch(config-if-nve)# host-reachability protocol bgp</pre>	Defines BGP as the mechanism for host reachability advertisement.
Step 5	source-interface loopback <i>src-if</i> Example: <pre>switch(config-if-nve)# source-interface loopback 0</pre>	Defines the source interface, which must be a loopback interface with a valid /32 IP address. This /32 IP address must be known by the transient devices in the transport network and the remote VTEPs. This requirement is accomplished by advertising the address through a dynamic routing protocol in the transport network.
Step 6	multisite border-gateway interface loopback <i>vi-num</i> Example: <pre>switch(config-if-nve)# multisite border-gateway interface loopback 1</pre>	Defines the loopback interface used for the border gateway virtual IP address (VIP). The border-gateway interface must be a loopback interface that is configured on the switch with a valid /32 IP address. This /32 IP address must be known by the transient devices in the transport network and the remote VTEPs. This requirement is accomplished by advertising the address through a dynamic routing protocol in the transport network. This loopback must be different than the source interface loopback. The range of <i>vi-num</i> is from 0 to 1023.
Step 7	member vni <i>vni-range</i> associate-vrf Example: <pre>switch(config-if-nve)# member vni 10010 associate-vrf</pre>	Configures the virtual network identifier (VNI). The range for <i>vni-range</i> is from 1 to 16,777,214. The value of <i>vni-range</i> can be a single value like 5000 or a range like 5001-5008.
Step 8	mcast-group <i>ip-addr</i> Example: <pre>switch(config-if-nve-vni)# mcast-group 225.0.0.1</pre>	Configures the NVE multicast group IP prefix within the fabric.
Step 9	multisite mcast-group <i>dci-core-group address</i> Example: <pre>switch(config-if-nve-vni)# multisite mcast-group 226.1.1.1</pre>	Configures the multicast group which is used to encapsulate TRM and L2 BUM packets in the DCI core.
Step 10	multisite ingress-replication optimized Example: <pre>switch(config-if-nve-vni)# multisite ingress-replication optimized</pre>	Defines the Multi-Site BUM replication method for extending the Layer 2 VNI.

Verifying TRM with Multi-Site Configuration

To display the status for the TRM with Multi-Site configuration, enter the following command:

Command	Purpose
show nve vni <i>virtual-network-identifier</i>	Displays the L3VNI. Note For this feature, optimized IR is the default setting for the Multi-Site extended L3VNI. MS-IR flag inherently means that it's MS-IR optimized.

Example of the **show nve vni** command:

For IPv4

```
switch(config)# show nve vni 51001
```

```
Codes: CP - Control Plane      DP - Data Plane
       UC - Unconfigured      SA - Suppress ARP
       SU - Suppress Unknown Unicast
       Xconn - Crossconnect
       MS-IR - Multisite Ingress Replication
```

Interface	VNI	Multicast-group	State	Mode	Type	[BD/VRF]	Flags
nve1	51001	226.0.0.1	Up	CP	L3	[cust_1]	MS-IR