



# Preinstallation Checklist


Select the preinstallation checklist for your deployment:

- [Single Switch Configuration, on page 1](#)
- [Dual Switch Configuration, on page 4](#)
- [Common Network Requirements, on page 7](#)
- [HyperFlex Edge and Firmware Compatibility Matrix for 3.x Deployments, on page 13](#)
- [Intersight Connectivity, on page 14](#)

## Single Switch Configuration

Single switch configuration provides a simple topology requiring only a single switch, and two 1GE ports per server. Link or switch redundancy is not provided. Access ports and trunk ports are the two supported network port configurations.

### Network Topology



### Upstream Network Requirements

- A managed switch with VLAN capability
- Six physical 1GE ports for three HyperFlex nodes
- Jumbo frames are not required to be configured
- Portfast or portfast trunk should be configured on all ports to ensure uninterrupted access to Cisco Integrated Management Controller (CIMC)

### Virtual Network Requirements

The recommended configuration for each ESXi host calls for the following networks to be separated:

- Management traffic network
- Data traffic network
- vMotion network
- VM network

The minimum network configuration requires at least two separate networks:

- Management network (includes vMotion and VM network)
- Data network (for storage traffic)

Two vSwitches each carrying different networks are required:

- **vswitch-hx-inband-mgmt**—ESXi management (vmk0), storage controller management, vMotion (vmk2), VM guest portgroups
- **vswitch-hx-storage-data**—HyperFlex storage data network, Hypervisor storage interface (vmk1)



---

**Note**

After some HyperFlex Edge deployments using the single switch configuration, it is normal to see the storage data vSwitch and associated portgroup failover order with only a standby adapter populated. The missing active adapter does not cause any functional issue with the cluster and we recommend leaving the failover order as configured by the installation process.

---


### Port Requirements

Two 1GE ports are required per server:

- Port 1—management (ESXi and CIMC), vMotion traffic, and VM guest traffic
- Port 2—HyperFlex storage traffic
- There are two supported network port configurations: access ports or trunk ports.
- Spanning tree portfast (access ports) or portfast trunk (trunk ports) must be enabled for all network ports connected to HyperFlex servers.
  - Failure to configure portfast causes intermittent CIMC disconnects during ESXi bootup and longer than necessary network re-convergence during physical link failure.

- To decide if your deployment will use access ports or trunk ports, see the following section "About Access and Trunk Ports".

Physical network topology guidance:



- Cable both integrated LOM ports to the same ToR switch.
- If desired, cable the dedicated CIMC port to the same switch or to an out-of-band management switch.
- Do not use the 10GE ports on the VIC.

**About Access and Trunk Ports**

Ethernet interfaces can be configured either as access ports or trunk ports, as follows:

- An access port can have only one VLAN configured on the interface; it can carry traffic for only one VLAN.
- A trunk port can have one or more VLANs configured on the interface; it can carry traffic for several VLANs simultaneously.

The following table summarizes the differences between access and trunk ports. You can use the details described in this table to determine which ports to use for your deployment.



**Important**

Trunk ports are assumed in this guide, and is highly recommended for your deployment.

Trunk Ports	Access Ports
Requires more setup and definition of VLAN tags within CIMC, ESXi, and HX Data Platform Installer.	Provides a simpler deployment process than trunk ports.
Provides the ability to logically separate management, vMotion, and VM guest traffic on separate subnets.	Requires that management, vMotion, and VM guest traffic must share a single subnet.

Trunk Ports	Access Ports
Provides flexibility to bring in additional L2 networks to ESXi.	Requires a managed switch to configure ports 1 and 2 on discrete VLANs; storage traffic must use a dedicated VLAN, no exceptions.




**Note** Both trunk and access ports require a managed switch to configure ports 1 and 2 on discrete VLANs.

See *Sample Network Configurations* for more details.

## Dual Switch Configuration

Dual switch configuration provides a slightly more complex topology with full redundancy that protects against: switch failure, link and port failure, and LOM/PCIe NIC HW failures. It requires two switches that may be standalone or stacked, and four 1GE ports and one additional PCIe NIC per server. Trunk ports are the only supported network port configuration.

### Network Topology



### Upstream Network Requirements

- Two managed switches with VLAN capability (standalone or stacked)
- 12 physical 1GE ports for three HyperFlex nodes

All 12 ports must trunk and allow all applicable VLANs.

- Jumbo frames are not required to be configured
- Portfast trunk should be configured on all ports to ensure uninterrupted access to Cisco Integrated Management Controller (CIMC)

### Virtual Network Requirements

The recommended configuration for each ESXi host calls for the following networks to be separated:

- Management traffic network
- Data traffic network
- vMotion network
- VM network

The minimum network configuration requires at least two separate networks:

- Management network (includes vMotion and VM network)
- Data network (for storage traffic)

Two vSwitches each carrying different networks are required:

- **vswitch-hx-inband-mgmt**—ESXi management (vmk0), storage controller management, VM guest portgroups
- **vswitch-hx-storage-data**—HyperFlex storage data network, Hypervisor storage interface (vmk1), vMotion (vmk2)

Failover order:

- **vswitch-hx-inband-mgmt**—entire vSwitch is set for active/standby. All services by default consume a single uplink port and failover when needed. Failover order for VM portgroups may be overridden as needed.
- **vswitch-hx-storage-data**—HyperFlex storage data network and vmk1 are set to the same active/standby order. The vMotion VMKernel port is set to use the opposite order when configured using the `post_install` script.

### Port Requirements

Four 1GE ports are required per server:

- Port 1—management (ESXi, HyperFlex controller, and CIMC) and VM guest traffic
- Port 2—HyperFlex storage traffic (and vMotion standby)
- Port 3—VM guest traffic (and management standby)
- Port 4—vMotion traffic (and storage standby)
- Two ports using LOM and two ports from a PCIe add-in NIC:
  - 1 LOM and 1 PCIe port serve management and VM guest traffic in a redundant configuration



- 1 LOM and 1 PCIe port serve storage data and vMotion traffic in a redundant and load balanced configuration
- The Intel i350 quad port NIC (UCSC-PCIE-IRJ45) must be installed for this topology:
  - The NIC may be selected at ordering time and shipped preinstalled from the factory.
  - The NIC may also be field-installed if ordered separately. Either riser #1 or #2 may be used, although riser #1 is recommended.
- Only trunk ports are supported in the dual switch configuration.
- Spanning tree portfast trunk must be enabled for all network ports connected to HyperFlex servers.
  - Failure to configure portfast causes intermittent CIMC disconnects during ESXi bootup and longer than necessary network re-convergence during physical link failure.

Physical network topology guidance:



### Warning

Proper cabling is important to ensure full network redundancy.



- Cable both integrated LOM ports to the same ToR switch.
- Cable any two out of four PCIe NIC ports to the same ToR switch. Do not connect more than two PCIe NIC ports prior to installation. Post cluster installation, you may freely use the remaining ports.

- Redundancy occurs at the vSwitch level and includes one uplink port from the onboard LOM and one uplink port from PCIe NIC for each vSwitch
- If desired, cable the dedicated CIMC port to the same switch or to an out-of-band management switch.
- Do not use the 10GE ports on the VIC.

# Common Network Requirements

Before you begin installation, confirm that your environment meets the following specific software and hardware requirements.




**Attention**


On HyperFlex M5 nodes, when using a 1GE topology manually configure the port speed to 1000/full on all switch ports. See the [Common Network Requirements, on page 7](#).

## VLAN Requirements

### Single Switch Network Topology



### Dual Switch Network Topology



Network	VLAN ID	Description
Use a separate subnet and VLANs for each of the following networks:		
VLAN for VMware ESXi, and Cisco HyperFlex management		Used for management traffic among ESXi, HyperFlex, and VMware vCenter, and must be routable. <b>Note</b> This VLAN must have access to Intersight.
CIMC VLAN		Can be same or different from the Management VLAN. <b>Note</b> This VLAN must have access to Intersight.
VLAN for HX storage traffic		Used for storage traffic and requires only L2 connectivity.
VLAN for VMware vMotion		Used for vMotion VLAN, if applicable. <b>Note</b> Can be the same as the management VLAN but not recommended.



Network	VLAN ID	Description
VLAN(s) for VM network(s)		Used for VM/application network.  <b>Note</b> Can be multiple VLANs separated by a VM portgroup in ESXi.

### Inband versus Out-of-Band CIMC

This guides assume the use of inband CIMC using Shared LOM Ext mode. The result is CIMC management traffic multiplexed with vSphere traffic onto the LOM ports, reducing cabling, switchports, and additional configuration.

Customers may opt to use the dedicated CIMC management port for out-of-band use. Users should account for this third IGE port when planning their upstream switch configuration. Additionally, the user should set the CIMC to dedicated mode during CIMC configuration. Follow [Cisco UCS C-series documentation](#) to configure the CIMC in dedicated NIC mode. Under **NIC properties**, set the NIC mode to **dedicated** before saving the configuration.

In either case, CIMC must have network access to Intersight.

### Supported vCenter Topologies

Use the following table to determine the topology supported for vCenter.

Topology	Description	Recommendation
Single vCenter	Virtual or physical vCenter that runs on an external server and is local to the site. A management rack mount server can be used for this purpose.	Highly recommended
Centralized vCenter	vCenter that manages multiple sites across a WAN.	Highly recommended
Nested vCenter	vCenter that runs within the cluster you plan to deploy.	Installation for a HyperFlex Edge cluster may be performed without a vCenter. Alternatively, you may deploy with an external vCenter and migrate it into the cluster.  For the latest information, see the <a href="#">How to Deploy vCenter on the HX Data Platform</a> tech note.

### Customer Deployment Information

A typical three-node HyperFlex Edge deployment requires 13 IP addresses – 10 IP addresses for the management network and 3 IP addresses for the vMotion network.

**CIMC Management IP Addresses**

Server	CIMC Management IP Addresses
Server 1	
Server 2	
Server 3	
Subnet mask	
Gateway	
DNS Server	
NTP Server	
<b>Note</b> NTP configuration on CIMC is required for proper Intersight connectivity.	

**Network IP Addresses**

**Note** By default, the HX Installer automatically assigns IP addresses in the 169.254.1.X range, to the Hypervisor Data Network and the Storage Controller Data Network.



**Note** Spanning Tree portfast trunk (trunk ports) should be enabled for all network ports. Failure to configure portfast may cause intermittent disconnects during ESXi bootup and longer than necessary network re-convergence during physical link failure.

<b>Management Network IP Addresses (must be routable)</b>	
<b>Hypervisor Management Network</b>	<b>Storage Controller Management Network</b>
Server 1:	Server 1:
Server 2:	Server 2:
Server 3:	Server 3:
<b>Storage Cluster Management IP address</b>	
<b>Subnet mask</b>	
<b>Default gateway</b>	

### VMware vMotion Network IP Addresses

For vMotion services, you may configure a unique VMkernel port or, if necessary, reuse the vmk0 if you are using the management VLAN for vMotion (not recommended).

Server	vMotion Network IP Addresses (configured using the post_install script)
Server 1	
Server 2	
Server 3	
Subnet mask	
Gateway	

### Port Requirements



#### Important

Ensure that the following port requirements are met in addition to the prerequisites listed for [Intersight Connectivity](#).

If your network is behind a firewall, in addition to the standard port requirements, VMware recommends ports for VMware ESXi and VMware vCenter.

- CIP-M is for the cluster management IP.
- SCVM is the management IP for the controller VM.
- ESXi is the management IP for the hypervisor.

The comprehensive list of ports required for component communication for the HyperFlex solution is located in Appendix A of the [HX Data Platform Security Hardening Guide](#)



#### Tip

If you do not have standard configurations and need different port settings, refer to [Table C-5 Port Literal Values](#) for customizing your environment.

### Hypervisor Credentials

<i>root</i> username	root
<i>root</i> password	Cisco123 <b>Important</b> Deployments based on Cisco HX Data Platform Release, 3.0 and higher, require a new custom password if you have not changed the default factory password prior to starting installation.

## VMware vCenter Configuration



**Note** HyperFlex communicates with vCenter through standard ports. Port 80 is used for reverse HTTP proxy and may be changed with TAC assistance. Port 443 is used for secure communication to the vCenter SDK and may not be changed.

<b>vCenter admin username</b> <i>username@domain</i>	
<b>vCenter admin password</b>	
<b>vCenter data center name</b>	
<b>VMware vSphere compute cluster and storage cluster name</b>	

## Network Services



**Note**

- DNS and NTP servers should reside outside of the HX storage cluster.
- Use an internally-hosted NTP server to provide a reliable source for the time.
- All DNS servers should be pre-configured with forward (A) and reverse (PTR) DNS records for each ESXi host before starting deployment. When DNS is configured correctly in advance, the ESXi hosts are added to vCenter via FQDN rather than IP address.

Skipping this step will result in the hosts being added to the vCenter inventory via IP address and require users to change to FQDN using the following procedure: [Changing Node Identification Form in vCenter Cluster from IP to FQDN](#).

<b>DNS Servers</b> <i>&lt;Primary DNS Server IP address, Secondary DNS Server IP address, ... &gt;</i>	
<b>NTP servers</b> <i>&lt;Primary NTP Server IP address, Secondary NTP Server IP address, ... &gt;</i>	
<b>Time zone</b> <i>Example: US/Eastern, US/Pacific</i>	

**Connected Services**

<b>Enable Connected Services</b> (Recommended) <i>Yes or No required</i>	
<b>Email for service request notifications</b> <i>Example: name@company.com</i>	

**Supported VMware vSphere Versions and Editions**

Confirm that a compatible version of vSphere is preinstalled on all HyperFlex servers.

HyperFlex Version	VMware vSphere Versions	VMware vSphere Editions
4.0	6.0 U1b, 6.0 U2, 6.0 U2 patch 3, 6.0 U2 patch 4, 6.0 U3, 6.5 U1, 6.7 U2	Enterprise, Enterprise Plus, Standard, Essentials Plus, ROBO
3.5(x)		Enterprise, Enterprise Plus, Standard, Essentials Plus, ROBO
3.0	6.0 U3, 6.5 U1, 6.5 U2	Enterprise, Enterprise Plus, Standard, Essentials Plus, ROBO

**Physical Requirements**

HX220c nodes are 1 RU each. For a three-node cluster, 3 RU are required.

**Reinstallation**

To perform reinstallation of a HyperFlex Edge System, contact Cisco TAC.

# HyperFlex Edge and Firmware Compatibility Matrix for 3.x Deployments

**Cisco HX Data Platform, Release 3.x based Deployments**

Confirm the component firmware on the server meets the minimum versions listed in the following tables.

**Important**

HyperFlex Edge does not support Cisco IMC versions 4.0(4a), 4.0(4b), 4.0(4c), 4.0(4d), and 4.0(4e).

Table 1: HX220c M4 / HXAF220c M4 Cluster

Component	Minimum Firmware Version - HXDP 3.x <b>*(be sure to review important note(s) above)</b>	Recommended Firmware Version - HXDP 3.x <b>*(be sure to review important note(s) above)</b>
Cisco Integrated Management Controller (CIMC)	3.0(3f)	4.0(2f)
Host Upgrade Utility (HUU) Download Link	3.0(3f) <a href="#">Download Software</a>	4.0(2f) <a href="#">Download Software</a>

Table 2: HX220c M5 / HXAF220c M5 Cluster

Component	Minimum Firmware Version - HXDP 3.x <b>*(be sure to review important note(s) above)</b>	Recommended Firmware Version - HXDP 3.x <b>*(be sure to review important note(s) above)</b>
Cisco Integrated Management Controller (CIMC)	3.1(2d)	4.1(2f)
Host Upgrade Utility (HUU) Download Link	3.1(2d) <a href="#">Download Software</a>	4.1(2f) <a href="#">Download Software</a>

## Intersight Connectivity

Consider the following prerequisites pertaining to Intersight connectivity:

- Before installing the HX cluster on a set of HX servers, make sure that the device connector on the corresponding UCS Manager instance is properly configured to connect to Cisco Intersight and claimed.
- All device connectors must properly resolve `svc.ucs-connect.com` and allow outbound initiated HTTPS connections on port 443. The current version of the HX Installer supports the use of an HTTP proxy, except when the cluster is redeployed and is not new from the factory.
- All controller VM management interfaces must properly resolve `download.intersight.com` and allow outbound initiated HTTPS connections on port 443. The current version of HX Installer supports the use of an HTTP proxy if direct Internet connectivity is unavailable, except when the cluster is redeployed and is not new from the factory.
- The intended ESX server, HX Controller network, and vCenter host must be accessible through UCS Fabric Interconnect management interfaces.
- Starting with HXDP release 3.5(2a), the Intersight installer does not require a factory installed controller VM to be present on the HyperFlex servers.

In addition, on post-cluster deployment the new HX cluster is automatically claimed in Intersight for ongoing management.