



ATM SVC Troubleshooting Enhancements

Last Updated: December 1, 2011

Feature History

Release	Modification
12.2(8)T	This feature was introduced.

This document describes the ATM SVC Troubleshooting Enhancements feature in Cisco IOS Release 12.2(8)T. It includes the following sections:

- [Finding Feature Information, page 1](#)
- [Feature Overview, page 1](#)
- [Supported Platforms, page 2](#)
- [Supported Standards and MIBs and and RFCs, page 3](#)
- [Prerequisites, page 3](#)
- [Configuration Tasks, page 3](#)
- [Monitoring and Maintaining ATM SVCs, page 3](#)
- [Configuration Examples, page 4](#)
- [Command Reference, page 4](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Feature Overview

The ATM SVC Troubleshooting Enhancements feature introduces two new debug commands: **debug atm native** and **debug atm nmba**. These commands can be used to troubleshoot ATM switched virtual circuits



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

(SVCs). The **debug atm nbma** and **debug atm native** commands are used to debug problems with Resource Reservation Protocol (RSVP) SVC creation and teardown. The **debug atm native** command can also be used to debug problems with SVCs created using static maps.

- [Benefits, page 2](#)
- [Restrictions, page 2](#)
- [Related Documents, page 2](#)

Benefits

The ATM SVC Troubleshooting Enhancements feature provides two debug commands that can be used to troubleshoot ATM SVCs that were created using static maps or RSVP.

Restrictions

The **debug atm nbma** command can be used only to debug RSVP SVCs. The **debug atm native** command can be used only to debug problems with RSVP SVCs or SVCs that were created using static maps.

Related Documents

- *Cisco IOS Wide-Area Networking Configuration Guide*, Release 12.2
- *Cisco IOS Wide-Area Networking Command Reference*, Release 12.2

Supported Platforms

- Cisco 2600 series
- Cisco 3620
- Cisco 3631
- Cisco 3640
- Cisco 3660
- Cisco 3725
- Cisco 3745
- Cisco 7200 series
- Cisco 7500 series
- Cisco MC3810 series
- Universal Router Module (URM) for Cisco IGX 8400

Determining Platform Support Through Cisco Feature Navigator

Cisco IOS software is packaged in feature sets that support specific platforms. To get updated information regarding platform support for this feature, access Cisco Feature Navigator. Cisco Feature Navigator dynamically updates the list of supported platforms as new platform support is added for the feature.

Cisco Feature Navigator is a web-based tool that enables you to quickly determine which Cisco IOS software images support a specific set of features and which features are supported in a specific Cisco IOS image. You can search by feature or release. Under the release section, you can compare releases side by side to display both the features unique to each software release and the features in common.

To access Cisco Feature Navigator, you must have an account on Cisco.com. If you have forgotten or lost your account information, send a blank e-mail to cco-locksmith@cisco.com. An automatic check will

verify that your e-mail address is registered with Cisco.com. If the check is successful, account details with a new random password will be e-mailed to you. Qualified users can establish an account on Cisco.com by following the directions at <http://www.cisco.com/register> .

Cisco Feature Navigator is updated regularly when major Cisco IOS software releases and technology releases occur. For the most current information, go to the Cisco Feature Navigator home page at the following URL:

<http://www.cisco.com/go/fn>

Supported Standards and MIBs and and RFCs

Standards

API Semantics for Native ATM Services , ATM Forum, February 1999

MIBs

No new or modified MIBs are supported by this feature.

To obtain lists of supported MIBs by platform and Cisco IOS release, and to download MIB modules, go to the Cisco MIB website on Cisco.com at the following URL:

<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

RFCs

No new or modified RFCs are supported by this feature.

Prerequisites

The tasks in this document assume that ATM SVCs or RSVP SVCs are already created.

Configuration Tasks

None.

Monitoring and Maintaining ATM SVCs

To monitor and maintain RSVP SVCs or ATM SVCs that were created using static maps, use the following commands in privileged EXEC mode:

Command	Purpose
Router# debug atm native {[api] [conn] [error] [filter]}	Displays Native ATM API events.

Command	Purpose
Router# debug atm nbma [api]	Displays NBMA API events during the creation of RSVP SVCs.

Configuration Examples

None.

Command Reference

The following commands are introduced or modified in the feature or features documented in this module. For information about these commands, see the *Cisco IOS Asynchronous Transfer Mode Command Reference*. For information about all Cisco IOS commands, go to the Command Lookup Tool at <http://tools.cisco.com/Support/CLILookup> or to the *Cisco IOS Master Commands List*.

- **debug atm native**
- **debug atm nbma**

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.