



Flexible Netflow - Ingress VRF Support

The Flexible Netflow - Ingress VRF Support feature enables collecting the virtual routing and forwarding (VRF) ID from incoming packets on a router by applying an input flow monitor having a flow record that collects the VRF ID as a key or a nonkey field.

- [Finding Feature Information, on page 1](#)
- [Information About Flexible NetFlow Ingress VRF Support , on page 1](#)
- [How to Configure Flexible NetFlow Ingress VRF Support , on page 2](#)
- [Configuration Examples for Flexible NetFlow Ingress VRF Support , on page 7](#)
- [Additional References, on page 8](#)
- [Feature Information for Flexible NetFlow—Ingress VRF Support , on page 9](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Information About Flexible NetFlow Ingress VRF Support

Flexible NetFlow—Ingress VRF Support Overview

This feature enables collecting the virtual routing and forwarding (VRF) ID from incoming packets on a router by applying an input flow monitor having a flow record that collects the VRF ID as a key or a nonkey field.

How to Configure Flexible NetFlow Ingress VRF Support

Creating a Customized Flow Record

Perform this task to configure a customized flow record.

Customized flow records are used to analyze traffic data for a specific purpose. A customized flow record must have at least one **match** criterion for use as the key field and typically has at least one **collect** criterion for use as a nonkey field.

There are hundreds of possible permutations of customized flow records. This task shows the steps that are used to create one of the possible permutations. Modify the steps in this task as appropriate to create a customized flow record for your requirements.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **flow record *record-name***
4. **description *description***
5. **match {ip | ipv6} {destination | source} address**
6. Repeat Step 5 as required to configure additional key fields for the record.
7. **collect interface {input | output}**
8. Repeat the above step as required to configure additional nonkey fields for the record.
9. **end**
10. **show flow record *record-name***
11. **show running-config flow record *record-name***

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|---|--|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. • Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters global configuration mode. |
| Step 3 | flow record <i>record-name</i> Example: Device(config)# flow record FLOW-RECORD-1 | Creates a flow record and enters Flexible NetFlow flow record configuration mode. • This command also allows you to modify an existing flow record. |

| | Command or Action | Purpose |
|----------------|--|--|
| Step 4 | description <i>description</i> Example: Device(config-flow-record)# description Used for basic traffic analysis | (Optional) Creates a description for the flow record. |
| Step 5 | match {ip ipv6} {destination source} address Example: Device(config-flow-record)# match ipv4 destination address | Configures a key field for the flow record. Note This example configures the IPv4 destination address as a key field for the record. For information about the other key fields available for the match ipv4 command, and the other match commands that are available to configure key fields. |
| Step 6 | Repeat Step 5 as required to configure additional key fields for the record. | — |
| Step 7 | collect interface {input output} Example: | Configures the input interface as a nonkey field for the record. Note This example configures the input interface as a nonkey field for the record. |
| Step 8 | Repeat the above step as required to configure additional nonkey fields for the record. | — |
| Step 9 | end Example: Device(config-flow-record)# end | Exits Flexible NetFlow flow record configuration mode and returns to privileged EXEC mode. |
| Step 10 | show flow record <i>record-name</i> Example: Device# show flow record FLOW_RECORD-1 | (Optional) Displays the current status of the specified flow record. |
| Step 11 | show running-config flow record <i>record-name</i> Example: Device# show running-config flow record FLOW_RECORD-1 | (Optional) Displays the configuration of the specified flow record. |

Creating a Customized Flow Monitor

Perform this required task to create a customized flow monitor.

Each flow monitor has a separate cache assigned to it. Each flow monitor requires a record to define the contents and layout of its cache entries. These record formats can be one of the predefined formats or a user-defined format. An advanced user can create a customized format using the **flow record** command.

Before you begin

If you want to use a customized record instead of using one of the Flexible NetFlow predefined records, you must create the customized record before you can perform this task. If you want to add a flow exporter to the flow monitor for data export, you must create the exporter before you can complete this task.



Note You must use the **no ip flow monitor** command to remove a flow monitor from all of the interfaces to which you have applied it before you can modify the parameters for the **record** command on the flow monitor.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **flow monitor *monitor-name***
4. **description *description***
5. **record {*record-name* | netflow-original | netflow {ipv4 | ipv6} *record* [*peer*]}**
6. **cache {*entries number* | timeout {**active** | **inactive** | **update**} *seconds* | {**immediate** | **normal** | **permanent**}}**
7. Repeat Step 6 as required to finish modifying the cache parameters for this flow monitor.
8. **statistics packet *protocol***
9. **statistics packet *size***
10. **exporter *exporter-name***
11. **end**
12. **show flow monitor [[name] *monitor-name* [cache [format {csv | record | table}]]] [statistics]**
13. **show running-config flow monitor *monitor-name***

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|---|
| Step 1 | enable Example: > enable | Enables privileged EXEC mode. • Enter your password if prompted. |
| Step 2 | configure terminal Example: # configure terminal | Enters global configuration mode. |
| Step 3 | flow monitor <i>monitor-name</i> Example: | Creates a flow monitor and enters Flexible NetFlow flow monitor configuration mode. |

| | Command or Action | Purpose |
|----------------|---|--|
| | (config) # flow monitor FLOW-MONITOR-1 | • This command also allows you to modify an existing flow monitor. |
| Step 4 | description description Example: (config-flow-monitor) # description Used for basic ipv4 traffic analysis | (Optional) Creates a description for the flow monitor. |
| Step 5 | record {record-name netflow-original netflow {ipv4 ipv6} record [peer]} Example: (config-flow-monitor) # record FLOW-RECORD-1 | Specifies the record for the flow monitor. |
| Step 6 | cache {entries number timeout {active inactive update} seconds {immediate normal permanent}} Example: | (Optional) Modifies the flow monitor cache parameters such as timeout values, number of cache entries, and the cache type. The values for the keywords associated with the timeout keyword have no effect when the cache type is set to immediate . |
| Step 7 | Repeat Step 6 as required to finish modifying the cache parameters for this flow monitor. | — |
| Step 8 | statistics packet protocol Example: (config-flow-monitor) # statistics packet protocol | (Optional) Enables the collection of protocol distribution statistics for Flexible NetFlow monitors. |
| Step 9 | statistics packet size Example: (config-flow-monitor) # statistics packet size | (Optional) Enables the collection of size distribution statistics for Flexible NetFlow monitors. |
| Step 10 | exporter exporter-name Example: (config-flow-monitor) # exporter EXPORTER-1 | (Optional) Specifies the name of an exporter that was created previously. |
| Step 11 | end Example: (config-flow-monitor) # end | Exits Flexible NetFlow flow monitor configuration mode and returns to privileged EXEC mode. |
| Step 12 | show flow monitor [[name] monitor-name [cache [format {csv record table}]] [statistics]] Example: | (Optional) Displays the status and statistics for a Flexible NetFlow flow monitor. |

Applying a Flow Monitor to an Interface

| | Command or Action | Purpose |
|----------------|--|--|
| | # show flow monitor FLOW-MONITOR-2 cache | |
| Step 13 | show running-config flow monitor <i>monitor-name</i> Example: <pre># show running-config flow monitor FLOW_MONITOR-1</pre> | (Optional) Displays the configuration of the specified flow monitor. |

Applying a Flow Monitor to an Interface

Before it can be activated, a flow monitor must be applied to at least one interface. Perform this required task to activate a flow monitor.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface** *type number*
4. **{ip | ipv6} flow monitor** *monitor-name* {**input | output**}
5. Repeat Steps 3 and 4 to activate a flow monitor on any other interfaces in the device over which you want to monitor traffic.
6. **end**
7. **show flow interface** *type number*
8. **show flow monitor name** *monitor-name* **cache format record**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|---|
| Step 1 | enable Example: <pre>Device> enable</pre> | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: <pre>Device# configure terminal</pre> | Enters global configuration mode. |
| Step 3 | interface <i>type number</i> Example: <pre>Device(config)# interface GigabitEthernet 0/0/0</pre> | Specifies an interface and enters interface configuration mode. |
| Step 4 | {ip ipv6} flow monitor <i>monitor-name</i> { input output } Example: <pre></pre> | Activates a flow monitor that was created previously by assigning it to the interface to analyze traffic. |

| | Command or Action | Purpose |
|---------------|--|---|
| | Device(config-if)# ip flow monitor FLOW-MONITOR-1 input | |
| Step 5 | Repeat Steps 3 and 4 to activate a flow monitor on any other interfaces in the device over which you want to monitor traffic. | — |
| Step 6 | end Example: Device(config-if)# end | Exits interface configuration mode and returns to privileged EXEC mode. |
| Step 7 | show flow interface type number Example: Device# show flow interface GigabitEthernet 0/0/0 | Displays the status of Flexible NetFlow (enabled or disabled) on the specified interface. |
| Step 8 | show flow monitor name monitor-name cache format record Example: Device# show flow monitor name FLOW_MONITOR-1 cache format record | Displays the status, statistics, and flow data in the cache for the specified flow monitor. |

Configuration Examples for Flexible NetFlow Ingress VRF Support

Example: Configuring Flexible NetFlow for Ingress VRF Support

The following example configures the collection of the virtual routing and forwarding (VRF) ID from incoming packets on a router by applying an input flow monitor having a flow record that collects the VRF ID as a key field.

This example starts in global configuration mode.

```
!
flow record rm_1
match routing vrf input
match ipv4 source address
match ipv4 destination address
collect interface input
collect interface output
collect counter packets
!
flow monitor mm_1
record rm_1
!
interface GigabitEthernet 0/0/0
```

Additional References

```

ip vrf forwarding green
ip address 172.16.2.2 255.255.255.252
ip flow monitor mm_1 input
!
end

```

Additional References

Related Documents

| Related Topic | Document Title |
|---|---|
| Cisco IOS commands | Cisco IOS Master Command List, All Releases |
| Flexible NetFlow conceptual information and configuration tasks | <i>Flexible NetFlow Configuration Guide</i> |
| Flexible NetFlow commands | <i>Cisco IOS Flexible NetFlow Command Reference</i> |

Standards/RFCs

| Standard | Title |
|--|-------|
| No new or modified standards/RFCs are supported by this feature. | — |

MIBs

| MIB | MIBs Link |
|------|---|
| None | To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs |

Technical Assistance

| Description | Link |
|---|---|
| The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password. | http://www.cisco.com/cisco/web/support/index.html |

Feature Information for Flexible NetFlow—Ingress VRF Support

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for Flexible NetFlow—Ingress VRF Support

| Feature Name | Releases | Feature Information |
|--------------------------------------|--|--|
| Flexible NetFlow—Ingress VRF Support | 12.2(33)SRE 12.2(50)SY 15.0(1)M 15.0(1)SY 15.0(1)SY1 | Enables collecting the virtual routing and forwarding (VRF) ID from incoming packets on a router by applying an input flow monitor having a flow record that collects the VRF ID as a key or a nonkey field. Support for this feature was added for Cisco 7200 and 7300 Network Processing Engine (NPE) series routers in Cisco IOS Release 12.2(33)SRE. The following commands were introduced or modified: collect routing, match routing, option (Flexible NetFlow), show flow monitor . |

