



RSVP over UDP

Last Updated: July 19, 2012

The Resource Reservation Protocol (RSVP) over UDP feature provides the capability for routers to enable neighbor routers to process and send RSVP control packets over UDP. With the implementation of the RSVP over UDP feature, the RSVP protocol stack is enhanced to support processing of RSVP control messages over UDP and raw IP.

- [Finding Feature Information, page 1](#)
- [Prerequisites for RSVP Over UDP , page 1](#)
- [Information About RSVP over UDP, page 2](#)
- [How to Configure RSVP over UDP, page 2](#)
- [Configuration examples for RSVP over UDP, page 4](#)
- [Additional References, page 5](#)
- [Feature Information for RSVP over UDP , page 5](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for RSVP Over UDP

- You must enable RSVP before you enable the RSVP over UDP feature.
- The RSVP stack running on the client host must support sending and receiving the RSVP control messages with the first hop routers they are connected to.



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Information About RSVP over UDP

- [RSVP over UDP, page 2](#)

RSVP over UDP

The RSVP over UDP feature addresses the following scenarios:

- A router intends to communicate to the first hop router over UDP but not raw IP.
- A firewall that is located in between two routers drops raw IP packets due to security concerns, but allows UDP packets.

How to Configure RSVP over UDP

- [Enabling RSVP, page 2](#)
- [Configuring RSVP over UDP, page 3](#)

Enabling RSVP

This task starts RSVP and sets the bandwidth and single-flow limits. By default, RSVP is disabled so that it is backward compatible with systems that do not implement RSVP. To enable RSVP for IP on an interface, perform the following task.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface** *type number*
4. **ip rsvp bandwidth** [*interface-bandwidth* [**percent** *percent-bandwidth* | [*single-flow-bandwidth*] [**sub-pool** *bandwidth*]]]
5. **end**

DETAILED STEPS

Command or Action	Purpose
Step 1 enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.

Command or Action	Purpose
Step 2 <code>configure terminal</code> Example: Device# <code>configure terminal</code>	Enters global configuration mode.
Step 3 <code>interface type number</code> Example: Device(config)# <code>interface fastethernet 0/1</code>	Configures the specified interface and enters interface configuration mode.
Step 4 <code>ip rsvp bandwidth [interface-bandwidth [percent percent-bandwidth] [single-flow-bandwidth] [sub-pool bandwidth]]</code> Example: Device(config-if)# <code>ip rsvp bandwidth 23 54</code>	Enables RSVP for IP on an interface.
Step 5 <code>end</code> Example: Device(config-if)# <code>end</code>	Exits interface configuration mode and returns to privileged EXEC mode.

Configuring RSVP over UDP

To enable RSVP over UDP, perform the following task:

SUMMARY STEPS

1. `enable`
2. `configure terminal`
3. `ip rsvp udp neighbor neighbor-IP-address router [vrf vrf-name]`
4. `end`

DETAILED STEPS

Command or Action	Purpose
Step 1 <code>enable</code> Example: Device> <code>enable</code>	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.

Command or Action	Purpose
Step 2 <code>configure terminal</code> Example: <pre>Device# configure terminal</pre>	Enters global configuration mode.
Step 3 <code>ip rsvp udp neighbor <i>neighbor-IP-address</i> router [vrf <i>vrf-name</i>]</code> Example: <pre>Device(config)# ip rsvp udp neighbor 10.1.1.1 router vrf vrf-1</pre>	Configures the RSVP over UDP feature for the neighbor router.
Step 4 <code>end</code> Example: <pre>Device(config)# end</pre>	Returns to privileged EXEC mode.

Configuration examples for RSVP over UDP

- [Example: Enabling RSVP, page 4](#)
- [Example: Configuring RSVP over UDP, page 4](#)

Example: Enabling RSVP

The following example shows how to enable RSVP for IP on an interface:

```
enable
configure terminal
interface fastethernet 0/1
 ip rsvp bandwidth 23 54
end
```

Example: Configuring RSVP over UDP

The following example shows how to configure the RSVP over UDP feature on a neighbor router:

```
enable
configure terminal
ip rsvp udp neighbor 10.1.1.1 router vrf vrf-1
end
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	<i>Master Command List, All Releases</i>
RSVP commands	<i>Quality of Service Solutions Command Reference</i>
Overview on RSVP	<i>Signaling Overview</i>

Standards and RFCs

Standard/RFC	Title
RFC 2205	<i>RSVP—Version 1 Function Specification</i>
RFC 2209	<i>RSVP—Version 1 Message Processing Rules</i>

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for RSVP over UDP

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1 *Feature Information for RSVP over UDP*

Feature Name	Releases	Feature Information
RSVP over UDP	15.2(4)M	<p>The RSVP over UDP feature allows a router to enable a neighbor router to process and send RSVP control packets over UDP.</p> <p>The following commands were introduced or modified: ip rsvp udp neighbor.</p>

© 2012-2013 Cisco Systems, Inc. All rights reserved.