

# show nbf sessions

To display NetBEUI connection information, use the **show nbf sessions** command in EXEC mode.

**show nbf sessions**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** EXEC

Command History	Release	Modification
	11.1	This command was introduced.

**Examples** The following is sample output from the **show nbf sessions** command:

```
Router> show nbf sessions

Async6 NetBIOS Session Table:
Srcnum  Destnum  Dest-Interface  DestMAC
8        6         Ethernet0 00aa.005b.c17b

NetBIOS Global Session Table:
Srcnum  Destnum  Dest-Interface  DestMAC  Src-Interface  SrcMac(I)

6        8         Async7 0000.0000.0000  Ethernet0 00aa.005b.c17b(95)
ADD_[GROUP]NAME_QUERY queuesize=0
STATUS_QUERY queuesize=0
STATUS_RESPONSE queuesize=0
NAME_QUERY queuesize=0
NAME_RECOGNIZED queuesize=0
SESSION_INITIALIZE queuesize=0
SESSION_INITIALIZE (pending) queuesize=0
```

[Table 1](#) describes the significant fields shown in the display.

**Table 1** *show nbf sessions Field Descriptions*

Field	Description
Interface NetBIOS Session Table:	Summarizes Async/ISDN interface NetBIOS connection information.
Srcnum, Destnum	Source and destination connection numbers.
Dest-Interface, DestMAC	Destination interface and MAC address.
Global NetBIOS Session Table:	Summarizes LAN NetBIOS connection information.
Dest-Interface DestMAC	Destination interface (Async7 in this case) and MAC address (0000.0000.0000 in this case).

Table 1 *show nbf sessions Field Descriptions (continued)*

Field	Description
Src-Interface SrcMac	Source interface (Ethernet0 in this case) and MAC address (00aa.005b.c17b(95) in this case).
NetBIOS Datagram Queue Summary:	Summarizes NetBIOS pending datagram queues.
ADD_[GROUP]NAME_QUERY	Add Group Name Query packets.
STATUS_QUERY	Status Query packets.
STATUS_RESPONSE	Status Response packets.
NAME_QUERY	Name Query packets.
NAME_RECOGNIZED	Name Recognized packets.
SESSION_INITIALIZE (pending)	NetBIOS session Initialize packets.

**Related Commands**

Command	Description
<b>ppp multilink group</b>	Restricts a physical link to joining only a designated multilink-group interface.
<b>netbios access-list</b>	Defines an IPX NetBIOS FindName access list filter.
<b>netbios input-access-filter</b>	Controls incoming IPX NetBIOS FindName messages.
<b>netbios name-cache</b>	Defines a static NetBIOS name cache entry, tying the server with the name netbios-name to the mac-address, and specifying that the server is accessible either locally through the interface-name specified, or remotely through the ring-group group-number specified.
<b>netbios output-access-filter</b>	Controls outgoing NetBIOS FindName messages.
<b>show nbf cache</b>	Displays NetBIOS name cache contents.

# show plat hardware qfp active feature ess state pppoe

To display Quantum Flow Processor (QFP) edge switch services active instance state information for a PPP over Ethernet (PPPoE) client, use the **show plat hardware qfp active feature ess state pppoe** command in privileged EXEC mode.

**show plat hardware qfp active feature ess state pppoe [unknown-history]**

<b>Syntax Description</b>	<b>unknown-history</b> (Optional) Displays information about the unknown session reporting history.
---------------------------	---

**Command Default** Information about all PPPoE sessions are displayed.

**Command Modes** Privileged EXEC (#)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Release 2.1	This command was introduced on the Cisco ASR 1000 Series Aggregation Services Routers.
	Cisco IOS XE Release 2.6	This command was modified. This command was extended to include PPPoE unknown session information.

**Usage Guidelines** You can use the **show plat hardware qfp active feature ess state pppoe** command to display the number of data packets received in QFP for the unknown PPPoE sessions and the number of unknown sessions that have been reported to the Cisco IOS router. For example, if the QFP receives 100 data packets for one unknown PPPoE session, then the total number of packets received will be 100 and one session will be reported.

Cisco IOS router sends a PPPoE active discovery terminate (PADT) message to tear down reported unknown PPPoE sessions if the **sessions auto cleanup** command is configured in the Broadband Access Aggregation (BBA) group.

**Examples** The following is sample output from the **show plat hardware qfp active feature ess state pppoe** command:

```
Router# show plat hardware qfp active feature ess state pppoe

ESS PPPOE State:
  Current number of segments: 0

PPPoE Session Lookup Depth:
  Distribution: 100%

PPPoE Unknown Session Handling:
  Reporting Rate(PPS)       : 100
  Refreshing Period(Second): 90
```

■ **show plat hardware qfp active feature ess state pppoe**

```

Current period:
  Start      : Dec 10 01:59:51
  Checked    : 0
  Reported   : 0

```

Table 2 describes the significant fields shown in the display.

**Table 2** *show plat hardware qfp active feature ess state pppoe Field Descriptions*

<b>Field</b>	<b>Description</b>
ESS PPPOE State:	Current state of the Enterprise Storage Server (ESS).
Current number of segments:	Total number of segments.
PPPoE Session Lookup Depth:	Lookup depth of the PPPoE session, in percentage.
Distribution:	Distribution value, in percentage.
PPPoE Unknown Session Handling:	Details about handling the PPPoE unknown sessions.
Reporting Rate(PPS):	Reporting rate in packets per second.
Refreshing Period(Second):	Time taken to refresh, in seconds.
Current period:	Current status.
Start:	Date and time at which the command was executed.
Checked:	Total number of data packets for the unknown PPPoE sessions received by the QFP.
Reported:	Total number of unknown sessions that have been reported to the Cisco IOS router.

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>sessions auto cleanup</b>	Configures an aggregation device to attempt to recover PPPoE sessions that failed after reload by notifying CPE devices about the PPPoE session failures.

# show port config

To display the configuration parameters of the active session for the specified port or the specified port range, use the **show port config** command in EXEC mode.

## Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show port config {slot | slot/port}
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show port config {shelfslot | shelfslot/port}
```

Syntax Description	slot	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	slot/port	All ports on the specified slot and service processing element (SPE). For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. The port values range from 0 to one less than the number of ports supported by the card. You must include the slash mark.
	shelfslot	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
	shelfslot/port	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and port values range from 0 to one less than the number of ports supported by the card. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5400 and Cisco AS5800.
	12.2(2)XA	This command was implemented on the Cisco AS5350.
	12.2(2)XB1	This command was integrated into Cisco IOS Release 12.2(2)XB1.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T.

**Usage Guidelines** The port should have an associated active session when the **show port config** command is executed.



**Note** The **show port config** command is similar to the **show modem config** MICA technologies modem command.

**Examples**

The following example shows output from the **show port config** command on the Cisco AS5400 with the NextPort DFC. This example shows port configuration for the modem service port slot 1, port 0.

```
Router# show port config 1/0

Service Type                               :Modem service
Originate/Answer Mode                       :Answer
Data Bits Selection                         :8
Parity Selection                            :No Parity
Stop bits Selection                         :1
V.42 ODP generation                         :Enabled
EC Autodetect Time-out                     :5000 ms
Protocol Negotiation Time-out               :10000 ms
Protocol Negotiation Fallback character     :13
Protocol Negotiation Retransmission Limit  :12
EC Min, Max Octets Frame length            :256
Data Compression                           :V.44Tx V.44Rx
ARA Error Correction                        :ARA1.0 & ARA2.0 Disabled
V.42 Error Correction                       :V.42(LAP-M) Originate&Answer enabled
MNP Error Correction                       :MNP Originate&Answer enabled
Link Protocol Fallback                     :Async Framing (Start/Stop/Parity)
Calling Tone                               :Disabled
Guard Tone                                 :Disabled
Modem Standard                             :V.90 Automode
Max Non-PCM Connect Rate                   :33600 bps
Min Non-PCM Connect Rate                   :300 bps
Max PCM Connect Rate                       :60000 bps
Min PCM Connect Rate                       :28000 bps
Signal Quality Threshold                   :Bit Errors >= 1:1000 cause recovery
Fallback/Fallforward Squelch Timer         :500 ms
Fall Forward Timer                         :10000 ms
Fall Back Timer                            :500 ms
Terminate Time-out                         :20 secs
Wait for Data Mode Time-out                :60 secs
Lost Carrier To Hang-up Delay              :1400 ms
PCM Transmit Level Setting                 :-13 dBm
Retrain Limit                              :4
V.34 Max Symbol Rate                       :3429 Baud
V.34 Min Symbol Rate                       :2400 Baud
V.34 Carrier Frequency                     :Auto Carrier Selection
V.34 Preemphasis Filter Selection          :11
+++ Escape Detection                       :Enabled-in-Originate-Mode-Only
AT Command Processor                       :Enabled
Call Setup Delay                           :0 ms
Automatic Answer Delay                     :2 secs
Escape Detection Character                  :ASCII 43 (+)
Carriage Return Character                  :ASCII 13 (CR)
Line Feed Character                        :ASCII 10 (LF)
Backspace Character                        :ASCII 8 (BS)
Pause Before Blind Dialing                 :2 secs
Comma Dial Modifier Time                   :2 secs
MOH Timeout                                :No limit
QC Configuration                           :Enabled ANSpcm Level -12dBm
V.44 Max Tx Codewords                      :256
V.44 Max Rx Codewords                      :256
V.44 Max Tx String Length                  :32
V.44 Max Rx String Length                  :32
V.44 Max Tx History Size                   :256
V.44 Max Rx History Size                   :256
```

The following example shows port configuration information for a digital service port slot 1, port 8 on the Cisco AS5800 with the UPC:

```
Router# show port config 1/8

Shelf/Slot/SPE/Port -- 1/8/27/165
Service Type                : Modem service
Originate/Answer Mode      : Answer
Data Bits Selection        : 8
Parity Selection           : No Parity
Stop bits Selection        : 1
V.42 ODP generation        : Enabled
EC Autodetect Time-out     : 5000 ms
Protocol Negotiation Time-out : 10000 ms
Protocol Negotiation Fallback character : 13
Protocol Negotiation Retransmission Limit : 12
EC Min, Max Octets Frame length : 256
Data Compression           : V.42bis or MNP5
ARA Error Correction       : ARA1.0 & ARA2.0 Disabled
V.42 Error Correction      : V.42(LAP-M) Originate&Answer enabled
MNP Error Correction       : MNP Originate&Answer enabled
Link Protocol Fallback    : Async Framing (Start/Stop/Parity)
Calling Tone               : Disabled
Guard Tone                : Disabled
Modem Standard             : V.90 Automode
Max Non-PCM Connect Rate  : 33600 bps
Min Non-PCM Connect Rate  : 300 bps
Max PCM Connect Rate      : 60000 bps
```

Table 3 describes the significant fields shown in the displays.

**Table 3** *show port config Field Descriptions*

Field	Description
Service Type	Digital or analog service type.
Originate/Answer Mode	Answer or originate. Default is answer.
Data Bits Selection	7, 8, or 9 data bits. Default is 8.
Parity Selection	0 = no parity, 1 = even parity, 2 = odd parity. Default is no parity.
Stop bits Selection	1 or 2 stop bits. Default is 1 stop bit.
V.42 ODP generation	Disabled or generate ODP sequence when originating a V.42 call. Default is Generate ODP sequence when originating a V.42 call.
EC Autodetect Time-out value	Maximum period, in milliseconds (ms), during which the modem will run an automated detection machine upon the incoming data. Default is 5000 ms.
Protocol Negotiation Time-out	Maximum wait (in ms) for error correction protocol negotiation before fallback. Default is 10000 ms.
Protocol Negotiation Fallback Character	0 to 127. Default is 13.
Protocol Negotiation Retransmission Limit	0 = Do not disconnect on excessive retransmission; 1 to 255 = number of successive retransmissions to cause disconnect. Default is 12.
EC Min, Max Octets Frame Length	Buffer length; 64 to 1024 octets of data. Default is 256.

Table 3 show port config Field Descriptions (continued)

Field	Description
Data Compression	Disabled, V.42bis, MNP5, or V.42bis or MNP5 (V.42 has precedence). Default is V.42bis or MNP5 (V.42 has precedence).
ARA Error Correction	ARA1.0 & ARA2.0 Disabled, Enabled for Answer only, Enabled for Answer originate ARA1.0, and Enabled for Answer originate ARA2.0. Default is Enabled for Answer only.
V.42 Error Correction	V.42(LAP-M) Disabled, V.42(LAP-M) Originate&Answer enabled. Default is Disabled.
MNP Error Correction	MNP Disabled or MNP Originate&Answer enabled. Default is MNP Originate&Answer enabled.
Link Protocol Fallback	Asynch Framing (Start/Stop/Parity), Synchronous framing (Raw 8 bits to DSP), or Disconnect (Hang-up). Default is Asynch Framing (Start/Stop/Parity).
DSP processor MVIP TDM slice	0 to 15.
Calling Tone	Disabled or Send calling tone. Default is Disabled.
Guard Tone	Disabled, Use Guard tone (V.22 & V.22bis only). Default is Disabled.
Modem Standard	V.34bis Automode with terbo, V.34bis Automode skip terbo, V.32 terbo Automode, V.32bis Automode, V.22bis Automode, or K56Flex 1.1. Default is V.34bis Automode with terbo.
Max. Connect Rate	75 to 56000 bits per second (bps).
Min. Connect Rate	75 to 56000 bps.
Signal Quality Threshold	No action on bit errors, Bit Errors >=1:100 cause recovery, Bit Errors >=1:1000 cause recovery, Bit Errors >=1:10000 cause recovery, Bit Errors >=1:100000 cause recovery, or Bit Errors >=1:1000000 cause recovery. Default is 1:1000.
Fallback/Fallforward Squelch Timer	Time to delay (in ms) after a speed shift before allowing another speed shift. Default is 500 ms.
Fall Forward Timer	Elapsed time (in ms) with continuous good signal quality to cause a fall forward. Default is 10000 ms.
Fall Back Timer	Elapsed time (in ms) with bad signal quality to cause a fallback. Default is 500 ms.
Terminate Time-out	Elapsed time (in seconds) after a disconnect request before forcing a link disconnection. During this period, the modem sends buffered data and then clears down the link. Default is 20 seconds.
Wait for Data Mode Time-out	Maximum time (in seconds) during link establishment before disconnection. Default is 40; 60 for K56Flex.
Lost Carrier To Hang-up Delay	Maximum time (in ms) without a carrier to cause the link disconnect. Default is 1400 ms.
PCM Transmit Level Setting	6d Bm, 7 dBm, 8 dBm, -20 dBm, or -21 dBm. Default is 9 dBm.
Retrain Limit	Maximum successive failed retrains to cause the link to disconnection. Default is 4.



Table 3 *show port config Field Descriptions (continued)*

Field	Description
V.34 Max. Symbol Rate	2400 baud, 2743 baud, 2800 baud, 3000 baud, 3200 baud, or 3429 baud. Default is 3429 baud.
V.34 Min. Symbol Rate	2400 baud, 2743 baud, 2800 baud, 3000 baud, 3200 baud, or 3429 baud. Default is 2400 baud.
V.34 Carrier Frequency	Low Carrier, High Carrier, or Auto Carrier Selection. Default is High Carrier.
V.34 Preemphasis Filter Selection	0 to 10 = a selected filter; 11 = Automatic Preemphasis Selection. Default is 11.
Tx and Rx Signaling Type	NULL signaling, MF signaling, DTMF signaling, Lower band R2 signaling, Upper band R2 signaling, or R1 signaling. Default is NULL signaling.
Call Progress Tone Detection	No tone detection, Dial tone detection, Ring-Back tone detection, or Busy tone detection. Default is No tone detection.
+++ Escape Detection	Disabled, Enabled, or Enabled-in-Originate-Mode-Only. Default is Enabled-in-Originate-Mode-Only.
AT Command Processor	Disabled or Enabled. Default is Disabled.
Call Set Up Delay	No delay before link initiation, delay value (1 to 255 ms). Default is No delay.
Automatic Answer	Answer immediately, delay value (1 to 255 seconds). Default is 1 second.
Escape Detection Character	ASCII value (0 to 127). Default is 43.
Carriage Return Character	ASCII value (0 to 127). Default is 13.
Line Feed Character	ASCII value (0 to 127). Default is 10.
Backspace Character	ASCII value (0 to 127). Default is 8.
Pause Before Blind Dialing	2 to 255 seconds. Default is 2.
Wait For Carrier After Dial	Wait for data mode timeout.
Comma Dial Modifier Time	2 to 255 seconds. Default is 2.

**Related Commands**

Command	Description
<b>show port operational-status</b>	Displays the operational status of a specific port or port range.

# show port digital log

To display the data event log for digital modems, use the **show port digital log** command in EXEC mode.

**show port digital log** [*reverse slot/port*] [*slot | slot/port*]

Syntax Description	Parameter	Description
	<b>reverse</b>	(Optional) Displays a report with the most recent entry first.
	<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/port</i>	(Optional) All ports on the specified slot and service processing element (SPE). For the Cisco AS5400, slot values range from 1 to 7 and port values range from 0 to one less than the number of ports supported by the card. You must include the slash mark.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5400.
	12.1(5)XM1	This command was implemented on the Cisco AS5350 universal gateway.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

## Usage Guidelines



### Note

This command is not supported on the Cisco AS5800 with the Universal Port DFC.

## Examples

The following is sample output from the **show port digital log** command on the Cisco AS5400 with the NextPort DFC:

```
Router# show port digital log

Port 5/00 Events Log
 00:02:41: incoming called number: 35140
      Service type: DIGITAL_DATA
      Session State: IDLE
      Service type: DIGITAL_DATA
      Session State: ACTIVE
 00:02:41: Digital State event:
      State: Steady
 00:02:40: Digital Static event:
      Connect Protocol           : V.110
      Data Bits                   : 8
      Parity                       : 0
```

```

    Stop Bits                : 1
    TX,RX Bit Rate           : 19200, 19200
Port 5/01 Events Log
00:02:42: incoming called number: 35140
    Service type: DIGITAL_DATA
    Session State: IDLE
    Service type: DIGITAL_DATA
    Session State: ACTIVE
00:02:41: Digital State event:
    State: Steady
00:02:41: Digital Static event:
    Connect Protocol         : V.110
    Data Bits                : 8
    Parity                   : 0
    Stop Bits                : 1
    TX,RX Bit Rate           : 19200, 19200
Port 5/02 Events Log
00:02:42: incoming called number: 35140
    Service type: DIGITAL_DATA
    Session State: IDLE
    Service type: DIGITAL_DATA
    Session State: ACTIVE
00:02:42: Digital State event:
    State: Steady
00:02:42: Digital Static event:
    Connect Protocol         : V.110
    Data Bits                : 8
    Parity                   : 0
    Stop Bits                : 1
    TX,RX Bit Rate           : 19200, 19200
Port 5/03 Events Log
00:02:43: incoming called number: 35140
    Service type: DIGITAL_DATA
    Session State: IDLE
    Service type: DIGITAL_DATA
    Session State: ACTIVE
00:02:43: Digital State event:
    State: Steady
00:02:43: Digital Static event:
    Connect Protocol         : V.110
    Data Bits                : 8
    Parity                   : 0
.
.
.

```

Table 4 describes the significant fields shown in the display.

**Table 4** *show port digital log Field Descriptions*

Field	Description
Port	The port and slot with the events log of current session.
incoming called number	The incoming called number.
Service type	The type of digital service, data or voice.
Session State	The condition of the current state, active or idle.

Table 4 *show port digital log Field Descriptions (continued)*

Field	Description
Digital State event:	The digital state. Values are as follows: 0—IDLE state 10—CONNECTING state 30—Steady 50—TERMINATING state
Connect Protocol	The data carrier connect standard used to support the rates of bits per second (bps).
Data Bits	The number of data bits, 7, 8, or 9. Default is 8.
Parity	The parity selection of 0 = no parity, 1 = odd parity. Default is no parity.
Stop Bits	The selection of stop bits, 1 or 2. Default is 1.
TX, RX Bit Rate	The transmit and receive bit rate. For RX, the bit rate is from the remote service provider to the local service provider. For TX, the bit rate is from the local service provider to the remote service provider.
Events Log	Displays the log of events for that port.

**Related Commands**

Command	Description
<b>clear port digital log</b>	Clears specific service events.
<b>clear port log</b>	Clears all event entries in the port level history event log.
<b>show port digital log</b>	Displays port events with the most recent event first.

# show port log

To display the service events generated by the sessions, use the **show port log** command in privileged EXEC mode.

```
show port {fax | voice} log [reverse] [slot/port] [slot | slot/port]
```

Syntax Description	
<b>fax</b>	Displays the fax data event log.
<b>voice</b>	Displays the voice data event log.
<b>reverse</b>	(Optional) Displays the port history event log with the most recent event first.
<i>slot/port</i>	(Optional) Displays information for all ports on the specified slot and service processing element (SPE). Slot values range from 1 to 7 and port values range from 0 to 107. You must include the slash mark.
<i>slot</i>	(Optional) Displays information for all ports on the specified slot. Slot values range from 1 to 7.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5400 and Cisco AS5800.
	12.1(5)XM2	This command was integrated into Cisco IOS Release 12.1(5)XM2.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350 and Cisco AS5400 platforms.
	12.3(4)T	Voice activity detection (VAD) background noise, echo return loss (ERL) level, and Acombined (ACOM) level were replaced with average values for each statistic in the output. A new field was added for the average echo canceller (ECAN or EC) background noise.
	12.3(14)T	T.38 fax relay call statistics were made available to Call Detail Records (CDRs) through Vendor-Specific Attributes (VSAs) and added to the call log.

## Examples

The following example shows value averages for VAD background noise, ERL level, ACOM level, and EC background noise level. Relevant fields in the output are shown in bold.

```
Router# show port voice log 1/0
```

```
Port 1/00 Events Log
*Aug 22 07:59:27.515:Voice Terminate event:
  Disconnect Reason           : normal call clearing (16)
  Call Timer                   : 57 secs
  Current playout delay       : 65 ms
  Min/Max playout delay       : 65/105 ms
  Clock offset                 : 142003 ms
  Predictive concealment      : 0 ms
```

```

Interpolative concealment      : 0 ms
Silence concealment           : 0 ms
Buffer overflow discards      : 1
End-point detection errors     : 0
Tx/Rx Voice packets          : 2813/2816
Tx/Rx signaling packets       : 0/0
Tx/Rx comfort noise packets   : 0/0
Tx/Rx duration                : 56260/56260 ms
Tx/Rx voice duration          : 0/0 ms
Out of sequence packets       : 0
Bad protocol headers          : 0
Num. of late packets          : 0
Num. of early packets         : 1
Tx/Rx Power                   : -87.0/-57.3 dBm
Tx/Rx Mean                     : -86.7/-57.0 dBm
Average VAD Background noise level : 6.2 dBm
Average ERL level                  : 127.0 dB
Average ACOM level                  : 127.0 dB
Tx/Rx current activity         : silence/silence
Tx/Rx byte count              : 450080/450240
Average ECAN Background noise level: -83.4 dBm
*Aug 22 07:59:27.515:Voice SSRC change events:
  Latest ssrc value            : 391643394
  Total ssrc changes           : 1

```

The following example shows output for the Cisco AS5400 with the universal port Dial Feature Card (DFC). The example shows the port voice history event log for slot 4, port 0.

```
Router# show port voice log 4/0
```

```

03:36:26: incoming caller number: 11001
03:36:26: incoming called number: 21001
03:36:26: Voice Connect event:
Voice Codec : G.711 a-law
Echo Canceler Length : 64 taps
Digit detection enable : DTMF signaling - enabled
Echo Cancellation Control : Echo cancellation - enabled
Echo update - enabled
Non-linear processor - enabled
Echo reset coefficients -
disabled
High pass filter enable -
disabled
Comfort noise generation : Generate comfort noise
Voice activity detection : Disabled
Information field size : 20 ms
Digit relay enable : OOB Digit relay -
disabled
IB Digit relay -
disabled
Encapsulation protocol : RTP
Playout de-jitter mode : adaptive
Input Gain : 0 dB
Output Gain : 0 dB
Tx/Rx SSRC : 0/0
03:36:27: Voice Terminate event:
Disconnect Reason : Non-specific host disconnect
Call Timer : 122 secs
Current playout delay : 30 ms
Min/Max playout delay : 25/45 ms
Clock offset : 528623613 ms
Predictive concealment : 0 ms
Interpolative concealment : 0 ms
Silence concealment : 0 ms

```

```

Buffer overflow discards : 0
End-point detection errors : 0
Tx/Rx Voice packets : 6130/6130
Tx/Rx signaling packets : 0/0
Tx/Rx comfort noise packets : 0/0
Tx/Rx duration : 122615/122615
Tx/Rx voice duration : 90000/82000
:
Out of sequence packets : 0
Bad protocol headers : 0
Num. of late packets : 0
Num. of early packets : 0
Tx/Rx Power : 932/101 dBm
Tx/Rx Mean : 364/325 dBm
:
Background noise level : -1 dBm
ERL level : 623 dB
ACOM level : 586 dB
Tx/Rx current activity : silence/silence

```

Table 5 describes the significant fields shown in the display.

**Table 5** *show port log Field Descriptions*

Field	Description
incoming caller number	The incoming caller number.
incoming called number	The incoming called number.
Voice Codec	Codec used for the current call.
Echo Canceler Length	Length of echo canceler in number of taps. Ranges from 1 to 1024 (128 milliseconds [ms]).
Digit detection enable	Bit mask where 1 = enabled, 0 = disabled, Bit 0 = dual tone multifrequency (DTMF) signaling detection.
Echo Cancellation Control	Bit mask where 1 = enabled, 0 = disabled. Bit 0: Echo cancellation enable. Bit 1: Echo update enable. Bit 2: Nonlinear processor enable. Bit 3: Echo reset coefficients (single shot). Bit 4: High pass filter disable. Bits 5—15: reserved (set to 0).
Echo update	Bit 1: Echo update enable.
Non-linear processor	Bit 2: Nonlinear processor enable.
Echo reset coefficients	Bit 3: Echo reset coefficients (single shot).
High pass filter enable	Bit mask where 1 = enabled, 0 = disabled Bit 0 = Echo cancellation enable. Bit 1: Echo update enable Bit 2: Nonlinear processor enable Bit 3: Echo reset coefficients (single shot) Bit 4: High pass filter disable Bits 5—15: reserved (set to 0)

Table 5 *show port log Field Descriptions (continued)*

Field	Description
Comfort noise generation	0 = generate silence - G.711 only, 1 = generate comfort noise.
Voice activity detection	0 = disabled, 1 = enabled.
Information field size	Maximum size (in ms) of information field in fax relay packets. The range is 0 to 90 ms.
Digit relay enable	Bit mask where 1 = enabled, 0 = disabled, Bit 0 = Digit Passthrough suppression.
IB Digit relay	Bit 1 = IB Digit Relay.
Encapsulation protocol	1 = RTP (VoIP), 2 = FRF.11 (VoFR), 3 = VoATM.
Playout de-jitter mode	0 = fixed, 1 = adaptive.
Input Gain	-6.0 to 6.0 in 0.1 decibel (dB) increments.
Output Gain	0 to -14.0 in 0.1 dB increments.
Disconnect Reason	Disconnect reason.
Call Timer	In seconds.
Current playout delay	Current playout delay estimate (in ms).
Min/Max playout delay	Minimum and Maximum playout delay encountered (in ms).
Clock offset	Clock offset value (in ms).
Predictive concealment	Cumulative duration (in ms).
Interpolative concealment	Cumulative duration (in ms).
Silence concealment	Cumulative duration (in ms).
Buffer overflow discards	Cumulative number buffer overflow errors.
End-point detection errors	Cumulative number of endpoint detection errors.
Tx/Rx SSRC	Value of Tx/Rx SSRC in the Routing Table Protocol (RTP) header.
Tx/Rx Voice packets	Cumulative count of voice packets sent and received.
Tx/Rx signaling packets	Cumulative count of signaling packets sent and received.
Tx/Rx comfort noise packets	Cumulative count of comfort noise packets sent and received.
Tx/Rx duration	Total duration of voice transmission and reception (in ms).
Tx/Rx voice duration	Total duration of voice transmission and reception (in ms).
Out of sequence packets	Cumulative count of packets received out of sequence.
Bad protocol headers	Cumulative count of packets received with bad protocol headers.
Num. of late packets	Cumulative count of packets received late.
Num. of early packets	Cumulative count of packets received early.
Tx/Rx Power	Current power of sent and received signal (to time-division multiplexing [TDM]) in 0.1 dBm increments.
Tx/Rx Mean	Average power of sent and received signal (to TDM) in 0.1 dBm increments.



Table 5 *show port log Field Descriptions (continued)*

Field	Description
Background noise level	Current background noise level estimate in 0.1 decibel (dB) increments.
ERL level	Current Echo Return Loss (ERL) level estimate in 0.1 dB increments.
ACOM level	Current ACOM level estimate in 0.1 dB increments. The term ACOM is used in G.165, <i>General Characteristics of International Telephone Connections and International Telephone Circuits: Echo Cancellers</i> . ACOM is the combined loss achieved by the echo canceller, which is the sum of the ERL, ERL enhancement, and nonlinear processing loss for the call.
Tx/Rx current activity	0 = silence, 1 = voice.

The following example shows output for the Cisco AS5400 with the universal port DFC. The example shows the port fax history event log for slot 1, port 0.

```
Router# show port fax log 1/0

Port 1/00 Events Log
Port 1/01 Events Log
Port 1/02 Events Log
  *Jan  1 18:39:30.499 UTC: Fax-relay Connect event:
    Max. transmission rate      : 4800 bps
    Information field size      : 20 ms
    TCF generation              : transparent
    Transmit level              : -10 dBm
    Encapsulation protocol      : UDPTL
    IFP Payload Type            :
    ECM Disable                  : Disabled
```

The following example shows output for the Cisco AS5350 on shelf 1, slot 3 with the T.38 Fax Relay statistics:

```
Router# show port fax log 1/3

Port 1/03 Events Log
  May  7 21:32:22.556 UTC: Fax-relay Connect event:
    Max. transmission rate      : 14400 bps
    Information field size      : 20 ms
    TCF generation              : transparent
    Transmit level              : -10 dBm
    Encapsulation protocol      : UDPTL
    ECM Disable                  : Not disabled
    1 bytes of link info not formatted : 0x01 0x00
Fax-relay Terminate event:
  Disconnect Reason            : 0
  Call Timer                    : 55 secs
  Current playout delay        : 80 ms
  Min/Max playout delay        : 1/560 ms
  Buffer underflow discard      : 0
  Buffer overflow discard       : 0
  End-point detection errors    : 0
  Tx/Rx Fax packets            : 1580/90
  Tx/Rx duration                : 32856/6193 ms
  Tx/Rx pages                   : 1/0
  Out of sequence packets      : 0
  Bad protocol headers         : 0
  Fax state                     : Idle
!
```

```

Current signal level      : 42 dBm
Phase jitter             : 0 degrees
Frequency offset        : 0 Hz
EQM                     : 0
Packet loss concealment count : 0
TX/RX Byte Count        : 0/76
Recent HS Modulation    : V.17/short/14400
ECM in use              : 1

```

The following example shows output for the Cisco AS5350 on shelf 1, slot 3 with the T.38 fax relay statistics:

```
Router# show port fax log 1/3
```

```
Port 1/03 Events Log
```

```
May 7 21:32:22.556 UTC: Fax-relay Connect event:
```

```

Max. transmission rate   : 14400 bps
Information field size   : 20 ms
TCF generation          : transparent
Transmit level           : -10 dBm
Encapsulation protocol  : UDPTL
ECM Disable             : Not disabled
1 bytes of link info not formatted : 0x01 0x00

```

```
Fax-relay Terminate event:
```

```

Disconnect Reason       : 0
Call Timer              : 55 secs
Current playout delay   : 80 ms
Min/Max playout delay   : 1/560 ms
Buffer underflow discard : 0
Buffer overflow discard  : 0
End-point detection errors : 0
Tx/Rx Fax packets      : 1580/90
Tx/Rx duration          : 32856/6193 ms
Tx/Rx pages             : 1/0
Out of sequence packets : 0
Bad protocol headers    : 0
Fax state               : Idle

```

```
!
```

```

Current signal level      : 42 dBm
Phase jitter             : 0 degrees
Frequency offset        : 0 Hz
EQM                     : 0
Packet loss concealment count : 0
TX/RX Byte Count        : 0/76
Recent HS Modulation    : V.17/short/14400
ECM in use              : 1

```

Table 6 lists the significant fields displayed in the output of **show port fax log** command:

**Table 6** *show port fax log Field Descriptions*

Field	Description
Max. transmission rate	0: No Limit. 1: 2400 bits per second (bps). 2: 4800 bps. 3: 7200 bps. 4: 9600 bps. 5: 12000 bps. 6: 14400 bps.
Information field size	Maximum size of information field in fax relay packets. The range is 0 to 90 ms.
TCF generation	0: transparent (remote). 1: controlled (local).
Transmit level	Transmit level of remodulator (in decibels per milliwatt [dBm]): -10 to -21.
Encapsulation protocol	1: UDPTL (T.38—VoIP) (default). 2: FRF.11 (VoFR). 3: RTP (IFP in RTP).
IFP Payload Type	0 to 127. Negotiated payload type for fax relay over RTP. (Valid only when encapsulation protocol is RTP.)
ECM Disable	0 - Error Correction Mode (ECM) is not disabled. 1 - ECM is disabled.
Disconnect Reason	Disconnect Reason.
Call Timer	Call timer in seconds.
Current playout delay	Current playout delay estimate in milliseconds (ms).
Min/Max playout delay	Minimum and maximum playout delay encountered in ms.
Buffer underflow discard	Cumulative number of buffer underflow errors.
Buffer overflow discard	Cumulative number of buffer overflow errors.
End-point detection errors	Cumulative number of endpoint detection errors.
Tx/Rx Fax packets	Cumulative count of fax packets sent and received.
Tx/Rx duration	Total duration of fax transmission and reception in ms.
Tx/Rx pages	Total pages of fax transmitted and received.
Out of sequence packets	Cumulative count of packets received out of sequence.
Bad protocol headers	Cumulative count of packets received with bad protocol headers.
Fax state	Idle.
Current signal level	Current sent and received signal level estimate in dBm.

**Table 6** *show port fax log Field Descriptions (continued)*

<b>Field</b>	<b>Description</b>
Phase jitter	Measured amount of phase jitter which indicates how large the “rocking” is in degrees. On an oscilloscope, the constellation points would look like crescent moons. Values can range up to 15 degrees. The typical value is 0 (that is, phase jitter is not normally present).
Frequency offset	The difference (in hertz) between the expected RX carrier frequency and the actual RX carrier frequency.
EQM	Eye Quality Monitor (EQM) provides an assessment of line quality during transmission of both high speed (V.29, V.17, etc) and low speed (V.21) data.
Packet loss concealment count	Packet loss concealment count.
Tx/Rx Byte Count	Number of bytes sent and received.
Recent HS Modulation	Recent high-speed modulation used.
ECM in use	0 - Error Correction Mode (ECM) is not in use. 1 - ECM is in use.

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>clear port log</b>	Clears all port log events.
<b>show port operational-status</b>	Displays active session statistics.

# show port modem calltracker

To display the port-level information for an active modem, use the **show port modem calltracker** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show port modem calltracker [slot | slot/port]
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show port modem calltracker [shelfslot | shelfslot/port]
```

Syntax	Description
<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
<i>slot/port</i>	(Optional) All ports on the specified slot and service processing element (SPE). For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. Port values range from 0 to one less than the number of ports supported by the card. You must include the slash mark.
<i>shelfslot</i>	(Optional) All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and Universal Port Card (UPC) slot values range from 2 to 11. You must include the slash mark.
<i>shelfslot/port</i>	(Optional) The specified port range on a shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 1 to 323. You must type in the forward slashes (/).

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5400 and Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350 universal gateway.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** When there is no call on the specified port, the most recent call information is displayed. This command uses the Call Tracker database. To enable Call Tracker, enter the **calltracker enable** global configuration command.

## Examples

The following is sample output from the **show port modem calltracker** command on the Cisco AS5400 with the NextPort DFC. This example shows output for slot 3, port 3:

```
Router# show port modem calltracker 3/3

----- call handle=          62 -----
status=Active, service=PPP, origin=Answer, category=Modem
DS0 slot/port/ds1/chan=4/7/7/0, called=124, calling=(n/a)
userid=as5300-ref2, ip=192.169.124.1, mask=255.255.255.0
setup=06/22/2000 21:50:47, conn=6.77, phys=25.00, service=29.83, authen=29.83
init rx/tx b-rate=33600/33600, rx/tx chars=0/0
resource slot/port=3/3, mp bundle=0, charged units=0, account id=0
idb handle=0x645B97CC, tty handle=0x622207BC, tcb handle=0x0
-----

protocol: last=LAP-M, attempted=LAP-M
compression: last=V.42bis-Both, supported= V.42bis-RX V.42bis-TX
standard: last=V.34+, attempted=V.21, initial=V.21

snr=40 dB, sq=5, rx/tx level=-15/0 dBm
phase jitter: freq=1 Hz, level=2 degrees
far end echo level=-90 dBm, freq offset=0 Hz
phase roll=0 degrees, round-trip delay=0 msecs
digital pad=None dB, digital pad comp=0
rbs pattern=0, constellation=0 point
rx/tx: symbol rate=3429/3429, carrier freq=1959/1959
rx/tx: trellis code=0/0, preemphasis index=0/0
rx/tx: constellation shape=Off/Off, nonlinear encode=Off/Off
rx/tx: precode=Off/Off, xmit level reduct=0/0 dBm

rx/tx: chars=0/0, general info=0x0
rx/tx: link layer chars=0/0, NAKs=0/0
error corrected: rx/tx=0/0, rx bad=0
ec retransmissions=0, retransmitted frames=0
rx/tx ppp slip=0/0, bad ppp slip=0

rx/tx b-rate: last=33600/33600, lowest=0/0, highest=0/0
phase 2 projected max rx b-rate: client=0, host=33600
phase 4 desired rx/tx b-rate: client=16384/25987, host=25987/42765
retrains: local=0, remote=0, failed=0
speedshift: local up/down=0/0, remote up/down=0/0, failed=0

v110: rx good=0, rx bad=0, tx=0, sync lost=0
SS7/COT status=0x00
v90: status=(Invalid #141), client=(n/a), failure=None

rx/tx: max neg I frame=128/128, neg window=0/128
v42bis size: dictionary=0, string=16
T401 timeouts=0, tx window closures=0, rx overruns=0
test err=0, reset=0, v0 synch loss=0
mail lost: host=0, sp=0

duration(sec)=0, disc reason=0x0
disc text=(n/a)

-----5-----10-----15-----20-----25-----30
line shape   : 0x00000000000000000000000000000000000000000000000000000000000000
v8bis capab  : 0x12C9808081C609B502009481834347CB000000000000000000000000
v8bis mod sl : 0x00000000000000000000000000000000000000000000000000000000000000
v8 jnt menu  : 0xC16513942A8D000000000000000000000000000000000000000000
v8 call menu : 0x00C16513942A000000000000000000000000000000000000000000
v90 training: 0x00000000
v90 sgn ptrn: 0x00000000
```



# show port modem log

To display the events generated by the modem sessions, use the **show port modem log** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show port modem log [reverse] [slot | slot/port] [slot | slot/port]
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show port modem log [reverse] [shelfslot | shelfslot/port] [shelfslot | shelfslot/port]
```

Syntax	Description
<b>reverse</b>	(Optional) Displays the modem port history event log with the most recent event first.
<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. A range of slots can be specified by entering a second value for the <i>slot</i> argument
<i>slot/port</i>	(Optional) All ports on the specified slot and service processing element (SPE). For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. Port values range from 0 to one less than the number of ports supported by the card. You must include the slash mark. A range of ports can be specified by entering a second value for the <i>slot/port</i> argument.
<i>shelfslot</i>	(Optional) All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and Universal Port Card (UPC) slot values range from 2 to 11. You must include the slash mark. A range shelves and slots can be specified by entering a second value for the <i>shelfslot</i> argument.
<i>shelfslot/port</i>	(Optional) All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and port values range from 0 to one less than the number of ports supported by the card. You must type in the forward slashes ( <i>/</i> ). A range of ports can be specified by entering a second value for the <i>shelfslot/port</i> argument.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5400 and Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(2)XA	Link and states information was added.
	12.2(2)XB1	This command was integrated into Cisco IOS Release 12.2(2)XB1.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.



**Usage Guidelines**

The port modem test log displays the results of the SPE diagnostics tests.

**Examples**

The following is sample output for the Cisco AS5400 with the NextPort DFC. This example shows the port history event log for slot 5, port 47:

```
Router# show port modem log 5/47
```

```
Port 5/47 Events Log
  Service type: DATA_FAX_MODEM
  Service mode: DATA_FAX_MODEM
  Session State: IDLE
00:02:23: incoming called number: 35160
  Service type: DATA_FAX_MODEM
  Service mode: DATA_FAX_MODEM
  Session State: IDLE
  Service type: DATA_FAX_MODEM
  Service mode: DATA_FAX_MODEM
  Session State: ACTIVE
00:02:23: Modem State event:
  State: Connect
00:02:16: Modem State event:
  State: Link
00:02:13: Modem State event:
  State: Train Up
00:02:05: Modem State event:
  State: EC Negotiating
00:02:05: Modem State event:
  State: Steady
00:02:05: Modem Static event:
  Connect Protocol           : LAP-M
  Compression                : V.42bis
  Connected Standard         : V.34+
  TX,RX Symbol Rate         : 3429, 3429
  TX,RX Carrier Frequency   : 1959, 1959
  TX,RX Trellis Coding       : 16/16
  Frequency Offset           : 0 Hz
  Round Trip Delay           : 0 msec
  TX,RX Bit Rate             : 33600, 33600
  Robbed Bit Signalling (RBS) pattern : 0
  Digital Pad                 : None
  Digital Pad Compensation   : None
  4 bytes of link info not formatted : 0x00 0x00 0x00 0x00 0x00
00:02:06:Modem Dynamic event:
  Sq Value                   : 5
  Signal Noise Ratio         : 40 dB
  Receive Level              : -12 dBm
  Phase Jitter Frequency     : 0 Hz
  Phase Jitter Level         : 2 degrees
  Far End Echo Level         : -90 dBm
  Phase Roll                  : 0 degrees
  Total Retrans              : 0
  EC Retransmission Count    : 0
  Characters transmitted, received : 0, 0
  Characters received BAD    : 0
  PPP/SLIP packets transmitted, received : 0, 0
  PPP/SLIP packets received (BAD/ABORTED) : 0
  EC packets transmitted, received OK : 0, 0
  EC packets (Received BAD/ABORTED) : 0
```

The following example shows the port history event log with the most recent event first on slot 5, port 40:

```
Router# show port modem log reverse 5/40
```

```
Modem port 5/40 Events Log
00:02:18:Modem Dynamic event:
  Sq Value                               :    5
  Signal Noise Ratio                       :   38 dB
  Receive Level                             :  -12 dBm
  Phase Jitter Frequency                   :    0 Hz
  Phase Jitter Level                       :    0 degrees
  Far End Echo Level                       :    0 dBm
  Phase Roll                               :    0 degrees
  Total Retrans                            :    0
  EC Retransmission Count                   :    0
  Characters transmitted, received         :  0, 0
  Characters received BAD                   :    0
  PPP/SLIP packets transmitted, received  :  0, 0
  PPP/SLIP packets received (BAD/ABORTED) :    0
  EC packets transmitted, received OK     :  0, 0
  EC packets (Received BAD/ABORTED)      :    0
00:02:18: Modem Static event:
  Connect Protocol                         :   LAP-M
  Compression                              :   V.42bis
  Connected Standard                       :   V.90
  TX,RX Symbol Rate                        :  8000, 3200
  TX,RX Carrier Frequency                  :  1829, 1829
  TX,RX Trellis Coding                     :   16/16
  Frequency Offset                         :    0 Hz
  Round Trip Delay                         :    4 msecs
  TX,RX Bit Rate                           :  52000, 28800
  Robbed Bit Signalling (RBS) pattern      :   255
  Digital Pad                              :   None
  Digital Pad Compensation                 :   Enabled
  4 bytes of link info not formatted       :  0x00 0x00 0x00 0x00 0x00
00:02:23: Modem State event:
  State: Steady
00:02:23: Modem State event:
  State: EC Negotiating
00:02:36: Modem State event:
  State: Train Up
00:02:39: Modem State event:
  State: Link
00:02:46: Modem State event:
  State: Connect
00:02:46: Port State Reached:
  Service type: DATA_FAX_MODEM
  Service mode: DATA_FAX_MODEM
  Session State: ACTIVE
00:02:46: Port State Reached:
  Service type: DATA_FAX_MODEM
  Service mode: DATA_FAX_MODEM
  Session State: IDLE
00:02:47: incoming called number: 6000
00:02:47: incoming caller number: 90002
```

The following is sample output for the Cisco AS5800 with the UPC. This example shows the port history event log for slot 8, ports 0 to 6:

```
Router# show port modem log 1/8/0 1/8/6
```

```
Port 1/08/00 Events Log
09:09:53: Service Type: DATA_FAX_MODEM
09:09:53: Service Mode: DATA_FAX_MODEM
```

```

09:09:53: Session State: FLUSHING
09:09:53: Service Type: DATA_FAX_MODEM
09:09:53: Service Mode: DATA_FAX_MODEM
09:09:53: Session State: IDLE
09:09:53: Modem State event:
      State: Terminate
09:09:53: Modem End Connect event:
      Call Timer : 26 secs
      Disconnect Reason Info : 0x1F00
          Type (=0 ): <unknown>
          Class (=31 ): Requested by host
          Reason (=0 ): non-specific host disconnect
      Total Retrans : 0
      EC Retransmission Count : 0
      Characters transmitted, received : 2633, 485
      Characters received BAD : 0
      PPP/SLIP packets transmitted, received : 0, 0
      PPP/SLIP packets received (BAD/ABORTED) : 0
      EC packets transmitted, received OK : 27, 21
      EC packets (Received BAD/ABORTED) : 0
09:09:54: Modem Link Rate event:
09:09:55: Service Type: DATA_FAX_MODEM
09:09:55: Service Mode: DATA_FAX_MODEM
09:09:55: Session State: IDLE
09:09:55: Service Type: DATA_FAX_MODEM
09:09:55: Service Mode: DATA_FAX_MODEM
09:09:55: Session State: ACTIVE
09:09:55: Modem State event:
      State: Connect
09:09:55: Modem State event:
      State: Link
09:09:55: Modem State event:
      State: Train Up
09:09:55: Modem State event:
      State: EC Negotiating
09:09:55: Modem State event:
      State: Steady
09:09:55: Modem Static event:
      Connect Protocol : LAP-M
      Compression : V.42bis
      Connected Standard : V.34+
      TX,RX Symbol Rate : 3429, 3429
      TX,RX Carrier Frequency : 1959, 1959
      TX,RX Trellis Coding : 16/16
      Frequency Offset : 0 Hz
      Round Trip Delay : 1 msecs
      TX,RX Bit Rate : 31200, 28800
      Robbed Bit Signalling (RBS) pattern : 0
      Digital Pad : None
      Digital Pad Compensation : None
      4 bytes of link info not formatted : 0x00 0x00 0x00 0x00 0x00
09:09:56: Modem Dynamic event:
      Sq Value : 5
      Signal Noise Ratio : 38 dB
      Receive Level : -15 dBm
      Phase Jitter Frequency : 13 Hz
      Phase Jitter Level : 0 degrees
      Far End Echo Level : -90 dBm
      Phase Roll : 0 degrees
      Total Retrans : 0
      EC Retransmission Count : 0
      Characters transmitted, received : 0, 0
      Characters received BAD : 0
      PPP/SLIP packets transmitted, received : 0, 0

```

## ■ show port modem log

```

    PPP/SLIP packets received (BAD/ABORTED) :    0
    EC packets transmitted, received OK      :    0, 0
    EC packets (Received BAD/ABORTED)       :    0
09:09:58: Service Type: DATA_FAX_MODEM
09:09:58: Service Mode: DATA_FAX_MODEM
09:09:58: Session State: FLUSHING
09:09:58: Service Type: DATA_FAX_MODEM
09:09:58: Service Mode: DATA_FAX_MODEM
09:09:58: Session State: IDLE
09:09:58: Modem State event:
           State: Terminate
.
.
.

```

Table 7 describes the significant fields shown in the displays.

**Table 7** *show port modem log Field Descriptions*

Field	Description
Port 5/47 Events Log	Port number and slot is displayed.
Service type:	Data fax modem is displayed.
Service mode:	Data fax modem mode.
Session State:	Idle or busy state.
Incoming called number:	The number of the incoming call.
Modem <slot/port> Events Log:	The modem for which log events are currently displayed.
Modem State Event	<p>Current state of the modem, which can be any of the following:</p> <ul style="list-style-type: none"> <li>• Connect—Modem is connected to a remote host.</li> <li>• Open—Open modem event.</li> <li>• Link—Link protocol event occurred.</li> <li>• Training—Modem retraining event.</li> <li>• EC correction—Error correction frames sent or received.</li> <li>• Steady—Steady modem event.</li> <li>• Bad—Inoperable state, which is configured by the <b>modem bad</b> command.</li> <li>• Bad*—Inoperable state, which is configured by the <b>modem startup-test</b> command during initial power-up testing.</li> <li>• Reset—Modem is in reset mode.</li> <li>• D/L—Modem is downloading firmware.</li> <li>• Bad FW—Downloaded modem firmware is not operational.</li> <li>• Busy—Modem is out of service and not available for calls</li> <li>• Idle—Modem is ready for incoming and outgoing calls.</li> </ul>

Table 7 *show port modem log Field Descriptions (continued)*

Field	Description
Modem Static event:	<p>Current static event of the MICA modem, which can be any of the following:</p> <ul style="list-style-type: none"> <li>• Connect Protocol—Connection protocol used for the current session, which can be SYNC mode, ASYNC mode, ARA1.0, ARA2.0, LAP-M, or MNP.</li> <li>• Compression—Type of compression used for the current session, which can be None, V.42bis TX, V.42bis RX, V.42bis both, or MNP5 data compression.</li> <li>• Connected Standard—Standards protocol used to connect, which can be V.21, Bell103, V.22, V.22bis, Bell212, V.23, V.32, V.32bis, V.32terbo, V.34, V.34+, or K56Flex 1.1.</li> <li>• TX, RX Symbol Rate—Symbol rate used to send samples to the line or receive samples off of the line.</li> <li>• TX, RX Carrier Frequency—Carrier frequency used by the remote service provider.</li> <li>• TX, RX Trellis Coding—Trellis coding received and sent.</li> <li>• Frequency Offset—+/-32 in 1/8 hertz (Hz) steps.</li> <li>• Round Trip Delay—Total round trip propagation delay of the link, which is expressed in milliseconds (ms).</li> <li>• TX, RX Bit Rate—For RX, the bit rate from the remote service provider to the local service provider. For TX, the bit rate from the local service provider to the remote service provider.</li> </ul>

Table 7 *show port modem log Field Descriptions (continued)*

Field	Description
Modem Dynamic event:	<p>Current dynamic event of the MICA modem, which can be any of the following:</p> <ul style="list-style-type: none"> <li>• Sq Value—Signal quality value, which can be from 0 to 7 (0 is the worst possible quality).</li> <li>• Signal Noise Ratio—Expressed in decibels, which can be from 0 to 70 dB steps.</li> <li>• Receive Level—Expressed in decibels, which can be from 0 to 128 dBm steps.</li> <li>• Phase Jitter Frequency—+/-32 in 1/8 Hz steps.</li> <li>• Phase Jitter Level—0 to 90 degrees.</li> <li>• Far End Echo Level—0 to -90 in dBm of far end echo level (that portion of the sent analog signal that has bounced off the analog front end of the remote modem).</li> <li>• Phase Roll—+/-32 in 1/8 Hz steps.</li> <li>• Total Retrans—Count of total retrains.</li> <li>• ECR retransmission Count—Count of total error correction retransmissions that occurred during the duration of the link.</li> <li>• Characters Transmitted, Received—Count of total characters sent and received.</li> <li>• Characters received BAD—A subset of the characters sent and received. Represents the total number of parity error characters.</li> <li>• PPP/SLIP packets transmitted, received—Total count of PPP/SLIP packets sent and received. This total could include all PPP/SLIP packets, including BAD/ABORTED packets.</li> <li>• PPP/SLIP packets received, (BAD/ ABORTED)—Total count of the bad or aborted PPP/Serial Line Internet Protocol (SLIP) packets, which is a subset of the above (PPP/SLIP packets received, transmitted).</li> <li>• EC packets transmitted, received—Count of total error correction frames sent and received. This total could include all error correction packets, including BAD/ABORTED packets.</li> <li>• EC packets (Received BAD/ ABORTED)—Total count of the bad or aborted error correction packets, which is a subset of the EC packets sent and received.</li> </ul>

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>clear port log</b>	Clears all event entries in the port level history event log.
<b>port modem autotest</b>	Automatically and periodically performs a modem diagnostics test for modems inside the access server or router.
<b>port modem startup-test</b>	Performs diagnostic testing for all modems.
<b>show port modem log</b>	Displays the events generated by the modem sessions.
<b>show spe modem active</b>	Displays active modem statistics of all SPEs, a specified SPE, or the specified SPE range.
<b>test port modem back-to-back</b>	Tests two specified ports back-to-back and transfers a specified amount of data between the ports.

# show port modem test

To display the modem test log, use the **show port modem test** command in EXEC mode.

## Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show port modem test [slot | slot/port]
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show port modem test [shelfslot | shelfslot/port]
```

Syntax Description	slot	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	slot/port	(Optional) All ports on the specified slot and service processing element (SPE). For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. Port values range from 0 to one less than the number of ports supported by the card. You must include the slash mark.
	shelfslot	(Optional) All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and Universal Port Card (UPC) slot values range from 2 to 11. You must include the slash mark.
	shelfslot/port	(Optional) The specified port range on a shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5400 and Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** The port modem test log displays the results of the SPE diagnostics tests.

**Examples** The following is sample output for the Cisco AS5400 with the NextPort DFC. This example displays the results of the SPE startup test, SPE autotest, and SPE back-to-back test.



**Note**

The Reason column indicates why the test was started. The TIME INTERVAL is one of the triggers under autotest, the other being the error threshold.



```
Router# show port modem test
```

```

Date Time                Modem Test                Reason                    State Result
3/02 12:00:57 PM         2/01 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:00:57 PM         2/00 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:00:58 PM         2/02 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:00:58 PM         2/03 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:00:58 PM         2/04 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:00:58 PM         2/05 Back-To-Back          :STARTUP TEST            Idle PASS
.
.
.
3/02 12:01:14 PM         3/95 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:01:14 PM         3/94 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:01:15 PM         3/75 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:01:15 PM         3/74 Back-To-Back          :STARTUP TEST            Idle PASS
3/02 12:13:52 PM         3/20 Back-To-Back          :USER INITIATED          Idle PASS
3/02 12:13:52 PM         2/10 Back-To-Back          :USER INITIATED          Idle PASS
.
.
.
3/02 12:44:00 PM         3/102 No Test (Time)         :MIN IDLE MODEMS        Idle NOTST
3/02 12:44:00 PM         3/103 No Test (Time)         :MIN IDLE MODEMS        Idle NOTST
3/02 12:44:00 PM         3/104 No Test (Time)         :MIN IDLE MODEMS        Idle NOTST
3/02 12:44:00 PM         3/105 No Test (Time)         :MIN IDLE MODEMS        Idle NOTST
3/02 12:44:00 PM         3/106 No Test (Time)         :MIN IDLE MODEMS        Idle NOTST
3/02 12:44:00 PM         3/107 No Test (Time)         :MIN IDLE MODEMS        Idle NOTST
3/02 12:44:21 PM         2/73 Back-To-Back          :TIME INTERVAL           Idle PASS
3/02 12:44:21 PM         2/72 Back-To-Back          :TIME INTERVAL           Idle PASS
3/02 12:44:21 PM         2/33 Back-To-Back          :TIME INTERVAL           Idle PASS
3/02 12:44:21 PM         2/32 Back-To-Back          :TIME INTERVAL           Idle PASS
3/02 12:44:21 PM         3/37 Back-To-Back          :TIME INTERVAL           Idle PASS

```

Table 8 describes the significant fields shown in the display.

**Table 8** *show port modem test Field Descriptions*

Field	Description
Date	Date the back-to-back test occurred for the specified modem.
Time	Time the test occurred.
Modem	Specified modem that performed a back-to-back test.
Test	Operation performed on the specified modem.
Reason	Reason the modem performed the back-to-back test.
State	Current operational state of the modem.
Result	Result of the back-to-back test for the specified modem.

#### Related Commands

Command	Description
<b>clear port log</b>	Clears all event entries in the port level history event log.
<b>port modem autotest</b>	Automatically and periodically performs a modem diagnostics test for modems inside the access server or router.
<b>port modem startup-test</b>	Performs diagnostic testing for all modems.
<b>show port modem log</b>	Displays the modem port history event log or modem test log.
<b>show port log reverse</b>	Displays the latest event first from the port history event log.

Command	Description
<b>show port modem log</b>	Displays the events generated by the modem sessions.
<b>test port modem back-to-back</b>	Tests two specified ports back-to-back and transfers a specified amount of data between the ports.

# show port operational-status

To display the active session statistics, use the **show port operational-status** command in privileged EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show port operational-status {slot | slot/port}
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show port operational-status {shelf/slot | shelf/slot/port}
```

Syntax	Description
<i>slot</i>	Displays information for all ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
<i>slot/port</i>	Displays information for all ports on the specified slot and service processing element (SPE). For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. Port values range from 0 to one less than the number of ports supported by the card. You must include the slash mark.
<i>shelf/slot</i>	Displays information for all ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and Universal Port Card (UPC) slot values range from 2 to 11. You must include the slash mark.
<i>shelf/slot/port</i>	Displays information for all ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and port values range from 0 to one less than the number of ports supported by the card. You must type in the forward slashes (/).

**Command Modes** Privileged EXEC

Command History	Release	Modification
	12.1(1)XD	This command was implemented on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(2)XA	Disconnect reasons and states information were added.
	12.2(2)XB1	This command was integrated into Cisco IOS Release 12.2(2)XB1.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.
	12.3(4)T	Configuration output was modified to show voice activity detection (VAD) background noise and echo canceller (EC or ECAN) background noise statistics.
	12.3(14)T	T.38 fax relay call statistics were made available to Call Detail Records (CDRs) through Vendor-Specific Attributes (VSAs) and added to the call log.

**Usage Guidelines**

This command displays the operational status of a specific port or port range. The port should have an associated active modem session when the command is executed. The **show port operational-status** command is equivalent to the **show modem operational-status** MICA technologies modem command.

**Examples**

The following is sample output from the **show port operational-status** command on the Cisco AS5400 with the NextPort DFC. This example displays operational status for slot 2, SPE 0, port 1:

```
Router# show port operational-status 2/1

slot/spe/Port -- 2/0/1
Service Type                :Modem service
Disconnect Reason Info     :0x0
Type (=0 ): <unknown>
Class (=0 ): Other
Reason (=0 ): no disconnect has yet occurred
Modulation Standard        :V.34+
TX/RX Bit Rate             :31200/14400
Connect Protocol           :LAP-M
Compression                :V.42bis
Call Timer                 :47 secs
Link Signal Quality        :7
SNR                        :37 dB
TX/RX Symbol Rate         :3429/3429
TX/RX Carrier Frequency   :1959/1959
TX/RX Trellis Coding       :16/16
TX/RX Preemphasis Index   :0/1
TX/RX Constellation Shaping :On-Active/On-Active
TX/RX Nonlinear Encoding   :On-Active/On-Active
TX/RX Precoding           :On-Active/On-Active
TX/RX Xmit Level Reduction :3/1 dBm
Receive Level              :-15 dBm
Frequency Offset          :0 Hz
Phase Jitter Frequency    :2 Hz
Phase Jitter Level        :2 degrees
Far End Echo Level        :-90 dBm
Phase Roll                 :0 degrees
Round Trip Delay          :0 msec
>Total Retrans            :0
Self Test Error count     :0
EC Retransmission count   :0
EC packets transmitted/received OK :11/12
EC packets (Received BAD/ABORTED) :0
Characters transmitted/received :76/13
Characters received BAD   :0
PPP/SLIP packets transmitted/received :0/0
PPP/SLIP packets received (BAD/ABORTED) :0
RBS Pattern               :0
Digital Pad               :0
Digital Pad Compensation  :0
```

The following example displays operational status for a V.110 digital service for the Cisco AS5400 on slot 2, SPE 3, port 23:

```
Router# show port operational-status 2/23

slot/spe/Port -- 2/3/23
Service Type                : Digital service
Connect Protocol           : V110
Data Bits                  : 8
Parity                     : 0
Stop Bits                  : 1
```

```

TX/RX Bit Rate           : 19200/19200
Call Timer               : 116 secs
EC packets transmitted/received OK : 0/0
EC packets (Received BAD/ABORTED) : 0
PPP/SLIP packets transmitted, received : 8/8
PPP/SLIP packets received (BAD/ABORTED) : 0
Sync Loss                : 0

```

The following example shows output from the **show port operational-status** command for the Cisco AS5800 on shelf 1, slot 8:

```

Router# show port operational-status 1/8

Shelf/Slot/SPE/Port -- 1/8/32/194
Service Type           : Modem service
Disconnect Reason Info : 0x0
  Type (=0 ) : <unknown>
  Class (=0 ) : Other
  Reason (=0 ) : no disconnect has yet occurred
Modulation Standard    : V.34+
TX/RX Bit Rate         : 31200/31200
Connect Protocol       : LAP-M
Compression            : V.42bis
Call Timer             : 18 secs
Link Signal Quality    : 6
SNR                   : 38 dB
TX/RX Symbol Rate     : 3429/3429
TX/RX Carrier Frequency : 1959/1959
TX/RX Trellis Coding   : 16/16
TX/RX Preemphasis Index : 0/1
TX/RX Constellation Shaping : Off-None/On-Active
TX/RX Nonlinear Encoding : Off-None/On-Active
TX/RX Precoding        : Off-None/On-Active
TX/RX Xmit Level Reduction : 6/5 dBm
Receive Level          : -15 dBm
Frequency Offset       : 0 Hz
Phase Jitter Frequency : 5 Hz
Phase Jitter Level     : 2 degrees
Far End Echo Level     : -90 dBm
Phase Roll             : 0 degrees
Round Trip Delay       : 1 msec
Total Retrans          : 0
Self Test Error count  : 0
EC Retransmission count : 1
EC packets transmitted/received OK : 34/14
EC packets (Received BAD/ABORTED) : 0
Characters transmitted/received : 9393/355
Characters received BAD : 0
PPP/SLIP packets transmitted/received : 0/0
PPP/SLIP packets received (BAD/ABORTED) : 0
RBS Pattern            : 0
Digital Pad            : 0
Digital Pad Compensation : 0
.
.
.

```

The following example shows VAD background noise and ECAN background noise statistics:

```

Router# show port operational-status 1/0

Slot/SPE/Port -- 1/0/0
Service Type           :Voice service
Voice Codec            :G.711 u-law

```

## show port operational-status

```

Echo Canceler Length           :8 ms
Echo Cancellation Control      :Echo cancellation           - enabled
                                Echo update                       - enabled
                                Non-linear processor             - enabled
                                Echo reset coefficients          - disabled
                                High pass filter enable         - disabled
Digit detection enable         :DTMF signaling             - enabled
Voice activity detection       :Disabled
Comfort noise generation      :Generate comfort noise
Digit relay enable             :OOB Digit relay           - disabled
                                IB Digit relay                 - disabled

Information field size         :20 ms
Playout de-jitter mode        :adaptive
Encapsulation protocol        :RTP
Input Gain                     :0.0 dB
Output Gain                    :0.0 dB
Tx/Rx SSRC                    :20/0
Current playout delay         :65 ms
Min/Max playout delay         :65/105 ms
Clock offset                   :142003 ms
Predictive concealment        :0 ms
Interpolative concealment     :0 ms
Silence concealment           :0 ms
Buffer overflow discards      :1
End-point detection errors    :0
Tx/Rx Voice packets           :1337/1341
Tx/Rx signaling packets      :0/0
Tx/Rx comfort noise packets   :0/0
Tx/Rx duration                :26745/26745 ms
Tx/Rx voice duration         :0/0 ms
Out of sequence packets      :0
Bad protocol headers          :0
Num. of late packets          :0
Num. of early packets         :1
Tx/Rx Power                   : -87.0/-57.3 dBm
Tx/Rx Mean                    : -86.3/-57.0 dBm
VAD Background noise level    :6.2 dBm
ERL level                     :127.0 dB
ACOM level                    :127.0 dB
Tx/Rx current activity        :silence/silence
Tx/Rx byte count              :213920/214240
ECAN Background noise level   : -83.4 dBm
Latest SSRC value             :391643394
Number of SSRC changes        :1
Number of payload violations   :0

```

Table 9 describes the significant fields shown in the displays.

**Table 9** *show port operational-status Field Descriptions*

Field	Description
slot/SPE/Port	Displays the slot and port designation for the SPE card location.
Service Type	Indicates the type of service.
Disconnect Reason Info	Displays the reason for disconnection.
Modulation Standard	Modulation standard can be V.21, Bell103, V.22, V.22bis, Bell 212, V.23, V.32, V.32bis, V.32terbo, V.34, V.34+, or K56Flex 1.1.
TX/RX Bit Rate	TX is the bit rate from the local DCE to the remote DCE. RX is the bit rate from the remote DCE to the local DCE. These rates may be asynchronous.

Table 9 *show port operational-status Field Descriptions (continued)*

Field	Description
Connect Protocol	Connect protocol for the current session, which can be SYNC mode, ARA1.0, ARA2.0, LAP-M, MNP, FAX mode, SS7/COT, or V.110.
Compression	Compression protocol used for the current connection, which can be None, V.42bis TX, V.42bis RX, V.42bis both, or MNP5 data compression.
Link Signal Quality	Measure of line quality for a given bit rate where 0 is the worst and 3 is steady state. If a 1 or 2 is present, the modem must shift down to a lower rate. Likewise, if the value is 4 to 7, the modem speeds shift up to a higher rate. If the value is high (for example, 7) and the bit rate is low, then there may be a problem at the remote end receiver.
SNR	The ratio measurement (in dB) of the desired signal to noise. This value can range from 0 to 70 dB and changes in 1 dB steps. Note that a 28.8-kbps connection demands an SNR of about 37 dB. Any values lower than this level result in a diminished quality of connection. A 33.6-kbps connection demands a signal-to-noise ratio (SNR) of 38 to 39 dB. Also note that a “clean” line has an SNR of about 41 dB.
TX/RX Symbol Rate	TX is symbol rate used to send samples to the line. RX is the symbol rate used to receive samples off of the line. The rates are synchronous with each other.
TX/RX Carrier Frequency	For TX, carrier frequency used by the local DCE. For RX, carrier frequency used by the remote DCE.
TX/RX Trellis Coding	Adds dependency between symbols in order to make the detection in noise more robust (Forward Error Correction). Modems may use 8 (V.32, V.32bis, V.17), 16, 32, 64 (V.34, V.34+, V.90, K56flex), or no trellis coding (V.22, V.22bis, V.21, Bell212, Bell103, V.29, V.27).
TX/RX Preemphasis Index	Involves shaping the raw transmit spectrum in order to deal with spectrum roll-offs. The preemphasis index can take on the values 0 to 10. A zero denotes no reshaping. Typical values usually fall in the ranges from 0 to 2 or 6 to 7. This technique is used with V.34 and V.34+ standards.
TX/RX Constellation Shaping	A method for improving noise immunity by using a probability distribution for sent signal points. The signal states used to predict the sensitivity to certain transmission impairments. Values may be either Off-none or On-active. This technique is used with V.34 and V.34+ standards.
TX/RX Nonlinear Encoding	Occurs during the training phase and moves the outer points of the constellation away in order to deal with nonlinear distortion. Nonlinear distortion (0 to 200 Hz) tends to affect the higher power signals. Moving the outer constellation points out reduces the chance of error. Values may be either Off-none or On-active. MICA modems support nonlinear coding in both directions. This technique is used with V.34 and V.34+ standards.

Table 9 show port operational-status Field Descriptions (continued)

Field	Description
TX/RX Precoding	Serves the same purpose as the preemphasis index but instead manages the bits and not the raw transmit signals. This is done only when requested and therefore will occur in the RX mode. The values may be either Off-none or On-active. This technique is used with V.34 and V.34+ standards.
TX/RX Xmit Level Reduction	Affects the transmit signal with 0 to 15 in dBm of reduction. If nonlinear distortion is detected, the modem prompts the client for a lower-powered TX signal. If the remote end detects nonlinear distortion, it may request that the sender lower the TX signal. This technique is used with V.34 and V.34+ standards.
Receive Level	The power of the received signal in dBm steps. It ranges from 0 to -128 dBm. Typically the range in the United States is about -22 dBm, and in Europe is -12 dBm. A good range is from -12 dBm to -24 dBm.
Frequency Offset	The difference (in hertz) between the expected RX carrier frequency and the actual RX carrier frequency.
Phase Jitter Frequency	Peak to peak differential (in hertz) between two signal points. Uncanceled phase jitter looks like “rocking” of the baseband quadrature amplitude modulation (QAM) constellation. The points look like arcs with the outer points having longer arcs.
Phase Jitter Level	Amount of phase jitter measured and indicates how large the “rocking” is in degrees. On an oscilloscope, the constellation points would look like crescent moons. Values can range up to 15 degrees. The typical value is zero (that is, phase jitter is not normally present).
Far End Echo Level	Over long connections, an echo is produced by impedance mismatches at 2-wire-to-4-wire and 4-wire-to-2-wire hybrid circuitry. The far-end echo level (that portion of the sent analog signal that has bounced off of the remote modem analog front end) may range from 0 to -90 in dBm.
Phase Roll	Phase roll affects the echo signal coming back. A certain constellation pattern is sent from a modem and arrives at the central office. Some echoed form of this signal/constellation pattern is sent back. However, the constellation shape may be rotated from 0 to 359 degrees. This rotation is called the phase roll.
Round Trip Delay	Total round trip propagation delay of the link (in milliseconds). This is important for proper echo cancellation. The amount that the delay varies on the network.
Total Retrans	Count of total retrans and speed shifts.
Self Test Error count	Total errors generated during a self-test run.
EC Retransmission count	The number of times the NextPort has gone into error recovery in the TX direction for a particular connection. The larger the number, the worse the connection. However, this parameter should be weighed against the count produced by EC packets sent and received in order to determine if there should really be a concern.



Table 9 *show port operational-status Field Descriptions (continued)*

Field	Description
EC packets transmitted/received OK	Error correction (EC) packets sent is the number of TX frames that the client modem accepted. EC packets received is the number of data RX frames accepted.
EC packets (Received BAD/ABORTED)	This is identical to the EC Retransmission count field.
PPP/SLIP packets transmitted/received	Total count of PPP/Serial Line Internet Protocol (SLIP) packets sent and received. This total could include all PPP/SLIP packets, including BAD/ABORTED packets.
PPP/SLIP packets received (BAD/ABORTED)	Total count of the bad or aborted PPP/SLIP packets, which is a subset of PPP/SLIP packets received. A counted PPP packet has a bad frame check sequence (FCS), or the SLIP packet has a transparency error.
RBS Pattern	Reports the number of robbed bits detected in the connection. The robbed bits are used for inband signaling. This information is reported only for K56Flex (by the analog modem) and is found only on a channelized line such as T1 or E1. The six least significant bits (LSBs) of the returned value indicate the periodic robbed bit signaling (RBS) pattern where a 1 denotes a pulse code modulation (PCM) sample with a robbed bit.
VAD Background noise level	VAD background noise level, in 6.2 dBm increments.
ECAN Background noise level	ECAN background noise level, in -83.4 decibels per milliwatt (dBm) increments.

The following example shows output from the **show port operational-status** command for the Cisco AS5350 on shelf 1, slot 5 with the T.38 fax relay statistics:

```
Router# show port operational-status 1/5
```

```
Telephony call-legs: 1
SIP call-legs: 0
H323 call-legs: 0
MGCP call-legs: 0
Multicast call-legs: 0
Total call-legs: 1

GENERIC:
SetupTime=10465510 ms
Index=1
PeerAddress=41023
PeerSubAddress=
PeerId=1
PeerIfIndex=242
LogicalIfIndex=180
ConnectTime=1046791
CallDuration=00:00:41 sec
CallState=4
CallOrigin=2
ChargedUnits=0
InfoType=fax
TransmitPackets=260
```

## show port operational-status

```

TransmitBytes=4396
ReceivePackets=1014
ReceiveBytes=40385

TELE:

ConnectionId=[0x37DF8CCA 0x9FA611D8 0x8007000A 0xF4107CA0]
!
IncomingConnectionId=[0x37DF8CCA 0x9FA611D8 0x8007000A 0xF4107CA0]
CallID=11
TxDuration=6640 ms
VoiceTxDuration=0 ms
FaxTxDuration=0 ms
FaxRate=disable bps
FaxRelayMaxJitBufDepth 0
FaxRelayJitterBufOverflow 0
Initial HS Modulation is UNKNOWN
Recent HS modulation is UNKNOWN
Number of pages 0
Direction of transmission is Unknown
Num of Packets TX'ed/RX'ed 0/0
Packet loss conceal is 0
Encapsulation protocol is T.38 (UDPTL)
ECM is DISABLED
NoiseLevel=0
ACOMLevel=0
OutSignalLevel=0
InSignalLevel=0
InfoActivity=0
ERLLevel=0
SessionTarget=
!
ImgPages=0
CallerName=Analog 41023
CallerIDBlocked=False
OriginalCallingNumber=
OriginalCallingOctet=0x80
OriginalCalledNumber=41021
OriginalCalledOctet=0xA1
OriginalRedirectCalledNumber=
OriginalRedirectCalledOctet=0xFF
TranslatedCallingNumber=41023
TranslatedCallingOctet=0x80
TranslatedCalledNumber=41021
TranslatedCalledOctet=0xA1
TranslatedRedirectCalledNumber=
TranslatedRedirectCalledOctet=0xFF
GwReceivedCalledNumber=41021
GwReceivedCalledOctet3=0xA1
GwOutpulsedCalledNumber=41021

```

Table 10 describes the significant fields showing T.38 fax relay statistics:

**Table 10** show port operational-status Field Descriptions showing significant T.38 Fax Relay Statistics

Field	Description
Telephony call-legs	Type of call: Telephony.
SIP call-legs	Type of call: Session Initiation Protocol (SIP).
H323 call-legs	Type of call: H.323.
MGCP call-legs	Type of call: Media Gateway Control Protocol (MGCP).

Table 10 show port operational-status Field Descriptions showing significant T.38 Fax Relay Statistics

Field	Description
Multicast call-legs	Type of call: Multicast.
Total call-legs	Total calls.
PeerIfIndex	Voice port index number for this peer. For ISDN media, this would be the index number of the B channel used for this call.
LogicalIfIndex	Index number of the logical interface for this call.
TxDuration	Duration of transmit path open from this peer to the voice gateway for this call.
VoiceTxDuration	Duration of voice transmission from this peer to the voice gateway for this call in milliseconds (ms).
FaxTxDuration	Duration of fax transmission from this peer to the voice gateway for this call in ms.
FaxRate	Fax transmission rate from this peer to the specified dial peer in bps.
FaxRelayMaxJitBufDepth	Fax relay maximum jitter buffer depth in ms.
FaxRelayJitterBufOverflow	Fax relay jitter buffer overflow in ms.
Initial HS Modulation	Initial high speed modulation used.
Recent HS Modulation	Recent high-speed modulation used
ACOMLevel	Current ACOM level estimate in 0.1 dB increments. The term ACOM is used in G.165, "General Characteristics of International Telephone Connections and International Telephone Circuits: Echo Cancellers." ACOM is the combined loss achieved by the echo canceller, which is the sum of the ERL, ERL enhancement, and nonlinear processing loss for the call.
ERLLevel	Current Echo Return Loss (ERL) level estimate in 0.1 dB increments.
OriginalCallingNumber, OriginalCallingOctet, OriginalCalledNumber, OriginalCalledOctet, OriginalRedirectCalledNumber, OriginalRedirectCalledOctet	Original call information regarding calling, called, and redirect numbers, as well as octet-3s. Octet-3s are information elements (IEs) of Q.931 that include type of number, numbering plan indicator, presentation indicator, and redirect reason information.
TranslatedCallingNumber, TranslatedCallingOctet, TranslatedCalledNumber, TranslatedCalledOctet, TranslatedRedirectCalledNumber, TranslatedRedirectCalledOctet	Translated call information.
GwReceivedCalledNumber, GwReceivedCalledOctet3	Call information received at the gateway.

### Related Commands

<b>Command</b>	<b>Description</b>
<b>port modem autotest</b>	Automatically and periodically performs a modem diagnostics test for modems inside the access server or router.
<b>show modem operational-status</b>	Displays the operational status of a specific port or port range.
<b>show spe modem active</b>	Displays active modem statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>test port modem back-to-back</b>	Tests two specified ports back-to-back and transfers a specified amount of data between the ports.
<b>voicecap configure</b>	Applies a voicecap on NextPort platforms.

## show ppp bap

To display the PPP Bandwidth Allocation Protocol (BAP) configuration settings and run-time status for a multilink bundle, use the **show ppp bap** command in privileged EXEC mode.

```
show ppp bap {counters [reset] | group [name] | queues}
```

Syntax Description	counters [reset]	Incoming and outgoing call counters and connection request data. The optional <b>reset</b> keyword resets the counters.
	<b>group</b> [name]	All or, optionally, a specific BAP bundle group.
	<b>queues</b>	BAP queues.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	11.3	This command was introduced.
	12.2T	This command was enhanced with a display of incoming and outgoing call counters and connection request data.

**Examples** The following is sample output from the **show ppp bap group** command:

```
Router# show ppp bap group

Group bap-peer (multilink), id 35, peer has precedence, state Idle
Master interface: Dialer1
Outgoing requests: Call, Link Drop
Incoming requests: Call, Callback, Link Drop
Original number dialed 5550198
Transmit queue size threshold is not set
Peer link addition dependent upon load
Timers (secs): Call not set, Callback not set, Link Drop not set,
                Response 30, Pending 20
Retries: Request 3, Dial 1, Indication no limit
Link removal after 3 link drop retries not set
```

[Table 11](#) describes the significant fields shown in the display of the **show ppp bap group** command.

**Table 11** *show ppp bap group* Field Descriptions

Field	Description
Group bap-peer (multilink), id 35	Group name and internally assigned ID. “(multilink)” indicates the governing protocol.
peer has precedence	In cases where the remote and local peers issue simultaneous requests, the remote peer’s request takes precedence when the “peer has precedence” message is displayed. The local peer’s request takes precedence when the “precedence over peer” message is displayed.
state Idle	Internal state.

Table 11 *show ppp bap group Field Descriptions (continued)*

Field	Description
Outgoing requests	Current requests configured for outbound negotiation.
Incoming requests	Current requests allowed for inbound negotiation.
Peer link addition dependent upon load	Router is monitoring the load and subjecting requests to the load settings.
Timers (secs): Call not set, Callback not set, Link Drop not set, Response 30, Pending 20	Settings for specified timers.
Retries: Request 3, Dial 1, Indication no limit	Limits set on specified types of retransmissions.
Link removal after 3 link drop retries not set	The link will not be removed after no response to the link removal request because default behavior was not changed and the relevant link drop parameter was not set.

The display from the **show ppp bap counters** command shows fields of statistics gathered about request and response datagrams that allow endpoints to negotiate a connection and add or drop links from a multilink bundle, per RFC 2125:

- CallReq—Call-Request is a request for permission to add a link to a bundle.
- CallRsp—Call-Response is the required response to Callback-Request datagram.
- CallbackReq—Callback-Request is a request that the peer add a link to a bundle via a callback.
- CallbackRsp—Callback-Response is sent in response to a received Callback-Request.
- DropQueryReq—Link-Drop-Query-Request negotiates with the peer to drop a link from a bundle.
- DropQueryRsp—Link-Drop-Query-Response is sent to the peer to negotiate dropping a link.
- StatusInd—Call-Status-Indication is sent to its peer as a result of a Call-Request or a Callback-Request to indicate whether the attempt to add the link succeeded or failed.
- StatusRsp—Call-Status-Response is sent in response to a received Call-Status-Indication.

The counters record statistical information used by Cisco personnel for debugging purposes that is generally of no interest to end users. Following is sample output:

```
Router# show ppp bap counters
```

```
Incoming      inv-link  opt-err  rejects
              0         4         2

Outgoing      inv-link  add-att  rem-att  add-fail  add-pass  dial-att  oob-ind
              1         6         5         0         0         0         0

Incoming      off  pend  pend-add  wait  unf-req
CallReq       0    1     1         0     0
CallRsp       0    0     0         0     0
CallbackReq   0    0     0         0     0
CallbackRsp   0    0     0         0     0
DropQueryReq  0    0     0         0     0
DropQueryRsp  0    0     0         0     0
StatusInd     0    0     0         0     0
StatusRsp     0    0     0         0     0
```

Outgoing	off	pend	pend-add	unf	unf-req
CallReq	0	0	0	0	0
CallRsp	0	1	0	0	0
CallbackReq	0	0	0	0	0
CallbackRsp	0	0	0	0	0
DropQueryReq	0	0	0	0	0
DropQueryRsp	0	0	0	0	0
StatusInd	0	0	0	0	0
StatusRsp	0	0	0	0	0

---

**Related Commands**

---

<b>Command</b>	<b>Description</b>
<b>show ppp multilink</b>	Displays bundle information for the MLP bundles.

---

# show ppp multilink

To display bundle information for Multilink PPP (MLP) bundles, use the **show ppp multilink** command in user EXEC or privileged EXEC mode.

```
show ppp multilink [active | inactive | interface type number | [username {name | none}]
                  [endpoint {discriminator | none}]]
```

Syntax Description		
<b>active</b>	(Optional)	Displays information about active multilink bundles only.
<b>inactive</b>	(Optional)	Displays information about inactive multilink bundles only.
<b>interface</b>	(Optional)	Displays information for the specified bundle interface.
<i>type</i>	(Optional)	Interface type. For more information, use the question mark (?) online help function.
<i>number</i>	(Optional)	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
<b>username</b>	(Optional)	Displays information for all multilink bundles that have the specified peer username.
<i>name</i>	(Optional)	Username of the multilink bundle.
<b>none</b>	(Optional)	Displays information for multilink bundles with no remote username.
<b>endpoint</b>	(Optional)	Displays information for all multilink bundles that have the specified endpoint discriminator.
<i>discriminator</i>	(Optional)	Endpoint discriminator.
<b>none</b>	(Optional)	Displays information for all multilink bundles with no endpoint discriminator.

Command Modes	
	User EXEC (>)
	Privileged EXEC (#)

Command History	Release	Modification
	11.2	This command was introduced.
	12.2(13)T	This command was modified. This command was updated to include per-class information when Multiclass Multilink PPP (MCMP) is negotiated.
	12.3(7)T	This command was modified. The <b>active</b> , <b>inactive</b> , <b>endpoint</b> , and <b>username</b> keywords were added to enable information to be displayed for bundles that have specific parameters.
	12.4(9)T	This command was modified. The output of the command was changed to include the following fields: Remote Endpoint Discriminator, Local Endpoint Discriminator, Bundle up for, total bandwidth, load, Receive buffer limit, frag timeout, fragments/bytes in reassembly list, lost fragments, reordered, discarded fragments/bytes, lost received, received sequence, sent sequence, Member links, BR2/0:1, since, weight, and frag size.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.



Release	Modification
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
15.4(2)S	This command was implemented on the Cisco ASR 901 Series Aggregation Services Router.

## Examples

The following is sample output from the **show ppp multilink** command when no bundles are on a system:

```
Router# show ppp multilink
```

```
No active bundles
```

The following is an example of sample output when a single MLP bundle (named bundle1) is on a system:

```
Router# show ppp multilink
```

```
Bundle bundle1, 3 members, first link is BRI0: B-channel 1
0 lost fragments, 8 reordered, 0 unassigned, sequence 0x1E/0x1E rcvd/sent
```

The following is another example of sample output when a single MLP bundle (named 7206-3) is on a system:

```
Router# show ppp multilink
```

```
Virtual-Access4
Bundle name: 7206-3
Remote Endpoint Discriminator: [1] 7206-3
Local Endpoint Discriminator: [1] 7206-4
Bundle up for 00:00:07, total bandwidth 64, load 1/255
Receive buffer limit 12192 bytes, frag timeout 1000 ms
 0/0 fragments/bytes in reassembly list
 0 lost fragments, 0 reordered
 0/0 discarded fragments/bytes, 0 lost received
 0x0 received sequence, 0x0 sent sequence
Member links: 1 active, 0 inactive (max not set, min not set)
 BR2/0:1, since 01:59:35, 80 weight, 72 frag size
```

The following is sample output when two active bundles are on a system:

```
Router# show ppp multilink
```

```
Bundle bundle1, 3 members, first link is BRI0: B-Channel 1
 0 lost fragments, 8 reordered, 0 unassigned, sequence 0x1E/0x1E rcvd/sent
Bundle bundle2, 4 members, first link is BRI2: B-Channel 1
 0 lost fragments, 28 reordered, 0 unassigned, sequence 0x12E/0x12E rcvd/sent
```

The following example for a stack group member called systema shows output when a stack group has been created. On stack group member systema, the MLP bundle named bundle1 has bundle interface Virtual-Access4. Two child interfaces are joined to this bundle interface. The first is a local PRI channel (Serial 0:4), and the second is an interface from stack group member systemb.

```
Router# show ppp multilink
```

```
Virtual-Access4
Bundle name: 7206-3
Remote Endpoint Discriminator: [1] 7206-3
Local Endpoint Discriminator: [1] 7206-4
Bundle up for 00:00:07, total bandwidth 64, load 1/255
Receive buffer limit 12192 bytes, frag timeout 1000 ms
```

```

Using relaxed lost fragment detection algorithm.
 0/0 fragments/bytes in reassembly list
 0 lost fragments, 0 reordered
 0/0 discarded fragments/bytes, 0 lost received
 0x0 received sequence, 0x0 sent sequence
Member links: 2 active, 0 inactive (max not set, min not set)
  BR2/0:1, since 01:59:35, 80 weight, 72 frag size
  systemb:Vi6 (10.1.1.1), since 00:00:42, unsequenced

```

The following is sample output when the PPP Bandwidth Allocation Control Protocol (BACP) is enabled for the multilink bundle:

```

Router# show ppp multilink

Virtual-Access4
  Bundle name: 7206-3
  Remote Endpoint Discriminator: [1] 7206-3
  Local Endpoint Discriminator: [1] 7206-4
  Bundle up for 00:00:07, total bandwidth 64, load 1/255
  Bundle under BAP control
  Dialer interface is Dialer1
  Receive buffer limit 12192 bytes, frag timeout 1000 ms
    0/0 fragments/bytes in reassembly list
    0 lost fragments, 0 reordered
    0/0 discarded fragments/bytes, 0 lost received
    0x0 received sequence, 0x0 sent sequence
  Member links: 1 active, 0 inactive (max not set, min not set)
    BR2/0:1, since 01:59:35, 80 weight, 72 frag size

Discriminators Local Remote
  BR2/0:1          24      1

```

Table 12 describes the significant fields shown in the display.

**Table 12** *show ppp multilink Field Descriptions with PPP BACP Enabled*

Field	Description
Bundle name	Configured name of the multilink bundle.
Member links	Number of interfaces in the group.
Bundle under BAP control	Multilink bundle is controlled and bandwidth is allocated by BACP.
Dialer Interface is	Name of the interface that dials the calls.
Member links	Number of child interfaces.
Discriminators Local Remote	Link Control Protocol (LCP) link discriminators, which are identifiers negotiated for each link in the bundle. This information is specific to BACP. BACP uses these discriminators to determine which link to drop during negotiations.

The following is sample output when MCMP is negotiated on a virtual access interface named Virtual-Access3:

```

Router# show ppp multilink interface Virtual-Access 3

Virtual-Access3, bundle name is bundle1
Bundle up for 01:59:35, 1/255 load, 2 receive classes, 2 transmit classes
Receive buffer limit 12192 bytes per class, frag timeout 1524 ms
Dialer interface is Dialer1
!
```

```

Receive Class 0:
0/0 fragments/bytes in reassembly list
0 lost fragments, 0 reordered
0/0 discarded fragments/bytes, 0 lost received
0x0 received sequence
!
Receive Class 1:
0/0 fragments/bytes in reassembly list
0 lost fragments, 0 reordered
0/0 discarded fragments/bytes, 0 lost received
0x0 received sequence
!
Transmit Class 0:
0x8 sent sequence
!
Transmit Class 1:
0x0 sent sequence
!
Member links: 1 (max not set, min not set)
BR2/0:1, since 01:59:35, 80 weight, 72 frag size

```

The following is sample output when Distributed MLP (DLMP) is enabled on Cisco MWR2941 router. The fragments would always contain zero because the counters do not exist in the DMLP output. This is only applicable on Cisco MWR series routers:

```

Bundle name: pas3_ep
Remote Endpoint Discriminator: [1] pas3_ep
Local Endpoint Discriminator: [1] pas1_ep
Bundle up for 00:04:47, total bandwidth 31744, load 1/255
Receive buffer limit 192000 bytes, frag timeout 1000 ms
Interleaving disabled
  0/0 fragments/bytes in reassembly list
  0 lost fragments, 0 reordered
  0/0 discarded fragments/bytes, 0 lost received
  0xB received sequence, 0xC sent sequence
Distributed MLP bundle status is: active
Member links: 16 active, 0 inactive (max not set, min not set)
  Se0/4:0, since 00:04:48, 7440 weight, 1496 frag size
  Se0/5:0, since 00:04:48, 7440 weight, 1496 frag size
  Se0/6:0, since 00:04:48, 7440 weight, 1496 frag size
  Se0/7:0, since 00:04:48, 7440 weight, 1496 frag size
  Se0/8:0, since 00:04:48, 7440 weight, 1496 frag size
  Se0/0:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/1:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/2:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/3:0, since 00:04:49, 7440 weight, 1496 frag size
  Se0/9:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/10:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/11:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/12:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/13:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/14:0, since 00:04:47, 7440 weight, 1496 frag size
  Se0/15:0, since 00:04:47, 7440 weight, 1496 frag size
No inactive multilink interfaces

```

Table 13 describes the significant fields shown in the display when MCMP is enabled.

**Table 13** *show ppp multilink Field Descriptions with MCMP Enabled*

Field	Description
bundle name is	Configured name of the multilink bundle.
Bundle up for	Time (in hh:mm:ss) for which the bundle has been up.
load	Load on the link in the range from 1/255 to 255/255 (255/255 is a 100 percent load).
receive classes, transmit classes	Number of data classes defined for the multilink bundle.
Receive buffer limit	Maximum number of bytes that will be buffered for reassembly for each class of data.
frag timeout	Amount of time, in milliseconds, the router will wait for the expected sequence number to arrive after receiving an out-of-order fragment.
Receive Class 0	Information about Class 0 (normal data) packets received by the router.
fragments/bytes in reassembly list	Number of fragments and bytes currently buffered and awaiting reassembly.
lost fragments	Number of fragments that have been lost.
reordered	Number of fragments that have been reordered.
discarded fragments/bytes	Number of fragments and bytes that have been discarded. This usually occurs only if the fragment is a part of a packet for which one or more fragments were lost.
lost received	Number of fragments that arrived after they were declared lost.
Receive Class 1	Information about Class 1 (high-priority) packets received by the router.
Transmit Class 0	Information about Class 0 (normal data) packets sent by the router.
Transmit Class 1	Information about Class 1 (high-priority) packets sent by the router.
Member links	Number of child interfaces.
BR2/0:1	Identity of the child interface.
since	Amount of time (in hh:mm:ss) the interface has been active.
weight	Relative weight of the link (calculated as bandwidth x fragment delay). This value is used to calculate the fragment size and for load balancing. Each fragment should be less than or equal to the weight, including all link layer headers.
frag size	Fragment size of packets sent over the link, not including link layer headers. The difference between the weight and the fragment size indicates how much link layer overhead is being calculated for each fragment.

The following sample output displays information about all the active multilink bundles:

```
Router# show ppp multilink active

Virtual-Access4, bundle name is 7200-4
  Endpoint discriminator is 7200-4
  Bundle up for 00:31:26, 1/255 load
```

```

Receive buffer limit 12192 bytes, frag timeout 1000 ms
  0/0 fragments/bytes in reassembly list
  0 lost fragments, 0 reordered
  0/0 discarded fragments/bytes, 0 lost received
  0x0 received sequence, 0x0 sent sequence
Member links:1 (max not set, min not set)
Vi3, since 00:31:26
PPPoATM link, ATM PVC 15/200 on ATM4/0.10000
Packets in ATM PVC Holdq:0 , Particles in ATM PVC Tx Ring:1

```

Table 14 describes the significant fields shown in the display when information for all active bundles is displayed.

**Table 14** *show ppp multilink Field Descriptions for Active Bundles*

Field	Description
bundle name is	Configured name of the multilink bundle.
Endpoint discriminator	Identifies the MLP bundle to which the PPP over ATM (PPPoA) session is associated.
Bundle up for	Time (in hh:mm:ss) for which the bundle has been up.
1/255 load	Load on the link in the range from 1/255 to 255/255 (255/255 is a 100 percent load).
Receive buffer limit	Maximum number of bytes that will be buffered for reassembly for each class of data.
frag timeout	Amount of time, in milliseconds, the router will wait for the expected sequence number to arrive after receiving an out-of-order fragment.
fragments/bytes in reassembly list	Number of fragments and bytes currently buffered and awaiting reassembly.
lost fragments	Number of fragments that have been lost.
reordered	Number of fragments that have been reordered.
discarded fragments/bytes	Number of fragments and bytes that have been discarded. This usually occurs only if the fragment is a part of a packet for which one or more fragments were lost.
lost received	Number of fragments that arrived after they were declared lost.
received sequence	Sequence number of the last MLP packet received.
sent sequence	Sequence number of the last MLP packet sent.
Member links	Number of child interfaces.
Vi3	Identity of the child interface.
since	Amount of time (in hh:mm:ss) the interface has been active.
Packets in ATM PVC Holdq	Number of packets in the ATM permanent virtual connection (PVC) hold queue.
Particles in ATM PVC Tx Ring	Number of particles in the transmission ring of the ATM PVC.

#### Related Commands

Command	Description
<b>ppp multilink</b>	Enables MLP on an interface and, optionally, enables BACP and its BAP subset for dynamic bandwidth allocation.

# show queuing virtual-access

To display information about interleaving, use the **show queuing virtual-access** command in EXEC mode.

**show queuing virtual-access** *number*

<b>Syntax Description</b>	<i>number</i>	Virtual access interface number.
<b>Command Modes</b>	EXEC (>)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.3	This command was introduced.

## Examples

The following is sample output from the **show queuing virtual-access** command:

```
Router# show queuing virtual-access 1

Input queue: 0/75/0 (size/max/drops); Total output drops: 164974
Queueing strategy: weighted fair
Output queue: 315/64/164974/31191 (size/threshold/drops/interleaves)
  Conversations 5/8 (active/max active)
  Reserved Conversations 2/2 (allocated/max allocated)

(depth/weight/discards/interleaves) 64/4096/38669/0
Conversation 36, linktype: ip, length: 52
source: 172.23.3.201, destination: 225.1.2.3, id: 0x0001, ttl: 254,
TOS: 0 prot: 17, source port 6789, destination port 2345

(depth/weight/discards/interleaves) 64/4096/0/0
Conversation 2, linktype: ip, length: 52
source: 172.23.3.201, destination: 225.1.2.4, id: 0x0001, ttl: 254,
TOS: 0 prot: 17, source port 5432, destination port 9870
```

Table 15 describes the significant fields shown in the display.

**Table 15** *show queuing virtual-access Field Descriptions*

Field	Description
Input queue: size, max, drops	Input queue used for virtual access interface 1, with the current size, the maximum size, and the number of dropped packets.
Total output drops	Number of output packets dropped.
Output queue: size/threshold/drops/interleaves	Output queue counters. Maximum number of packets allowed in the queue, number in the queue, the number of packets dropped due to a full queue, and the number of real-time packets interleaved among fragments of larger packets.
Conversations (active/max active)	Fair queue conversation statistics: number of conversations currently active and the maximum that have been active.

**Table 15** *show queuing virtual-access Field Descriptions (continued)*

<b>Field</b>	<b>Description</b>
Reserved conversations (allocated, max allocated)	Reserved conversations in the weighted fair queue (current/maximum number allocated). Reserved conversations get the highest priority.
(depth/weight/discards/interleaves) 64/4096/38669/0	Depth of the queue, weight assigned to each packet in the queue, number of packets discarded in the queue so far, and the number of interleaves.
Conversation 36, linktype: ip, length: 52	Conversation identifier, protocol used on the link (IP), and the number of bytes.
source: 140.3.3.201, destination: 225.1.2.3,	Source IP address and destination IP address.
id: 0x0001	Protocol ID, identifying IP.
ttl: 254	Time to live, in seconds.
TOS: 0	Type of service.
prot: 17	Protocol field in IP. The value 17 indicates UDP.
source port 5432	Source TCP/UDP port.
destination port 9870	Destination TCP/UDP port.

# show rcapi status

To display whether RAPI is turned on or off, use the **show rcapi status** command in privileged EXEC mode.

## show rcapi status

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	12.0(7)XV	This command was introduced on the Cisco 800 series router.

**Usage Guidelines** When RAPI is running, details about the list of CAPI clients currently registered, the type of application that each client is running, and the status of each CAPI call at the time of the display. This command works only with the Net3 switch type.

**Examples** The following is sample output from the **show rcapi status** command:

```
Router# show rcapi status
```

```
RCAPI SERVER ON
RCAPI SERVER PORT 2578
RCAPI NUMBER 5553000 5553100
```

CLIENT	SESSION ID	LISTEN	CONNECTION ID	TYPE	CALL STATUS
172.18.100.3	16777212	ON			
172.18.100.5	16777218	OFF	50333953	Bit Transparent	Connected
172.18.100.6	16777227	OFF	50333962	HDLC	Connected

Related Commands	Command	Description
	<b>debug rcapi events</b>	Displays diagnostic DCP and driver messages.
	<b>rcapi number</b>	Enables the Cisco 800 series router to distinguish between incoming CAPI calls and incoming non-CAPI calls such as POTS, PPP, and X.25.
	<b>rcapi server</b>	Enables the RAPI server on the 800 series router and, optionally, sets the TCP port number.



# show resource-pool call

To display all active call information for all customer profiles and resource groups, use the **show resource-pool call** command in EXEC mode.

## show resource-pool call

**Syntax Description** This command has no arguments or keywords.

**Command Modes** EXEC

Command History	Release	Modification
	12.0(4)XI	This command was introduced.

**Usage Guidelines** Use the **show resource-pool call** EXEC command to see all active call information for all customer profiles and resource groups. Use this command to see output when one call is up. If no calls are up, there is no output. Enter the command to see valid information for all current calls.

**Examples** The following is sample output from the **show resource-pool call** command:

```
Router# show resource-pool call

Shelf 0, slot 0, port 0, channel 2, state RM_RPM_RES_ALLOCATED
  Customer profile cpl, resource group isdn1
  DNIS number 71017
```

[Table 16](#) describes the significant fields shown in the display.

**Table 16** *show resource-pool call Field Descriptions*

Field	Description
Shelf	The shelf number where the call is being handled.
Slot	The slot number where the call is being handled.
Port	The port number where the call is being handled.
Channel	The channel number where the call is being handled.
State	The state of the call.
Customer profile	The customer profile name (alphanumeric).
Resource group	The name of the resource group being used for the call.
DNIS number	The DNIS number for the call.

# show resource-pool customer

To display the contents of one or more customer profiles, use the **show resource-pool customer** command in EXEC mode.

**show resource-pool customer** [*name*]

<b>Syntax Description</b>	<i>name</i>	(Optional) Name of a specific customer profile. The name can have up to 23 characters.
---------------------------	-------------	--

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(4)XI	This command was introduced.

## Examples

The following example displays the contents of the customer profile named customer1-isp:

```
Router# show resource-pool customer customer1-isp

 5 active connections
 3 calls accepted
 8 max number of simultaneous connections
 0 calls rejected due to profile limits
 0 calls rejected due to resource unavailable
 0 overflow connections
 0 overflow states entered
 0 minutes spent in overflow
28 minutes since last clear command
```

[Table 17](#) describes the significant fields shown in the display.

**Table 17** *show resource-pool customer Field Descriptions*

Field	Description
Active connections	Lists the number of active connections in the specified customer profile.
Calls accepted	Cumulative number of calls accepted since the last <b>clear</b> command in the customer profile—regardless of the call type.
Max number of simultaneous connections	Maximum number of simultaneous connections assigned for this customer profile.
Calls rejected due to profile limits	Cumulative number of calls rejected since the last <b>clear</b> command because the maximum number of allowable simultaneous connections was exceeded. You can configure each customer profile to not exceed a simultaneous call limit. This feature stops a single customer profile from consuming all the system resources.

*Table 17 show resource-pool customer Field Descriptions (continued)*

<b>Field</b>	<b>Description</b>
Calls rejected due to resource unavailable	Cumulative number of calls rejected since the last <b>clear</b> command because no system resources were available to accept the call (such as a free modem for an analog call or an HDLC framer for a circuit switched data call).
Overflow connections	Number of overflow connections active since the last <b>clear</b> command.
Overflow states entered	Number of overflow states processed since the last <b>clear</b> command.
Minutes spent in overflow	Number of minutes that the overflow session has been in process since the last <b>clear</b> command.
Minutes since last clear command	Number of minutes since the <b>clear</b> command has been used.
List of Customer Profiles	Lists the customer profiles set up on the access server.

# show resource-pool discriminator

To see how many times an incoming call has been rejected due to a specific Calling Line Identification (CLID) or Dialed Number Identification Service (DNIS) call-type combination, use the **show resource-pool discriminator** command in privileged EXEC mode.

```
show resource-pool discriminator [name]
```

<b>Syntax Description</b>	<i>name</i>	(Optional) Name of the specific CLID or DNIS and call-type that will be rejected. The name can have up to 23 characters.
---------------------------	-------------	--

<b>Command Default</b>	No default behavior or values. You must configure a call discriminator for the command to work or appear.	
------------------------	---	--

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(4)XI	This command was introduced.
12.1(5)T	This command was enhanced to include the CLID group when the discriminator contains CLID groups.	

**Usage Guidelines** Use the **show resource-pool discriminator** EXEC command to see how many times an incoming call has been rejected due to a specific CLID or DNIS and call-type combination.

If you enter the **show resource-pool discriminator** command without including a call discriminator name, a list of the current call discriminator profiles appears. If you enter a call discriminator profile name with the **show resource-pool discriminator** command, the number of calls rejected by the selected call discriminator appears.

**Examples** The following command displays the list of call discriminator profiles configured.

```
Router# show resource-pool discriminator

List of Call Discriminator Profiles:
  cd1
  cd2
  cd3
  cd4
```

The following command displays the number of calls rejected by call discriminator **cd1** since the last clear command was used (this number is cumulative).

```
Router# show resource-pool discriminator cd1

  0 calls rejected
```

Table 18 describes the significant fields shown in the displays.

*Table 18 show resource-pool discriminator Field Descriptions*

Field	Description
List of Call Discriminator Profiles	A list of the Call Discriminator Profile names currently assigned.
Calls rejected	Number of calls rejected since the last <b>clear</b> command was used. (This is cumulative.)

#### Related Commands

Command	Description
<b>resource-pool call treatment discriminator</b>	Configures a CLID group in a discriminator.

# show resource-pool resource

To see the resource groups configured in the network access server, use the **show resource-pool resource** command in EXEC mode.

```
show resource-pool resource [name]
```

<b>Syntax Description</b>	<i>name</i>	(Optional) Contents of a specifically named resource group, which was set up by using the <b>resource-pool group resource name</b> command. The name can have up to 23 characters.
---------------------------	-------------	--

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(4)XI	This command was introduced.

**Usage Guidelines** Use the **show resource-pool resource** EXEC command to see the resource groups configured in the network access server. To see the contents of a specific resource group, use the **show resource-pool resource name** command.

**Examples** The following is sample output from the **show resource-pool resource** EXEC command:

```
Router# show resource-pool resource
```

```
List of Resources:
  modem1
  rg1
  hi
```

The following is sample output about **modem-group-1** from the **show resource-pool resource** EXEC command:

```
Router# show resource-pool resource modem-group-1

  2 resources in the resource group
  0 resources currently active
  0 calls accepted in the resource group
  0 calls rejected due to resource unavailable
  0 calls rejected due to resource allocation errors
```

Table 19 describes the significant fields shown in the display.

**Table 19** *show resource-pool resource name Field Descriptions*

<b>Field</b>	<b>Description</b>
Resources in the resource group	Number of resources allocated to this pool. For example, you can limit a range of modems to five. You can limit a range of circuit-switched data calls to 50.
Resources currently active	Number of resources that are currently used in the resource group.
Calls accepted in the resource group	Number of calls accepted in the resource group (this is cumulative).
Calls rejected due to resource unavailable	Number of calls rejected because a resource was not available (this is cumulative).
Calls rejected due to resource allocation errors	Number of times the access server had an available resource, but the resource had an error when the access server tried to allocate it (for example, a bad modem). Therefore, the call was rejected. (This is cumulative.)

# show resource-pool vpdn

To display information about a specific virtual private dialup network (VPDN) group or specific VPDN profile, use the **show resource-pool vpdn** command in EXEC mode.

```
show resource-pool vpdn {group | profile} [name]
```

## Syntax Description

<b>group</b>	All the VPDN groups configured on the router.
<b>profile</b>	All the VPDN profiles configured on the router.
<i>name</i>	(Optional) Specific VPDN group or profile.

## Command Modes

EXEC

## Command History

Release	Modification
12.0(4)XI	This command was introduced.

## Examples

Use the **show resource-pool vpdn group** command to display information about a specific VPDN group.

### Example 1

This example displays specific information about the VPDN group named vpdng2:

```
Router# show resource-pool vpdn group vpdng2

VPDN Group vpdng2 found under Customer Profiles: customer2

Tunnel (L2TP)
-----
dnis:customer2-calledg
cisco.com

Endpoint          Session Limit Priority Active Sessions Status Reserved Sessions
-----
172.21.9.97      *              1         0              OK
-----
Total            *              0         0              0
```

### Example 2

The following example displays information about all the VPDN groups configured on the router:

```
Router# show resource-pool vpdn group

List of VPDN Groups under Customer Profiles
Customer Profile customer1: vpdng1
Customer Profile customer2: vpdng2
List of VPDN Groups under VPDN Profiles
VPDN Profile profile1: vpdng1
VPDN Profile profile2: vpdng2
```



Table 20 describes the significant fields shown in the displays.

**Table 20** *show resource-pool vpdn group Field Descriptions*

Field	Description
Endpoint	IP address of HGW/LNS router.
Session Limit	Number of sessions permitted for the designated endpoint.
Priority	Loadsharing HGW/LNSs are always marked with a priority of 1.
Active Sessions	Number of active sessions on the network access server. These are sessions successfully established with endpoints (not reserved sessions).
Status	Only two status types are possible: OK and busy.
Reserved Sessions	Authorized sessions that are waiting to see if they can successfully connect to endpoints. Essentially, these sessions are queued calls. In most cases, reserved sessions become active sessions.
*	No limit is set.
List of VPDN Groups under Customer Profiles	A list of VPDN groups that are assigned to customer profiles. The customer profile name is listed first, followed by the name of the VPDN group assigned to it.
List of VPDN Groups under VPDN Profiles	A list of VPDN groups that are assigned to VPDN profiles. The VPDN profile name is listed first, followed by the VPDN group assigned to it.

### Example 3

The following example displays a list of all VPDN profiles configured on the router:

```
Router# show resource-pool vpdn profile
```

```
% List of VPDN Profiles:
  profile1
  profile2
  profile3
```

### Example 4

The following example displays details about a specific VPDN profile named vpdnp1:

```
Router# show resource-pool vpdn profile vpdnp1
```

```
0 active connections
0 max number of simultaneous connections
0 calls rejected due to profile limits
0 calls rejected due to resource unavailable
0 overflow connections
0 overflow states entered
0 overflow connections rejected
3003 minutes since last clear command
```

Table 21 describes the significant fields shown in the displays.

**Table 21** *show resource-pool vpdn profile Field Descriptions*

Field	Description
List of VPDN Profiles	A list of the VPDN profiles that have been assigned.
Active connections	Number of active VPDN connections counted by the VPDN profile.
Max number of simultaneous connections	Maximum number of VPDN simultaneous connections counted by the VPDN profile. This value helps you determine how many VPDN sessions to subscribe to a specific profile.
Calls rejected due to profile limits	Number of calls rejected since the last <b>clear</b> command because the profile limit has been exceeded.
Calls rejected due to resource unavailable	Number of calls rejected since the last <b>clear</b> command because the assigned resource was unavailable.
Overflow connections	Number of overflow connections used since the last <b>clear</b> command.
Overflow states entered	Number of overflow states entered since the last <b>clear</b> command.
Overflow connections rejected	Number of overflow connections rejected since the last <b>clear</b> command.
Minutes since last clear command	Number of minutes elapsed since the last <b>clear</b> command was used.

#### Related Commands

Command	Description
<b>resource-pool profile customer</b>	Creates a customer profile and enters customer profile configuration mode.
<b>resource-pool profile vpdn</b>	Creates a VPDN profile and enters VPDN profile configuration mode.
<b>vpdn group</b>	Associates a VPDN group with a customer or VPDN profile.
<b>vpdn-group</b>	Creates a VPDN group and enters VPDN group configuration mode.

# show sessions

To display information about open local-area transport (LAT), Telnet, or rlogin connections, use the **show sessions** command in EXEC mode.

**show sessions**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** EXEC

Command History	Release	Modification
	10.0	This command was introduced.

**Usage Guidelines** This command display the host name, address, number of unread bytes for the user to receive, idle time, and connection name.

**Examples** The following is sample output from the **show sessions** command:

```
Router# show sessions
```

```
Conn Host          Address           Byte    Idle  Conn Name
  1 MATHOM          192.168.7.21     0       0    MATHOM
* 2 CHAFF          172.25.12.19     0       0    CHAFF
```

The asterisk (\*) indicates the current terminal session.

[Table 22](#) describes significant fields shown in the display.

**Table 22** *show sessions Field Descriptions*

Field	Description
Conn	Name or address of the remote host to which the connection is made.
Host	Remote host to which the router is connected through a Telnet session.
Address	IP address of the remote host.
Byte	Number of unread bytes displayed for the user to receive.
Idle	Interval (in minutes) since data was last sent on the line.
Conn Name	Assigned name of the connection.

Related Commands	Command	Description
	<b>protocol (VPDN)</b>	Sets X.3 parameters for PAD connections.
	<b>where</b>	Lists open sessions associated with the current terminal line.

# show sgbp

To display the status of the stack group members, use the **show sgbp** command in EXEC mode.

## show sgbp

**Syntax Description** This command has no arguments or keywords.

**Command Modes** EXEC

Release	Modification
11.2	This command was introduced.

**Examples** The following is sample output from the **show sgbp** command:

```
Router# show sgbp

Group Name: stack State: 0 Ref: 0xC07B060
  Member Name: systemb State: ACTIVE Id: 1
  Ref: 0xC14256F
  Address: 10.1.1.1 Tcb: 0x60B34538

  Member Name: systemc State: ACTIVE Id: 2
  Ref: 0xA24256D
  Address: 10.1.1.2 Tcb: 0x60B34439

  Member Name: systemd State: IDLE Id: 3
  Ref: 0x0
  Address: 10.1.1.3 Tcb: 0x0
```

[Table 23](#) describes the significant fields shown in the display.

**Table 23** *show sgbp Field Descriptions*

Field	Description
Group Name	Name of the stack group.
State	Status of the group or its member. The values are 0 for the stack group itself, and either ACTIVE or IDLE for each of the members of the group.
Member Name	Name of a specific host defined as a member of this stack group.
Id	Identifier used for each member of the group; typically the final digit of the host's IP address on the network they share.
Address	IP address of the stack group member.

# show sgbp queries

To display the current seed bid value, use the **show sgbp queries** command in EXEC mode.

## show sgbp queries

**Syntax Description** This command has no arguments or keywords.

**Command Modes** EXEC

Command History	Release	Modification
	11.2	This command was introduced.

**Examples** The following example shows a bid of 50 from this system. Peers queried the system for the bid, the bid was accepted, and a connection was opened from a peer in the stack group.

```
Router# show sgbp queries

Seed bid: default, 50

Bundle: book State: Query_from_peers OurBid: 50
10.1.1.2      State: Open_from_peer  Bid: 050 Retry: 0
```

[Table 24](#) describes the significant fields shown in the display.

**Table 24** *show sgbp queries Field Descriptions*

Field	Description
Seed bid	The initial bid; in this case, the default 50.
Bundle	Name of the MMP bundle.
State	Activity that occurred. In this case, a peer queried this system for its bid for the specified bundle.
OurBid	What this system bid for the bundle. It bid 50.
10.1.1.2	The peer's IP address.
State Bid Retry	Activity that occurred on the bid. In this case, the stack-group peer 1.1.1.2 accepted this system's bid of 50 for the bundle and opened a connection with this system. Since the peer opened a connection, no retry was needed.

# show snapshot

To display snapshot routing parameters associated with an interface, use the **show snapshot** command in EXEC mode.

```
show snapshot [interface-type interface-number]
```

<b>Syntax Description</b>	<i>interface-type</i> (Optional) Interface type and number. <i>interface-number</i>
---------------------------	--

<b>Command Modes</b>	EXEC
----------------------	------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	10.3	This command was introduced.

**Examples** The following is sample output from the **show snapshot** command:

```
Router# show snapshot serial 1

Serial1 is up, line protocol is up, snapshot up
Options: dialer support
Length of each activation period: 3 minutes
Period between activations:      10 minutes
Retry period on connect failure: 10
For dialer address 240
  Current queue: active, remaining active time: 3 minutes
  Updates received this cycle: ip, ipx, appletalk
For dialer address 1
  Current queue: client quiet, time until next activation: 7 minutes
```

[Table 25](#) describes the significant fields shown in the display.

**Table 25** *show snapshot Field Descriptions*

Field	Description
Serial1 is up, line protocol is up	Indicates whether the interface hardware is currently active (whether carrier detect is present) and whether it has been taken down by an administrator.
snapshot up	Indicates whether the snapshot protocol is enabled on the interface.
Options:	Option configured on the <b>snapshot client</b> or <b>snapshot server</b> interface configuration command. It can be one of the following: <ul style="list-style-type: none"> <li>dialer support—Snapshot routing is configured with the <b>dialer</b> keyword.</li> <li>stay asleep on carrier up—Snapshot routing is configured with the <b>suppress-statechange-updates</b> keyword.</li> </ul>
Length of each activation period	Length of the active period.

Table 25 *show snapshot Field Descriptions (continued)*

Field	Description
Period between activations	Length of the quiet period.
Retry period on connect failure	Length of the retry period.
For dialer address	Displays information about each dialer rotary group configured with the <b>dialer map</b> command.
Current queue:	Indicates which period snapshot routing is currently in. It can be one of the following: <ul style="list-style-type: none"> <li>• active—Routing updates are being exchanged.</li> <li>• client quiet—The client router is in a quiet period and routing updates are not being exchanged.</li> <li>• server quiet—The server router is in a quiet period, awaiting an update from the client router before awakening, and routing updates are not being exchanged.</li> <li>• post active—Routing updates are not being exchanged. If the server router receives an update from the client router, it processes it but does not begin an active period. This allows time for resynchronization of active periods between the client and server routers.</li> <li>• no queue—This is a temporary holding queue for new snapshot routing interfaces and for interfaces being deleted.</li> </ul>
remaining active time time until next activation	Time remaining in the current period.
Updates received this cycle	Protocols from which routing updates have been received in the current active period. This line is displayed only if the router or access server is in an active period.

# show spe

To display service processing element (SPE) status, use the **show spe** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe [slot | slot/spe | slot/port]
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe [shelf/slot | shelf/slot/spe]
```

Syntax Description	
<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. and SPE values range from 1 to 17. You must include the slash mark.
<i>slot/port</i>	(Optional) The specified port range on a slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. Port values range from 0 to one less than the number of ports supported by the card. You must include the slash mark.
<i>shelf/slot</i>	(Optional) The specified port range on a shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
<i>shelf/slot/spe</i>	(Optional) All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.1(5)XM2	This command was integrated into Cisco IOS Release 12.1(5)XM2.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350 and Cisco AS5400 platforms.

**Usage Guidelines** Use the **show spe** command to display status and history statistics of all SPEs, a specified SPE, or the specified range of SPEs.



**Examples**

The following example displays history statistics for all SPEs after a busyout was executed on SPE 2/0 and a shutdown was executed on SPE 2/1 on the Cisco AS5400:

```
Router# show spe

SPE settings:
=====
Country code configuration: default T1 (u Law)
Polling interval: 12 secs.
History log events: 50(per port)
Port legends:
=====
Port state: (s)shutdown (t)test (r)recovery (d)download
             (b)busiedout (p)busyout pending, (B)bad (a)active call
Call Type: (m)modem (d)digital (__)not in use
```

SPE#	Port #	SPE State	SPE Busyout	SPE Shut	SPE Crash	Port State	Call Type
2/00	0000-0005	ACTIVE	0	0	0	aaaaaa	dddddd
2/01	0006-0011	ACTIVE	0	0	0	aaaaaa	dddddd
2/02	0012-0017	ACTIVE	0	0	0	aaaaaa	dddddd
2/03	0018-0023	ACTIVE	0	0	0	aaaaaa	dddmdm
2/04	0024-0029	ACTIVE	0	0	0	aaaaaa	dmmmmm
2/05	0030-0035	ACTIVE	0	0	0	aaa_aa	mmm_mm
2/06	0036-0041	ACTIVE	0	0	0	__aaaa	__mddd
2/07	0042-0047	ACTIVE	0	0	0	aaa_aa	mmm_mm
2/08	0048-0053	ACTIVE	0	0	0	_aaa_a	_mmm_m
2/09	0054-0059	ACTIVE	0	0	0	_aa_aa	_md_mm
2/10	0060-0065	ACTIVE	0	0	0	_a_a_a	_m_m_m
2/11	0066-0071	ACTIVE	0	0	0	_a_aaa	_d_mmd
2/12	0072-0077	ACTIVE	0	0	0	aaaaaa	mdmddd
2/13	0078-0083	ACTIVE	0	0	0	_aaaaa	_dmmdd
2/14	0084-0089	ACTIVE	0	0	0	_a_aaa	_m_ddd
2/15	0090-0095	ACTIVE	0	0	0	a_aaaa	m_dddd
2/16	0096-0101	ACTIVE	0	0	0	aaaaaa	dddmd
2/17	0102-0107	ACTIVE	0	0	0	aaaaaa	dddddd

The following example shows output for the **show spe** command on the Cisco AS5800 with the universal port card. This example shows SPE settings for slot 2, SPEs 0 to 53:

```
Router# show spe

SPE settings
=====
Country code configuration default T1 (u Law)
Polling interval 12 secs.
History log events 50(per port)
Port legends
=====
Port state (s)shutdown (t)test (r)recovery (d)download
             (b)busiedout (p)busyout pending, (B)bad (a)active call
Call type (m)modem (d)digital (__)not in use
```

SPE#	Port #	SPE State	SPE Busyout	SPE Shut	SPE Crash	Port State	Call Type
1/02/00	0000-0005	ACTIVE	0	0	0	a_a_a_	m_m_m_
1/02/01	0006-0011	ACTIVE	0	0	0	aaa__	mmm__
1/02/02	0012-0017	ACTIVE	0	0	0	_a_aa_	_m_mm_
1/02/03	0018-0023	ACTIVE	0	0	0	_aaaaa	_mmmmm
1/02/04	0024-0029	ACTIVE	0	0	0	a_a_a_	m_m_m_
1/02/05	0030-0035	ACTIVE	0	0	0	__a__	__m__
1/02/06	0036-0041	ACTIVE	0	0	0	_aaa_a	_mmm_m
1/02/07	0042-0047	ACTIVE	0	0	0	a_____	m_____

```

1/02/08 0048-0053 ACTIVE 0 0 0 _aa_aa _mm_mm
1/02/09 0054-0059 ACTIVE 0 0 0 _aa_aa _mm_mm
1/02/10 0060-0065 ACTIVE 0 0 0 _a_a_a _m_m_m
1/02/11 0066-0071 ACTIVE 0 0 0 a_aa_ m_mm_
1/02/12 0072-0077 ACTIVE 0 0 0 aaa_ mmm_
1/02/13 0078-0083 ACTIVE 0 0 0 aaaa_a mmmm_m
1/02/14 0084-0089 ACTIVE 0 0 0 _aaa_ _mmm_
1/02/15 0090-0095 ACTIVE 0 0 0 a_aaa m_mmm
1/02/16 0096-0101 ACTIVE 0 0 0 _aaaa_ _mmmm_
1/02/17 0102-0107 ACTIVE 0 0 0 _aaa_a _mmm_m
1/02/18 0108-0113 ACTIVE 1 0 0 _aaaaa _mmmmm
1/02/19 0114-0119 ACTIVE 1 0 0 aa_aa mm_mm_
1/02/20 0120-0125 ACTIVE 1 0 0 aa_aa mm_mm
1/02/21 0126-0131 ACTIVE 1 0 0 aaa_aa mmm_mm
1/02/22 0132-0137 ACTIVE 1 0 0 a_ _m_
1/02/23 0138-0143 ACTIVE 1 0 0 a_aaa m_mmm
1/02/24 0144-0149 ACTIVE 1 0 0 a_a_aa m_m_mm
1/02/25 0150-0155 ACTIVE 1 0 0 _aaa_ _mmm_
1/02/26 0156-0161 ACTIVE 1 0 0 a_a_a m_m_m
1/02/27 0162-0167 ACTIVE 1 0 0 a_a_aa m_m_mm
1/02/28 0168-0173 ACTIVE 1 0 0 a_aa_ m_mm_
1/02/29 0174-0179 ACTIVE 1 0 0 a_ _m_
1/02/30 0180-0185 ACTIVE 1 0 0 _aaaaa _mmmmm
1/02/31 0186-0191 ACTIVE 1 0 0 _a_aa_ _m_mm_
1/02/32 0192-0197 ACTIVE 1 0 0 aaa_a mmm_m
1/02/33 0198-0203 ACTIVE 1 0 0 a_a_a m_m_m
1/02/34 0204-0209 ACTIVE 1 0 0 aaaaaa mmmmmm
1/02/35 0210-0215 ACTIVE 1 0 0 _aa_a_ _mm_m_
1/02/36 0216-0221 ACTIVE 0 0 0 a_a_aa m_m_mm
1/02/37 0222-0227 ACTIVE 0 0 0 a_aaaa m_mmmm
1/02/38 0228-0233 ACTIVE 0 0 0 aaaaaa mmmmmm
1/02/39 0234-0239 ACTIVE 0 0 0 aa_aa mm_mm
1/02/40 0240-0245 ACTIVE 0 0 0 aa_aaa mmm_mmm
1/02/41 0246-0251 ACTIVE 0 0 0 a_a_ m_m_
1/02/42 0252-0257 ACTIVE 0 0 0 aa_aa mm_mm
1/02/43 0258-0263 ACTIVE 0 0 0 aaa_aa mmm_mm
1/02/44 0264-0269 ACTIVE 0 0 0 aaaa_a mmmm_m
1/02/45 0270-0275 ACTIVE 0 0 0 aaa_a mmm_m_
1/02/46 0276-0281 ACTIVE 0 0 0 aaaaa_ mmmmm_
1/02/47 0282-0287 ACTIVE 0 0 0 _aaaa_ _mmmm_
1/02/48 0288-0293 ACTIVE 0 0 0 a_aa_a m_mm_m
1/02/49 0294-0299 ACTIVE 0 0 0 aa_a_a mm_m_m
1/02/50 0300-0305 ACTIVE 0 0 0 aa_aaa mm_mmm
1/02/51 0306-0311 ACTIVE 0 0 0 aaaaa_ mmmmm_
1/02/52 0312-0317 ACTIVE 0 0 0 aaaaaa mmmmmm
1/02/53 0318-0323 ACTIVE 0 0 0 aaaa_a mmmm_m

```

Table 26 describes the significant fields shown in the display.

**Table 26** *show spe Field Descriptions*

Field	Description
SPE #	Specifies the slot and port number of the SPE.
Port #	Displays the port number.
SPE State	Displays the state of the SPE port.
SPE Busyout	Displays the number of busyout calls.
SPE Shut	Indicates if the port is shut down.
SPE Crash	Specifies if the port has crashed.

Table 26 *show spe Field Descriptions (continued)*

Field	Description
Port State	Indicates if the port is active or idle.
Call Type	Data, modem, or fax call type.

Related Commands	Command	Description
	<b>show spe digital active</b>	Displays active digital calls and digital statistics of all SPEs, a specified SPE, or the specified range of SPEs.
	<b>show spe modem active</b>	Displays active modem statistics of all SPEs, a specified SPE, or the specified range of SPEs.
	<b>show spe voice active</b>	Displays active voice statistics of all SPEs, a specified SPE, or the specified SPE range.

## show spe digital

To display history statistics of all service processing elements (SPEs) for digital service, in summary form or for SPEs starting with a specified slot or a specified shelf/slot/range of SPEs, use the **show spe digital** command in EXEC mode.

**show spe digital** [*slot* | *slot/spe*]

Syntax Description		
<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.	
<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5400, slot values range from 1 to 7 and SPE values range from 1 to 17. You must include the slash mark.	

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced.
	12.1(3)T	This command was implemented on the Cisco AS5400.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** Use the **show spe digital** command on the Cisco AS5350 and Cisco AS5400 with NextPort port dial feature card (DFC).



**Note**

This command is not supported on the Cisco AS5800 with the universal port card (UPC).

**Examples** The following example uses the starting slot/SPE version of the **show spe digital** command. This example shows statistics for slot 5, SPE 4:

```
Router# show spe digital 5/4

#SPE 5/04
Cisco Universal SPE; Fw: 0.06.07.03; Async5/24 - 5/29, TTY672 - 677
Last clearing of statistics counters      : never
  11 incoming completes                 24 incoming failures
   0 outgoing completes                  0 outgoing failures
   0 failed dial attempts                 0 ring no answers
   0 no dial tones                       0 link failures
   0 watchdog timeouts                   0 protocol errors
   0 dial timeouts
```

```

Transmit Speed Counters      :
Speed    Calls Speed    Calls Speed    Calls Speed    Calls
Speed    Calls
 64000      0 28800      0 14400      0 7200      0
1200        0
 56000      0 24000      0 12000      0 4800      1
600         0
 38400      0 19200      10 9600       0 2400      0

Receive Speed Counters      :
Speed    Calls Speed    Calls Speed    Calls Speed    Calls
Speed    Calls
 64000      0 28800      0 14400      0 7200      0
1200        0
 56000      0 24000      0 12000      0 4800      1
600         0
 38400      0 19200      10 9600       0 2400      0

```

Table 27 describes the significant fields shown in the display.

**Table 27** *show spe digital Field Descriptions*

Field	Description
SPE #	Specifies the slot and port number of the SPE.
Cisco Universal SPE	Firmware version installed on the SPE.
Last clearing of statistics counters	Last time the modem counters were cleared using the <b>clear modem counters</b> command.
Transmit Speed Counters	List of connection speeds that were sent by the SPE.
Receive Speed Counters	List of connection speeds that were received by the SPE.

#### Related Commands

Command	Description
<b>show spe digital active</b>	Displays active digital calls and digital statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital csr</b>	Displays digital CSR statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital disconnect-reason</b>	Displays the local disconnection reasons for all digital calls on the SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital summary</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.

# show spe digital active

To display active digital calls and digital statistics of all service processing elements (SPEs), a specified SPE, or the specified range of SPEs, use the **show spe digital active** command in EXEC mode.

**show spe digital active** [*slot* | *slot /spe*]

Syntax Description	slot	(Optional) All ports on the specified slot. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5400, slot values range from 1 to 7 and SPE values range from 1 to 17. You must include the slash mark.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced.
	12.1(3)T	This command was implemented on the Cisco AS5400.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** Use the **show spe digital active** command on the Cisco AS5350 and Cisco AS5400 with the NextPort dial feature card (DFC).



**Note**

This command is not supported on the Cisco AS5800 with the universal port card (UPC).

**Examples**

The following is sample output from the **show spe digital active** command on the Cisco AS5400 with the NextPort DFC. This example displays active digital statistics for slot 5, SPE 06:

```
Router# show spe digital active 5

SPE 5/06
Port  Prot    Duration  Char          Sync
41    V.110    188      19200/19200  In    0

SPE 5/09
Port  Prot    Duration  Char          Sync
54    V.110    187      19200/19200  In    0
56    V.110    187      19200/19200  In    0
57    V.110    188      19200/19200  In    0
.
```

Table 28 describes the significant fields shown in the display.

**Table 28** *show spe digital active* Field Descriptions

Field	Description
SPE #	Specifies the slot and port number of the SPE.
Port	Port that is active.
Prot	Protocol used for the call in progress.
Duration	Duration of call.
Char Tx/Rx	Characters sent and received.

#### Related Commands

Command	Description
<b>show spe digital</b>	Displays history statistics of all digital SPEs, in summary form or for SPEs starting with a specified slot or a specified shelf/slot/range of SPEs.
<b>show spe digital csr</b>	Displays digital calls CSR statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital disconnect-reason</b>	Displays the local disconnect reasons for all digital calls on the SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital summary</b>	Display history statistics of all SPEs, a specified SPE, or the specified range of SPEs.

# show spe digital csr

To display digital call success rate (CSR) statistics of all service processing elements (SPEs), a specified SPE, or the specified range of SPEs, use the **show spe digital csr** command in EXEC mode.

```
show spe digital csr {summary [slot | slot/spe] [slot | slot/spe] | {slot | slot/spe} [slot | slot/spe]}
```

## Syntax Description

<b>summary</b>	Summary digital CSR statistics.
<i>slot</i>	All ports on the specified slot. For the Cisco AS5400, slot values range from 1 to 7. A range of slots can be specified by entering a second value for the <i>slot</i> argument.
<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5400, slot values range from 1 to 7 and SPE values range from 1 to 17. You must include the slash mark. A range of ports can be specified by entering a second value for the <i>slot/spe</i> argument.

## Command Modes

EXEC

## Command History

Release	Modification
12.1(1)XD	This command was introduced.
12.1(3)T	This command was implemented on the Cisco AS5400.
12.1(5)XM1	This command was implemented on the Cisco AS5350.
12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

## Usage Guidelines

Use the **show spe digital csr** command on the Cisco AS5350 and Cisco AS5400 with the NextPort dial feature card DFC.



### Note

This command is not supported on the Cisco AS5800 with the universal port DFC.

## Examples

The following is sample output from the **show spe digital csr** command on the Cisco AS5400 with the NextPort DFC. This example displays the number of call success rate counters for slot 5:

```
Router# show spe digital csr 5
```

SPE	Avg Hold Time	Inc calls		Out calls		Failed Dial	No Answer	Succ Pct
		Succ	Fail	Succ	Fail			
5/00	00:04:22	6	0	0	0	0	0	100%
5/01	00:04:22	6	0	0	0	0	0	100%
5/02	00:04:22	6	0	0	0	0	0	100%
5/03	00:04:22	6	0	0	0	0	0	100%
5/04	00:04:22	6	0	0	0	0	0	100%
5/05	00:04:21	6	0	0	0	0	0	100%
5/06	00:04:22	4	0	0	0	0	0	100%



5/07	00:04:22	1	0	0	0	0	0	100%
5/08	00:04:21	6	0	0	0	0	0	100%
5/09	00:04:23	5	0	0	0	0	0	100%
5/10	00:00:00	0	0	0	0	0	0	0%
5/11	00:04:21	5	0	0	0	0	0	100%
5/12	00:04:20	2	0	0	0	0	0	100%
5/13	00:00:00	0	0	0	0	0	0	0%
5/14	00:00:00	0	0	0	0	0	0	0%
5/15	00:00:00	0	0	0	0	0	0	0%
5/16	00:00:00	0	0	0	0	0	0	0%
5/17	00:00:00	0	0	0	0	0	0	0%

Table 29 describes the significant fields shown in the display.

**Table 29** *show spe digital csr Field Descriptions*

Field	Description
SPE	The SPE slot and port number.
Avg Hold Time	The average hold time.
Inc calls, Succ/Fail	The cumulative number of incoming calls that have succeeded and failed in the configured time period.
Out calls, Succ/Fail	The cumulative number of outgoing calls that have succeeded and failed in the configured time period.
Failed Dial	The number of calls that failed when dialed.
No Answer	The number of calls that were not answered.
Succ Pct	The CSR of the carrier.

#### Related Commands

Command	Description
<b>show spe digital</b>	Displays history statistics of all digital SPEs, in summary form or for SPEs starting with a specified slot or a specified shelf/slot/range of SPEs.
<b>show spe digital active</b>	Displays active digital calls and digital statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital disconnect-reason</b>	Displays the local disconnect reasons for all digital calls on the SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital summary</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.

## show spe digital disconnect-reason

To display the local disconnection reasons for all digital calls on the service processing elements (SPEs), a specified SPE, or the specified range of SPEs, use the **show spe digital disconnect-reason** command in EXEC mode.

**show spe digital disconnect-reason** [**summary** | *slot* | *slot/spe*]

Syntax Description	summary	(Optional) Summary of local disconnection reasons for digital ports.
	<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5400, slot values range from 1 to 7 and SPE values range from 1 to 17. You must include the slash mark.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced.
	12.1(3)T	This command was implemented on the Cisco AS5400.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** Use the **show spe digital disconnect-reason** command on the Cisco AS5350 and Cisco AS5400 with the NextPort dial feature card (DFC).



**Note**

This command is not supported on the Cisco AS5800 with the universal port card (UPC).

**Examples**

The following is sample output from the **show spe digital disconnect-reason** command on the Cisco AS5400 with the NextPort DFC. This example displays reasons for digital call disconnections on slot 5:

```
Router# show spe digital disconnect-reason 5

#SPE 5/00 :
=====CLASS HOST=====          =====CLASS SERVICE=====
NonSpecific          0 ATH                               0
Busy                 0 Aborted                           0
No Answer            0 Connect Timeout                   0
DTR                  0 Sync Loss                          0
ATH                  0
NoDialTone           0
No Carrier           0
```

```

ACK                0  TOTAL                0

#SPE 5/03  :
=====CLASS HOST=====      =====CLASS SERVICE=====
NonSpecific        0  ATH                0
Busy               1  Aborted            0
No Answer          0  Connect Timeout   0
DTR                0  Sync Loss         0
.
.
.

```

Table 30 describes the significant fields shown in the display.

**Table 30** *show spe digital disconnect-reason Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
CLASS HOST	Disconnect reasons are as follows: <ul style="list-style-type: none"> <li>• NonSpecific</li> <li>• Busy</li> <li>• No Answer—Number of times the SPE rang but did not answer the incoming call.</li> <li>• DTR</li> <li>• ATH</li> <li>• NoDialTone—Number of times the dial-out attempt failed because the SPE failed to detect a dial tone.</li> <li>• No Carrier</li> <li>• ACK</li> </ul>
CLASS SERVICE	Disconnect reasons are a s follows: <ul style="list-style-type: none"> <li>• ATH</li> <li>• Aborted</li> <li>• Connect Timeout</li> <li>• Sync Loss</li> </ul>

#### Related Commands

Command	Description
<b>show spe digital</b>	Displays history statistics of all digital SPEs, in summary form or for SPEs starting with a specified slot or a specified shelf/slot/range of SPEs.
<b>show spe digital active</b>	Displays active digital calls and digital statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital csr</b>	Displays digital call success rate (CSR) statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital summary</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.

## show spe digital summary

To display history statistics of all service processing elements (SPEs), a specified SPE, or the specified range of SPEs, use the **show spe digital summary** command in EXEC mode.

**show spe digital summary** [*slot* | *slot/spe*]

<b>Syntax Description</b>	<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5400, slot values range from 1 to 7 and SPE values range from 1 to 17. You must include the slash mark.

**Command Modes** EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.1(1)XD	This command was introduced.
	12.1(3)T	This command was implemented on the Cisco AS5400.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** Use the **show spe digital summary** command on the Cisco AS5350 and Cisco AS5400 with the NextPort dial feature card (DFC).



**Note**

This command is not supported on the Cisco AS5800 with the universal port card (UPC).

**Examples**

The following is sample output from the **show spe digital summary** command on the Cisco AS5400 with the NextPort DFC. This example displays active digital statistics for slot 5:

```
Router# show spe digital summary 5

Async5/00 - 5/107, TTY648 - 755
    209 incoming completes          397 incoming failures
      0 outgoing completes           0 outgoing failures
      0 failed dial attempts         0 ring no answers
      0 no dial tones                0 link failures
      0 watchdog timeouts            0 protocol errors
      0 dial timeouts

Transmit Speed Counters          :
Speed  Calls  Speed  Calls  Speed  Calls  Speed  Calls  Speed  Calls
64000   0 28800   0 14400   0  7200   0 1200   20
56000   0 24000   0 12000   0  4800  20  600   20
38400   0 19200  149  9600   0  2400   0
```

```

Receive Speed Counters      :
Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls
64000    0  28800    0  14400    0  7200     0  1200     20
56000    0  24000    0  12000    0  4800     20  600     20
38400    0  19200   149  9600     0  2400     0
.
.
.

```

Table 31 describes the significant fields shown in the display.

**Table 31** *show spe digital summary Field Descriptions*

Field	Description
A summary of SPE events also appears.	
incoming completes and failures	Total number of incoming connection requests that the SPE answered and successfully or unsuccessfully connected with the remote DCE device.
outgoing completes and failures	Total number of outgoing connection requests that the SPE dialed and successfully or unsuccessfully connected with the remote DCE device.
failed dial attempts	Number of times the SPE attempted to dial out but the call failed to leave the modem.
ring no answers	Number of times the SPE rang but did not answer the incoming call.
no dial tones	Number of times the dial-out attempt failed because the SPE failed to detect a dial tone.
link failures	Number of times the SPE detected a link failure.
watchdog timeouts	Number of times the SPE internal watchdog timer expired.
protocol errors	Number of times the SPE protocol failed to make a call connection
dial timeouts	Number of times the SPE timed out while attempting to dial.
Transmit Speed Counters	List of connection speeds that were sent by the SPE.
Receive Speed Counters	List of connection speeds that were received by the SPE.

#### Related Commands

Command	Description
<b>show spe digital</b>	Displays history statistics of all digital SPEs, in summary form or for SPEs starting with a specified slot or a specified shelf/slot/range of SPEs.
<b>show spe digital active</b>	Displays active digital calls and digital statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital csr</b>	Displays digital call success rate (CSR) statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital disconnect-reason</b>	Displays the local disconnection reasons for all digital calls on the SPEs, a specified SPE, or the specified range of SPEs.

# show spe log

To display the service processing element (SPE) system log, use the **show spe log** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe log [reverse | slot]
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe log [reverse | shelfslot]
```

Syntax Description	reverse	(Optional) Displays the SPE system log with the most recent event first.
	<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	<i>shelfslot</i>	(Optional) All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.

Command Modes	EXEC
---------------	------

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

Usage Guidelines	The <b>show spe log</b> command displays the slot history event log.
------------------	--

Examples	The following is sample output from the <b>show spe log</b> command on the Cisco AS5400 with the NextPort DFC:
----------	--

```
Router# show spe log

Slot 3 Events Log
 2d15h   : SPE State Event:
          Address: 0x3000000
          SPE     : 3/00
          Command: SPE_IMMEDIATE_DISABLE Complete
 2d14h   : SPE State Event:
          Address: 0x3000100
          SPE     : 3/06
          Command: SPE_IMMEDIATE_DISABLE Complete
```

```

2d13h   : SPE State Event:
        Address: 0x3000200
        SPE     : 3/12
        Command: SPE_IMMEDIATE_DISABLE Complete
00:00:26: SPE State Event:
        Address: 0x3000001
        SPE     : 3/01
        Command: SPE_IMMEDIATE_DISABLE Complete
Slot 4 Events Log
2d13h   : SPE State Event:
        Address: 0x4000000
        SPE     : 4/00
        Command: SPE_IMMEDIATE_DISABLE Complete
Slot 7 Events Log
2d15h   : Diag Post event:
        Address   : 0x7000204
        SPE       : 7/16
        Result    : SPE_POST_TEST_FAILED
        Test ID   : SPE_POWER_ON_SELF_TEST
        Diag Code : 0xFE01C004
        Data Format: ASCII
        Data Len  : 0

```

Table 32 describes the significant fields shown in the display.

**Table 32** *show spe log Field Descriptions*

Field	Description
Address	Address of the SPE
SPE	The slot and port number of the SPE.

#### Related Commands

Command	Description
<b>clear spe log</b>	Clears all event entries in the slot history event log.
<b>show spe log reverse</b>	Displays the slot history event log, with the most recent event first.

# show spe modem

To display the modem service history statistics for a specified service processing element (SPE), use the **show spe modem** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem {slot | slot/spe}
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem {shelf/slot | shelf/slot/spe}
```

Syntax Description		
<i>slot</i>	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.	
<i>slot/spe</i>	All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.	
<i>shelf/slot</i>	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.	
<i>shelf/slot/spe</i>	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 1 to 53. You must include the slash mark.	

Command Modes	
	EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

## Examples

The following is sample output from the **show spe modem** command on the Cisco AS5400 with the NextPort DFC:

```
Router# show spe modem 1/2

Asyncl/2/00 - 1/3/323, TTY972 - 1619
  4819 incoming completes          287 incoming failures
    0 outgoing completes          0 outgoing failures
    0 failed dial attempts        0 ring no answers          0 autotests
    0 no carriers                 11 dial timeouts          0 autotest fails
    0 no dial tones               0 link failures           0 fail count
    0 watchdog timeouts          2784 protocol errors      0 recovers
Transmit Speed Counters
```



```

Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls
60000    0      48000    431   38400    0      30666    0      12000    143
58000    0      46666    0      38000    4      29333    0      9600     5
56000    15     46000    56     37333    110   28800    700   7200    11
54666    0      45333    299   36000    84     28000    5      4800     2
54000    0      44000    226   34666    0      26400    266   2400     0
53333    122    42666    0      34000    39     24000    46     1200     3
52000    562    42000    68     33600    323   21600    27     300      0
50666    0      41333    38     33333    9      19200    38
50000    59     40000    65     32000    20     16800    12
49333    370    38666    0      31200    653   14400    5

Receive Speed Counters
Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls
38400    0      26400    2280  16800    11     7200     1      300      2
33600    113   24000    266   14400    139    4800     1
31200    215   21600    56     12000    4      2400     3
28800    1665  19200    47     9600     16     1200     0.

```

The following is sample output from the **show spe modem** command on the Cisco AS5800 with the universal port card:

```

Router# show spe modem 1/8/0

#SPE 1/08/00
Cisco Universal SPE; Fw: 0.00.06.81; Async1/8/00 - 1/8/05, TTY2916 - 2921
Last clearing of statistics counters      : never
  90 incoming completes                   0 incoming failures
   0 outgoing completes                   0 outgoing failures
   0 failed dial attempts                 0 ring no answers      0 autotests
   0 no carriers                          0 dial timeouts        0 autotest fails
   0 no dial tones                        0 link failures        0 fail count
   0 watchdog timeouts                    0 protocol errors

Transmit Speed Counters      :
Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls
60000    0      48000    0      38400    0      30666    0      12000    0
58000    0      46666    0      38000    0      29333    0      9600     0
56000    0      46000    0      37333    0      28800    0      7200     0
54666    0      45333    0      36000    0      28000    0      4800     0
54000    0      44000    0      34666    0      26400    0      2400     0
53333    0      42666    0      34000    0      24000    0      1200     0
52000    0      42000    0      33600    0      21600    0      300      0
50666    0      41333    0      33333    0      19200    0
50000    0      40000    0      32000    0      16800    0
49333    0      38666    0      31200    90     14400    0

Receive Speed Counters      :
Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls  Speed    Calls
38400    0      26400    0      16800    0      7200     0      300      0
33600    11     24000    0      14400    0      4800     0
31200    25     21600    0      12000    0      2400     0
28800    54     19200    0      9600     0      1200     0

```

Table 33 describes the significant fields shown in the display.

**Table 33** *show spe modem Command Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
Cisco Universal SPE	Firmware version installed on the SPE.
Last clearing of “show modem” counters	Last time the modem’s counters were cleared using the <b>clear modem counters</b> command.
Summary of modem and SPE events as follows:	
incoming completes and failures	Total number of incoming connection requests that the SPE answered and successfully or unsuccessfully connected with the remote DCE device.
outgoing completes and failures	Total number of outgoing connection requests that the SPE dialed and successfully or unsuccessfully connected with the remote DCE device.
failed dial attempts	Number of times the SPE attempted to dial out but the call failed to leave the modem.
ring no answers	Number of times the SPE rang but did not answer the call.
autotests	Number of times an autotest was run on the SPE.
no carriers	Number of times the SPE disconnected because no carrier was present.
dial timeouts	Number of times the SPE timed out while attempting to dial.
autotest fails	Number of times the SPE failed an autotest.
no dial tones	Number of times the dial-out attempt failed because the SPE failed to detect a dial tone.
link failures	Number of times the SPE detected a link failure.
fail count	Number of times the SPE failed.
watchdog timeouts	Number of times the SPE internal watchdog timer expired.
protocol errors	Number of times the SPE protocol failed to make a call connection.
Transmit Speed Counters	List of connection speeds that were sent by the SPE.
Receive Speed Counters	List of connection speeds that were received by the SPE.

#### Related Commands

Command	Description
<b>show modem</b>	Displays modem service history statistics for the MICA technologies modem.
<b>show spe</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.

## show spe modem active

To display the modem service statistics of all active calls on specified service processing elements (SPEs), use the **show spe modem active** command in EXEC mode.

### Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem active {slot | slot/spe}
```

### Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem active {shelfslot | shelfslot/spe}
```

Syntax Description	slot	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	slot/spe	All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
	shelfslot	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
	shelfslot/spe	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was introduced on the Cisco AS5350.
	12.2(2)XA	This command was supported on the Cisco AS5350.
	12.2(2)XB	This command was integrated into Cisco IOS Release 12.2(2)XB.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

### Examples

The following is sample output from the **show spe modem active** command on the Cisco AS5400 with the NextPort DFC. This example displays active modem statistics for slot 5, SPE 6:

```
Router# show spe modem active 5/6
```

```
SPE 5/06
Port Type Prot Comp Duration Tx/Rx Tx/Rx(Lvl) SNR Cfg Retrain
37 V.90 LAP-M V.42bis 95 3890/76 --/-11 38 In 0
```

The following is sample output from the **show spe modem active** command on the Cisco AS5800 with universal port card. This example displays active modem statistics for shelf 1, slot 8:

```
Router# show spe modem active 1/8
```

```
SPE 1/08/34
Port  Type      Prot    Comp    Duration  Tx/Rx(bps) Tx/Rx(Lvl) SNR Cfg  Retrain
209   V.34+      LAP-M   V.42bis 23       28800/31200 --/-13    37 In  0

SPE 1/08/35
Port  Type      Prot    Comp    Duration  Tx/Rx(bps) Tx/Rx(Lvl) SNR Cfg  Retrain
215   V.34+      LAP-M   V.42bis 12       28800/31200 --/-13    37 In  0

SPE 1/08/36
Port  Type      Prot    Comp    Duration  Tx/Rx(bps) Tx/Rx(Lvl) SNR Cfg  Retrain
216   V.34+      LAP-M   V.42bis 24       33600/31200 --/-36    38 In  0
217   ##         ##      ##      0        33600/300   --/19     37 In  0
218   ##         ##      ##      0        33600/300   --/19     37 In  0
219   ##         ##      ##      0        33600/300   --/19     35 In  0
```

Table 34 describes the significant fields shown in the display.

**Table 34** *show spe modem active Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
Port	Displays the port number.
Type	Modulation type.
Prot	The connection protocol used for the call.
Comp	The compression protocol used for the call.
Duration	Time duration of the call.
Tx/Rx(bps)	Transmission and receiving speed for the call in bits per second (bps).
Tx/Rx(Lvl)	Transmission and receiving level reduction for the call in decibels per milliwatt (dBm).
SNR	The signal-to-noise ratio for the call in dB.
Cfg	
Retrain	Number of retrain failures. A connection was lost and not reestablished after three attempts.

#### Related Commands

Command	Description
<b>show port operational-status</b>	Displays the operational status of a specific port or port range.
<b>show spe</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.

# show spe modem csr

To display the call success rate (CSR) for the specified service processing elements (SPEs), use the **show spe modem csr** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem csr {summary | slot | slot/spe}
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem csr {summary | shelfslot | shelfslot/spe}
```

Syntax Description	summary	Displays all call success rate statistics for all SPEs.
	<i>slot</i>	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/spe</i>	All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
	<i>shelfslot</i>	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
	<i>shelfslot/spe</i>	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash mark.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(2)XA	This command was implemented on the Cisco AS5350.
	12.2(2)X	This command was integrated into Cisco IOS Release 12.2(2)XB.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** The **show spe modem csr** command displays the modem CSR statistics for a specific SPE, range of SPEs, or all the SPEs. The **summary** keyword displays the CSR statistics for all SPEs.

**Examples**

The following are sample outputs from the **show spe modem csr** command on the Cisco AS5400 with the NextPort DFC:

```
Router# show spe modem csr 5/6
```

SPE	Avg Hold	Inc calls		Out calls		Failed	No	Succ
	Time	Succ	Fail	Succ	Fail	Dial	Answer	Pct
5/06	00:22:41	2	0	0	0	0	0	100%

```
Router# show spe modem csr 5/1 5/6
```

SPE	Avg Hold	Inc calls		Out calls		Failed	No	Succ
	Time	Succ	Fail	Succ	Fail	Dial	Answer	Pct
5/01	00:00:00	0	0	0	0	0	0	0%
5/02	00:00:00	0	0	0	0	0	0	0%
5/03	00:00:00	0	0	0	0	0	0	0%
5/04	00:00:00	0	0	0	0	0	0	0%
5/05	00:00:00	0	0	0	0	0	0	0%
5/06	00:22:48	2	0	0	0	0	0	100%

The following is sample output from the **show spe modem csr summary** command on the Cisco AS5800 with the universal port card:

```
Router# show spe modem csr summary
```

Avg Hold		Inc calls			Out calls			Failed	No	Succ
Time	Succ	Fail	Avail	Succ	Fail	Avail	Dial	Answer	Pct	
002631	4827	285	93	0	0	93	5	0	94%	

Table 35 describes the significant fields shown in the display.

**Table 35** *show spe modem csr Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
Avg Hold Time	The average hold time for the SPE.
Inc/Out calls	Calls dialing into and out of the modem: <ul style="list-style-type: none"> <li>Succ—Total call successfully connected.</li> <li>Fail—Total calls that did not successfully connect.</li> <li>Avail—Total modems available for use in the system.</li> </ul>
Failed Dial	The number of attempts the SPE failed to make a connection.
No Answer	Number of times the SPE rang but did not answer the call.
Succ Pct	The percentage of calls that were successfully connected.

**Related Commands**

Command	Description
<b>show spe</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe modem summary</b>	Displays a summary of modem statistics for the specified SPE or range of SPEs.

## show spe modem disconnect-reason

To display all modem disconnection reasons for the specified service processing element (SPE), use the **show spe modem disconnect-reason** command in EXEC mode.

**Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)**

```
show spe modem disconnect-reason {summary | slot | slot/spe}
```

**Cisco AS5800 with the Universal Port Card (UPC)**

```
show spe modem disconnect-reason {summary | shelfslot | shelfslot/spe}
```

Syntax Description	summary	Displays the disconnect reasons for all SPEs.
	<i>slot</i>	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/spe</i>	All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
	<i>shelfslot</i>	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
	<i>shelfslot/spe</i>	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 1 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was introduced on the Cisco AS5350.
	12.2(2)XA	This command was implemented on the Cisco AS5350.
	12.2(2)XB	This command was integrated into Cisco IOS Release 12.2(2)XB.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** Disconnection reasons are reasons why active calls are disconnected. The disconnect reasons are displayed with Class boundaries. The **show spe modem disconnect-reason** command is equivalent to the **show modem call stats** MCIA technologies modem command.

## show spe modem disconnect-reason

### Examples

The following is sample output from the **show spe modem disconnect-reason** command on the Cisco AS5400 with the NextPort DFC:

```
Router# show spe modem disconnect-reason 5/6

#SPE 5/06 :
====CLASS OTHER====  =====CLASS DSP=====  ===CLASS EC LCL===  ==CLASS EC FRMR===
Software Rst      0  No Carrier      0  No LR           0  Frmr Bad Cmd    0
EC Termntd       0  No ABT dtctd   0  LR Param1      0  Frmr Data       0
Bad MNP5 Rx      0  Trainup flr    0  LR Incmpt      0  Frmr Length     0
Bad V42B         0  Retrain Lt     0  Retrns Lt      0  Frmr Bad NR     0
Bad COP stat     0  ABT end flr    0  Inactivity     0
ATH              0
Aborted          0
Connect Tout     0  Hst NonSpec    0  No XID         0  LD LR Param1    0
Reset DSP        0  Hst Busy       0  XID Incmpt     0  LD LR Incmpt    0
                  Hst No answr   0  Disc           0  LD Retrns Lt    0
====CLASS EC Cmd===  Hst DTR        1  DM             0  LD Inactivty    0
Bad Cmd          0  Hst ATH        0  Bad NR         0  LD Protocol     0
                  Hst NoDialTn   0  SABME Online   0  LD User         0
=====N O N E=====  Hst No Carr    0  XID Online     0
None             0  Hst Ack        0  LR Online      0  TOTAL           1
```

The following is sample output from the **show spe modem disconnect-reason summary** command on the Cisco AS5800 with the universal port card:

```
Router# show spe modem disconnect-reason summary

====CLASS OTHER====  =====CLASS DSP=====  ===CLASS EC LCL===  ==CLASS EC FRMR===
Software Rst      0  No Carrier     21  No LR          0  Frmr Bad Cmd    0
EC Termntd       0  No ABT dtctd   0  LR Param1     0  Frmr Data       0
Bad MNP5 Rx      0  Trainup flr    26  LR Incmpt     0  Frmr Length     0
Bad V42B         12  Retrain Lt     0  Retrns Lt     37  Frmr Bad NR     0
Bad COP stat     0  ABT end flr    0  Inactivity     0
ATH              0
Aborted          0
Connect Tout     11  Hst NonSpec    799  No XID         5  LD LR Param1    0
Reset DSP        0  Hst Busy       0  XID Incmpt     0  LD LR Incmpt    0
                  Hst No answr   0  Disc           2718  LD Retrns Lt    0
====CLASS EC Cmd===  Hst DTR        870  DM             0  LD Inactivty    0
Bad Cmd          0  Hst ATH        0  Bad NR         0  LD Protocol     0
                  Hst NoDialTn   0  SABME Online   0  LD User         0
=====N O N E=====  Hst No Carr    0  XID Online     0
None             29  Hst Ack        0  LR Online      0  TOTAL           4555
```

### Related Commands

Command	Description
<b>show spe</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe modem summary</b>	Displays a summary of modem statistics for the specified SPE or range of SPEs.



## show spe modem high speed

To display the total number of connections within each high-speed modulation or codec for a specific range of service processing elements (SPEs), use the **show spe modem high speed** command in EXEC mode.

### Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem high speed {summary | slot | slot/spe}
```

### Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem high speed {summary | shelf/slot | shelf/slot/spe}
```

Syntax	Description
<b>summary</b>	Displays a brief list of all modulation connections negotiated.
<i>slot</i>	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
<i>slot/spe</i>	All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
<i>shelf/slot</i>	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
<i>shelf/slot/spe</i>	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

### Examples

The following is sample output from the **show spe modem high speed** command on the Cisco AS5400 with the NextPort DFC:

```
Router# show spe modem high speed 1/0
```

```
#SPE 1/0      :
Modln        V.FC          V.34          K56Flex       V.90          Modln
Speed   Tx    Rx      Tx    Rx      Tx    Rx      Tx    Rx    Speed
56000  -----  -----  -----  -----  000000  -----  000000  -----  56000
54667  -----  -----  -----  -----  -        -        0        -    54667
```

## show spe modem high speed

```

54000 ----- 0 - - - 54000
53333 ----- - - 0 - 53333
52000 ----- 0 - 0 - 52000
50667 ----- - - 0 - 50667
50000 ----- 0 - - - 50000
49333 ----- - - 0 - 49333
48000 ----- 0 - 0 - 48000
46667 ----- - - 0 - 46667
46000 ----- 0 - - - 46000
45333 ----- - - 0 - 45333
44000 ----- 0 - 0 - 44000
42667 ----- - - 0 - 42667
42000 ----- 0 - - - 42000
41333 ----- - - 0 - 41333
40000 ----- 0 - 0 - 40000
38667 ----- - - 0 - 48667
38000 ----- 0 - - - 38000
37333 ----- - - 0 - 37333
36000 ----- 0 - 0 - 36000
34667 ----- - - 0 - 34667
34000 ----- 0 - - - 34000
33600 ----- 0 0 - - 0 33600
33333 ----- - - - - 0 - 33333
32000 ----- - - 0 - 0 - 32000
31200 ----- 0 0 - 0 0 31200
30667 ----- - - - - 0 - 30667
29333 ----- - - - - 0 - 29333
28800 0 0 0 0 - 0 - 0 28800
28000 - - - - - - 0 - 28000
26400 0 0 0 0 - 0 - 0 26400
24000 0 0 0 0 - 0 - 0 24000
21600 0 0 0 0 - 0 - 0 21600
19200 0 0 0 0 - 0 - 0 19200
16800 0 0 0 0 - 0 - 0 16800
14400 0 0 0 0 - 0 - 0 14400
12000 - - 0 0 - 0 - 0 12000
9600 - - 0 0 - 0 - 0 9600
7200 - - 0 0 - 0 - 0 7200
4800 - - 0 0 - 0 - 0 4800
2400 - - 0 0 - - - 2400
TOTAL 0000000 0000000 0000000 0000000 TOTAL
#SPE 1/1 :
Modln V.FC V.34 K56Flex V.90 Modln
Speed Tx Rx Tx Rx Tx Rx Tx Rx Speed
56000 ----- 0000000 ----- 0000000 ----- 56000
54667 ----- - - 0 - 54667
54000 ----- 0 - - - 54000
53333 ----- - - 0 - 53333
52000 ----- 0 - 0 - 52000
50667 ----- - - 0 - 50667
50000 ----- 0 - - - 50000
49333 ----- - - 0 - 49333
48000 ----- 0 - 0 - 48000
46667 ----- - - 0 - 46667
46000 ----- 0 - - - 46000
45333 ----- - - 0 - 45333
44000 ----- 0 - 0 - 44000
42667 ----- - - 0 - 42667
42000 ----- 0 - - - 42000
41333 ----- - - 0 - 41333
40000 ----- 0 - 0 - 40000
38667 ----- - - 0 - 48667
38000 ----- 0 - - - 38000
37333 ----- - - 0 - 37333

```

```

36000 ----- 0 - 0 - 36000
34667 ----- - - 0 - 34667
34000 ----- 0 - - - 34000
33600 ----- 0 0 - - 0 33600
33333 ----- - - - - 0 - 33333
32000 ----- - - 0 - 0 - 32000
31200 ----- 0 0 - 0 - 0 31200
30667 ----- - - - - 0 - 30667
29333 ----- - - - - 0 - 29333
28800 0 0 0 0 - 0 - 0 28800
28000 - - - - - 0 - 28000
26400 0 0 0 0 - 0 - 0 26400
24000 0 0 0 0 - 0 - 0 24000
21600 0 0 0 0 - 0 - 0 21600
19200 0 0 0 0 - 0 - 0 19200
16800 0 0 0 0 - 0 - 0 16800
14400 0 0 0 0 - 0 - 0 14400
12000 - - 0 0 - 0 - 0 12000
9600 - - 0 0 - 0 - 0 9600
7200 - - 0 0 - 0 - 0 7200
4800 - - 0 0 - 0 - 0 4800
2400 - - 0 0 - - - 2400
TOTAL 0000000 0000000 0000000 0000000 TOTAL

```

The following is sample output from the **show spe modem high speed** command on the Cisco AS5800 with universal port card:

Router# **show spe modem high speed 1/8/1**

```

-- Indicates an invalid speed for a standard
#SPE 1/08/01 :
Modln      V.FC      V.34      K56Flex    V.90      Modln
Speed      Tx        Rx        Tx         Rx        Tx         Rx        Tx         Rx        Speed
60000 ----- 000000 000000 000000 000000 000000 000000 60000
58000 ----- 0 ----- 58000
56000 ----- 0 - 0 - 56000
54667 ----- - - 0 - 54667
54000 ----- 0 - - - 54000
53333 ----- - - 0 - 53333
52000 ----- 0 - 0 - 52000
50667 ----- - - 0 - 50667
50000 ----- 0 - - - 50000
49333 ----- - - 0 - 49333
48000 ----- 0 - 0 - 48000
46667 ----- - - 0 - 46667
46000 ----- 0 - - - 46000
45333 ----- - - 0 - 45333
44000 ----- 0 - 0 - 44000
42667 ----- - - 0 - 42667
42000 ----- 0 - - - 42000
41333 ----- - - 0 - 41333
40000 ----- 0 - 0 - 40000
38667 ----- - - 0 - 38667
38400 ----- - - - - 38400
38000 ----- 0 - - - 38000
37333 ----- - - 0 - 37333
36000 ----- 0 - 0 - 36000
34666 ----- - - 0 - 34666
34000 ----- 0 - - - 34000
33600 ----- 0 1 - - 0 33600
33333 ----- - - - - 0 - 33333
32000 ----- - - 0 - 0 - 32000
31200 ----- 6 1 - 0 - 0 31200
30667 ----- - - - - 0 - 30667

```

## ■ show spe modem high speed

```

29333 -----
28800      0      0      0      4      -      0      -      0 28800
28000      -      -      -      -      -      -      0      - 28000
26400      0      0      0      0      -      0      -      0 26400
24000      0      0      0      0      -      0      -      0 24000
21600      0      0      0      0      -      0      -      0 21600
19200      0      0      0      0      -      0      -      0 19200
16800      0      0      0      0      -      0      -      0 16800
14400      0      0      0      0      -      0      -      0 14400
12000      -      -      0      0      -      0      -      0 12000
 9600      -      -      0      0      -      0      -      0  9600
 7200      -      -      0      0      -      0      -      0  7200
 4800      -      -      0      0      -      0      -      0  4800
 2400      -      -      0      0      -      0      -      0  2400
TOTAL    0000000      0000012      0000000      0000000

```

Table 36 describes the significant fields shown in the display.

**Table 36** *show spe modem high speed Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
ModIn Speed	Modem line speed, in bits per second.
Tx	The number of sent calls that occurred at this speed.
Rx	The number of received calls that occurred at this speed.

---

**Related Commands**

Command	Description
<b>show spe modem low speed</b>	Displays the total number of connections within each low modulation or codec for the specified SPEs.

# show spe modem high standard

To display the total number of connections within each high modulation or codec for a specific range of service processing element (SPE), use the **show spe modem high standard** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem high standard {summary | slot | slot/spe}
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem high standard {summary | shelfslot | shelfslot/spe}
```

Syntax Description	summary	Displays a brief list of all modulation connections negotiated.
	<i>slot</i>	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/spe</i>	All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
	<i>shelfslot</i>	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
	<i>shelfslot/spe</i>	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

## Examples

The following is sample output from the show spe modem high standard command on the Cisco AS5400 with the NextPort DFC. This example displays standard low-speed connections for SPEs in slot 5:

```
Router# show spe modem high standard 5

SPE/Mod->   V.FC   V.34  K56Flex   V.90
5/00         0      1      2         1
5/01         0      0      0         0
5/02         0      0      0         0
5/03         0      0      0         0
```

## show spe modem high standard

```

5/04          0          0          0          0
5/05          0          0          0          0
5/06          0          0          0          2
5/07          0          0          0          0
5/08          0          0          0          0
5/09          0          0          0          0
5/10          0          0          0          0
5/11          0          0          0          0
5/12          0          0          0          0
5/13          0          0          0          0
5/14          0          0          0          0
5/15          0          0          0          0
5/16          0          0          0          0
5/17          0          0          0          0
TOTAL        00000000 00000001 00000002 00000003

```

The following is sample output from the **show spe modem high standard** command on the Cisco AS5800 with the universal port card. This example displays standard low-speed connections for SPEs in slot 8:

```

Router# show spe modem high standard 1/8/1

SPE/Mod->    V.FC      V.34  K56Flex  V.90
1/08/01      0          6          0          0
TOTAL        00000000 00000006 00000000 00000000

```

[Table 37](#) describes the significant fields shown in the display.

**Table 37** *show spe modem high standard Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
Mod	The modem type.

### Related Commands

Command	Description
<b>show spe modem low standard</b>	Displays the total number of connections within each low modulation or codec for the SPE.

# show spe modem low speed

To display the total number of connections within each low-speed modulation or codec for the specified service processing elements (SPEs), use the **show spe modem low speed** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem low speed {summary | {slot | slot/spe} [slot | slot/spe]}
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem low speed {summary | {shelfslot | shelfslot/spe} [shelfslot | shelfslot/spe]}
```

Syntax Description	summary	Displays a brief list of all modulation connections negotiated.
	<i>slot</i>	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. A range of slots can be specified by entering a second value for the <i>slot</i> argument.
	<i>slot/spe</i>	Ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark. A range of ports can be specified by entering a second value for the <i>slot/spe</i> argument.
	<i>shelfslot</i>	Ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark. A range of slots can be specified by entering a second value for the <i>shelfslot</i> argument.
	<i>shelfslot/spe</i>	Ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks. A range of ports can be specified by entering a second value for the <i>shelfslot/spe</i> argument.

Command Modes	EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

## Examples

The following is sample output from the **show spe modem low speed** command on the Cisco AS5400 with the NextPort DFC. This example displays standard low-speed connections:

```
Router# show spe modem low speed 1/0
```

## ■ show spe modem low speed

```

#SPE 1/0 :
Speed B103 V.21 B212 V.22 V.22b <-- MODEM FAX -->
V.32 V.32b V.27t V.29 V.17
14400 ----- 30 ----- 0
12000 ----- 0 ----- 0
9600 ----- 0 0 ----- 0 0
7200 ----- - 0 ----- 0 0
4800 ----- 0 0 ----- 0 0
2400 ----- 0 ----- 0 -----
1200 ----- 0 0 6 -----
600 -----
300 0 0 -----
TOTAL 000000 000000 000000 000000 000006 000000 000030 000000 000000 000000
#SPE 1/1 :
Speed B103 V.21 B212 V.22 V.22b <-- MODEM FAX -->
V.32 V.32b V.27t V.29 V.17
14400 ----- 30 ----- 0
12000 ----- 0 ----- 0
9600 ----- 0 0 ----- 0 0
7200 ----- - 0 ----- 0 0
4800 ----- 0 0 ----- 0 0
2400 ----- 0 ----- 0 -----
1200 ----- 0 0 6 -----
600 -----
300 0 0 -----
TOTAL 000000 000000 000000 000000 000006 000000 000030 000000 000000 000000

```

The following is sample output from the **show spe modem low speed** command on the Cisco AS5800 with the universal port card. This example displays standard low-speed connections for SPEs in slot 8:

```
Router# show spe modem low speed 1/8/0 1/8/6
```

```

-- Indicates an invalid speed for a standard
#SPE 1/08/00 :
Speed B103 V.21 B212 V.22 V.22b <-- MODEM FAX -->
V.23 V.32 V.32b V.27t V.29 V.17
14400 ----- 0 ----- 0
12000 ----- 0 ----- 0
9600 ----- 0 0 ----- 0 0
7200 ----- - 0 ----- 0 0
4800 ----- 0 0 ----- 0 0
2400 ----- 0 ----- 0 -----
1200 ----- 0 0 0 0 -----
300 0 0 -----
TOTAL 000000 000000 000000 000000 000000 000000 000000 000000 000000 000000

```

Table 38 describes the significant fields shown in the display.

**Table 38** *show spe modem low speed Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
Speed	The modem line speed, in bits per second.
MODEM	The modem type.
FAX	The fax type.

### Related Commands

Command	Description
<b>show spe modem high standard</b>	Displays the total number of connections within each high modulation or codec for a specific range of SPEs.



# show spe modem low standard

To display the total number of connections within each low modulation or codec for the specified service processing elements (SPEs), use the **show spe modem low standard** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem low standard {summary | slot | slot/spe}
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem low standard {summary | shelfslot | shelfslot/spe}
```

Syntax Description	summary	Displays a brief list of all modulation connections negotiated.
	<i>slot</i>	All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	<i>slot/spe</i>	All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
	<i>shelfslot</i>	All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
	<i>shelfslot/spe</i>	All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

## Examples

The following example displays standard low-speed connections for SPEs in slot 5 on the Cisco AS5400:

```
Router# show spe modem low standard 5
SPE/Mod-> B103 V.21 B212 V.22 V.22b <-- MODEM FAX -->
          V.23 V.32 V.32b V.27t V.29 V.17
5/00      0    0    0    0    0    0    0    0    0    0    0
5/01      0    0    0    0    0    0    0    0    0    0    0
5/02      0    0    0    0    0    0    0    0    0    0    0
5/03      0    0    0    0    0    0    0    0    0    0    0
5/04      0    0    0    0    0    0    0    0    0    0    0
```

## show spe modem low standard

```

5/05      0    0    0    0    0    0    0    0    0    0    0
5/06      0    0    0    0    0    0    0    0    0    0    0
5/07      0    0    0    0    0    0    0    0    0    0    0
5/08      0    0    0    0    0    0    0    0    0    0    0
5/09      0    0    0    0    0    0    0    0    0    0    0
5/10      0    0    0    0    0    0    0    0    0    0    0
5/11      0    0    0    0    0    0    0    0    0    0    0
5/12      0    0    0    0    0    0    0    0    0    0    0
5/13      0    0    0    0    0    0    0    0    0    0    0
5/14      0    0    0    0    0    0    0    0    0    0    0
5/15      0    0    0    0    0    0    0    0    0    0    0
5/16      0    0    0    0    0    0    0    0    0    0    0
5/17      0    0    0    0    0    0    0    0    0    0    0
TOTAL     00000 00000 00000 00000 00000 00000 00000 00000 00000 00000 00000

```

The following example displays standard low-speed connections for SPEs in slot 8 on the Cisco AS5800:

```

Router# show spe modem low standard 1/8
          <--          MODEM          FAX          -->
SPE/Mod-> B103  V.21  B212  V.22  V.22b  V.23  V.32  V.32b  V.27t  V.29  V.17
1/08/00      0    0    0    0    0    0    0    0    0    0    0
1/08/01      0    0    0    0    0    0    0    0    0    0    0
1/08/02      0    0    0    0    0    0    0    0    0    0    0
1/08/03      0    0    0    0    0    0    0    0    0    0    0
1/08/04      0    0    0    0    0    0    0    0    0    0    0
1/08/05      0    0    0    0    0    0    0    0    0    0    0
1/08/06      0    0    0    0    0    0    0    0    0    0    0
1/08/07      0    0    0    0    0    0    0    0    0    0    0
1/08/08      0    0    0    0    0    0    0    0    0    0    0
1/08/09      0    0    0    0    0    0    0    0    0    0    0
1/08/10      0    0    0    0    0    0    0    0    0    0    0
1/08/11      0    0    0    0    0    0    0    0    0    0    0
1/08/12      0    0    0    0    0    0    0    0    0    0    0
1/08/13      0    0    0    0    0    0    0    0    0    0    0
1/08/14      0    0    0    0    0    0    0    0    0    0    0
1/08/15      0    0    0    0    0    0    0    0    0    0    0
1/08/16      0    0    0    0    0    0    0    0    0    0    0
1/08/17      0    0    0    0    0    0    0    0    0    0    0
1/08/18      0    0    0    0    0    0    0    0    0    0    0
1/08/19      0    0    0    0    0    0    0    0    0    0    0
1/08/20      0    0    0    0    0    0    0    0    0    0    0
          <--          MODEM          FAX          -->
SPE/Mod-> B103  V.21  B212  V.22  V.22b  V.23  V.32  V.32b  V.27t  V.29  V.17
1/08/21      0    0    0    0    0    0    0    0    0    0    0
1/08/22      0    0    0    0    0    0    0    0    0    0    0
1/08/23      0    0    0    0    0    0    0    0    0    0    0
1/08/24      0    0    0    0    0    0    0    0    0    0    0
1/08/25      0    0    0    0    0    0    0    0    0    0    0
1/08/26      0    0    0    0    0    0    0    0    0    0    0
1/08/27      0    0    0    0    0    0    0    0    0    0    0
1/08/28      0    0    0    0    0    0    0    0    0    0    0
1/08/29      0    0    0    0    0    0    0    0    0    0    0
1/08/30      0    0    0    0    0    0    0    0    0    0    0
1/08/31      0    0    0    0    0    0    0    0    0    0    0
1/08/32      0    0    0    0    0    0    0    0    0    0    0
1/08/33      0    0    0    0    0    0    0    0    0    0    0
1/08/34      0    0    0    0    0    0    0    0    0    0    0
1/08/35      0    0    0    0    0    0    0    0    0    0    0
1/08/36      0    0    0    0    0    0    0    0    0    0    0
1/08/37      0    0    0    0    0    0    0    0    0    0    0
1/08/38      0    0    0    0    0    0    0    0    0    0    0
1/08/39      0    0    0    0    0    0    0    0    0    0    0
1/08/40      0    0    0    0    0    0    0    0    0    0    0

```

```

1/08/41      0    0    0    0    0    0    0    0    0    0    0    0
1/08/42      0    0    0    0    0    0    0    0    0    0    0    0
                <--          MODEM          FAX          -->
SPE/Mod->  B103  V.21  B212  V.22  V.22b  V.23  V.32  V.32b  V.27t  V.29  V.17
1/08/43      0    0    0    0    0    0    0    0    0    0    0    0
1/08/44      0    0    0    0    0    0    0    0    0    0    0    0
1/08/45      0    0    0    0    0    0    0    0    0    0    0    0
1/08/46      0    0    0    0    0    0    0    0    0    0    0    0
1/08/47      0    0    0    0    0    0    0    0    0    0    0    0
1/08/48      0    0    0    0    0    0    0    0    0    0    0    0
1/08/49      0    0    0    0    0    0    0    0    0    0    0    0
1/08/50      0    0    0    0    0    0    0    0    0    0    0    0
1/08/51      0    0    0    0    0    0    0    0    0    0    0    0
1/08/52      0    0    0    0    0    0    0    0    0    0    0    0
1/08/53      0    0    0    0    0    0    0    0    0    0    0    0
TOTAL      00000 00000 00000 00000 00000 00000 00000 00000 00000 00000 00000 00000

```

Table 39 describes the significant fields shown in the displays.

**Table 39** *show spe modem low standard Field Descriptions*

Field	Description
SPE	The slot and port number of the SPE.
MODEM	The modem type.
FAX	The fax type.

#### Related Commands

Command	Description
<b>show spe modem high standard</b>	Displays the total number of connections within each high modulation or codec for a specific range of SPE.

## show spe modem summary

To display a summary of modem statistics for the specified service processing element (SPE) or range of SPEs, use the **show spe modem summary** command in EXEC mode.

### Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe modem summary [slot | slot/spe]
```

### Cisco AS5800 with the Universal Port Card (UPC)

```
show spe modem summary [shelfslot | shelfslot/spe]
```

Syntax Description	
<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
<i>shelfslot</i>	(Optional) All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
<i>shelfslot/spe</i>	(Optional) All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

Command Modes	
	EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was introduced on the Cisco AS5350.
	12.2(2)XA	Disconnection reasons and states information were added.
	12.2(2)XB	This command was integrated into Cisco IOS Release 12.2(2)XB.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

### Examples

The following is sample output from the **show spe modem summary** command on the Cisco AS5400:

```
Router# show spe modem summary
```

```
Asyncl/00 - 5/107, TTY216 - 755
    786 incoming completes          4 incoming failures
    0 outgoing completes           0 outgoing failures
    0 failed dial attempts         0 ring no answers      0 autotests
```

```

0 no carriers          0 dial timeouts      0 autotest fails
0 no dial tones       0 link failures      0 fail count
0 watchdog timeouts   0 protocol errors    0 recovers

```

```

Transmit Speed Counters      :
Speed   Calls  Speed   Calls  Speed   Calls  Speed   Calls  Speed   Calls
60000   0    48000   0    38400   0    30666   0    12000   0
58000   0    46666   0    38000   0    29333   0    9600    0
56000   0    46000   0    37333   0    28800   10   7200    0
54666   0    45333   0    36000   0    28000   0    4800    0
54000   0    44000   0    34666   0    26400   0    2400    0
53333   0    42666   0    34000   0    24000   0    1200    0
52000   0    42000   0    33600   631  21600   0    300     0
50666   0    41333   0    33333   0    19200   0
50000   0    40000   0    32000   0    16800   0
49333   0    38666   0    31200   145  14400   0

```

```

Receive Speed Counters      :
Speed   Calls  Speed   Calls  Speed   Calls  Speed   Calls  Speed   Calls
38400   0    26400   0    16800   0    7200    0    300     0
33600   786  24000   0    14400   0    4800    0
31200   0    21600   0    12000   0    2400    0
28800   0    19200   0    9600    0    1200    0

```

The following is sample output from the **show spe modem summary** command on the Cisco AS5800:

```

Router# show spe modem summary

Async1/2/00 - 1/3/323, TTY972 - 1619
  4827 incoming completes      284 incoming failures
    0 outgoing completes      0 outgoing failures
    0 failed dial attempts     0 ring no answers      0 autotests
    0 no carriers              11 dial timeouts       0 autotest fails
    0 no dial tones            0 link failures        0 fail count
    0 watchdog timeouts        2787 protocol errors   0 recovers

Transmit Speed Counters
Speed   Calls  Speed   Calls  Speed   Calls  Speed   Calls  Speed  Calls
60000   0    48000   432  38400   0    30666   0    12000  143
58000   0    46666   0    38000   4    29333   0    9600   5
56000   15   46000   56   37333   111  28800   700  7200  11
54666   0    45333   299  36000   84   28000   5    4800   2
54000   0    44000   227  34666   0    26400   267  2400   0
53333   123  42666   0    34000   39   24000   46   1200   3
52000   563  42000   68   33600   323  21600   27   300    0
50666   0    41333   38   33333   9    19200   38
50000   59   40000   65   32000   20   16800   12
49333   371  38666   0    31200   654  14400   5

Receive Speed Counters
Speed   Calls  Speed   Calls  Speed   Calls  Speed   Calls  Speed  Calls
38400   0    26400   2286  16800   11   7200    1    300    2
33600   113  24000   267   14400   139  4800    1
31200   216  21600   56   12000   4    2400    3
28800   1665 19200   47   9600    16   1200    0

```

Table 40 describes the significant fields shown in the display.

**Table 40** *show spe modem summary Field Descriptions*

Field	Description
Summary of modem and SPE events follows:	
incoming completes and failures	Total number of incoming connection requests that the SPE answered and successfully or unsuccessfully connected with the remote DCE device.
outgoing completes and failures	Total number of outgoing connection requests that the SPE dialed and successfully or unsuccessfully connected with the remote DCE device.
failed dial attempts	Number of times the SPE attempted to dial out but the call failed to leave the modem.
ring no answers	Number of times the SPE rang but did not answer the call.
autotests	Number of times an autotest was run on the SPE.
no carriers	Number of times the SPE disconnected because no carrier was present.
dial timeouts	Number of times the SPE timed out while attempting to dial.
autotest fails	Number of times the SPE failed an autotest.
no dial tones	Number of times the dial-out attempt failed because the SPE failed to detect a dial tone.
link failures	Number of times the SPE detected a link failure.
fail count	Number of times the SPE failed.
watchdog timeouts	Number of times the SPE internal watchdog timer expired.
protocol errors	Number of times the SPE protocol failed to make a call connection.
recovers	Number of times the SPE recovered.
Transmit Speed Counters	List of connection speeds that were sent by the SPE.
Receive Speed Counters	List of connection speeds that were received by the SPE.
Transmit Speed Counters	List of connection speeds that were sent by the SPE.
Receive Speed Counters	List of connection speeds that were received by the SPE.

#### Related Commands

Command	Description
<b>show port operational-status</b>	Displays the operational status of a specific port or range of ports.
<b>show spe</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.
<b>show spe digital</b>	Displays history statistics of all digital SPEs, in summary form or for SPEs starting with a specified slot or a specified shelf/slot/range of SPEs.
<b>show spe modem disconnect-reason</b>	Displays all modem disconnection reasons for the specified SPE or range of SPEs.

# show spe recovery

To display service processing element (SPE) recovery statistics, use the **show spe recovery** command in EXEC mode.

## Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe recovery [slot | slot/spe]
```

## Cisco AS5800 with the Universal Port Card (UPC)

```
show spe recovery [shelfslot | shelfslot/spe]
```

Syntax Description	slot	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7.
	slot/spe	(Optional) All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark.
	shelfslot	(Optional) All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark.
	shelfslot/spe	(Optional) All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks.

**Command Modes** EXEC

Command History	Release	Modification
	12.1(1)XD	This command was introduced on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** Use this command to display a list of recovered SPEs.

**Examples** The following is sample output from the **show spe recovery** command on the Cisco AS5400:

```
Router# show spe recovery

SPE#      Session Abort  Session NAK  Call Failure
1/00      0              0            0
1/01      0              0            0
1/02      0              0            0
1/03      0              0            0
```

## ■ show spe recovery

1/04	0	0	0
1/05	0	0	0
1/06	0	0	0
1/07	0	0	0
1/08	0	0	0
1/09	0	0	0
1/10	0	0	0
1/11	0	0	0
1/12	0	0	0
1/13	0	0	0
1/14	0	0	0
1/15	0	0	0
1/16	0	0	0
1/17	0	0	0

The following is sample output from the **show spe recovery** command on the Cisco AS5800:

Router# **show spe recovery 1/8**

SPE#	Session Abort	Session NAK	Call Failure
1/08/00	0	0	0
1/08/01	0	0	0
1/08/02	0	0	0
1/08/03	0	0	0
1/08/04	0	0	0
1/08/05	0	0	0
1/08/06	0	0	0
1/08/07	0	0	0
1/08/08	0	0	0
1/08/09	0	0	0
1/08/10	0	0	0
1/08/11	0	0	0
1/08/12	0	0	0
1/08/13	0	0	0
1/08/14	0	0	0
1/08/15	0	0	0
1/08/16	0	0	0
1/08/17	0	0	0
1/08/18	0	0	0
1/08/19	0	0	0
1/08/20	0	0	0
1/08/21	0	0	0
1/08/22	0	0	0
1/08/23	0	0	0
1/08/24	0	0	0
1/08/25	0	0	0
1/08/26	0	0	0
1/08/27	0	0	0
1/08/28	0	0	0
1/08/29	0	0	0
1/08/30	0	0	0
1/08/31	0	0	0
1/08/32	0	0	0
1/08/33	0	0	0
1/08/34	0	0	0
1/08/35	0	0	0
1/08/36	0	0	0
1/08/37	0	0	0
1/08/38	0	0	0
1/08/39	0	0	0
1/08/40	0	0	0
1/08/41	0	0	0
1/08/42	0	0	0
1/08/43	0	0	0



1/08/44	0	0	0
1/08/45	0	0	0
1/08/46	0	0	0
1/08/47	0	0	0
1/08/48	0	0	0
1/08/49	0	0	0
1/08/50	0	0	0
1/08/51	0	0	0
1/08/52	0	0	0
1/08/53	0	0	0

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show spe</b>	Displays SPE status.

## show spe version

To display the firmware version on a service processing element (SPE), use the **show spe version** command in EXEC mode.

### Cisco AS5350 and Cisco AS5400 with the NextPort Dial Feature Card (DFC)

```
show spe version [slot | slot/spe] [slot | slot/spe]
```

### Cisco AS5800 with the Universal Port Card (UPC)

```
show spe version [shelfslot | shelfslot/spe] [shelfslot | shelfslot/spe]
```

Syntax Description		
<i>slot</i>	(Optional) All ports on the specified slot. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. A range of slots can be specified by entering a second value for the <i>slot</i> argument.	
<i>slot/spe</i>	(Optional) All ports on the specified slot and SPE. For the Cisco AS5350 slot values range from 1 to 3. For the Cisco AS5400, slot values range from 1 to 7. SPE values range from 1 to 17. You must include the slash mark. A range of ports can be specified by entering a second value for the <i>slot/spe</i> argument.	
<i>shelfslot</i>	(Optional) All ports on the specified shelf and slot. For the Cisco AS5800, shelf values range from 0 to 1 and UPC slot values range from 2 to 11. You must include the slash mark. A range of slots can be specified by entering a second value for the <i>shelfslot</i> argument.	
<i>shelfslot/spe</i>	(Optional) All ports on the specified SPE. For the Cisco AS5800, shelf values range from 0 to 1, slot values range from 2 to 11, and SPE values range from 0 to 53. You must include the slash marks. A range of ports can be specified by entering a second value for the <i>shelfslot/spe</i> argument.	

Command Modes	EXEC
---------------	------

Command History	Release	Modification
	12.0(7)T	This command was introduced.
	12.1(1)XD	This command was implemented on the Cisco AS5400.
	12.1(3)T	This command was implemented on the Cisco AS5800.
	12.1(5)XM1	This command was implemented on the Cisco AS5350.
	12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and support was added for the Cisco AS5350.

**Usage Guidelines** Use the **show spe version** command to display the firmware version running on a specific SPE. If the *shelfslot/spe* argument is specified, the firmware version for the identified SPE or range of SPEs is displayed. If the *slot* argument is specified, the firmware version for the identified SPEs in this slot or range of slots is displayed. If no argument is specified, all SPE versions are displayed.

The **show spe version** command also displays the version to firmware file mappings.

The **show spe version** command is similar to the **show modem mapping** MICA technologies modem command.

### Examples

The following is sample output from the **show spe version** command on a Cisco AS5400:

```
Router# show spe version

IOS-Bundled Default Firmware-Filename
=====
system:/ucode/np_spe_firmware1

Version  Firmware-Type
=====  =====
0.6.5.5  SPE firmware
0.0.0.0  Portware

On-Flash Firmware-Filename
=====
flash:np.spe

Version  Firmware-Type
=====  =====
0.6.4.5  SPE firmware

SPE-#  SPE-Type  SPE-Port-Range  Version  UPG Firmware-Filename
4/00   CSMV6     0000-0005      0.6.5.5  N/A np.spe
4/01   CSMV6     0006-0011      0.6.5.5  N/A ios-bundled default
4/02   CSMV6     0012-0017      0.6.5.5  N/A ios-bundled default
4/03   CSMV6     0018-0023      0.6.5.5  N/A ios-bundled default
4/04   CSMV6     0024-0029      0.6.5.5  N/A ios-bundled default
4/05   CSMV6     0030-0035      0.6.5.5  N/A ios-bundled default
4/06   CSMV6     0036-0041      0.6.5.5  N/A ios-bundled default
4/07   CSMV6     0042-0047      0.6.5.5  N/A ios-bundled default
4/08   CSMV6     0048-0053      0.6.5.5  N/A ios-bundled default
4/09   CSMV6     0054-0059      0.6.5.5  N/A ios-bundled default
4/10   CSMV6     0060-0065      0.6.5.5  N/A ios-bundled default
4/11   CSMV6     0066-0071      0.6.5.5  N/A ios-bundled default
4/12   CSMV6     0072-0077      0.6.5.5  N/A ios-bundled default
4/13   CSMV6     0078-0083      0.6.5.5  N/A ios-bundled default
4/14   CSMV6     0084-0089      0.6.5.5  N/A ios-bundled default
4/15   CSMV6     0090-0095      0.6.5.5  N/A ios-bundled default
4/16   CSMV6     0096-0101      0.6.5.5  N/A ios-bundled default
4/17   CSMV6     0102-0107      0.6.5.5  N/A ios-bundled default
```

The following is sample output from the **show spe version** command on a Cisco AS5800:

```
Router# show spe version 1/8

IOS-Bundled Default Firmware-Filename
=====
system:/ucode/np_spe_firmware1
system:/ucode/mica_board_firmware

Version  Firmware-Type
=====  =====
0.0.6.81 SPE firmware
2.7.2.0  Mica Portware

On-Flash Firmware-Filename
=====
slot0:np_6_81.spe
slot0:np_6_80.spe
slot0:mica-modem-pw.2.7.1.1.bin
slot0:mica-modem-pw.2.7.2.0.bin

Version  Firmware-Type
=====  =====
0.0.6.81 SPE firmware
0.0.6.80 SPE firmware
2.7.1.0  Mica Portware
2.7.2.0  Mica Portware

SPE-#  SPE-Type  SPE-Port-Range  Version  UPG Firmware-Filename
1/08/00  CSMV6     0000-0005      0.0.6.81  N/A ios-bundled default
1/08/01  CSMV6     0006-0011      0.0.6.81  N/A ios-bundled default
1/08/02  CSMV6     0012-0017      0.0.6.81  N/A ios-bundled default
1/08/03  CSMV6     0018-0023      0.0.6.81  N/A ios-bundled default
1/08/04  CSMV6     0024-0029      0.0.6.81  N/A ios-bundled default
1/08/05  CSMV6     0030-0035      0.0.6.81  N/A ios-bundled default
1/08/06  CSMV6     0036-0041      0.0.6.81  N/A ios-bundled default
1/08/07  CSMV6     0042-0047      0.0.6.81  N/A ios-bundled default
1/08/08  CSMV6     0048-0053      0.0.6.81  N/A ios-bundled default
```

```

1/08/09   CSMV6      0054-0059   0.0.6.81   N/A ios-bundled default
1/08/10   CSMV6      0060-0065   0.0.6.81   N/A ios-bundled default
1/08/11   CSMV6      0066-0071   0.0.6.81   N/A ios-bundled default
1/08/12   CSMV6      0072-0077   0.0.6.81   N/A ios-bundled default
1/08/13   CSMV6      0078-0083   0.0.6.81   N/A ios-bundled default
1/08/14   CSMV6      0084-0089   0.0.6.81   N/A ios-bundled default
1/08/15   CSMV6      0090-0095   0.0.6.81   N/A ios-bundled default
1/08/16   CSMV6      0096-0101   0.0.6.81   N/A ios-bundled default
1/08/17   CSMV6      0102-0107   0.0.6.81   N/A ios-bundled default
1/08/18   CSMV6      0108-0113   0.0.6.81   N/A ios-bundled default
1/08/19   CSMV6      0114-0119   0.0.6.81   N/A ios-bundled default
1/08/20   CSMV6      0120-0125   0.0.6.81   N/A ios-bundled default
1/08/21   CSMV6      0126-0131   0.0.6.81   N/A ios-bundled default
1/08/22   CSMV6      0132-0137   0.0.6.81   N/A ios-bundled default
1/08/23   CSMV6      0138-0143   0.0.6.81   N/A ios-bundled default
1/08/24   CSMV6      0144-0149   0.0.6.81   N/A ios-bundled default
1/08/25   CSMV6      0150-0155   0.0.6.81   N/A ios-bundled default
1/08/26   CSMV6      0156-0161   0.0.6.81   N/A ios-bundled default
1/08/27   CSMV6      0162-0167   0.0.6.81   N/A ios-bundled default
1/08/28   CSMV6      0168-0173   0.0.6.81   N/A ios-bundled default
1/08/29   CSMV6      0174-0179   0.0.6.81   N/A ios-bundled default
1/08/30   CSMV6      0180-0185   0.0.6.81   N/A ios-bundled default
1/08/31   CSMV6      0186-0191   0.0.6.81   N/A ios-bundled default
1/08/32   CSMV6      0192-0197   0.0.6.81   N/A ios-bundled default
1/08/33   CSMV6      0198-0203   0.0.6.81   N/A ios-bundled default
1/08/34   CSMV6      0204-0209   0.0.6.81   N/A ios-bundled default
1/08/35   CSMV6      0210-0215   0.0.6.81   N/A ios-bundled default
1/08/36   CSMV6      0216-0221   0.0.6.81   N/A ios-bundled default
1/08/37   CSMV6      0222-0227   0.0.6.81   N/A ios-bundled default
1/08/38   CSMV6      0228-0233   0.0.6.81   N/A ios-bundled default
1/08/39   CSMV6      0234-0239   0.0.6.81   N/A ios-bundled default
1/08/40   CSMV6      0240-0245   0.0.6.81   N/A ios-bundled default
1/08/41   CSMV6      0246-0251   0.0.6.81   N/A ios-bundled default
1/08/42   CSMV6      0252-0257   0.0.6.81   N/A ios-bundled default
1/08/43   CSMV6      0258-0263   0.0.6.81   N/A ios-bundled default
1/08/44   CSMV6      0264-0269   0.0.6.81   N/A ios-bundled default
1/08/45   CSMV6      0270-0275   0.0.6.81   N/A ios-bundled default
1/08/46   CSMV6      0276-0281   0.0.6.81   N/A ios-bundled default
1/08/47   CSMV6      0282-0287   0.0.6.81   N/A ios-bundled default
1/08/48   CSMV6      0288-0293   0.0.6.81   N/A ios-bundled default
1/08/49   CSMV6      0294-0299   0.0.6.81   N/A ios-bundled default
1/08/50   CSMV6      0300-0305   0.0.6.81   N/A ios-bundled default
1/08/51   CSMV6      0306-0311   0.0.6.81   N/A ios-bundled default
1/08/52   CSMV6      0312-0317   0.0.6.81   N/A ios-bundled default
1/08/53   CSMV6      0318-0323   0.0.6.81   N/A ios-bundled default

```

The following examples show various implementations of the **show spe version** command to display information about the available SPE sources and modem resources:

```
Router# show spe version
```

```

IOS-Bundled Default Firmware-Filename      Version  Firmware-Type
=====
system:/ucode/mica_board_firmware          2.0.2.0  Mica Boardware
system:/ucode/mica_port_firmware           2.6.2.0  Mica Portware
system:/ucode/microcom_firmware            5.1.20   Microcom F/W and DSP

On-Flash Firmware-Filename                 Version  Firmware-Type
=====
flash:portware.2620.ios                     2.6.2.0  Mica Portware
flash:mcom-modem-firmware.3.1.30.bin         3.1.30   Microcom Firmware
flash:mcom-fw-dsp.5.1.9_47.22.bin           5.1.9    Microcom F/W and DSP
flash:R0620.ios                             0.6.2.0  Mica Portware

```

```
flash:pw2710.ios                2.7.1.0 Mica Portware
flash:mica-modem-pw_2_7_1_0.bin 2.7.1.0 Mica Portware
```

SPE-#	SPE-Type	SPE-Range	Version	Upgrade	Firmware-Filename
1/0	MICA-HMM	1/0 - 1/5	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/1	MICA-HMM	1/6 - 1/11	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/2	MICA-HMM	1/12 - 1/17	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/3	MICA-HMM	1/18 - 1/23	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/5	MICA-HMM	1/30 - 1/35	2.7.1.0	N/A	system:/ucode/mica_port_firmware
1/6	MICA-HMM	1/36 - 1/41	2.7.1.0	N/A	system:/ucode/mica_port_firmware
1/7	MICA-HMM	1/42 - 1/47	2.7.1.0	N/A	system:/ucode/mica_port_firmware
1/9	MICA-HMM	1/54 - 1/59	2.7.1.0	N/A	flash:/pw2710.ios
2/0	MCOM-V90	2/0	5.1(20)	N/A	system:/ucode/microcom_firmware
2/1	MCOM-V90	2/1	5.1(20)	N/A	system:/ucode/microcom_firmware
2/2	MCOM-V90	2/2	5.1(20)	N/A	system:/ucode/microcom_firmware
2/3	MCOM-V90	2/3	5.1(20)	N/A	system:/ucode/microcom_firmware
2/4	MCOM-V90	2/4	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/5	MCOM-V90	2/5	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/6	MCOM-V90	2/6	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/7	MCOM-V90	2/7	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/8	MCOM-V90	2/8	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/9	MCOM-V90	2/9	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/10	MCOM-V90	2/10	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/11	MCOM-V90	2/11	5.1(9)	N/A	flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/12	MCOM-V34	2/12	2.3(6)	N/A	feature_card_flash
2/13	MCOM-V34	2/13	2.3(6)	N/A	feature_card_flash
2/14	MCOM-V34	2/14	2.3(6)	N/A	feature_card_flash
2/15	MCOM-V34	2/15	2.3(6)	N/A	feature_card_flash
2/16	MCOM-V34	2/16	2.3(6)	N/A	feature_card_flash
2/17	MCOM-V34	2/17	2.3(6)	N/A	feature_card_flash
2/18	MCOM-V34	2/18	2.3(6)	N/A	feature_card_flash
2/19	MCOM-V34	2/19	2.3(6)	N/A	feature_card_flash
2/20	MCOM-V34	2/20	2.3(6)	N/A	feature_card_flash
2/21	MCOM-V34	2/21	2.3(6)	N/A	feature_card_flash
2/22	MCOM-V34	2/22	2.3(6)	N/A	feature_card_flash
2/23	MCOM-V34	2/23	2.3(6)	N/A	feature_card_flash

```
Router# show spe version 1
```

SPE-#	SPE-Type	SPE-Range	Version	Upgrade	Firmware-Filename
1/0	MICA-HMM	1/0 - 1/5	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/1	MICA-HMM	1/6 - 1/11	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/2	MICA-HMM	1/12 - 1/17	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/3	MICA-HMM	1/18 - 1/23	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/5	MICA-HMM	1/30 - 1/35	2.7.1.0	N/A	system:/ucode/mica_port_firmware
1/6	MICA-HMM	1/36 - 1/41	2.7.1.0	N/A	system:/ucode/mica_port_firmware
1/7	MICA-HMM	1/42 - 1/47	2.7.1.0	N/A	system:/ucode/mica_port_firmware
1/9	MICA-HMM	1/54 - 1/59	2.7.1.0	N/A	flash:/pw2710.ios

```
Router# show spe version 1/2
```

SPE-#	SPE-Type	SPE-Range	Version	Upgrade	Firmware-Filename
1/2	MICA-HMM	1/12 - 1/17	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin

The following two examples show implementation of the **show spe version** command to display information about a range of SPEs:

```
Router# show spe version 1/2 2
```

SPE-#	SPE-Type	SPE-Range	Version	Upgrade	Firmware-Filename
1/2	MICA-HMM	1/12 - 1/17	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin
1/3	MICA-HMM	1/18 - 1/23	2.7.1.0	N/A	flash:mica-modem-pw_2_7_1_0.bin

## show spe version

```

1/5 MICA-HMM 1/30 - 1/35 2.7.1.0 N/A system:/ucode/mica_port_firmware
1/6 MICA-HMM 1/36 - 1/41 2.7.1.0 N/A system:/ucode/mica_port_firmware
1/7 MICA-HMM 1/42 - 1/47 2.7.1.0 N/A system:/ucode/mica_port_firmware
1/9 MICA-HMM 1/54 - 1/59 2.7.1.0 N/A flash:/pw2710.ios
2/0 MCOM-V90 2/0 5.1(20) N/A system:/ucode/microcom_firmware
2/1 MCOM-V90 2/1 5.1(20) N/A system:/ucode/microcom_firmware
2/2 MCOM-V90 2/2 5.1(20) N/A system:/ucode/microcom_firmware
2/3 MCOM-V90 2/3 5.1(20) N/A system:/ucode/microcom_firmware
2/4 MCOM-V90 2/4 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/5 MCOM-V90 2/5 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/6 MCOM-V90 2/6 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/7 MCOM-V90 2/7 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/8 MCOM-V90 2/8 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/9 MCOM-V90 2/9 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/10 MCOM-V90 2/10 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/11 MCOM-V90 2/11 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/12 MCOM-V34 2/12 2.3(6) N/A feature_card_flash
2/13 MCOM-V34 2/13 2.3(6) N/A feature_card_flash
2/14 MCOM-V34 2/14 2.3(6) N/A feature_card_flash
2/15 MCOM-V34 2/15 2.3(6) N/A feature_card_flash
2/16 MCOM-V34 2/16 2.3(6) N/A feature_card_flash
2/17 MCOM-V34 2/17 2.3(6) N/A feature_card_flash
2/18 MCOM-V34 2/18 2.3(6) N/A feature_card_flash
2/19 MCOM-V34 2/19 2.3(6) N/A feature_card_flash
2/20 MCOM-V34 2/20 2.3(6) N/A feature_card_flash
2/21 MCOM-V34 2/21 2.3(6) N/A feature_card_flash
2/22 MCOM-V34 2/22 2.3(6) N/A feature_card_flash
2/23 MCOM-V34 2/23 2.3(6) N/A feature_card_flash

```

Router# show spe version 1/2 2/6

```

SPE-# SPE-Type SPE-Range Version Upgrade Firmware-Filename
1/2 MICA-HMM 1/12 - 1/17 2.7.1.0 N/A flash:mica-modem-pw_2_7_1_0.bin
1/3 MICA-HMM 1/18 - 1/23 2.7.1.0 N/A flash:mica-modem-pw_2_7_1_0.bin
1/5 MICA-HMM 1/30 - 1/35 2.7.1.0 N/A system:/ucode/mica_port_firmware
1/6 MICA-HMM 1/36 - 1/41 2.7.1.0 N/A system:/ucode/mica_port_firmware
1/7 MICA-HMM 1/42 - 1/47 2.7.1.0 N/A system:/ucode/mica_port_firmware
1/9 MICA-HMM 1/54 - 1/59 2.7.1.0 N/A flash:/pw2710.ios
2/0 MCOM-V90 2/0 5.1(20) N/A system:/ucode/microcom_firmware
2/1 MCOM-V90 2/1 5.1(20) N/A system:/ucode/microcom_firmware
2/2 MCOM-V90 2/2 5.1(20) N/A system:/ucode/microcom_firmware
2/3 MCOM-V90 2/3 5.1(20) N/A system:/ucode/microcom_firmware
2/4 MCOM-V90 2/4 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/5 MCOM-V90 2/5 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin
2/6 MCOM-V90 2/6 5.1(9) N/A flash:/mcom-fw-dsp.5.1.9_47.22.bin

```

Router# show spe version

```

IOS-Bundled Default Firmware-Filename
=====
system:/ucode/mica_board_firmware 2.0.2.0 Mica Boardware
system:/ucode/mica_port_firmware 2.6.2.0 Mica Portware
system:/ucode/microcom_firmware 5.1.20 Microcom F/W and DSP

On-Flash Firmware-Filename
=====
flash:portware.2620.ios 2.6.2.0 Mica Portware
flash:mcom-modem-firmware.3.1.30.bin 3.1.30 Microcom Firmware
flash:mcom-fw-dsp.5.1.9_47.22.bin 5.1.9 Microcom F/W and DSP
flash:R0620.ios 0.6.2.0 Mica Portware
flash:pw2710.ios 2.7.1.0 Mica Portware
flash:mica-modem-pw_2_7_1_0.bin 2.7.1.0 Mica Portware

```

```

SPE-#  SPE-Type  SPE-Range  Version  Upgrade  Firmware-Filename
1/0    MICA-HMM    1/0 - 1/5  2.7.1.0  N/A      flash:mica-modem-pw_2_7_1_0.bin
1/1    MICA-HMM    1/6 - 1/11 2.7.1.0  N/A      flash:mica-modem-pw_2_7_1_0.bin
1/2    MICA-HMM    1/12 - 1/17 2.7.1.0  N/A      flash:mica-modem-pw_2_7_1_0.bin
1/3    MICA-HMM    1/18 - 1/23 2.7.1.0  N/A      flash:mica-modem-pw_2_7_1_0.bin

```

For the Cisco AS5800, the **show spe version** command display will be different. Note that the SPE-Port-Range field indicates the shelf/slot/port of the SPE.

```
Router# show spe version
```

```

Firmware-Filename                               Version  Firmware-Type
=====
IOS-Bundled Default                             2.6.2.0  Mica Portware
slot0:/pw2710.ios                               2.7.1.0  Mica Portware
slot0:/pw3102.ios                               3.1.0.2  Mica Portware
slot0:/pw3101.ios                               3.1.0.1  Mica Portware

SPE-#  SPE-Type  SPE-Port-Range  Version  Upgrade  Firmware-Filename
3/0    MICA-DMM  1/3/00 - 1/3/11  2.7.1.0  N/A      slot0:/pw2710.ios
3/1    MICA-DMM  1/3/12 - 1/3/23  2.7.1.0  N/A      slot0:/pw2710.ios
3/2    MICA-DMM  1/3/24 - 1/3/35  2.7.1.0  N/A      slot0:/pw2710.ios
3/3    MICA-DMM  1/3/36 - 1/3/47  2.7.1.0  N/A      slot0:/pw2710.ios
3/4    MICA-DMM  1/3/48 - 1/3/59  2.7.1.0  N/A      slot0:/pw2710.ios
3/5    MICA-DMM  1/3/60 - 1/3/71  2.7.1.0  N/A      slot0:/pw2710.ios
3/6    MICA-DMM  1/3/72 - 1/3/83  2.7.1.0  N/A      slot0:/pw2710.ios
3/7    MICA-DMM  1/3/84 - 1/3/95  2.7.1.0  N/A      slot0:/pw2710.ios
3/8    MICA-DMM  1/3/96 - 1/3/107 2.7.1.0  N/A      slot0:/pw2710.ios

```

[Table 41](#) describes the significant fields for the **show spe version** command on the Cisco AS5800 access server.

**Table 41** *show spe version Field Descriptions*

Field	Description
SPE-#	The slot and port number of the SPE.
SPE-Type	The type of the SPE.
SPE-Port-Range	The range of ports within the specific SPE.
Version	The version of firmware loaded on the SPE.
Upgrade	The method used to reboot the SPE—choices are: busyout (default), N/A, reboot, or recover.
Firmware-Filename	Name of the firmware. You can use the <b>dir</b> command at the prompt to display available firmware filenames.
IOS-Bundled Default Firmware-Filename	The firmware filenames bundled with the Cisco IOS software (system:/ucode).
Firmware-Type	The type of modem associated with the firmware version.
On-Flash Firmware-Filename	The firmware filenames on the Flash (flash:).

Related Commands	Command	Description
	<b>firmware location</b>	Upgrades SPE firmware after the new SPE firmware image is retrieved from Cisco.com or elsewhere.
	<b>show modem mapping</b>	Displays a snapshot of all the firmware versions running on all the modems in the access server.
	<b>show spe</b>	Displays history statistics of all SPEs, a specified SPE, or the specified range of SPEs.



# show tech-support modem

To create a modem ISDN channel aggregation (MICA) modem functionality report on a Cisco AS5300 or AS5800 access server, use the **show tech-support modem** command in privileged EXEC mode.

**show tech-support modem [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Produces an extensive modem functionality report.
---------------------------	--

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.2(11)T	This command was introduced for MICA technologies modems on the Cisco AS5300 and AS5800.

**Usage Guidelines** This command is useful when information is required to troubleshoot a problem with MICA modems in the field. Customers are typically asked to send the output for a number of Cisco IOS EXEC commands. The **show tech-support modem** command provides extensive output of many EXEC commands through entry of a single command.

The report displayed by the **show tech-support modem** command is the successive output of many commands. The report takes some time to run and, when captured in a buffer, can be over 100 pages in length. The following commands are run by the **show tech-support modem** command. The commands are shown in the order run:

- **show version**
- **show running-config**
- **show modem version**
- **show modem**
- **show modem summary**
- **show spe version**
- **show controllers t1 call-counters**
- **show controllers e1 call-counters**
- **show modem connect-speeds**
- **show modem mapping**
- **show line**
- **show caller**
- **show users all**

The following additional commands are run by the **show tech-support modem detail** command. The commands are shown in the order run:

- **show modem configuration**
- **show modem operational-status**
- **show modem mica all**
- **show modem csm**
- **show modem log**

To interpret the modem reports, refer to the descriptions for each command in the appropriate command reference manual.

---

### Examples

The following example shows how to display a basic list of modem reports:

```
Router# show tech-support modem
```

The following example shows how to display an extensive list of modem reports:

```
Router# show tech-support modem detail
```

---

### Related Commands

Command	Description
<b>execute-on</b>	Executes a command on a line card to monitor and maintain information on the card (for example, a line card on a dial shelf).

# show tech-support spe

To create a NextPort service processing element (SPE) modem functionality report on a Cisco AS5350, AS5400, AS5800, or AS5850 access server, use the **show tech-support spe** command in privileged EXEC mode.

**show tech-support spe [detail]**

<b>Syntax Description</b>	<b>detail</b> (Optional) Produces an extensive modem functionality report.				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>12.2(11)T</td> <td>This command was introduced for SPE modems on the Cisco AS5350, AS5400, AS5800, and AS5850.</td> </tr> </tbody> </table>	Release	Modification	12.2(11)T	This command was introduced for SPE modems on the Cisco AS5350, AS5400, AS5800, and AS5850.
Release	Modification				
12.2(11)T	This command was introduced for SPE modems on the Cisco AS5350, AS5400, AS5800, and AS5850.				

## Usage Guidelines

This command is useful when information is required to troubleshoot a problem with SPE modems in the field. Customers are typically asked to send the output for a number of Cisco IOS EXEC commands. The **show tech-support spe** command provides extensive output of many EXEC commands by entering a single command.

The report displayed by the **show tech-support spe** command is the successive output of many commands. The report takes some time to run and, when captured in a buffer, can be over 100 pages in length. The following commands are run by the **show tech-support spe** command. The commands are shown in the order run:

- **show version**
- **show running-config**
- **show spe version**
- **show spe**
- **show spe modem summary**
- **show spe modem csr summary**
- **show spe modem disconnect-reason summary**
- **show spe recovery**
- **show csm call-rate**
- **show nextport mm**
- **show controllers e1 call-counters**
- **show controllers t1 call-counters**
- **show line**
- **show caller**
- **show users all**

The following additional commands are run by the **show tech-support spe detail** command. The commands are shown in the order run:

- **show csm modem**
- **show spe log**
- **show port modem log**

To interpret the modem reports, refer to the descriptions for each command listed in the appropriate command reference manual.

---

### Examples

The following example shows how to display a basic list of modem reports:

```
Router# show tech-support spe
```

The following example shows how to display an extensive list of modem reports:

```
Router# show tech-support spe detail
```

---

### Related Commands

Command	Description
<b>execute-on</b>	Executes a command on a line card to monitor and maintain information on the card (for example, a line card on a dial shelf).