



Setup and Upgrade Commands

This section serves as a reference to view the list of commands related to setting up and upgrading the router. Use this section to understand the command syntaxes, default values and sample command usage with output.

- [Action Commands, on page 1](#)
- [Show Commands, on page 12](#)

Action Commands

clear configuration inconsistency

To clear an inconsistency alarm for a router configuration, use the **clear configuration inconsistency** command in XR EXEC mode.

clear configuration inconsistency

Syntax Description

This command has no keywords or arguments.

Command Default

EXEC mode: Clears the inconsistency alarms for an SDR configuration.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 3.x.x	This command was introduced.

Usage Guidelines

An inconsistency alarm is set when there is a failure to restore the configuration; this can occur during router startup, or when a line card or route processor (RP) card is inserted or when there is an OIR (Online Insertion and Removal).

When the inconsistency alarm is set, all configuration commit operations fail until the alarm is cleared using the **clear configuration inconsistency** command. This command clears the alarm and removes the failed configuration.

Enter the **clear configuration inconsistency** command to clear the alarm and allow commit operations to continue.



Note To reapply the failed configuration, you must reapply and recommit the configuration. Use the **load configuration failed** command with the **startup** keyword to populate the target configuration with the contents of the previous failed configuration from the startup configuration.

Use the **show configuration history** command with the **alarm** keyword to view the inconsistency alarm set and alarm clear events in the configuration history log.

Command Modes

To clear the inconsistency alarms for the router, enter the **clear configuration inconsistency** command in XR EXEC mode.

Task ID

Task ID	Operations
config-services	execute

The following example shows how to clear the inconsistency alarms for a router configuration. The command is entered in EXEC mode.

```
Router# clear configuration inconsistency
```

```
Creating any missing directories in Configuration File system...OK
Initializing Configuration Version Manager...OK
Syncing commit database with running configuration...OK
```

In the following example, a history of the inconsistency alarms set and cleared for the configuration are displayed using the **show configuration history** command with the **alarm** keyword:

```
Router# show configuration history alarm
```

Sno.	Event	Info	Time Stamp
~~~~	~~~~~	~~~~~	~~~~~
1	alarm	inconsistency alarm raised	Thu Jun 22 15:23:15 2009
2	alarm	inconsistency alarm cleared	Thu Jun 22 15:42:30 2009
3	alarm	inconsistency alarm raised	Sun Jul 9 13:39:57 2009
4	alarm	inconsistency alarm cleared	Sun Jul 9 14:15:48 2009
5	alarm	inconsistency alarm raised	Sat Jul 15 18:18:26 2009
6	alarm	inconsistency alarm cleared	Sat Jul 15 19:21:03 2009

## install apply

To apply the latest changes on the router, use the **install apply** command in XR EXEC mode.

```
install apply { reload | restart } [noprompt] [synchronous]
```

### Syntax Description

<b>noprompt</b>	(Optional) Applies the changes without prompting for permission.
<b>reload</b>	(Optional) Applies the changes by reloading the device.
<b>restart</b>	(Optional) Applies the changes by restarting impacted processes.

<b>synchronous</b>	(Optional) Applies the changes synchronously.
--------------------	-----------------------------------------------

**Command Default** Applies the changes by the least impactful method available based on the changeset.

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** To activate software changes performed through **install package** or **install source** commands, use the **install apply** command. The apply is either performed through process restart or a full system reload depending on the nature of the changes. Once the changes are applied, you can test the new software. If you are satisfied with the new software, you can run **install commit** to commit to the changes you have performed. If you are unsatisfied, reloading the device will return the device to the previous committed software.



**Note** The default of installation commands is asynchronous mode, meaning that the command runs in the background and the XR EXEC mode is returned as soon as possible. Performing a command in synchronous mode allows the installation process to finish before the prompt is returned.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	read, write

This example shows how to apply the changes by reloading the device:

```
Router# install apply reload
```

This example shows how to apply the changes by restarting impacted processes:

```
Router# install apply restart
```

## install commit

To make the active software persistent across system reloads, use the **install commit** command in XR EXEC mode.

**install commit** [**synchronous**]

<b>synchronous</b>	(Optional) Applies the changes synchronously.
--------------------	-----------------------------------------------

**Command Default** Commits the active software set.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines**

To make the current active software persistent across reloads, use the **install commit** command.

If the system is restarted before the active software set is saved with the **install commit** command, the previously committed software set is used.

**Task ID**

Task ID	Operations
pkg-mgmt	read, write

The following example shows how to make the current active software set persistent:

```
Router# install commit

Install operation 16 'install commit' started by user 'user_b' at 19:18:58 UTC
Sat Apr 08 2006.
Install operation 16 completed successfully at 19:19:01 UTC Sat Apr 08 2006.
```

## install package

To install packages on the router, use the **install package** command in XR EXEC mode.

```
install package { abort { all-since-apply | latest } | { add | downgrade } [ source location ]
[package] | remove package | replace location | rollback transaction-ID | upgrade [ source
location ] [ package ] [ synchronous ] }
```

<b>abort</b> <b>all-since-apply</b>   <b>latest</b>	Aborts the latest package update or all package updates since the last apply.
<b>add</b> <i>packagename</i>   <b>source</b> <i>source</i>	Adds the specified package. You can either specify the name of the package, Cisco bugfix ID or the full path of the source.  The source can be a repository or a local directory or a tarfile (local or remote).  You can add more than one package.
<b>downgrade</b> <i>packagename</i>   <b>source</b> <i>source</i>	Downgrades the specified package.  The source can be a repository or a local directory or a tarfile (local or remote).  You can add more than one package.
<b>remove</b> <i>packagename</i>	Removes the specified package.

<b>replace</b> <i>location</i>	Replaces currently installed software with that in a given ISO. You can specify the full local path to ISO. The ISO must be located in or under one of the following directories: <code>/harddisk:/</code> or <code>/misc/disk1/</code> or <code>/ftp://</code> or <code>/http://</code> .
<b>rollback</b> <i>transaction-ID</i>	Rolls back to the software committed by the given transaction ID.
<b>upgrade</b> <i>packagename</i>   <b>source</b> <i>source</i>	Upgrades the specified package. You can either specify the name of the package, Cisco bugfix ID or the full path of the source. The source can be a repository (local or remote) or a local directory or a tarfile (local or remote). Remote repository or tarfiles can be accessed via <code>ftp://</code> or <code>https://</code> or <code>http://</code> .
<b>synchronous</b>	(Optional) Installs the package synchronously.

**Command Default** None

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** To specify the source, you must specify the full path to a local directory. The full path must be a subdirectory of `/var/xr/disk1/`, `/harddisk:/`, or `/misc/disk1/`.

You can use the URL of a remote DNF repository or tarball. The URL can optionally contain a VRF, and should be in the following format:

- `ftp://<server>[;<vrf>]/<full_path_to_repo>`
- `http://<server>[;<vrf>]/<full_path_to_repo>`
- `https://<server>[;<vrf>]/<full_path_to_repo>`

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	pkg-mgmt	read, write

This example shows how to replace the current software with the 8000-x64.iso image:

```
Router# install package replace /harddisk:/8000-x64.iso
```

This example shows how to add more than one package:

```
Router# install package add package-1 package-2 package-n
```

This example shows how to remove an optional package:

```
Router# install package remove package-name
```

This example shows how to upgrade to new package versions which contain bugfixes:

```
Router# install package upgrade xr-8000-core-7.0.11v1.0.1-1 xr-core-7.0.1v1.0.1-1
```

This example shows how to downgrade a package:

```
Router# install package downgrade xr-telnet
Router# install apply reload
```

## install source

The **install source** command installs or upgrades packages from the specified source and applies the change automatically.

```
install source { location | any-configured } [reload] [noprompt] [synchronous]
```

<i>location</i>	A source can be the name of a configured DNF repository, a local directory, a local tar file, a remote repository or tar file.
<b>any-configured</b>	Use any configured repository to obtain packages.
<b>reload</b>	(Optional) Applies the changes through a reload.
<b>noprompt</b>	(Optional) Applies the changes without prompting for permission.
<b>synchronous</b>	(Optional) Applies the changes synchronously.

**Command Default** None

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The location of the source can be a repository, URL, or a local directory.

For local directories, you must specify the full path. The full path must be a subdirectory of `/var/xr/disk1/`, `/harddisk:/`, or `/misc/disk1/`.

For remote repositories or tarballs, the IP address of the repository must be accessible from the Management Ethernet port. In-band interfaces on linecards cannot be used to reach the repository. The URL can optionally contain a VRF, and should be in the following format:

- `ftp://<server>[;<vrf>]/<full_path_to_repo>`
- `http://<server>[;<vrf>]/<full_path_to_repo>`
- `https://<server>[;<vrf>]/<full_path_to_repo>`

Task ID	Task ID	Operations
	pkg-mgmt	read, write

This example shows how to install the package from the local directory:

```
Router# install source /harddisk:/files xr-ipsla-7.0.11v1.0.1-1.x86_64.rpm
```

This example shows how to install the package from a configured local or remote repository named `install-repo`:

```
Router# install source install-repo xr-ipsla
```

This example shows how to install the package from a repository URL:

```
Router# install source http://72.16.0.0:3333/remote-repo xr-ipsla
```

This example shows how to install more than one package in a single packaging operation:

```
Router# install source /harddisk:/files xr-ipsla-7.0.11v1.0.0-1.x86_64.rpm
xr-mcast-7.0.11v1.0.0-1.x86_64.rpm
```

## install rollback

To roll back to the software associated with the specific transaction ID, use the **install rollback** command in XR EXEC mode.

```
install rollback id [commit] [reload] [noprompt] [synchronous]
```

<i>id</i>	Specifies the transaction ID for the rollback.
<b>commit</b>	(Optional) Commits the installed software after rollback.
<b>reload</b>	(Optional) Applies the changes through a reload.
<b>noprompt</b>	(Optional) Applies the changes without prompting for permission.
<b>synchronous</b>	(Optional) Applies the changes synchronously.

<b>Command Default</b>	None				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

**Usage Guidelines**

This roll back operation installs the previous software and also applies the change automatically. This may reload the router depending on the package that is rolled back.

Alternatively, use the **install package rollback** command to only roll back the package but not apply the changes. You can check whether the router will reload or restart if you apply the change using the **show install history last transaction verbose** command or **show install request** command. Based on the command output, you can take the appropriate action using **install apply reload | restart** command to either reload or restart the system. Use the **install commit** command to commit the transaction.

**Task ID****Task ID    Operations**


---

pkg-mgmt read,  
write

---

This example shows how to the roll back to the software associated with the specific transaction ID 200.

```
Router# install rollback 200
```

This example shows how to roll back and commit the changes:

```
Router# install rollback 200 commit
```

This example shows how to roll back and reload:

```
Router# install rollback 200 reload
```

## install replace

To replace the currently installed software with that in a given ISO and apply the change, use the **install replace** command in XR EXEC mode.

**install replace** *location* [**commit**] [**reload**] [**noprompt**] [**synchronous**]

<i>location</i>	Specifies the location of the package for installation.
<b>commit</b>	(Optional) Commits the installed software after replacing.
<b>reload</b>	(Optional) Replaces the software through a reload.
<b>noprompt</b>	(Optional) Applies the changes without prompting for permission.
<b>synchronous</b>	(Optional) Applies the changes synchronously.

**Command Default**

None

**Command Modes**

XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Include the keyword **noprompt** in the command to enable the system to bypass your permission to reload the router.

Task ID	Task ID	Operations
	pkg-mgmt	read, write

This example shows how to replace the current software with the 8000-x64.iso image.

```
Router# install replace /harddisk:/8000-x64.iso
```

This example shows how to replace the current software and commit the changes:

```
Router# install replace /harddisk:/8000-x64.iso commit
```

This example shows how to replace the current software and reload:

```
Router# install replace /harddisk:/8000-x64.iso reload
```

## reload

To reload the route processor (RP), use the **reload** command in XR EXEC mode.

### reload

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Releases	Modifications
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **reload** command to cause the RP to reload the Cisco IOS XR software according to the configuration register setting (for example, 0x0 to enter ROMMON mode and 0x2 to reload the RP to EXEC mode). If a standby RP is in the ready redundancy state, the **reload** command also causes the router to fail over to the standby RP. Use the **show redundancy** command in EXEC mode to display the status of the standby RP.

When the **reload** command is used and a switchover occurs, the running (active) software configuration is automatically maintained during switchover.



**Caution** If a standby RP is not installed or is not in the ready state, then the router experiences a loss of service while the active RP is reloading Cisco IOS XR software. To view the status of the standby RP, issue the **show redundancy** command in EXEC mode.

If you use the **reload** command and there is no available standby node, you are prompted to continue with the reload:

```
RP/0/RP0/CPU0:router# reload
Standby card not present or not Ready for failover. Proceed?[confirm]y
```

## Task ID

### Task Operations ID

root-lr execute

The following example shows how to reload the active RP. If a standby RP is in the ready state, then the router fails over to the standby RP. If the standby RP is not installed or is not in the ready state, then the router enters ROMMON mode and routing operations stop.

```
RP/0/RP0/CPU0:router# reload
Updating Commit Database. Please wait...[OK]
Proceed with reload? [confirm] y

PCI0 device[7]: Vendor ID 0x10ee
PCI0 device[7]: Device ID 0x300e
PCI1 device[7]: Device ID 0x1100
PCI1 device[7]: Vendor ID 0x1013
PCI1 device[8]: Device ID 0x649
PCI1 device[8]: Vendor ID 0x1095
PCI1 device[9]: Device ID 0x5618
PCI1 device[9]: Vendor ID 0x14e4
PCI1 device[10]: Device ID 0x5618
PCI1 device[10]: Vendor ID 0x14e4
System Bootstrap, Version 1.15(20040120:002852) ,
Copyright (c) 1994-2004 by cisco Systems, Inc.
Board type is 0x100000 (1048576)
Enabling watchdog
Broadcom 5618 #0 Found on PCI
Broadcom 5618 #1 Found on PCI
No. of BCM 56xx switches found 2 .
BCM Switch #0 initialisation complete.
BCM Switch #1 initialisation complete
G4(7450-SMP-GT64260_A) platform with 2048 Mb of main memory

rommon B1 >
```

## reload bootmedia

To reload bootable image from the hardware module network location, use the **reload bootmedia** command in EXEC mode.

**reload bootmedia** { **network location** { *node-id* | **all** } | **usb** }

Syntax Description	Parameter	Description
	<b>network</b>	To reload bootable image from the hardware module.
	<b>location</b> <i>node-id</i>	Specifies a node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation.
	<b>location</b> <b>all</b>	Copies to all nodes.
	<b>usb</b>	To reload bootable image from usb.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

### Usage Guidelines

The reload bootmedia network command reloads reload bootable image from the hardware module network location. Include the keyword **noprompt** in the command to enable the system to bypass your permission to reload the router.

The following example shows how to reload bootable image from all hardware module network location:

```
RP/0/RP0/CPU0:ios#reload bootmedia network location all
Wed Feb 15 07:21:42.536 UTC
Proceed with reload? [confirm]
```

The following example shows how to reload bootable image from specific hardware module network location:

```
RP/0/RP0/CPU0:ios#reload bootmedia network location 0/RP0/CPU0
Wed Feb 15 07:21:42.536 UTC
Proceed with reload? [confirm]
```

The following example shows how to reload bootable image from usb:

```
RP/0/RP0/CPU0:ios#reload bootmedia usb
Wed Feb 15 07:21:42.536 UTC
Proceed with reload? [confirm]
```

# Show Commands

## show hw-module fpd

To display field-programmable device (FPD) compatibility for all modules or a specific module, use the **show hw-module fpd** command in XR EXEC mode.

```
show hw-module [{ fpd | location node-id fpd | location node-id fpd fpd-name | location all fpd
fpd-name }]
```

<b>Syntax Description</b>	<b>location</b> { <i>node-id</i>   <b>all</b> } Specifies the location of the module. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the <b>all</b> keyword to indicate all nodes.						
<b>Command Default</b>	None						
<b>Command Modes</b>	XR EXEC mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.		
Release	Modification						
Release 7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>sysmgr</td> <td>read</td> </tr> <tr> <td>root-lr</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	sysmgr	read	root-lr	read
Task ID	Operations						
sysmgr	read						
root-lr	read						

The following example shows the output of **show hw-module fpd** command:

```
RP/0/RP0/CPU0:ios#show hw-module fpd
Wed Apr 5 17:46:55.067 UTC

Auto-upgrade:Enabled
Attribute codes: B golden, P protect, S secure, A Anti Theft aware
FPD Versions
=====
Location   Card type      HWver FPD device      ATR Status  Running Programd  Reload Loc
-----
0/RP0/CPU0 8201           0.2 Bios                 S CURRENT      1.27          1.27 0/RP0/CPU0
0/RP0/CPU0 8201           0.2 BiosGolden          BS CURRENT      1.20          1.20 0/RP0/CPU0
0/RP0/CPU0 8201           0.2 IoFpga              CURRENT      1.11          1.11 0/RP0
0/RP0/CPU0 8201           0.2 IoFpgaGolden        B CURRENT      1.01          1.01 0/RP0
0/RP0/CPU0 8201           0.2 x86Fpga             S CURRENT      1.06          1.06 0/RP0
0/RP0/CPU0 8201           0.2 x86FpgaGolden       BS CURRENT      1.01          1.01 0/RP0
0/RP0/CPU0 8201           0.2 x86TamFw            S CURRENT      5.13          5.13 0/RP0
0/RP0/CPU0 8201           0.2 x86TamFwGolden      BS CURRENT      5.06          5.06 0/RP0
0/PM0       PSU1.4KW-ACPE  0.0 DT-PrimMCU          CURRENT      3.01          3.01 NOT REQ
0/PM0       PSU1.4KW-ACPE  0.0 DT-SecMCU          CURRENT      2.02          2.02 NOT REQ
```

```

0/PM1      PSU1.4KW-ACPE  0.0  DT-PrimMCU          CURRENT  3.01   3.01   NOT REQ
0/PM1      PSU1.4KW-ACPE  0.0  DT-SecMCU           CURRENT  2.02   2.02   NOT REQ

```

The following example shows how to display FPD compatibility for specific location module in the router:

```

RP/0/RP0/CPU0:ios#show hw-module location 0/RP0/CPU0 fpd
Wed Apr 5 17:47:01.104 UTC

```

Auto-upgrade:Enabled

Attribute codes: B golden, P protect, S secure, A Anti Theft aware

FPD Versions

=====

Location	Card type	HWver	FPD device	ATR	Status	Running	Programd	Reload	Loc
0/RP0/CPU0	8201	0.2	Bios	S	CURRENT	1.27	1.27	0/RP0/CPU0	
0/RP0/CPU0	8201	0.2	BiosGolden	BS	CURRENT		1.20	0/RP0/CPU0	
0/RP0/CPU0	8201	0.2	IoFpga		CURRENT	1.11	1.11	0/RP0	
0/RP0/CPU0	8201	0.2	IoFpgaGolden	B	CURRENT		1.01	0/RP0	
0/RP0/CPU0	8201	0.2	x86Fpga	S	CURRENT	1.06	1.06	0/RP0	
0/RP0/CPU0	8201	0.2	x86FpgaGolden	BS	CURRENT		1.01	0/RP0	
0/RP0/CPU0	8201	0.2	x86TamFw	S	CURRENT	5.13	5.13	0/RP0	
0/RP0/CPU0	8201	0.2	x86TamFwGolden	BS	CURRENT		5.06	0/RP0	

The following example shows the output of **show hw-module location 0/RP0/CPU0 fpd Bios** command:

```

RP/0/RP0/CPU0:ios#show hw-module location 0/RP0/CPU0 fpd Bios
Wed Apr 5 17:47:04.255 UTC

```

Auto-upgrade:Enabled

Attribute codes: B golden, P protect, S secure, A Anti Theft aware

FPD Versions

=====

Location	Card type	HWver	FPD device	ATR	Status	Running	Programd	Reload	Loc
0/RP0/CPU0	8201	0.2	Bios	S	CURRENT	1.27	1.27	0/RP0/CPU0	

The following example shows how to display FPD compatibility for all modules in the router:

```

RP/0/RP0/CPU0:ios#show hw-module fpd all
Tue Apr 4 08:55:32.545 UTC

```

Auto-upgrade:Disabled

Attribute codes: B golden, P protect, S secure, A Anti Theft aware

FPD Versions

=====

Location	Card type	HWver	FPD device	ATR	Status	Running	Programd	Reload	Loc
0/RP0/CPU0	8201	0.30	Bios		NEED UPGD	7.01	7.01	0/RP0/CPU0	
0/RP0/CPU0	8201	0.30	BiosGolden	B	NEED UPGD		7.01	0/RP0/CPU0	
0/RP0/CPU0	8201	0.30	IoFpga		NEED UPGD	7.01	7.01	0/RP0	
0/RP0/CPU0	8201	0.30	IoFpgaGolden	B	NEED UPGD		7.01	0/RP0	
0/RP0/CPU0	8201	0.30	SsdIntelS3520		NEED UPGD	7.01	7.01	0/RP0	
0/RP0/CPU0	8201	0.30	x86Fpga		NEED UPGD	7.01	7.01	0/RP0	
0/RP0/CPU0	8201	0.30	x86FpgaGolden	B	NEED UPGD		7.01	0/RP0	
0/RP0/CPU0	8201	0.30	x86TamFw		NEED UPGD	7.01	7.01	0/RP0	
0/RP0/CPU0	8201	0.30	x86TamFwGolden	B	NEED UPGD		7.01	0/RP0	
0/PM0	PSU2KW-ACPI	0.0	PO-PrimMCU		NEED UPGD	7.01	7.01	NOT REQ	
0/PM1	PSU2KW-ACPI	0.0	PO-PrimMCU		NEED UPGD	7.01	7.01	NOT REQ	

The following example shows the output of **show hw-module location all fpd IoFpga** command:

```

RP/0/RP0/CPU0:ios#show hw-module location all fpd IoFpga
Wed Apr 5 17:47:10.752 UTC

```

```

Auto-upgrade:Enabled
Attribute codes: B golden, P protect, S secure, A Anti Theft aware
FPD Versions
=====
Location   Card type      HWver FPD device   ATR Status   Running Programd   Reload Loc
-----
0/RP0/CPU0 8201           0.2   IoFpga         CURRENT      1.11   1.11   0/RP0

```

## show install active

To display active packages, use the **show install active** command in XR EXEC mode.

```
show install active [{ all [ location { node-id | all } ] | summary }]
```

Syntax Description	
<b>all location</b>	Displays all the active packages.
<b>location node-id</b>	Displays all packages in a specified location or all locations.
<b>location all</b>	
<b>summary</b>	Displays a summary of active packages along with a list of optional packages.

**Command Default** The command without the **all** keyword just displays the currently active XR packages. It does not display all packages on the system such as OS packages.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

This example shows how to view all active packages:

```

Router#show install active all
Wed Mar  8 04:57:35.230 UTC

Software Hash: bf46f5add2ea3cd85c91c647a2ca043e1a829c49e5c290baec0c89c937a17429
Package                                               Version
-----
8000-boot-scripts                                   7.8.1.34Iv1.0.0-r0
8000-cpa-setup-x86                                  7.8.1.34Iv1.0.0-r0
8101-32h-cpa-sb-x86                                  7.8.1.34Iv1.0.0-r0
8102-64h-cpa-sb-x86                                  7.8.1.34Iv1.0.0-r0
8111-32eh-cpa-sb-x86                                  7.8.1.34Iv1.0.0-r0
8201-32fh-cpa-sb-x86                                  7.8.1.34Iv1.0.0-r0
8201-cpa-sb-x86                                       7.8.1.34Iv1.0.0-r0
8202-32fh-m-cpa-sb-x86                               7.8.1.34Iv1.0.0-r0
8202-cpa-sb-x86                                       7.8.1.34Iv1.0.0-r0
8203-88h16fh-m-cpa-sb-x86                             7.8.1.34Iv1.0.0-r0
8212-cpa-sb-x86                                       7.8.1.34Iv1.0.0-r0
8608-fb-data-cpa-sb-x86                               7.8.1.34Iv1.0.0-r0
8608-mpa-crevalle-cpa-sb-x86                         7.8.1.34Iv1.0.0-r0

```

```

8608-mpa-narwhal-cpa-sb-x86          7.8.1.34Iv1.0.0-r0
8608-mpa-pinafore-cpa-sb-x86       7.8.1.34Iv1.0.0-r0
8608-mpa-tiber-cpa-sb-x86         7.8.1.34Iv1.0.0-r0
8804-fc-data-cpa-sb-x86           7.8.1.34Iv1.0.0-r0
acl                                 2.2.52-r0.61
argon                               7.8.1.34Iv1.0.0-r0
--More--

```

This example shows how to view all active packages in a specified location:

```

Router#show install active all location 0/RP0/CPU0
Wed Mar  8 04:58:25.254 UTC

```

```

Software Hash: ef055dac99b856182211deb7585c02fb812c02d6a04cd5b92b521ccf7b9c6ee5
Package                                               Architecture
Version
-----
8000-boot-scripts                                   corei7_64
7.8.1.34Iv1.0.0-r0
8000-cpa-setup-x86                                  corei7_64
7.8.1.34Iv1.0.0-r0
8101-32h-cpa-sb-x86                                 corei7_64
7.8.1.34Iv1.0.0-r0
8102-64h-cpa-sb-x86                                 corei7_64
7.8.1.34Iv1.0.0-r0
8111-32eh-cpa-sb-x86                                corei7_64
7.8.1.34Iv1.0.0-r0
8201-32fh-cpa-sb-x86                                corei7_64
7.8.1.34Iv1.0.0-r0
8201-cpa-sb-x86                                     corei7_64
7.8.1.34Iv1.0.0-r0
8202-32fh-m-cpa-sb-x86                              corei7_64
7.8.1.34Iv1.0.0-r0
8202-cpa-sb-x86                                     corei7_64
7.8.1.34Iv1.0.0-r0
8203-88h16fh-m-cpa-sb-x86                           corei7_64
7.8.1.34Iv1.0.0-r0
8212-cpa-sb-x86                                     corei7_64
7.8.1.34Iv1.0.0-r0
8608-fb-data-cpa-sb-x86                              corei7_64
7.8.1.34Iv1.0.0-r0
8608-mpa-crevalle-cpa-sb-x86                         corei7_64
7.8.1.34Iv1.0.0-r0
8608-mpa-narwhal-cpa-sb-x86                          corei7_64
7.8.1.34Iv1.0.0-r0
8608-mpa-pinafore-cpa-sb-x86                         corei7_64
7.8.1.34Iv1.0.0-r0
8608-mpa-tiber-cpa-sb-x86                            corei7_64
7.8.1.34Iv1.0.0-r0
8804-fc-data-cpa-sb-x86                              corei7_64
7.8.1.34Iv1.0.0-r0
acl                                                    corei7_64
2.2.52-r0.61
argon                                                  wrlsdk_x86
7.8.1.34Iv1.0.0-r0
--More--

```

This example shows how to view the summary of active packages:

```

Router#show install active summary
Wed Mar  8 05:00:29.564 UTC
Active Packages:   XR: 205      All: 1465
Label:             7.8.1.34I-PROD_BUILD_7_8_1_34I_SIT_IMAGE
Software Hash:     bf46f5add2ea3cd85c91c647a2ca043e1a829c49e5c290baec0c89c937a17429

```

Optional Packages	Version
-----	-----
xr-8000-l2mcast	7.8.1.34Iv1.0.0-1
xr-8000-mcast	7.8.1.34Iv1.0.0-1
xr-8000-netflow	7.8.1.34Iv1.0.0-1
xr-bgp	7.8.1.34Iv1.0.0-1
xr-cdp	7.8.1.34Iv1.0.0-1
xr-ipsla	7.8.1.34Iv1.0.0-1
xr-is-is	7.8.1.34Iv1.0.0-1
xr-k9sec	7.8.1.34Iv1.0.0-1
xr-ldp	7.8.1.34Iv1.0.0-1
xr-mcast	7.8.1.34Iv1.0.0-1
xr-mps-oam	7.8.1.34Iv1.0.0-1
xr-netflow	7.8.1.34Iv1.0.0-1
xr-ospf	7.8.1.34Iv1.0.0-1
xr-perf-meas	7.8.1.34Iv1.0.0-1
xr-perfmgmt	7.8.1.34Iv1.0.0-1
xr-telnet	7.8.1.34Iv1.0.0-1
xr-track	7.8.1.34Iv1.0.0-1
--More--	

## show install available

To display packages available for installation, use the **show install available** command in XR EXEC mode.

```
show install available [all]
```

<b>Syntax Description</b>	<b>all location</b> (Optional) Displays all packages available to be installed in a system. <i>node-id</i>
---------------------------	---------------------------------------------------------------------------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--------------------------------------------------------

The following example shows how to view the available packages:

```
Router# show install available all
```

## show install fixes

To display bug fixes, use the **show install fixes** command in XR EXEC mode.

```
show install fixes { active | available | committed | deactivate } [{ brief | bugids value }]
```

<b>active</b>	Display active bug fixes.
<b>available</b>	Display the list of available bug fixes.
<b>committed</b>	Display committed bug fixes
<b>deactivate</b> <i>bugfix_list</i>	Display information on how to remove a bug fix
<b>brief</b>	(Optional) Displays only the bug IDs and not the relevant packages.
<b>bugids</b> <i>value</i>	(Optional) Displays bug fixes for a specific bug ID. You can choose to view information for more than one bug id seperated by a space.

**Command Default** None

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

The following example shows how to view the list of available bug fixes:

```
Router# show install fixes available
Bug Id           Packages                               Repository
-----
CSCxx12345      xr-8000-core-7.0.11v1.0.1-1           <repository-name>
                xr-core-7.0.11v1.0.1-1               <repository-name>
```

The following example shows how to view the information for a active bug ID:

```
Router# show install fixes active bugids CSCxx12345
```

The following example shows how to remove the DDTs CSCwc26944:

```
Router#show install fixes deactivate CSCwc26944
```

```
User-requested DDTs deactivated by this command: CSCwc26944
```

```
All DDTs deactivated by this command: CSCvs01738,CSCwc26944
```

Package changes:

```
xr-8000-core-7.5.2v1.0.5 -> xr-8000-core-7.5.2v1.0.4
xr-8000-fib-ea-7.5.2v1.0.1 -> xr-8000-fib-ea-7.5.2v1.0.0 (missing)
xr-8000-leabaofa-7.5.2v1.0.3 -> xr-8000-leabaofa-7.5.2v1.0.2
xr-8000-mcast-7.5.2v1.0.1 -> xr-8000-mcast-7.5.2v1.0.0 (missing)
xr-8000-utapp-blaze-7.5.2v1.0.2 -> xr-8000-utapp-blaze-7.5.2v1.0.1
xr-fib-7.5.2v1.0.3 -> xr-fib-7.5.2v1.0.2
xr-mcast-7.5.2v1.0.1 -> xr-mcast-7.5.2v1.0.0 (missing)
xr-ncs5401-core-7.5.2v1.0.14 -> xr-ncs5401-core-7.5.2v1.0.10
xr-ncs5700-core-7.5.2v1.0.14 -> xr-ncs5700-core-7.5.2v1.0.10
```

## show install history

```
xr-ofa-7.5.2v1.0.3 -> xr-ofa-7.5.2v1.0.1
xr-snmpp-7.5.2v1.0.1 -> xr-snmpp-7.5.2v1.0.0 (missing)
```

Example install commands:

```
install source any-configured xr-8000-core-7.5.2v1.0.4 xr-8000-fib-ea-7.5.2v1.0.0
xr-8000-leabaofa-7.5.2v1.0.2 xr-8000-mcast-7.5.2v1.0.0 xr-8000-utapp-blaze-7.5.2v1.0.1
xr-fib-7.5.2v1.0.2 xr-mcast-7.5.2v1.0.0 xr-ncs5401-core-7.5.2v1.0.10
xr-ncs5700-core-7.5.2v1.0.10 xr-ofa-7.5.2v1.0.1 xr-snmpp-7.5.2v1.0.0
install package downgrade xr-8000-core-7.5.2v1.0.4 xr-8000-fib-ea-7.5.2v1.0.0
xr-8000-leabaofa-7.5.2v1.0.2 xr-8000-mcast-7.5.2v1.0.0 xr-8000-utapp-blaze-7.5.2v1.0.1
xr-fib-7.5.2v1.0.2 xr-mcast-7.5.2v1.0.0 xr-ncs5401-core-7.5.2v1.0.10
xr-ncs5700-core-7.5.2v1.0.10 xr-ofa-7.5.2v1.0.1 xr-snmpp-7.5.2v1.0.0
```

IMPORTANT: The above commands cannot currently be run because there are missing packages. Put the following packages in an accessible repository.

```
xr-8000-fib-ea-7.5.2v1.0.0
xr-8000-mcast-7.5.2v1.0.0 (optional package)
xr-mcast-7.5.2v1.0.0 (optional package)
xr-snmpp-7.5.2v1.0.0
```

IMPORTANT: If the optional packages are not available, then they can be completely removed before removing the DDTs using install package remove xr-8000-mcast-7.5.2v1.0.0 xr-mcast-7.5.2v1.0.0

## show install history

To display the history of the installation process, use the **show install history** command in XR EXEC mode.

```
show install history { all [ location node-id ] [reverse] [verbose] | table [{ ID number
| [ last entries ] [reverse] } ] }
```

<b>all</b>	Displays the history of all install operations.
<b>last entries</b>	Displays a last entry of the history information table
<b>location</b> <i>node-id</i>	Displays details of the specified location. The <i>node-id</i> argument is entered in the <code>rack/slot/module</code> notation.
<b>table</b>	Displays a summary table of the install operations.
<b>ID number</b>	Specifies the table ID of the history information.
<b>reverse</b>	Displays entries in reverse order.
<b>verbose</b>	Displays detailed information.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines**

To identify whether a reload is required or only process restart is needed, use **show install history last transaction verbose** command.

When there is insufficient disk space in the root file system, the **show install request** command displays an error message. Use **show install history last package** command to view the details of the packaging operation and any errors that have occurred.

The following example shows how to view the history of the install operation:

```
Router# show install history table
-----
Transaction                Atomic Change                Packaging Operations
-----
Id  Status                    Id  Method  Status    Id  Operation  Inputs Status
-----
 1  In progress                1  Reload  Success   1  Upgrade    1  Success
```

The following example shows how to view history of last transaction:

```
Router# show install history last transaction verbose
2019-09-11 17:01:46 UTC    Transaction 3 started
2019-09-11 17:01:46 UTC    Atomic change 3.1 started
2019-09-11 17:01:46 UTC    Packaging operation 3.1.1 started
2019-09-11 17:16:46 UTC    Transaction 3 complete
2019-09-11 17:01:46 UTC    Cleanup in progress
```

The following example shows how to view the last packaging operation for a specific location:

```
Router# show install history last package location 0/RP0/CPU0 verbose
```

The following example shows how to view the complete details of the last packaging operation, including a failure:

```
Router# show install history last package
Wed Jan  8 13:29:51.586 UTC
2020-01-08 13:25:32 UTC    Packaging operation 3.2.1 started
2020-01-08 13:25:32 UTC    Add
2020-01-08 13:25:32 UTC    xr-telnet
2020-01-08 13:28:26 UTC    Error on 0/1/CPU0: Insufficient disk space to install packages
2020-01-08 13:28:26 UTC    Packaging operation 3.2.1 failed: Disk space check failed
on nodes: 0/1/CPU0
2020-01-08 13:28:26 UTC    Packaging operation 3.2.1 aborted: Automatically recovered
after failure
```

```
Location 0/1/CPU0
Last event: Error (Insufficient disk space to install packages)
Disk space pre-check failure:
Phase: Download
Required space: 140944B
Available space: 110623B
```

## show install log

To display the details of installation requests, use the **show install log** command in XR EXEC mode.

```
show install log [all] [detail] [id number] [last number] [reverse]
```

**Syntax Description**

**all** (Optional) Displays a log for all install operations.

**detail** (Optional) Displays details including impact to processes and nodes.

---

**id number** (Optional) Displays the log information for the specified transaction ID.

---

**last number** (Optional) Displays the log information for the last number of transactions.

---

**reverse** (Optional) Displays the logs in reverse order.

---



---

**Command Default** None

---

**Command Modes** XR EXEC mode

---

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

---



---

**Usage Guidelines** Enter the **show install log** command with no arguments to display a summary of all installation operations, including the changes to files and the processes impacted by each request. Specify the **id** argument to display details for a specific operation.

---

Task ID	Task ID	Operations
	pkg-mgmt	read

---

The following example shows the log information for a specific transaction ID:

```
Router# show install log detail id 1
```

## show install request

To display the current status of install requests, use the **show install request** command in XR EXEC mode.

```
show install request { brief [monitor] | location node-id [monitor] | { verbose location node-id [monitor] | monitor location node-id } }
```

---

Syntax Description	brief	Displays install request information summary.
	<b>location</b> <i>node-id</i>	Displays install information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<b>verbose</b>	Displays detailed information about the install request.

---



---

**Command Default** None

---

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.8.1	The keyword <b>monitor</b> was deprecated.

### Usage Guidelines

Cisco IOS XR processes only one installation request per device at a time. The **show install request** command displays any incomplete request that is currently running.



**Note** When the command is running asynchronously, use **show install request** command to monitor the progress.

If the install operation encounters a failure, the **show install request** command, displays an error message. Use the **show install history last package** command to obtain complete details of the failure.

The following example shows sample output from the **show install request** command:

```
Router# show install request
```

```
Install operation 17 'install add /tftp://172.31.255.255/dir/19mcast' started by user
'user_b' at 14:38:45 UTC Thu Mar 30 2006. The operation is 1% complete 2,017KB
downloaded The operation can still be aborted.
```

The following example shows sample output from the **show install request** command when there is insufficient disk space in the root file system. An error message is displayed to indicate the insufficient disk space .

```
Router#show install request
Wed Jan 8 13:29:38.086 UTC
```

```
User request: install replace /harddisk:/replace.iso
Operation ID: 3.2
State: Failure since 2020-01-08 13:28:26 UTC
```

```
Disk space check failed on nodes: 0/1/CPU0. Automatically recovered after failure, ready
for next user request.
```

```
Current activity: Await user input
Time started: 2020-01-08 13:29:25
```

```
The following actions are available:
```

```
install package add
install package remove
install package upgrade
install package downgrade
install package replace
install package rollback
install commit
```

## show interfaces

To display statistics, state and other information such as mac address etc. for all interfaces configured on the router or for a specific node, use the **show interfaces** command in XR EXEC mode.

**show interfaces** [ **summary** | [ *type interface-path-id* | **all** | **local** ] [ **non-dynamic** ] [ **brief** | **description** | **detail** | **sparse** | **accounting** ] ] [ **location** *node-id* ]

**Syntax Description**

<i>type</i>	(Optional) Specifies the type of interface for which you want to display statistics. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces brief</b> command to see a list of all interfaces configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>all</b>	(Optional) Displays interface information for all interfaces. This is the default.
<b>local</b>	(Optional) Displays interface information for all interfaces in the local card.
<b>location</b> <i>node-id</i>	(Optional) Displays information about all interfaces on the specified node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>accounting</b>	(Optional) Displays the number of packets of each protocol type that have been sent through the interface.
<b>brief</b>	(Optional) Displays brief information of each interface (one line per interface).
<b>description</b>	(Optional) Displays the status, protocol, and description of each interface (one line per interface).

<b>detail</b>	(Optional) Displays detailed information about each interface. This is the default.
<b>summary</b>	(Optional) Displays a summary of interface information by interface type.
<b>sparse</b>	(Optional) Displays sparse per interface information excluding interface statistics.
<b>non-dynamic</b>	(Optional) Displays interface information excluding dynamic interfaces.

**Command Default** By default, executing **show interface** command without any option works similar as **show interface all**, and it displays the information for all interfaces in the system.

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.0.0	This command was introduced.
	Release 7.4.2	The keywords <b>sparse</b> and <b>non-dynamic</b> were introduced.

**Usage Guidelines** The **show interfaces** command displays statistics, state and other information such as mac address etc. for the network interfaces.

For example, if you type the **show interfaces** command without an interface type, you receive information for all the interfaces installed in the networking device. Only by specifying the interface *type*, *slot*, and *port* arguments can you display information for a particular interface.

If you enter a **show interfaces** command for an interface type that has been removed from the networking device, an error message is displayed: “Interface not found.”

The output displayed depends on the network for which an interface has been configured.



**Note** Executing **show interfaces** command without filters obtains and displays interface statistics for all interfaces. Hence, it is recommended to execute the command with filters to select specific interfaces or interface types of interest for a faster response. Executing **show interfaces** with options **brief** or **sparse** excludes interface statistics thus providing a faster response.



**Note** The 5-minute input and output rates should be used only as an approximation of traffic per second during a given 5-minute period. These rates are exponentially weighted averages with a time constant of 5 minutes. A period of four time constants must pass before the average is within 2 percent of the instantaneous rate of a uniform stream of traffic over that period.

---

**Task ID**


---

**Task ID Operations**


---

 interface read
 

---



---

**Examples**

This example shows the output from the **show interfaces** command. The output displayed depends on the type and number of interface cards in the networking device.

```
Router# show interfaces HundredGigE 0/3/0/35

HundredGigE0/3/0/35 is up, line protocol is up
  Interface state transitions: 1
  Hardware is HundredGigE, address is e666.9aa0.223c (bia e666.9aa0.223c)
  Description: **To RouterX Hu0/7/0/2**
  Internet address is 192.168.1.29/30
  MTU 1514 bytes, BW 100000000 Kbit (Max: 100000000 Kbit)
    reliability 255/255, txload 239/255, rxload 238/255
  Encapsulation ARPA,
  Full-duplex, 100000Mb/s, unknown, link type is force-up
  output flow control is off, input flow control is off
  Carrier delay (up) is 10 msec
  loopback not set,
  Last link flapped 3w3d
  ARP type ARPA, ARP timeout 04:00:00
  Last input 00:00:00, output 00:00:00
  Last clearing of "show interface" counters never
  30 second input rate 93725392000 bits/sec, 32528692 packets/sec
  30 second output rate 93726416000 bits/sec, 32527860 packets/sec
  68118736643563 packets input, 24783244282360579 bytes, 0 total input drops
  0 drops for unrecognized upper-level protocol
  Received 0 broadcast packets, 0 multicast packets
    0 runts, 0 giants, 0 throttles, 0 parity
  174 input errors, 174 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  68115867305777 packets output, 24782409845763776 bytes, 0 total output drops
  Output 0 broadcast packets, 0 multicast packets
  0 output errors, 0 underruns, 0 applique, 0 resets
  0 output buffer failures, 0 output buffers swapped out
  0 carrier transitions
```

This example shows bundle member links whose link interface status is “err-disable” and line protocol state is “admin-down” after the bundle interface has been administratively shut down using the **shutdown** command:

```
Router# show interfaces brief

Thu May  6 06:30:55.797 DST

          Intf      Intf      LineP      Encap  MTU      BW
          Name      State     State     Type (byte)  (Kbps)
-----
-----
```

```

          BE10          down          down          ARPA 1514          0
          BE100         up            up            ARPA 1514 100000000
          BE101         up            up            ARPA 1514 100000000
          Lo0           up            up            Loopback 1500      0
          Nu0           up            up            Null 1500          0
Fo0/3/0/26 admin-down admin-down ARPA 1514 40000000
Hu0/3/0/0  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/1  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/2  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/3  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/4  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/5  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/6  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/7  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/8  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/9  admin-down admin-down ARPA 1514 100000000
Hu0/3/0/10 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/11 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/12 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/13          down          down          ARPA 1514 100000000
Hu0/3/0/14          up            up            ARPA 1514 100000000
Hu0/3/0/15          up            up            ARPA 1514 100000000
Hu0/3/0/16 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/17 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/18          up            up            ARPA 1514 100000000
Hu0/3/0/19          up            up            ARPA 1514 100000000
Hu0/3/0/20 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/21 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/22 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/23 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/24          up            up            ARPA 1514 100000000
Hu0/3/0/25 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/27 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/28 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/29 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/30 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/31 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/32 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/33 admin-down admin-down ARPA 1514 100000000
Hu0/3/0/34          down          down          ARPA 1514 100000000
Hu0/3/0/35          up            up            ARPA 1514 100000000
Mg0/RP0/CPU0/0          up            up            ARPA 1514 1000000
Mg0/RP1/CPU0/0          up            up            ARPA 1514 1000000

```

This example shows the output from the **show interfaces interface-path-id sparse** command.

```
RP/0/0/CPU0:ios#show interfaces gigabitEthernet 0/1/0/0 sparse
Wed Apr 5 18:05:34.000 IST
```

```

Interface name : GigabitEthernet0/1/0/0
Operational state : administratively down
Admin state : administratively down
MAC address : 02:7d:42:e9:bd:36
Burned In Address : 027d.42e9.bd36
IPv4 Address : 2.2.2.2/24
Max. Bandwidth (Kbit) : 1000000
Effective Bandwidth (Kbit) : 1000000
MTU (in bytes) : 1514
Duplexity : Full-duplex
Link type : force-up

```

Table 1: show interfaces Field Descriptions

Field	Description
Interface name	Displays the name of the current interface. In the example, the interface name is TenGigE0/1/0/1.
Interface state	Displays the state of the interface. In the example, the interface is in the administratively down state.
Interface state transitions	<p>Displays the number of times the interface has changed the state.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Interface state transitions command counts only if the interface stays up. If the line protocol flaps, then it is not counted.</li> <li>• Interface state transitions counts the state when the line protocol state changes the state from up to down/admin-down or admin-down/down to up. If an interface changes the state from down to admin-down or admin-down to down, the counter is not incremented.</li> <li>• Use the <b>clear state-transitions</b> command to clear the counter for the current or all interfaces.</li> </ul>
line protocol state	<p>Displays the state of the Layer 2 line protocol. This field may be different from the interface state if, for example, a keepalive failure has brought down the Layer 2.</p> <p><b>Note</b></p> <p>The line protocol state is not the same as the protocol state displayed in the <b>show ip interfaces</b> command, because it is the state of Layer 2 (media) rather than Layer 3 (IP protocol).</p>
Hardware	Displays the current hardware type.
address is <i>n.n.n.n/n</i>	<p>Displays the Layer 2 address (MAC address for Ethernet interfaces).</p> <p><b>Note</b></p> <p>Enter the <b>mac-address</b> command to configure the hardware address.</p>

Field	Description
bia	Displays the burned-in address (BIA) for the interface. The BIA is the default L2 (MAC) address for the interface.  <b>Note</b> The BIA is not configurable.
description	Displays the user-defined string that is associated with the interface.  <b>Note</b> Enter the <b>description</b> command to configure the description associated with the interface.
Internet address	Displays the Layer 3 (IP) address for the interface.  <b>Note</b> Enter the <b>ipv4 address</b> command to configure the internet address for the interface.
MTU	Displays the maximum transmission unit (MTU) for the interface. The MTU is the maximum packet size that can be transmitted over the interface.  <b>Note</b> The MTU field indicates the interface MTU. Enter the <b>mtu</b> command to configure a lower MTU value at the Layer 3 level.
BW	Displays the bandwidth of the interface in kbps.
reliability	Displays the proportion of packets that are not dropped and do not have errors.  <b>Note</b> The reliability is shown as a fraction of 255.
txload	Indicates the traffic flowing out of the interface as a proportion of the bandwidth.  <b>Note</b> The txload is shown as a fraction of 255.
rxload	Indicates the traffic flowing into the interface as a proportion of the bandwidth.  <b>Note</b> The rxload is shown as a fraction of 255.
Encapsulation	Layer 2 encapsulation installed on the interface.

Field	Description
CRC	<p>Indicates the length of the cyclic redundancy check (CRC), in bytes.</p> <p><b>Note</b> The CRC is not present for all interface types.</p> <p><b>Note</b> Enter the <b>pos crc</b> command to configure the CRC.</p>
loopback or controller loopback	<p>Indicates whether the hardware has been configured to be looped back.</p> <p><b>Note</b> Enter the <b>loopback</b> command to configure the loopback or controller loopback.</p>
keepalive	<p>Displays the configured keepalive value, in seconds.</p> <p><b>Note</b> Enter the <b>keepalive</b> command to configure the value of the keepalive field.</p> <p><b>Note</b> The <i>keepalive</i> field may not be present if it is not applicable to the interface type.</p>
Duplexity	<p>Displays the duplexity of the link.</p> <p><b>Note</b> This field is present only for shared media.</p> <p><b>Note</b> For some interface types, you can configure the duplexity by entering the <b>full-duplex</b> and <b>half-duplex</b> commands.</p>
Speed	Speed and bandwidth of the link in Mbps. This field is present only when other parts of the media info line are also displayed (see duplexity and media type).
Media Type	Media type of the interface.
output flow control	Whether output flow control is enabled on the interface.
input flow control	See output flow control.
ARP type	Address Resolution Protocol (ARP) type used on the interface. This value is not displayed on interface types that do not use ARP.

Field	Description
ARP timeout	ARP timeout in <i>hours:mins:secs</i> . This value is configurable using the <b>arp timeout</b> command.
Last clearing of counters	Time since the following counters were last cleared using the <b>clear counters</b> exec command in <i>hours:mins:secs</i> .
Input rate	<p>Average number of bits and packets received per second during the load-interval. If the interface is not in promiscuous mode, it senses network traffic that it sends and receives (rather than all network traffic).</p> <p><b>Note</b> Load duration is based on load-interval configured under the interface. The default load duration is 5 minutes, if load-interval is not configured under the interface.</p> <p><b>Note</b> The input rate should be used only as an approximation of traffic per second during a given load duration. This rate is exponentially weighted average with a time constant of load duration. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.</p>
packets input	Number of packets received on the interface that were successfully delivered to higher layers.
bytes input	<p>Total number of bytes successfully received on the interface.</p> <p><b>Note</b> This does not include FCS bytes.</p>
total input drops	Total number of packets that were dropped after they were received. This includes packets that were dropped due to configured quality of service (QoS) or access control list (ACL) policies. This does not include drops due to unknown Layer 3 protocol.
drops for unrecognized upper-level protocol	Total number of packets that could not be delivered because the necessary protocol was not configured on the interface.
Received broadcast packets	Total number of Layer 2 broadcast packets received on the interface. This is a subset of the total input packet count.

Field	Description
Received multicast packets	Total number of Layer 2 multicast packets received on the interface. This is a subset of the total input packet count.
runts	Number of received packets that were too small to be handled. This is a subset of the input errors count.
giants	Number of received packets that were too large to be handled. This is a subset of the input errors count.
throttles	Number of packets dropped due to throttling (because the input queue was full).
parity	Number of packets dropped because the parity check failed.
input errors	Total number of received packets that contain errors and hence cannot be delivered. Compare this to total input drops, which counts packets that were not delivered despite containing no errors.
CRC	Number of packets that failed the CRC check.
frame	Number of packets with bad framing bytes.
overrun	Number of overrun errors experienced by the interface. Overruns represent the number of times that the receiver hardware is unable to send received data to a hardware buffer because the input rate exceeds the receiver's ability to handle the data.
ignored	Total number of ignored packet errors. Ignored packets are those that are discarded because the interface hardware does not have enough internal buffers. Broadcast storms and bursts of noise can result in an increased number of ignored packets.
abort	Total number of abort errors on the interface.
packets output	Number of packets received on the interface that were successfully delivered to higher layers.
bytes output	Total number of bytes successfully received on the interface. <b>Note</b> This does not include FCS bytes.
total output drops	Number of packets that were dropped before being transmitted

Field	Description
Received broadcast packets	Number of Layer 2 broadcast packets transmitted on the interface. This is a subset of the total input packet count.
Received multicast packets	Total number of Layer 2 multicast packets transmitted on the interface. This is a subset of the total input packet count.
output errors	Number of times that the receiver hardware was unable to handle received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
underruns	Number of underrun errors experienced by the interface. Underruns represent the number of times that the hardware is unable to transmit data to a hardware buffer because the output rate exceeds the transmitter's ability to handle the data.
applique	Number of applique errors.
resets	Number of times that the hardware has been reset. The triggers and effects of this event are hardware-specific.
output buffer failures	Number of times that a packet was not output from the output hold queue because of a shortage of MEMD shared memory.
output buffers swapped out	Number of packets stored in main memory when the output queue is full; swapping buffers to main memory prevents packets from being dropped when output is congested. The number is high when traffic is bursty.
carrier transitions	Number of times the carrier detect (CD) signal of a serial interface has changed state.

## show inventory

To retrieve and display information about all the Cisco products that are installed in the router, use the **show inventory** command in XR EXEC mode.

```
show inventory [{ node-id | all | location { node-id | all } | raw | chassis | details | fan | power | vendor-type }]
```

### Syntax Description

<i>node-id</i>	(Optional) Location for which to display the specified information. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.
----------------	----------------------------------------------------------------------------------------------------------------------------------------------

<b>all</b>	(Optional) Displays inventory information for all the physical entities in the chassis.
<b>location</b> { <i>node-id</i>   <b>all</b> }	(Optional) Displays inventory information for a specific node, or for all nodes in the chassis.
<b>raw</b>	(Optional) Displays raw information about the chassis for diagnostic purposes.
<b>chassis</b>	(Optional) Displays only information about the chassis.
<b>details</b>	(Optional) Displays detailed entity information.
<b>fan</b>	(Optional) Displays inventory information for the fans.
<b>power</b>	(Optional) Displays inventory information for the power supply.
<b>vendor-type</b>	(Optional) Displays vendor-type information.

**Command Default**

All inventory information for the entire chassis is displayed.

**Command Modes**

XR EXEC mode

**Command History**

Release	Modification
Release 7.0.12	This command was introduced.

**Usage Guidelines**

If a Cisco entity is not assigned a product ID (PID), that entity is not retrieved or displayed.

Enter the **show inventory** command with the **raw** keyword to display every RFC 2737 entity installed in the router, including those without a PID, unique device identifier (UDI), or other physical identification.



**Note** The **raw** keyword is primarily intended for troubleshooting problems with the **show inventory** command itself.

If any of the Cisco products do not have an assigned PID, the output displays incorrect PIDs, and version ID (VID) and serial number (SN) elements may be missing.

For UDI compliance products, the PID, VID, and SN are stored in EEPROM and NVRAM. Use the **show inventory** command to display this information.

The following example shows partial sample output from the **show inventory** command with the **raw** keyword:

```
RP/0/RP0/CPU0:ios#show inventory raw
Tue Mar  7 07:34:48.602 UTC

NAME: "Rack 0", DESCR: "Cisco 8201 1RU Chassis"
PID: 8201                , VID: V00, SN: FOC2217JIRS

NAME: "Rack 0-Control Card Slot 0", DESCR: "8201 Route Processor Slot 0"
PID: N/A                , VID: N/A, SN: N/A

NAME: "0/RP0/CPU0", DESCR: "Cisco 8201 1RU Chassis"
PID: 8201                , VID: V00, SN: FOC2219JGLB
```

```

NAME: "0/RP0/CPU0-Mother Board", DESCR: "Mother Board"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/RP0/CPU0-Broadwell-DE (D-1530)", DESCR: "Processor Module"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/RP0/CPU0-Attention", DESCR: "LED Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/RP0/CPU0-Status", DESCR: "LED Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/RP0/CPU0-Sync", DESCR: "LED Sensor"
PID: N/A , VID: N/A, SN: N/A

NAME: "0/RP0/CPU0-MB_RT_GB_PIN", DESCR: "Power Sensor - MB-RT_GB_ONLY_0.8VB_PIN"
PID: N/A , VID: N/A, SN: N/A
--More--

```

The following example shows the sample output from the **show inventory** command with the **chassis** keyword:

```

RP/0/RP0/CPU0:ios#show inventory chassis
Thu Apr 6 04:56:46.987 UTC

NAME: "Rack 0", DESCR: "Cisco 8808 8-slot Chassis"
PID: 8808 , VID: V00, SN: FOX224PPUDA

```

The following table describes the significant fields shown in the display.

**Table 2: show inventory Field Descriptions**

Field	Description
NAME	Hardware for which the inventory information is displayed. If you are displaying the chassis inventory, this field shows “chassis.” If you are displaying raw inventory, or all inventory information for all nodes in the chassis, this field shows the node name in partially qualified format. For a node, the NAME is expressed in <i>rack/slot</i> notation.
DESCR	Describes the chassis or the node.  Chassis descriptions provide the name of the chassis and its Gbps. Node descriptions provide the type of node and its software version.
PID	Physical model name of the chassis or node.
VID	Physical hardware revision of the chassis or node.
SN	Physical serial number for the chassis or node.

## show ipv4 interface

To display the usability status of interfaces configured for IPv4, use the **show ipv4 interface** command in XR EXEC mode.

```
show ipv4 interface [{ type interface-path-id | brief | summary }]
```

<b>Command Default</b>	If VRF is not specified, the software displays the default VRF.						
<b>Command Modes</b>	XR EXEC mode						
<b>Usage Guidelines</b>	The <b>show ipv4 interface</b> command provides output similar to the <b>show ipv6 interface</b> command, except that it is IPv4-specific.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv4</td> <td>read</td> </tr> <tr> <td>network</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	ipv4	read	network	read
Task ID	Operations						
ipv4	read						
network	read						

### Examples

This is the sample output of the **show ipv4 interface** command:

```
Router# show ipv4 interface

Loopback0 is Up, line protocol is Up
  Internet address is
  .0.0.1/

  Secondary address 10.0.0./8
  MTU is 1514 (1514 is available to IP)
  Multicast reserved groups joined: 10.0.0.1
  Directed broadcast forwarding is disabled
  Outgoing access list is not set
  Inbound access list is not set
  Proxy ARP is enabled
  ICMP redirects are always sent
  ICMP unreachable are always sent
/0/0/0 is Up, line protocol is Up
  Internet address is 10.25.58.1/16
  MTU is 1514 (1500 is available to IP)
  Multicast reserved groups joined: .0..1
  Directed broadcast forwarding is disabled
  Outgoing access list is not set
  Inbound access list is not set
  Proxy ARP is enabled
  ICMP redirects are always sent
  ICMP unreachable are always sent
/0/0/0 is Shutdown, line protocol is Down

  Internet protocol processing disabled
```

This table describes the significant fields shown in the display.

**Table 3: show ipv4 interface Command Field Descriptions**

Field	Description
Loopback0 is Up	If the interface hardware is usable, the interface is marked “Up.” For an interface to be usable, both the interface hardware and line protocol must be up.

Field	Description
line protocol is Up	If the interface can provide two-way communication, the line protocol is marked “Up.” For an interface to be usable, both the interface hardware and line protocol must be up.
Internet address	IPv4 Internet address and subnet mask of the interface.
Secondary address	Displays a secondary address, if one has been set.
MTU	Displays the IPv4 MTU ¹ value set on the interface.
Multicast reserved groups joined	Indicates the multicast groups this interface belongs to.
Directed broadcast forwarding	Indicates whether directed broadcast forwarding is enabled or disabled.
Outgoing access list	Indicates whether the interface has an outgoing access list set.
Inbound access list	Indicates whether the interface has an incoming access list set.
Proxy ARP	Indicates whether proxy ARP ² is enabled or disabled on an interface.
ICMP redirects	Specifies whether ICMPv4 ³ redirects are sent on this interface.
ICMP unreachable	Specifies whether unreachable messages are sent on this interface.
Internet protocol processing disabled	Indicates an IPv4 address has not been configured on the interface.

¹ MTU = maximum transmission unit

² ARP = Address Resolution Protocoladdress resolution protocol

³ ICMPv4 = Internet Control Message Protocol internet control message protocol version 4

## show ipv6 interface

To display the usability status of interfaces configured for IPv6, use the **show ipv6 interface** command in XR EXEC mode.

```
show ipv6 interface [ { summary | [ type interface-path-id ] [ brief [ { link-local | global } ] ] }
```

### Syntax Description

*type* (Optional) Interface type. For more information, use the question mark (?) online help function.

*interface-path-id* (Optional) Either a physical interface instance or a virtual interface instance as follows:

- Physical interface instance. Naming notation is *rack/slot/module/port* and a slash between values is required as part of the notation.
  - *rack*: Chassis number of the rack.
  - *slot*: Physical slot number of the modular services card or line card.
  - *module*: Module number. A physical layer interface module (PLIM) is always 0.
  - *port*: Physical port number of the interface.

**Note** In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0) and the module is CPU0. Example: interface MgmtEth0/RSP0 /CPU0/0.

- Virtual interface instance. Number range varies depending on interface type.

For more information about the syntax for the router, use the question mark (?) online help function.

<b>brief</b>	(Optional) Displays the primary IPv6 addresses configured on the router interfaces and their protocol and line states.
<b>link-local</b>	(Optional) Displays the link local IPv6 address.
<b>global</b>	(Optional) Displays the global IPv6 address.
<b>summary</b>	(Optional) Displays the number of interfaces on the router that are assigned, unassigned, or unnumbered.

**Command Default** None

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0	This command was introduced.

**Usage Guidelines** The **show ipv6 interface** command provides output similar to the **show ipv4 interface** command, except that it is IPv6-specific.

Use the **link-local** or **global** keywords along with the **brief** keyword to view the link local or global IPv6 addresses.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv6	read

## Examples

This is the sample output of the **show ipv6 interface** command:

```
RP/0/RP0/CPU0:ios#show ipv6 interface
Wed Mar  8 04:27:58.236 UTC
FourHundredGigE0/0/0/0 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
FourHundredGigE0/0/0/1 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
FourHundredGigE0/0/0/2 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
FourHundredGigE0/0/0/3 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
FourHundredGigE0/0/0/4 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
FourHundredGigE0/0/0/5 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
FourHundredGigE0/0/0/6 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
FourHundredGigE0/0/0/7 is Shutdown, ipv6 protocol is Down, Vrfid is default (0x60000000)
  IPv6 is disabled, link-local address unassigned
--More--
```

This table describes the significant fields shown in the display.

**Table 4: show ipv6 interface Command Field Descriptions**

Field	Description
	Indicates whether the interface hardware is currently active (whether line signal is present) and whether it has been taken down by an administrator. If the interface hardware is usable, the interface is marked “Up.” For an interface to be usable, both the interface hardware and line protocol must be up.
line protocol is Up (or down)	Indicates whether the software processes that handle the line protocol consider the line usable (that is, whether keepalives are successful). If the interface can provide two-way communication, the line protocol is marked “Up.” For an interface to be usable, both the interface hardware and line protocol must be up.
IPv6 is enabled, stalled, disabled (stalled and disabled are not shown in sample output)	Indicates that IPv6 is enabled, stalled, or disabled on the interface. If IPv6 is enabled, the interface is marked “enabled.” If duplicate address detection processing identified the link-local address of the interface as being a duplicate address, the processing of IPv6 packets is disabled on the interface and the interface is marked “stalled.” If IPv6 is not enabled, the interface is marked “disabled.”
link-local address	Displays the link-local address assigned to the interface.

Field	Description
TENTATIVE	<p>The state of the address in relation to duplicate address detection. States can be any of the following:</p> <ul style="list-style-type: none"> <li>• duplicate—The address is not unique and is not being used. If the duplicate address is the link-local address of an interface, the processing of IPv6 packets is disabled on that interface.</li> <li>• tentative—Duplicate address detection is either pending or under way on this interface.</li> </ul> <p><b>Note</b> If an address does not have one of these states (the state for the address is blank), the address is unique and is being used.</p>
Global unicast addresses	Displays the global unicast addresses assigned to the interface.
ICMP redirects	State of Internet Control Message Protocol (ICMP) IPv6 redirect messages on the interface (the sending of the messages is enabled or disabled).
ND DAD	State of duplicate address detection on the interface (enabled or disabled).
number of DAD attempts	Number of consecutive neighbor solicitation messages that are sent on the interface while duplicate address detection is performed.
ND reachable time	Displays the neighbor discovery reachable time (in milliseconds) assigned to this interface.

This is the sample output of the **show ipv6 interface brief link-local** command:

```
Router#show ipv6 interface brief link-local
```

This is the sample output of the **show ipv6 interface brief global** command:

```
Router#show ipv6 interface brief global
```

This is the sample output of the **show ipv6 interface type interface-path-id brief link-local** command:

```
Router#show ipv6 interface tenGigE 0/0/0/0 brief link-local
```

```
Interface                IPv6-Address           Status    Protocol
0/0/0/0    fe80::fe:8ff:feeb:26c5    Up        Up
```

This is the sample output of the **show ipv6 interface type interface-path-id brief global** command:

```
Router#show ipv6 interface tenGigE 0/0/0/0 brief global
```

```
Interface                IPv6-Address           Status    Protocol
0/0/0/0    2001:db8::1              Up        Up
```

## show logging

To display the contents of the logging buffer, use the **show logging** command in XR EXEC mode.

```
show logging [{ [ alarm-location location ] | [ correlator options ] | local location
node-id | [ location node-id ] [ start month day hh : mm : ss ] [ process name ] [
string string ] [ end month day hh : mm : ss ] [ events options ] [ files ] [ history ] [ last
entries ] [ onboard entries ] [ suppress rule { rule_name | all } ] }
```

Syntax Description	
<b>alarm-location trace</b> <i>location</i>	(Optional) Displays alarm-location information. The <b>trace</b> option shows trace data for the alarm location components.
<b>correlator</b> <i>options</i>	(Optional) Displays content and information about correlation buffer. Options available are: <ul style="list-style-type: none"> <li>• <b>buffer</b>: Displays content of the correlation buffer.</li> <li>• <b>info</b>: Displays information about event correlation.</li> <li>• <b>trace</b>: Displays trace data for the alarm_logger component.</li> </ul>
<b>end</b> <i>month day hh : mm : ss</i>	(Optional) Displays syslog messages with a time stamp equal to or lower than the time stamp specified with the <i>monthday hh : mm : ss</i> argument.  The ranges for the <i>month day hh : mm : ss</i> arguments are: <ul style="list-style-type: none"> <li>• <i>month</i>—The month of the year. The values for the <i>month</i> argument are the names of the twelve months.</li> <li>• <i>day</i>—Day of the month. Range is from 01 to 31.</li> <li>• <i>hh</i> :—Hours. Range is from 00 to 23. You must insert a colon after the <i>hh</i> argument.</li> <li>• <i>mm</i> :—Minutes. Range is from 00 to 59. You must insert a colon after the <i>mm</i> argument.</li> <li>• <i>ss</i>—Seconds. Range is from 00 to 59.</li> </ul>
<b>events</b> <i>options</i>	Displays content and information about the event buffer. The various options available are: <ul style="list-style-type: none"> <li>• <b>buffer</b>: Displays content of the event buffer.</li> <li>• <b>info</b>: Displays information about events buffer.</li> <li>• <b>rule</b>: Displays specified rules.</li> <li>• <b>ruleset</b>: Displays rulesets.</li> <li>• <b>trace</b>: Displays trace data for the correlation component.</li> </ul>
<b>files</b>	Show logging files and path.

<b>history</b>	Displays contents of logging history.
<b>last <i>entries</i></b>	Displays last <n> entries. The number of entries can range from 1 to 500.
<b>local location <i>node-id</i></b>	(Optional) Displays system logging (syslog) messages from the specified local buffer. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>location <i>node-id</i></b>	(Optional) Displays syslog messages from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>onboard <i>options</i></b>	Displays on board logging. The various options available are: <ul style="list-style-type: none"> <li>• alarm: Displays alarm data.</li> <li>• fpd: Displays FPD version data.</li> <li>• inventory: Displays inventory data.</li> <li>• npu: Displays NPU life-time data.</li> <li>• temperature: Displays temperature sensor data</li> <li>• uptime: Displays system uptime data</li> <li>• voltage: Displays voltage sensor data.</li> </ul>
<b>start <i>month day hh : mm : ss</i></b>	(Optional) Displays syslog messages with a time stamp equal to or higher than the time stamp specified with the <i>month day mm : hh : ss</i> argument.  The ranges for the <i>month day hh : mm : ss</i> arguments are as follows: <ul style="list-style-type: none"> <li>• <i>month</i>—The month of the year. The values for the <i>month</i> argument are the names of the twelve months.</li> <li>• <i>day</i>—Day of the month. Range is from 01 to 31.</li> <li>• <i>hh :</i>—Hours. Range is from 00 to 23. You must insert a colon after the <i>hh</i> argument.</li> <li>• <i>mm :</i>—Minutes. Range is from 00 to 59. You must insert a colon after the <i>mm</i> argument.</li> <li>• <i>ss</i>—Seconds. Range is from 00 to 59.</li> </ul>
<b>process <i>name</i></b>	(Optional) Displays syslog messages related to the specified process.
<b>string <i>string</i></b>	(Optional) Displays syslog messages that contain the specified string.
<b>suppress rule {<i>rule_name</i> all}</b>	Displays content and information about log suppression. The <b>rule</b> option shows specified rules.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show logging** command to display the state of syslog error and event logging on the processor console. The information from the command includes the types of logging enabled and the size of the buffer.

Task ID	Task Operations ID
	logging read

### Examples

This is the sample output from the **show logging** command using both the **process name** keyword argument pair and **location node-id** keyword argument pair. Syslog messages related to the “init” process emitted from node 0/RP0/CPU0 are displayed in the sample output.

```
RP/0/RP0/CPU0:ios#show logging process init location 0/RP0/CPU0
Tue Mar  7 08:07:49.157 UTC
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Console logging: level warnings, 7 messages logged
  Monitor logging: level debugging, 0 messages logged
  Trap logging: level informational, 0 messages logged
  Buffer logging: level debugging, 133 messages logged
```

Log Buffer (2097152 bytes):

This table describes the significant fields shown in the display.

**Table 5: show logging Field Descriptions**

Field	Description
Syslog logging	If enabled, system logging messages are sent to a UNIX host that acts as a syslog server; that is, the host captures and saves the messages.
Console logging	If enabled, the level and the number of messages logged to the console are stated; otherwise, this field displays “disabled.”
Monitor logging	If enabled, the minimum level of severity required for a log message to be sent to the monitor terminal (not the console) and the number of messages logged to the monitor terminal are stated; otherwise, this field displays “disabled.”
Trap logging	If enabled, the minimum level of severity required for a log message to be sent to the syslog server and the number of messages logged to the syslog server are stated; otherwise, this field displays “disabled.”
Buffer logging	If enabled, the level and the number of messages logged to the buffer are stated; otherwise, this field displays “disabled.”

To find out OOR state of a router's hardware and Software Development Kit (SDK) resources, you can view the sample output from the **show logging** command with the output modifier as OOR. You can configure the threshold value at which a router reaches the **OOR State Red** or **Yellow** by using the `oor hw threshold` command. For more information, see `oor hw threshold` command in the chapter *Logging Services Commands of System Monitoring Command Reference for Cisco 8000 Series Routers*.

```
Router# show logging | inc OOR
Wed Jan 6 23:36:34.138 EST
LC/0/0/CPU0:Jan 6 23:01:09.609 EST: npu_drvr[278]: %PLATFORM-OFA-4-OOR_YELLOW : NPU 1, Table
nhgroup, Resource stage2_lb_group
LC/0/0/CPU0:Jan 6 23:01:29.655 EST: npu_drvr[278]: %PLATFORM-OFA-4-OOR_YELLOW : NPU 1, Table
nhgroup, Resource stage2_lb_member
LC/0/0/CPU0:Jan 6 23:01:38.938 EST: npu_drvr[278]: %PLATFORM-OFA-1-OOR_RED : NPU 3, Table
nhgroup, Resource stage2_lb_group
```

## show ntp status

To display the status of Network Time Protocol (NTP), use the **show ntp status** command in XR EXEC mode.

```
show ntp status [ location node-id ]
```

<b>Syntax Description</b>	<b>location node-id</b> (Optional) Displays the status of NTP from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.				
<b>Command Default</b>	None				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ip-services</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read
Task ID	Operations				
ip-services	read				

This example shows sample output from the **show ntp status** command:

```
Router# show ntp status

Clock is synchronized, stratum 3, reference is 192.168.128.5
nominal freq is 1000.0000 Hz, actual freq is 1000.0021 Hz, precision is 2**24
reference time is CC38EC6A.8FCCA1C4 (10:10:02.561 JST Tue Jul 29 2008)
clock offset is -124.051 msec, root delay is 174.060 msec
root dispersion is 172.37 msec, peer dispersion is 0.10 msec
loopfilter state is 'CTRL' (Normal Controlled Loop), drift is -0.0000021106 s/s
```

```
system poll interval is 32, last update was 19 sec ago
```

**Table 6: show ntp status Field Descriptions**

Field	Description
synchronized	Synchronized system to an NTP peer.
stratum	NTP stratum of this system.
reference	IPv4 address or first 32 bits of the MD5 hash of the IPv6 address of the peer to which clock is synchronized.
nominal freq	Nominal frequency in Hertz (Hz) of the system hardware clock.
actual freq	Measured frequency in Hz of the system hardware clock.
precision	Precision of the clock of this system in Hz.
reference time	Reference time stamp.
clock offset	Offset of clock to synchronized peer, in milliseconds.
root delay	Total delay along path to root clock, in milliseconds.
root dispersion	Dispersion of root path.
peer dispersion	Dispersion of synchronized peer.
loopfilter state	The state of the clock state machine transition function.
drift	Drift of the hardware clock.
system poll interval	Poll interval of the peer.
last update	Time the router last updated its NTP information.

## show platform

To display information and status for each node in the system, use the **show platform** command in XR EXEC mode.

```
show platform [node-id]
```

<b>Syntax Description</b>	<i>node-id</i> (Optional) Node for which to display information. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.
<b>Command Default</b>	Status and information are displayed for all nodes in the system.
<b>Command Modes</b>	XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **show platform** command provides a summary of the nodes in the system, including node type and status. Enter the **show platform** command in EXEC mode to display output for only those nodes that belong to the SDR on which the command is executed.

Task ID	Task ID	Operations
	system	read

The following example shows sample output from the **show platform** command:

```
RP/0/RP0/CPU0:ios#show platform
Thu Apr 6 00:56:22.922 UTC
Node                Type                State                Config state
-----
0/RP0/CPU0          8800-RP(Active)     IOS XR RUN           NSHUT,NMON
0/0/CPU0            8800-LC-48H         IOS XR RUN           NSHUT
0/1/CPU0            88-LC0-36FH-M       IOS XR RUN           NSHUT
0/FC0               8812-FC             OPERATIONAL          NSHUT
0/FC1               8812-FC             OPERATIONAL          NSHUT
0/FT0               8812-FAN            OPERATIONAL          NSHUT
0/FT1               8812-FAN            OPERATIONAL          NSHUT
0/FT2               8812-FAN            OPERATIONAL          NSHUT
0/FT3               8812-FAN            OPERATIONAL          NSHUT
0/PT0               8800-HV-TRAY        OPERATIONAL          NSHUT
0/PT1               8800-HV-TRAY        OPERATIONAL          NSHUT
0/PT2               8800-HV-TRAY        OPERATIONAL          NSHUT
```

The following is sample output for the **show platform** command with the *node-id* argument:

```
Router#show platform location 0/RP0/CPU0
Wed Mar 8 04:05:07.106 UTC
Node                Type                State                Config state
-----
0/RP0/CPU0          8201(Active)        IOS XR RUN           NSHUT
```

This table describes the significant fields shown in the display.

**Table 7: show platform Field Descriptions**

Field	Description
Node	Identifier of the node in the <i>rack/slot</i> notation.
Type	Type of node.
State	Current state of the specified node.
Config State	Current configuration state of the specified node.

## show redundancy

To display the status of route processor redundancy, use the **show redundancy** command in

EXEC

mode.

**show redundancy** [{**location** {*node-id* | **all**} | **statistics** | **summary**}]

<b>Syntax Description</b>	<b>location</b> { <i>node-id</i>   <b>all</b> }	(Optional) Specifies the node for which to display LED information. The <i>node-id</i> argument is expressed in the <i>rack / slot</i> notation. Use the <b>all</b> keyword to indicate all nodes.
	<b>statistics</b>	(Optional) Displays redundancy statistics information.
	<b>summary</b>	(Optional) Displays a summary of all redundant node pairs in the router.
<b>Command Default</b>	Route processor redundancy information is displayed for all nodes in the system.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	Use the <b>show redundancy</b> command to display the redundancy status of the route switch processors (RSPs). The <b>show redundancy</b> command also displays the boot and switchover history for the . To view the nonstop routing (NSR) status of the standby in the system, use the <b>summary</b> keyword.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	system	read
	basic-services	read (for <b>statistics</b> keyword)

The following example shows sample output from the **show redundancy** command:

```
RP/0/RSP0/CPU0:router# show redundancy location 0/rsp0/cpu0
Thu Jul 30 05:47:12.155 DST
Node 0/RSP0/CPU0 is in ACTIVE role
Node 0/RSP0/CPU0 has no valid partner

Reload and boot info
-----
A9K-RSP-4G reloaded Tue Jul 14 15:21:30 2009: 2 weeks, 1 day,
14 hours, 25 minutes ago
Active node booted Tue Jul 14 15:21:30 2009: 2 weeks, 1 day,
14 hours, 25 minutes ago
```

```
Active node reload "Cause: User initiated forced reload all"
```

**Table 8: show redundancy Field Descriptions**

Field	Description
Node */*/* is in XXX role	Current role of the primary route processor, where (*/*/*) is the route processor ID in the format <i>rack/slot/module</i> , and XXX is the role of the route processor (active or standby).  In the example, this field shows that the node with the ID 0/RP0/CPU0 is in active role.
Partner node (*/*/*) is in XXX role	Current role of the secondary (or partner) route processor, where (*/*/*) is the route processor ID in the <i>rack/slot/module</i> format, and XXX is the role of the route processor (active or standby).  In the example, this field shows that the node with the ID 0/RP1/CPU0 is in standby role.
Standby node in (*/*/*) is ready	Current state of the standby node, where (*/*/*) is the standby route processor ID.  In the example, the standby node is ready.
Standby node in (*/*/*) is NSR-ready	Current state of the standby node regarding nonstop routing (NSR), where (*/*/*) is the standby route processor ID.  In the example, the standby node is NSR-ready.
Reload and boot info	General overview of the active and standby route processors' reload and boot history.

## show version

To display the software version, build information, system hardware type and uptime, use the **show version** command in XR EXEC mode.

**show version**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines**

The **show version** command displays a variety of system information, including hardware and software version, router uptime, and active software.

**Task ID****Task ID      Operations**

basic-services	read
----------------	------

This example shows partial output from the **show version** command:

```
RP/0/RP0/CPU0#show version
Cisco IOS XR Software, Version 7.8.2 LNT
Copyright (c) 2013-2023 by Cisco Systems, Inc.

Build Information:
  Built By      : ingunawa
  Built On     : Wed Mar 15 16:45:19 UTC 2023
  Build Host   : iox-ucs-060
  Workspace    : /auto/srcarchive13/prod/7.8.2/8000/ws
  Version     : 7.8.2
  Label       : 7.8.2

cisco 8000 (Intel(R) Xeon(R) CPU D-1530 @ 2.40GHz)
cisco 8812 (Intel(R) Xeon(R) CPU D-1530 @ 2.40GHz) processor with 32GB of memory
R1 uptime is 7 hours, 19 minutes
Cisco 8812 12-slot Chassis
```

## show media

To display the current state of the disk storage media, use the **show media** command in XR EXEC mode.

```
show media location { node-id | all }
```

**Syntax Description**

**location** {*node-id* | **all**} (Optional) Specifies the node where the file system is located. The *node-id* argument is expressed in the *rack/slot* notation. Use the **all** keyword to indicate all nodes.

**Command Default**

The disk storage media for the active RP is displayed.

**Command Modes**

XR EXEC mode

**Command History****Usage Guidelines**

Use the **show media** command to view the status of the storage media on your system.

**Task ID****Task ID      Operations**

filesystem	read
------------	------

This example shows output from the **show media** command:

```
Router#show media location 0/RP0/CPU0
Tue Mar  7 15:00:14.506 UTC

Media Info for Location: node0_RP0_CPU0
Partition                               Size      Used  Percent  Avail
```

```
-----  
rootfs:          56.9G      8.8G      15%     48.2G  
data:            80.8G      1.4G       2%     79.4G  
/var/lib/docker  6.9G        17M       1%      6.5G  
disk0:           4.0G        8.4M       1%      3.8G  
log:             5.5G        64M        2%      5.2G  
harddisk:        63G         53M        1%      60G
```