



Connect Router to the Network



Note The images in this chapter are only for representation purposes, unless specified otherwise. The chassis' actual appearance and size may vary.

- [Connecting a Console to the Router, on page 1](#)
- [Connect the Management Interface, on page 2](#)
- [Transceivers, Connectors, and Cables, on page 3](#)
- [Install and Remove SFP or SFP+ Modules, on page 4](#)
- [Install and Remove QSFP Transceiver Modules, on page 9](#)
- [Connect Interface Ports, on page 16](#)
- [Maintain Transceivers and Optical Cables, on page 16](#)
- [Create the Initial Router Configuration, on page 16](#)

Connecting a Console to the Router

Before you create a network management connection for the router or connect the router to the network, you must create a local management connection through a console terminal and configure an IP address for the router. The router can be accessed using remote management protocols, such as SSH and Telnet. By default, SSH is included in the software image. But telnet is not part of the software image. You must manually install the telnet optional package to use it.

You also can use the console to perform the following functions, each of which can be performed through the management interface after you make that connection:

- configure the router using the command-line interface (CLI)
- monitor network statistics and errors
- configure Simple Network Management Protocol (SNMP) agent parameters
- initiate software download updates via console

You make this local management connection between the asynchronous serial port on a Route Processor card and a console device capable of asynchronous transmission. Typically, you can use a computer terminal as the console device. On the Route Processor cards, you use the console serial port.



Note Before you can connect the console port to a computer terminal, ensure that the computer terminal supports VT100 terminal emulation. The terminal emulation software makes communication between the router and computer possible during setup and configuration.

Before you begin

- The router must be fully installed in its rack. The router must be connected to a power source and grounded.
- The necessary cabling for the console, management, and network connections must be available.
 - An RJ45 rollover cable and a DB9F/RJ45 adapter.
 - Network cabling should already be routed to the location of the installed router.

Procedure

Step 1 Configure the console device to match the following default port characteristics:

- 115200 baud
- 8 data bits
- 1 stop bit
- No parity

Step 2 Connect an RJ45 rollover cable to a terminal, PC terminal emulator, or terminal server.
The RJ45 rollover cable is not part of the accessory kit.

Step 3 Route the RJ45 rollover cable as appropriate and connect the cable to the console port on the chassis.
If the console or modem cannot use an RJ45 connection, use the DB9F/RJ45F PC terminal adapter. Alternatively, you can use an RJ45/DSUB F/F or RJ45/DSUB R/P adapter, but you must provide those adapters.

What to do next

You are ready to create the initial router configuration.

Connect the Management Interface

The Route Processor management port (MGMT ETH) provides out-of-band management, which lets you to use the command-line interface (CLI) to manage the router by its IP address. This port uses a 10/100/1000 Ethernet connection with an RJ-45 interface.



Note In a dual Route Processor router, you can ensure that the active Route Processor card is always connected to the network by connecting the management interface on both Route Processor cards to the network. That is, you can perform this task for each Route Processor card. When the Route Processor card is active, the router automatically has a management interface that is running and accessible from the network.



Caution To prevent an IP address conflict, do not connect the MGMT 100/1000 Ethernet port until the initial configuration is complete.

Before you begin

You must have completed the initial router configuration.

Procedure

- Step 1** Connect a modular, RJ-45, UTP cable to the MGMT ETH port on the Route Processor card.
- Step 2** Route the cable through the central slot in the cable management system.
- Step 3** Connect the other end of the cable to a 100/1000 Ethernet port on a network device.

What to do next

You are ready to connect the interface ports to the network.

Transceivers, Connectors, and Cables

Transceiver and Cable Specifications

To determine which transceivers and cables are supported by this router, see [Cisco Transceiver Modules Compatibility Information](#).

To see the transceiver specifications and installation information, see [Cisco Transceiver Modules Install and Upgrade Guides](#).

RJ-45 Connectors

The RJ-45 connector connects Category 3, Category 5, Category 5e, Category 6, or Category 6A foil twisted-pair or unshielded twisted-pair cable from the external network to the following module interface connectors:


- Router chassis
 - CONSOLE port
 - MGMT ETH port



Caution To comply with GR-1089 intrabuilding, lightning immunity requirements, you must use a foil twisted-pair (FTP) cable that is properly grounded at both ends.

The following figure shows the RJ-45 connector.

Figure 1: RJ-45 Connector



1	Pin 1	2	Pin 8
---	-------	---	-------

Install and Remove SFP or SFP+ Modules

Before you remove or install an SFP or SFP+ module, read the installation information in this section.




Warning **Statement 1051—Laser Radiation**

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.



Caution Protect the line card by inserting a clean SFP/SFP+ module cage cover, which is shown in the figure below, into the optical module cage when there is no SFP or SFP+ module installed.

Figure 2: SFP/SFP+ Module Cage Cover





Caution Protect the SFP or SFP+ modules by inserting clean dust covers into them after the cables are removed. Be sure to clean the optic surfaces of the fiber cables before you plug them back into the optical ports of another module. Avoid getting dust and other contaminants into the optical ports of your SFP or SFP+ modules, because the optics do not work correctly when obstructed by dust.



Caution We strongly recommended that you do not install or remove the SFP or SFP+ module with fiber-optic cables that are attached to it because of the potential of damaging the cable, the cable connector, or the optical interfaces in the module. Disconnect all cables before removing or installing an SFP or SFP+ module. Removing and inserting a module can shorten its useful life, so you should not remove and insert modules any more than is absolutely necessary.




Note When installing an SFP or SFP+ module, you should hear a click as the triangular pin on the bottom of the module snaps into the hole in the receptacle. The click indicates that the module is correctly seated and secured in the receptacle. Verify that the modules are seated and secured in their assigned receptacles on the line card by firmly pushing on each SFP or SFP+ module.

Bale Clasp SFP or SFP+ Module

The bale clasp SFP or SFP+ module has a clasp that you use to remove or install the module (see the figure below).

Figure 3: Bale Clasp SFP or SFP+ Module



Installing the Transceiver Module



Warning **Statement 1055**—Class 1/1M Laser

Invisible laser radiation is present. Do not expose to users of telescopic optics. This applies to Class 1/1M laser products.



Warning **Statement 1051**—Laser Radiation

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.



Warning **Statement 1079**—Hot Surface

This icon is a hot surface warning. To avoid personal injury, do not touch without proper protection.



Caution The transceiver module is a static-sensitive device. Always use an ESD wrist strap or similar individual grounding device when handling transceiver modules or coming into contact with system modules.

Caution Protect the transceiver ports by inserting clean dust caps (8000-QSFP-DCAP) into any ports not in use. Be sure to clean the optic surfaces of the fiber cables before you plug them back into the optical ports of another module. Use dust caps for all the open ports on the chassis.

The router ships with dust caps plugged in. We highly recommend you to keep the dust caps plugged in until you are ready to plug an optic.


The dust caps protect the ports from possible EMI interference and also avoid contamination due to dust collection. To meet the EMI interference requirements, you must use the metal dust caps when the ports are not in use by optical modules.

The QSFP transceiver module has a pull-tab latch. To install a transceiver module, follow these steps:

Procedure

- Step 1** Attach an ESD wrist strap to yourself and a properly grounded point on the chassis or the rack.
- Step 2** Remove the transceiver module from its protective packaging.
- Step 3** Check the label on the transceiver module body to verify that you have the correct model for your network. Do not remove the dust plug until you're ready to attach the network interface cable. Dust plug is not shown in the images.
- Step 4** Hold the transceiver by the pull-tab so that the identifier label is on the top.
- Step 5** Align the transceiver module in front of the module's transceiver socket opening and carefully slide the transceiver into the socket until the transceiver contact with the socket electrical connector.


Figure 4: Installing the QSFP Transceiver Module



- Step 6** Press firmly on the front of the transceiver module with your thumb to fully seat the transceiver in the module's transceiver socket (see the below figure).

Caution If the latch isn't fully engaged, you might accidentally disconnect the transceiver module.

Figure 5: Seating the QSFP Transceiver Module




Remove a Bale Clasp SFP or SFP+ Module

To remove this type of SFP or SFP+ module, follow these steps:

Procedure

-
- Step 1** Attach an ESD-preventive wrist or ankle strap and follow its instructions for use.
- Step 2** Disconnect and remove all interface cables from the ports; note the current connections of the cables to the ports on the line card.
- Step 3** Open the bale clasp on the SFP module with your index finger, as shown in the figure below. If the bale clasp is obstructed and you cannot use your index finger to open it, use a small flat-blade screwdriver or other long, narrow instrument to open the bale clasp.
- Step 4** Grasp the SFP module between your thumb and index finger and carefully remove it from the port, as shown in the figure below.
- Note** This action must be performed during your first instance. After all the ports are populated, this may not be possible.

Figure 6: Removing a Bale Clasp SFP or SFP+ Module




- Step 5** Place the removed SFP module on an antistatic mat, or immediately place it in a static shielding bag if you plan to return it to the factory.
- Step 6** Protect your line card by inserting a clean SFP module cage covers into the optical module cage when there is no SFP module installed.

Install and Remove QSFP Transceiver Modules

This section provides the installation, cabling, and removal instructions for the Quad Small Form-Factor Pluggable transceiver modules. Refer to the [Cisco Optical Transceiver Handling Guide](#) for additional details on optical transceivers.

The following figure shows a 400-Gigabit QSFP-DD optical transceiver.

Figure 7: 400-Gigabit QSFP-DD Transceiver Module



1	Pull-tab	2	QSFP-DD transceiver body
3	Electrical connection to the module circuitry		



Warning Statement 1079—Hot Surface

This icon is a hot surface warning. To avoid personal injury, do not touch without proper protection.



Required Tools and Equipment

You need these tools to install the transceiver modules:

- Wrist strap or other personal grounding device to prevent ESD occurrences.
- Antistatic mat or antistatic foam to set the transceiver on.
- Fiber-optic end-face cleaning tools and inspection equipment.

Installing the Transceiver Module



Warning **Statement 1055**—Class 1/1M Laser

Invisible laser radiation is present. Do not expose to users of telescopic optics. This applies to Class 1/1M laser products.



Warning **Statement 1051**—Laser Radiation

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.



Warning **Statement 1079**—Hot Surface

This icon is a hot surface warning. To avoid personal injury, do not touch without proper protection.



Caution The transceiver module is a static-sensitive device. Always use an ESD wrist strap or similar individual grounding device when handling transceiver modules or coming into contact with system modules.

Caution Protect the transceiver ports by inserting clean dust caps (8000-QSFP-DCAP) into any ports not in use. Be sure to clean the optic surfaces of the fiber cables before you plug them back into the optical ports of another module. Use dust caps for all the open ports on the chassis.

The router ships with dust caps plugged in. We highly recommend you to keep the dust caps plugged in until you are ready to plug an optic.


The dust caps protect the ports from possible EMI interference and also avoid contamination due to dust collection. To meet the EMI interference requirements, you must use the metal dust caps when the ports are not in use by optical modules.

The QSFP transceiver module has a pull-tab latch. To install a transceiver module, follow these steps:

Procedure

-
- Step 1** Attach an ESD wrist strap to yourself and a properly grounded point on the chassis or the rack.
- Step 2** Remove the transceiver module from its protective packaging.
- Step 3** Check the label on the transceiver module body to verify that you have the correct model for your network. Do not remove the dust plug until you're ready to attach the network interface cable. Dust plug is not shown in the images.
- Step 4** Hold the transceiver by the pull-tab so that the identifier label is on the top.
- Step 5** Align the transceiver module in front of the module's transceiver socket opening and carefully slide the transceiver into the socket until the transceiver contact with the socket electrical connector.


Figure 8: Installing the QSFP Transceiver Module



- Step 6** Press firmly on the front of the transceiver module with your thumb to fully seat the transceiver in the module's transceiver socket (see the below figure).

Caution If the latch isn't fully engaged, you might accidentally disconnect the transceiver module.

Figure 9: Seating the QSFP Transceiver Module



Attach the Optical Network Cable

Before you begin

Before you remove the dust plugs and make any optical connections, follow these guidelines:

- Keep the protective dust plugs installed in the unplugged fiber-optic cable connectors and in the transceiver optical bores until you are ready to make a connection.
- Inspect and clean the optical connector end faces just before you make any connections.
- Grasp the optical connector only by the housing to plug or unplug a fiber-optic cable.



Note The transceiver modules and fiber connectors are keyed to prevent incorrect insertion.



Note The multiple-fiber push-on (MPO) connectors on the optical transceivers support network interface cables with either physical contact (PC) or ultra-physical contact (UPC) flat polished face types. The MPO connectors on the optical transceivers do not support network interface cables with an angle-polished contact (APC) face type.




Note Inspect the MPO connector for the correct cable type, cleanliness, and any damage. For complete information on inspecting and cleaning fiber-optic connections, see the [Inspection and Cleaning Procedures for Fiber-Optic Connections](#) document.

Procedure

- Step 1** Remove the dust plugs from the optical network interface cable MPO connectors and from the transceiver module optical bores. Save the dust plugs for future use.
- Step 2** Attach the network interface cable MPO connectors immediately to the transceiver module.

Figure 10: Cabling a Transceiver Module



Removing the Transceiver Module



Warning **Statement 1055**—Class 1/1M Laser

Invisible laser radiation is present. Do not expose to users of telescopic optics. This applies to Class 1/1M laser products.



Warning **Statement 1051**—Laser Radiation

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.



Warning **Statement 1079—Hot Surface**

This icon is a hot surface warning. To avoid personal injury, do not touch without proper protection.



Caution The transceiver module is a static-sensitive device. Always use an ESD wrist strap or similar individual grounding device when handling transceiver modules or coming into contact with modules.



Caution Protect the transceiver ports by inserting clean dust caps (8000-QSFP-DCAP) into any ports not in use. Be sure to clean the optic surfaces of the fiber cables before you plug them back into the optical ports of another module. Use dust caps for all the open ports on the chassis.

The router ships with dust caps plugged in. We highly recommend you to keep the dust caps plugged in until you are ready to plug an optic.


The dust caps protect the ports from possible EMI interference and also avoid contamination due to dust collection. To meet the EMI interference requirements, you must use the metal dust caps when the ports are not in use by optical modules.

To remove a transceiver module, follow these steps:

Procedure

-
- Step 1** Disconnect the network interface cable from the transceiver connector.
 - Step 2** Install the dust plug immediately into the transceiver's optical bore.
 - Step 3** Grasp the pull-tab and gently pull to release the transceiver from the socket.

Figure 11: Removing the QSFP Transceiver Module



- Step 4** Slide the transceiver out of the socket.
- Step 5** Place the transceiver module into an antistatic bag.
-

Connect Interface Ports

You can connect optical interface ports on line cards with other devices for network connectivity.

Disconnect Optical Ports from the Network

When you need to remove fiber-optic transceivers, you must first remove the fiber-optic cables from the transceiver before you remove the transceiver from the port.

Maintain Transceivers and Optical Cables

Refer to [Inspection and Cleaning Procedures for Fiber-Optic Connections](#) document for inspection and cleaning processes for fiber optic connections.

Create the Initial Router Configuration

Assign an IP address to the router management interface to connect the router to the network.

When you initially power up the router, it boots up and displays a series of configuration-related questions. You can use the default choices for each configuration except for the IP address, which you must provide.



Note These routers are designed to boot up in less than 30 mins, provided the neighboring devices are in full-operational state.

When the system is powered on and the console port is connected to the terminal, the RP CPU messages are seen.



Note The Cisco 8608 router doesn't support BMC.

Before you begin

- A console device must be connected with the router.
- The router must be connected to a power source.
- Determine the IP address and netmask that is needed for the Management interfaces: `MgmtEth0/RP0/CPU0/0` and `MgmtEth0/RP1/CPU0/0`:

Procedure

Step 1 Power up the router.

The LEDs on each power supply light up (green) when the power supply units are sending power to the router, and the software asks you to specify a password to use with the router.

Step 2 When the system boots up for the first time, the system prompts you to create a new username and password. The following prompt appears:

```
!!!!!!!!!!!!!!!!!!!!!! NO root-system username is configured. Need to configure root-system
username. !!!!!!!!!!!!!!!!!!!!!!!
```

```
--- Administrative User Dialog ---
```

```
Enter root-system username:
```

```
% Entry must not be null.
```

```
Enter root-system username: cisco
```

```
Enter secret:
```

```
Use the 'configure' command to modify this configuration.
```

```
User Access Verification
```

```
Username: cisco
```

```
Password:
```

```
RP/0/RP0/CPU0:ios#
```

Step 3 Enter a new password to use for this router.

The software checks the security strength of your password and rejects your password if the system does not consider it as a strong password. To increase the security strength of your password, make sure that it adheres to the following guidelines:

- At least eight characters
- Minimizes or avoids the use of consecutive characters (such as "abcd")
- Minimizes or avoids repeating characters (such as "AAA")
- Does not contain recognizable words in the dictionary
- Does not contain proper names
- Contains both uppercase and lowercase characters
- Contains numbers and letters

Note Cleartext passwords cannot include the dollar sign (\$) special character.

Tip If a password is trivial (such as a short, easy-to-decipher password), the software rejects that password. Passwords are case-sensitive.

When you enter a strong password, the software asks you to confirm the password.

Step 4 Reenter the password.

When you enter the same password, the software accepts the password.

Step 5 Enter the configuration mode.

Step 6 Enter the IP address for the management interface. If using dual RPs, enter the IP address on both management interfaces.

Step 7 Enter a network mask for the management interface.

Step 8 Save your configuration.

Step 9 The software asks whether you want to edit the configuration. If you don't want to edit your configuration, enter **'no'**.

Verify Chassis Installation

After installing the chassis, use the following **show** commands to verify the installation and configuration in the EXEC mode. Any issue if detected, take corrective action before making further configurations.

Command	Description
show platform	Displays the state information of each card.
show redundancy	Displays the status of route processor redundancy.
show led	Displays LED information for the router, or for a specific LED location.
show hw-module fpd	Displays field-programmable device (FPD) compatibility for all modules or a specific module.
show alarms brief system active	Displays all existing alarms in the router.

Command	Description
show media	Displays the current state of the disk storage media.
show inventory	Displays information about the field replaceable units (FRUs), including product IDs, serial numbers, and version IDs.
show environment power	Displays the power usage information for the entire router.
show environment fan	Displays the status of the fan trays.
show environment temperature	<p>Displays temperature readings for card temperature sensors. Each module has temperature sensors with two thresholds:</p> <ul style="list-style-type: none"> • Minor temperature threshold – When a minor threshold is exceeded, minor alarm occurs and the following actions occur for all four sensors: <ul style="list-style-type: none"> • Displays system messages • Sends SNMP notifications (if configured) • Log environmental alarm event that can be reviewed by running the show alarm command. • Major temperature threshold – When a major threshold is exceeded, a major alarm occurs and the following actions occur: <ul style="list-style-type: none"> • For sensors 1, 3, and 4 (outlet and on board sensors), the following actions occur: <ul style="list-style-type: none"> • Displays system messages. • Sends SNMP notifications (if configured). • Logs environmental alarm event that can be reviewed by running the show alarm command. • For sensor 2 (intake sensor), the following actions occur: <ul style="list-style-type: none"> • If the threshold is exceeded in a switching card, only that card is shut down. • If the threshold exceeds an active Route Processor card with HA-standby or standby present, only that Route Processor card is shut down and the standby Route Processor card takes over. • If you do not have a standby Route Processor card in your router, you have up to 2 minutes to decrease the temperature. During this interval, the software monitors the temperature every 5 seconds and continuously sends system messages as configured. <p>Note</p> <ul style="list-style-type: none"> • Cisco recommends that you install dual Route Processor cards. • For some card temperature sensors, the temperature thresholds for both minor and major might display 'NA'. This is an expected behaviour and indicates that there are no alarms for those corresponding thresholds.
show environment voltage	Displays the voltage for the entire router.

Command	Description
show environment current	Displays the current environment status.
show platform domain	Displays the active and standby modes of Route Processor Cards and Switch Cards.

show platform command

The following example shows a sample output from the **show platform** command:

```
Router#show platform
Wed Jul 12 14:36:14.897 UTC
Node                Type                State                Config state
-----
0/RP0/CPU0          8608-RP (Active)    IOS XR RUN           NSHUT
0/RP1/CPU0          8608-RP (Standby)  IOS XR RUN           NSHUT
0/SC0               8608-SC0-128       OPERATIONAL          NSHUT
0/SC1               8608-SC0-128       OPERATIONAL          NSHUT
0/FB0               8608-SC0-128 [FB]  OPERATIONAL          NSHUT
0/FB1               8608-SC0-128 [FB]  OPERATIONAL          NSHUT
0/0                 86-MPA-4FH-M        OPERATIONAL          NSHUT
0/3                 86-MPA-14H2FH-M    OPERATIONAL          NSHUT
0/FT0               8608-FAN            OPERATIONAL          NSHUT
0/FT1               8608-FAN            OPERATIONAL          NSHUT
0/FT2               8608-FAN            OPERATIONAL          NSHUT
0/FT3               8608-FAN            OPERATIONAL          NSHUT
0/FT4               8608-FAN            OPERATIONAL          NSHUT
0/FT5               8608-FAN            OPERATIONAL          NSHUT
0/FT6               8608-FAN            OPERATIONAL          NSHUT
0/FT7               8608-FAN            OPERATIONAL          NSHUT
0/PM0               PSU3.2KW-ACPI       OPERATIONAL          NSHUT
0/PM1               PSU3.2KW-ACPI       OPERATIONAL          NSHUT
```

show redundancy command

The following example shows a sample output from the **show redundancy** command:

```
Router#show redundancy
Wed Jul 12 14:41:17.597 UTC
Redundancy information for node 0/RP0/CPU0:
=====
Node 0/RP0/CPU0 is in ACTIVE role
Partner node (0/RP1/CPU0) is in STANDBY role
Standby node in 0/RP1/CPU0 is ready
Standby node in 0/RP1/CPU0 is NSR-ready

Reload and boot info
-----
RP reloaded Wed Jul 12 14:01:06 2023: 40 minutes ago
Active node booted Wed Jul 12 14:01:06 2023: 40 minutes ago
Standby node boot Mon Jan 1 19:13:53 2018: 5 years, 27 weeks, 3 days, 19 hours, 27 minutes ago
Standby node last went not ready Wed Jul 12 14:04:03 2023: 37 minutes ago
Standby node last went ready Wed Jul 12 14:05:50 2023: 35 minutes ago
Standby node last went not NSR-ready Wed Jul 12 14:03:46 2023: 37 minutes ago
Standby node last went NSR-ready Wed Jul 12 14:08:20 2023: 32 minutes ago
There have been 0 switch-overs since reload
```

Active node reload "0/SC0 reload triggered graceful chassis reload"
 Standby node reload "0/SC0 reload triggered graceful chassis reload"

show led command

The following example shows a sample output from the **show led** command:

```
Router#show led
Wed Jul 12 14:41:20.426 UTC
=====
Location          LED Name          Mode          Color
=====
0
0/0               Attention         OPERATIONAL   OFF
                  Status           OPERATIONAL   GREEN
0/3               Attention         OPERATIONAL   OFF
                  Status           OPERATIONAL   GREEN
0/FB0             Attention         OPERATIONAL   OFF
                  Status           OPERATIONAL   GREEN
0/FB1             Attention         OPERATIONAL   OFF
                  Status           OPERATIONAL   GREEN
0/FT0             Status/Attention OPERATIONAL   GREEN
0/FT1             Status/Attention OPERATIONAL   GREEN
0/FT2             Status/Attention OPERATIONAL   GREEN
0/FT3             Status/Attention OPERATIONAL   GREEN
0/FT4             Status/Attention OPERATIONAL   GREEN
0/FT5             Status/Attention OPERATIONAL   GREEN
0/FT6             Status/Attention OPERATIONAL   GREEN
0/FT7             Status/Attention OPERATIONAL   GREEN
0/PM0             Attention         OPERATIONAL   OFF
                  Fault           OPERATIONAL   OFF
                  Input          OPERATIONAL   GREEN
                  Output         OPERATIONAL   GREEN
0/PM1             Attention         OPERATIONAL   OFF
                  Fault           OPERATIONAL   OFF
                  Input          OPERATIONAL   GREEN
                  Output         OPERATIONAL   GREEN
0/RP0/CPU0        Attention         OPERATIONAL   OFF
                  BITS           OPERATIONAL   OFF
                  GNSS          OPERATIONAL   OFF
                  GPS           OPERATIONAL   OFF
                  RP-Active     OPERATIONAL   GREEN
                  Status        OPERATIONAL   BLINKING RED
                  Sync          OPERATIONAL   OFF
                  Timing-PTP    OPERATIONAL   OFF
0/RP1/CPU0        Attention         OPERATIONAL   OFF
```

```

BITS OPERATIONAL OFF
GNSS OPERATIONAL OFF
GPS OPERATIONAL OFF
RP-Active OPERATIONAL OFF
Status OPERATIONAL GREEN
Sync OPERATIONAL OFF
Timing-PTP OPERATIONAL OFF
0/SC0
Attention OPERATIONAL OFF
Status OPERATIONAL GREEN
0/SC1
Attention OPERATIONAL OFF
Status OPERATIONAL GREEN

```

show hw-module fpd command

The following example shows a sample output from the **show hw-module fpd** command:

```

Router#show hw-module fpd
Wed Jul 12 14:41:23.437 UTC

```

```

Auto-upgrade:Enabled
Attribute codes: B golden, P protect, S secure, A Anti Theft aware

```

Location	Card type	HWver	FPD device	ATR	Status	FPD Versions	
						Running	Programd
0/RP0/CPU0	8608-RP	1.0	Bios	S	CURRENT	1.09	1.09
0/RP0/CPU0	8608-RP	1.0	BiosGolden	BS	CURRENT		1.01
0/RP0/CPU0	8608-RP	1.0	IoFpga	S	CURRENT	1.09	1.09
0/RP0/CPU0	8608-RP	1.0	IoFpgaGolden	BS	CURRENT		1.09
0/RP0/CPU0	8608-RP	1.0	SsdMicron7300M2		CURRENT	2.60	2.60
0/RP0/CPU0	8608-RP	1.0	x86Fpga	S	CURRENT	1.07	1.07
0/RP0/CPU0	8608-RP	1.0	x86FpgaGolden	BS	CURRENT		1.07
0/RP0/CPU0	8608-RP	1.0	x86TamFw	S	CURRENT	7.12	7.12
0/RP0/CPU0	8608-RP	1.0	x86TamFwGolden	BS	CURRENT		7.12
0/RP1/CPU0	8608-RP	1.0	Bios	S	CURRENT	1.09	1.09
0/RP1/CPU0	8608-RP	1.0	BiosGolden	BS	CURRENT		1.01
0/RP1/CPU0	8608-RP	1.0	IoFpga	S	CURRENT	1.09	1.09
0/RP1/CPU0	8608-RP	1.0	IoFpgaGolden	BS	CURRENT		1.09
0/RP1/CPU0	8608-RP	1.0	SsdMicron7300M2		CURRENT	2.60	2.60
0/RP1/CPU0	8608-RP	1.0	x86Fpga	S	CURRENT	1.07	1.07
0/RP1/CPU0	8608-RP	1.0	x86FpgaGolden	BS	CURRENT		1.07
0/RP1/CPU0	8608-RP	1.0	x86TamFw	S	CURRENT	7.12	7.12
0/RP1/CPU0	8608-RP	1.0	x86TamFwGolden	BS	CURRENT		7.12

```

0/RP1
0/PM0    PSU3.2KW-ACPI    1.0    EM-LogicMCU    CURRENT    0.10    0.10
NOT REQ
0/PM0    PSU3.2KW-ACPI    1.0    EM-PrimMCU    CURRENT    0.02    0.02
NOT REQ
0/PM0    PSU3.2KW-ACPI    1.0    EM-SecMCU    CURRENT    0.02    0.02
NOT REQ
0/PM1    PSU3.2KW-ACPI    1.0    EM-LogicMCU    CURRENT    0.10    0.10
NOT REQ
0/PM1    PSU3.2KW-ACPI    1.0    EM-PrimMCU    CURRENT    0.02    0.02
NOT REQ
0/PM1    PSU3.2KW-ACPI    1.0    EM-SecMCU    CURRENT    0.02    0.02
NOT REQ
0/0      86-MPA-4FH-M     1.0    IoFpga        S    CURRENT    1.02    1.02
0/0
0/0      86-MPA-4FH-M     1.0    IoFpgaGolden  BS    CURRENT    1.02
0/0
0/3      86-MPA-14H2FH-M  1.0    IoFpga        S    CURRENT    1.02    1.02
0/3
0/3      86-MPA-14H2FH-M  1.0    IoFpgaGolden  BS    CURRENT    1.02
0/3
0/SC0    8608-SC0-128    1.0    IoFpga        S    CURRENT    1.01    1.01
0/SC0
0/SC0    8608-SC0-128    1.0    IoFpgaGolden  BS    CURRENT    1.01
0/SC0
0/SC1    8608-SC0-128    1.0    IoFpga        S    CURRENT    1.01    1.01
0/SC1
0/SC1    8608-SC0-128    1.0    IoFpgaGolden  BS    CURRENT    1.01
0/SC1
0/SC1    8608-SC0-128    1.0    IoFpgaGolden  BS    CURRENT    1.01
0/SC1
0/FB0    8608-SC0-128 [FB]  1.0    IoFpga        CURRENT    1.10    1.10
NOT REQ
0/FB0    8608-SC0-128 [FB]  1.0    IoFpgaGolden  B    CURRENT    1.07
NOT REQ
0/FB1    8608-SC0-128 [FB]  1.0    IoFpga        CURRENT    1.10    1.10
NOT REQ
0/FB1    8608-SC0-128 [FB]  1.0    IoFpgaGolden  B    CURRENT    1.07
NOT REQ

```

show alarms brief system active command

The following example shows a sample output from the **show alarms brief system active** command:

```

Router#show alarms brief system active
Wed Jul 12 14:41:31.583 UTC

-----
Active Alarms
-----
Location          Severity    Group      Set Time          Description
-----
0                  Major      Environ    07/12/2023 14:03:04 UTC  Power Module
redundancy lost

```

show media command

The following example shows a sample output from the **show media** command:

```

Router#show media
Wed Jul 12 14:41:36.162 UTC

Media Info for Location: node0_RP0_CPU0
Partition                Size      Used  Percent  Avail
-----
rootfs:                  71.6G    9.7G    13%     62G
data:                   339.1G    2.7G     1%    336.5G
/var/lib/docker         9.4G     37M     1%     8.8G
disk0:                  9.4G     37M     1%     8.8G
log:                    9.4G    173M     2%     8.7G
harddisk:               71G     704M     2%     66G

```

show inventory command

The following example shows a sample output from the **show inventory** command:

```

Router#show inventory
Wed Jul 12 14:41:39.052 UTC
NAME: "Rack 0", DESCR: "Cisco 8600 - 8 Slot Centralized Chassis"
PID: 8608-SYS          , VID: V00, SN: FOX2635PQK0

NAME: "0/RP0/CPU0", DESCR: "Cisco 8608 Route Processor"
PID: 8608-RP          , VID: V01, SN: FOC2520N3KW

NAME: "0/RP1/CPU0", DESCR: "Cisco 8608 Route Processor"
PID: 8608-RP          , VID: V01, SN: FOC2520N3LT

NAME: "0/0", DESCR: "Cisco 8600 4x400G RedundantMPA"
PID: 86-MPA-4FH-M     , VID: V01, SN: FOC2539NXBZ

NAME: "FourHundredGigE0/0/0/0", DESCR: "Non-Cisco QSFPDD 400G PASSIVE COPPER Pluggable
Optics Module"
PID: 2323766-2       , VID: 2, SN: 18169373

NAME: "FourHundredGigE0/0/0/1", DESCR: "Non-Cisco QSFPDD 400G PASSIVE COPPER Pluggable
Optics Module"
PID: 2323766-2       , VID: 2, SN: 18169373

NAME: "FourHundredGigE0/0/0/2", DESCR: "Non-Cisco QSFPDD 400G PASSIVE COPPER Pluggable
Optics Module"
PID: 2323766-2       , VID: 2, SN: 18169307

NAME: "FourHundredGigE0/0/0/3", DESCR: "Non-Cisco QSFPDD 400G PASSIVE COPPER Pluggable
Optics Module"
PID: 2323766-2       , VID: 2, SN: 18169307

NAME: "0/3", DESCR: "Cisco 8600 14x100G and 2x400G Combo Redundant MPA"
PID: 86-MPA-14H2FH-M , VID: V01, SN: FOC2448N8ZA

NAME: "HundredGigE0/3/0/9", DESCR: "Cisco QSFP28 100G SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V02, SN: AVF2202S1Y1

NAME: "HundredGigE0/3/0/2", DESCR: "Cisco QSFP28 100G SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V02, SN: AVF2227S0MZ

NAME: "HundredGigE0/3/0/8", DESCR: "Cisco QSFP28 100G SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V02, SN: AVF2144S2JH

NAME: "0/SC0", DESCR: "Cisco 8608 12.8T Switch Card"
PID: 8608-SC0-128    , VID: V01, SN: FOC2708N583

NAME: "0/SC1", DESCR: "Cisco 8608 12.8T Switch Card"

```



```

PID: 8608-SCO-128      , VID: V01, SN: FOC2708N57N

NAME: "0/FB0", DESCR: "8608 Fan Controller Board on 8608-SCO-128"
PID: 8608-SCO-128[FB] , VID: V01, SN: FOC2708N52Y

NAME: "0/FB1", DESCR: "8608 Fan Controller Board on 8608-SCO-128"
PID: 8608-SCO-128[FB] , VID: V01, SN: FOC2708N24B

NAME: "0/FT0", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV26307038

NAME: "0/FT1", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV26307054

NAME: "0/FT2", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV26307046

NAME: "0/FT3", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV2630703U

NAME: "0/FT4", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV2630701R

NAME: "0/FT5", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV2630705C

NAME: "0/FT6", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV26307048

NAME: "0/FT7", DESCR: "CISCO 8608 FAN"
PID: 8608-FAN          , VID: V01, SN: NCV2630705S

NAME: "0/PM0", DESCR: "Cisco 3.2KW AC Power Supply Unit"
PID: PSU3.2KW-ACPI    , VID: V01, SN: ART2522B035

NAME: "0/PM1", DESCR: "Cisco 3.2KW AC Power Supply Unit"
PID: PSU3.2KW-ACPI    , VID: V01, SN: ART2546B00S

```

show environment power command

The following example shows a sample output from the **show environment power** command:

```

Router#show environment power
Wed Jul 12 14:41:45.688 UTC
=====
CHASSIS LEVEL POWER INFO: 0
=====
Total output power capacity (N + 1)      : 6400W + 0W
Total output power required              : 4412W
Total power input                        : 787W
Total power output                       : 705W
=====
Power      Supply      -----Input-----  -----Output---  Status
Module    Type              Volts    Amps    Volts    Amps
=====
0/PM0     PSU3.2KW-ACPI      213.2    2.0    54.7    6.9    OK
0/PM1     PSU3.2KW-ACPI      212.6    1.7    54.7    6.0    OK

Total of Power Modules:                787W/3.7A                705W/12.9A
=====
Location  Card Type              Power      Power      Status

```

		Allocated Watts	Used Watts	
0/RP0/CPU0	8608-RP	200	49	ON
0/RP1/CPU0	8608-RP	200	49	ON
0/SC0	8608-SC0-128	550	168	ON
0/SC1	8608-SC0-128	550	166	ON
0/FB0	8608-SC0-128 [FB]	10	-	ON
0/FB1	8608-SC0-128 [FB]	10	-	ON
0/0	86-MPA-4FH-M	350	125	ON
0/1	-	32	-	RESERVED
0/2	-	32	-	RESERVED
0/3	86-MPA-14H2FH-M	350	159	ON
0/4	-	32	-	RESERVED
0/5	-	32	-	RESERVED
0/6	-	32	-	RESERVED
0/7	-	32	-	RESERVED
0/FT0	8608-FAN	250	10	ON
0/FT1	8608-FAN	250	9	ON
0/FT2	8608-FAN	250	10	ON
0/FT3	8608-FAN	250	10	ON
0/FT4	8608-FAN	250	10	ON
0/FT5	8608-FAN	250	9	ON
0/FT6	8608-FAN	250	10	ON
0/FT7	8608-FAN	250	10	ON

show environment fan command

The following example shows a sample output from the **show environment fan** command:

```
Router#show environment fan
Wed Jul 12 14:41:50.676 UTC
=====
Location          FRU Type          Fan speed (rpm)
                  FAN_0            FAN_1
-----
0/FT0             8608-FAN          2880    2850
0/FT1             8608-FAN          2820    2880
0/FT2             8608-FAN          2820    2820
0/FT3             8608-FAN          2880    2910
0/FT4             8608-FAN          2880    2910
0/FT5             8608-FAN          2850    2850
0/FT6             8608-FAN          2880    2910
0/FT7             8608-FAN          2910    2880
0/PM0             PSU3.2KW-ACPI     5247    5225
0/PM1             PSU3.2KW-ACPI     5247    5204 G
```

show environment temperature location/location command

The following example shows a sample output from the **show environment temperature location** command. The location specified is **0/RP0/CPU0**:

```
Router#show environment temperature location 0/RP0/CPU0
Wed Jul 12 14:42:31.532 UTC
=====
Location  TEMPERATURE          Value    Crit    Major    Minor    Minor
Major    Crit
Sensor    (deg C)    (Lo)    (Lo)    (Lo)    (Hi)
(Hi)    (Hi)
-----
```

0/RP0/CPU0	Inlet_Temp	27	-10	0	5	NA
50	55					
	X86_CORE_5_T	67	-10	-5	0	NA
100	105					
	DIMM_TEMP1	38	-10	-5	0	NA
95	100					
	DIMM_TEMP2	37	-10	-5	0	NA
95	100					
	SSD_Temp	40	-10	-5	0	NA
80	83					
	T1_2PLUS1_TEMP	43	-10	0	5	NA
105	115					
	T1_1PLUS1_TEMP	39	-10	0	5	NA
105	115					
	Outlet_Temp	38	-10	-5	0	NA
110	115					
	Hot_Spot_Temp	40	NA	NA	NA	NA
NA	140					
	X86_PKG_TEMP	66	-10	-5	0	NA
100	105					
	X86_CORE_0_T	66	-10	-5	0	NA
100	105					
	X86_CORE_1_T	66	-10	-5	0	NA
100	105					
	X86_CORE_2_T	66	-10	-5	0	NA
100	105					
	X86_CORE_3_T	66	-10	-5	0	NA
100	105					
	X86_CORE_4_T	67	-10	-5	0	NA
100	105					

show environment voltage location/location command

The following example shows a sample output from the **show environment voltage location** command. The location specified is **0/RP0/CPU0**:

```
Router#show environment voltage location 0/RP0/CPU0
Wed Jul 12 14:42:40.711 UTC
```

Location	VOLTAGE Sensor	Value (mV)	Crit (Lo)	Minor (Lo)	Minor (Hi)	Crit (Hi)
0/RP0/CPU0	P55V	55025	44400	53000	57000	60000
	P1V0_ADC	999	900	950	1050	1100
	P2V5_ADC	2514	2250	2375	2625	2750
	MGTAVTT_OMG_ADC	1196	1080	1140	1260	1320
	EN_VP3P3_ADC	3265	3003	3135	3465	3597
	P1V8_OMG_ADC	1800	1620	1710	1890	1980
	P0V9_ADC	894	810	855	945	990
	IBV	12000	10800	11040	12840	13200
	VP3P3_I210	3307	3003	3135	3465	3597
	VP1P0_VCS	998	910	950	1050	1090
	VP2P5_VCS	2509	2275	2375	2625	2725
	P3V3_ADC	3318	2970	3135	3465	3630
	VP1V8_ZL	1800	1638	1710	1890	1962
	VP3P3_ZL	3300	3003	3135	3465	3597
	VP1P8_OCXO	1800	1638	1710	1890	1962
	VP3P3_OCXO	3299	3003	3135	3465	3597
	VP3P89	3890	3610	3770	4010	4160
	VP3P3_STBY	3299	3003	3135	3465	3597

VP2P5	2510	2275	2375	2625	2725
VP3P3_HWL	3306	3003	3135	3465	3597
VP7P0	7000	6300	6440	7560	7700
VP3V3_GNSS	3307	3003	3135	3465	3597
P5V0_ADC	5032	4550	4750	5250	5450
VP5P0_ANT	5015	4550	4750	5250	5450
VP1P3_CPU	1300	1183	1235	1365	1417
VP1P5_CPU	1500	1350	1380	1620	1650
VP1P7_CPU	1699	1590	1640	1760	1810
VP3P3_CPU	3305	3003	3135	3465	3597
VP1P8_CPU	1785	1638	1710	1890	1962
VP0P6_A_CPU	592	540	552	648	660
VP1P05_CPU	1050	950	970	1130	1160
VP1P2_CPU	1197	1080	1100	1300	1320
VP1P05_CPU_VCCSCSUS	1050	950	970	1130	1160
P5VISO_ADC	5030	4550	4750	5250	5450
VP1P2_CPUFPGA_CORE	1200	1080	1100	1300	1320
VP3P3_SATA	3303	3003	3135	3465	3597
PVCCIN	1783	1638	1710	1890	1962
P1V05_VCCSCSUS	1050	950	970	1130	1160
P1V2_VDDQ	1199	1080	1100	1300	1320
P1V05_COMBINED	1050	950	970	1130	1160
USB_5VA_ADC	5030	4550	4750	5250	5450
P3V3_BPID_ADC	3315	3003	3135	3465	3597
P5V0_CHLED_ADC	5032	4550	4750	5250	5450
P1V0_MGT_ADC	999	900	950	1050	1100

show environment current location *location* command

The following example shows a sample output from the **show environment current location** command. The location specified is **0/RP0/CPU0**:

```
Router#show environment current location 0/RP0/CPU0
Wed Jul 12 14:42:48.023 UTC
```

Location	CURRENT Sensor	Value (mA)

0/RP0/CPU0	P55V_CURRENT	897
	CPU_CORE_CURRENT	11468
	P1V05_SUS_CURRENT	748
	DDR4_CURRENT	2058
	P1V05_IO_CURRENT	2335

show platform domain command

The following example shows a sample output from the **show platform domain** command:

```
Router#show platform domain
Wed Jul 19 21:50:13.913 UTC
```

ID	Name	Lead	HA Role	State

1	DOMAIN_RP0_SC0	0/RP0/CPU0	ACTIVE	READY
2	DOMAIN_RP1_SC1	0/RP1/CPU0	STANDBY	READY