



Secure Logging Commands

This module describes the Cisco IOS XR software commands used to configure secure logging on the Cisco 8000 Series Routers over Transport Layer Security (TLS). TLS, the successor of Secure Socket Layer (SSL), is an encryption protocol designed for data security over networks.

For detailed information about secure logging concepts, configuration tasks, and examples, see the *Implementing Secure Logging* module in the *System Security Configuration Guide for Cisco 8000 Series Routers*.

- [address](#), on page 2
- [logging tls-server](#), on page 3
- [tls-hostname](#) , on page 4
- [tlsv1-disable](#), on page 5
- [trustpoint](#) , on page 6
- [vrf](#), on page 7

address

To configure the syslog server settings with IP address, use the **address** command in logging TLS peer configuration mode. To remove the configuration, use the **no** form of this command.

address { **IPv4** *ipv4-address* | **IPv6** *ipv6-address* }

Syntax Description

ipv4-address IPv4 address in A.B.C.D format.

ipv6-address IPv6 address in X:X::X format.

Command Default

None

Command Modes

Logging TLS peer configuration mode

Command History

Release	Modification
Release 6.2.1	This command was introduced.

Usage Guidelines

You can use the IPv4 or IPv6 address of the server to access the remote syslog server.

Task ID

Task ID	Operations
logging	Read, Write

Examples

The following example shows how to configure syslog server settings with IPv4 address:

```
Router(config)# logging tls-server TEST
Router(config-logging-tls-peer)# severity debugging
Router(config-logging-tls-peer)# trustpoint tp
Router(config-logging-tls-peer)# address ipv4 10.105.230.83
```

Related Commands

Command	Description
logging tls-server, on page 3	Configures syslog over TLS server.
trustpoint , on page 6	Configures the trustpoint for the TLS server.

logging tls-server

To configure System Logging over Transport Layer Security (TLS) server, use the **logging tls-server** command in Global Configuration mode. To remove the configuration, use the **no** form of this command.

logging tls-server *tls-name*

Syntax Description	<i>tls-name</i> User-defined name for the TLS server.				
Command Default	None				
Command Modes	Global configuration mode				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 6.2.1</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 6.2.1	This command was introduced.
Release	Modification				
Release 6.2.1	This command was introduced.				
Usage Guidelines	This command enters the logging TLS peer configuration mode, where you can configure the settings to access the remote syslog server.				
Task ID	<table><tr><th>Task ID</th><th>Operation</th></tr><tr><td>logging</td><td>read, write</td></tr></table>	Task ID	Operation	logging	read, write
Task ID	Operation				
logging	read, write				

This example shows how to configure a TLS server that enters the logging TLS peer configuration mode:

```
Router#Configure
Router(config)# logging tls-server TEST
Router(config-logging-tls-peer)#
```

tls-hostname

To configure the syslog server settings with hostname or FQDN of the secure log server, use the **tls-hostname** command in logging TLS peer configuration mode. To remove the configuration, use the **no** form of this command.

tls-hostname *hostname*

Syntax Description

hostname Name of the logging host.

Command Default

None

Command Modes

Logging TLS peer configuration mode

Command History

Release	Modification
Release 6.2.1	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID **Operations**

logging Read,
Write

Examples

The following example shows how to configure syslog server settings with server hostname:

```
Router(config)# logging tls-server TEST
Router(config-logging-tls-peer)# severity debugging
Router(config-logging-tls-peer)# trustpoint tp
Router(config-logging-tls-peer)# tls-hostname xyz.cisco.com
```

Related Commands

Command	Description
logging tls-server, on page 3	Configures syslog over TLS server.
trustpoint , on page 6	Configures the trustpoint for the TLS server.

tlsv1-disable

To disable Transport Layer Security (TLS) version 1.0, use the **tlsv1-disable** command in Global Configuration modeXR Config mode.

tlsv1-disable

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global Configuration modeXR Config mode
----------------------	---

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	system	Read, Write

Examples	The following example shows how to disable TLS version 1.0:
-----------------	---

```
Router(config)# grpc tlsv1-disable
```

trustpoint

To configure syslog server settings with a trustpoint for the TLS server, use the **trustpoint** command in logging TLS peer configuration mode. To remove the configuration, use the **no** form of this command.

trustpoint *trustpoint-name*

Syntax Description	<i>trustpoint-name</i> Name of the configured trustpoint
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Logging TLS peer configuration mode
----------------------	-------------------------------------

Command History	Release	Modification
	Release 6.2.1	This command was introduced.

Usage Guidelines	Ensure that you have already configured the trustpoint name, using the crypto ca trustpoint command.
-------------------------	---

Task ID	Task ID	Operations
	logging	Read, Write

Examples

The following example shows how to configure syslog server settings with trustpoint:

```
Router(config)# logging tls-server TEST
Router(config-logging-tls-peer)# severity debugging
Router(config-logging-tls-peer)# trustpoint tp
```

Related Commands	Command	Description
	logging tls-server, on page 3	Configures syslog over TLS server.

vrf

To configure the VRF option for the TLS server, use the **vrf** command in logging TLS peer configuration mode. To remove the configuration, use the **no** form of this command.

vrf *vrf-name*

Syntax Description	<i>vrf-name</i> VPN Routing/Forwarding instance name.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Logging TLS peer configuration mode
----------------------	-------------------------------------

Command History	Release	Modification
	Release 6.2.1	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	logging	Read, Write

Examples The following example shows how to configure a VRF instance:

```
Router(config)# logging tls-server TEST
Router(config-logging-tls-peer)# vrf vrftest
```

Related Commands	Command	Description
	logging tls-server, on page 3	Configures syslog over TLS server.

