



# Trustworthy Systems Commands

---

This module describes the commands related to trustworthy systems on Cisco IOS XR7 software.

For detailed information about the key components that form the trustworthy security systems, see the *Implementing Trustworthy Systems* chapter in the *System Security Configuration Guide for Cisco NCS 5500 Series Routers*.

- [show platform security integrity log, on page 2](#)

# show platform security integrity log

To display the security integrity logs for the router, use the **show platform security integrity log** command in XR EXEC mode.

```
show platform security integrity log { boot location location-name | runtime file-location
| secure-boot status location location-name }
```

## Syntax Description

<b>boot</b>	Displays boot integrity logs
<b>runtime</b>	Displays integrity measurement architecture (IMA) logs
<b>secure-boot</b>	Displays information related to secure boot

## Command Default

None

## Command Modes

XR EXEC

## Command History

Release	Modification
Release 7.10.1	The command was modified to include the secure boot status.
Release 7.0.12	This command was introduced.

## Usage Guidelines

If the router does not support this secure boot verification functionality, then the status is displayed as *Not Supported*.

## Task ID

Task ID	Operations
	system read, write

## Examples

This example shows how to verify the secure boot status of the router:

```
Router#show platform security integrity log secure-boot status
Wed Aug 10 15:39:17.871 UTC

+-----+
| Node location: node0_RP0_CPU0 |
+-----+
Secure Boot Status: Enabled
Router#
```