



## Point-to-Point Layer 2 Services Commands

---

This section describes the commands used to configure point-to-point services for Layer 2 VPNs.



---

**Note** All commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router that is introduced from Cisco IOS XR Release 6.3.2. References to earlier releases in Command History tables apply to only the Cisco NCS 5500 Series Router.

---



---

**Note**

- Starting with Cisco IOS XR Release 6.6.25, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 560 Series Routers.
- Starting with Cisco IOS XR Release 6.3.2, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router.
- References to releases before Cisco IOS XR Release 6.3.2 apply to only the Cisco NCS 5500 Series Router.
- Cisco IOS XR Software Release 7.0.1 specific updates are not applicable for the following variants of Cisco NCS 540 Series Routers:
  - N540-28Z4C-SYS-A
  - N540-28Z4C-SYS-D
  - N540X-16Z4G8Q2C-A
  - N540X-16Z4G8Q2C-D
  - N540X-16Z8Q2C-D
  - N540-12Z20G-SYS-A
  - N540-12Z20G-SYS-D
  - N540X-12Z16G-SYS-A
  - N540X-12Z16G-SYS-D

---

For detailed information about concepts and configuration, see the Configure Point-to-Point Layer 2 Services chapter in the *L2VPN and Ethernet Services Configuration Guide for Cisco NCS 5500 Series Routers*, *L2VPN and Ethernet Services Configuration Guide for Cisco NCS 540 Series Routers*, and *L2VPN and Ethernet Services Configuration Guide for Cisco NCS 560 Series Routers*.

- [interface \(p2p\)](#), on page 3
- [dynamic-arp-inspection](#), on page 5
- [hw-module profile load-balance algorithm](#), on page 7
- [hw-module profile l2pt-extended-protocols-enable](#), on page 8
- [hw-module storm-control-combine-policer-bw](#), on page 9
- [ip-source-guard](#), on page 10
- [l2vpn](#), on page 11
- [mac limit notification](#), on page 12
- [mac limit threshold](#), on page 13
- [mac secure](#), on page 14
- [mac withdraw](#), on page 16
- [p2p](#), on page 17
- [pw-class \(L2VPN\)](#), on page 18
- [pw-class encapsulation mpls](#), on page 20
- [show ethernet mac-allocation](#), on page 23
- [show l2vpn](#), on page 24
- [show l2vpn collaborators](#), on page 26
- [show l2vpn bridge-domain \(VPLS\)](#), on page 28
- [show l2vpn database](#), on page 32
- [show l2vpn forwarding](#), on page 35
- [show l2vpn forwarding message counters](#), on page 38
- [show l2vpn index](#), on page 43
- [show l2vpn protection main-interface](#), on page 45
- [show l2vpn resource](#), on page 48
- [show l2vpn trace](#), on page 49
- [show l2vpn xconnect](#), on page 52
- [show l2vpn pw-class](#), on page 55
- [storm-control](#), on page 57
- [xconnect group](#), on page 59

# interface (p2p)

To configure an attachment circuit, use the **interface** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

```
interface type interface-path-id l2transport
no interface type interface-path-id l2transport
```

<b>Syntax Description</b>	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or a virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** None

**Command Modes** p2p configuration sub-mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

## Examples

The following example shows how you can configure an attachment circuit on a TenGigE interface:

```
Router# configure
Router(config)# interface TenGigE 0/0/0/10.20 l2transport
Router(config-subif)# encapsulation dot1ad 3000
Router(config-subif)# commit
Router(config-subif)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">l2transport (Ethernet)</a>	Enables Layer 2 transport port mode on an Ethernet interface and enter Layer 2 transport configuration mode.

Command	Description
<code>encapsulation dot1ad</code>	Defines the matching criteria to map 802.1ad frames ingress on an interface to the appropriate service instance.

# dynamic-arp-inspection

To validate Address Resolution Protocol (ARP) packets in a network, use the **dynamic-arp-inspection** command in the l2vpn bridge group bridge domain configuration mode. To disable dynamic ARP inspection, use the **no** form of this command.

**dynamic-arp-inspection** {**logging** | **address-validation** {*src-mac**dst-mac**ipv4*}}

Syntax Description	logging	(Optional) Enables logging.
	<b>Note</b>	When you use the logging option, the log messages indicate the interface on which the violation has occurred along with the IP or MAC source of the violation traffic. The log messages are rate limited at 1 message per 10 seconds.
	<b>Caution</b>	Not all the violation events are recorded in the syslog.
	<b>address-validation</b>	(Optional) Performs address-validation.
	<i>src-mac</i>	Source MAC address in the Ethernet header.
	<i>dst-mac</i>	Destination MAC address in the Ethernet header.
	<i>ipv4</i>	IP addresses in the ARP body.

**Command Default** Dynamic ARP inspection is disabled.

**Command Modes** L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** This example shows how to enable dynamic ARP inspection on bridge bar:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
```

```
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group b1  
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar  
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# dynamic-arp-inspection  
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-dai)#
```

This example shows how to enable dynamic ARP inspection logging on bridge bar:

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# l2vpn  
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group b1  
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar  
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# dynamic-arp-inspection logging  
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-dai)#
```

This example shows how to enable dynamic ARP inspection address validation on bridge bar:

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# l2vpn  
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group b1  
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar  
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# dynamic-arp-inspection address-validation  
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-dai)#
```

# hw-module profile load-balance algorithm

To enable the load-balancing mode for PPPoE traffic in the router, use the **hw-module profile load-balance algorithm** command in the Global Configuration mode.

## hw-module profile load-balance algorithm PPPoE

**Command Default** The load-balancing mode is disabled by default.

**Command Modes** Global Configuration mode

Command History	Release	Modification
	Release 7.4.1	This command was introduced.

**Usage Guidelines** You must reload the affected line card or chassis to enable the load-balancing mode.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows how to enable the load balance mode for PPPoE traffic:

```
Router# configure
Router(config)# hw-module profile load-balance algorithm pppoe
Router(config)# exit
Router# reload
```

# hw-module profile l2pt-extended-protocols-enable

To configure extended Layer 2 protocol tunneling on an Ethernet interface, use the **hw-module profile l2pt-extended-protocols-enable** command in Layer 2 transport configuration mode. To disable a Layer 2 protocol tunneling configuration, use the **no** form of this command.

**hw-module profile l2pt-extended-protocols-enable**  
**no hw-module profile l2pt-extended-protocols-enable**

<b>Syntax Description</b>	<p><b>l2pt-extended-protocols-enable</b> Enables L2PT for the interface. Along with existing tunneling protocols like CDP, PVRST, STP, VTP, the following extended protocols are supported for tunneling by using the <b>hw-module profile l2pt-extended-protocols-enable</b> command:</p> <ul style="list-style-type: none"> <li>• Link Layer Discovery Protocol (LLDP)</li> <li>• Link Aggregation Control Protocol (LACP)</li> <li>• Operation, Administration, Management (OAM)</li> <li>• Ethernet Local Management Interface (ELMI)</li> <li>• EtherChannel Port Aggregation Protocol (PAgP)</li> <li>• Unidirectional Link Detection (UDLD)</li> <li>• Multiple MAC Registration Protocol (MMRP)</li> <li>• Multiple VLAN Registration Protocol (MVRP)</li> <li>• 802.1X protocol</li> </ul>
---------------------------	---

**Syntax Description** This command has no arguments or keywords.

**Command Default** The Layer 2 extended protocols are disabled by default.

**Command Modes** Global Configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.9.1	This command was introduced for NCS 540 series routers.

## Examples

The following example shows how to configure an Ethernet interface to tunnel in the ingress direction with extended Layer 2 protocol tunneling:

```
Router# configure
Router(config)# hw-module profile l2pt-extended-protocols-enable
Router(config)# exit
Router# reload
```



# hw-module storm-control-combine-policer-bw

To increase the storm control policer scale per NPU core, use the **hw-module storm-control-combine-policer-bw** command in the global configuration mode. To disable storm control, use the **no** form of this command.

## hw-module storm-control-combine-policer-bw enable

### Command Default

Storm control combine is disabled by default.

### Command Modes

Global configuration mode

### Command History

Release	Modification
Release 7.4.1	This command was introduced for Cisco NC57 line cards.
Release 7.8.1	This command was modified to support storm control configuration per subinterface.

### Usage Guidelines

You must manually reload the router to activate the **hw-module storm-control-combine-policer-bw enable** command.

### Examples

The following example activates the combined policer mode:

```
Router# configure
Router(config)# hw-module storm-control-combine-policer-bw enable
Router# commit
```

The following example shows storm control configuration per subinterface:

```
Router# configure
Router(config)# hw-module storm-control-combine-policer-bw enable
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# interface HundredGigE0/0/0/1.10
Router(config-l2vpn-bg-bd-ac)# storm-control unknown-unicast pps 500
Router(config-l2vpn-bg-bd-ac)# storm-control multicast pps 2000
Router(config-l2vpn-bg-bd-ac)# storm-control broadcast pps 1000
Router(config-l2vpn-bg-bd-ac)# commit
Router(config-l2vpn-bg-bd-ac)# exit
Router(config-l2vpn-bg-bd)# interface HundredGigE0/0/0/1.20
Router(config-l2vpn-bg-bd-ac)# storm-control unknown-unicast pps 200
Router(config-l2vpn-bg-bd-ac)# storm-control multicast pps 1000
Router(config-l2vpn-bg-bd-ac)# storm-control broadcast pps 2000
Router(config-l2vpn-bg-bd-ac)# commit
Router(config-l2vpn-bg-bd-ac)# exit
```

# ip-source-guard

To enable source IP address filtering on a layer 2 port, use the **ip-source-guard** command in l2vpn bridge group bridge domain configuration mode. To disable source IP address filtering, use the **no** form of this command.

## ip-source-guard logging

<b>Syntax Description</b>	<b>logging</b> (Optional) Enables logging.				
<b>Command Default</b>	IP Source Guard is disabled.				
<b>Command Modes</b>	l2vpn bridge group bridge domain configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.9.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.9.1	This command was introduced.
Release	Modification				
Release 7.9.1	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write
Task ID	Operations				
l2vpn	read, write				

## Examples

This example shows how to enable ip source guard on bridge bar:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group b1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# ip-source-guard
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-ipsg)#
```

This example shows how to enable ip source guard logging on bridge bar:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group b1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# ip-source-guard logging
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-ipsg)#
```

# l2vpn

To enter L2VPN configuration mode, use the **l2vpn** command in the Global Configuration mode. To return to the default behavior, use the **no** form of this command.

**l2vpn**  
**no l2vpn**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global Configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

## Examples

The following example shows how to enter L2VPN configuration mode:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)#
```

# mac limit notification

To generate syslog messages and SNMP trap notifications, use the **mac limit notification** command in the L2VPN BD configuration mode.

**mac limit notification** [{**both** | **none** | **trap** }]

Syntax Description	
<b>both</b>	Generates syslog message and SNMP trap messages.
<b>none</b>	No notifications are generated.
<b>trap</b>	Generates only SNMP trap messages

**Command Default** None.

**Command Modes** L2VPN bridge-domain configuration mode

Command History	Release	Modification
	Release 6.1.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read, write

## Example

This example shows how to generate syslogs and SNMP trap messages:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group 555
Router(config-l2vpn-bg)# bridge-domain 666
Router(config-l2vpn-bg-bd)# mac limit notification both
Router(config-l2vpn-bg-bd)#commit
```

# mac limit threshold

To configure MAC address limit threshold value, use the **mac limit threshold** command in the L2VPN configuration mode.

**mac limit threshold** *value*

<b>Syntax Description</b>	<i>value</i> Specifies MAC limit threshold value. The valid range is 0 - 100 %.				
<b>Command Default</b>	75%.				
<b>Command Modes</b>	L2VPN configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.0	This command was introduced.
Release	Modification				
Release 6.1.0	This command was introduced.				
<b>Usage Guidelines</b>	MAC address limit action applies only when the number of local MAC addresses exceeds the configured limit. The software unlearns the MAC addresses until it reaches the configured MAC limit threshold value. Later, the router restarts learning new MAC addresses. In the event when the MAC limit threshold is not configured, the default threshold is 75% of the configured MAC address limit.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

## Example

This example shows how to configure MAC limit threshold of 80%:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# mac limit threshold 80
Router(config-l2vpn)#commit
```

## mac secure

To configure MAC security at a port and to set the action that is to be taken when security is violated, use the **mac secure** command in the L2VPN bridge-group, bridge-domain configuration mode or in the EVPN configuration mode.

To configure MAC security in the L2VPN bridge-group, bridge-domain configuration mode use:

```
mac secure { action [{ none | shutdown } ] | logging | threshold | shutdown-recovery-timeout timer-value }
```

Syntax Description		
	<b>action</b>	(Optional) Indicates the action to be taken when security is violated.
	<b>none</b>	Forwards the violating packet and allows the MAC address to be relearned.
	<b>shutdown</b>	Shuts down the violating bridge port.
	<b>logging</b>	(Optional) Enables logging.
	<b>threshold</b>	Enables threshold based mac secure.
	<b>shutdown-recovery-timeout timer-value</b>	Sets the Recovery timer to revert shutdown action automatically after the timer expires. Recovery timer value can be set in the range of 10 to 3600 seconds.

To configure MAC security in the EVPN configuration mode use:

```
mac secure [ freeze-time freeze-time | move-count move-count | move-interval move-interval | retry-count retry-count | | reset-freeze-count-interval interval ] disable
```

Syntax Description		
	<b>freeze-time freeze-time</b>	Length of time to lock the MAC address after it has been detected as duplicate. Default is 30 seconds.
	<b>move-count move-count</b>	Number of moves to occur within the specified <b>move-interval</b> before freezing the MAC address. Default is 5.
	<b>move-interval move-interval</b>	Interval to watch for subsequent MAC moves before freezing the MAC address. Default is 180 seconds.
	<b>retry-count retry-count</b>	Number of times to unfreeze a MAC address before freezing it permanently. Default is three times.
	<b>reset-freeze-count-interval interval</b>	Interval after which the count of duplicate detection events is reset. Default is 24 hours. The range is from 1 hour to 48 hours.
	<b>disable</b>	Disable duplicate detection of MAC address.

**Command Default** None

**Command Modes** L2VPN bridge-group, bridge-domain configuration

EVPN configuration

Command History	Release	Modification
	Release 7.5.1	This command was introduced.

**Usage Guidelines** MAC secure is supported on physical and bundle AC, PW, and EVPN.

Task ID	Task ID	Operations
	l2vpn	Read, write

### Examples

This example shows how to enable MAC security in the L2VPN bridge-group, bridge-domain configuration mode.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge-group BG1
Router(config-l2vpn-bg)# bridge-domain BD1
Router(config-l2vpn-bg-bd)# mac secure
Router(config-l2vpn-bg-bd-mac-sec)# action shutdown
Router(config-l2vpn-bg-bd-mac-sec)# threshold
Router(config-l2vpn-bg-bd-mac-sec)# shutdown-recovery-timeout 300
Router(config-l2vpn-bg-bd-mac-sec)# exit
Router(config-l2vpn-bg-bd)# interface GigabitEthernet0/2/0/0.1
Router(config-l2vpn-bg-bd-ac)# exit
Router(config-l2vpn-bg-bd)# interface GigabitEthernet0/2/0/0.2
Router(config-l2vpn-bg-bd-ac)# commit
```

### Examples

This example shows how to enable MAC security in the EVPN configuration mode.

```
Router# configure
Router(config)# evpn
Router(config-evpn)# mac secure
Router(config-evpn-mac-secure)# move-count 7
Router(config-evpn-mac-secure)# move-interval 30
Router(config-evpn-mac-secure)# commit
```

# mac withdraw

To enable MAC address withdrawal for a specified bridge domain, use the **mac withdraw** command in L2VPN configuration mode.

**mac withdraw** [**disable** | **optimize** | **state-down**]

Syntax Description	disable	optimize	state-down
	Disables MAC address withdrawal.	Enables optimization of MAC address withdrawal when the bridge port goes down.	Sends MAC address withdrawal message when the bridge port goes down.

**Command Default** None

**Command Modes** L2VPN configuration mode

Command History	Release	Modification
	Release 6.6.25	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

The following example shows how to disable MAC address withdrawal.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to configure MAC address withdrawal when the bridge port goes down.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw state-down
```

The following example shows how to configure optimization of MAC address withdrawal when the bridge port goes down.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw optimize
```



# p2p

To configure point-to-point cross-connects and to enter p2p configuration submode, use the **p2p** command in L2VPN xconnect mode. To return to the default behavior, use the **no** form of this command.

```
p2p xconnect-name
no p2p xconnect-name
```

<b>Syntax Description</b>	<i>xconnect-name</i> (Optional) Configures the name of the point-to-point cross- connect.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	L2VPN xconnect
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.

<b>Usage Guidelines</b>	The name of the point-to-point cross-connect string is a free format description string.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

**Examples** The following example shows a point-to-point cross-connect configuration:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# xconnect group XCON1
Router(config-l2vpn-xc)# p2p XCON1_P2P3
Router(config-l2vpn-xc-p2p)# interface TenGigE0/0/0/0
Router(config-l2vpn-xc-p2p)# interface TenGigE0/0/0/8
Router(config-l2vpn-xc-p2p)# commit
```

## pw-class (L2VPN)

To enter pseudowire class sub-mode to define a pseudowire class template, use the **pw-class** command in L2VPN configuration sub-mode. To delete the pseudowire class, use the **no** form of this command.

```
pw-class class-name
no pw-class class-name
```

<b>Syntax Description</b>	<i>class-name</i> Pseudowire class name.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	L2VPN configuration sub-mode
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--



**Note** All L2VPN configurations can be deleted using the **no l2vpn** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to define a simple pseudowire class:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# xconnect group l1vpn
Router(config-l2vpn-xc)# p2p rtrA_to_rtrB
Router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
Router(config-l2vpn-xc-p2p-pw)# pw-class kanata01
Router(config-l2vpn-xc-p2p-pw)# encapsulation mpls
Router(config-l2vpn-xc-p2p-pw)# exit
Router(config-l2vpn-xc-p2p)# exit
Router(config-l2vpn)# commit
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">interface (p2p), on page 3</a>	Configures an attachment circuit.

<b>Command</b>	<b>Description</b>
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
<a href="#">show l2vpn xconnect, on page 52</a>	Displays brief information on configured cross-connects.
<a href="#">show l2vpn pw-class, on page 55</a>	Displays L2VPN pseudowire class information.

## pw-class encapsulation mpls

To configure MPLS pseudowire encapsulation, use the **pw-class encapsulation mpls** command in L2VPN pseudowire class configuration mode. To undo the configuration, use the **no** form of this command.

```
pw-class class-name encapsulation mpls {control word | ipv4 | load-balancing flow-label |
preferred-path | protocol ldp | redundancy one-way | sequencing | tag-rewrite | transport-mode | vccv
verification-type none}
```

```
no pw-class class-name encapsulation mpls {control word | ipv4 | load-balancing flow-label |
preferred-path | protocol ldp | redundancy one-way | sequencing | tag-rewrite | transport-mode | vccv
verification-type none}
```

Syntax Description		
	<i>class-name</i>	Encapsulation class name.
	<b>control word</b>	Disables control word for MPLS encapsulation. Disabled by default.
	<b>ipv4</b>	Sets the local source IPv4 address.
	<b>load-balancing flow-label</b>	Sets flow label-based load balancing.
	<b>preferred-path</b>	Configures the preferred path tunnel settings.
	<b>protocol ldp</b>	Configures LDP as the signaling protocol for this pseudowire class.
	<b>redundancy one-way</b>	Configures one-way PW redundancy behavior in the Redundancy Group.
	<b>sequencing</b>	Configures sequencing on receive or transmit.
	<b>tag-rewrite</b>	Configures VLAN tag rewrite.

<b>transport-mode</b>	Configures transport mode to be Ethernet. The transport-mode VLAN is not supported.
	<p><b>Note</b> The transport-mode VLAN is not supported for VPWS.</p> <p><b>Note</b> The system does not support transport-mode under pw-class for VPLS. The transport-mode configuration is not supported under pw-class, and it is supported only under bridge domain for NCS 5500.</p>
<b>vccv none</b>	Enables or disables the VCCV verification type.

**Command Default** None

**Command Modes** L2VPN pseudowire class configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.

### Usage Guidelines



**Note** All L2VPN configurations can be deleted using the **no l2vpn** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

This example shows how to define MPLS pseudowire encapsulation:

```
Router# configure
```

```
Router(config)# l2vpn
Router(config-l2vpn)# pw-class kanata01
Router(config-l2vpn-pwc)# encapsulation mpls
```

Related Commands	Command	Description
	<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.

# show ethernet mac-allocation

To display the number of dynamically allocated MAC addresses information, use the **show ethernet mac-allocation** command in the EXEC mode.

**show ethernet mac-allocation** [{ **client** | **clients** | **detail** | **error** | **server** | **statistics** | **summary** | **trace** }]

Syntax Description	<b>client</b> Shows MAC allocation client library trace data.				
	<b>clients</b> Shows the MAC allocation on client information.				
	<b>detail</b> Shows the detailed information of MAC allocation.				
	<b>error</b> Shows error traces only.				
	<b>server</b> Shows MAC allocation server trace data.				
	<b>statistics</b> Shows the statistic details.				
	<b>summary</b> Shows the summary information.				
	<b>trace</b> Shows MAC allocation trace data.				
Command Default	None				
Command Modes	EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td> <td>This command was introduced.  Applicable to N540-28Z4C-SYS-A/D, N540X-16Z4G8Q2C-A/D, N540-12Z20G-SYS-A/D, and N540X-12Z16G-SYS-A/D variants.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command was introduced.  Applicable to N540-28Z4C-SYS-A/D, N540X-16Z4G8Q2C-A/D, N540-12Z20G-SYS-A/D, and N540X-12Z16G-SYS-A/D variants.
Release	Modification				
Release 7.0.1	This command was introduced.  Applicable to N540-28Z4C-SYS-A/D, N540X-16Z4G8Q2C-A/D, N540-12Z20G-SYS-A/D, and N540X-12Z16G-SYS-A/D variants.				

## Example

The following example displays summary of MAC allocation, **show ethernet mac-allocation summary** command.

```
Router# show ethernet mac-allocation summary

Mon Jun 14 04:11:41.168 UTC
Minimum pool size:      3072
Pool increment:        1
Maximum free addresses: Unlimited
Configured pool size:   0 (0 free)
Dynamic pool size:     3072 (3061 free)
Total pool size:       3072 (3061 free)
Number of clients:     2
```

# show l2vpn

To display L2VPN information, use the **show l2vpn** command in the EXEC mode.

## show l2vpn

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task	Operation ID
	l2vpn	read

## Example

The following example displays output for the **show l2vpn** command. The output provides an overview of the state of the globally configured features.

```
Router# show l2vpn

Mon Oct 12 14:14:48.869 UTC
HA role      : Active
ISSU role    : Primary
Process FSM  : PrimaryActive
-----
PW-Status: enabled
PW-Grouping: disabled
Logging PW: disabled
Logging BD state changes: disabled
Logging VFI state changes: disabled
Logging NSR state changes: disabled
TCN propagation: disabled
PW OAM transmit time: 30s
```

Related Commands	Command	Description
	<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
	<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.



Command	Description
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.

# show l2vpn collaborators

To display information about the state of the interprocess communications connections between l2vpn\_mgr and other processes, use the **show l2vpn collaborators** command in EXEC mode.

## show l2vpn collaborators

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task	Operations
	l2vpn	read, write

## Examples

The following example shows sample output for the **show l2vpn collaborators** command:

```
Router# show l2vpn collaborators
Mon Oct 12 14:14:57.373 UTC

L2VPN Collaborator stats:
Name                State          Up Cnts      Down Cnts
-----
LSD                 Up              1             0
```

This table describes the significant fields shown in the display.

**Table 1: show l2vpn collaborators Field Descriptions**

Field	Description
Name	Abbreviated name of the task interacting with l2vpn_mgr.
State	Indicates if l2vpn_mgr has a working connection with the other process.
Up Cnts	Number of times the connection between l2vpn_mgr and the other process has been successfully established.

Field	Description
Down Cnts	Number of times that the connection between l2vpn_mgr and the other process has failed or been terminated.

**Related Commands**

Command	Description
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information

## show l2vpn bridge-domain (VPLS)

To display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains, use the **show l2vpn bridge-domain** command in XR EXEC mode.

```
show l2vpn bridge-domain [{autodiscovery | bd-name bridge-domain-name | brief | detail | group
bridge-domain-group-name | hardware | interface type interface-path-id | pw-id value }] neighbor
IP-address [{pw-id value | pbb | summary}]
```

Syntax Description	
<b>autodiscovery</b>	(Optional) Displays BGP autodiscovery information.
<b>bd-name</b> <i>bridge-domain-name</i>	(Optional) Displays filter information on the <i>bridge-domain-name</i> . The <i>bridge-domain-name</i> argument is used to name a bridge domain.
<b>brief</b>	(Optional) Displays brief information about the bridges.
<b>detail</b>	(Optional) Displays detailed information about the bridges. Also, displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the pseudowire.
<b>group</b> <i>bridge-domain-group-name</i>	(Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.
<b>hardware</b>	(Optional) Displays hardware information.
<b>interface</b> <i>type interface-path-id</i>	(Optional) Displays the filter information for the interface on the bridge domain. <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>neighbor</b> <i>ip-address</i>	(Optional) Displays the bridge domains that contain the pseudowires to match the filter for the neighbor. The <i>ip-address</i> argument is used to specify IP address of the neighbor.
<b>pw-id</b> <i>value</i>	(Optional) Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.
<b>pbb</b>	(Optional) Displays provider backbone bridge information.
<b>summary</b>	(Optional) Displays the summary information for the bridge domain.

**Command Default** None

**Command Modes** XR EXEC mode

**Command History** Release Modification

**Usage Guidelines**

Use the **interface** keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed. No pseudowires are displayed.

When an SR policy is configured as the preferred path for a VPLS circuit, the traffic traverses through the SR policy path. The PW counters are updated with statistics about packets transmitted and received. When the SR policy configuration is deleted, the traffic session is still functional because the traffic transmission switches back to the normal LSP path between the PEs. There is no drop in the end-to-end traffic transmitted. However, the packet statistics counters are reset and start from zero. This is because, when the SR policy is deleted, the PW too gets deleted and the statistics information associated with the old PW is cleared. The counter restarts from zero when the new PW is created after the switch takes place.

**Task ID****Task Operations ID**

l2vpn read

**Examples**

This is the sample output for **show l2vpn bridge-domain** command.

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain bd-name evpn detail
Fri Dec 11 06:58:17.691 UTC
Legend: pp = Partially Programmed.
Bridge group: evpn-aa-irb-inter, bridge-domain: evpn, id: 1797, state: up, ShgId: 0, MSTi:
0
  Coupled state: disabled
  VINE state: EVPN-IRB
  MAC learning: enabled
  MAC withdraw: enabled
    MAC withdraw for Access PW: enabled
    MAC withdraw sent on: bridge port up
    MAC withdraw relaying (access to access): disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 64000, Action: none, Notification: syslog
  MAC limit reached: no, threshold: 99%
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 Snooping: disabled
  DHCPv4 Snooping profile: none
  IGMP Snooping: disabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: disabled
  Bridge MTU: 1500
  MIB cvplsConfigIndex: 1798
  Filter MAC addresses:
  P2MP PW: disabled
  Multicast Source: Not Set
  Create time: 11/12/2020 02:02:56 (04:55:20 ago)
  No status change since creation
  ACs: 2 (2 up), VFIs: 0, PWs: 0 (0 up), PBBs: 0 (0 up), VNIs: 0 (0 up)
  List of EVPNs:
    EVPN, state: up
```

## show l2vpn bridge-domain (VPLS)

```

evi: 2001
XC ID 0x800006a7
Statistics:
  packets: received 0 (unicast 0), sent 0
  bytes: received 0 (unicast 0), sent 0
  MAC move: 0
List of ACs:
AC: BVI10001, state is up
  Type Routed-Interface
  MTU 2000; XC ID 0x80000fa3; interworking none
  BVI MAC address:
    0088.0088.0088
  Split Horizon Group: Access
  PD System Data: AF-LIF-IPv4: 0x00000000 AF-LIF-IPv6: 0x00000000 FRR-LIF: 0x00000000

AC: Bundle-Ether30001.2001, state is up
  Type VLAN; Num Ranges: 1
  Outer Tag: 3001
  Rewrite Tags: []
  VLAN ranges: [2001, 2001]
  MTU 1500; XC ID 0xa00005e0; interworking none; MSTi 1
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 64000, Action: none, Notification: syslog
  MAC limit reached: no, threshold: 99%
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  E-Tree: Root
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 Snooping: disabled
  DHCPv4 Snooping profile: none
  IGMP Snooping: disabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: bridge-domain policer
  Static MAC addresses:
  Statistics:
    packets: received 404672709 (multicast 0, broadcast 0, unknown unicast 0, unicast
0), sent 0
    bytes: received 30835628366 (multicast 0, broadcast 0, unknown unicast 0, unicast
0), sent 0
    MAC move: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0
  Dynamic ARP inspection drop counters:
    packets: 0, bytes: 0
  IP source guard drop counters:
    packets: 0, bytes: 0
  PD System Data: AF-LIF-IPv4: 0x00018919 AF-LIF-IPv6: 0x0001891a FRR-LIF: 0x00000000

List of Access PWs:
List of VFIs:
List of Access VFIs:

```

## Related Commands

Command	Description
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.

Command	Description
<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information

# show l2vpn database

To display L2VPN database, use the **show l2vpn database** command in EXEC mode.

```
show l2vpn database {ac | node}
```

<b>Syntax Description</b>	<b>ac</b> Displays L2VPN Attachment Circuit (AC) database				
	<b>node</b> Displays L2VPN node database.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.0.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.0.1	This command was introduced.
Release	Modification				
Release 6.0.1	This command was introduced.				
<b>Usage Guidelines</b>	Even when xSTP (extended spanning tree protocol) operates in the PVRST mode, the output of the show or debug commands flag prefix is displayed as MSTP or MSTi, instead of PVRST.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read
Task ID	Operation				
l2vpn	read				

The following example displays output for the **show l2vpn database ac** command:

```
Router# show l2vpn database ac

Mon Oct 12 14:15:47.731 UTC
Bundle-Ether1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x3
  Signaled capability valid: Yes
  Signaled capability flags: 0x360018
  Configured capability flags: 0x0
  XCID: 0xa0000001
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-ifname: Bundle-Ether1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x00000000
    ac-type: 0x04
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000003
    segment mtu/l2-mtu: 1500/1514
```



```
TenGigE0/0/0/0.1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x3
  Signaled capability valid: Yes
  Signaled capability flags: 0x360018
  Configured capability flags: 0x0
  XCID: 0xea
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-ifname: TenGigE0_0_0_0.1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x08000018
    ac-type: 0x15
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000003
    segment mtu/l2-mtu: 1504/1518
```

The following example displays output for the **show l2vpn database node** command:

```
Router# show l2vpn database node
Mon Oct 12 14:16:30.540 UTC
Node ID: 0x1000 (0/RP0/CPU0)
MA: vlan_ma      inited:1, flags:0x 2, circuits:3744
  AC event trace history [Total events: 4]
  -----
  Time           Event                               Num Rcvd   Num Sent
  ====           =====                               =
  10/12/2015 12:46:00 Process joined                       0           0
  10/12/2015 12:46:00 Process init success                 0           0
  10/12/2015 12:46:00 Replay start rcvd                   0           0
  10/12/2015 12:46:00 Replay end rcvd                      0           0

MA: ether_ma     inited:1, flags:0x 2, circuits:2
  AC event trace history [Total events: 4]
  -----
  Time           Event                               Num Rcvd   Num Sent
  ====           =====                               =
  10/12/2015 12:41:19 Process joined                       0           0
  10/12/2015 12:41:19 Process init success                 0           0
  10/12/2015 12:41:19 Replay start rcvd                   0           0
  10/12/2015 12:41:19 Replay end rcvd                      0           0

MA: atm_ma       inited:0, flags:0x 0, circuits:0
MA: hdlc_ma      inited:0, flags:0x 0, circuits:0
MA: fr_ma        inited:0, flags:0x 0, circuits:0
MA: ppp_ma       inited:0, flags:0x 0, circuits:0
MA: cem_ma       inited:0, flags:0x 0, circuits:0
MA: vif_ma       inited:0, flags:0x 0, circuits:0
MA: pwhe_ma      inited:0, flags:0x 0, circuits:0
MA: nve_mgr      inited:0, flags:0x 0, circuits:0
MA: mstp         inited:0, flags:0x 0, circuits:0
MA: span         inited:0, flags:0x 0, circuits:0
MA: erp          inited:0, flags:0x 0, circuits:0
MA: erp_test     inited:0, flags:0x 0, circuits:0
```

```
show l2vpn database
```

```
MA: mstp_test    initied:0, flags:0x 0, circuits:0
MA: evpn        initied:0, flags:0x 0, circuits:0
```

### Related Commands

Command	Description
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information

# show l2vpn forwarding

To display forwarding information from the layer2\_fib manager, use the **show l2vpn forwarding** command in EXEC mode.

**show l2vpn forwarding** {**counter** | **debug** | **detail** | **hardware** | **interface** | **location** [*node-id*] | **private**}

Syntax Description		
<b>counter</b>		Displays the cross-connect counters.
<b>debug</b>		Displays debug information.
<b>detail</b>		Displays detailed information from the layer2_fib manager.
<b>hardware</b>		Displays hardware-related layer2_fib manager information.
<b>interface</b>		Displays the match AC subinterface.
<b>location</b> <i>node-id</i>		Displays layer2_fib manager information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>private</b>		Output includes private information.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read

## Examples

The following sample output is from the **show l2vpn forwarding** command:

```
Router# show l2vpn forwarding location 0/RP0/CPU0
Mon Oct 12 14:19:11.771 UTC
Segment 1                               Segment 2                               State
-----
Te0/0/0/0.234                           ac Te0/0/0/26.234                       UP
Te0/0/0/0.233                           ac Te0/0/0/26.233                       UP
Te0/0/0/0.232                           ac Te0/0/0/26.232                       UP
Te0/0/0/0.231                           ac Te0/0/0/26.231                       UP
Te0/0/0/0.230                           ac Te0/0/0/26.230                       UP
```

The following sample output is from the **show l2vpn forwarding counter location** command:

```
Router# show l2vpn forwarding counter location 0/RP0/CPU0

Mon Oct 12 14:18:01.194 UTC
Legend: ST = State, DN = Down

Segment 1                               Segment 2                               ST Byte
-----                               -----                               -
Te0/0/0/0.234                           ac Te0/0/0/26.234                       UP 15098997504
Te0/0/0/0.233                           ac Te0/0/0/26.233                       UP 15098997568
Te0/0/0/0.232                           ac Te0/0/0/26.232                       UP 15098997504
Te0/0/0/0.231                           ac Te0/0/0/26.231                       UP 15098997568
Te0/0/0/0.230                           ac Te0/0/0/26.230                       UP 15098997568
```

The following sample output is from the **show l2vpn forwarding summary location** command:

```
Router# show l2vpn forwarding summary location 0/RP0/CPU0
Mon Oct 12 14:18:25.838 UTC
To Resynchronize MAC table from the Network Processors, use the command...
    l2vpn resynchronize forwarding mac-address-table location <r/s/i>

Major version num:1, minor version num:0
Shared memory timestamp:0xa41120d180
Global configuration:
Number of forwarding xconnect entries:1873
  Up:1873  Down:0
  AC-PW(atom):0 AC-PW(l2tpv2):0 AC-PW(l2tpv3):0
  AC-PW(l2tpv3-ipv6):0
  AC-AC:1873 AC-BP:0 (PWHE AC-BP:0) AC-Unknown:0
  PW-BP:0 PW-Unknown:0
  PBB-BP:0 PBB-Unknown:0
  EVPN-BP:0 EVPN-Unknown:0
  VNI-BP:0 VNI-Unknown:0
  Monitor-Session-PW:0 Monitor-Session-Unknown:0
Number of xconnects down due to:
  AIB:0 L2VPN:0 L3FIB:0 VPDN:0
Number of xconnect updates dropped due to:
  Invalid XID: 0 VPWS PW, 0 VPLS PW, 0 Virtual-AC, 0 PBB,
  0 EVPN
  0 VNI
Exceeded max allowed: 0 VPLS PW, 0 Bundle-AC
Number of p2p xconnects: 1873
Number of bridge-port xconnects: 0
Number of nexthops:0
Number of bridge-domains: 0
  0 with routed interface
  0 with PBB-EVPN enabled
  0 with EVPN enabled
  0 with p2mp enabled
Number of bridge-domain updates dropped: 0
Number of total macs: 0
  0 Static macs
  0 Routed macs
  0 BMAC
  0 Source BMAC
  0 Locally learned macs
  0 Remotely learned macs
Number of total P2MP Ptree entries: 0
Number of PWHE Main-port entries: 0
Number of EVPN Multicast Replication lists: 0 (0 default)
```

The following sample output is from the **show l2vpn forwarding detail location** command:

```
Router# show l2vpn forwarding detail location 0/RP0/CPU0

Mon Oct 12 14:18:47.187 UTC
Local interface: TenGigE0/0/0/0.234, Xconnect id: 0x1, Status: up
  Segment 1
    AC, TenGigE0/0/0/0.234, status: Bound
    Statistics:
      packets: received 238878391, sent 313445
      bytes: received 15288217024, sent 20060480
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, TenGigE0/0/0/26.234, status: Bound

Local interface: TenGigE0/0/0/0.233, Xconnect id: 0x2, Status: up
  Segment 1
    AC, TenGigE0/0/0/0.233, status: Bound
    Statistics:
      packets: received 238878392, sent 313616
      bytes: received 15288217088, sent 20071424
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, TenGigE0/0/0/26.233, status: Bound

Local interface: TenGigE0/0/0/0.232, Xconnect id: 0x3, Status: up
  Segment 1
    AC, TenGigE0/0/0/0.232, status: Bound
    Statistics:
      packets: received 238878391, sent 313476
      bytes: received 15288217024, sent 20062464
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, TenGigE0/0/0/26.232, status: Bound
```

Related Commands	Command	Description
	<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
	<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
	<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
	<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
	<a href="#">show l2vpn database, on page 32</a>	Displays L2VPN database
	<a href="#">show l2vpn forwarding message counters, on page 38</a>	Displays l2vpn forwarding message counters information.

# show l2vpn forwarding message counters

To display L2VPN forwarding messages exchanged with L2FIB Collaborators, use the **show l2vpn forwarding message counters** command in EXEC mode.

**show l2vpn forwarding message counters** {hardware | location *node-id*}

<b>Syntax Description</b>	<b>hardware</b>	Displays message counter information from hardware.
	<b>location</b> <i>node-id</i>	Displays message counter information for the specified location.
<b>Command Default</b>	None	
<b>Command Modes</b>	EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.
<b>Usage Guidelines</b>	Even when xSTP (extended spanning tree protocol) operates in the PVRST mode, the output of the show or debug commands flag prefix is displayed as MSTP or MSTi, instead of PVRST.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read

The following examples shows the output from the **show l2vpn forwarding message counters location** command:

```
Router# show l2vpn forwarding message counters location 0/RP0/CPU0
Mon Oct 12 14:19:41.768 UTC
Messages exchanged with L2FIB Collaborators:
```

```
-----
      Message                               Count      Info1      Info2
      Time
      =====
      =====
      12vpn provision messages received:    7496      0x800001c    0x0
      Oct 12 13:09:38.477
      12vpn unprovision messages received:    0          0x0          0x0
      -
      12vpn bridge provision messages received: 0          0x0          0x0
      -
      12vpn bridge unprovision messages received: 0          0x0          0x0
      -
      12vpn bridge main port update messages received: 0          0x0          0x0
      -
      bdx bridge main port update messages received: 0          0x0          0x0
      -
      12vpn bridge main port update w/ action=MSTI_DELETE 0          0x0          0x0
      -
      12vpn bridge main port update ACK sent: 0          0x0          0x0
```

```

-
bdxc bridge main port update ACK sent:          0          0x0          0x0
-
l2vpn reception of ACK relay msg received:      0          0x0          0x0
-
l2vpn bridge port provision messages received:  0          0x0          0x0
-
l2vpn bridge port unprovision messages received: 0          0x0          0x0
-
l2vpn shg provision messages received:         0          0x0          0x0
-
l2vpn shg unprovision messages received:       0          0x0          0x0
-
l2vpn static mac provision messages received:   0          0x0          0x0
-
l2vpn static mac unprovision messages received: 0          0x0          0x0
-
l2vpn static mac flush messages received:      0          0x0          0x0
-
l2vpn dynamic mac local learning messages received: 0          0x0          0x0
-
l2vpn dynamic mac local learning dropped queue len: 0          0x0          0x0
-
l2vpn dynamic mac local learning dropped cache: 0          0x0          0x0
-
l2vpn dynamic mac local learning dropped multicast: 0          0x0          0x0
-
l2vpn dynamic mac bcast send failed:          0          0x0          0x0
-
l2vpn dynamic mac remote learning messages received 0          0x0          0x0
-
l2vpn dynamic mac refresh messages received:   0          0x0          0x0
-
l2vpn dynamic mac delete/create messages received: 0          0x0          0x0
-
l2vpn dynamic mac no-xid dropped:              0          0x0          0x0
-
l2vpn dynamic local mac unprovision messages:  0          0x0          0x0
-
l2vpn dynamic remote mac unprovision messages: 0          0x0          0x0
-
l2vpn dynamic local mac aged out messages sent: 0          0x0          0x0
-
l2vpn dynamic mac limit message received:      0          0x0          0x0
-
l2vpn dynamic mac delete notification:         0          0x0          0x0
-
l2vpn mac move counter:                        0          0x0          0x0
-
l2vpn qid mac remote:                          0          0x0          0x0
-
l2vpn qid mac remote evpn:                     0          0x0          0x0
-
l2vpn qid mac refresh:                         0          0x0          0x0
-
l2vpn qid mac learning:                       0          0x0          0x0
-
AIB update messages received:                  7494        0x8007502    0x8000150
Oct 12 12:49:44.112
AIB delete messages received:                  0          0x0          0x0
-
FIB nhop registration messages sent:           0          0x0          0x0
-
FIB nhop unregistration messages sent:        0          0x0          0x0

```

## show l2vpn forwarding message counters

```

-
FIB ecd ldi update messages received:          0          0x0          0x0
-
FIB invalid NHOP prov messages received:       0          0x0          0x0
-
l2vpn hw learn MAC update messages received:  0          0x0          0x0
-
l2vpn hw learn MAC BD limit set messages received: 0          0x0          0x0
-
l2vpn hw learn MAC BD limit clr messages received: 0          0x0          0x0
-
l2vpn hw learn MAC BP limit set messages received: 0          0x0          0x0
-
l2vpn hw learn MAC BP limit clr messages received: 0          0x0          0x0
-
l2vpn backbone source mac provision msg received: 1          0x0          0x0
Oct 12 12:41:19.807
l2vpn backbone source mac unprovision msg received: 0          0x0          0x0
-
l2vpn bridge port MAC flush msg received:     0          0x0          0x0
-
bdxc ISSU drop msg received:                   0          0x0          0x0
-
l2vpn ISSU drop msg received:                  0          0x0          0x0
-
l2vpn BD MAC Flush messages received:         0          0x0          0x0
-
l2vpn TCN messages received:                   0          0x0          0x0
-
bdxc G8032 TCN messages transmitted:          0          0x0          0x0
-
l2fib PD failure count:                       0          0x0          0x0
-
bdxc DHCP binding provision msg received:     0          0x0          0x0
-
bdxc DHCP binding unprovision msg received:   0          0x0          0x0
-
bdxc DHCP configuration msg received:         0          0x0          0x0
-
platform DAI violation msg received:          0          0x0          0x0
-
platform IPSG violation msg received:         0          0x0          0x0
-
platform MAC Secure violation msg received:   0          0x0          0x0
-
l2vpn g8032 ring provision msg received:      0          0x0          0x0
-
l2vpn g8032 ring unprovision msg received:    0          0x0          0x0
-
l2vpn g8032 ring inst provision msg received: 0          0x0          0x0
-
l2vpn g8032 ring inst unprovision msg received: 0          0x0          0x0
-
bdxc VPDN L2TPv2 provision msg received:     0          0x0          0x0
-
bdxc VPDN L2TPv2 unprovision msg received:   0          0x0          0x0
-
bdxc VPDN L2TPv2 invalid msg received:       0          0x0          0x0
-
bdxc P2MP PTREE provision msg received:      0          0x0          0x0
-
bdxc P2MP PTREE unprovision msg received:    0          0x0          0x0
-
bdxc P2MP PTREE provision msg dropped:       0          0x0          0x0

```



```

-
  bdxo P2MP PTREE unprovision msg dropped:           0           0x0           0x0
-
  l2vpn reception of protection ack msg received:    0           0x0           0x0
-
  l2vpn GLOBAL messages received:                   1           0x0           0x0
Oct 12 12:41:19.807
  l2vpn BD Flush request messages to l2vpn:         0           0x0           0x0
-
  l2vpn evpn mcast provision msg received:          0           0x0           0x0
-
  l2vpn evpn mcast unprovision msg received:        0           0x0           0x0
-
  l2vpn evpn mcast invalid msg received:           0           0x0           0x0
-
  l2vpn evpn mcast unprovision all msg received:    0           0x0           0x0
-
  l2vpn evpn main port provision msg received:      0           0x0           0x0
-
  l2vpn evpn main port unprovision msg received:    0           0x0           0x0
-
  l2vpn evpn main port invalid msg received:       0           0x0           0x0
-
  l2vpn MVRP request:                               0           0x0           0x0
-
  l2vpn pwgroup status update msg received:        0           0x0           0x0
-

```

The following examples shows the output from the **show l2vpn forwarding message counters hardware location** command:

```

Router# show l2vpn forwarding message counters hardware location 0/$
Mon Oct 12 14:19:59.017 UTC

```

#### Event Statistics Summary

```

-----
          Create      Modify      Bind      Unbind      Delete
LOCXC AC          7492        3748        7496         4           0
VPWS AC           0           0           0           0           0
VPLS AC           0           0           0           0           0
L2TP AC           0           0           0           0           0
VPWS PW           0           0           0           0           0
VPLS PW           0           0           0           0           0
BRIDGE           0           0           0           0           0
BRIDGEPORT       0           0           0           0           0
MAC              0           0           0           0           0
PBB              0           0           0           0           0
DHCP             0           0           0           0           0
L2TP            0           0           0           0           0
L2TP SESSION     0           0           0           0           0

```

#### Performance Statistics Summary

```

-----
          Create      Modify      Delete      Bind      Unbind
LOCXC AC    000.032 s    000.790 s    < 1 ms    000.810 s    000.003 s
VPWS AC     < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms
VPLS AC     < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms
L2TP AC     < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms
VPWS PW     < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms
VPLS PW     < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms
BRIDGE     < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms
BRIDGEPORT < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms
MAC        < 1 ms     < 1 ms     < 1 ms     < 1 ms     < 1 ms

```

**show l2vpn forwarding message counters**

PBB	< 1 ms	< 1 ms	< 1 ms	< 1 ms	< 1 ms
DHCP	< 1 ms	< 1 ms	< 1 ms	< 1 ms	< 1 ms
L2TP	< 1 ms	< 1 ms	< 1 ms	< 1 ms	< 1 ms
L2TP SESSION	< 1 ms	< 1 ms	< 1 ms	< 1 ms	< 1 ms

**Related Commands**

Command	Description
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
<a href="#">show l2vpn database, on page 32</a>	Displays L2VPN database
<a href="#">show l2vpn forwarding, on page 35</a>	Displays forwarding information from the layer2_fib manager on the line card.

# show l2vpn index

To display statistics about the index manager, use the **show l2vpn index** command in EXEC mode.

```
show l2vpn index [{location | private}]private
```

<b>Syntax Description</b>	<b>location</b>	(Optional) Displays index manager statistics for the specified location.
	<b>private</b>	(Optional) Detailed information about all indexes allocated for each pool.
<b>Command Default</b>	None	
<b>Command Modes</b>	EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read

## Examples

This example shows the sample output of the **show l2vpn index** command:

```
Router# show l2vpn index
Mon Oct 12 14:20:20.218 UTC
Pool id: 0x0, App: AC
  Max number of ID mgr instances: 1
  ID mgr instances in use: 1
  Pool size: 32513
  zombied IDs: 0
  allocated IDs: 3745

Pool id: 0xffff80002, App: BD
  Max number of ID mgr instances: 1
  ID mgr instances in use: 1
  Pool size: 8192
  zombied IDs: 0
  allocated IDs: 0

Pool id: 0xffff80003, App: MP2MP
  Max number of ID mgr instances: 1
  ID mgr instances in use: 1
  Pool size: 65535
  zombied IDs: 0
```

```

allocated IDs: 0

Pool id: 0xffff80004, App: RD
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 65536
zombied IDs: 0
allocated IDs: 0

Pool id: 0xffff80005, App: IFLIST
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 65535
zombied IDs: 0
allocated IDs: 1

Pool id: 0xffff80006, App: ATOM
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 131071
zombied IDs: 0
allocated IDs: 0

Pool id: 0xffff80007, App: PWGroup
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 65535
zombied IDs: 0
allocated IDs: 1

Pool id: 0xfffd0000, App: Global
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 16383
zombied IDs: 0
allocated IDs: 2

```

**Related Commands**

Command	Description
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
<a href="#">show l2vpn database, on page 32</a>	Displays L2VPN database
<a href="#">show l2vpn forwarding, on page 35</a>	Displays forwarding information from the layer2_fib manager on the line card.

# show l2vpn protection main-interface

To display an overview of the main interface or instance operational information, use the **show l2vpn protection main-interface** command in EXEC mode.

**show l2vpn protection main-interface** [*interface name*{*Interface*}] [{**brief** | **detail** | **private**}]

Syntax Description		
	<i>interface name</i>	Interface name of the Ethernet ring G.8032 name.
	<i>interface</i>	The forwarding interface ID in number or in Rack/Slot/Instance/Port format as required.
	<b>brief</b>	Brief information about the G.8032 ethernet ring configuration.
	<b>detail</b>	Information in detail about the G.8032 ethernet ring configuration.
	<b>private</b>	Private information about the G.8032 ethernet ring configuration.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 6.0.1	This command was introduced.
	Release 7.7.1	The command output was enhanced to include protection access gateway subtype indication MST-AG.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

## Example

This example shows the output from the **show l2vpn protection main-interface** command:

```
RP/0/0/CPU0:router# show l2vpn protection main-interface
Main Interface ID          Subintf Count Protected  Blocked
-----
GigabitEthernet0/0/0/0    1                None       No
Instance : 0
```

## show l2vpn protection main-interface

```

State          : FORWARDING
Sub-Intf #    : 1
Flush #       : 0
Sub-interfaces : GigabitEthernet0/0/0/0.4

```

Main Interface ID	Subintf Count	Protected	Blocked
GigabitEthernet0/0/0/1	1	None	No

```

Instance : 0
State    : FORWARDING
Sub-Intf # : 1
Flush #  : 0
Sub-interfaces : GigabitEthernet0/0/0/0.4

```

```

RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/1
Tue Mar 15 10:54:13.366 EDT

```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/1	2	Yes	MST-AG

```

Instance : 0
State    : FORWARDING
Sub-Intf # : 1
Flush #   : 1

```

```

Instance : 1
State    : BLOCKED
Sub-Intf # : 1
Flush #   : 0

```

```

RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/2
Tue Mar 15 10:54:15.044 EDT

```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/2	2	Yes	STP

```

Instance : 0
State    : FORWARDING
Sub-Intf # : 1
Flush #   : 0

```

```

Instance : 1
State    : FORWARDING
Sub-Intf # : 1
Flush #   : 0

```

```

RP/0/0/CPU0:router# show l2vpn protection main-interface brief

```

Main Interface ID	Ref Count	Instance	Protected	State
GigabitEthernet0/0/0/0	3	2	No	FORWARDING
GigabitEthernet0/0/0/1	1	1	No	FORWARDING

```

RP/0/RSP0/CPU0:router# show l2vpn protection main-interface detail

```

Main Interface ID	# of subIntf	Protected
GigabitEthernet0/1/0/19	4	No

Main Interface ID	# of subIntf	Protected
GigabitEthernet0/1/0/20	3	No

```

Main Interface ID          # of subIntf Protected
-----
GigabitEthernet0/1/0/3    2                      No

Main Interface ID          # of subIntf Protected
-----
GigabitEthernet0/1/0/30   1                      No

Main Interface ID          # of subIntf Protected
-----
GigabitEthernet0/1/0/7    4                      No

```

RP/0/0/CPU0:router# show l2vpn protection main-interface private

```

Main Interface ID          Ref Count  Protected  Blocked  If Handle  Registered
-----
GigabitEthernet0/0/0/0    3          None       No       0x20000020 No

```

Instance : 0

```

State      : FORWARDING      Config ID : 0
Sub-Intf # : 0              Ack      # : 0
Bridge D # : 0              N-Ack    # : 0
Flush #    : 0              Rcv      # : 0
Sub-interfaces : GigabitEthernet0/0/0/0.4

```

Instance event trace history [Total events: 1, Max listed: 8]

```

-----
Time          Event          State          Action
====          =====          =
01/01/1970 01:00:01 Rcv state IF known      Invalid      134833160
07/02/2010 10:13:03 Update L2FIB            FORWARDING   0
01/01/1970 01:00:25 Rcvd AC MA create + UP I/F ST FORWARDING   0

```

## Related Commands

Command	Description
l2vpn	

# show l2vpn resource

To display the memory state in the L2VPN process, use the **show l2vpn resource** command in EXEC mode.

**show l2vpn resource**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read

## Examples

The following example shows sample output for the **show l2vpn resource** command:

```
Router# show l2vpn resource
Mon Oct 12 14:21:54.670 UTC
Memory: Normal
```

This table describes the significant fields shown in the display.

*Table 2: show l2vpn resource Command Field Descriptions*

Field	Description
Memory	Displays memory status.

Related Commands	Command	Description
	<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
	<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
	<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
	<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
	<a href="#">show l2vpn index, on page 43</a>	Displays statistics about the index manager.



# show l2vpn trace

To display trace data for L2VPN, use the **show l2vpn trace** command in EXEC mode.

```
show l2vpn trace [{checker | file | hexdump | last | location | reverse | stats | tailf | unique | usec | verbose
| wide | wrapping}]
```

Syntax Description	Parameter	Description
	<b>checker</b>	Displays trace data for the L2VPN Uberverifier.
	<b>file</b>	Displays trace data for the specified file.
	<b>hexdump</b>	Display traces data in hexadecimal format.
	<b>last</b>	Display last <n> entries
	<b>location</b>	Displays trace data for the specified location.
	<b>reverse</b>	Display latest traces first
	<b>stats</b>	Display trace statistics
	<b>tailf</b>	Display new traces as they are added
	<b>unique</b>	Display unique entries with counts
	<b>usec</b>	Display usec details with timestamp
	<b>verbose</b>	Display internal debugging information
	<b>wide</b>	Display trace data excluding buffer name, node name, tid
	<b>wrapping</b>	Display wrapping entries

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

This example displays output for the **show l2vpn trace** command:

## show l2vpn trace

```

Router# show l2vpn trace
Mon Oct 12 14:22:09.082 UTC
188 unique entries (2596 possible, 0 filtered)
Oct 12 12:37:44.197 l2vpn/policy 0/RP0/CPU0 1# t4349 POLICY:320: l2vpn_policy_reg_agent
started - route_policy_supported=False, forward_class_supported=False
Oct 12 12:39:21.870 l2vpn/fwd-pd 0/RP0/CPU0 1# t5664 FWD_PD:731:
Oct 12 12:39:21.883 l2vpn/fwd-err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:76: Major version mis-match,
SHM: 0x0 Expected: 0x1
Oct 12 12:39:21.883 l2vpn/fwd-err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:87: Magic number mis-match,
SHM: 0x0 Expected: 0xa7b6c3d8
Oct 12 12:39:21.884 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:76: Major version mis-match,
SHM: 0x0 Expected: 0x1
Oct 12 12:39:21.884 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:87: Magic number mis-match,
SHM: 0x0 Expected: 0xa7b6c3d8
Oct 12 12:39:21.890 l2vpn/fwd-detail 0/RP0/CPU0 1# t5664 FWD_DETAIL:263: PWGROUP Table init
succeeded
Oct 12 12:39:21.890 l2vpn/fwd-detail 0/RP0/CPU0 2# t5664 FWD_DETAIL:416: l2tp session table
rebuilt
Oct 12 12:39:21.903 l2vpn/fwd-common 0/RP0/CPU0 1# t5664 FWD_COMMON:39: L2FIB_OBJ_TRACE:
trace_buf=0x7d48e0
Oct 12 12:39:25.613 l2vpn/issu 0/RP0/CPU0 1# t5664 ISSU:790: ISSU - iMDR init called;
'infra/imdr' detected the 'informational' condition 'the service is not supported in the
node'
Oct 12 12:39:25.613 l2vpn/issu 0/RP0/CPU0 1# t5664 ISSU:430: ISSU - attempt to start
COLLABORATOR wait timer while not in ISSU mode
Oct 12 12:39:25.638 l2vpn/fwd-common 0/RP0/CPU0 1# t5664 FWD_COMMON:4241: show edm thread
initialized
Oct 12 12:39:25.781 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC|ERR:783: Mac aging init
Oct 12 12:39:25.781 l2vpn/fwd-mac 0/RP0/CPU0 2# t5664 FWD_MAC:1954: l2vpn_gsp_cons_init
returned Success
Oct 12 12:39:25.781 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_MAC|ERR:783: Mac aging init
Oct 12 12:39:25.782 l2vpn/fwd-aib 0/RP0/CPU0 4# t5664 FWD_AIB:446: aib connection opened
successfully
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 2# t5664 FWD_MAC:2004: Client successfully
joined gsp group
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:781: Initializing the txlist
IPC thread
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:3195: gsp_optimal_msg_size =
31264 (real: True)
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:626: Entering mac aging timer
init
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t7519 FWD_MAC:725: Entering event loop for
mac txlist thread
Oct 12 12:39:25.797 l2vpn/fwd-mac 0/RP0/CPU0 1# t4222 FWD_MAC:2221: learning_client_colocated
0, is_client_netio 1

```

## Related Commands

Command	Description
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
<a href="#">show l2vpn index, on page 43</a>	Displays statistics about the index manager.

Command	Description
<a href="#">show l2vpn resource, on page 48</a>	Displays the memory state in the L2VPN process.

## show l2vpn xconnect

To display brief information on configured cross-connects, use the **show l2vpn xconnect** command in EXEC mode.

**show l2vpn xconnect** [{**brief** | **detail***encapsulation* | **group** | **groups** | **interface** | **location** | **neighbor** | **standby** | **state** | **summary** | **type** **locally-switched**}]

### Syntax Description

<b>brief</b>	(Optional) Displays encapsulation brief information.
<b>detail</b>	(Optional) Displays detailed information.
<i>encapsulation</i>	(Optional) Filters on encapsulation type.
<b>group</b>	(Optional) Displays all cross-connects in a specified group.
<b>groups</b>	(Optional) Displays all groups information.
<b>interface</b>	(Optional) Filters on interface and subinterface.
<b>location</b>	(Optional) Displays location specific information.
<b>neighbor</b>	(Optional) Filters on neighbor.
<b>private</b>	(Optional) Displays private information.
<b>standby</b>	(Optional) Displays standby node specific information.
<b>state</b>	(Optional) Filters the following xconnect state types: <ul style="list-style-type: none"> <li>• up</li> <li>• down</li> </ul>
<b>summary</b>	(Optional) Displays AC information from the AC Manager database.
<b>type</b>	(Optional) Filters the locally switched xconnect type.

### Command Default

None

### Command Modes

EXEC mode

### Command History

Release	Modification
Release 6.0.1	This command was introduced.
Release 7.4.1	This command was modified to include (SI) Seamless Inactive status in the show output.

### Usage Guidelines

If a specific cross-connect is specified in the command then only that cross-connect will be displayed; otherwise, all cross-connects are displayed.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows sample output for the **show l2vpn xconnect** command:

```
Router# show l2vpn xconnect
Mon Oct 12 14:22:20.566 UTC
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        SB = Standby, SR = Standby Ready, (PP) = Partially Programmed
XConnect
Group      Name      ST      Segment 1      Segment 2      ST      ST
-----
XC         XC         UP      BE1             BE2             UP      UP
-----
XCON31    XCON1_P2P1 UP      Te0/0/0/0.1    Te0/0/0/26.1   UP      UP
-----
XCON32    XCON1_P2P2 UP      Te0/0/0/0.2    Te0/0/0/26.2   UP      UP
-----
XCON33    XCON1_P2P3 UP      Te0/0/0/0.3    Te0/0/0/26.3   UP      UP
-----
XCON34    XCON1_P2P4 UP      Te0/0/0/0.4    Te0/0/0/26.4   UP      UP
-----
XCON35    XCON1_P2P5 UP      Te0/0/0/0.5    Te0/0/0/26.5   UP      UP
-----
XCON36    XCON1_P2P6 UP      Te0/0/0/0.6    Te0/0/0/26.6   UP      UP
-----
XCON37    XCON1_P2P7 UP      Te0/0/0/0.7    Te0/0/0/26.7   UP      UP
-----
XCON38    XCON1_P2P8 UP      Te0/0/0/0.8    Te0/0/0/26.8   UP      UP
-----
```

This example shows the output of the **show run l2vpn** command :

```
Router# show run l2vpn
Mon Oct 12 14:23:24.723 UTC
l2vpn
xconnect group XC
  p2p XC
    interface Bundle-Ether1
    interface Bundle-Ether2
  !
!
xconnect group XCON31
  p2p XCON1_P2P1
    interface TenGigE0/0/0/0.1
    interface TenGigE0/0/0/26.1
  !
!
xconnect group XCON32
  p2p XCON1_P2P2
    interface TenGigE0/0/0/0.2
    interface TenGigE0/0/0/26.2
  !
!
xconnect group XCON33
  p2p XCON1_P2P3
```

## show l2vpn xconnect

```

interface TenGigE0/0/0/0.3
interface TenGigE0/0/0/26.3

RP/0/RSP1/CPU0:14A1#show l2vpn xconnect pw-id 11
Thu Feb 25 11:57:27.622 EST
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        SB = Standby, SR = Standby Ready, (PP) = Partially Programmed,
        LU = Local Up, RU = Remote Up, CO = Connected, (SI) = Seamless Inactive

```

```

XConnect          Segment 1          Segment 2
Group      Name      ST      Description          ST      Description          ST
-----
evpn-vpws  test11-1  UP      BE11                 UP      EVPN 11,11,24048    UP
-----
legacy-tldp
          test11      DN      BE11                 SB(SI)  192.168.12.110  11      UP
-----

```

This table describes the significant fields shown in the display.

**Table 3: show l2vpn xconnect Command Field Descriptions**

Field	Description
XConnect Group	Displays a list of all configured cross-connect groups.
Group	Displays the cross-connect group number.
Name	Displays the cross-connect group name.
Description	Displays the cross-connect group description. If no description is configured, the interface type is displayed.
ST	State of the cross-connect group: up (UP) or down (DN).

## Related Commands

Command	Description
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
<a href="#">show l2vpn database, on page 32</a>	Displays L2VPN database
<a href="#">show l2vpn pw-class, on page 55</a>	Displays L2VPN pseudowire class information.

# show l2vpn pw-class

To display L2VPN pseudowire class information, use the **show l2vpn pw-class** command in EXEC mode.

```
show l2vpn pw-class [{detail | location | name class name | standby}]
```

Syntax Description	detail	(Optional) Displays detailed information.
	location	(Optional) Displays location specific information.
	name <i>class-name</i>	(Optional) Displays information about a specific pseudowire class name.
	standby	(Optional) Displays standby node specific information.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 6.0.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read

## Examples

The following example shows sample output for the **show l2vpn pw-class** command:

```
Router# show l2vpn pw-class

Name                               Encapsulation   Protocol
-----                               -
mplsclass_75                       MPLS             LDP
l2tp-dynamic                        L2TPv3          L2TPv3
```

This example shows sample output for the **show l2vpn pw-class detail** command:

```
Router# show l2vpn pw-class detail
Encapsulation MPLS, protocol LDP
Transport mode not set, control word unset (default)
Sequencing not set
Static tag rewrite not set
PW Backup disable delay: 0 sec
MAC withdraw message is sent over PW: no
IPv4 source address 10.0.0.1
```

This table describes the significant fields shown in the display.

**Table 4: show l2vpn pw-class Command Field Descriptions**

Field	Description
Name	Displays the name of the pseudowire class.
Encapsulation	Displays the encapsulation type.
Protocol	Displays the protocol type.

#### Related Commands

Command	Description
<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.
<a href="#">p2p, on page 17</a>	Enters p2p configuration submode to configure point-to-point cross-connects.
<a href="#">pw-class (L2VPN), on page 18</a>	Enters pseudowire class sub-mode to define a pseudowire class template.
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
<a href="#">show l2vpn database, on page 32</a>	Displays L2VPN database



# storm-control

To enable storm control on an access circuit (AC) under a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain access circuit configuration mode. To disable storm control, use the **no** form of this command.

```
storm-control {broadcast | multicast | unknown-unicast} {pps pps-value | kbps kbps-value}
no storm-control {broadcast | multicast | unknown-unicast} {pps pps-value | kbps kbps-value}
```

Syntax Description		
<b>broadcast</b>		Configures storm control for broadcast traffic.
<b>multicast</b>		Configures storm control for multicast traffic.
<b>unknown-unicast</b>		Configures storm control for unknown unicast traffic. <ul style="list-style-type: none"> <li>Storm control does not apply to bridge protocol data unit (BPDU) packets. All BPDU packets are processed as if traffic storm control is not configured.</li> <li>Storm control does not apply to internal communication and control packets, route updates, SNMP management traffic, Telnet sessions, or any other packets addressed to the router.</li> </ul>
<b>pps pps-value</b>		Configures the packets-per-second (pps) storm control threshold for the specified traffic type. Valid values range from 1 to 160000.
<b>kbps kbps-value</b>		Configures the storm control in kilo bits per second (kbps). The range is from 64 to 1280000.

**Command Default** Storm control is disabled by default.

**Command Modes** l2vpn bridge group bridge-domain access circuit configuration

Command History	Release	Modification
	Release 6.3.1	This command was introduced.

## Usage Guidelines

- The storm control configuration is supported only on one sub-interface under a main interface, though the system allows you to configure storm control on more than one sub-interface. However, only the first storm control configuration under a main interface takes effect, though the running configuration shows all the storm control configurations that are committed. After reload, any of the storm control configurations may take effect irrespective of the order of configuration.
- Starting from 7.8.1, you can enable per subinterface configuration support for storm control by using the **hw-module storm-control-combine-policer-bw enable** command.
- System supports storm control per-EFP.
- If storm control is applied on one bridge port, you cannot apply storm control on another bridge port or sub-interface under the same main-port. On configuring, system pop-ups an error, but needs to be manually unconfigured.

- System does not support storm control on pseudowire bridge-ports.
- Storm control counters are not supported
- Only kbps rate is supported by hardware. Though the pps configuration is allowed, it is converted to kbps. The pps rate is calculated as 1 pps = 8 kbps.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example enables two storm control thresholds on an access circuit:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group cisco
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain abc
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# interface GigabitEthernet0/1/0/0.100
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# storm-control broadcast kbps 4500
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# commit
```

## xconnect group

To configure cross-connect groups, use the **xconnect group** command in L2VPN configuration mode. To return to the default behavior, use the **no** form of this command.

```
xconnect group group-name
no xconnect group group-name
```

<b>Syntax Description</b>	<i>group-name</i> Configures a cross-connect group name using a free-format 32-character string.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	L2VPN configuration
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.1	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--



<b>Note</b>	You can configure up to a maximum of 16K cross-connects per box.
-------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to group all cross-connects for XCON1:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# xconnect group XCON1
Router(config-l2vpn)# p2p xc1
Router(config-l2vpn-xc-p2p)# interface gigabitethernet0/1/0/0.1
Router(config-l2vpn-xc-p2p)# neighbor 10.165.100.151 pw-id 100
Router(config-l2vpn-xc-p2p-pw)# mpls static label local 50 remote 40
Router(config-l2vpn-xc-p2p-pw)# commit
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">interface (p2p), on page 3</a>	Configures an attachment circuit.
	<a href="#">l2vpn, on page 11</a>	Enters L2VPN configuration mode.

Command	Description
<a href="#">show l2vpn, on page 24</a>	Displays L2VPN information
<a href="#">show l2vpn xconnect, on page 52</a>	Displays brief information on configured cross-connects.