



## **Cisco Broadband Access Center for Cable Installation Guide**

Release 2.7

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

Text Part Number: OL-19105-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCDE, CCENT, Cisco Eos, Cisco HealthPresence, the Cisco logo, Cisco Lumin, Cisco Nexus, Cisco StadiumVision, Cisco TelePresence, Cisco WebEx, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn and Cisco Store are service marks; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerPanels, ProConnect, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0812R)

*Cisco Broadband Access Center for Cable Installation Guide, Release 2.7*  
© 2002-2009 Cisco Systems, Inc. All rights reserved.



# CONTENTS

## **Preface** vii

- Audience vii
- How This Guide Is Organized vii
- Document Conventions viii
- Related Documentation ix
- Obtaining Documentation and Submitting a Service Request ix

---

## **CHAPTER 1**

### **Overview** 1-1

- Operating System Requirements 1-1
  - JDK Patches for Solaris 8 1-1
  - JDK Patches for Solaris 9 1-2
  - KDC Patches 1-2
- Network Registrar Requirements 1-2
- Hardware Requirements 1-2
- Types of Installations 1-4

---

## **CHAPTER 2**

### **Preparing to Install Components** 2-1

- Broadband Access Center for Cable Components 2-1
- Installation and Startup Process 2-2
- Broadband Access Center Database Requirements 2-5
  - File System Block Size 2-5
  - Large File Support 2-6
- Installation Checklist 2-6
- Installation 2-7
  - Installation Using the Graphical User Interface 2-7
  - Installing from the Command Line 2-8

---

## **CHAPTER 3**

### **Installing Components** 3-1

- Installing Components Using the Graphical User Interface 3-1
  - Installing the Regional Distribution Unit 3-2
  - Installing Extensions on a Network Registrar Server 3-3
    - Installing Extensions 3-4
    - Configuring Extensions 3-5

- Validating Extensions 3-6
- Installing the Key Distribution Center 3-7
- Installing the Device Provisioning Engine 3-8
- Installing Components Using the CLI 3-8
  - Installing the Regional Distribution Unit 3-9
  - Installing Network Registrar Extensions 3-11
  - Installing the Key Distribution Center 3-14
  - Installing the Device Provisioning Engine 3-16

**CHAPTER 4**

**Installing in a Lab Environment 4-1**

- Installation Checklist 4-1
- Installing in a Lab Environment Using the GUI 4-2
- Installing in a Lab Environment Using the CLI 4-3
- Configuring Network Registrar and a CMTS 4-6

**CHAPTER 5**

**Post-Installation Activities 5-1**

- Enabling a Network Registrar Spoofing DNS Server 5-1
- Configuring the Syslog Utility to Receive Alerts from BACC 5-1
- Uninstalling Broadband Access Center 5-2
  - Uninstalling BACC from the Graphical User Interface 5-3
  - Uninstalling BACC from the Console Mode 5-3

**CHAPTER 6**

**Upgrading Broadband Access Center for Cable 6-1**

- Before You Begin 6-2
- Upgrading the RDU 6-2
- Upgrading the Solaris DPE 6-2
- Upgrading Hardware DPEs 6-4
- Upgrading Network Registrar Extensions 6-5
- Upgrading the KDC 6-5
- Migrating the RDU Database 6-6

**CHAPTER 7**

**Setting Up a Device Provisioning Engine 7-1**

- Hardware DPE Setup Sequence 7-1
  - Connecting the Device Provisioning Engine 7-1
  - Configuring and Running a Terminal Emulation Program 7-2
- Logging In 7-2
- Configuring a Device Provisioning Engine for Data 7-3

Configuring a Device Provisioning Engine for Voice Technology	7-5
Setting Up Voice Technology	7-5
Controls Available	7-7
Debugging	7-7

---

**APPENDIX A****Network Registrar Configuration File Example** A-1

Configuration Scripts	A-1
Sample Script for DOCSIS Modems and Computers	A-1
Sample Script for DOCSIS Modems and PacketCable MTAs	A-2

---

**INDEX**





## Preface

---

Welcome to the *Cisco Broadband Access Center for Cable Installation Guide 2.7*. This chapter provides an outline of the other chapters in this guide, and demonstrates the styles and conventions used in the guide.

This chapter contains the following sections:

- [Audience, page vii](#)
- [How This Guide Is Organized, page vii](#)
- [Document Conventions, page viii](#)
- [Related Documentation, page ix](#)
- [Obtaining Documentation and Submitting a Service Request, page ix](#)

## Audience

This installation guide enables system integrators, network administrators, and network technicians to install Cisco Broadband Access Center for Cable, referred to as BACC throughout this installation guide, on Solaris operating systems and to set up the Cisco device provisioning engine (DPE).



### Note

---

Within this installation guide you may encounter references to BACC. With two exceptions, these references are actually referring to the BACC product. The exceptions are in those areas where you are prompted to enter specific data that may also contain references to BACC and where references are made to specific file, directory or pathnames.

In these instances, you must enter the characters exactly as they appear in this guide.

---

## How This Guide Is Organized

This guide describes how to install BACC on Solaris operating system. The major sections of this guide are described here:

Section	Title	Description
Chapter 1	<a href="#">Overview</a>	Provides general requirements for a successful installation of BACC.
Chapter 2	<a href="#">Preparing to Install Components</a>	Describes considerations you need to take into account as you prepare to install BACC. For example, it describes the individual components of BACC, the order of operations for installing the software, and the BACC database requirements. It also describes initial steps for installing the software using either a graphical user interface or a command line interface.
Chapter 3	<a href="#">Installing Components</a>	Describes how to install the individual components of BACC using either the graphical user interface or the CLI.
Chapter 4	<a href="#">Installing in a Lab Environment</a>	Describes how to install a lab version of BACC using either the graphical user interface or the CLI.
Chapter 5	<a href="#">Post-Installation Activities</a>	Describes those activities that are performed following installation.
Chapter 6	<a href="#">Upgrading Broadband Access Center for Cable</a>	Describes the upgrade procedures performed on various BACC components.
Chapter 7	<a href="#">Setting Up a Device Provisioning Engine</a>	Describes how to configure a device provisioning engine (DPE).
Appendix A	<a href="#">Network Registrar Configuration File Example</a>	Shows examples of files used to configure Network Registrar for high-speed data (HSD) and voice technology deployments.

## Document Conventions

This guide uses the following conventions:

- **Boldface** is used for commands, keywords, and buttons.
- *Italic* is used for command input for which you supply values.
- `Screen` font is used for examples of information that are displayed on the screen.
- **Boldface screen** font is used for examples of information that you enter.
- UNIX paths are indicated as follows: `/tools/list/connections`.



### Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.



### Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

Refer to these manuals for additional information:

- *Release Notes for Broadband Access Center for Cable, Release 2.7*
- *Cisco Broadband Access Center for Cable Administrator's Guide*
- *Cisco Broadband Access Center for Cable CLI Reference Guide*
- To support the DPE-590:
  - *Device Provisioning Engine 590 Recovery CD-ROM Release Notes*
  - *Cisco Content Engine 500 Series Hardware Installation Guide*
- To support the DPE-2115:
  - *Device Provisioning Engine 2115 Recovery CD-ROM Release Notes*
  - *Installation and Setup Guide for the Cisco 1102 VLAN Policy Server*

**Caution**

---

Refer to this guide for port and connector identification and to perform hardware installation only. Do not attempt to perform any of the configuration instructions found in that guide.

---

- *Cisco Network Registrar User's Guide*
- *Cisco Network Registrar CLI Reference*

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.





# CHAPTER 1

## Overview

---

Broadband Access Center for Cable (BACC) automates the process of configuring and provisioning cable network devices. BACC interfaces with Cisco Network Registrar, which includes a high-speed DHCP server for IP address management and a DNS server.

This chapter describes:

- [Operating System Requirements, page 1-1](#)
- [Network Registrar Requirements, page 1-2](#)
- [Hardware Requirements, page 1-2](#)
- [Types of Installations, page 1-4](#)

## Operating System Requirements

You must install BACC on a computer running the Solaris 8 or 9 operating system. You must have the correct type and number of patches installed on your system before you can install BACC.

### JDK Patches for Solaris 8

The JDK patches recommended for successful BACC installation include:

- 112003-03
- 109147-31
- 108434-18
- 113887-26
- 110386-03
- 113648-03
- 108652-86
- 108987-14
- 108993-39
- 108773-18
- 111308-05
- 108435-18
- 111111-04
- 111023-03
- 115827-01
- 108921-22
- 108528-29
- 109326-16
- 111310-01
- 112438-03
- 113886-26
- 112396-02
- 111317-05
- 116602-01
- 108940-65
- 108989-02
- 110615-13

## JDK Patches for Solaris 9

The JDK patches recommended for successful BACC installation include:

- 113886-26
- 112785-44
- 113887-26
- 113096-03

## KDC Patches

The KDC patches required for successful BACC installation include:

- 112438-01
- 109326-06

## Network Registrar Requirements

Before you install BACC, be aware of these Cisco Network Registrar requirements:

- We recommend that you use Network Registrar 6.1.2.3 or higher with BACC 2.7.
- A Network Registrar DHCP server must be installed on a computer with Solaris 8 or 9.
- In a failover deployment of BACC, you must configure two redundant DHCP servers for failover.
- After you install BACC, ensure that Network Registrar scopes are configured to reflect failover capability and the topology of the network on which BACC is installed.

For more information about configuring failover on Network Registrar servers, see the *Network Registrar User's Guide*.

## Hardware Requirements

A BACC installation requires these servers:

- A regional distribution unit (RDU). This is the primary server in a BACC deployment. It contains the central BACC database and manages the generation of configurations.
- One or more device provisioning engines (DPE). A Cisco device provisioning engine caches provisioning information and handles all configuration requests including the transfer of configuration files to devices. It is integrated with the Cisco Network Registrar DHCP server to control the assignment of IP addresses. Multiple DPEs can communicate with a single DHCP server. DPEs include factory installed software that enables provisioning, but you must perform some initial set up.

**Note**

The hardware installation procedures for the device provisioning engine are described in the following guides:

- For the DPE-590, refer to the *Cisco Content Engine 500 Series Hardware Installation Guide*. This can be found at:  
[http://www.cisco.com/en/US/docs/app\\_ntwk\\_services/waas/ce/ce500/installation/guide/ce500hig.html](http://www.cisco.com/en/US/docs/app_ntwk_services/waas/ce/ce500/installation/guide/ce500hig.html)
- For the DPE-2115, refer to the *Installation and Setup Guide for the Cisco 1102 VLAN Policy Server*. This can be found at:  
[www.cisco.com/en/US/products/sw/secursw/ps2136/products\\_installation\\_and\\_configuration\\_guide\\_book09186a00801f0d02.html](http://www.cisco.com/en/US/products/sw/secursw/ps2136/products_installation_and_configuration_guide_book09186a00801f0d02.html)

- A key distribution center (KDC). The KDC and the DPE registration services handle the authentication of all voice technology media terminal adapters (MTAs). When a lab installation is performed, the KDC is installed on the lab computer. For performance reasons however, in a component installation, the KDC should be installed on a separate server.



**Note** The KDC is required only when configuring a system to support voice technology operations.

- One or more Cisco Network Registrar servers. Network Registrar provides Dynamic Host Configuration Protocol (DHCP) and Domain Name System (DNS) functionality. Implementing dynamic DNS (DDNS) within Network Registrar, increases the number of servers you need to deploy.

Table 1-1 describes the hardware requirements for each server.

**Table 1-1 Hardware Recommendations per Provisioning Group**

# Subscribers	Server	Min. # Servers	Recommended # Servers <sup>1</sup>	Server Class	# Processors	Memory
10000	DPE	1	2	SUN V210 1GHz <sup>2</sup>	1	1 GB
	CNR	1	2	SUN V210 1GHz	1	1 GB
	KDC	1	-	SUN V210 1GHz	1	1 GB
25000	DPE	1	2	SUN V210 1GHz <sup>2</sup>	1	1 GB
	CNR	1	2	SUN V210 1GHz	1	1 GB
	KDC	1	-	SUN V210 1GHz	2	2 GB
100000	DPE	1	2	SUN V210 1GHz <sup>2</sup>	2	2 GB
	CNR	1	2	SUN V210 1GHz	2	2 GB
	KDC	1	-	SUN V210 1GHz	2	2 GB
250000	DPE	2	2	SUN V210 1GHz <sup>2</sup>	2	2 GB
	CNR	2	2	SUN V210 1GHz	2	2 GB
	KDC	-	-	NA <sup>3</sup>	-	-
500000	DPE	2	2	SUN V210 1GHz <sup>2</sup>	2	2 GB
	CNR	2	2	SUN V210 1GHz	2	2 GB
	KDC	-	-	NA <sup>3</sup>	-	-

**Table 1-1** Hardware Recommendations per Provisioning Group (continued)

# Subscribers	Server	Min. # Servers	Recommended # Servers <sup>1</sup>	Server Class	# Processors	Memory
1 million	DPE	2	2	SUN V210 1GHz <sup>2</sup>	2	2 GB or 4 GB <sup>4</sup>
	CNR	2	2	SUN V210 1GHz	2	2 GB or 4 GB <sup>4</sup>
	KDC	-	-	NA <sup>3</sup>	-	-
Lab Install	Single server for all	1	1	SUN V210 1GHz	1	1 GB

1. The number of recommended servers is based on the average subscriber with two devices (1 cable modem and 1 PC).
2. With BACC 2.6.1 and later releases, the non-appliance Sun DPE can be replaced with a DPE-2115 single 3.06 Ghz CPU and 2 GB memory, which yields equal or better performance.
3. Only 100000 MTA devices are currently supported per provisioning group.
4. 2 GB for configuration files that are less than or equal to 1.5 KB and 4 GB for configuration files that are more than 1.5 KB.

## Types of Installations

This guide discusses two types of installation:

- Individual component installation—The installation program enables you to install one or more individual components of BACC. The individual components are the RDU, Cisco Network Registrar extensions, the Solaris device provisioning engine (DPE), and the KDC. Refer to [Chapter 3, “Installing Components”](#) for specifics about installing the individual components.
- Lab installation—The installation program enables you to install BACC for use in a laboratory environment for demonstration or evaluation prior to deploying BACC into a full network implementation. Refer to [Chapter 4, “Installing in a Lab Environment”](#) for more information.

You can install BACC from the installation program’s graphical user interface (GUI) or from the command line.



## CHAPTER 2

# Preparing to Install Components

---

This chapter provides the information you need to prepare for a successful Broadband Access Center for Cable (BACC) component installation, including these topics:

- [Broadband Access Center for Cable Components, page 2-1](#)
- [Installation and Startup Process, page 2-2](#)
- [Broadband Access Center Database Requirements, page 2-5](#)
- [Installation Checklist, page 2-6](#)
- [Installation, page 2-7](#)

## Broadband Access Center for Cable Components

The BACC component installation program prompts you to install one or more of these components:

- **Regional distribution unit (RDU).** The RDU is the primary server in the BACC provisioning system. You should install the RDU on a Solaris 8 or Solaris 9 server that meets the requirements described in the [“Hardware Requirements” section on page 1-2](#). The RDU performs these functions:
  - Manages the generation of device configurations.
  - Acts as a clearinghouse through which all application programming interface (API) requests must pass.
  - Manages the BACC system.
- **Network Registrar extensions.** These extensions are the link between BACC and Network Registrar. Install this component on all Network Registrar servers in your BACC environment. If you are deploying BACC in a failover environment, you must also install the extensions on the failover servers.



---

**Note** We recommend that you install the BACC Network Registrar extensions on a server running Network Registrar 6.1.2.3 or higher.

---

- **Device Provisioning Engine (DPE).** BACC supports the deployment of a DPE on Solaris Sparc computers running Solaris 8 or Solaris 9.



---

**Note** The DPE component now requires licenses to be installed at the RDU. If you have not yet received your licenses, contact your Cisco Systems representative before proceeding.

---

If, during DPE installation, the installation program detects the presence of a TFTP server running on the same computer that the DPE being installed on, the installation is immediately terminated and an error message appears on screen.

- Key Distribution Center (KDC). For maximum performance and segmentation of the network, you may install one KDC instance per provisioning group. The KDC, along with the DPE registration service, handles the authentication of all PacketCable voice technology MTAs. When a laboratory installation is performed, the KDC is installed on the lab computer. For performance reasons however, in a component installation, the KDC should be installed on a separate server. The KDC component requires a license.



**Note** The KDC and DPE have service keys that are required to allow them to communicate.

Although the component installation program supports installing the components on the same computer, in practice, you are likely to run the program on several different computers as described in these sections:

1. Installing the RDU on a Solaris 8 or 9 server.
2. Installing the Network Registrar extensions on a Network Registrar server or servers.
3. Installing the DPE on Solaris Sparc computers running Solaris 8 or Solaris 9.
4. Installing the KDC server.

## Installation and Startup Process

To ensure a smooth installation and startup process, complete the order of operations as listed in [Table 2-1](#).

**Table 2-1** *Installation and Startup Process*

Item	Description
1.	Determine which components you are installing and on what computers.
2.	Verify the file system block size of the directory in which you intend to install the BACC database and database transaction log files. See the <a href="#">“Broadband Access Center Database Requirements”</a> section on page 2-5.
3.	Review the installation checklist. See the <a href="#">“Installation Checklist”</a> section on page 2-6.
4.	Install a DPE. When you install the DPE, ensure that you have this information available: <ul style="list-style-type: none"> <li>• Home Directory location</li> <li>• Data Directory location</li> </ul> <p>After Solaris DPE installation is complete, you must configure the DPE using the command line interface (CLI). Refer to the <i>Cisco Broadband Access Center for Cable CLI Reference Guide</i> for these configuration instructions.</p>

**Table 2-1**      **Installation and Startup Process (continued)**

Item	Description
5.	<p data-bbox="467 310 1149 342">Install the RDU. When you install the RDU, ensure that you:</p> <ul data-bbox="479 359 1485 617" style="list-style-type: none"><li data-bbox="479 359 1328 390">• Obtain a valid BACC license key for each technology that you provision.</li><li data-bbox="479 405 1485 464">• Configure the syslog file for alerts. See the <a href="#">“Configuring the Syslog Utility to Receive Alerts from BACC”</a> section on page 5-1.</li><li data-bbox="479 478 1469 537">• Verify that the RDU is running by starting the administrators user interface. For more information, see the <i>Broadband Access Center for Cable Administrator’s Guide</i>.</li><li data-bbox="479 552 1485 611">• Change the BACC administrator’s password. For more information, see the <i>Broadband Access Center for Cable Administrator’s Guide</i>.</li></ul> <p data-bbox="467 632 1469 695"><b>Note</b>    The existence of a text file called log.txt indicates that errors occurred during the installation process. This text file is located under the &lt;BACC_HOME&gt; directory.</p>

Table 2-1 Installation and Startup Process (continued)

Item	Description
6.	<p data-bbox="431 317 1487 407">Install and configure Network Registrar, if it is not already installed on your systems. We recommend that you use Network Registrar 6.1.2.3 or higher. For more information, see the <i>Network Registrar Installation Guide</i>.</p> <ul style="list-style-type: none"> <li data-bbox="444 426 1487 459">• When you install Network Registrar Local Cluster (LCCM), ensure that you:               <ol style="list-style-type: none"> <li data-bbox="488 474 1214 508">a. Obtain a valid Network Registrar license key for local cluster.</li> <li data-bbox="488 520 1487 611">b. On all Network Registrar local cluster servers, install the BACC extensions for the product. For more information see the “<a href="#">Installing Extensions on a Network Registrar Server</a>” section on page 3-3.</li> <li data-bbox="488 623 1487 751">c. Configure Network Registrar, including its extensions. Specifically, you need to configure scopes, policies, client-classes, and scope selection tags. For more information, see the “<a href="#">Configuring Extensions</a>” section on page 3-5, and also see the <i>Network Registrar User’s Guide</i>.</li> <li data-bbox="488 764 1487 854">d. Configure the syslog on the Network Registrar for alerts and debugging information. See the “<a href="#">Configuring the Syslog Utility to Receive Alerts from BACC</a>” section on page 5-1.</li> <li data-bbox="488 867 1487 957">e. Validate the installation by connecting to the administrative user interface and viewing the administrator’s user interface. For more information, see the <i>Cisco Broadband Access Center for Cable Administrator’s Guide</i>.</li> </ol> </li> <li data-bbox="444 970 1487 1003">• When you install Network Registrar Regional Cluster (RCCM), ensure that you:               <ol style="list-style-type: none"> <li data-bbox="488 1018 1487 1146">a. Identify the master server for Network Registrar Regional Installation, which administers all the configured CNR local clusters. This server can be Solaris or Windows or Linux. However, we recommend that you have the Solaris Operating System on the CNR Regional Server.</li> <li data-bbox="488 1159 1317 1192">b. Obtain a valid central-cluster license key for the CNR Regional Server.</li> <li data-bbox="488 1205 1487 1295">c. After you install the BACC extensions for the product on all CNR local servers, replicate the local data into regional and pull the “<a href="#">Replica Address Space</a>”. For more information see the <i>Network Registrar User’s Guide</i>.</li> <li data-bbox="488 1308 1487 1398">d. Alternatively, you can also create subnets, client-classes, policies, and so on at RCCM and push them to the required LCCM DHCP server. For more information, see the <i>Network Registrar User’s Guide</i>.</li> <li data-bbox="488 1411 1487 1501">e. Configure this CNR Regional CCM Server’s IP address, port number, and login details into the RDU defaults for IP Reservation support. For more information, see the <i>Cisco Broadband Access Center for Cable Administrator’s Guide</i>.</li> </ol> </li> </ul> <p data-bbox="431 1514 1487 1596"><b>Note</b> Network Registrar Release Version prior to 6.1 does not support Regional Cluster, Hence BACC’s IP Lease Reservation Support feature cannot be used.</p>

Table 2-1 Installation and Startup Process (continued)

Item	Description
7.	<p>Install and configure the KDC. When you install the KDC, ensure that you have this information available:</p> <ul style="list-style-type: none"> <li>• A valid license for KDC.</li> <li>• KDC realm—Identified by a unique name, the KDC realm consists of a KDC, and the clients and servers registered to that KDC.</li> </ul> <p><b>Note</b> The realm must match the certificate chain at the KDC.</p> <ul style="list-style-type: none"> <li>• KDC FQDN—This is the fully qualified domain name on which the KDC server is located.</li> <li>• KDC interface address—This is the interface (generally the IP address of the KDC server) on which the KDC listens for requests.</li> </ul> <p><b>Note</b> During installation it may be necessary to install several Solaris patches on your computer. The installation program will display a complete list of patches that are required. Should patch installation become necessary, refer to the Sun Microsystems website to download the required patches.</p>
<b>Note</b>	If you decide to terminate the BACC installation after the operating system database has been installed, you must uninstall it before attempting to reinstall the product. If you do not do this, and rerun the installation program, you cannot change the location of either the <BACC_DATA> and <BACC_DBLOG> directories.

## Broadband Access Center Database Requirements

Before you install BACC, be aware of these database considerations:

- File system block size
- Support for large files

### File System Block Size

For optimum performance and reliability of the BACC database, configure the file system or systems that contain the database files and database log files with an 8 KB block size or greater. If your system configuration does not support an 8 KB block size, then configure the block size in multiples of 8 KB; for example, 16 KB or 32 KB.

The installation program prompts you to specify a directory in which to install database files and database log files. These directories are identified in BACC with system variables, <BACC\_DATA> and <BACC\_DBLOG> respectively.

To verify that a directory resides on a file system with a minimum 8 KB block size, follow these steps:

- Step 1** Run the UNIX **mount** command without any parameters to determine on which file system device the directory resides. The default directory is /var/CSCObpr. For example:

```
/var on /dev/dsk/c0t0d0s4 read/write/setuid/intr/largefiles/onerror=panic/dev=2200004 on
Mon Nov 26 08:07:53
```

In this example, the file system device is /dev/dsk/c0t0d0s4.

**Step 2** To determine the file system block size, use the **df** command. For example:

```
# df -g /dev/dsk/c0t0d0s4
```

Example output from the **df** command is as follows:

```
/var                (/dev/dsk/c0t0d0s4 ):      8192 block size      1024 frag size
961240 total blocks  851210 free blocks      755086 available    243712 total files
239730 free files    35651588 filesys id
ufs fstype           0x00000004 flag          255 filename length
```

In this example, the block size is 8192 bytes, which is 8 KB. The block size of the selected directory, therefore, is correct.

## Large File Support

Ensure that the file system in which you place database files is configured to support files above 2 GB. To verify large file support:

**Step 1** Run the UNIX **mount** command without parameters.

**Step 2** Note whether the intended file system contains the keyword **largefiles**.

An example output of the **mount** command is:

```
/var on /dev/dsk/c0t0d0s4 read/write/setuid/intr/largefiles/onerror=panic/dev=2200004 on
Mon Nov 26 08:07:53
```

In this example, the output contains the keyword **largefiles**. This file system, therefore, can support files greater than 2 GB.

## Installation Checklist

Before you run the installation software, use this checklist to ensure that you are ready:

- Verify the prerequisite system hardware and software requirements described in [Chapter 1, “Overview”](#)
- Determine the home directory (<BACC\_HOME>) in which you want to install the BACC component or components. The default directory is /opt/CSCObpr.



### Note

Cisco Systems recommends that you have at least 350 MB of disk space available.

- Ensure that you have *root* access to the computers where you intend to install BACC components.
- Have your BACC license key or keys at hand. You need a valid license key for each technology that you want to provision with BACC.
- For the RDU, determine where you want to install the data directory (<BACC\_DATA>) and the database transaction logs (<BACC\_DBLOG>). (The default directory is /var/CSCObpr.)

**Note**

Cisco recommends that you install the database transaction logs on a different physical disk than either the home directory or the data directory.

- For the RDU, select the shared secret password that BACC servers on your network use as a token to authenticate communication with one another. The shared secret password is the same for all BACC servers on your network.
- We recommend that Network Registrar 6.1.2.3 or higher is installed and running on any servers where you are installing BACC extensions.
- For extensions, determine the name of provisioning group to which the Network Registrar server belongs.
- For Network Registrar extensions, determine where you want to install the data directory (<BACC\_DATA>).
- Verify that you have the necessary Network Registrar configuration files, (See [Appendix A, “Network Registrar Configuration File Example”](#) for an example of these configuration files.)
- Verify that you have the necessary KDC servers available.

**Note**

If you interrupt the installation program after it begins copying files, you may have to manually clean up the locations of copied files.

## Installation

The initial steps in the BACC installation program are identical regardless of the BACC component you are installing. This section describes how to work with the installation program and the initial installation steps.

You install BACC using either the graphical user interface (GUI) or the command line interface (CLI). Both of these interfaces are supplied with BACC.

### Installation Using the Graphical User Interface

To install BACC using the graphical interface:

- Step 1** Using an X-Windows client, log in as *root* on the computer on which you intend to install the BACC component.
- Step 2** At the Solaris system prompt, navigate to the directory containing the `setup.bin` file. If you are using the BACC CD-ROM, you will find `setup.bin` located at the root of your CD-ROM drive.
- Step 3** Enter this command to start the installation program:  

```
> setup.bin
```

The installation program verifies that you have installed the required patches to the Solaris operating system. When the verification is complete, the Welcome screen appears.
- Step 4** Click **Next**. The Choose Installation Type screen appears.

- Step 5** Select one of the two installation types:
- Individual Components—This option enables you to install an RDU, Network Registrar extensions, the DPE, or the KDC. See these sections for the appropriate installation instructions:
    - [Installing the Regional Distribution Unit, page 3-2](#)
    - [Installing Extensions on a Network Registrar Server, page 3-3](#)
    - [Installing the Key Distribution Center, page 3-7](#)
    - [Installing the Device Provisioning Engine, page 3-8](#)
  - Lab—This option enables you to install the software in a laboratory environment. See [Chapter 4, “Installing in a Lab Environment”](#) in this guide.
- Step 6** Click **Next**. Depending on the option you selected in the preceding step, either the Installation Components screen appears, or you begin the lab installation.




---

**Note** You must select one of the displayed installation components before you can proceed with the installation.

---

## Installing from the Command Line

To perform the initial installation procedure from the command line:

- 
- Step 1** Log into the intended BACC host as *root*.
- Step 2** At the Solaris system prompt, change directory to your CD-ROM drive or other installation media. The installation program, `setup.bin`, is at the root of this drive.
- Step 3** Enter this command to start the installation program:

```
> setup.bin -console
```

The installation program verifies that you have installed the required patches to the Solaris operating system. When the verification is complete, the program displays welcome information.

- Step 4** Press **Enter** to continue. The program prompts you to choose the installation type. You can choose to install:
- Individual components
  - Lab installation

- Step 5** To choose individual components, enter **C**; or, to choose Lab installation, enter **L**. For example:

```
Choose Installation
```

```
Choose the type of BPR installation you want to install.
```

```
The Lab installation will store all components in the chosen destination.
Otherwise, you can select individual components and destinations.
```

```
Enter C for individual components or L for lab [C]:c
```

The program prompts you to confirm the installation type.

**Step 6** Press **y** and then **Enter** to continue.

At this point you must decide which installation you want to perform. To install individual components go to the [“Installing Components Using the CLI”](#) section on page 3-8. To install in a lab environment go to the [“Installing in a Lab Environment Using the CLI”](#) section on page 4-3.

---





## CHAPTER 3

# Installing Components

---

This chapter explains the procedures you must follow to correctly install Broadband Access Center for Cable (BACC) components in a Solaris operating system environment.

This chapter contains these topics:

- [Installing Components Using the Graphical User Interface, page 3-1](#)
- [Installing Components Using the CLI, page 3-8](#)

## Installing Components Using the Graphical User Interface

This section explains the procedures that you follow to install one or more of components of BACC using the GUI.

You can choose to install one or all of these components:

- Regional distribution unit (RDU). Refer to [Installing the Regional Distribution Unit, page 3-2](#) for further information.
- Network Registrar extensions. Refer to [Installing Extensions on a Network Registrar Server, page 3-3](#) for further information.
- Key Distribution Center (KDC). Refer to [Installing the Key Distribution Center, page 3-7](#) for further information.
- Device Provisioning Engine (DPE). Refer to [Installing the Device Provisioning Engine, page 3-8](#) for further information.

For more information about each component see the “[Broadband Access Center for Cable Components](#)” section on page 2-1.

Before you begin any of these procedures, you must complete the initial installation procedure described in the “[Installation and Startup Process](#)” section on page 2-2.

## Installing the Regional Distribution Unit

Install the RDU server on a Solaris 8 server that meets the requirements described in the “[Hardware Requirements](#)” section on page 1-2.

To install the RDU server, complete the steps described in the “[Installation and Startup Process](#)” section on page 2-2, then follow these steps:

- 
- Step 1** Click **Next**. The Home Directory Destination screen appears. The default directory is `/opt/CSCObpr`.
- Step 2** Accept the default directory or enter a new directory. You can use the **Browse** button to select a new directory.
- Step 3** Click **Next**. The installation program displays the Create Directory dialog box. Click **Yes** to continue. The Data Directory Destination screen appears. The default directory is `/var/CSCObpr`.
- Step 4** Accept the default directory or enter a new directory. You can use the **Browse** button to select a new directory.



---

**Note** By default, the installation program installs the data directory (BPR\_DATA) on a different directory than the home directory (BPR\_HOME). Cisco Systems recommends that the data directory be on a different physical disk than the home directory; for example `/var/disk0/CSCObpr`. However, you can install the data directory on the same disk as the home directory.

The directory specified becomes the top-level directory under which the installation program creates a number of subdirectories; for example, `/var/disk0/CSCObpr/rdu/db`.

---

- Step 5** Click **Next**. The installation program displays the Create Directory dialog box. Click **Yes** to continue. The Database Transaction Logs screen appears.
- Step 6** Enter the pathname for the directory in which you want the transaction logs (BPR\_DBLOG) installed. The default directory is `/var/CSCObpr`.



---

**Note** By default, the installation program installs the database transaction logs directory (BPR\_DBLOG) in the same directory as the data directory (BPR\_DATA). Cisco Systems recommends that you locate the database transaction logs directory on the fastest disk on the system; for example, `/var/disk1/CSCObpr`. You also should ensure that the disk has 1 GB of space available.

The directory specified becomes the top-level directory under which the installation program creates a number of subdirectories.

---

- Step 7** Accept the default directory or enter a new directory. You can use the **Browse** button to select a new directory.
- Step 8** Click **Next**. The installation program displays the Create Directory dialog box. Click **Yes** to continue. The Regional Distribution Unit Host/Port screen appears.
- Step 9** Accept the default listening port number or enter a new port number. The default port is 49187.

**Note**

The installation program obtains the IP address of the RDU automatically. You do not need to enter this value.

**Caution**

If you change the default listening port value, ensure that the new value does not conflict with any existing port assignments. Also, ensure that you configure all DPEs and Network Registrar servers with the correct RDU port number. See the *Broadband Provisioning Registrar Administrator's Guide* for information about configuring the DPE and Network Registrar extensions.

**Step 10** Click **Next**. The Shared Secret Password screen appears.

**Step 11** Enter and confirm the shared secret password.

**Note**

The RDU, DPEs, and Network Registrar extension points all use the same shared secret. This is a character string, or token, that is used to authenticate communication.

**Step 12** Click **Next**. The Installation Parameters screen appears. This screen identifies the values that you have entered in the previous screens. To modify any of the values entered:

- a. Click **Back** until the desired screen appears.
- b. Make the necessary changes.
- c. Click **Next** repeatedly until you return to this screen.

**Step 13** Click **Next**. When the installation is complete, the Installation Summary screen appears. Click **Finish** to exit the installation program.

**Note**

You must configure your license keys using the administrator's user interface. Refer to the *Cisco Broadband Access Center for Cable Administrator's Guide* for additional information.

## Installing Extensions on a Network Registrar Server

You install BACC extensions on a Network Registrar server. If you are deploying BACC in a failover environment, you also must install the extensions on the failover servers. After you install extensions, you need to configure them.

The remainder of this section explains how to install, configure, and validate these extensions.

## Installing Extensions

Before you install the Network Registrar extensions, complete the steps described in the “[Installation and Startup Process](#)” section on page 2-2. To install the extensions:

- Step 1** On the Installation Components screen, select the Cisco Network Registrar extension points option, then click **Next** to continue; the Home Directory Destination screen appears.



**Note** The installation program now validates your Network Registrar (CNR) installation. We recommend that you have CNR version 6.1.2.3 or higher. If the required version is not installed, the installation process is terminated and you must upgrade to the required Network Registrar version before proceeding.

- Step 2** Enter the pathname for the home directory, or click the **Browse** button to locate the desired directory.



**Note** The installation program does not ask for the home directory when it identifies that you are installing BACC components on a computer that already has a BACC component installed on it.

- Step 3** Click **Next**. The installation program performs some validation and, prompts you to create the directory, if necessary, before the Data Directory Destination screen appears.

- Step 4** Accept the default directory or enter a new directory. You can use the **Browse** button to select a new directory.



**Note** By default, the installation program installs the data directory (BPR\_DATA) on a different directory than the home directory (BPR\_HOME). Cisco Systems recommends that the data directory be on a different physical disk than the home directory; for example, /var/disk0/CSCObpr. However, you can install the data directory on the same disk as the home directory.

- Step 5** Click **Next**. The Regional Distribution Unit Host/Port screen appears.

- Step 6** Enter the IP address (or hostname) and the listening port of the host where the RDU software is installed. By default, the name of the local host appears in the RDU IP Address field. The RDU uses the listening port to communicate with the DPEs and Network Registrar extension points.

- Step 7** Click **Next**. The Cisco Network Registrar Extension Point Provisioning Group screen appears.

- Step 8** Enter the name of the extension point provisioning group.

- Step 9** Click **Next**. The PacketCable Panel screen appears.

- Step 10** Determine if you need to install the voice technology option and click:
- **Yes** button if you want to install the voice technology option. The PacketCable Properties screen appears.
  - **No** if you do not have a valid license key for this technology. After clicking **No**, go to step number 12.

- Step 11** Enter the appropriate information into the fields shown.

Field Name	Description
Kerberos Realm Name	Specifies, using a unique name, the Kerberos realm. This must match the realm set at the associated components.
IP Address of Primary DHCP Server	Specifies the IP address of the voice technology primary DHCP server.
IP Address of Primary DNS Server	Specifies the IP address of the computer which is running the primary DNS server.
IP Address of Secondary DHCP Server	Specifies the IP address of the voice technology secondary DHCP server.
IP Address of Secondary DNS Server	Specifies the IP address of the computer which is running the secondary DNS server; if that server is being used.

**Step 12** Click **Next**. The Shared Secret Password screen appears.

**Step 13** Enter and confirm the shared secret password.



**Note** Use the shared secret password specified during the RDU installation.

**Step 14** Click **Next**. The Installation Parameters screen appears. This screen identifies the values that you have entered in the previous screens. To modify any of the values entered click **Back** until the desired screen appears.

**Step 15** Click **Next**. When the installation is complete, the Installed Components Summary screen appears. Click **Finish** to exit the installation program.

## Configuring Extensions

After you install the BACC extensions to Network Registrar, you must configure the extensions. The procedure described in this section makes these assumptions:

- The BACC component is installed in `/opt/CSCObrpr`.
- Network Registrar is installed in `/opt/nwreg2`.
- The Network Registrar username is **admin** and the password is **changeme**.

To configure extensions, follow these steps:

**Step 1** Log in as *root* to the Network Registrar server.

**Step 2** At the command line, enter these commands:

```
<NR_HOME>/usrbin/nrcmd -N admin -P changeme -b <
<BACC_HOME>/cnr_ep/bin/bpr_cnr_enable_extpts.nrcmd
```

**Step 3** Enter these commands to reload the Network Registrar server:

```
/etc/init.d/nwreglocal stop
/etc/init.d/nwreglocal start
```

Alternatively, you can enter this command to reload the DHCP server alone:

```
<NR_HOME>/usrbin/nrcmd -N admin -P changeme "dhcp reload"
```

---

**Caution**

Be aware that you also must configure client-classes, scope selection tags, policies, and scopes before you can use the Network Registrar server. See the *Network Registrar User's Guide* for information about configuring these entities.

---

## Validating Extensions

In the **nrcmd** program, run the following command and verify the output is the same:

```
nrcmd> extension list
100 Ok
dextdropas:
  entry = dextdropas
  file = libdextdropas.so
  init-args =
  init-entry =
  lang = Dex
preClientLookup:
  entry = bprClientLookup
  file = libbprextensions.so
  init-args = BACC_HOME=/opt/CSCObpr, BACC_DATA=/var/CSCObpr
  init-entry = bprInit
  lang = Dex
prePacketEncode:
  entry = bprExecuteExtension
  file = libbprextensions.so
  init-args =
  init-entry =
  lang = Dex
```

**Note**

The <BACC\_HOME> and <BACC\_DATA> values may be different in your installation.

---

Also in the **nrcmd** program, run the following command and verify the output is the same:

```
nrcmd> dhcp listextensions
100 Ok
post-packet-decode: dextdropas
pre-packet-encode: prePacketEncode
pre-client-lookup: preClientLookup
post-client-lookup:
post-send-packet:
pre-dns-add-forward:
check-lease-acceptable:
```

---

## Installing the Key Distribution Center

To install the Key Distribution Center (KDC), complete the steps described in the “[Installation and Startup Process](#)” section on page 2-2, then follow these steps:

**Step 1** On the Installation Components screen, select the Key Distribution Center option, then click **Next** to continue; the Home Directory Destination screen appears.

**Step 2** Enter the pathname for the home directory, or click the **Browse** button to locate the desired directory.



**Note** The installation program does not ask for the home directory when it identifies that you are installing BACC components on a computer that already has a BACC component installed on it.

**Step 3** Click **Next**. The installation program performs some validation and, prompts you to create the directory, if necessary, before displaying the Data Directory Destination screen.

**Step 4** Click **Next** and the Key Distribution Center Realm Name screen appears.

**Step 5** Enter the appropriate information into the fields shown.

Field Name	Description
KDC Realm	Specifies, using a unique name, the Kerberos realm. This must match the realm set at the associated components.
KDC FQDN	Identifies the fully qualified domain name on which the KDC server is located.
KDC Interface Address	Specifies the interface (generally the IP address of the KDC server) on which the KDC listens for requests.

**Step 6** Click **Next** and the KDC Service Key and DPE screen appears.



**Note** The KDC requires a password for each DPE. This password must be entered at the corresponding DPE and **MUST** match that entered for the KDC otherwise the DPE will not operate.

**Step 7** Enter a 6 to 20 character password (see the example below) and the fully qualified domain name (FQDN), for each DPE, and then click **Add**. Continue to add additional DPEs as necessary.

### Example KDC Password

12345678901234567890

**Step 8** Click **Next** when you are done. The Installation Parameters screen appears.

**Step 9** After verifying that the parameters are correct, click **Next** to install BACC, or **Back** to modify the parameters. When installation is complete, the Installation Summary screen appears.

**Step 10** Click **Finish** to end the installation process and exit the installation program.

**Caution**

After installing the KDC, you must install your licenses, and the chain of certificates, or the KDC will not start.

## Installing the Device Provisioning Engine

To install the DPE, complete the steps described in the [“Installation and Startup Process”](#) section on page 2-2, then follow these steps:

- Step 1** On the Installation Components screen, select the Device Provisioning Engine option, then click **Next** to continue; the Home Directory Destination screen appears.
- Step 2** Enter the pathname for the home directory, or click the **Browse** button to locate the desired directory.
- Step 3** Click **Next**. The installation program performs some validation and, prompts you to create the directory, if necessary, before displaying the Data Directory Destination screen.
- Step 4** Click **Next**, when you are done. The Installation Parameters screen appears.
- Step 5** After verifying that the parameters are correct, click **Next** to install the DPE, or **Back** to modify the parameters. When installation is complete, the Installation Summary screen appears.
- Step 6** Click **Finish** to end the installation process and exit the installation program.

## Installing Components Using the CLI

This section explains the procedures that you follow to install one or more of components of BACC using the CLI.

Refer to these sections for installation instructions:

- [Installing the Regional Distribution Unit, page 3-9](#)
- [Installing Network Registrar Extensions, page 3-11](#)
- [Installing the Key Distribution Center, page 3-14](#)
- [Installing the Device Provisioning Engine, page 3-16](#)

For more information about each component see the [“Broadband Access Center for Cable Components”](#) section on page 2-1.

Before you begin any of these procedures, you must complete the initial installation procedure. For more information, see the [“Installing from the Command Line”](#) section on page 2-8.

## Installing the Regional Distribution Unit

To install an RDU, complete the steps described in the [“Installing from the Command Line”](#) section on page 2-8. Then, follow these steps:

**Step 1** When the installation program prompts you to select one or more components, enter **y** and press **Enter** at the Regional Distribution Unit (RDU) (y/n/?) prompt. The program then asks if you want to install Cisco Network Registrar extension points, the DPE, and the KDC.

**Step 2** To skip installing either the extension points or the KDC, press **n** and **Enter** for each option.

You can choose to install these options at a later date. See the [“Installing Network Registrar Extensions”](#) section on page 3-11 for additional information.

For example:

```
Installation Components
```

```
Select one or more components to install BPR.
Regional distribution unit (RDU) (y/n/?) [no] y
Cisco Network Registrar extension points (y/n/?) [no] n
Device Provisioning Engine (DPE) (y/n/?) [no] n
Key Distribution Center (KDC) (y/n?) [no] n
```

The program prompts you to confirm the components that you want to install.

**Step 3** Press **y** and **Enter** to continue. The program prompts you to start individual component validation.

**Step 4** Press **Enter** to continue. For example:

```
Starting the individual component installation parameters validation.
```

```
Press Enter to Continue or 'q' to Quit:
Validating the individual component installation parameters - Please wait.
```

The program prompts you to enter the home directory destination.

**Step 5** To accept the default directory, /opt/CSCObpr, press **Enter**; or enter another directory. For example:

```
Home Directory Destination
```

```
Home Directory Destination [/opt/CSCObpr]
```

The program asks you to confirm the directory.

**Step 6** Press **y** and **Enter** to continue. The program prompts you to enter the data directory destination.

**Step 7** To accept the default directory, /var/CSCObpr, press **Enter**; or enter another directory. For example:

```
Data Directory Destination
```

```
Data Directory Destination [/var/CSCObpr]/var/disk0/CSCObpr
```

The program then asks you to confirm the directory.



**Note** By default, the installation program installs the data directory (BPR\_DATA) on a different directory than the home directory (BPR\_HOME). Cisco Systems recommends that the data directory be on a different physical disk than the home directory; for example, /var/disk0/CSCObpr. However, you can install the data directory on the same disk as the home directory.

**Step 8** Press **y** and **Enter** to continue. The program prompts you to enter the database transaction logs destination.

**Step 9** To accept the default directory, `/var/CSCObpr`, press **Enter**; or enter another directory. For example:

```
Database Transaction Logs Destination
```

```
Logs Directory Destination
```

```
Logs Directory Destination [/var/CSCObpr] /var/disk1/CSCObpr
```

The program then asks you to confirm the directory.



**Note** By default, the installation program installs the database transaction logs directory (BPR\_DBLOG) in the same directory as the data directory (BPR\_DATA). Cisco Systems recommends that you locate the database transaction logs directory on the fastest disk on the system and that you ensure that the disk has 1 GB of space available.

The directory specified becomes the top-level directory under which the installation program creates a number of subdirectories.

**Step 10** Press **y** and **Enter** to continue. The program prompts you to enter the listening port for the RDU.

**Step 11** To accept the default value, 49187, press **Enter**; or enter another port number. For example:

```
Regional Distribution Unit Host/Port
```

```
Enter the IP address and the listening port of the regional distribution
unit(RDU)associated with this installation.
```

```
Enter the Host/IP address and address of the listening port for the RDU and RDU Listening
Port [49187]
```



**Note** The installation program obtains the IP address of the RDU automatically. You do not need to enter this value.

The program then prompts you to confirm the listening port number.



**Note** The RDU listens on all interfaces. The listening port is the port number that the RDU uses to communicate with other BACC components, such as DPEs and Network Registrar extension points.

**Step 12** Press **y** and **Enter** to continue. The program prompts you to enter the shared secret password.



**Note** You must use the same shared secret password for all RDUs, DPEs, and Network Registrar extension points in your network. The default password is **secret**.

**Step 13** Enter the password that you want to use for authentication among BACC servers. For example:

```
Shared Secret Password
```

```
Enter the password to be used for authentication
among the BPR servers.
```

If you are performing a lab installation, then the password will be used for all the servers. If this is a component installation, then the password you enter must be the same as the components previously installed.

```
Enter the Shared Secret Password [secret] changeme
```

The program prompts you to confirm the password.

- Step 14** Enter the password again and press **y** to continue. The program displays the installation parameters you have selected. For example:

```
The Component Installation will use the following parameters
to install the RDU component:
```

```
Home directory:/opt/CSCObpr
Data directory:/var/disk0/CSCObpr
Logs directory:/var/disk1/CSCObpr
RDU Port:49187
```

- Step 15** Press **y** to install the RDU component. The program displays a message when the installation is complete.



**Caution**

You must configure your license keys using the administrator's user interface. Refer to the *Cisco Broadband Access Center for Cable Administrator's Guide* for further information.

## Installing Network Registrar Extensions

Before you install Network Registrar extensions, complete the steps described in the [“Installing from the Command Line” section on page 2-8](#) and ensure that Network Registrar is running. To install the extensions:

- Step 1** When the installation program prompts you to select one or more components, press **y** and **Enter** at Cisco Network Registrar extension points (y/n/?).

To skip installing an RDU, the DPE, and the KDC, press **n** and **Enter** for these options.

For example:

```
Installation Components
```

```
Select one or more components to install BPR.
```

```
Regional distribution unit (RDU) (y/n/?) [no] n
Cisco Network Registrar extension points (y/n/?) [no] y
Device Provisioning Engine (DPE) (y/n/?) [no] n
Key Distribution Center (KDC) (y/n?) [no] n
```

The program prompts you to confirm the components that you want to install.

- Step 2** Press **y** and **Enter** to continue. The program displays a message that it is starting individual component validation.

- Step 3** Press **Enter** to continue. For example:

```
Starting the individual component installation parameters validation.
```

```
Press Enter to Continue or 'q' to Quit:
```

```
Validating the individual component installation parameters - Please wait.
```

The program prompts you to enter the home directory destination.

- Step 4** To accept the default home directory destination, /opt/CSCObpr/, press **Enter**; or enter another directory. For example:

```
Home Directory Destination

Home Directory Destination [/opt/CSCObpr]
```

The program then asks you to confirm the directory.

- Step 5** Press **y** and **Enter** to continue. The program prompts you to enter the data directory destination

- Step 6** To accept the default directory, /var/CSCObpr, press **Enter**; or enter another directory. For example:

```
Data Directory Destination

Data Directory Destination [/var/CSCObpr] /var/disk0/CSCObpr
```




---

**Note** By default, the installation program installs the data directory (BPR\_DATA) on a different directory than the home directory (BPR\_HOME). Cisco Systems recommends that the data directory be on a different physical disk than the home directory; for example /var/disk0/CSCObpr. However, you can install the data directory on the same disk as the home directory.

---

- Step 7** Press **y** and **Enter** to continue. The program prompts you to enter the host IP address and the listening port of the RDU.

- Step 8** Enter the IP address (or hostname) and listening port of the host where the RDU software is installed. The program prompts you to confirm this information. For example:

```
Regional Distribution Unit Host/Port

Enter the IP address and the listening port of the regional distribution unit (RDU)
associated with this installation.

Enter the Host/IP address and address of the listening port for the RDU.

RDU IP Address [doc-u5.cisco.com] 10.10.10.2
RDU Listening Port [49187]

===== Confirmation =====
RDU Host:10.10.10.2
RDU Port:49187

Is this correct (y/n/q/?) [yes] y
```

- Step 9** Press **y** and **Enter** to continue. The program prompts you to enter the name of the extension point provisioning group.

- Step 10** Enter the name of the Network Registrar extension point group. For example:

```
Cisco Network Registrar Extension Point Provisioning Group
Enter the Cisco Network Registrar extension point provisioning group.
```

This a required field. The value you specify must contain only alphanumeric characters without spaces and not exceed 10 characters in length. You can use the BPR command-line tool to change this value after you complete this installation.

```
Extension Point Provisioning Group [] group1
```

- Step 11** Press **y** and **Enter** to continue. The program then lets you decide if you are going to be provisioning voice technology devices. For example:

```
Are you going to use a device(s) that supports PacketCable voice technology?
```

```
If you are going to use PacketCable devices we need some more info.
Enter Yes to Install PacketCable and No if you do not want Packetcable
installed [No]: yes
```

- Step 12** Press **y** if you are using voice technology devices or **n** if you are not. If you are not using voice technology devices, you will be prompted to enter a shared secret password as described in Step 14. If you press **y**, the program will prompt you to enter several voice technology properties. For example:

```
Enter KDC Realm Name          ACME.COM

Enter the IP Address of the Primary DHCP Server.    10.10.10.1

Enter the IP Address of the Primary DNS Server.    10.10.10.3

Enter the IP Address of the Secondary DHCP Server.  10.10.10.2

Enter the IP Address of the Secondary DNS Server.  10.10.10.4
```

- Step 13** Press **y** and **Enter** to continue. The program prompts you to enter the shared secret password.




---

**Note** You must use the same shared secret password for all BACC servers on your network.

---

- Step 14** Enter the password that you want to use for authentication among BACC servers. For example:

```
Shared Secret Password
```

```
Enter the password to be used for authentication
among the BPR servers.
```

```
If you are performing a lab installation, then the password will be used for all the
servers. If this is a component installation, then the password you enter must be the
same as the components previously installed.
```

```
Enter the Shared Secret Password [secret] changeme
```

The program prompts you to confirm the password.

- Step 15** Enter the password again.

- Step 16** Press **y** and **Enter** to continue. The program then displays the installation parameters you have selected. For example:

```
Installation Parameters
```

```
This screen shows the installation parameters that you have chosen:
```

```
===== Confirmation =====
The Component Installation will use the following parameters
to install the NR Extension Points component:
```

```
Home directory:/opt/CSCObpr
Data directory:/var/disk0/CSCObpr
NR extension point provisioning group:group1
```

- Step 17** Press **y** and **Enter** to install the Network Registrar extensions. The program displays a message when the installation is complete.

- Step 18** To configure the extensions complete the procedure described in the “Configuring Extensions” section on page 3-5.

## Installing the Key Distribution Center

To install the KDC:

- Step 1** When the installation program prompts you to select one or more components, press **y** and **Enter** at Key Distribution Center (KDC) (y/n/?).

To skip installing an RDU and Network Registrar extension points, enter **n** and **Enter** for these options.

For example:

```
Installation Components
```

```
Select one or more components to install BPR.
```

```
Regional distribution unit (RDU) (y/n/?) [no] n
Cisco Network Registrar extension points (y/n/?) [no] n
Device Provisioning Engine (DPE) (y/n/?) [no] n
Key Distribution Center (KDC) (y/n/?) [yes] y
```

The program prompts you to confirm the components that you want to install.

- Step 2** Press **y** and **Enter** to continue. The program displays a message that it is starting individual component validation.

- Step 3** When validation is complete, the program prompts you to enter the home directory destination. Validation involves checking to verify that the correct patches have been installed. If they are not, error messages appear on screen.

- Step 4** To accept the default home directory destination, /opt/CSCObpr/, press **Enter**, or enter another directory. For example:

```
Home Directory Destination
```

```
Home Directory Destination [/opt/CSCObpr]
```

Choosing yes will create the directory during the installation. Choosing no will allow a different directory to be chosen.

```
The directory /opt/CSCObpr does not exist. Create it? (y/n/?) [yes]
```

- Step 5** When validation is complete, the program prompts you to enter the data directory destination.

- Step 6** To accept the default data directory destination, /var/CSCObpr/, press **Enter**, or enter another directory. For example:

```
Data Directory Destination
```

```
Data Directory Destination [/var/CSCObpr]
```

Choosing yes will create the directory during the installation. Choosing no will allow a different directory to be chosen.

```
The directory /var/CSCObpr does not exist. Create it? (y/n/?) [yes]
```

The program prompts you to confirm the components that you want to install.

- Step 7** Press **y** and **Enter** to create the directory and continue. The program prompts you to enter the KDC realm name. For example:

```
Key Distribution Center (KDC) Realm Name
```

```
Enter the Kerberos realm name for the KDC:
```

```
The realm name should be consistent with the realm you give to DPEs in this provisioning group.
```

```
KDC Interface Address [10.10.10.5]
KDC FQDN [acme_u6.acme.com]
KDC Realm [ACME.COM]
```

The program prompts you to confirm the realm name.

- Step 8** Press **y** and **Enter** to confirm your entry and continue. The program prompts you to enter the KDC service key and the DPE panel. For example:

```
KDC Service Key and DPE Panel
```

```
Please Enter the Necessary Info
```

```
Enter Password Here [] 12345678901234567890
Enter Your DPE FQDN [] dpe1.cisco.com
```




---

**Note** Please be aware that the service key consists of 48 characters. If all are not entered the service key will be invalid.

---

- Step 9** The program prompts you to enter the information for another DPE. Press **y** and **enter** to add another DPE, or press **n** and enter to continue.




---

**Note** The installation program uses the same voice technology shared key for all DPEs.

---

- Step 10** Press **y** and **Enter** to continue. The program displays the installation parameters that you selected. For example:

```
Installation Parameters
```

```
This screen shows the installation parameters that you have chosen:
```

```
===== Confirmation =====
The Component Installation will use the following parameters
to install the KDC component:
```

```
KDC realm name: ACME.COM
Home directory: /opt/CSCObpr
Data directory: /var/CSCObpr
```

- Step 11** Press **y** and **Enter** to install the KDC. The program displays a message when the installation is complete.




---

**Caution** After installing the KDC, you must install your licenses and the chain of certificates or the KDC will not start.

---

## Installing the Device Provisioning Engine

To install the DPE:

- Step 1** When the installation program prompts you to select one or more components, press **y** and **Enter** at Device Provisioning Engine (y/n/?).
- To skip installing an RDU and Network Registrar extension points, enter **n** and **Enter** for these options.

For example:

```
Installation Components
```

```
Select one or more components to install BPR.
```

```
Regional distribution unit (RDU) (y/n/?) [no] n
Cisco Network Registrar extension points (y/n/?) [no] n
Device Provisioning Engine (DPE) (y/n/?) [yes] y
Key Distribution Center (KDC) (y/n/?) [no] n
```

The program prompts you to confirm the components that you want to install.

- Step 2** Press **y** and **Enter** to continue. The program displays a message that it is starting individual component validation. Press **Enter** to continue

- Step 3** When validation is complete, the program prompts you to enter the home directory destination. Validation involves checking to verify that the correct patches have been installed. If they are not, error messages appear on screen.

- Step 4** To accept the default home directory destination, /opt/CSCObpr/, press **Enter**, or enter another directory. For example:

```
Home Directory Destination
```

```
Home Directory Destination [/opt/CSCObpr]
```

```
Choosing yes will create the directory during the installation. Choosing no will allow a
different directory to be chosen.
```

```
The directory /opt/CSCObpr does not exist. Create it? (y/n/?) [yes]
```

- Step 5** When validation is complete, the program prompts you to enter the data directory destination.

- Step 6** To accept the default data directory destination, /var/CSCObpr/, press **Enter**, or enter another directory. For example:

```
Data Directory Destination
```

```
Data Directory Destination [/var/CSCObpr]
```

```
Choosing yes will create the directory during the installation. Choosing no will allow
a different directory to be chosen.
```

```
The directory /var/CSCObpr does not exist. Create it? (y/n/?) [yes]
```

The program prompts you to confirm the components that you want to install.

- Step 7** Press **y** and **Enter** to create the directory and continue. The program displays the installation parameters that you selected. For example:

```
Installation Parameters
```

```
This screen shows the installation parameters that you have chosen:
```

```
===== Confirmation =====  
The Component Installation will use the following parameters  
to install the DPE component:  
  
    Home directory: /opt/CSCObpr  
    Data directory: /var/CSCObpr
```

**Step 8** Press **y** and **Enter** to install the DPE. The program displays a message when the installation is complete.

---





## CHAPTER 4

# Installing in a Lab Environment

---

This chapter describes how to install BACC in a lab environment to demonstrate product functionality and how to configure a CMTS and Network Registrar to support BACC.

When you install Broadband Access Center for Cable (BACC) in a lab environment, the installation program installs all components on a single server. The lab installation program involves fewer steps than the component installation and automates much of the configuration. When you complete the installation, however, you need to perform some setup on a cable modem termination system (CMTS) and on Network Registrar.

The lab installation program is designed to keep the installation and configuration as simple as possible by using a predefined overall system configuration.

The lab installation program uses predefined default values for the installation that assume a specific network configuration.

## Installation Checklist

You can install BACC in a lab environment on a single computer running the Solaris 8 or 9 operating system. Before you run the installation program, use this checklist to ensure that you are ready:

- Verify the prerequisite system hardware and software requirements described in [Chapter 1, “Overview.”](#)
- Have your BACC evaluation license key or keys at hand. You need a valid license key for each technology that you want to provision with BACC.
- Ensure that you have *root* access to the computers where you intend to install BACC.
- Verify that Network Registrar is installed and running on the server. We recommend that you use Network Registrar 6.1.2.3 or higher.
- Determine the destination directory in which you want to install BACC.



---

**Note** Cisco Systems recommends that you have at least 350 MB of disk space available.

---

- For extensions, determine the name of provisioning group to which the Network Registrar server belongs.
- Verify that you have the necessary Network Registrar configuration files. See [Appendix A, “Network Registrar Configuration File Example”](#) for an example of these configuration files.

# Installing in a Lab Environment Using the GUI

The lab installation prompts for this information:

- BACC destination directory
- Network Registrar administrator username and password
- Shared secret password

During a lab installation, a set of predetermined default values are used as a network configuration.

To install BACC in a lab environment, complete these steps:

- 
- Step 1** Complete steps 1 through 4 in the [“Installation Using the Graphical User Interface”](#) section on page 2-7.
- Step 2** Click **Lab** when the Choose Installation Type screen appears.
- Step 3** Click **Next**. The lab installation program automatically checks to see if it detects a TFTP server.




---

**Caution** When installing BACC on a Solaris server, both the Solaris and Network Registrar TFTP servers must be disabled.

---

Provided that a TFTP server is not detected, a PacketCable voice technology screen appears.

- Step 4** Determine if you need to install the voice technology option and click:
- **Yes** button if you want to install the voice technology option
  - **No** if you do not have a valid license key for this technology.
- Step 5** Click **Next** and the Destination Directory screen appears.
- Step 6** Enter the pathname of the location where you want to install BACC.
- Step 7** Click **Next**. The installation program verifies that the selected installation directory exists and, if it does not, prompts you to automatically create it. The installation program also confirms that the required disk space is available, and then the Cisco Network Registrar Username and Password screen appears.
- Step 8** Enter the Network Registrar administrative username and password.
- Step 9** Click **Next**. The Key Distribution Center Realm Name screen appears.
- Step 10** If the default KDC realm name is inappropriate, enter desired KDC Realm, FQDN, and interface address name.
- Step 11** Click **Next**. The PacketCable Properties screen appears.




---

**Note** If you did not select the voice technology option from the PacketCable Panel, this screen will not appear.

---

- Step 12** Enter the appropriate information into the fields shown.

Field Name	Description
Kerberos Realm Name	Specifies, using a unique name, the Kerberos realm. This must match the realm set at the associated components.
IP Address of Primary DHCP Server	Specifies the IP address of the voice technology primary DHCP server.
IP Address of Primary DNS Server	Specifies the IP address of the computer which is running the primary DNS server.
IP Address of Secondary DHCP Server	Specifies the IP address of the voice technology secondary DHCP server.
IP Address of Secondary DNS Server	Specifies the IP address of the computer which is running the secondary DNS server; if that server is being used.

**Step 13** The Shared Secret Password screen appears.

**Step 14** Enter and confirm the shared secret password. This password is a token that a BACC server uses to authenticate communication with other BACC servers.

**Step 15** Click **Next** and the Lab Installation Parameters screen appears. This screen identifies the values that you have entered in the previous screens. To modify any of the values entered:

- a. Click **Back** until the desired screen appears.
- b. Make the necessary changes.
- c. Click **Next** repeatedly until you return to this screen.

**Step 16** Click **Next** and the lab version of BACC is installed. When installation is complete, the Installation Summary screen appears.

**Step 17** Click **Finish** and BACC is completely installed in your lab environment.



**Note**

You use the administrator's user interface to configure your license keys. Refer to the *Cisco Broadband Access Center for Cable Administrator's Guide* for additional information.



**Caution**

After installation is complete, you must install your licenses and the chain of certificates or the KDC will not start.

## Installing in a Lab Environment Using the CLI

The lab installation prompts for this information:

- BACC destination directory
- Network Registrar administrator username and password
- Shared secret password

To install BACC in a lab environment, complete the steps described in the “[Installing from the Command Line](#)” section on page 2-8:

**Step 1** The program displays this message:

```
Are you going to use a device(s) that supports Packetcable voice technology?
```

```
If you are going to use Packetcable devices we need some more info.
Enter Yes to Install Packetcable and No if you don't want Packetcable
installed [No]: Yes
```

**Step 2** Enter **Yes** and press **Enter**. A confirmation message appears.

**Step 3** Answer the confirmation question appropriately and press **Enter**. The program displays this message.

```
Validating LAB settings...
```

The program then prompts you to enter the destination directory.

**Step 4** To accept the default directory, /opt/CSCObpr, press **Enter**. For example:

```
Destination Directory

Directory path for BACC_HOME

Location BACC_HOME

Installation Directory [/opt/CSCObpr]
```

The program then asks you to confirm the directory.

**Step 5** Press **y** and **Enter** to continue. The program prompts you to enter the Cisco Network Registrar username and password.

**Step 6** To enter a Network Registrar username and password:

- a. Enter a valid administrator username and password.
- b. Enter the password again to confirm it.

For example:

```
Cisco Network Registrar Username and Password

Enter the administrator username and password for the NR server.

Enter the username and password for the NR server to be used in the lab
installation. You must confirm the NR password.
Network Registrar administrator Username [admin] admin
Network Registrar administrator Password [] changeme
Confirm Network Registrar Password [] changeme
```

The program then redisplay the administrator username, password, and password confirmation. It then prompts you to confirm this information.

**Step 7** Press **y** and **Enter** to continue. The program prompts you to enter the KDC realm name. The realm name must be the same one used with all of the DPEs in the provisioning group. For example:

```
Enter the Kerberos realm name for the KDC
```

The realm name should be consistent with the realm you give to DPEs in this provisioning group.

```
KDC Interface Address:
KDC FQDN:
KDC Realm:
```

**Step 8** Enter the appropriate KDC Interface Address, FQDN, and Realm information and then press **Enter**. The program redisplay the KDC information and prompts you to confirm this information.

**Step 9** Press **y** and **Enter** to continue. The program prompts you to enter PacketCable properties. For example:

```
Enter PacketCable properties

Enter KDC Realm Name
Enter IP Address for Primary DHCP []
Enter IP Address for Primary DNS []
Enter IP Address for Secondary DHCP []
Enter IP Address for Secondary DNS []
```

**Step 10** Enter the appropriate voice technology information. Keep in mind that the KDC Realm name you enter here must be the same as that entered in the previous screen.

**Step 11** Press **Enter**; the program redisplay the PacketCable Properties information and prompts you to confirm the information.

**Step 12** Press **y** and **Enter** to continue. The program prompts you to enter the shared secret password. This password is a token that a BACC server uses to authenticate communication with other BACC servers. The default password is **secret**.

**Step 13** Enter the password that you want to use for authentication among BACC servers. For example:

```
Shared Secret Password

Enter the password to be used for authentication
among the BPR servers.

If you are performing a lab installation, then the password will be used for
all the servers. If this is a component installation, then the password you
enter must be the same as the components previously installed.

Enter the Shared Secret Password [secret] secret
```

The program prompts you to confirm the password.

**Step 14** Enter the password again and press **y** to continue. The program then displays the installation parameters that you selected. For example:

```
Installation Parameters

This screen shows the installation parameters that you have chosen:

===== Confirmation =====
The Lab/Demo Installation will install all components using the following
parameters:

Installation directory:/opt/CSCObpr

Is this correct (y/n/q/?) [yes]
```

**Step 15** Press **y** and **Enter** to install the lab software. The program displays a message when the installation is complete.



**Note**

You use the administrator's user interface to configure your license keys. Refer to the *Cisco Broadband Access Center for Cable Administrator's Guide* for additional information.

**Caution**

After installation is complete, you must install your licenses and the chain of certificates or the KDC will not start.

## Configuring Network Registrar and a CMTS

For BACC to function, you need to set up Network Registrar client-classes, policies, scopes, and selection tags. You also need to perform some configuration of CMTS devices.

To configure Network Registrar and CMTS devices, complete these steps:

**Step 1** Set up scopes on your Network Registrar server. For example:

```
<NR_HOME>/usrbin/nrcmd -N <USER_NAME> -P <PASSWORD> -b <
<BACC_HOME>/cnr_ep/samples/bpr_cnr_hsd_sample_config.nrcmd
```

**Note**

The `<BACC_HOME>/cnr_ep/samples/bpr_cnr_hsd_sample_config.nrcmd` command runs a sample Network Registrar configuration script, which defines client-classes, policies, scopes, selection tags and other related information. You must update this file to reflect the IP address settings on your network. For more information about this file, see [“Network Registrar Configuration File Example”](#). For more detailed information about defining client-classes, policies, scopes, and selection tags, see the *Network Registrar User’s Guide*.

**Step 2** Enable the cable interface or interfaces on your CMTS with the correct IP addresses and DHCP helper-address. For example, you might edit the CMTS configuration as follows:

```
interface Cable3/0
  ip address 192.168.5.0 255.255.255.0
  ip address 192.168.6.0 255.255.255.0 secondary
  ip address 192.168.7.0 255.255.255.0 secondary
  ip address 192.168.8.0 255.255.255.0 secondary
```

**Note**

The IP addresses used here are identical to those in the sample script supplied with the BACC product. You must edit these addresses to match your own IP address range. Do not attempt to use these IP addresses in an operational environment.

```
no ip directed-broadcast
no keepalive
cable downstream annex B
cable downstream modulation 64qam
cable downstream interleave-depth 32
cable downstream frequency 477000000
cable upstream 0 frequency 26000000
cable upstream 0 power-level 0
no cable upstream 0 shutdown
cable dhcp-giaddr primary
cable helper-address <IP Address Of Your Network Registrar Server>
```

**Note**

A sample configuration script file is included with the BACC product. This file, called `cmts_sample.cfg`, is located in the `<BACC_HOME>/cnr_ep/samples` directory.

- Step 3** To configure your CMTS to insert the DHCP relay agent information option in forwarded BOOTREQUEST messages, use this Cisco IOS command:

```
ip dhcp relay information option
```

The default device detection logic in BACC uses DHCP option 82 information (relay-agent information) to detect devices.

- Step 4** To configure your CMTS so that it does *not* validate the relay agent information option in forwarded BOOTREPLY messages, use this IOS command:

```
no ip dhcp relay information check
```

---





# CHAPTER 5

## Post-Installation Activities

---

This chapter describes activities you can perform after installing BACC:

- [Enabling a Network Registrar Spoofing DNS Server, page 5-1](#)
- [Configuring the Syslog Utility to Receive Alerts from BACC, page 5-1](#)
- [Uninstalling Broadband Access Center, page 5-2](#)

### Enabling a Network Registrar Spoofing DNS Server

A spoofing DNS server redirects all DNS requests to the same IP address. This can be used to enforce a self-provisioning flow for a new subscriber.

For example, assume that a DNS host is *dns.acme.com*, and has an IP address of 10.10.10.5. Assume also, that the Web server with the self-provisioning flow is 10.10.10.6.

On the DNS server, set the following in Network Registrar:

```
nrcmd> zone . delete
nrcmd> zone . create primary dns.acme.com postmaster.dns.acme.com
nrcmd> zone . addrr * a 10.10.10.6
nrcmd> save
nrcmd> dns reload
```

When DNS reloads, the changes will take effect.

On the DHCP server, set the following in Network Registrar:

```
nrcmd> policy unprovisioned setoption domain-name-servers 10.10.10.5
nrcmd> policy unprovisioned setoption domain-name acme.com
nrcmd> save
nrcmd> dhcp reload
```

### Configuring the Syslog Utility to Receive Alerts from BACC

This section describes how to configure the syslog utility on both the Network Registrar extension points and RDU server to receive alerts and debugging information from BACC.

- 
- Step 1** Log in as *root* on the Network Registrar server.
- Step 2** At the command line, create the log file. For example:

```
touch /var/log/bpr.log
```

**Step 3** Open the `/etc/syslog.conf` file with a text editor.

**Step 4** Add this line to the `/etc/syslog.conf` file:

```
local6.info          /var/log/bpr.log
```




---

**Note** You must insert one or more tabs between the `local6:info` and `/var/log/bpr.log` information.

---

**Step 5** Save and close the `/etc/syslog.conf` file.

**Step 6** To force the syslog utility to take the new configuration, at the command line enter these commands:

```
ps -ef | grep syslogd
root      217      1  0  Nov 26   ?        0:00   /usr/sbin/syslogd

kill -HUP 217
```




---

**Note** The pid in this example is 217, but may change when you run `ps -ef | grep syslogd`. Use the correct output, from that command, as the input to `kill -HUP`.

---

Syslog is now ready to receive alerts from BACC.

---

## Uninstalling Broadband Access Center

The program described in this section uninstalls the RDU, Network Registrar extensions, the DPE, and the KDC, but it does not uninstall the Network Registrar application. Prior to removing BACC you must manually remove the BACC configuration on Network Registrar.

The uninstallation program removes all files located under the installation directory (the default installation directory is `/opt/CSCObpr`). If the database is found under the installation directory, as is the case in the lab installation program, the program displays a warning message that it is deleting the database. You can exit from the uninstallation program at that time, or you can choose to proceed.

The uninstallation program also shuts down and removes these processes if they are detected: RDU, KDC, SNMP Agent, JRun, BACC agent, and the DPE.

The uninstallation program does *not* remove files that were placed outside the installation directory. For example, a component installation places the database and database transaction logs directories under `/var/CSCObpr`. So these files are not removed. The uninstallation program also does *not* remove any files that are located under the Network Registrar directory.



### Caution

---

If you uninstall BACC after configuring your Network Registrar servers to use BACC extensions, your network will no longer function correctly. You must uninstall BACC extensions in Network Registrar to completely uninstall the BACC program.

---

There are two ways to remove BACC:

- [Uninstalling BACC from the Graphical User Interface, page 5-3](#)
- [Uninstalling BACC from the Console Mode, page 5-3](#)

## Uninstalling BACC from the Graphical User Interface

To uninstall BACC using the graphical user interface:

- Step 1** Log in as *root*.
- Step 2** Manually remove the configuration of the BACC extensions on the Network Registrar server. You can do this from any server that has **nrcmd** installed and connectivity with Network Registrar.
- Follow these steps:
- To uninstall the BACC extensions from your Network Registrar configuration, use these commands:

```
<NR_HOME>/usrbin/nrcmd -N admin -P changeme -b <
<BACC_HOME>/cnr_ep/bin/bpr_cnr_disable_extpts.nrcmd
```
  - To reload your DHCP server, use these commands:

```
/etc/init.d/nwreglocal stop
/etc/init.d/nwreglocal start
```

Alternatively, enter this command:

```
<NR_HOME>/usrbin/nrcmd -N admin -P changeme "dhcp reload"
```
  - To remove the BACC extensions from the Network Registrar extensions directory, use this command:

```
rm -f <NR_HOME>/extensions/dhcp/dex/libbprextensions.so
```
- Step 3** At the CLI prompt, enter:

```
<BACC_HOME>/_uninst/uninstall.bin
```

The uninstallation program's Welcome screen appears.
- Step 4** Click **Next**. The uninstallation program begins removing BACC files.
- When the uninstallation is complete, the Cisco Broadband Provisioning Registrar was Uninstalled screen appears.

- Step 5** To exit the uninstallation program, click **Finish**.

**Note**

Should the uninstallation program fail to successfully uninstall BACC, error messages will appear on screen.

## Uninstalling BACC from the Console Mode

To uninstall BACC from the console mode:

**Note**

If you are uninstalling BACC from a lab installation, the database is automatically deleted based on your confirmation. To prevent the accidental or unplanned deletion of the database, copy or back up the database files and log files as instructed in the *Cisco Broadband Access Center for Cable Administrator's Guide*.

- 
- Step 1** Log in as *root*.
- Step 2** Manually remove the configuration of the BACC extensions on the Network Registrar server. You can do this from any server that has **nrcmd** installed and connectivity with Network Registrar. Follow these steps:
- a. To uninstall the BACC extensions from your Network Registrar configuration, use these commands:
 

```
<NR_HOME>/usrbin/nrcmd -N admin -P changeme -b <
<BACC_HOME>/cnr_ep/bin/bpr_cnr_disable_extpts.nrcmd
```
  - b. To reload your DHCP server, use these commands:
 

```
/etc/init.d/nwreglocal stop
/etc/init.d/nwreglocal start
```

Alternatively, enter this command:

```
<NR_HOME>/usrbin/nrcmd -N admin -P changeme "dhcp reload"
```
  - c. To remove the BACC extensions from the Network Registrar extensions directory, use this command:
 

```
rm -f <NR_HOME>/extensions/dhcp/dex/libbprextensions.so
```
- Step 3** At the CLI prompt, enter:
- ```
<BACC_HOME>/_uninst/uninstall.bin -console
```
- The following is displayed:
- ```
Welcome to the Uninstallation Program

Press Enter to uninstall Cisco Broadband Provisioning Registrar from your system.

Press Enter to Continue or 'q' to Quit:
```
- Step 4** Press **Enter** to start the removal process. When uninstallation is complete these messages appear:
- ```
Cisco Broadband Provisioning Registrar was Uninstalled

Cisco Broadband Provisioning Registrar files were uninstalled successfully.

Press Enter to finish:
```
- Step 5** Press **Enter** to exit the program.
-



# CHAPTER 6

## Upgrading Broadband Access Center for Cable

This chapter describes how to upgrade a BACC 2.5.0.2 or higher installation to BACC 2.7. If you have a BACC release preceding BACC 2.5.0.2, you must first upgrade your system to BACC 2.5.0.2 and then complete this upgrade procedure.

[Table 6-1](#) summarizes the order of upgrade and migration tasks required for BACC components for different versions.

**Table 6-1** Upgrading BACC components

| Version                                              | RDU                                                                             | Solaris DPE                                | Appliance DPE-590                                        | Appliance DPE-2115                                       | CNR-EP                                        | KDC                                        |
|------------------------------------------------------|---------------------------------------------------------------------------------|--------------------------------------------|----------------------------------------------------------|----------------------------------------------------------|-----------------------------------------------|--------------------------------------------|
| BACC 2.5.0.2<br>(Migration of RDU database required) | Run setup.bin. At the end, the installer prompts you to run the migration tool. | N/A                                        | Download the upgrade file and run the DPE patch process. | Download the upgrade file and run the DPE patch process. | Run the upgrade script to upgrade the CNR_EP. | Run the upgrade script to upgrade the KDC. |
| BACC 2.6.x<br>(Migration of RDU database required)   | Run setup.bin. At the end, the installer prompts you to run the migration tool. | Run the upgrade script to upgrade the DPE. | Download the upgrade file and run the DPE patch process. | Download the upgrade file and run the DPE patch process. | Run the upgrade script to upgrade the CNR_EP. | Run the upgrade script to upgrade the KDC. |

The BACC upgrade procedure requires that the components be updated in the exact order described below. Performing the upgrade in any other order may result in errors during provisioning:

- [Before You Begin, page 6-2](#)
- [Upgrading the RDU, page 6-2](#)
- [Upgrading the Solaris DPE, page 6-2](#)
- [Upgrading Hardware DPEs, page 6-4](#)
- [Upgrading Network Registrar Extensions, page 6-5](#)
- [Upgrading the KDC, page 6-5](#)

## Before You Begin

The following procedure is required before upgrading all components except the RDU.

- 
- Step 1** Untar the upgrade file(27upgrade.tar) onto the computer where the BACC components reside. For example:
- ```
tar -xvf 27upgrade.tar
```
- The component upgrade scripts are extracted to the **patch27/bin** upgrade folder.
- Step 2** Run the **backupDb.sh** script to back up the RDU database files. See the *Cisco Broadband Access Center for Cable Administrator's Guide* for additional information.
- 

## Upgrading the RDU

To upgrade the RDU:

- 
- Step 1** Run the **setup.bin** file normally associated with a new installation of BACC. The **setup.bin** file automatically detects the previous installation.
- Step 2** When the installation program prompts you to perform the database migration procedure, run the migration script using the **migrateDb.sh** script as described in [Migrating the RDU Database, page 6-6](#).
- 

## Upgrading the Solaris DPE

Complete these steps to upgrade the installed Solaris DPE component from release 2.6.x to release 2.7:

- 
- Step 1** Run this script from the upgrade folder:
- ```
./27-upgrade-dpe.sh
```
- Step 2** You must manually restart the agent to finish the upgrade process.

An output similar to this displays.

```
BPR Located
BPR Home directory is /opt/CSCObpr
Current version is 2.6.(x)
DPE Component Installed
Stopping the BPR Agent

BPR Agent is stopped.

BPR Agent stopped
Copying the Upgrade Files
Upgrading Package Information
Upgrade for BPR 2.7 Completed Successfully
Please start your BPR Agent to finish the upgrade Process
```

**Step 3** Run this command to verify that the output indicates it is BACC release 2.7:

```
# pkgparam CSCObpr VERSION
```

The version information returned should be 2.7.



**Note** The previous version of the file bpr.jar is renamed as bpr-2x.jar and is located in the <BACC\_HOME>/lib directory.

**Step 4** Check the list of installed files. An output similar to this is displayed.

```
drwxr-xr-x 4 root smmsp 512 May 26 11:22 electric
-rw-r--r-- 1 root smmsp 11730913 May 26 11:22 bpr.jar
-rwxr-xr-x 1 root smmsp 116848 May 26 11:22 libosstatus.so
-rwxr-xr-x 1 root smmsp 465392 May 26 11:22 libnative.so
-rwxr-xr-x 1 root smmsp 827344 May 26 11:22 libInformManager.so
-rwxr-xr-x 1 root smmsp 1983836 May 26 11:22 libbprextensions.so
-rw-r--r-- 1 root smmsp 30790 May 26 11:23 pkcerts.jar
-rwxr-xr-x 1 root smmsp 938940 May 26 11:23 libdb_java-4.1.so
-rwxr-xr-x 1 root smmsp 840988 May 26 11:23 libdb-4.1.so
-rwxr-xr-x 1 root smmsp 187162 May 26 11:23 sun_parser.jar
-rwxr-xr-x 1 root smmsp 28404 May 26 11:23 sun_jaxp.jar
-rwxr-xr-x 1 root smmsp 33428 May 26 11:23 sleepycat.jar
-rw-r--r-- 1 root smmsp 936631 May 26 11:23 bcprov.jar
-rwxr-xr-x 1 root smmsp 832960 May 26 11:23 libgcc_s.so.1
-rwxr-xr-x 1 root smmsp 62624 May 26 11:23 TelnetD.jar
-rwxr-xr-x 1 root smmsp 8661944 May 26 11:23 libstdc++.so.5
-rw-r--r-- 1 root smmsp 285176 May 26 11:23 libscp_java01.so
-rw-r--r-- 1 root smmsp 849020 May 26 11:23 libscp01.so
-rw-r--r-- 1 root smmsp 185208 May 26 11:23 libmlog.so
-rw-r--r-- 1 root smmsp 529820 May 26 11:23 libcnrschema.so
-rw-r--r-- 1 root smmsp 2847640 May 26 11:23 libaic.so
-rw-r--r-- 1 root smmsp 217572 May 26 11:23 dnsjava-1.5.1.jar
-rwxr-xr-x 1 root smmsp 29411 May 26 11:23 comm.jar
-rwxr-xr-x 1 root smmsp 384820 May 26 11:23 cnrsdk.jar
-rwxr-xr-x 1 root smmsp 131919 May 26 11:23 xmlParserAPIs.jar
-rwxr-xr-x 1 root smmsp 1728861 May 26 11:23 xercesImpl.jar
-rwxr-xr-x 1 root smmsp 2370312 May 26 11:23 libssl.so.0.9.7
-rwxr-xr-x 1 root smmsp 2328048 May 26 11:23 libnetsnmp.so.5
drwxr-xr-x 2 root smmsp 512 May 26 11:23 SnmpAgent
-rwxr-xr-x 1 root smmsp 14475552 May 26 11:23 libcrypto.so.0.9.7
-rwxr-xr-x 1 root smmsp 28404 May 26 11:23 jaxp.jar
-rwxr-xr-x 1 root smmsp 187162 May 26 11:23 crimson.jar
-rwxr-xr-x 1 root smmsp 1107051 May 26 11:23 AdventNetSnmp.jar
-rwxr-xr-x 1 root smmsp 801714 May 26 11:23 xalan.jar
-rwx----- 1 root smmsp 167588 May 26 11:23 libnativeCrypto.so
-rw-r--r-- 1 root smmsp 515746 May 26 11:23 adminui.war
-rw-r--r-- 1 root smmsp 84311 May 26 11:23 sampleui.war
```



**Note** The actual directory contents displayed in this procedure may differ, from those shown above, depending on the components installed on the computer.

# Upgrading Hardware DPEs

You may remotely patch your DPE devices, or if you have local access to these devices, you can fully reimage them. Refer to the recovery CD-ROM release notes that accompanied the DPE device for the required reimaging procedure.

Complete these steps to upgrade the DPE component to release 2.7:



**Caution**

If the hardware DPE is rebooted or powered off while a patch is being applied, the device is left in an unknown state and must be completely reimaged. Refer to either the DPE-590 or DPE-2115 *Recovery CD-ROM Release Notes* that accompany the DPE device, for reimaging instructions.

**Step 1**

Open an FTP connection to each DPE to be patched and upload the patch bundle to the DPE. See step 3 for the appropriate DPE file name.



**Note**

When opening the FTP connection, you must enter the username **admin** and the login password chosen for the selected DPE.

**Step 2**

After an FTP connection is established, change directory to 'incoming' using this command at the FTP prompt:

```
cd incoming
```

This will locate the patch file so that the DPE can easily find it.

**Step 3**

Select the upgrade file corresponding to the BACC version currently running on your DPE and FTP it to the DPE.

| If you have this DPE model... | Running this BACC release... | Use this file to upgrade to BACC 2.7 |
|-------------------------------|------------------------------|--------------------------------------|
| DPE 590                       | BACC 2.5.0.2                 | dpe-590-2502to27-upgrade.bpr         |
|                               | BACC 2.6.x                   | dpe-590-26xto27-upgrade.bpr          |
| DPE-2115                      | BACC 2.5.0.2                 | dpe-2115-2502to27-upgrade.bpr        |
|                               | BACC 2.6.x                   | dpe-2115-26xto27-upgrade.bpr         |

For example, you use this command to FTP the DPE-590 upgrade file from BACC 2.6.x to BACC 2.7:

```
bin
put dpe-590-26xto27-upgrade.bpr
```

**Step 4**

Log into each DPE, in the enable mode, and run the **upgrade** command. You are prompted to select the 2.7 upgrade file and apply it. After the upgrade is finished, the DPE will reboot.

**Step 5**

Log into each DPE, in the enable mode, and run the **show version** command. This should identify the current version running on the DPE as BACC 2.7.

# Upgrading Network Registrar Extensions

Use this procedure to upgrade the Network Registrar extensions from BACC 2.5.0.2, or 2.6.x to BACC 2.7:

- 
- Step 1** Run the **27-upgrade-cnrep.sh** script.
- Step 2** Stop the Network Registrar Server Agent when prompted.  
The upgrade script automatically copies the upgraded extension point files into the required directories. When complete, it prompts you to restart the Network Registrar Server Agent.
- Step 3** Run this command to verify that the output indicates it is BACC release 2.7:  
`# pkgparam CSCObpr VERSION`
- The version information returned should be 2.7.
- Step 4** Go to the `/opt/CSCObpr/lib` directory. Provided that the upgrade was successful, the directory content should appear similar to the list for the Solaris DPE upgrade with the addition of the `libbprextensions-2x.so` file.



**Note** The previous version of the file `bpr.jar` is renamed as `bpr-2x.jar` and is located in the `<BACC_HOME>/lib` directory.

- Step 5** If a second check is required to verify upgrade success, go to the `$CNR_HOME/extensions/dhcp/dex` directory and verify that these files appear:

```
-rwxr-xr-x      1 root  bin  6      0904      Oct 29 2003  libdexextension.so
-rwxr-xr-x      1 root  other 1530628  Jul 22 12:43 libbprextensions-2x.so
-rwxr-xr-x      1 root  other 1560748  Aug 11 12:49 libbprextensions.s
```



**Note** The actual directory contents displayed in this procedure may differ, from those shown above, depending on the components installed on the computer.

## Upgrading the KDC



**Note** BACC 2.7 KDC requires a new license. Please ensure that the correct license and certificates are installed before you start the BACC agent.

Use this procedure to upgrade the KDC from BACC 2.5.0.2 or 2.6.x to BACC 2.7:

- 
- Step 1** Run the **27-upgrade-KDC.sh** script.
- Step 2** Manually start the BACC agent to complete the upgrade process.
- Step 3** Run this command to verify that the output indicates it is BACC release 2.7:

```
# pkgparam CSCObpr VERSION
```

The version information returned should be 2.7.

**Step 4** Go to the `/opt/CSCObpr/kdc/internal/bin` directory. Provided that the upgrade was successful, this directory content should appear similar to this:

```
-r-x----- 1 root  smmsp      1388           May 26 11:23  shutdownKDC.sh
-r-x----- 1 root  smmsp      535           May 26 11:23  runKDC.sh
-rwxr-xr-x  1 root  smmsp    1023548        May 26 11:23  kdc
```

**Note**

The actual directory content that is displayed may differ, from that shown above, depending on the components installed on the computer.

## Migrating the RDU Database

The Regional Distribution Unit (RDU) database migration script lets you migrate your RDU database from BACC 2.5.0.2 into BACC 2.7.

The migration script is automatically installed, and unpacked, whenever the BACC 2.7 installation program (**setup.bin**) is run. The installation program unpacks the migration script file into the `<BACC_HOME>/migration` directory. You run the RDU database migration script using the **migrateDb.sh** script. This script migrates the BACC 2.5.0.2 or BACC 2.6.x database to BACC 2.7.

**Note**

Prior to installing the new BACC version you must run the **backupDb.sh** script to back up the database files. See the *Cisco Broadband Access Center for Cable Administrator's Guide* for additional information.

After the migration is completed, run the **verifyDb.sh** script to check database consistency. Verification is an optional step and may be skipped if shorter downtime for migration is critical.

Each time a migration is performed, information is recorded in a migration log file, which is stored in `<BACC_DATA>/rdu/logs` directory. The `migration.log` file identifies which version of the database is being migrated.

Start the RDU using “`bprAgent start rdu`” command and observe messages about successful initialization in the `rdu.log` file.

**Caution**

The RDU should not be started while migration is in progress; any attempt to restart the RDU results in a series of error messages being written into the `rdu.log` file. These messages will indicate that database migration is needed before the RDU can be restarted.

### Migrating from BACC 2.5.0.2

When migrating from release 2.5.0.2, you must use command line parameters to specify the file system directory for temporary storage when running the **migrateDb.sh** script. This script is located in the `<BACC_HOME>/migration` directory.

When running this script, use this syntax:

```
./migrateDb.sh temp_dir
```

Where *temp\_dir* identifies the temporary directory.

When performing this migration, you must allow for the available disk space required for temporary storage. The available disk space must be at least the same as the size of the old database files. However, for performance reasons, Cisco recommends that you locate this directory on a different disk from the database and the database log files.

Internally, the migration process from BACC 2.5.0.2 is a two-step process. The first step, migration from BACC 2.5.0.2 to BACC 2.6 generates a migration25to26.log file. The second part, from BACC 2.6 to 2.7 generates a migration26to27.log file.

- If migration is interrupted during the first part, from BACC 2.5.0.2 to BACC 2.6, migration restarts from where it left off, and the same migration log continues to be used.
- If migration is interrupted during the second part, from BACC 2.6 to 2.7, migration restarts from the beginning. The old migration log is renamed with a suffix with the timestamp and a new migration log is created.

If migration is interrupted during the first part, and a clean restart of migration from BACC 2.5.0.2 is required, you must:

- 
- |               |                                                                              |
|---------------|------------------------------------------------------------------------------|
| <b>Step 1</b> | Delete all files from the temporary directory.                               |
| <b>Step 2</b> | Rerun the database migration script.                                         |
| <b>Step 3</b> | Start the RDU to initialize the database.                                    |
| <b>Step 4</b> | Run the <b>verifyDb.sh</b> script to verify database consistency (optional). |
| <b>Step 5</b> | Restart the RDU after migration is complete and the database verified.       |
- 

### Migrating from BACC 2.6

When migrating 2.6.x, no command line parameter is needed.

Use this syntax:

```
./migrateDb.sh
```

Migrating from BACC 2.6 generates a migration26to27.log file.

Interrupting the migration from BACC 2.6.x to BACC 2.7 restarts the migration from the beginning. The old migration log is renamed with a suffix with the timestamp and a new migration log is created.





# CHAPTER 7

## Setting Up a Device Provisioning Engine

A Cisco Device Provisioning Engine caches provisioning information and handles all configuration requests including downloading configuration files to devices. It is integrated with the Cisco Network Registrar DHCP server to control the assignment of IP addresses. Multiple DPEs can communicate with a single DHCP server. DPEs come with factory installed software that enables provisioning, but you must perform some initial configuration.

This chapter describes the setup procedure.

### Hardware DPE Setup Sequence

Table 7-1 identifies the sequence of events for setting up a hardware DPE.

**Table 7-1** DPE Setup Sequence

| Item | To do this . . .                                                | See this section...                                                                     |
|------|-----------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| 1.   | Connect the DPE to the serial port of a computer.               | <a href="#">Connecting the Device Provisioning Engine, page 7-1</a>                     |
| 2.   | Configure and run a terminal emulation program on the computer. | <a href="#">Configuring and Running a Terminal Emulation Program, page 7-2</a>          |
| 3.   | Log in to the DPE and change the login/enable password.         | <a href="#">Logging In, page 7-2</a>                                                    |
| 4.   | Configure the DPE for data.                                     | <a href="#">Configuring a Device Provisioning Engine for Data, page 7-3</a>             |
| 5.   | Configure the DPE to support voice technology.                  | <a href="#">Configuring a Device Provisioning Engine for Voice Technology, page 7-5</a> |
| 6.   | Configure the DPE to support the CableHome technology.          | See the <i>Cisco Broadband Access Center for Cable Administrator's Guide</i> .          |

### Connecting the Device Provisioning Engine

Each DPE comes with a console cable. To begin setting up the DPE, complete these steps:

- Step 1** Attach one end of the cable to the console port of the DPE.

- Step 2** Attach the other end of the cable to the serial port on the computer that you want to use to configure the DPE.
- Step 3** Proceed to the [“Configuring and Running a Terminal Emulation Program” section on page 7-2](#).
- 

## Configuring and Running a Terminal Emulation Program

You must configure and then run a terminal emulation program on the computer that you have connected to the DPE.

To configure and run a terminal emulation program, complete these steps:

- Step 1** Log in to the computer as *root*.
- At the command line, enter the name of a terminal emulator. Choose a terminal emulation program that enables communication with the DPE through the serial port on the host computer.
- Step 2** Configure these settings on the terminal emulator:
- Speed:9600
  - Data Bits:8
  - Parity:None
  - Stop Bits:1
  - Flow Control:Hardware
- When you have correctly configured the terminal emulation program, you are prompted to log in to the DPE.
- Step 3** Proceed to the [“Logging In” section on page 7-2](#).
- 

## Logging In

To log in to the DPE, complete these steps:

- Step 1** At the password prompt, enter the login password. The default user and enable passwords are changeme. For example:

```
localhost BPR Device Provisioning Engine
```

```
User Access Verification
```

```
Password:
```



**Note** For security reasons, Cisco Systems strongly recommends that you change the original password.

---

The system displays this user mode prompt:

```
localhost>
```

**Step 2** Run the **enable** command to enter privileged mode. You must be working in privileged mode to configure the DPE. For example:

```
localhost> enable
```

The system prompts you for the enable password.

**Step 3** At the prompt, enter the enable password. The default is changeme.

The system displays this privileged mode prompt:

```
localhost#
```

**Step 4** To change the login and enable password, as Cisco Systems recommends:

a. At the localhost# prompt, enter the **password** command. For example:

```
localhost# password
```

The system prompts you for the new password.

b. Enter the new password. The system prompts you to enter the new password again.

c. Re-enter the new password. The system displays a message that you successfully changed the password.

Remember that this is your new log in password. If you want to change the privileged mode password, use the **enable password** command.

**Step 5** Proceed to the [“Configuring a Device Provisioning Engine for Data”](#) section on page 7-3.

---

## Configuring a Device Provisioning Engine for Data

To configure a DPE, have this information available:

- The static IP address that you want to assign to the DPE.
- The IP address or fully qualified domain name of the RDU for the DPE.
- The provisioning group or groups of which the DPE is part.
- The IP address of the default gateway on your network, if the default gateway is implemented on your network.
- The host and domain names of the DPE.



### Tip

You can use the **show run** command to view the running configuration. A complete list of show commands is available through the use of the **show commands** command. Refer to the *Broadband Access Center for Cable CLI Reference Guide* for additional information.

---



### Note

The commands pertaining to security are only enabled when connected to the DPE serial port. Refer to the *Broadband Access Center for Cable CLI Reference Guide* for additional information.

---

To configure a DPE, complete these steps:

- Step 1** Assign a static IP address and subnet mask to the first ethernet port on the DPE. For example, to assign IP address 10.10.10.1 and the subnet mask 255.255.255.0, enter these commands:

```
localhost# interface ethernet 0 ip address 10.10.10.1 255.255.255.0
localhost# interface ethernet 0 ip enabled true
localhost# interface ethernet 0 provisioning enabled true
```



**Note** The values provided here are sample values only. Use values appropriate for your network.

- Step 2** Enter the IP address for the RDU or its domain name if you are implementing DNS. Also, identify the port on which the RDU is listening. The default listening port is 49187. For example:

```
localhost# dpe rdu-server 10.10.10.1 49187
```

- Step 3** Specify the provisioning group or groups of which the DPE is part. Where appropriate, specify the secondary provisioning group of which it is part. For example:

```
localhost# dpe provisioning-group primary group1
localhost# dpe provisioning-group secondary group2
```

- Step 4** If your network topology has a default gateway IP address, enter that information. For example:

```
localhost# ip default-gateway 10.10.10.1
```

- Step 5** To set up DNS for the DPE, enter the IP address of the DNS server. For example:

```
localhost# ip name-server 10.20.10.1
```



**Note** To enter more than one DNS server name, lists the servers with a space between each entry.

- Step 6** Provide the DNS hostname and domain name for the DPE. For example:

```
localhost# hostname DPE1
localhost# ip domain-name example.com
```

- Step 7** Configure the current time on the DPE. For example:

```
localhost# clock set 23:59:59 20 12 2003
```

- Step 8** Set the shared secret password to be the same as that on the RDU.



**Note** This is one of the security related commands mentioned earlier in this chapter. This command can only be run if the console is connected to the DPE serial port.

- Step 9** For the configuration to take effect, you must reload the DPE. For example:

```
localhost# reload
```

After you reload the DPE, you can establish a Telnet session using the IP address of the DPE. Remember to use the new login and enable password that you created in the [“Logging In” section on page 7-2](#).

# Configuring a Device Provisioning Engine for Voice Technology

This section describes those configuration activities that must be performed to properly set up a DPE to support voice technology.



## Note

The tips provided in this section refer to the `dpe.properties` file, located in the `<BACC_HOME>/dpe/conf` directory, for a lab installation of BAC. You change the properties specified, as indicated in the tip, to enable the described feature. If you edit the properties, you must restart the DPE.



## Caution

In the `dpe.properties` file, there should only be a single instance of each property described in these tips.

## Setting Up Voice Technology

Complete these steps to set up voice technology on your DPEs.

**Step 1** Enter these commands to set the FQDN for each enabled DPE interface:

```
interface ethernet 0 provisioning fqdn <fqdn-value>
interface ethernet 1 provisioning fqdn <fqdn-value>
```



## Tip

`dpe.properties: /server/provFQDNs=FQDN[IP address]:port`. This could translate, for example, into `c3po.pcnet.cisco.com[10.10.10.5]:49186`.



## Note

The FQDN is sent as the `SNMPEntity` in DHCP option 177 suboption 3.

**Step 2** Enter these commands to configure voice technology at DPE:

```
packetcable registration kdc-service-key <password>
```



## Note

This is a protected mode security command, accessible only on the local console. The contents of this property are only visible when logged into the local console.



## Caution

The DPE password entered using this CLI command must match the corresponding password used in Keygen utility when generating Service Keys for KDC.



## Tip

`dpe.properties: /pktcbl/regsvr/KDCServiceKey=(xx: ... xx)` Where `(xx: ... xx)` represents a 24 byte randomly selected, colon separated, hexadecimal value; for example:  
`31:32:33:34:35:36:37:38:39:30:31:32:33:34:3 5:36:37:38:39:30:31:32:33:34.`

For a lab installation, the KDC and DPE are installed on the same host, and the installation program automatically generates a random KDC service key for both the KDC and the DPE.

**Step 3** Enter this command to control the choice of encryption algorithm for use during SNMPv3:

```
packetcable registration policy-privacy <value>
```



**Note** If you enter a value of zero (which is the default value) for this policy privacy, the MTA will choose a privacy option for SNMPv3. Entering any non-zero value means Provisioning Server will set its privacy option in SNMPv3 to a specific protocol. Although, at publication, DES is the only privacy option supported by voice technology.



**Tip** dpe.properties: /pktcbl/regsvr/policyPrivacy=1 - This enables DES privacy.

**Step 4** Enter this command to set the SNMP service key used for SNMPv3 cloning to the RDU.

```
packetcable snmp key-material <password>
```



**Note** This is a protected mode security command, accessible only on the local console. The contents of this property are only visible when logged into the local console.

The default value for this command is <null>. Enter this default to turn SNMPv3 cloning off at this DPE.



**Tip** dpe.properties: to turn SNMPv3 cloning off, use /pktcbl/snmp/keyMaterial= to turn it on, use /pktcbl/snmp/keyMaterial=<key>. For example, /pktcbl/snmp/keyMaterial=31:32:33:34:35:36:37:38:39:30:31:32:33:34:35:36:37:38:39:30:31:32:33:34:35:36:37:38:39:30:31:32:33:34:35:36:37:38:39:30:31:32:33:34:35:36:37:38:39:30:31:32:33:34:35:36



**Caution** Set this property, to the same 46 hexadecimal bytes that are used at the RDU (rdu.properties file located in the <BACC\_HOME>/rdu/conf directory) to enable SNMP cloning.

**Step 5** Enter this command to enable the PacketCable voice technology.

```
packetcable enable
```



**Note** PacketCable provisioning is disabled at the DPE by default. If you change this property, you must reboot the DPE for the new setting to take effect. Also, you can turn voice technology on or off by entering either **packetcable enable** or **no packetcable** respectively.



**Tip** dpe.properties: /pktcbl/enable=enabled

**Step 6** Run the **dpe reload** command.

## Controls Available

These commands described in this section, provide additional configuration settings. Changing these properties on the DPE-590 causes the change to take effect immediately, without a DPE restart. If you are working with a lab install, and modify any DPE property, you must restart the DPE for the change to take effect.

- **packetcable registration encryption**—This command optionally enables encryption of the MTA configuration file.



Tip

---

```
dpe.properties: /pktcbl/regsvr/configEncrypt=1
```

---

- **no packetcable registration encryption**—This command optionally disables encryption of the MTA configuration file.



Tip

---

```
dpe.properties: /pktcbl/regsvr/configEncrypt=0
```

---

- **packetcable snmp timeout <timeout>**—This command dynamically sets the number of seconds that the DPE waits for a response to an SNMPv3 SET operation. The timeout is expressed in seconds and the default value is 10 seconds.



Tip

---

```
dpe.properties: /pktcbl/snmp/timeout=1 and /pktcbl/snmp/timeout=10
```

---

## Debugging

Complete these steps to verify that your DPEs are operating properly after configuring them for operation with voice technology.

- Step 1** Enter this command to collect all the log, property, and network configuration files on the DPE :
- ```
support bundle state
```

This command places the collected log files in the /outgoing directory. From there, the bundle is accessible using FTP.

- Step 2** Enter this command to check the status of both the DPE and voice technology settings:

```
show dpe
```

### Example show dpe command output

```
BPR Agent is running
dpe is running

Version BPR 2.5 (cbpr_25_L_200302040515).
Caching 51970 device configs and 2 external files.
Received 312 cache hits and 0 misses.
Received 0 lease updates.
Connection status is Disconnected.
Sent 77 SNMP informs and 77 SNMP sets.
Received 77 MTA provisioning successful SNMP informs.
```

```
Received 0 MTA provisioning failed SNMP informs.  
Running for 11 days 1 hours 59 mins 15 secs.
```

This command also checks if voice technology provisioning is running, and displays the current health of the SNMPv3 service.

---



# APPENDIX **A**

## Network Registrar Configuration File Example

---

This appendix describes the sample configuration files included with this installation. This file is typical of the files you use during the BAC installation.

### Configuration Scripts

This section describes sample configuration scripts that you can copy and use to work with your BAC implementation. One exists for DOCSIS modems and computers, while another is available for DOCSIS modems and PacketCable MTAs.

### Sample Script for DOCSIS Modems and Computers

This sample configuration nrcmd script (**bpr\_cnr\_hsd\_sample\_config.nrcmd**) is used for a high-speed data deployment of DOCSIS modems and computers, in a multiple host configuration with failover protection. It is installed in this directory: <BACC\_HOME>/cnr\_ep/samples/.

These assumptions have been made to create this script:

- DHCP primary server IP address is: 192.168.0.32
- DNS primary server IP address is: 192.168.0.32

This sample script defines these objects:

- Scope selection tag objects for provisioned client-classes.
- Client-class objects for provisioned DOCSIS modems and computers.
- Policy objects for unprovisioned and provisioned devices. The only difference is that DNS servers are not given to unprovisioned devices.
- Scope and scope policy objects for unprovisioned and provisioned DOCSIS modems and computers.
- Disable the TFTP server.

To run this script, in the Network Registrar **nrcmd** program, enter:

```
<NR_HOME>/usrbin/nrcmd -N <username> -P <password> -b < bpr_cnr_hsd_sample_config.nrcmd
```

Where:

- -N—identifies the username
- -P—identifies the password

## Sample Script for DOCSIS Modems and PacketCable MTAs

This sample configuration nrcmd script (**bpr\_cnr\_pktcbl\_sample\_config.nrcmd**) is used for a high-speed data deployment of DOCSIS modems and PacketCable MTAs. A multiple host configuration with failover protection is also used, and the script is also installed in the <BACC\_HOME>/cnr\_ep/samples/ directory.

These assumptions have been made to create this script:

- DHCP primary server IP address is: 192.168.0.32
- DNS primary server IP address is: 192.168.0.32

This sample script defines objects similar to those described in the [“Sample Script for DOCSIS Modems and Computers”](#) section on page A-1.

To run this script, in the Network Registrar **nrcmd** program, enter:

```
<NR_HOME>/usrbin/nrcmd -N <username> -P <password> -b < bpr_cnr_pktcbl_sample_config.nrcmd
```



## INDEX

---

### A

#### API

RDU [2-1](#)

available disk space [4-1](#)

---

### B

#### BAC

administrator's password [2-3](#)

alert messages [5-1](#)

installation [1-vii](#)

graphical user interface [1-4](#)

home and data directories [3-2, 3-4, 3-9, 3-12](#)

server requirements [1-2](#)

license key [2-3, 4-1](#)

Solaris 8 [1-1](#)

#### Broadband Access Center

*See* BAC

---

### C

#### cable modem termination system

*See* CMTS

Choose Installation Type screen [2-7, 4-2](#)

#### Cisco Network Registrar

DHCP server [7-1](#)

CMTS [4-6](#)

device configuration [4-6](#)

DHCP relay agent information [4-7](#)

enabling the cable interface [4-6](#)

IP addresses [4-6](#)

Network Registrar [4-6](#)

#### command line interface

installing components [3-8](#)

#### commands

df [2-6](#)

mount [2-5, 2-6](#)

setup.bin [2-7](#)

setup.bin -console [2-8](#)

#### Configuration

extensions to Network Registrar [3-5](#)

Network Registrar [3-6](#)

configuration [2-1](#)

Data Over Cable Service Interface Specification (DOCSIS) [2-1](#)

configurations [2-1](#)

#### CSRC DPR

Solaris host [2-8](#)

---

### D

#### database

file locations [2-5](#)

performance optimization [2-5](#)

requirements [2-5](#)

verifying large file support [2-6](#)

Database Transaction Logs screen [3-2](#)

Data Directory Destination screen [3-2, 3-4, 3-7, 3-8](#)

#### Device Provisioning Engine

*See* DPE

#### DHCP

Network Registrar [1-2](#)

settings for Network Registrar [5-1](#)

## DNS

- DNS server [5-1](#)
- enabling a spoofing server [5-1](#)
- for the DPE [7-4](#)
- Network Registrar [1-3](#)
- reload [5-1](#)
- server [7-4](#)

## DOCSIS

- configuration management [2-1](#)

Documentation [1-ix](#)

- conventions [1-viii](#)
- organization [1-vii](#)
- related documents [1-ix](#)

## Domain Name System

*See* DNS

## DPE

- commands
  - enable [7-3](#)
  - enable password [7-3](#)
  - password [7-3](#)
- communication with a single DHCP server [7-1](#)
- configuration [7-5](#)
- configuring a device [7-3](#)
- connections [7-1](#)
- downloading configuration files [7-1](#)
- dpe.properties file [7-5](#)
  - /pktcbl/enable [7-6](#)
  - /pktcbl/regsvr/configEncrypt=0 [7-7](#)
  - /pktcbl/regsvr/configEncrypt=1 [7-7](#)
  - /pktcbl/regsvr/KDCServiceKey [7-5](#)
  - /pktcbl/regsvr/policyPrivacy [7-6](#)
  - /pktcbl/snmp/keyMaterial [7-6](#)
  - /pktcbl/snmp/timeout=1 [7-7](#)
  - /pktcbl/snmp/timeout=10 [7-7](#)
  - /server/provFQDNs [7-5](#)
- hardware requirements [1-2](#)
- logging in [7-2](#)
- service key and FQDN [3-7](#)
- set up sequence [7-1](#)

terminal emulation program [7-2](#)

## Dynamic DNS

*See* DDNS [1-3](#)

Dynamic Host Configuration Protocol [1-3](#)

*See* DHCP

---

**F**

failover deployment [1-2](#)

extension points [1-2](#)

---

**G**

graphical user interface [3-1](#)

KDC installation [3-1](#)

lab installation [4-2](#)

Network Registrar extension installation [3-1](#)

RDU installation [3-1, 3-2](#)

---

**H**

hardware requirements

RDU [1-2](#)

Home Directory Destination screen [3-2, 3-4, 3-7, 3-8](#)

---

**I**

individual component validation [3-14, 3-16](#)

installation [1-1](#)

checklist [2-6, 4-1](#)

exiting the program [3-3, 3-5](#)

lab installations [4-1](#)

operating system requirements [1-1](#)

pathname [4-2](#)

installation and startup process [2-2](#)

Installation Components screen [3-4, 3-7, 3-8](#)

Installation Parameters screen [3-3, 3-5, 3-7, 3-8](#)

Installation Summary screen [3-3, 3-7, 3-8, 4-3](#)

installation types [1-4](#)

- individual component installation [1-4](#)
- lab installation [1-4](#)

Installed Components Summary screen [3-5](#)

IP addresses

- of Primary DHCP Server [3-5, 4-3](#)
- of Primary DNS Server [3-5, 4-3](#)
- of Secondary DHCP Server [3-5, 4-3](#)
- of Secondary DNS Server [3-5, 4-3](#)

---

## J

JRun process, detecting [5-2](#)

---

## K

### KDC

- DPE registration service [1-3](#)
- FQDN [3-7, 4-2](#)
- hardware requirements [1-3](#)
- installation [2-2, 2-5, 3-7](#)
- interface address [3-7, 4-2](#)
- packetcable MTA authentication [2-2](#)
- realm name [3-4, 3-5, 3-7, 4-2, 4-3](#)

KDC Service Key and DPE screen [3-7](#)

Key Distribution Center

*See* KDC

---

## L

Lab Installation Parameters screen [4-3](#)

---

## N

Network Registrar [1-2](#)

- administrative username and password [4-2](#)
- BAC requirements [1-2](#)
- configuration files [4-1](#)

configuration script [A-1](#)

DHCP server [1-2, 5-1](#)

extensions [2-1](#)

installation

- server extensions [3-3](#)

installation validation [3-4](#)

installing extensions [2-4, 3-9, 3-11](#)

license key [2-4](#)

reloading the server [3-5](#)

server login [3-5](#)

servers [1-3](#)

upgrading [3-4](#)

version [2-1](#)

Network Registrar Extension Point Provisioning Group screen [3-4](#)

Network Registrar Username and Password screen [4-2](#)

nrcmd cli [A-2](#)

nrcmd command line interface [4-6, A-1](#)

---

## P

Packet Cable Panel screen [3-4](#)

Packet Cable Properties screen [3-4](#)

---

## R

### RDU

- installation [2-3, 3-2, 3-9](#)

- primary BAC server [2-1](#)

- RDU agent [5-2](#)

regional distribution unit

*See* RDU

Regional Distribution Unit Host/Port screen [3-2, 3-4](#)

related documentation [1-ix](#)

---

## S

scope selection tag [A-1](#)

Shared Secret Password screen [3-3, 3-5, 4-3](#)

Solaris [1-vii](#)

installing BAC [1-vii](#)

setting up DPEs [1-vii](#)

TFTP server [4-2](#)

Solaris installation

checklist [2-6](#)

Network Registrar requirements [1-2](#)

operating system environment [3-1](#)

RDU [2-1,3-2](#)

---

**T**

terminal emulation program [7-2](#)

---

**U**

uninstall.bin [5-4](#)

uninstall.bin directory [5-3](#)

uninstalling [5-2](#)

BAC [5-3](#)