



## **Installation Guide for Cisco Multicast Manager 3.3.2**

December 2013

### **Cisco Systems, Inc.**

[www.cisco.com](http://www.cisco.com)

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

©2013 Cisco Systems, Inc. All rights reserved.



<b>Preface</b>	<b>v</b>
Objectives	v
Audience	v
Organization	v
Conventions	vi
Related Documentation	vi
Obtaining Documentation, Obtaining Support, and Security Guidelines	vii

---

**CHAPTER 1**

<b>Installing Cisco Multicast Manager</b>	<b>1-1</b>
System Requirements	1-1
Hardware Requirements	1-1
Operating System Requirements	1-2
Supported Client Browsers	1-3
Required Services and Ports	1-3
Licensing	1-4
Overview of CMM Licensing	1-4
Obtaining a CMM License	1-5
Installing the CMM License	1-6
Managing CMM Licenses	1-7
TFTP Server	1-9
Linux IP Address/Default Route	1-10
Solaris Installation Instructions	1-10
Installing the License File	1-10
Creating the Installation Directory (Optional)	1-11
Mounting the CD-ROM	1-11
Unzipping the Tar File	1-11
Running the Solaris Installation Script	1-11
Linux Installation Instructions	1-16
Installing the License File	1-16
Creating the Linux Installation Directory (Optional)	1-16
Mounting the CD-ROM (Linux)	1-17
Unzipping the Tar File	1-17
Running the Linux Installation Script	1-17

Changing the HTTPS Port	1-22
Upgrading to Cisco Multicast Manager 3.3.2	1-22
Upgrading on Linux Using a CD or ISO Image	1-23
Upgrading on Linux Using a Tar File	1-24
Upgrading on Solaris Using a CD or ISO Image	1-27
Upgrading on Solaris Using a Tar File	1-28
Upgrading CMM 2.x to CMM 3.3.2	1-32
Restoring a Previous Version of CMM	1-32
Starting and Stopping CMM	1-34
Remote Upgrade	1-35
Server Migration	1-35
Export Utility	1-35
Import Utility	1-37
Backup Utility	1-39

---

**INDEX**



# Preface

---

Cisco Multicast Manager (CMM) is a web-based software application that allows you to gather information about IP multicast running in your network, monitor multicast networks, and diagnose problems.

This preface includes:

- [Objectives, page v](#)
- [Audience, page v](#)
- [Organization, page v](#)
- [Conventions, page vi](#)
- [Related Documentation, page vi](#)
- [Obtaining Documentation, Obtaining Support, and Security Guidelines, page vi](#)

## Objectives

This guide describes how to install Cisco Multicast Manager. Using the information provided in this guide, you can complete the tasks that are necessary to install CMM in your multicast environment.

## Audience

This guide is for network administrators or operators who use the CMM software to manage multicast networks. Network administrators or operators should have:

- Basic network management skills
- Basic multicast knowledge

## Organization

This guide contains the following chapter:

[Chapter 1, “Installing Cisco Multicast Manager,”](#) describes preliminary installation steps, detailed installation steps for the Solaris platform and the Linux platform, and tasks to perform after the initial installation.

# Conventions

This guide uses basic conventions to represent text and table information.

Command descriptions use the following conventions:

- Commands and keywords are in **boldface** font.
- Arguments for which you supply values are in *italic* font.
- Elements in square brackets ([ ]) are optional.
- Alternate but required keywords are grouped in braces ({ }) and separated by a vertical bar (|).

Examples use the following conventions:

- Terminal sessions and information that the system displays are printed in `screen` font.
- Information that you enter is in **boldface screen** font. Variables for which you enter actual data are printed in *italic screen* font.
- Nonprinting characters, such as passwords, are shown in angle brackets (< >).
- Information that the system displays is in `screen` font, with default responses in square brackets ([ ]).

This publication also uses the following conventions:

- Menu items and button names are in **boldface** font.
- Directories and filenames are in *italic* font.
- If items such as buttons or menu options are dimmed on the application windows, it means that the items are not available either because you do not have the correct permissions or because the item is not applicable at this time.



## Note

---

Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in the manual.

---



## Tip

---

Means *the following are useful tips*.

---

# Related Documentation

Additional information can be found in the following publications of the CMM documentation set:

- *User Guide for Cisco Multicast Manager 3.3.1*
- *Release Notes for Cisco Multicast Manager 3.3.2*

# Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.







# Installing Cisco Multicast Manager

---

This chapter contains the following sections:

- [System Requirements, page 1-1](#)
- [Required Services and Ports, page 1-3](#)
- [Licensing, page 1-4](#)
- [TFTP Server, page 1-9](#)
- [Linux IP Address/Default Route, page 1-10](#)
- [Solaris Installation Instructions, page 1-10](#)
- [Linux Installation Instructions, page 1-16](#)
- [Changing the HTTPS Port, page 1-22](#)
- [Starting and Stopping CMM, page 1-32](#)
- [Server Migration, page 1-33](#)

## System Requirements

This section describes the system requirements for running Cisco Multicast Manager 3.3.2.

## Hardware Requirements

Cisco Multicast Manager can run on Linux systems and on Sun Microsystems systems running Sun Solaris 10.

## Disk Space

4 GB or more of free space for CMM application and data.

## Processors

The processor requirements for CMM 3.3.2 are shown below.

### AMD Linux

- Dual, Quad, or 6-Core AMD Opteron processor

### Linux-Intel

- Xeon Dual or Quad Core (equivalent or better)

### Solaris-SPARC

- Sun UltraSPARC IIIi or better

## Memory Requirements

The minimum memory requirements for CMM 3.3.2 are:

- 4 GB for less than 500 devices
- 8 GB for large Enterprise networks (more than 500 devices)

### Swap Space

The CMM host should have twice as much swap memory as RAM. For example, a server with 4 GB of RAM should have 8 GB of swap memory, and a server with 8 GB of RAM should have 16 GB of swap memory.

## Operating System Requirements

### Linux

CMM 3.3.2 can run on the following Linux versions:

- Red Hat Enterprise Linux ES/AS 4
- Red Hat Enterprise Linux ES/AS 5
- Red Hat Enterprise Linux Client release 5.5
- Red Hat Enterprise Linux Server release 6.4

Both 32-bit and 64-bit Linux versions are supported.

### CPU Requirements

Linux devices running CMM 3.3.2 should meet the following CPU requirements:

- Two CPUs with dual core for less than 500 devices
- Four CPUs with four cores for more than 500 devices

## Sun Microsystems Servers

CMM 3.3.2 can run on the following Solaris version:

- Solaris 10

Cisco Multicast Manager supports the following hardware on Sun Microsystems servers:

- Sun Fire V440: Two CPUs with 1.593-GHz UltraSPARC IIIi processors.
  - Up to four cores for less than 500 devices.
  - Eight cores for 500 devices or more.




---

**Note** The Solaris X86 version is not supported.

---

## VMWare

- VMWare ESX 3.5
- VMWare ESX 3.3.1

CMM supports both the 32-bit and 64-bit versions.

## Supported Client Browsers

- Internet Explorer 8.x on Windows XP or Windows 7
- Internet Explorer 9.x on Windows 7
- Firefox 7.x and Firefox 8.x on Windows XP or Windows 7




---

**Note** The browser must have Adobe Flash Player installed.

---

## Required Services and Ports

You must ensure that the required ports for inter-process communication and network access are accessible on the CMM host device.

Table 1-1 describes the ports used by CMM.

**Table 1-1** Ports and Services Used by CMM 3.3.2

Service	Port	Description
HTTPS	8080	HTTP protocol with Secure Sockets Layer
Cliproxyd_tel	8081	CLI access through Telnet
Cliproxyd_ssh	8082	CLI access through SSH
Cliproxyd_dtv	8083	CLI threshold polling using Telnet
Snmpd	161	SNMP agent
snmptrapd	162	SNMP Trap Receiver

**Table 1-1** Ports and Services Used by CMM 3.3.2 (continued)

Service	Port	Description
MySQL	3306	MySQL Database
Web Service	8085	Web Service on HTTP

## Licensing

This section describes:

- [Overview of CMM Licensing, page 1-4](#)
- [Obtaining a CMM License, page 1-5](#)
- [Installing the CMM License, page 1-6](#)
- [Managing CMM Licenses, page 1-7](#)

## Overview of CMM Licensing

CMM 3.3.2 requires a license file, which is provided when you purchase the product. There are two types of license:

- Licenses which enables use of CMM to manage up to 50 devices for a 60-day trial period. The CMM distribution includes a free evaluation license.
- Permanent licenses that you receive when you purchase CMM.

The license file enables the product features that you have purchased.

The license file can enable:

- Cisco Multicast Manager with Video Operations Solution (VOS) support.
- Cisco Multicast Manager with Multicast VPN (MVPN) support.
- Cisco Multicast Manager with both VOS support and MVPN support.

CMM 3.3.2 uses FlexLM licensing.

If one of the features is not enabled, then the menus in the user interface do not include selections that enable options provided with the feature.

The application license is contained in the license file that you receive from Cisco when you purchase CMM. CMM license filenames consist of a timestamp that indicates when the license was obtained, and the file extension *.lic*. For example, *1294942836970.lic*.

After installation, CMM stores license files in the */etc/licenses* directory under the CMM root directory. If you upgrade your license after initially installing a license, the previous license is moved to the */etc/licenses/history* directory.

CMM 3.3.2 includes several license utility scripts that you can use to maintain your license files:

- *addFlexlmLicense.sh*—Adds a CMM license.  
See [Running the CMM Add License Script, page 1-8](#).
- *FlexlmLicense*—Allows you to list your current licenses or check the validity of your CMM licensing.  
See [Running the Check License Script, page 1-8](#).

## Obtaining a CMM License

To obtain a CMM license, you will need a product authorization key (PAK). This key:

- Is provided on the product registration label that is in the Cisco Information Packet included with your product.
- May be provided by Cisco TAC in an e-mail sent to you in response to a license request.

To obtain a permanent license:

- 
- Step 1** Obtain the host ID or the MAC address of the machine where you will install CMM.
- On a Solaris device, you can obtain the host ID of the CMM host by running the following command:  

```
#hostid
```

The command returns the host ID of your host.
  - On a Linux device, obtain the MAC address of the machine by entering the following:  

```
[root]# /sbin/ifconfig | grep HWaddr
```

The command line displays the MAC address:  

```
eth0      Link encap:Ethernet  HWaddr 00:0C:29:15:32:78
```

- Step 2** Retain the host ID or MAC address.  
You will need this information to register your license for CMM.

- Step 3** Go to the Cisco Product Licensing Registration page at the following URL:  
<http://www.cisco.com/go/license>

- Step 4** Log into Cisco.com.



---

**Note** You must have a Cisco.com user ID and password to log in.

---

The Product Licensing Registration page appears.

- Step 5** Enter the product authorization key (PAK).



---

**Note** The PAK is provided on the label that accompanied the Cisco Information Packet included with your product, or in an e-mail from Cisco TAC when you purchase CMM 3.3.2.

---

The Product Registration servlet displays a page summarizing the license. [Figure 1-1](#) shows a typical license summary.

Figure 1-1 Product License Summary Page

Tools & Resources  
Product License Registration

HOME  
SUPPORT  
TOOLS & RESOURCES  
Product License Registration

1 Enter a PAK Number 2 Validate Features 3 Designate Licensee 4 Finish and Submit

Help Feedback

Related Tools  
Dynamic Configuration Tool  
TAC Service Request Tool  
Delivery Application  
Cisco Commerce Workspace  
Order Status Tool

Cisco Multicast Manager (v3.2 and later)

Your product information is shown below. Displayed is the product name and associated features and quantity.

Remove PAK	Product SKU	Option SKU	Description	Quantity
<input type="checkbox"/>	CMM3.2-MEDIA-K9		CMM3.2-MEDIA-K9 : For Internal purposes only	1
		L-CMM3.2-VOS-FS	L-CMM3.2-VOS-FS : For Internal purposes only	1
		CMM3.2-MVPN-FS	CMM3.2-MVPN-FS : For Internal purposes only	1
		CMM3.2-BASE-SM	CMM3.2-BASE-SM : For Internal purposes only	1

Go Back All Done Update

PAK:FXPAKD78954

239998

**Step 6** Review the information on the product information display and make sure that it is correct.

**Step 7** If it is correct, click the **All Done** button.

The Product License Registration servlet prompts you to enter a host ID (for Solaris) or a MAC address (for Linux).

**Step 8** Enter the host ID or MAC address that you obtained in [Step 1](#) above.

**Step 9** Click the **End-User License Agreement** link and review the license agreement.

**Step 10** Check the **Agreement** check box if you agree.

**Step 11** Scroll down the page and review the registrant information for your license and modify it if required.

**Step 12** Click the **Continue** button.

The Product License Registration servlet displays a summary of the licensing information.

**Step 13** Review the information to make sure it is correct.

**Step 14** Click the **Submit** button.

Cisco will email you a license file for the product features that you have purchased.

**Step 15** Save the license file on the host where you will install CMM.

The license file can be saved anywhere on the installation machine.

## Installing the CMM License

You can install the CMM license in three ways:

- During initial installation or upgrade, by specifying the license filename when prompted.
- By using the CMM GUI.
- By using the add license script (*addFlexlmLicense.sh*):

Complete these steps to install the license file:

- 
- Step 1** If you have obtained a license file prior to the initial installation, install the license during the installation process.
- During installation of CMM, the system prompts for the license file. Enter the directory path and license file name when prompted by the installation script.
- If you have not obtained a permanent license, the installation script allows you to complete the installation using an evaluation license that allows management of up to 50 devices and is good for 60 days.
- See the installation sections for Solaris and Linux for information on the licensing prompts:
- [Running the Solaris Installation Script, page 1-11](#)
  - [Running the Linux Installation Script, page 1-17](#)
- Step 2** After an initial installation, use one of the following methods to update the licenses for your CMM server:
- Choose **Administration > License Info** from the CMM Main Menu and click the **Update License** button to update your license file. You can use the licensing page to upgrade from an evaluation license to a permanent license, or to update your existing permanent licenses.  
See “License Info” in Chapter 10 of the *User Guide for Cisco Multicast Manager, 3.3.1*.
  - To update the license using the CMM add license script (*addFlexlmLicense.sh*):
    - Go to the root directory for the CMM installation (*/usr/local/netman* for Linux and */opt/RMSMMT* for Solaris).
    - Enter the following command:  

```
addFlexlmLicense.sh <license_filename>
```

where *license\_filename* is the directory path and filename for the license file.  
For additional information on running script, see [Running the CMM Add License Script, page 1-8](#).
- 

## Managing CMM Licenses

CMM 3.3.2 includes a License Info page that allows you to update the license used for the CMM installation. For information on the License Info page, see [http://www.cisco.com/en/US/docs/net\\_mgmt/cisco\\_multicast\\_manager/3.3.1/user/guide/CMM\\_331\\_user\\_guide.html](http://www.cisco.com/en/US/docs/net_mgmt/cisco_multicast_manager/3.3.1/user/guide/CMM_331_user_guide.html).

CMM 3.3.2 provides two license management scripts;

- *addFlexlmLicense.sh*—Adds a CMM license.  
See [Running the CMM Add License Script, page 1-8](#).
- *FlexlmLicense*—Allows you to list your current licenses or check the validity of your CMM licensing.  
See [Running the Check License Script, page 1-8](#).

## Running the CMM Add License Script

Add CMM licenses from the command line using the *addFlexlmLicense.sh* script.

The *addFlexlmLicense.sh* script has the following syntax:

```
addFlexlmLicense <license_filename>
```

where *license\_filename* is the directory and license filename of the license file.

To run the add license script:

---

**Step 1** Go to the CMM root directory (*/opt/RMSMMT* on Solaris or */usr/local/netman* on Linux).

**Step 2** Enter the following command:

```
./addFlexlmLicense.sh <license_filename>
```

where *license\_filename* is the directory path and license file name.

[Example 1-1](#) shows sample output from *addFlexlmLicense.sh*.

### Example 1-1 Sample Output from *addFlexlmLicense.sh*

```
-bash-3.00# ./addFlexlmLicense.sh /tmp/test.lic
Install date : Wed Sep 12 23:46:33 PDT 2013
Expire date  : Permanent
Features    : MMT,VOS,MVPN
Version     : 3.3
Device limit : 1000
FlexlmHostId : ANY
VendorName  : cisco
License Type : Purchased

License status : success
```

**Step 3** Start the CMM application and from the Main Menu, choose **Administration > License Info** to verify the license.

---

## Running the Check License Script

Check your CMM license using the *FlexlmLicense* script.

The *FlexlmLicense* script has the following syntax:

```
CMMROOT/FlexlmLicense [info] [check]
```

To view information about the current license, use the **info** option.

To verify the current license, use the **check** option.

To run the *FlexlmLicense* script:

---

**Step 1** Go to the CMM root directory (*/opt/RMSMMT* on Solaris or */usr/local/netman* on Linux).

**Step 2** Enter one of following commands:

```
./FlexlmLicense info
```

or



```
./FlexlmLicense check
```

The **info** parameter specifies display of license information and the **check** parameter specifies that a license verification is performed.

[Example 1-2](#) shows sample output from the *FlexlmLicense* script with the info option.

#### **Example 1-2 Sample Output from FlexlmLicense info**

```
-bash-3.00# ./FlexlmLicense info
Install date   : Wed Sep 12 23:46:33 PDT 2013
Expire date    : Permanent
Features       : MMT,VOS,MVPN
Version        : 3.3
Device limit   : 1000
FlexlmHostId   : ANY
VendorName     : cisco
License Type   : Purchased
License status : success
```

[Example 1-3](#) shows sample output from *FlexlmLicense check*.

#### **Example 1-3 Sample Output from FlexlmLicense check**

```
-bash-3.00# ./FlexlmLicense check
cisco|MMT,MVPN,VOS|1000
License status : success
```

## TFTP Server

If you want to download router configurations and use the router config verification tool, CMM requires that the server have Trivial File Transfer Protocol (TFTP) enabled and a TFTP server installed on the CMM system.

If you will set up a TFTP server, create a TFTP directory on the largest partition and then link it from the root directory as follows, assuming the directory was created under /usr: `ln -s /usr/tftpboot /tftpboot`.

#### **For Linux ES/AS 4:**

```
tftp-0.39-2
```

#### **For Linux ES/AS 5:**

```
tftp-0.39-0.EL5.0
```

After TFTP is installed, modify the */etc/xinetd.d/tftp* file to enable the TFTP server.

Set the ownership and permissions as follows:

```
chown root:mtuser tftpboot
chmod 0775 tftpboot
```

Then restart the **xinetd** process: `/etc/init.d/xinetd restart`.

**For Solaris:**

Comment out the `tftpd` line in the `/etc/inetd.conf` file to enable the TFTP server, then restart the `inetd` process.

## Linux IP Address/Default Route

- To change the system's IP address, you modify the `/etc/sysconfig/network-scripts/ifcfg-eth0` file, then restart the system.
- To change the default gateway, you must modify the `/etc/sysconfig/network` file.
- To temporarily change these values, you can use the following commands:

```
ifconfig eth0 x.x.x.x
route delete default
route add default gw x.x.x.x metric 1
```

## Solaris Installation Instructions

Complete these steps to install CMM 3.3.2 on a Sun Solaris system:

1. Install the license file.
2. Create the installation directory (optional).
3. Do one of the following:
  - If you are installing from the CD-ROM, mount the CD-ROM.
  - If you are installing from the tar file, unzip the tar file.
4. Run the Solaris installation script.

**Note**


---

NIS + must be disabled on Solaris for the proper installation of CMM.

---

## Installing the License File

If you have purchased a license for CMM, copy the license file provided by Cisco to an appropriate directory on the host machine. During installation, the interface will prompt you for the location of the license file.

If you have not yet purchased a license, you can use the evaluation license provided with the CMM 3.3.2 distribution to manage up to 50 devices for 60 days.

For information on how licensing works, see [Licensing, page 1-4](#).

For additional information, see:

- [Obtaining a CMM License, page 1-5](#)
- [Installing the CMM License, page 1-6](#)
- [Managing CMM Licenses, page 1-7](#)

## Creating the Installation Directory (Optional)

On Solaris systems, Cisco Multicast Manager must be installed in the `/opt/RMSMMT` directory, and requires approximately 3 GB of disk space.

If there is not enough room in `/opt`, create the `RMSMMT` directory on another partition, then create a symbolic link to it from `/opt`. For example, log in as root and issue these commands:

```
# mkdir /space/RMSMMT
# cd /opt
# ln -s /space/RMSMMT RMSMMT
# chown -h mmtuser:mmtuser RMSMMT
```

## Mounting the CD-ROM

If you are mounting a *DVD* and the process `vold` is not running, you will need to manually mount the CD-ROM, use one of the following commands:

```
# mount -rt hsfs /dev/sr0 /cdrom
```

or

```
# mount -rt hsfs /dev/dsk/c0t6d0s2 /cdrom
```

If you are mounting an *ISO CD-ROM* image downloaded from Cisco.com, use the following command:

```
mount -F hsfs -o ro `lofiadm -a /export/temp/cmm33.iso` /mnt
```



**Note** `/mnt` is the mount point and can be any designated directory. If this command does not work, check with your system administrator for mounting instructions.

## Unzipping the Tar File

If you are installing from the tar file, create a `/tmp` directory and unzip the tar file there:

```
# cd /tmp
# gunzip < cmm332_solaris.tar.gz | tar xvf -
```

The file extraction process creates a directory named *Solaris* and extracts the release distribution files to that directory.

## Running the Solaris Installation Script

To run the Solaris installation script:

---

**Step 1** Log in as *root*.

**Step 2** If you are installing from a CD-ROM, enter:

```
# cd /cdrom/cdrom0
# ./install.sh
```

If you are installing from the extracted tar file location, enter:

```
# cd /tmp/Solaris
```

```
# ./setup.sh
```

The system issues a series of prompts.

**Step 3** Answer the prompts as indicated in [Table 1-2](#).

**Table 1-2** *Solaris Installation Prompts*

Prompt	Response
Checking for the available disk space... <This message appears only if available disk space is less than recommended>  Space available in cmm-as5-04: 465337 Kb which is less than the Disk space recommended: 3145728 Kb  Do you wish to continue the installation? [y/n]:	There is no default entry for this prompt. Enter <b>y</b> if you want to proceed with the installation; otherwise, enter <b>n</b> .
Checking for physical memory in the system... <This message appears only if the available RAM space is less than recommended>  Physical Memory available in cmm-as5-04: 1060864 Kb which is less than the RAM space recommended: 2055200 Kb  Do you wish to continue the installation? [y/n]:	There is no default entry for this prompt. Enter <b>y</b> if you want to proceed with the installation; otherwise, enter <b>n</b> .
The application installs in /opt/RMSMMT. Do you wish to continue? [y/n] (default - y):	Press <Enter> to accept the default installation directory ( <i>opt/RMSMMT</i> ); otherwise enter <b>n</b> and then specify another installation directory.
Have you purchased a license for Cisco Multicast Manager 3.3.2? Do you wish to continue? [y/n] (default - y):	Do one of the following: <ul style="list-style-type: none"> <li>• If you have purchased a license file for CMM 3.3.2, enter <b>y</b>.</li> <li>• If you have not yet purchased a license file, enter <b>n</b> to continue installation using the CMM evaluation license that is provided with the CMM 3.3.2 distribution. The evaluation license allows you to use CMM 3.3.2 for 60 days.</li> </ul> For additional information on CMM licensing, see <a href="#">Licensing, page 1-4</a>
Enter purchased license file:	If you enter <b>y</b> in response to the previous prompt, this prompt appears. Enter the path and filename of the license file. If the license file is in the current directory, enter the name of the license file.

**Table 1-2 Solaris Installation Prompts (continued)**

Prompt	Response
Cisco Multicast Manager by default uses a mysql database on port 3306. Do you want to change the default mysql port (y/n) (default - n):	To accept the default (do not change the default mysql database on port 3306), press <b>&lt;Enter&gt;</b> ; otherwise, enter <b>y</b> and then change the default Mysql port when prompted.
The community name to add read-only access for (default- public):	The default community string is <i>public</i> , but you can specify the community string that is configured on your device Press <b>Enter</b> to accept the default community name (public); otherwise, enter the community string that is defined on your device.
The physical location of the system:	Enter a description of where you are located. If you press <b>Enter</b> , the default is used (no string specifying a physical location)
Contact information of the administrator (default - root):	Enter the best method for contacting the administrator; for example, phone number, e-mail address, and so on. To accept the default e-mail address (root@<CMM server IP address>), press <b>Enter</b> .
Do you want to disable access control checks (y/n) (default - y):	To accept the default value ( <b>y</b> — for disable access control checks, press <b>Enter</b> ; otherwise, enter <b>n</b> to enable access control checks.
Do you want to add some other Trap OIDs with the default list (y/n) (default - n):	To accept the default value ( <b>n</b> —do not add additional trap OIDs, press <b>Enter</b> ; otherwise, if you wish to add more OIDs, enter <b>y</b> and enter a trap OID to be added.

[Example 1-4](#) shows sample output from the Solaris installation.

#### **Example 1-4 Sample Solaris Installation Output**

```
bash-3.00# ./setup.sh

Cisco Multicast Manager Version 3.3.2 installation setup
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights reserved.

Checking the OS version in cmm-s10-03...
Supported version 5.10 found

Checking for the available disk space...
Disk space available in cmm-s10-03 is 9793085 Kb(Recommended: 3145728 Kb)

Checking for physical memory in the system...
Physical memory available in cmm-s10-03 is 8257536 Kb(Recommended: 2055200 Kb)

No previous Cisco Multicast Manager version found in this machine cmm-s10-03

Installing Cisco Multicast Manager Version 3.3.2
The application installs in /opt/RMSMMT. Do you wish to continue? [y/n] (default - y):
```

```

License Installation Utility
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights
reserved.

Have you purchased a license for Cisco Multicast Manager 3.3.2? [y/n][Enter n to continue
with evaluation license] (default - n): n

*****

Installation will continue with Evaluation license.
Please contact get-cmm-key@cisco.com to get permanent license file
Specify the host id of this machine while sending license request

Host Id of this machine : 85139da6

*****

Press Enter key to continue installation...

Install date : Wed Aug 07 15:08:53 PST 2013
Expire date : Sun Sep 01 16:08:53 PDT 2013
Features : MMT,MVPN,VOS
Version : 3.3
Device limit : 50
FlexlmHostId : ANY
VendorName : cisco
License Type : Evaluation

License status : success

Creating mmtuser gid...
The mmtuser group already exists
Creating mmtuser uid...
The mmtuser id already exists.
Installing Perl...
Installing MIBS...
Installing support files...
Installing ciscomm to /etc/init.d...
Installing Tomcat...
Creating db base version for fresh install
mysql group already exist
mysql user already exist

Cisco Multicast Manager by default uses mysql database on port 3306.
Do you want to change the default mysql port (y/n) (default - n): Copying mysql
configuration file to /etc folder ...
Starting MySQL
..... SUCCESS!
Done creating cmm database
Updating Cisco Multicast Manager Db based on the install type and versions ...
Db schema changes done
Initializing IP Address database with reserved Multicast Addresses...
Shutting down MySQL
... SUCCESS!
Configuring Trap Receiver and SNMP Agent...

Getting Configuration Information for SNMP Agent
=====

Access control Setup
Description:SNMPv1/SNMPv2c read-only access community name

```

```

The community name to add read-only access for (default - public): Community name for
read only access is public

System Information Setup
Description:This section defines some of the information reported in the
"System" mib group

The physical Location of the system : Contact Information of the Administrator (default -
root@):
Contact Information of the Administrator is root@

Getting Configuration Information for Trap Receiver
=====

Access control Setup
Do you want to disable access control checks (y/n) (default - y):
Disables the access control check and accepts all incoming Notification traps

Following are the list of default OIDs the TRAP receiver is configured with
1. ciscoIpMRouteMissingHeartBeats (1.3.6.1.4.1.9.10.2.3.1.0.1)
2. pimNeighborLoss (1.3.6.1.3.61.1.0.1)
3. CISCO-PIM-MIB Traps (1.3.6.1.4.1.9.9.184.2.0.*)
4. MSDP-MIB Traps (1.3.6.1.3.92.1.1.7.*)
5. ciscoMvvpnMvrfChange (1.3.6.1.4.1.9.10.113.0.2)
6. ivMS Traps 3.x (1.3.6.1.4.1.15181.11.1.*)
7. ivMS Traps 4.x (1.3.6.1.4.1.15181.11.4.*)
8. Mixed Signal (1.3.6.1.4.1.24931.9.1.1.*)
9. BridgeTech Traps (1.3.6.1.4.1.24562.*)
10. CISCO-PIM-MIB-extn (1.3.6.1.4.1.9.10.120.0.*)
11. CISCO-PIM-IETF-MIB (1.3.6.1.4.1.9.10.119.0.*)
12. MYSTRO-VIDEOPORT-MIB (1.3.6.1.4.1.14373.2.*)
13. SAEUROPE-ADMINISTRATION-MIB (1.3.6.1.4.1.1482.20.1.*)
14. SAEUROPE-DCM-MIB (1.3.6.1.4.1.1482.1.3.2.2.*)
15. SAEUROPE-MESSAGES-MIB (1.3.6.1.4.1.1482.1.1.2.*)
16. SAEUROPE-TRAPCONTROL-MIB (1.3.6.1.4.1.1482.1.1.1.*)
17. CISCO-FLOW-MONITOR-MIB (1.3.6.1.4.1.9.9.692.0.*)

Do you want to add some other Trap OIDs with the default list (y/n) (default - n): Default
Trap OIDs Configured
Installation Finished.
Starting the application...
Starting mysql server...
Starting MySQL
. SUCCESS!
Starting CMM Data service...
Sun Microsystems Inc.SunOS 5.10GenericJanuary 2005
You have new mail.
19205
CMM DataService process started
Sun Microsystems Inc.SunOS 5.10GenericJanuary 2005
You have new mail.
Using CATALINA_BASE: /opt/RMSMMT/mmtsys/apache-tomcat
Using CATALINA_HOME: /opt/RMSMMT/mmtsys/apache-tomcat
Using CATALINA_TMPDIR: /opt/RMSMMT/mmtsys/apache-tomcat/temp
Using JRE_HOME: /opt/RMSMMT/mmtsys/jre/
19232
Starting the polling daemon...
Sun Microsystems Inc.SunOS 5.10GenericJanuary 2005
You have new mail.
Starting the CLI proxy daemons...
Sun Microsystems Inc.SunOS 5.10GenericJanuary 2005
You have new mail.
Sun Microsystems Inc.SunOS 5.10GenericJanuary 2005
You have new mail.

```

```

Starting the CLI proxy dtv daemon...
Sun Microsystems Inc.SunOS 5.10GenericJanuary 2005
You have new mail.
Starting SNMP Trap Receiver daemon...
Starting SNMP Trap Receiver

Starting SNMP Agent daemon...
02/23/2012 23:35:51 Stopping the snmpd process which is already running
Starting SNMP Agent
Starting Util process...
Sun Microsystems Inc.SunOS 5.10GenericJanuary 2005
You have new mail.
19339
.....
CMM Util process started

```

---

## Linux Installation Instructions

Complete these steps to install CMM 3.3.2 on a Linux system:

1. Install the license file.
2. Create the installation directory (optional).
3. Do one of the following:
  - If you are installing from the CD-ROM, mount the CD-ROM.
  - If you are installing from the tar file, unzip the tar file.
4. Run the Linux installation script.

## Installing the License File

If you have purchased a license for CMM, copy the license file provided by Cisco to an appropriate directory on the host machine. During installation, the interface will prompt you for the location of the license file.

If you have not yet purchased a license, you can use the evaluation license provided with the CMM 3.3.2 distribution to manage up to 50 devices for 60 days.

For information on how licensing works, see [Licensing, page 1-4](#).

For additional information, see:

- [Obtaining a CMM License, page 1-5](#)
- [Installing the CMM License, page 1-6](#)
- [Managing CMM Licenses, page 1-7](#)

## Creating the Linux Installation Directory (Optional)

On a Linux system, install Cisco Multicast Manager in */usr/local/netman*. On a Linux installation, Cisco Multicast Manager requires approximately 3 GB of disk space.

If there is not enough room in */usr/local*, create the netman directory on another partition, then create a symbolic link to it from */usr/local*. For example:



```
# mkdir /space/netman
# cd /usr/local
# ln -s /space/netman netman
# chown -h mmtuser:mmtuser netman
```

## Mounting the CD-ROM (Linux)

If you are mounting an actual physical CD-ROM, use one of the following commands:

For Red Hat Linux ES/AS 4:

```
# mount /dev/cdrom /mnt/cdrom
```

For Red Hat Linux ES/AS 5:

```
# mount /dev/hdc /media/cdrom
```

For VMWare ESX 3.5:

```
# mount /dev/hdc /media/cdrom
```

If you are mounting an **ISO CD-ROM** image downloaded from Cisco.com, use the following command:

```
# mount -t iso9660 -o loop image.iso /mnt/isoimage
```



### Note

*/mnt* is the mount point and can be any designated directory. If this command does not work, please check with your system administrator for mounting instructions.

## Unzipping the Tar File

If you are installing from the tar file, create a */tmp* directory and unzip the tar file there:

```
# cd /tmp
# tar -xzf cmm332_linux.tar.gz
```

The system creates a *Linux* directory and unzips the distribution file to that directory.

## Running the Linux Installation Script

To run the Linux installation script:

---

**Step 1** Log in as *root*.

**Step 2** If installing from a CDROM, enter:

```
# cd /cdrom/cdrom0
# ./install.sh
```

If installing from the extracted tar file location, enter:

```
# cd /tmp/Linux
# ./setup.sh
```

The system issues a series of prompts.

**Step 3** Answer the prompts as indicated in [Table 1-3](#).

**Table 1-3 Linux Installation Prompts**

Prompt	Response
Checking the OS version in cmm-as5-04... Supported Version Server5 Found Checking for the available disk space... <This message appears only if available disk space is less than recommended> Space available in cmm-as5-04: 465337 Kb which is less than the Disk space recommended: 3145728 Kb Do you wish to continue the installation? [y/n]:	There is no default entry for this prompt. Enter <b>y</b> if you want to proceed with the installation; otherwise, enter <b>n</b> .
Checking for physical memory in the system... <This message appears only if the available RAM is less than recommended> Physical Memory available in cmm-as5-04: 1060864 Kb which is less than the RAM space recommended: 2055200 Kb Do you wish to continue the installation? [y/n]:	There is no default entry for this prompt. Enter <b>y</b> if you want to proceed with the installation; otherwise, enter <b>n</b> .
The application installs in /usr/local/netman. Do you wish to continue? [y/n] (default - y):	Press <Enter> to accept the default installation directory (/usr/local/netman); otherwise enter <b>n</b> and then specify another installation directory.
Have you purchased a license for Cisco Multicast Manager 3.3.2? [y/n] [Enter n to continue with evaluation license] (default - n):	Do one of the following: <ul style="list-style-type: none"> <li>• If you have purchased a license file for CMM 3.3.2, enter <b>y</b>.</li> <li>• If you have not yet purchased a license file, enter <b>n</b> to continue installation using the CMM evaluation license that is provided with the CMM 3.3.2 distribution. The evaluation license allows you to use CMM 3.3.2 for 60 days.</li> </ul> For additional information on CMM licensing, see <a href="#">Licensing, page 1-4</a>
Enter purchased license file:	If you enter <b>y</b> in response to the previous prompt, this prompt appears. Enter the path and filename of the license file. If the license file is in the current directory, enter the name of the license file.
Cisco Multicast Manager by default uses mysql database on port 3306. Do you want to change the default mysql port (y/n) (default - n):	To accept the default (do not change the default mysql database on port 3306), press <b>Enter</b> ; otherwise, enter <b>y</b> to and then change the default Mysql port when prompted.

**Table 1-3 Linux Installation Prompts (continued)**

Prompt	Response
The community name to add read-only access for (default- public):	The default community string is <i>public</i> , but you can specify the community string that is configured on your device. Press <b>Enter</b> to accept the default community name (public); otherwise, enter the community string that is defined on your device.
The physical location of the system:	Enter a description of where you are located. If you press <b>Enter</b> , the default is used (no string specifying a physical location)
Contact information of the administrator (default - root):	Enter the best method for contacting the administrator; for example, phone number, e-mail address, and so on. To accept the default email address (root@<CMM server IP address>, press <b>Enter</b> .
Do you want to disable access control checks (y/n) (default - y):	To accept the default value ( <b>y</b> — for disable access control checks, press < <b>Enter</b> >; otherwise, enter <b>n</b> to enable access control checks.
Do you want to add some other Trap OIDs with the default list (y/n) (default - n):	To accept the default value ( <b>n</b> —do not add additional trap OIDs, press < <b>Enter</b> >; otherwise, if you wish to add more OIDs, enter <b>y</b> and enter a trap OID to be added.

Example 1-5 shows sample output from the Linux installation.

#### Example 1-5 Sample Linux Installation Output

```
[root@cmm-server1 Linux]# ./setup.sh

Cisco Multicast Manager Version 3.3.2 installation setup
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights reserved.

Checking the OS version in cmm-server1...
Supported Version AS4 Found

Checking for the available disk space...
Disk space available in cmm-server1 is 245024940 Kb(Recommended: 3145728 Kb)

Checking for physical memory in the system...
Physical memory available in cmm-server1 is 4151236 Kb(Recommended: 2055200 Kb)

No previous Cisco Multicast Manager version found in this machine cmm-server1

Installing Cisco Multicast Manager Version 3.3.2
The application installs in /usr/local/netman. Do you wish to continue? [y/n] (default - y):
License Installation Utility
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights reserved.

Have you purchased a license for Cisco Multicast Manager 3.3.2? [y/n][Enter n to continue with evaluation license] (default - n):
```

```
*****
Installation will continue with Evaluation license.
Please contact get-cmm-key@cisco.com to get permanent license file
Specify the host id of this machine while sending license request
```

```
Host Id of this machine : 001B78A6AC7B
```

```
*****
```

```
Press Enter key to continue installation...
```

```
Install date : Wed Aug 07 15:08:53 PST 2013
Expire date : Sun Sep 01 16:08:53 PDT 2013
Features : MMT,MVPN,VOS
Version : 3.3
Device limit : 50
FlexlmHostId : ANY
VendorName : cisco
License Type : Evaluation
```

```
License status : success
```

```
Creating mmtuser gid...
The mmtuser group already exists
Creating mmtuser uid...
The mmtuser id already exists.
Installing Perl...
Installing MIBS...
Installing support files...
Installing ciscomm to /etc/init.d...
Installing Tomcat...
Creating db base version for fresh install
mysql group already exist
mysql user already exist
```

```
Cisco Multicast Manager by default uses mysql database on port 3306.
Do you want to change the default mysql port (y/n) (default - n): Copying mysql
configuration file to /etc folder ...
Starting MySQL....._[60G[
_[0;32mOK_[0;39m ]
Done creating cmm database
Updating Cisco Multicast Manager Db based on the install type and versions ...
Db schema changes done
Initializing IP Address database with reserved Multicast Addresses...
Shutting down MySQL.._[60G[ _[0;32mOK_[0;39m ]
Configuring Trap Receiver and SNMP Agent...
```

```
Getting Configuration Information for SNMP Agent
=====
```

```
Access control Setup
Description:SNMPv1/SNMPv2c read-only access community name
```

```
The community name to add read-only access for (default - public): Community name for
read only access is public
```

```
System Information Setup
Description:This section defines some of the information reported in the
"System" mib group
```

The physical Location of the system : Contact Information of the Administrator (default - root@):

Contact Information of the Administrator is root@

Getting Configuration Information for Trap Receiver

=====

Access control Setup

Do you want to disable access control checks (y/n) (default - y):

Disables the access control check and accepts all incoming Notification traps

Following are the list of default OIDs the TRAP receiver is configured with

1. ciscoIpMRouteMissingHeartBeats (1.3.6.1.4.1.9.10.2.3.1.0.1)
2. pimNeighborLoss (1.3.6.1.3.61.1.0.1)
3. CISCO-PIM-MIB Traps (1.3.6.1.4.1.9.9.184.2.0.\*)
4. MSDP-MIB Traps (1.3.6.1.3.92.1.1.7.\*)
5. ciscoMvpnMvrfChange (1.3.6.1.4.1.9.10.113.0.2)
6. ivMS Traps (1.3.6.1.4.1.15181.11.1.\*)
7. ivMS Traps 4.x (1.3.6.1.4.1.15181.11.4.\*)
8. Mixed Signal (1.3.6.1.4.1.24931.9.1.1.\*)
9. BridgeTech Traps (1.3.6.1.4.1.24562.\*)
10. CISCO-PIM-MIB-extn (1.3.6.1.4.1.9.10.120.0.\*)
11. CISCO-PIM-IETF-MIB (1.3.6.1.4.1.9.10.119.0.\*)
12. MYSTRO-VIDEOPORT-MIB (1.3.6.1.4.1.14373.2.\*)
13. SAEUROPE-ADMINISTRATION-MIB (1.3.6.1.4.1.1482.20.1.\*)
14. SAEUROPE-DCM-MIB (1.3.6.1.4.1.1482.1.3.2.2.\*)
15. SAEUROPE-MESSAGES-MIB (1.3.6.1.4.1.1482.1.1.2.\*)
16. SAEUROPE-TRAPCONTROL-MIB (1.3.6.1.4.1.1482.1.1.1.\*)
17. CISCO-FLOW-MONITOR-MIB (1.3.6.1.4.1.9.9.692.0.\*)

Do you want to add some other Trap OIDs with the default list (y/n) (default - n): Default

Trap OIDs Configured

Installation Finished.

Starting the application...

Starting mysql server...

Starting MySQL\_[60G[ \_[0;32mOK\_[0;39m ]

Starting CMM Data service...

CMM DataService process started

Using CATALINA\_BASE: /usr/local/netman/mmtsys/apache-tomcat

Using CATALINA\_HOME: /usr/local/netman/mmtsys/apache-tomcat

Using CATALINA\_TMPDIR: /usr/local/netman/mmtsys/apache-tomcat/temp

Using JRE\_HOME: /usr/local/netman/mmtsys/jre/

Starting mysql server...

Starting MySQL\_[60G[ \_[0;32mOK\_[0;39m ]

Starting the polling daemon...

Starting the CLI proxy daemons...

Starting the CLI proxy dtv daemon...

Starting SNMP Trap Receiver daemon...

Starting SNMP Trap Receiver

Starting SNMP Agent daemon...

Starting SNMP Agent

Starting CMM Util process...

.....

CMM Util process started

## Changing the HTTPS Port

The server is configured by default to run on port 8080. If you want to change port 8080 to another port, complete these steps:

**Step 1** Navigate to the following directory:

Linux:

```
/usr/local/netman/mmtsys/apache-tomcat/conf/server.xml
```

Solaris:

```
/opt/RMSMMT/mmtsys/apache-tomcat/conf/server.xml
```

**Step 2** Edit the *server.xml* file.

**Step 3** Modify the `connector port` entry to specify a port other than port 8080:

a. If your installation is on a Linux device:

- Locate the XML element that reads:

```
<Connector port="8080" protocol="HTTP/1.1" SSLEnabled="true"
    maxThreads="150" scheme="https" secure="true"
    clientAuth="false" sslProtocol="TLS"
    keystoreFile="/usr/local/netman/mmtsys/apache-tomcat/conf/keystore"
    keypass="cmm_dev" />
```

- Change the entry `Connector port="8080"` to specify another port number.

b. If your installation is on a Solaris device:

- Locate the XML element that reads:

```
<Connector port="8080" protocol="HTTP/1.1" SSLEnabled="true"
    maxThreads="150" scheme="https" secure="true"
    clientAuth="false" sslProtocol="TLS"
    keystoreFile="/opt/RMSMMT/mmtsys/apache-tomcat/conf/keystore" keypass="cmm_dev" />
```

- Change the entry `Connector port="8080"` to specify another port number.

c. Save the *server.xml* file.

**Step 4** Restart the CMM processes.

For information on starting CMM, see [Starting and Stopping CMM, page 1-32](#).

## Upgrading to Cisco Multicast Manager 3.3.2

You may upgrade from versions 3.0, 3.0.1, 3.1, 3.1.1, 3.2, 3.3 or 3.3.1, to version 3.3.2 using a DVD or ISO image downloaded from Cisco.com, or a tar file.

To successfully upgrade, you must obtain a license file for CMM 3.3.2. For information on obtaining a license file, see [Licensing, page 1-4](#).

Before you upgrade, ensure that you have made a backup of your existing CMM installation as described in the upgrade instructions that follow.

**Note**

Upgrading to Solaris 10 will require you to disable any naming service (NIS, NIS+, LDAP) on the gateway machine before installation. The installation assumes that the machine used for the install is not using a networked user credentials management feature such as NIS+ or LDAP.

## Upgrading on Linux Using a CD or ISO Image

To upgrade on Linux using a CD or ISO image:

**Step 1**

To stop the CMM processes, enter:

```
./K98mnt
```

**Note**

If you are upgrading from CMM version 3.0, 3.0.1, 3.1, 3.1.1, 3.2, 3.3, 3.3.1 or 3.3.2, the CMM installation script automatically backs up your existing configuration and network inventory.

The backup files are stored in the following directory and .tar file:

- `/usr/local/netman/backup/cmmbackup3_0.tar` for CMM 3.0
- `/usr/local/netman/backup/cmmbackup3_1.tar` for CMM 3.1
- `/usr/local/netman/backup/cmmbackup3_2.tar` for CMM 3.2
- `/usr/local/netman/backup/cmmbackup3_3.tar` for CMM 3.3
- `/usr/local/netman/backup/cmmbackup3_3.1.tar` for CMM 3.3.1
- `/usr/local/netman/backup/cmmbackup3_3.2.tar` for CMM 3.3.2

For Red Hat Linux ES/AS 5:

```
# mount /dev/hdc /media/cdrom
```

- d. If you are mounting an **ISO CD-ROM** image downloaded from Cisco.com, use the following command:

```
# mount -t iso9660 -o loop image.iso /mnt/isoimage
```

**Note**

`/mnt` is the mount point and can be any designated directory. If this command does not work, please check with your system administrator for mounting instructions.

**Step 2**

To install, use the following commands:

For a physical DVD:

```
cd /mnt/cdrom
```

For an ISO image downloaded from Cisco.com:

```
cd /mnt/<isoimage folder>
```

**Step 3**

Execute the **setup.sh** script and follow the steps in [Running the Linux Installation Script, page 1-17](#).

- Step 4** If the upgrade procedure fails, see [Restoring a Previous Version of CMM, page 1-31](#) for instructions on restoring the original CMM installation.

## Upgrading on Linux Using a Tar File

To upgrade on Linux using a tar file:

- Step 1** To stop the CMM processes, enter:

```
./K98mmt
```



**Note**

If you are upgrading from CMM version 3.0, 3.0.1, 3.1, 3.1.1, 3.2, 3.3, 3.3.1 or 3.3.2, the CMM installation script automatically backs up your existing configuration and network inventory.

The backup files are stored in the following directory and .tar file:

- */usr/local/netman/backup/cmmbackup3\_0.tar* for CMM 3.0
- */usr/local/netman/backup/cmmbackup3\_1.tar* for CMM 3.1
- */usr/local/netman/backup/cmmbackup3\_2.tar* for CMM 3.2
- */usr/local/netman/backup/cmmbackup3\_3.tar* for CMM 3.3
- *usr/local/netman/backup/cmmbackup3\_3.1.tar* for CMM 3.3.1
- *usr/local/netman/backup/cmmbackup3\_3.2.tar* for CMM 3.3.2

```
[root@vm-rh54_64-01 Linux]# ./setup.sh

Cisco Multicast Manager Version 3.3.2 installation setup
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights reserved.

Checking the OS version in vm-rh54_64-01...
Supported Version Server5 Found

Checking for the available disk space...
Disk space available in vm-rh54_64-01 is 78945020 Kb(Recommended: 3145728 Kb)

Checking for physical memory in the system...
Physical memory available in vm-rh54_64-01 is 5975764 Kb(Recommended: 2055200 Kb)

INFO: Backing up property files from previous version
Cisco Multicast Manager Version 3.3 found in this machine vm-rh54_64-01

Do you want to continue upgrade from 3.3 to Cisco Multicast Manager 3.3.2? [y/n]: y

This will stops the Cisco Multicast Manager processes. Do you want to continue? [y/n]: y
Upgrading Cisco Multicast Manager Version to 3.3.2

Stopping Cisco Multicast Manager Processes ...
Using CATALINA_BASE: /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_HOME: /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_TMPDIR: /usr/local/netman/mmtsys/apache-tomcat/temp
Using JRE_HOME: /usr/local/netman/mmtsys/jre
Shutting down MySQL.. [ OK ]
```



```

Stopping CLI Proxy Daemon(ssh)..
Stopping CLI Proxy Daemon(tel)..
Stopping CLI Proxy Daemon(dtv)..
Stopping SNMP Trap Receiver..
Stopping SNMP Trap Agent..
7520
CMM Util process stopped successfully...
7204
CMM Data Service process stopped successfully...
CMM Processes Stopped Successfully

License Installation Utility
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights
reserved.

Have you have purchased license file for Cisco Multicast Manager 3.3.2 upgrade? [y/n]: y
Enter license file: /cmm/dummyFileName
Checking the Licensing File...

Install date   : Thu Aug 01 10:20:36 PST 2013
Expire date    : Permanent
Features       : MMT,MVPN,VOS
Version        : 3.3
Device limit   : Unlimited
FlexlmHostId  : ANY
VendorName     : cisco
License Type   : Purchased

License status : success

Backing up previous Cisco Multicast Manager database and configuration .....
Starting mysql server to upgrade export
Starting MySQL.                                     [ OK ]
Stop mysql server after upgrade export
Shutting down MySQL..                               [ OK ]
cat: /usr/local/netman/mmts/sys/rmspoll.conf: No such file or directory
cmm_backup/
cmm_backup/sys/
cmm_backup/sys/cmmdb.conf
cmm_backup/sys/multicastdiscovery.conf
cmm_backup/sys/mixedsignaloid.conf
cmm_backup/sys/rmspollcli.conf
cmm_backup/sys/multicasttrace.conf
cmm_backup/cmmdb.sql
cmm_backup/db/
cmm_backup/db/cookieState.db
cmm_backup/db/.ipaddr.db.lock
cmm_backup/db/ipaddr.db
cmm_backup/db/STDMIBS
cmm_backup/data/
cmm_backup/graphs/
cmm_backup/trace/
cmm_backup/share/
cmm_backup/share/snmp/
cmm_backup/share/snmp/snmptrapd.conf
cmm_backup/share/snmp/snmpd.conf
cmm_backup/application/
cmm_backup/application/i18n.properties
cmm_backup/application/warning.properties
Installing Perl...
Installing MIBS...
INFO : Shipping library for Linux 64 bit specific changes

```

```

Installing support files...
Installing ciscomm to /etc/init.d...
Installing Tomcat...
Updating Cisco Multicast Manager Db based on the install type and versions ...
Starting the mysql server for upgrade
Starting MySQL..                               [ OK ]
Base Db version exist is 3.3
Updating db for Cisco Multicast Manager version 3.3.2 schema changes
updating tree polling while upgrade for VidMon feature
Stopping mysql server after upgrade
Shutting down MySQL...                           [ OK ]
Configuring Trap Receiver and SNMP Agent...

Getting Configuration Information for SNMP Agent
=====

Access control Setup
Description:      SNMPv1/SNMPv2c read-only access community name

The community name to add read-only access for (default - public):
Community name for read only access is public

System Information Setup
Description:      This section defines some of the information reported in the
                  "System" mib group

The physical Location of the system : San Jose
Contact Information of the Administrator (default - root@):

Contact Information of the Administrator is root@

Getting Configuration Information for Trap Receiver
=====

Access control Setup
Do you want to disable access control checks (y/n) (default - y):

Disables the access control check and accepts all incoming Notification traps

Following are the list of default OIDs the TRAP receiver is configured with

1.  ciscoIpMRouteMissingHeartBeats (1.3.6.1.4.1.9.10.2.3.1.0.1)
2.  pimNeighborLoss (1.3.6.1.3.61.1.0.1)
3.  CISCO-PIM-MIB Traps (1.3.6.1.4.1.9.9.184.2.0.*)
4.  MSDP-MIB Traps (1.3.6.1.3.92.1.1.7.*)
5.  ciscoMvvpnMvrfChange (1.3.6.1.4.1.9.10.113.0.2)
6.  iVMS Traps (1.3.6.1.4.1.15181.11.1.*)
7.  iVMS Traps 4.x (1.3.6.1.4.1.15181.11.4.*)
8.  Mixed Signal (1.3.6.1.4.1.24931.9.1.1.*)
9.  BridgeTech Traps (1.3.6.1.4.1.24562.*)
10. CISCO-PIM-MIB-extn (1.3.6.1.4.1.9.10.120.0.*)
11. CISCO-PIM-IETF-MIB (1.3.6.1.4.1.9.10.119.0.*)
12. MYSTRO-VIDEOPORT-MIB (1.3.6.1.4.1.14373.2.*)
13. SAEUROPE-ADMINISTRATION-MIB (1.3.6.1.4.1.1482.20.1.*)
14. SAEUROPE-DCM-MIB (1.3.6.1.4.1.1482.1.3.2.2.*)
15. SAEUROPE-MESSAGES-MIB (1.3.6.1.4.1.1482.1.1.2.*)
16. SAEUROPE-TRAPCONTROL-MIB (1.3.6.1.4.1.1482.1.1.1.*)
17. CISCO-FLOW-MONITOR-MIB (1.3.6.1.4.1.9.9.692.0.*)

Do you want to add some other Trap OIDs with the default list (y/n) (default - n):
Default Trap OIDs Configured
Installation Finished.
INFO: Updating files for upgrade
INFO: Restoring property files from previous version

```

```

Starting the application...
Starting mysql server...
Starting MySQL. [ OK ]
Starting CMM Data service...
CMM DataService process started
Using CATALINA_BASE: /usr/local/netman/mmtsystomcat
Using CATALINA_HOME: /usr/local/netman/mmtsystomcat
Using CATALINA_TMPDIR: /usr/local/netman/mmtsystomcat/temp
Using JRE_HOME: /usr/local/netman/mmtsystjre/
Starting mysql server...
Starting MySQL [ OK ]
Starting the polling daemon...
Starting the CLI proxy daemons...
Starting the CLI proxy dtv daemon...
Starting SNMP Trap Receiver daemon...
Starting SNMP Trap Receiver

Starting SNMP Agent daemon...
Starting SNMP Agent
Starting CMM Util process...
.....
CMM Util process started

```

To upgrade on Solaris using a CD or an ISO image:


**Note**

If you are upgrading from CMM version 3.0, 3.0.1, 3.1, 3.1.1, 3.2, 3.3, 3.3.1 or 3.3.2, the CMM installation script automatically backs up your existing configuration and network inventory.

The backup files are stored in the following directory and .tar file:

- /opt/RMSMMT/backup/cmmbackup3\_0.tar for CMM 3.0
- /opt/RMSMMT/backup/cmmbackup3\_1.tar for CMM 3.1
- /opt/RMSMMT/backup/cmmbackup3\_2.tar for CMM 3.2
- /opt/RMSMMT/backup/cmmbackup3\_3.tar for CMM 3.3
- /opt/RMSMMT/backup/cmmbackup3\_3.1.tar for CMM 3.3.1
- /opt/RMSMMT/backup/cmmbackup3\_3.2.tar for CMM 3.3.2

To upgrade on Solaris using a tar file:


**Note**

If you are upgrading from CMM version 3.0, 3.0.1, 3.1, 3.1.1, 3.2, 3.3, 3.3.1 or 3.3.2, the CMM installation script automatically backs up your existing configuration and network inventory.

The backup files are stored in the following directory and .tar file:

- /opt/RMSMMT/backup/cmmbackup3\_0.tar for CMM 3.0
- /opt/RMSMMT/backup/cmmbackup3\_1.tar for CMM 3.1
- /opt/RMSMMT/backup/cmmbackup3\_2.tar for CMM 3.2
- /opt/RMSMMT/backup/cmmbackup3\_3.tar for CMM 3.3
- /opt/RMSMMT/backup/cmmbackup3\_3.1.tar for CMM 3.3.1
- /opt/RMSMMT/backup/cmmbackup3\_3.2.tar for CMM 3.3.2

```

[root@cmm-s10-03 Solaris]# ./setup.sh

Cisco Multicast Manager Version 3.3.2 installation setup
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights
reserved.

Checking the OS version in cmm-s10-03...
Supported version 5.10 found

Checking for the available disk space...
Disk space available in cmm-s10-03 is 6638485 Kb(Recommended: 3145728 Kb)

Checking for physical memory in the system...
Physical memory available in cmm-s10-03 is 8257536 Kb(Recommended: 2055200 Kb)

INFO: Backing up property files from previous version
Cisco Multicast Manager Version 3.3 found in this machine cmm-s10-03

Do you want to continue upgrade from 3.3 to Cisco Multicast Manager 3.3.2? [y/n]: y

This will stops the Cisco Multicast Manager processes. Do you want to continue? [y/n]: y
Upgrading Cisco Multicast Manager Version to 3.3.2

Stopping Cisco Multicast Manager Processes ...
Sun Microsystems Inc. SunOS 5.10 Generic January 2005
Using CATALINA_BASE: /opt/RMSMMT/mmtsys/apache-tomcat
Using CATALINA_HOME: /opt/RMSMMT/mmtsys/apache-tomcat
Using CATALINA_TMPDIR: /opt/RMSMMT/mmtsys/apache-tomcat/temp
Using JRE_HOME: /opt/RMSMMT/mmtsys/jre/
Stopping the Polling Daemon..
Stopping CLI Proxy Daemon (ssh)..
Stopping CLI Proxy Daemon(tel)..
Stopping CLI Proxy Daemon(dtv)..
Stopping SNMP Trap Receiver..
Stopping SNMP Trap Agent..
1069
CMM Util process stopped successfully...
936
CMM Data Service process stopped successfully...
Stopping mysql server...
Shutting down MySQL
.. SUCCESS!
kill: 1032: no such process
kill: 1047: no such process
kill: 1052: no such process

License Installation Utility
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights
reserved.

Have you have purchased license file for Cisco Multicast Manager 3.3.2 upgrade? [y/n]: y
Enter license file: /cmm/dummyFileName
Checking the Licensing File...

Install date : Thu Aug 01 18:24:41 PST 2013
Expire date : Permanent
Features : MMT,VOS,MVPN
Version : 3.3
Device limit : Unlimited
FlexlmHostId : ANY
VendorName : cisco
License Type : Purchased

```

```

License status : success

Backing up previous Cisco Multicast Manager database and configuration .....
Starting mysql server to upgrade export
Starting MySQL
. SUCCESS!
Stop mysql server after upgrade export
Shutting down MySQL
.. SUCCESS!
cat: cannot open /opt/RMSMMT/mmtsys/sys/rmspoll.conf
a cmm_backup// 0K
a cmm_backup//sys/ 0K
a cmm_backup//sys/cmmdb.conf 1K
a cmm_backup//sys/mixedsignaloid.conf 1K
a cmm_backup//sys/multicastdiscovery.conf 1K
a cmm_backup//sys/multicasttrace.conf 1K
a cmm_backup//sys/rmspollcli.conf 1K
a cmm_backup//share/ 0K
a cmm_backup//share/snmp/ 0K
a cmm_backup//share/snmp/snmpd.conf 1K
a cmm_backup//share/snmp/snmptrapd.conf 2K
a cmm_backup//cmmdb.sql 76K
a cmm_backup//data/ 0K
a cmm_backup//db/ 0K
a cmm_backup//db/ipaddr.db 24K
a cmm_backup//db/cookieState.db 24K
a cmm_backup//db/STDMIBS 1K
a cmm_backup//db/.ipaddr.db.lock 0K
a comebacks//graphs/ 0K
a cmm_backup//trace/ 0K
a comebacks//application/ 0K
a cmm_backup//application/warning.properties 1K
a cmm_backup//application/i18n.properties 1K
Installing Perl...
Installing MIBS...
Installing support files...
Installing ciscomm to /etc/init.d...
Installing Tomcat...
Updating Cisco Multicast Manager Db based on the install type and versions ...
Starting the mysql server for upgrade
Starting MySQL
.. SUCCESS!
Base Db version exist is 3.3
Updating db for Cisco Multicast Manager version 3.3.2 schema changes
updating tree polling while upgrade for VidMon feature
Stopping mysql server after upgrade
Shutting down MySQL
... SUCCESS!
Configuring Trap Receiver and SNMP Agent...

Getting Configuration Information for SNMP Agent
=====

Access control Setup
Description:      SNMPv1/SNMPv2c read-only access community name

The community name to add read-only access for (default - public):
Community name for read only access is public

System Information Setup
Description:      This section defines some of the information reported in the
                  "System" mib group

```

```

The physical Location of the system : San Jose
Contact Information of the Administrator (default - root@):

Contact Information of the Administrator is root@

Getting Configuration Information for Trap Receiver
=====

Access control Setup
Do you want to disable access control checks (y/n) (default - y):

Disables the access control check and accepts all incoming Notification traps

Following are the list of default OIDs the TRAP receiver is configured with
  1. ciscoIpMRouteMissingHeartBeats (1.3.6.1.4.1.9.10.2.3.1.0.1)
  2. pimNeighborLoss (1.3.6.1.3.6.1.1.0.1)
  3. CISCO-PIM-MIB Traps (1.3.6.1.4.1.9.9.184.2.0.*)
  4. MSDP-MIB Traps (1.3.6.1.3.92.1.1.7.*)
  5. ciscoMvpnMvrfChange (1.3.6.1.4.1.9.10.113.0.2)
  6. ivMS Traps 3.x (1.3.6.1.4.1.15181.11.1.*)
  7. ivMS Traps 4.x (1.3.6.1.4.1.15181.11.4.*)
  8. Mixed Signal (1.3.6.1.4.1.24931.9.1.1.*)
  9. BridgeTech Traps (1.3.6.1.4.1.24562.*)
 10. CISCO-PIM-MIB-extn (1.3.6.1.4.1.9.10.120.0.*)
 11. CISCO-PIM-IETF-MIB (1.3.6.1.4.1.9.10.119.0.*)
 12. MYSTRO-VIDEOPORT-MIB (1.3.6.1.4.1.14373.2.*)
 13. SAEUROPE-ADMINISTRATION-MIB (1.3.6.1.4.1.1482.20.1.*)
 14. SAEUROPE-DCM-MIB (1.3.6.1.4.1.1482.1.3.2.2.*)
 15. SAEUROPE-MESSAGES-MIB (1.3.6.1.4.1.1482.1.1.2.*)
 16. SAEUROPE-TRAPCONTROL-MIB (1.3.6.1.4.1.1482.1.1.1.*)
 17. CISCO-FLOW-MONITOR-MIB (1.3.6.1.4.1.9.9.692.0.*)

Do you want to add some other Trap OIDs with the default list (y/n) (default - n):
Default Trap OIDs Configured
Installation Finished.
INFO: Updating files for upgrade
INFO: Restoring property files from previous version
Starting the application...
Starting mysql server...
Starting MySQL
. SUCCESS!
Starting CMM Data service...
Sun Microsystems Inc.  SunOS 5.10      Generic January 2005
2263
CMM DataService process started
Sun Microsystems Inc.  SunOS 5.10      Generic January 2005
Using CATALINA_BASE:   /opt/RMSMNT/mmtsys/apache-tomcat
Using CATALINA_HOME:   /opt/RMSMNT/mmtsys/apache-tomcat
Using CATALINA_TMPDIR: /opt/RMSMNT/mmtsys/apache-tomcat/temp
Using JRE_HOME:        /opt/RMSMNT/mmtsys/jre/
2290
Starting the polling daemon...
Sun Microsystems Inc.  SunOS 5.10      Generic January 2005
Starting the CLI proxy daemons...
Sun Microsystems Inc.  SunOS 5.10      Generic January 2005
Sun Microsystems Inc.  SunOS 5.10      Generic January 2005
Starting the CLI proxy dtv daemon...
Sun Microsystems Inc.  SunOS 5.10      Generic January 2005
Starting SNMP Trap Receiver daemon...
Starting SNMP Trap Receiver

Starting SNMP Agent daemon...
01/13/2011 18:27:31 Stopping the snmpd process which is already running

```

```

Starting SNMP Agent
Starting Util process...
Sun Microsystems Inc.   SunOS 5.10       Generic January 2005
2397
.....
CMM Util process started
#

```

## Upgrading CMM 2.x to CMM 3.3.2

There is no direct upgrade path from CMM 2.x to CMM 3.3.2. To upgrade from CMM 2.x to CMM 3.3.2 you must first upgrade to CMM 3.1 and then upgrade CMM 3.1 to CMM 3.3.2.

For detailed upgrade information, see:

- “Upgrading to CMM 3.1” in the *Installation Guide for Cisco Multicast Manager, 3.1*, at the following location:  
[http://www.cisco.com/en/US/docs/net\\_mgmt/cisco\\_multicast\\_manager/3.1/installation/guide/cmm\\_in.html#wp1081762](http://www.cisco.com/en/US/docs/net_mgmt/cisco_multicast_manager/3.1/installation/guide/cmm_in.html#wp1081762)
- [Upgrading to Cisco Multicast Manager 3.3.2, page 1-22](#)

## Restoring a Previous Version of CMM

In the event that you encounter problems with the upgrade procedure, you can restore a previous version of CMM from a backed up installation.

Complete these steps to restore a previous version of CMM:

- 
- Step 1** If the previous CMM version is 3.0, 3.0.1, 3.1, 3.1.1, 3.2, 3.3, 3.3.1 or 3.3.2, complete these steps:
- Copy the backup files that were created automatically during the installation process:
    - For example, if you are restoring a Solaris installation of CMM 3.3.2, then copy the file `/opt/RMSMMT/backup/cmmbackup3_3.2.tar` to any location.  

```
cp /opt/RMSMMT/backup/cmmbackup3_3_2.tar /tmp
```
    - For example, if you are restoring a Linux installation of CMM 3.3.1, then copy the file `/usr/local/netman/backup/cmmbackup3_3.2.tar` to any location.  

```
cp /usr/local/netman/backup/cmmbackup3_3_2.tar /tmp
```
- Step 2** If your CMM installation is on a Solaris server, enter the following command to uninstall it:
- ```
/opt/RMSMMT/uninstall.sh
```
- Step 3** If your CMM installation is on a Linux server, enter the following command to uninstall it:
- ```
/usr/local/netman/uninstall.sh
```
- Step 4** If the uninstall script does not remove the installation, then do one of the following to remove it manually:
- If your CMM installation is on a Solaris server, enter the following to delete it:  

```
rm -fr /opt/RMSMMT
```
  - If your CMM installation is on a Linux server, enter the following to delete it:

```
rm -fr /usr/local/netman
```

**Step 5** Locate the tar file that contains the backup of the previous installation that you made during the upgrade procedure.

**Step 6** If the previous CMM version used is version 3.0, 3.0.1, 3.1, 3.1.1, 3.2, or 3.3, complete these steps:

- a. Perform a fresh installation of the previous CMM version.
- b. Import the backed up information using

**On Solaris:**

To import back up data of the previous CMM version:

```
/opt/RMSMMT/import.sh
```

**On Linux:**

To import back up data of the previous CMM version

```
/usr/local/netman/import.sh
```

**Step 7** Enter the following to start the CMM processes:

```
./S98mmt
```

---

## Starting and Stopping CMM

To start the application:

**On Solaris:**

Run the **S98mmt** script to start the CMM process.

To stop the application, run the **K98mmt** script.

The **S98mmt** script and the **K98mmt** scripts are located in the CMM home directory (by default, */opt/RMSMMT*).

**On Linux:**

Run the **S98mmt** script to start the CMM process.

To stop the application, run the **K98mmt** script.

The **S98mmt** script and the **K98mmt** scripts are located in the CMM home directory (by default */usr/local/netman*).

The **S98mmt** script also runs the **S98mmtpoll** script, which starts the polling daemon. The **S98mmtpoll** script can also be used as a watchdog script to ensure that the polling daemon is up and running. The root **crontab** configuration would be:

**On Solaris:**

```
0,5,10,15,20,25,30,35,40,45,50,55 * * * * /opt/RMSMMT/S98mmtpoll
```

**On Linux:**

```
* /5 * * * * /usr/local/netman/S98mmtpoll
```



These entries will run the script every five minutes.

The default login username is admin, and the default password is rmsmmt.

**Note**

The **K98mmt** script will stop the tomcat server, polling daemon, cliproxyd daemon, SNMP trap agent daemon, and SNMP trap receiver daemon. The **S98mmt** script will start the tomcat server, cliproxyd daemon, SNMP trap agent daemon, and SNMP trap receiver daemon, but not the polling daemon, for the first time. You will have to manually start the polling daemon through the application for the first time after configuring the global polling configuration.

During installation, the **K98mmt** script is installed in the `/etc/rc0.d` directory. This ensures that the polling daemon shuts down properly upon system reboot.

The installation script logs all of the install and upgrade information in a log file named `cmminstall.log`, under `/tmp` folder.

## Remote Upgrade

CMM 3.0, 3.1, 3.2, 3.3 and 3.3.1 can be upgraded remotely to 3.3.2. To perform a remote upgrade:

1. Export the CMM 3.x inventory, configurations, trace related information, administration information.
2. Import the exported inventory, configuration, trace related information, and administration information into the CMM 3.3.2 server.

See [Server Migration, page 1-33](#) for details on the procedure.

**Note**

The remote upgrade procedure cannot be used to migrate from one operating system platform to another.

## Server Migration

Two scripts, **export.sh** and **import.sh**, are provided for server migration. All database content and configurations can be exported and imported from one machine to other.

These scripts make it possible to upgrade your CMM installation remotely.

**Note**

The server migration procedure cannot be used to migrate from one operating system platform to another.

## Export Utility

The **export.sh** export utility allows you to save the CMM configuration to a tar file that you can transfer to another CMM device. On the second CMM device, you can import the saved configuration by using the **import.sh** script. This is useful when you want to configure several CMM installations with the same information.

To run the **export.sh** script, you will need the password for the MySQL server on the CMM device (the default password is `cmmt`).

The export utility prompts you for a target directory to which to write the exported data, and saves the data in a tar file. The default name for the tar file is *cmmbackup3\_3\_1.tar*, but you can specify another name for the tar file.

**Example 1-6** shows sample output from the Solaris version of the export script.

#### Example 1-6 Sample Export Utility Output

```
[root@vm-rh54_64-01 Linux]# ./export.sh

Cisco Multicast Manager Version 3.3.2 export utility
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights
reserved.

Enter the destination directory: /temp
This utility stops the CMM processes for taking backup.
Do you wish to continue? [y/n]: y

Using CATALINA_BASE:   /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_HOME:   /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_TMPDIR: /usr/local/netman/mmtsys/apache-tomcat/temp
Using JRE_HOME:        /usr/local/netman/mmtsys/jre
Shutting down MySQL...                               [ OK ]
Stopping CLI Proxy Daemon(ssh)..
Stopping CLI Proxy Daemon(tel)..
Stopping CLI Proxy Daemon(dtv)..
Stopping SNMP Trap Receiver..
Stopping SNMP Trap Agent..
8693
CMM Util process stopped successfully...
8361
CMM Data Service process stopped successfully...
kill 9176: No such process
kill 9195: No such process

Backing up data...

Starting MySQL.                                     [ OK ]
Enter password:
Shutting down MySQL...                               [ OK ]
cat: /usr/local/netman/mmtsys/sys/rmssql.conf: No such file or directory

Compressing the backed up data...
cmm_backup/
cmm_backup/sys/
cmm_backup/sys/cmmdb.conf
cmm_backup/sys/multicastdiscovery.conf
cmm_backup/sys/mixedsignaloid.conf
cmm_backup/sys/rmssqlcli.conf
cmm_backup/sys/multicasttrace.conf
cmm_backup/cmmdb.sql
cmm_backup/db/
cmm_backup/db/cookieState.db
cmm_backup/db/.ipaddr.db.lock
cmm_backup/db/ipaddr.db
cmm_backup/db/STDMIBS
cmm_backup/data/
cmm_backup/graphs/
cmm_backup/trace/
cmm_backup/share/
cmm_backup/share/snmp/
cmm_backup/share/snmp/snmptrapd.conf
cmm_backup/share/snmp/snmpd.conf
```

```

Data backed up successfully under /temp/cmmbackup3_3_2.tar

Starting the application...
Starting mysql server...
Starting MySQL. [ OK ]
Starting CMM Data service...
CMM DataService process started
Using CATALINA_BASE: /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_HOME: /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_TMPDIR: /usr/local/netman/mmtsys/apache-tomcat/temp
Using JRE_HOME: /usr/local/netman/mmtsys/jre/
Starting mysql server...
Starting MySQL [ OK ]
Starting the polling daemon...
Starting the CLI proxy daemons...
Starting the CLI proxy dtv daemon...
Starting SNMP Trap Receiver daemon...
Starting SNMP Trap Receiver

Starting SNMP Agent daemon...
Starting SNMP Agent
Starting CMM Util process...
.....
CMM Util process started
*****

```

---

## Import Utility

CMM 3.3.2 provides six import utilities for specific CMM releases. The import utilities allow you to import a saved CMM configuration that you saved by using the **export.sh** script to update CMM. This is useful when you want to configure several CMM installations with the same information.

CMM 3.3.2 provides six import scripts in the CMM root directory:

- **importCMM30.sh** —Run this script to import CMM 3.0 or CMM 3.0.x data.
- **importCMM31.sh** —Run this script to import CMM 3.1 or CMM3.1.x data.
- **importCMM32.sh** —Run this script to import CMM 3.2.
- **importCMM33.sh**— Run this script to import CMM 3.3.
- **importCMM331.sh**— Run this script to import CMM 3.3.1.
- **import.sh**— Run this script to import CMM 3.3.2.

To run the an import script, you will need the password for the MySQL server on the CMM device (the default password is *cmm*).

The import utility prompts you for the directory location and filename for the tar file that contains an exported CMM configuration.

[Example 1-7](#) shows sample output from the Linux version of the **import.sh** script.

### Example 1-7 Sample Import Utility Output

```
[root@vm-rh54_64-01 Linux]# ./import.sh
```

```
Cisco Multicast Manager Version 3.3.2 import utility
Copyright (c) 2009, 2010, 2011-2012, 2013 Cisco and/or its affiliates. All rights
reserved.
```

```
Enter the source directory of the tar file: /temp
Enter the backup File: cmmbackup3_3_2.tar
```

```
Checking CMM 3.3.2 installed in this machine...
```

```
This utility stops the CMM processes for restoring the backup
Do you wish to continue? [y/n]: y
```

```
Using CATALINA_BASE: /usr/local/netman/mmtsyst/apache-tomcat
Using CATALINA_HOME: /usr/local/netman/mmtsyst/apache-tomcat
Using CATALINA_TMPDIR: /usr/local/netman/mmtsyst/apache-tomcat/temp
Using JRE_HOME: /usr/local/netman/mmtsyst/jre
Shutting down MySQL.. [ OK ]
Stopping CLI Proxy Daemon(ssh)..
Stopping CLI Proxy Daemon(tel)..
Stopping CLI Proxy Daemon(dtv)..
Stopping SNMP Trap Receiver..
Stopping SNMP Trap Agent..
13174
CMM Util process stopped successfully...
12843
CMM Data Service process stopped successfully...
kill 13132: No such process
kill 13143: No such process
```

```
This utility deletes all the previous domain information
Do you wish to continue? [y/n]: y
```

```
Extracting...
cmm_backup/
cmm_backup/sys/
cmm_backup/sys/cmmdb.conf
cmm_backup/sys/multicastdiscovery.conf
cmm_backup/sys/mixedsignaloid.conf
cmm_backup/sys/rmssqlcli.conf
cmm_backup/sys/multicasttrace.conf
cmm_backup/cmmdb.sql
cmm_backup/db/
cmm_backup/db/cookieState.db
cmm_backup/db/.ipaddr.db.lock
cmm_backup/db/ipaddr.db
cmm_backup/db/STDMIBS
cmm_backup/data/
cmm_backup/graphs/
cmm_backup/trace/
cmm_backup/share/
cmm_backup/share/snmp/
cmm_backup/share/snmp/snmptrapd.conf
cmm_backup/share/snmp/snmpd.conf
Starting mysql server...
Starting MySQL. [ OK ]
Enter Mysql password:
Dumping the db contents...
Shutting down MySQL... [ OK ]
Copying data and conf files..

Starting the application...
Starting mysql server...
Starting MySQL. [ OK ]
Starting CMM Data service...
CMM DataService process started
```

```
Using CATALINA_BASE: /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_HOME: /usr/local/netman/mmtsys/apache-tomcat
Using CATALINA_TMPDIR: /usr/local/netman/mmtsys/apache-tomcat/temp
Using JRE_HOME: /usr/local/netman/mmtsys/jre/
Starting mysql server...
Starting MySQL [ OK ]
Starting the polling daemon...
Starting the CLI proxy daemons...
Starting the CLI proxy dtv daemon...
Starting SNMP Trap Receiver daemon...
Starting SNMP Trap Receiver

Starting SNMP Agent daemon...
Starting SNMP Agent
Starting CMM Util process...
.....
CMM Util process started
```

---

## Backup Utility

You can make periodic backups using the following script:

```
./backup.sh <folder>
```

This script is located in the following directories:

- On Linux:

```
/usr/local/netman
```

- On Solaris

```
/opt/RMSMNT/
```

---





---

## A

- addFlexlmLicense.sh script [1-4](#)
  - running [1-8](#)
- angle brackets [vi](#)

---

## B

- backup.sh [1-39](#)
- backup utility [1-39](#)
- boldface font [vi](#)
- braces [vi](#)
- browsers
  - supported [1-3](#)

---

## C

- Cisco Multicast Manager (CMM)
  - starting and stopping [1-34](#)
- client browsers [1-3](#)

---

## D

- default gateway
  - changing [1-10](#)
- disk space requirements
  - for Linux systems [1-16](#)
- document
  - audience [v](#)
  - conventions [vi](#)
  - objectives [v](#)
  - organization [v](#)
- documentation

related [vi](#)

---

## E

- export.sh script [1-35](#)
- exporting data
  - export.sh [1-35](#)

---

## F

- FlexLM [1-4](#)
- FlexlmLicense script [1-4](#)
  - running [1-8](#)
- font
  - boldface [vi](#)
  - boldface screen [vi](#)
  - italic [vi](#)
  - italic screen [vi](#)
  - screen [vi](#)

---

## I

- import scripts
  - import.sh [1-37](#)
  - importCMM30.sh [1-37](#)
  - importCMM31.sh [1-37](#)
  - importCMM32.sh [1-37](#)
- installation
  - license [1-6](#)
- installation directory
  - creating Linux [1-16](#)
  - creating Solaris [1-11](#)

## installation instructions

Linux [1-16](#)Solaris [1-10](#)

## installation prompts

Linux [1-18](#)Solaris [1-12](#)italic font [vi](#)

---

**K**K98mmt script [1-34](#)

---

**L**

## license

evaluation license [1-4](#)installing [1-6, 1-10, 1-16](#)managing [1-7](#)obtaining permanent [1-5](#)license file [1-4](#)

## license scripts

addFlexlmLicense.sh [1-4](#)FlexlmLicense script [1-4](#)

## licensing

FlexLM [1-4](#)overview [1-4](#)

## Linux

## supported hardware

AMD Opteron 250 processor [1-2](#)Xeon dual or quad core [1-2](#)supported versions [1-2](#)Linux installation instructions [1-16](#)Linux installation prompts [1-18](#)

## Linux installation script

running [1-17](#)

---

**M**memory requirements [1-4](#)mounting the CD-ROM [1-11, 1-17](#)Multicast VPN (MVPN) support [1-4](#)MySql [1-4](#)

---

**P**port usage [1-3](#)product authorization key [1-5](#)

## Product Licensing Registration

Cisco.com page for [1-5](#)

---

**R**remote upgrade [1-34](#)required ports [1-3](#)required services [1-3](#)restoring a previous version [1-32](#)

## running the installation script

Linux [1-17](#)Solaris [1-11](#)

---

**S**Sample Import Utility [1-37](#)

## sample installation output

Linux [1-19, 1-24, 1-29](#)Solaris [1-13](#)Server Migration [1-35](#)services used by CMM [1-3](#)

## Solaris installation directory

creating [1-11](#)Solaris installation instructions [1-10](#)Solaris installation prompts [1-12](#)

## Solaris-SPARC

supported hardware



- Sun UltraSPARC IIIi [1-2](#)
- square brackets [vi](#)
- starting and stopping Cisco Multicast Manager [1-34](#)
- Sun Microsystems servers
  - Sun Fire V440
    - supported processors [1-3](#)
- supported hardware
  - Sun Fire V440
    - UltraSPARC IIIi processors [1-3](#)
  - Sun Microsystems servers [1-3](#)
- system IP address [1-10](#)

---

## U

- unzipping the tar file [1-11, 1-17](#)
- upgrade
  - remote [1-34](#)
- upgrading
  - from CMM 2.x [1-32](#)
  - on Solaris [1-27](#)

---

## V

- vertical bar [vi](#)
- Video Operations Solution (VOS) support [1-4](#)
- VMWare support [1-3](#)