



# Troubleshooting

---

This section provides information about troubleshooting Prime NAM, and has the following section:

- [Resetting the Prime NAM Root Password to the Default Value, page 1](#)

## Resetting the Prime NAM Root Password to the Default Value

This procedure resets the Prime NAM root password to the default value of *root*. Use this procedure when you cannot remember the Prime NAM root password and need to access the Prime NAM CLI.

### SUMMARY STEPS

1. **enable**
2. **service-module sm *slot/0* password-reset**

### DETAILED STEPS

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. Enter your password if prompted.
<b>Step 2</b>	<b>service-module sm <i>slot/0</i> password-reset</b>  <b>Example:</b> Router# service-module sm 1/0 password-reset	Reloads the software on the SM-SRE.

**Resetting the Prime NAM Root Password to the Default Value**