




Provision Line Cards

This chapter describes the tasks related to provisioning the Cisco NCS 1000 line cards in Cisco Optical Site Manager.

Figure 1: Provision Line Cards



- [Supported Line Cards, on page 2](#)
- [Open the Card View, on page 2](#)
- [Change Admin State for Card Ports, on page 3](#)
- [Add Card Mode, on page 3](#)
- [Edit Card Mode, on page 10](#)
- [Provision Trail Trace Monitoring, on page 11](#)
- [Provision ODU Interfaces, on page 12](#)
- [Provision OTU Interfaces , on page 13](#)
- [Provision Ethernet Interfaces, on page 15](#)
- [Provision Optical Channels, on page 17](#)
- [Change Trunk Port Parameters, on page 19](#)
- [Provision Optical Threshold Settings, on page 20](#)
- [Provision G.709 Thresholds , on page 21](#)

- [Provision FEC Thresholds](#), on page 22
- [Provision RMON Thresholds](#), on page 22
- [Provision Loopback](#), on page 23
- [Provision Optical Safety](#) , on page 24
- [Enable Attention LED](#), on page 26

Supported Line Cards

Table 1: Feature History

Feature Name	Release Information	Description
Support for NCS 1001 and Cards	Cisco IOS XR Release 24.3.1	Cisco Optical Site Manager now allows you to manage the NCS 1001 node and its following cards: • NCS1K-PSM • NCS1K-EDFA

Cisco Optical Site Manager supports configuration and management of various NCS 1000 cards.

For detailed information about the supported cards, you can refer to the following topics:

- [Cisco NCS 1014](#)
- [Cisco NCS 1010](#)
- [Cisco NCS 1004](#)
- [Cisco NCS 1001](#)

Open the Card View

Use this task to open the card view.

Before you begin

[Log into Cisco Optical Site Manager](#)

Procedure

-
- Step 1** Click **COSM Topology** in the left panel..
The COSM Topology page appears.
- Step 2** Right-click the card from the Rack view and select **Open Card**.

Alternatively, you can also double-click the card to open the Card view.

Change Admin State for Card Ports

Use this task to change the admin state of the ports on a card.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

- Step 1** Click the **Provisioning** tab.
- Step 2** Click the **Pluggable Port Modules** section to expand it.
- The different ports along with their rates, reach distances, and admin states are displayed.
- Step 3** Click the **Edit** button.
- The fields in the table become editable.
- Step 4** Choose the admin state in the **Admin State** column from the drop-down list and click **Apply**.

Add Card Mode

Table 2: Feature History

Feature Name	Release Information	Description
Additional Card Mode and Trunk Rates for the NCS1K14-2.4T-X-K9 Card	Cisco IOS XR Release 24.3.1	The Select Card Mode page of the Card Configuration Wizard is updated to include the 1.2T Splitted configuration on the Trunk 0 port. You can also use the wizard to configure these trunk rates in the muxponder mode: • 100-GE client traffic for 600-G and 1000-G • 500-G and 900-G

Feature Name	Release Information	Description
Support for NCS 1004 Card and Card Modes	Cisco IOS XR Release 24.3.1	The Card Configuration Wizard now supports configuring these card modes for NCS1K4-OTN-XP cards: • 10G-GREY-MXP • 40x10G-4x100G-MXP You can also use the wizard to configure card mode for the NCS1K4-2-QDD-C-K9 card.
Card Configuration Wizard Enhancements	Cisco IOS XR Release 24.1.1	The Card Configuration Wizard is updated to select the MXP-1K muxponder mode supported by the new NCS1K14-2.4T-X-K9 card.

Cisco Optical Site Manager allows you to configure NCS 1000 line cards in various modes, including Muxponder and Slice configurations. These modes determine how the line card processes data and manages traffic, facilitating efficient client-to-trunk mapping.

How to Add a Card Mode

Perform these steps to add a card mode for a line card:

1. [Select Card Mode, on page 4](#)
2. [Select Trunk and Client Data Rate, on page 6](#)
3. [Add Internal Patch Cords, on page 7](#)
4. [Add Trunk Details, on page 9](#)
5. [Verify Configuration Details, on page 10](#)

Select Card Mode

Use this task to enter into the **Card Configuration Wizard** and select a card mode.

Figure 2: Select Card Mode


Card Configuration Wizard [1-2 NCS1K14-2.4T-X-K9]

This procedure will help you configure the selected card and the card mode, according to the possible combinations

1 Select Card Mode 2 Select Trunk and Client Rate 3 Trunk Details 4 Configuration Recap

No card modes configured yet

MXP-SLICES-1K Add
MXP-SLICES-1K
MXP-1K



Cancel Next

Before you begin

- [Log into Cisco Optical Site Manager](#)

Procedure

- Step 1** Open the **Card Configuration Wizard**.
- To open the **Card Configuration Wizard** from Rack view, perform these steps:
 - a. Right-click a line card in the Rack view.
 - b. Click **Card Mode**.
 - c. Select **Install**.
 - To open the **Card Configuration Wizard** from Card view, perform these steps:
 - a. Click the **Provisioning** tab.
 - b. Click the **Card Modes** section to expand it.
 - c. Click the **Add Card mode** button.

- Step 2** Select the card mode from the drop-down list and click **Add**.

Table 3: Supported Card Modes

For details on card modes for	refer to
NCS 1014	Configuring the Card Mode on NCS 1014 Line Cards
NCS 1004	Configuring the Card Mode on NCS 1004 Line Cards

Step 3 Click **Next**.

What to do next

Select the [Select Trunk and Client Data Rate](#).

Select Trunk and Client Data Rate

Use this task to select the trunk and client port data rates in the **Card Configuration Wizard**.

Figure 3: Select Trunk and Client Data Rate

Before you begin

- [Select Card Mode](#), on page 4

Procedure

Step 1 Select the trunk data rate from the **Trunk** drop-down list. The **Client** drop-down lists are displayed.

Step 2 Select the client data rates.

Table 4: Client Data Rate Options

To configure	Perform these steps
Mixed client data rate for client ports	a. From the Client drop-down lists, select Mixed Rate. Mixed rate configuration information message is displayed. b. Close the message box. c. Right-click the lane in the line card image and select the data rate from the available drop-down lists.
Same client data rate for all client ports	From the Client drop-down lists, select the same data rate for each client port.

Step 3 Click **Next**.

What to do next

- If optical type is configured as *txp*, see [Add Trunk Details, on page 9](#).
- If optical type is configured as *roadm*, see [Add Internal Patch Cords, on page 7](#).

Add Internal Patch Cords

Use this task to add Internal Patch Cords (IPC) in the **Card Configuration Wizard**.



Note Adding IPC page is only available if optical type is configured as *roadm*.

Figure 4: Add Internal Patch Cords

The screenshot shows the 'Card Configuration Wizard' window with the title '6-0 NCS1K4-2-QDD-C-K9'. It features a progress bar with five steps: 1. Select Card Mode, 2. Select Trunk and Client Rate, 3. Add IPC (current step), 4. Trunk Details, and 5. Configuration Recap. Below the progress bar, the 'From' section has a 'Port' dropdown set to '6/0/1'. The 'To' section includes a 'Type' dropdown set to 'Passive Unit', a 'UID' dropdown set to '3 [R1-P9] (NCS1K-MD-32E-C)', and a 'Port' dropdown set to '3/CH-5-RX'. An 'Adding' section shows a list with '6/0/0 ↔ 1/0/LINE' and a close icon. On the right, there are 'Reset' and '+ Add' buttons. At the bottom right, there are 'Back' and 'Next' buttons.

Before you begin

- [Select Trunk and Client Data Rate, on page 6](#)

Procedure

Step 1 Select the port from the **Port** drop-down list in the **From** section.

Step 2 In the **To** section, perform these steps:

Table 5: IPC Drop-down Lists Displayed Based on Device Type

To create an IPC for a	Select these drop-down lists
• Chassis • Passive Chassis	• UID • Slot • Port
Passive Unit	• UID • Port

Step 3 Click the **Add** button.

Step 4 (Optional) Do one of the following to remove internal patch cord:

- To remove a single internal patch cord, click the cross (x) icon next to the internal patch cord under the **Adding** section.

- To remove all added internal patch cords, click the **Reset** button.

Step 5 Click **Next**.

What to do next

Add the [Add Trunk Details](#) to configure the interfaces.

Add Trunk Details

Use this task to add select the trunk details in the **Card Configuration Wizard** to configure the interfaces.

Figure 5: Add Trunk Details

Card Configuration Wizard [1-2 NCS1K14-2.4T-X-K9]

This procedure will help you configure the selected card and the card mode, according to the possible combinations

1 Select Card Mode 2 Select Trunk and Client Rate 3 **Trunk Details** 4 Configuration Recap

Select trunk for configure the interfaces: 1/2/7

Optical Channel

Admin State: IS Frequency: 193.1 Rate: 500G

Baud Rate: Bits Per Symbol:

Back Next

Before you begin

- If optical type is configured as *roadm*, make sure to [Add Internal Patch Cords, on page 7](#)
- If optical type is configured as *txp*, make sure to [Select Trunk and Client Data Rate, on page 6](#)

Procedure

- Step 1** Select the trunk port from the **Select trunk for configure the interfaces** drop-down list.
- Step 2** In the **Optical Channel** section, select the **Admin State**, **Frequency**, **Baud Rate**, **Bits Per Symbol** and **Rate** from their corresponding drop-down lists.

What to do next

[Verify Configuration Details, on page 10](#)

Verify Configuration Details

In the **Configuration Recap** window, verify the selected configuration in the various windows of the **Card Configuration Wizard**.

Figure 6: Verify Configuration Details

Card Configuration Wizard [1-2 NCS1K14-2.4T-X-K9]

This procedure will help you configure the selected card and the card mode, according to the possible combinations

1 Select Card Mode 2 Select Trunk and Client Rate 3 Trunk Details 4 Configuration Recap

CardMode: MXP-1K

Trunks

Port: 0 | Pluggable Type: CIM8-L-K9 Port: 7 | Frequency: 193.1 | Rate: 500G | Admin State: IS | Bits Per Symbol: 2

Clients

Port: 1-1 | Rate: 100GE Port: 2 | Pluggable Type: QDD-4X100G-FR-S | Rate: 400GE Port: 4 | Pluggable Type: QDD-400G-FR4-S | Rate: 4x100GE

Back Finish

Before you begin

[Add Trunk Details, on page 9](#)

Procedure

-
- Step 1** Click to expand the *Trunk* and *Client* sections to verify the configured details.
- Step 2** Click **Finish** to add the card mode.
-

Edit Card Mode

Use this task to edit the trunk and client port data rates for a card mode configured on a card.

Before you begin

- [Log into Cisco Optical Site Manager](#)

Procedure

-
- Step 1** Open the **Card Configuration Wizard** using any of these options.
- To open the **Card Configuration Wizard** from Rack view, perform these steps:
 - a. Right-click a line card in the Rack, Chassis or Card view.
 - b. Click **Card Mode**.
 - c. Select **Edit**.
 - To open the **Card Configuration Wizard** from Card view, perform these steps:
 - a. Click the **Provisioning** tab.
 - b. Click the **Card Modes** section to expand it.
 - c. Select the check box corresponding to the card mode you want to edit and click the **Edit card mode** button.
- Step 2** Select the trunk and client data rates.
- For more details about selecting trunk and client data rates, see [Select Trunk and Client Data Rate, on page 6](#).
-

Provision Trail Trace Monitoring

This task allows you to configure the parameters for trail trace monitoring.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

-
- Step 1** Click the **Provisioning** tab.
- Step 2** Click the **Trail Trace Monitoring** section to expand it.
- Step 3** From the **Level** drop-down list, choose **Section** to list all the OTU interfaces and **Path** to list all the ODU interfaces.
- Step 4** Modify required settings as described in the following table.

Table 6: Trail Trace Identifier Settings

Parameter	Description	Options
Port	Displays the port number.	—
Legacy Tx-TTI	Displays the current transmit string of the TTI or sets a new transmit string.	0-64 bytes
Legacy Expected-TTI	Displays the current expected string or sets a new expected string.	0-64 bytes
Legacy Rx-TTI	(Display only) Displays the current received string.	—
Alarm Propagation	If a discrepancy is detected between the expected and received trace, it raises an alarm. If set to True, the alarm is propagated downstream to the other nodes.	• True • False
Detect Mode	Sets the mode for detecting the discrepancy between the expected and received trace.	• Disabled • Enabled • SAPI • DAPI • SAPI-and-DAPI

Step 5 Click **Apply**.

Provision ODU Interfaces

Use this task to modify the ODU settings of the card.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

- Step 1** Click the **Provisioning** tab.
- Step 2** Click the **ODU Interfaces** section to expand it.
- Step 3** Modify required settings described in the following table.

Table 7: ODU Interface Settings

Parameter	Description	Options
Port	(Display only) Displays the port name.	—
Description	Displays the description of the port.	—
SF BER	Sets the signal fail (SF) bit error rate (BER).	Only 1E-5 is allowed.
SD BER	Sets the signal degrade (SD) bit error rate (BER).	• 1E-5 • 1E-6 • 1E-7 • 1E-8 • 1E-9
Squelch Mode	When a LOS is detected on the near-end client input, the far-end client laser is turned off. It is said to be squelched. Alternatively, an AIS can be invoked. The OTU2-XP card supports Squelch Mode parameter when the card mode is set as Regenerator. The valid values are Squelch and AIS. When the card mode is set to Transponder or Mixed, the Squelch Mode cannot be changed and the parameter defaults to the Squelch value.	• Squelch • AIS
SquelchHold Off Time	Sets the period in milliseconds that the client interface waits for resolution of issues on the trunk side. The client squelching starts after this period.	• Disable • 50 ms • 100 ms • 250 ms • 500 ms
Service State	Displays the service state.	—
Rate	Displays the rate.	—

Step 4 Click **Apply**.

Provision OTU Interfaces

Use this task to modify the OTU settings of the card.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

- Step 1** Click the **Provisioning** tab.
- Step 2** Click the **OTU Interfaces** section to expand it.
- Step 3** Modify required settings described in the following table.

Table 8: OTU Interface Settings

Parameter	Description	Options
Port	(Display only) Displays the port name.	—
Description	Displays the description of the port.	—
HD FEC	Sets the OTN lines to forward error correction (FEC).	• DISABLE_FEC • EFEC • EFEC_14 • EFEC_17 • HG_FEC_20 • HG_FEC_7 • STANDARD_FEC
Interop Mode	Enables interoperability between line cards and other vendor interfaces.	• InteropNone • InteropEnable
Supports Sync	(Display only) Displays the SupportsSync card parameter. If the value is true, the card is provisioned as a NE timing reference.	• true • false
Sync Msg In	Sets the EnableSync card parameter. Enables synchronization status messages (S1 byte), which allow the node to choose the best timing source.	• true • false

Parameter	Description	Options
Admin SSM In	Overrides the synchronization status message (SSM) and the synchronization traceability unknown (STU) value. If the node does not receive an SSM signal, it defaults to STU.	• G811 • STU • G812T • G812L • SETS • DUS • PRS • ST2 • ST3E • ST3 • SMC • ST4 • RES • STU_SDH • DUS_SDH • SSM_FAILED • RES_SDH • TNC
Rate	Displays the rate.	—
Service State	Displays the service state.	—

Step 4 Click **Apply**.

Provision Ethernet Interfaces

Use this task to provision the parameters for the Ethernet interfaces of the card.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

-
- Step 1** Click the **Provisioning** tab.
- Step 2** Click the **Ethernet Interfaces** section to expand it.
- Step 3** Click the **Edit** button.
- Step 4** Modify any of the Ethernet settings as described in the following table. These parameters appear depends on the card mode.
- Step 5** Click **Apply**.
-

Table 9: Card Ethernet Settings

Parameter	Description	Options
Port	(Display only) Displays the port number	—
Description	Description of the port.	—
Speed	Sets the expected port speed.	—
MTU	Sets the maximum size of the Ethernet frames that are accepted by the port. The port must be in OOS/locked state.	Numeric. Default: 1548 Range 64–9700
FEC	Sets the FEC mode. When set to On, FEC is enabled.	• NA • Auto (default) • On • Off
Duplex	Sets the expected duplex capability of ports.	• Full • Half
Mapping	Sets the mapping mode.	• CBR • GFP
Auto Negotiation	Enables or disables autonegotiation on the port.	• Disabled • Enabled
Squelch Mode	Sets the squelch mode.	• Disable • Squelch • LF

Parameter	Description	Options
Squelch Hold Off Time	Sets the period in milliseconds that the client interface waits for resolution of issues on the trunk side. The client squelching starts after this period or local fault is sent.	• Disable • 50 ms • 100 ms • 250 ms • 500 ms
Service State	Displays the service status of the port.	

Provision Optical Channels

Use this task to configure the parameters for the optical channels on the card.

Before you begin

Table 10: Feature History

Feature Name	Release Information	Description
Optical Channel Section Enhancements	Cisco IOS XR Release 24.3.1	The Optical Channel section is now updated to allow the configuration of the Target Power and Fixed Ratio parameter values.

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

-
- Step 1** Click the **Provisioning** tab.
 - Step 2** Click the **Optical Channel** section to expand it.
 - Step 3** Click the **Edit** button and modify required parameters in the table.
 - Step 4** Click **Apply**.

This table describes the parameters displayed in the **Optical Channel** section.

Table 11: Optical Channel Settings

Parameter	Description	Options
Port	(Display only) Displays the port name.	—

Parameter	Description	Options
Reach	Indicates the distance from one node to another node.	• Auto Provision • List of reach values
SD FEC	Indicates the standard FEC.	• SD_FEC_15_DE_OFF • SD_FEC_15_DE_ON • SD_FEC_20 • SD_FEC_25_DE_OFF • SD_FEC_25_DE_ON • SD_FEC_7
Tx Power (dBm)	Sets the Tx power on the trunk port.	The range is –10.0 to 0.25 dBm.
PSM Info	When enabled on a TXP or MXP trunk port that is connected to a PSM card, it allows fast switching on the cards.	• NA • Enable • Disable
Frequency (THz)	Sets the frequency in THz	-
Wavelength (nm)	Displays the wavelength is set based on the Frequency .	-
Tx Shutdown	(Display only)	• true • false
Width (GHz)	(Display only)	-
CD (Working Range) High (ps/nm)	Sets the threshold for maximum chromatic dispersion.	-
CD (Working Range) Low (ps/nm)	Sets the threshold for minimum chromatic dispersion.	-

Parameter	Description	Options
Admin State	Sets the port service state unless network conditions prevent the change.	• Unlocked (ETSI)/ IS (ANSI) • Locked, disabled (ETSI)/ OOS, DSBLD (ANSI) • Locked, maintenance (ETSI)/ OOS, MT (ANSI) • Unlocked, automaticInService (ETSI)/ IS, AINS (ANSI)
Service State	Displays the service state.	—
Target Power	Sets the Rx VOA target power. Note You cannot configure this parameter if Fixed Ratio is already configured.	• Valid range: -19 dBm to +3 dBm • Default value: -2.0 dBm
Fixed Ratio	Sets the Rx VOA fixed ratio. Note You cannot configure this parameter if Target Power is already configured.	• Valid value: 0.0 dBm
Rate	Displays the rate.	—

Change Trunk Port Parameters

You can directly change the trunk port parameters from the Rack, Chassis, or Card view. These parameter values can then be viewed in the **Optical Channel** section of the **Provisioning** tab.

Use this task to configure the trunk port parameters, such as admin state, frequency, baud rate, and bits per symbol.

Before you begin

- [Log into Cisco Optical Site Manager](#)

Procedure

- Step 1** Right-click the trunk ports in the Rack, Chassis, or Card view and click **Change Trunk Details**.

- The **Change Configuration** dialog box is displayed.
- Step 2** Select the **Admin State** to change the admin status of the trunk port to Out of Service or Automatic in Service.
- Step 3** Enter or select the frequency in the **Frequency** field.
- The Wavelength of the trunk port is automatically selected based on the frequency configured.
- Step 4** Enter or select the **Baud Rate** or **Bits Per Symbol**.
- For more details about these fields, see the table [Table 11: Optical Channel Settings, on page 17](#)
- Step 5** Click **Apply**.

The parameter values are saved and displayed in the **Optical Channel** section of the **Provisioning** tab.

Provision Optical Threshold Settings

Use this task to set the threshold crossing alert values on the card.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

-
- Step 1** Click the **Provisioning** tab.
- Step 2** Click the **Optics Thresholds** section to expand it.
- Step 3** Choose the type of threshold that you want to change, *15 Min* or *24 Hour*.
- Step 4** Click **Add Optical Threshold** button.
- New Optical Threshold** dialog box is displayed.
- Step 5** In the **New Optical Threshold** dialog box, add these details:
- Select the **Interface** from the drop-down list.
 - Select **Granularity** from the drop-down list to set the threshold crossing alert for 15-minute or 24-hour interval.
 - Select **Location** from the drop-down list.
 - Select **Direction** from the drop-down list.
 - Select the performance monitoring type from the **PM Type** from the drop-down.
 - Select the parameter for which you want to set the threshold value from the **PM Type Extension** drop-down list.

Table 12: Performance Monitoring Parameters

Use this parameter	to
amplifierTilt	configure the thresholds for ingress or egress amplifier tilt.

Use this parameter	to
amplifierGain	configure the thresholds for ingress or egress amplifier gain.
opticalPower	configure the thresholds for total Rx or Tx power.
opticalPowerOSC	configure the thresholds for total Rx or Tx OSC power.
opticalPowerBackReflection	configure thresholds for optical power back reflection.
opticalPowerBackReflectionRatio	
Raman - 1	

g) Enter the minimum threshold value in the **Low** field and the maximum threshold value in the **High** field.

Step 6 Click **Apply**.

Provision G.709 Thresholds

Use this task to provision the G.709 PM thresholds for the OTN ports.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

Step 1 Click the **Provisioning** tab.

Step 2 Click the **G.709 Thresholds** section to expand it.

Step 3 Choose the value for the G.709 PM thresholds, and click **Apply**.

You can set the thresholds for Near End or Far End, for 15 minutes or 1 day intervals, or for SM (OTUk) or PM (ODUk).

Table 13: G.709 PM Thresholds

Parameter	Description
ES	Errored Seconds shows the number of errored seconds recorded during the PM time interval.

Parameter	Description
SES	Severely Errored Seconds shows the severely errored seconds recorded during the PM time interval.
UAS	Unavailable Seconds shows the unavailable seconds recorded during the PM time interval.
BBE	Background block error shows the number of background block errors that are recorded during the PM time interval.
FC	Failure Counter shows the number of failure counts recorded during the PM time interval.

Provision FEC Thresholds

Use this task to provision the FEC thresholds for the card.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

- Step 1** Click the **Provisioning** tab.
- Step 2** Click the **FEC Thresholds** section to expand it.
- Step 3** Choose the value for the FEC PMs and click **Apply**.

You can set the FEC thresholds for 15 minutes or one-day intervals.

The possible PM types are:

- BIT-EC—Sets the value for bit errors corrected.
- UNC-WORDS—Sets the value for uncorrectable words.

Provision RMON Thresholds

Use this task to provision the RMON thresholds on the control card.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

-
- Step 1** Click the **Provisioning > RMON Thresholds** tabs.
- Step 2** Click the + button.
- The Create RMON Threshold dialog box appears.
- Step 3** From the **Port ID** drop-down list, choose the port number.
- Step 4** From the **Variable** drop-down list, choose a variable.
- Step 5** From the **Alarm Type** drop-down list, indicate whether the event is triggered by the rising threshold, falling threshold, or both thresholds.
- The available options are **Rising Threshold**, **Falling Threshold**, and **Rising and Falling Threshold**.
- Step 6** From the **Sampling Type** drop-down list, choose either **Relative** or **Absolute**.
- Relative** restricts the threshold to use the number of occurrences within the user-set sample period.
- Absolute** sets the threshold to use the total number of occurrences, regardless of the time period.
- Step 7** Enter the appropriate number of seconds in the **Sampling Period** field.
- Step 8** Enter the appropriate number of occurrences in the **Rising Threshold** field.
- For a rising type of alarm, the measured value must move from below the falling threshold to above the rising threshold. For example, if a network is running below a rising threshold of 1000 collisions every 15 seconds and a problem causes 1001 collisions in 15 seconds, the excess occurrences trigger an alarm.
- Step 9** Enter the appropriate number of occurrences in the **Falling Threshold** field.
- In most cases, a falling threshold is set lower than the rising threshold.
- Step 10** Click **Apply**.
-

Provision Loopback

Use this task to provision loopback on the card.



Caution This task is traffic-affecting.

Before you begin

- [Log into Cisco Optical Site Manager](#)

- [Open the Card View, on page 2](#)
- Perform the loopback configuration only in the maintenance service state. To place the trunk ports in the Locked, maintenance state, see [Provision Optical Channels, on page 17](#).

Procedure

-
- Step 1** Click the **Maintenance** tab.
- Step 2** Click the **Loopback** section to expand it.
- Step 3** From the **Loopback Type** drop-down list, choose Terminal, Facility, Terminal-Drop, or Facility-Drop for each port required.
- Step 4** Select the admin state from the **Admin State** drop-down list.
- Step 5** Click **Apply**.
-

Provision Optical Safety

Use this task to provision the optical safety parameters for cards.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

-
- Step 1** Click the **Maintenance** tab.
- Step 2** Click the **Live Data** section to expand it.
- Step 3** Modify required settings described in the following table:

Table 14: Optical Safety Parameters for Cards

Parameter	Description	Options
Interface	(Display only) Displays the port name, port type, and direction.	—
Supported Safety	(Display only) Displays the supported safety mechanism.	• ALS for line cards and control cards. • ALS-OSRI for amplifier cards.

Parameter	Description	Options
ALS Mode	Automatic laser shutdown mode. The ALS mode is disabled for RX ALS interfaces.	From the drop-down list, choose one of the following: • ALS-Disabled—Deactivates ALS. • Automatic Restart—(Default) ALS is active. The power is automatically shut down when needed, and it automatically tries to restart using a probe pulse until the cause of the failure is repaired. • Manual Restart
OSRI	Optical safety remote interlock. The default value is OSRI-OFF. When set to OSRI-ON, the TX output power is shut down. Note OSRI configuration is not supported on the transponder and muxponder cards.	From the drop-down list, choose one of the following: • OSRI-OFF • OSRI-ON
ALS Status	(Display only) ALS status of the device.	• Working • Shutdown
Recovery Pulse Interval (Sec.)	Displays the interval between two optical power pulses.	60 to 300 seconds.
Recovery Pulse Duration (Sec.)	Displays the duration of the optical power pulse that begins when an amplifier restarts.	2 to 100 seconds
Manual Restart	Triggers manual restart action for the ALS interface. However, manual restart does not happen if Mode is set to Automatic Restart or Disabled.	—

Step 4 Click **Apply** to save the changes.

Enable Attention LED

Table 15: Feature History

Feature Name	Release Information	Description
Enable Attention LED on Demand	Cisco IOS XR Release 24.1.1	You can now turn on the Attention LED by selecting <i>true</i> from the Attention Led for drop-down list in the Provisioning tab. The Attention LED is available for specific ports, chassis, line cards, and controller cards. Once turned on, it will help field engineers quickly identify the relevant device at the installation location for maintenance or troubleshooting.

The Attention LED can be enabled on specific ports, chassis, line cards, or controller cards. This is particularly helpful for troubleshooting and maintenance by locating the device in its installed location.

Before you begin

- [Log into Cisco Optical Site Manager](#)
- [Open the Card View, on page 2](#)

Procedure

Step 1 Click the **Provisioning** tab.

Step 2 Click the **Attention Led** section to expand it.

Step 3 Perform any one of the following steps:

- To turn on the Attention LED of a chassis provisioned on the rack, perform these steps:
 1. Select *true* from the **Attention Led for** drop-down list and click **Apply**.
- To turn on the Attention LED of all the ports of a line card, perform these steps:
 1. Select *true* from the **Attention Led for** drop-down list and click **Apply**.
- To turn on the Attention LED of a specific port of a line card, perform these steps:
 1. Click **Edit**.
 2. Select *true* corresponding to the port you want to blink the Attention LED and click **Apply**.

Step 4 To turn off the Attention LED for a chassis or port, select *false* from the drop down list and click **Apply**.
