



Configure Cisco Optical Site Manager

This chapter outlines the configuration tasks for Cisco Optical Site Manager, covering both standalone and high availability modes.

- [Configure Cisco Optical Site Manager in standalone mode, on page 1](#)
- [High availability for NCS 1000, on page 3](#)
- [Configure Cisco Optical Site Manager in high availability on NCS 1000, on page 3](#)
- [Deployment models for HA in Cisco Optical Site Manager, on page 6](#)

Configure Cisco Optical Site Manager in standalone mode

Cisco Optical Site Manager can be configured in standalone mode on a single NCS 1010 or NCS 1014 controller card. This mode is useful for deployments where local management via a GUI is needed, or where interaction with third-party controllers is required without full network-wide SDN automation.

The configuration involves setting up Cisco Optical Site Manager interfaces, defining management interface parameters, and establishing user credentials for access.

Before you begin

Ensure that these configurations are enabled before configuring Cisco Optical Site Manager in standalone mode:

- NETCONF over SSH is enabled.
- Configure static routes on peer devices.

Follow these steps to configure Cisco Optical Site Manager in standalone mode:

Procedure

- | | |
|---------------|---|
| Step 1 | Enter into the IOS XR and COSM configuration mode using the configure terminal and cosm commands.

Example:
<pre>RP/0/RP0/CPU0:ios#configure terminal RP/0/RP0/CPU0:ios(config)# cosm</pre> |
| Step 2 | Configure the interface of the device running the Cisco Optical Site Manager by using mgmt-interface-name MgmtEth R/S/I/P command. |

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)# mgmt-interface-name MgmtEth 0/RP0/CPU0/0
```

Step 3 Configure the username using the **user-name** *user name* command.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)# user-name cisco
```

Note

The username must match the username of the host device.

Step 4 Configure the password using the **user-password** *password* command.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)# user-password ***
```

Note

The password must match the password of the host device.

Step 5 (Optional) From R24.3.1, enable auto-onboarding of the Cisco Optical Site Manager host devices.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)#cosm auto-onboard enable
```

Step 6 Commit the changes and exit the configuration modes using the **commit** and **end** commands.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm) commit
RP/0/RP0/CPU0:ios(config-cosm) end
```

Step 7 Verify the configuration using the **show running-config cosm** command.

Example:

This example shows the standalone Cisco Optical Site Manager configuration.

```
RP/0/RP0/CPU0:ios#show running-config cosm
Fri Oct 18 12:53:47.056 UTC
cosm
  mgmt-interface-name Loopback1
!
```

The configured *user-name* and *user-password* are not displayed in the output of the **show running-config cosm** command.

Cisco Optical Site Manager is configured in the standalone mode.

What to do next

[Enable or disable Cisco Optical Site Manager north-bound interfaces](#)

High availability for NCS 1000

Cisco Optical Site Manager High Availability (HA) provides continuous management and operational resilience for Cisco optical devices. By deploying two instances, one as Active and the other as Standby, HA ensures that device management remains uninterrupted even if one instance fails.

How does Cisco Optical Site Manager high availability ensure operational continuity?

Cisco Optical Site Manager High Availability (HA) provides a robust solution for managing device operations by utilizing dual application instances and specialized network interfaces.

The main features of Cisco Optical Site Manager high availability include:

- Two devices must be able to communicate with each other, allowing their respective Cisco Optical Site Manager instances to coordinate application roles (active or standby) and manage operations.
- Each device requires a Cisco Optical Site Manager management interface configured with the same IP address, starting in a shutdown state. This interface automatically transitions between UP and DOWN states based on whether the device is active or standby.
- A dedicated Cisco Optical Site Manager redundancy interface is used to establish the high availability communication channel and typically serves as the device's management interface.
- When in the active role, Cisco Optical Site Manager binds the HA server to the redundancy interface's IP address on port 5454.
- When in the Standby role, Cisco Optical Site Manager connects to the peer's redundancy interface IP address on port 5454 to communicate with the active instance.

HA roles and interfaces

- **Active role:** manages all device operations and binds the HA server to its redundancy interface and port.
- **Standby role:** Monitors the active instance and connects to the peer's redundancy IP and port. It is ready to take over if needed.
- **Redundancy interface:** network interface used solely for HA communication between Cisco Optical Site Manager instances.
- **Management interface:** interface with the same IP address on both devices, managed automatically depending on the instance role.

Configure Cisco Optical Site Manager in high availability on NCS 1000

Configure High Availability (HA) on Cisco Optical Site Manager is to enable fast recovery from faults in the optical transport network and to maintain service continuity by switching to standby components when active ones fail.

Cisco Optical Site Manager HA configuration requires two devices to have an interface configured as the management interface.

- `cosm mgmt-interface-name`: This interface must be configured with same IP address. This interface must be configured in a shutdown state and will automatically transition between UP and DOWN states based on the role (Active or Stand-By) assigned by the application.
- `cosm redundancy interface-name`: This interface must be configured with the redundancy interface and is used to establish the high availability communication channel and is typically the interface used for device management.

Before you begin

1. Before activating Cisco Optical Site Manager in HA configuration, verify that these parameter values are same on both host devices, if configured.
 - *optical-type (optional)*
 - *auto-onboard (optional)*
 - *netconf (optional)*
 - *restconf (optional)*
 - *webui (optional)*
 - *user-name*
 - *user-password*

Follow these steps to configure Cisco Optical Site Manager HA on a NCS 1010 or NCS 1014 device:

Procedure

-
- Step 1** Enter into the IOS XR and Cisco Optical Site Manager configuration modes.

Example:

```
RP/0/RP0/CPU0:ios#configure terminal
RP/0/RSP0/CPU0:ios(config)# cosm
```

- Step 2** Configure the gateway IP address.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)# redundancy gateway-ip 10.0.2.1
```

- Step 3** Configure the peer IP address.

This is the IP address of the peer device running the Cisco Optical Site Manager HA instance.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)# redundancy peer-ip 10.0.1.12
```

For releases 24.x.x and 25.x.x, verify that the *redundancy interface-name* IP address and the *redundancy peer-ip* address are not substrings of each other. For example, configuring 10.0.1.1 as the *redundancy interface-name* and 10.0.1.10 or 10.0.1.101 as the *redundancy peer-ip* (or vice-versa) causes Cisco Optical Site Manager HA to fail during startup.

- Step 4** Configure the HA interface name.

This is the interface of the device running the Cisco Optical Site Manager HA instance, which is used for all HA traffic.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)# redundancy interface-name MgmtEth 0/RP0/CPU0/2
```

Step 5 Commit the changes and exit all configuration modes.

Example:

```
RP/0/RP0/CPU0:ios(config-cosm)# commit
RP/0/RP0/CPU0:ios(config-cosm)# end
```

Step 6 Activate the HA application.

Example:

```
RP/0/RP0/CPU0:ios# cosm activate
```

Step 7 Verify the HA configuration and check the device status on both host devices.

Example:

The entry highlighted in bold show the status of the active and standby device.

```
//Check status on active device//
RP/0/RP0/CPU0:ios#show cosm status

COSM state: APP_ACTIVATED
AppMgr app state: ACTIVATED
AppMgr container state: RUNNING
Container status: Up 4 days
Last error: No error
COSM version: 24.3.1.D0151
Redundancy role: ACTIVE (connected standby 10.0.123.123-COSM)

//Check status on standby device//
RP/0/RP0/CPU0:ios#show cosm status

COSM state: APP_ACTIVATED
AppMgr app state: ACTIVATED
AppMgr container state: RUNNING
Container status: Up 4 days
Last error: No error
COSM version: 24.3.1.D0151
Redundancy role: STANDBY (connected active 10.11.111.111-COSM)
```

You can view the active and standby application status in the **Device Software** section of the **Software Manager** menu.



Note If the HA node is on loopback, the MAC address of the HA device is displayed as **N/A** in the **Devices** section of the **Device Configuration** page.

This example explains how to configure Cisco Optical Site Manager HA on a NCS 1010 or NCS 1014 device.

```
RP/0/RP0/CPU0:ios#configure terminal
RP/0/RP0/CPU0:ios(config)# cosm
```

```
RP/0/RP0/CPU0:ios(config-cosm)# redundancy gateway-ip 10.0.2.1
RP/0/RP0/CPU0:ios(config-cosm)# redundancy peer-ip 10.0.1.12
RP/0/RP0/CPU0:ios(config-cosm)# redundancy interface-name MgmtEth 0/RP0/CPU0/2
RP/0/RP0/CPU0:ios(config-cosm)# commit
RP/0/RP0/CPU0:ios(config-cosm)# end
RP/0/RP0/CPU0:ios# cosm activate
```

What to do next

[Enable or disable Cisco Optical Site Manager north-bound interfaces](#)

HA commands for Cisco Optical Site Manager

These commands are used to configure HA in Cisco Optical Site Manager on a NCS 1000 device.

Command	Description
configure	Enters global configuration mode.
cosm user-name <username>	Configures Cisco Optical Site Manager application username.
cosm user-password <password>	Configures Cisco Optical Site Manager application password.
cosm mgmt-interface-name <type> <number>	Configures the Cisco Optical Site Manager management interface. All Cisco Optical Site Manager NBI services (web UI, NETCONF, RESTCONF) are available on this interface.
cosm redundancy interface-name <type> <number>	Configures Cisco Optical Site Manager high availability interface. The interface is used to communicate with the peer device.
cosm redundancy peer-ip <IP-address>	Configures the IP address of the peer device, where other Cisco Optical Site Manager is running.
cosm redundancy gateway-ip <IP-address>	Configures the IP address of a target device that is always reachable by both devices hosting Cisco Optical Site Manager in high availability. Configuring the same gateway IP on both devices is strongly recommended. Cisco Optical Site Manager uses this target device to perform checks in certain high availability scenarios. The target device must be different from the cosm redundancy peer-ip . The target device may be the subnet gateway, the multilayer switch connecting the two devices, or another suitable device.
commit	Commits the changes.
end	Exits the global configuration mode.

Deployment models for HA in Cisco Optical Site Manager

Cisco Optical Site Manager supports several deployment models for implementing high availability (HA), each with distinct configuration requirements, advantages, and dependencies on the Data Communication Network (DCN) architecture and local site availability. Each model:

- analyzes possible deployment scenarios, detailing device connections and configurations,
- covers routing protocols in use and information on any additional devices involved.

Cisco Optical Site Manager supports these deployment models:

- **Dual-homing deployment with devices connected to DCN:** This model involves connecting devices to the DCN using a dual-homing setup.
- **Single-homing deployment with devices connected to DCN:** This model utilizes a single-home connection for devices to the DCN.
- **Deployment with devices interconnected and managed remotely:** In this model, devices are interconnected and managed remotely through the Optical Service Channel (OSC).
- **Deployment with devices interconnected with redundancy and managed remotely:** This model extends the previous one by incorporating redundancy for devices interconnected and remotely managed via OSC.

Dual-homing deployment with devices connected to DCN

This deployment model ensures that Cisco Optical Site Manager can always communicate with its peer, routing traffic through an alternative interface, cable, or switch if one fails.

Requirements for the dual-homing deployment

This HA deployment model requires following conditions:


- Both Cisco Optical Site Manager redundancy and management interfaces must be configured as Loopback interfaces.
- The IP addresses assigned to the MgmtEth interfaces of the devices are typically part of a private subnet, isolated under the Top-of-Rack (ToR) switches.
- Loopback IP addresses are distributed within the Data Communication Network (DCN) and must be reachable from Cisco Optical Network Controller.
- Loopback 0 interfaces are designated as Cisco Optical Site Manager management interfaces.
- Loopback 1 interfaces serve as Cisco Optical Site Manager redundancy interfaces, also providing direct access to the devices.

Implementing this deployment model requires specific network configurations and routing considerations:

- ToR switches must advertise the default route to downstream devices. This can be achieved by configuring a static route on the devices or by using 'default-information originate' with OSPF on the switches.
- The two devices hosting Cisco Optical Site Manager in high availability must have a static route or routing protocol configuration to reach the peer's Cisco Optical Site Manager redundancy interface (for example, Loopback 1 interface) using the VRRP IP as the next hop.
- ToR switches should implement VRRP and channel aggregation on multiple ports towards the peer switch for enhanced redundancy.

This figure explains the connections diagram of two-degrees node deployment model with devices connected to DCN in dual-homing.

Figure 1: Conceptual Explanation of High Availability Deployment for Devices Connected to DCN in a Dual-Homing Model



IP addressing schema for devices connected to DCN in dual-homing

This table details the IP addressing for the devices connected to DCN in dual-homing deployment model, with MgmtEth interfaces of the devices using the 192.168.1.0/24 subnet and loopback interfaces distributed within the DCN as part of the 10.1.1.0/27 subnet.


Table 1: IP addressing schema for dual-homing deployment

Cisco Optical Site Manager instance	NCS device	NCS device interface	NCS device IP/Mask	Connected to switch	Connected to switch interface
Cisco Optical Site Manager 1	NCS 1000-1	MgmtEth0/RP0/CPU0/0	192.168.1.11/24	Catalyst 9300 (A)	Gil/0/1
		MgmtEth0/RP0/CPU0/1	192.168.1.12/24	Catalyst 9300 (B)	Gil/0/1
		Loopback 0	10.1.1.1/32	—	—
		Loopback 1	10.1.1.11/32	—	—
	NCS 1000-2	MgmtEth0/RP0/CPU0/0	192.168.1.13/24	Catalyst 9300 (A)	Gil/0/2
		MgmtEth0/RP0/CPU0/1	192.168.1.14/24	Catalyst 9300 (B)	Gil/0/2
		Loopback 0	10.1.1.1/32	—	—
		Loopback 1	10.1.1.12/32	—	—
Cisco Optical Site Manager 2	NCS 1000-3	MgmtEth0/RP0/CPU0/0	192.168.1.15/24	Catalyst 9300 (A)	Gil/0/3
		MgmtEth0/RP0/CPU0/1	192.168.1.16/24	Catalyst 9300 (B)	Gil/0/3
		Loopback 0	10.1.1.2/32	—	—
		Loopback 1	10.1.1.13/32	—	—
	NCS 1000-4	MgmtEth0/RP0/CPU0/0	192.168.1.17/24	Catalyst 9300 (A)	Gil/0/4
		MgmtEth0/RP0/CPU0/1	192.168.1.18/24	Catalyst 9300 (B)	Gil/0/4
		Loopback 0	10.1.1.2/32	—	—
		Loopback 1	10.1.1.14/32	—	—

Cisco Optical Site Manager instance	NCS device	NCS device interface	NCS device IP/Mask	Connected to switch	Connected to switch interface
Cisco Optical Site Manager 3	NCS 1000-5	MgmtEth0/RP0/CPU0/0	192.168.1.19/24	Catalyst 9300 (A)	Gil/0/5
		MgmtEth0/RP0/CPU0/1	192.168.1.20/24	Catalyst 9300 (B)	Gil/0/5
		Loopback 0	10.1.1.3/32	—	—
		Loopback 1	10.1.1.15/32	—	—
	NCS 1000-6	MgmtEth0/RP0/CPU0/0	192.168.1.21/24	Catalyst 9300 (A)	Gil/0/6
		MgmtEth0/RP0/CPU0/1	192.168.1.22/24	Catalyst 9300 (B)	Gil/0/6
		Loopback 0	10.1.1.3/32	—	—
		Loopback 1	10.1.1.16/32	—	—

Practical example of devices connected to DCN in dual-homing

This figure provides a practical example of this deployment model, implemented with two Catalyst 9300 switches and two NCS1014 devices.

Figure 2: Deployment model featuring Catalyst 9300 Switches and Active/Standby NCS1014 devices

This example details the configurations for a Dual-Homing HA deployment model of NCS1014 devices connected to a DCN via Catalyst 9300 switches.

Catalyst 9300-A configuration

```
hostname CAT9300-A
fhrp version vrrp v3
ip routing
interface Vlan1
ip address 192.168.1.253 255.255.255.0
ip ospf 1 area 0
vrrp 1 address-family ipv4
address 192.168.1.1 primary
exit-vrrp
interface TenGigabitEthernet1/1/1
no switchport
ip address <Uplink IP> <Uplink mask>
interface TenGigabitEthernet1/1/2
channel-group 1 mode active
interface TenGigabitEthernet1/1/3
channel-group 1 mode active
router ospf 1
router-id 192.168.1.253
default-information originate
ip route 0.0.0.0 0.0.0.0 <Uplink gateway IP>
```

Catalyst 9300-B configuration

```

hostname CAT9300-B
fhrp version vrrp v3
ip routing
interface Vlan1
ip address 192.168.1.254 255.255.255.0
ip ospf 1 area 0
vrrp 1 address-family ipv4
address 192.168.1.1 primary
exit-vrrp
interface TenGigabitEthernet1/1/1
no switchport
ip address <Uplink IP> <Uplink mask>
interface TenGigabitEthernet1/1/2
channel-group 1 mode active
interface TenGigabitEthernet1/1/3
channel-group 1 mode active
router ospf 1
router-id 192.168.1.254
default-information originate
ip route 0.0.0.0 0.0.0.0 <Uplink gateway IP>

```

NCS 1014-A configuration

```

hostname COSM1-NCS1014-A
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600
interface Loopback0
ipv4 address 10.1.1.1 255.255.255.255
shutdown
interface Loopback1
ipv4 address 10.1.1.11 255.255.255.255
interface MgmtEth0/RP0/CPU0/0
ipv4 address 192.168.1.11 255.255.255.0
interface MgmtEth0/RP0/CPU0/1
ipv4 address 192.168.1.12 255.255.255.0
router static
address-family ipv4 unicast
10.1.1.12/32 192.168.1.1
router ospf 1
router-id 10.1.1.11
area 0
interface Loopback0
interface Loopback1
interface MgmtEth0/RP0/CPU0/0
interface MgmtEth0/RP0/CPU0/1
cosm
user-name <device username>
user-password <device password>
redundancy peer-ip 10.1.1.12
redundancy gateway-ip 192.168.1.1
redundancy interface-name Loopback1
auto-onboard enable
mgmt-interface-name Loopback0

```

NCS 1014-B configuration

```

hostname COSM1-NCS1014-B
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600
interface Loopback0
ipv4 address 10.1.1.1 255.255.255.255

```

```

shutdown
interface Loopback1
  ipv4 address 10.1.1.12 255.255.255.255
interface MgmtEth0/RP0/CPU0/0
  ipv4 address 192.168.1.13 255.255.255.0
interface MgmtEth0/RP0/CPU0/1
  ipv4 address 192.168.1.14 255.255.255.0
router static
  address-family ipv4 unicast
    10.1.1.11/32 192.168.1.1
router ospf 1
  router-id 10.1.1.12
  area 0
  interface Loopback0
  interface Loopback1
  interface MgmtEth0/RP0/CPU0/0
  interface MgmtEth0/RP0/CPU0/1
cosm
  user-name <device username>
  user-password <device password>
  redundancy peer-ip 10.1.1.11
  redundancy gateway-ip 192.168.1.1
  redundancy interface-name Loopback1
  auto-onboard enable
  mgmt-interface-name Loopback0

```

Single-homing deployment with devices connected to DCN

This deployment model for utilizes a single Top-of-Rack (ToR) switch and a single Management Ethernet interface for device connectivity.

Requirements for the single-homing deployment

This HA deployment model requires following conditions:

- Devices connect to the network over a single MgmtEth interface with a single cable to a single ToR switch.
- The Cisco Optical Site Manager redundancy interface can match the cabled interface (MgmtEth 0).
- The Cisco Optical Site Manager management interface must be configured as a Loopback interface (Loopback 0).
- IP addresses assigned to the MgmtEth interfaces can be part of a private subnet isolated under the ToR switches.
- The Loopback IP address should be distributed within the Data Communication Network (DCN) and be reachable from CONC.
- Direct access to the devices is always possible through the MgmtEth 0 IP addresses.


This deployment model offers specific operational characteristics and configuration guidelines:

- While a single failure can impact the reachability of a device, Cisco Optical Site Manager configured in high availability remains continuously reachable.
- The address plan and configurations described are specifically focused on the deployment of transponder platforms (e.g., NCS1014) to highlight differences from other deployment models.

- For optical line system platforms (e.g., NCS1010) in a mesh network, where an alternative path to reach the Cisco Optical Site Manager peer device exists via OSC, the address plan and configurations are consistent with models using Loopback interfaces for both Cisco Optical Site Manager redundancy and management interfaces (excluding MgmtEth0/RP0/CPU0/1 configuration if not cabled).

This figure explains the connections diagram of three Cisco Optical Site Manager instances configured in high availability mode on NCS 1000 device with devices connected to DCN in single-homing.

Figure 3: Conceptual explanation of HA deployment for devices connected to DCN in a single-homing model



IP addressing schema for devices connected to DCN in single-homing

This table details the IP addressing for the devices connected to DCN in single-homing deployment model, with the *MgmtEth* interface of the devices in subnet **192.168.1.0/24** and the *Loopback* interface distributed in the DCN as part of the subnet **10.1.1.0/27**.


Table 2: IP addressing schema for single-homing deployment

Cisco Optical Site Manager instance	NCS device	NCS device interface	NCS device IP/Mask	Connected to switch	Connected to switch interface
Cisco Optical Site Manager-1	NCS 1000-1	MgmtEth0/RP0/CPU0/0	192.168.1.11/24	Catalyst 9300	Gi1/0/1
		Loopback 0	10.1.1.1/32	—	—
	NCS 1000-2	MgmtEth0/RP0/CPU0/0	192.168.1.12/24	Catalyst 9300	Gi1/0/2
		Loopback 0	10.1.1.1/32	—	—
Cisco Optical Site Manager-2	NCS 1000-3	MgmtEth0/RP0/CPU0/0	192.168.1.13/24	Catalyst 9300	Gi1/0/3
		Loopback 0	10.1.1.2/32	—	—
	NCS 1000-4	MgmtEth0/RP0/CPU0/0	192.168.1.14/24	Catalyst 9300	Gi1/0/4
		Loopback 0	10.1.1.2/32	—	—
Cisco Optical Site Manager-3	NCS 1000-5	MgmtEth0/RP0/CPU0/0	192.168.1.15/24	Catalyst 9300	Gi1/0/5
		Loopback 0	10.1.1.3/32	—	—
	NCS 1000-6	MgmtEth0/RP0/CPU0/0	192.168.1.16/24	Catalyst 9300	Gi1/0/6
		Loopback 0	10.1.1.3/32	—	—

Practical example of devices connected to DCN in single-homing

This figure provides a practical example of this deployment model, implemented with one Catalyst 9300 switch and two NCS 1014 devices.

Figure 4: Deployment model featuring Catalyst 9300 switch and Active/Standby NCS 1014 devices



This example details the configurations for a single-homing HA deployment model of NCS 1014 devices connected to a DCN via a Catalyst 9300 switch.

Catalyst 9300 configuration

```
hostname CAT9300
ip routing
interface Vlan1
 ip address 192.168.1.1 255.255.255.0
 ip ospf 1 area 0
interface TenGigabitEthernet1/1/1
 no switchport
 ip address <Uplink IP> <Uplink mask>
router ospf 1
 router-id 192.168.1.1
 default-information originate
 ip route 0.0.0.0 0.0.0.0 <Uplink gateway IP>
```

NCS 1014-A configuration

```
hostname COSM1-NCS1014-A
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600
interface Loopback0
 ipv4 address 10.1.1.1 255.255.255.255
```

```

shutdown
interface MgmtEth0/RPO/CPU0/0
ipv4 address 192.168.1.11 255.255.255.0
router ospf 1
router-id 192.168.1.11
area 0
interface Loopback0
interface MgmtEth0/RPO/CPU0/0
cosm
user-name <device username>
user-password <device password>
redundancy peer-ip 192.168.1.12
redundancy gateway-ip 192.168.1.1
redundancy interface-name MgmtEth0/RPO/CPU0/0
auto-onboard enable
mgmt-interface-name Loopback0

```

NCS 1014-B configuration

```

hostname COSM1-NCS1014-B
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600
interface Loopback0
ipv4 address 10.1.1.1 255.255.255.255
shutdown
interface MgmtEth0/RPO/CPU0/0
ipv4 address 192.168.1.12 255.255.255.0
router ospf 1
router-id 192.168.1.12
area 0
interface Loopback0
interface MgmtEth0/RPO/CPU0/0
cosm
user-name <device username>
user-password <device password>
redundancy peer-ip 192.168.1.11
redundancy gateway-ip 192.168.1.1
redundancy interface-name MgmtEth0/RPO/CPU0/0
auto-onboard enable
mgmt-interface-name Loopback0

```

Deployment with devices interconnected and managed remotely via OSC

This deployment model facilitates the management of a remote node, specifically a 2-degrees ROADM, where devices are interconnected without direct Data Communication Network (DCN) connectivity.

Requirements for devices interconnected and managed remotely via OSC

This HA deployment model requires these conditions:

- Cisco Optical Site Manager is configured in high availability mode on the remote node.
- The remote node is reachable over the Optical Service Channel (OSC) from other nodes connected to the customer's DCN.
- Devices within the remote node (e.g., Location 2) achieve DCN reachability through multiple paths over the OSC of different degrees.


- The two devices hosting Cisco Optical Site Manager in high availability are directly interconnected through an Ethernet cable connected to their MgmtEth interfaces.

Implementing this deployment model requires specific interface configurations and routing to ensure high availability and remote manageability, independent of failures.

- Both Cisco Optical Site Manager redundancy and management interfaces must be configured as Loopback interfaces to ensure reachability independent of potential failures.
- IP addresses assigned to the MgmtEth interfaces (used for device interconnection) and GigabitEthernet interfaces must be strategically distributed within the network to support interconnection failures.
- Loopback IP addresses must be distributed within the DCN and be reachable from the Centralized Operations and Network Control (CONC) system.
- The two devices hosting Cisco Optical Site Manager in high availability in the remote location, which are directly interconnected via an Ethernet cable on their MgmtEth interfaces, require a static route or routing protocol configuration.
- This routing configuration must define how to reach the peer's Cisco Optical Site Manager redundancy interface (e.g., Loopback 1 interface) using the peer's MgmtEth interface as the next hop.

This figure shows a network diagram with three Cisco Optical Site Manager instances in three different locations, configured in HA mode on NCS 1000 family devices. The Cisco Optical Site Manager-2 device in the middle is managed as a remote device.

Figure 5: Conceptual explanation of HA deployment for devices interconnected and managed remotely via OSC



IP addressing schema for devices interconnected and managed remotely via OSC

This table details the IP addressing for devices in the managed remotely via OSC deployment model. The *MgmtEth* interfaces are in subnet **192.168.1.12/31**, and the *Loopback* interfaces are distributed in the DCN as part of subnet **10.1.1.0/27**.


Table 3: IP addressing schema for deployment with devices interconnected and managed remotely

Cisco Optical Site Manager instance	NCS device	NCS device interface	NCS device IP/Mask	Connected to NCS device	Connected to NCS device interface
Cisco Optical Site Manager 2	NCS 1010-1	MgmtEth0/RP0/CPU0/1	192.168.1.12/31	Peer NCS 1010	MgmtEth0/RP0/CPU0/1
		GigabitEthernet0/0/0/0	172.18.0.1/31	Neighbor	GigabitEthernet0/0/0/0
		Loopback 0	10.1.1.2/32	—	—
		Loopback 1	10.1.1.13/32	—	—
	NCS 1010-2	MgmtEth0/RP0/CPU0/1	192.168.1.13/31	Peer NCS 1010	MgmtEth0/RP0/CPU0/1
		GigabitEthernet0/0/0/0	172.18.0.2/31	Neighbor	GigabitEthernet0/0/0/0
		Loopback 0	10.1.1.2/32	—	—
		Loopback 1	10.1.1.14/32	—	—

Practical example of deployment with devices interconnected managed remotely via OSC

This figure provides a practical example of this deployment model, implemented with two NCS 1010 devices.

Figure 6: Example of deployment model with two NCS 1010 and Catalyst 93000 configured as 2-degrees ROADM



This example describes the configuration of two NCS 1010 devices deployed as a 2-degree ROADM, interconnected and managed remotely through the OSC.

NCS 1010-A configuration

```
hostname COSM1-NCS1010-A
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600

interface Loopback0
  ipv4 address 10.1.1.2 255.255.255.255
  shutdown

interface Loopback1
  ipv4 address 10.1.1.13 255.255.255.255

interface MgmtEth0/RP0/CPU0/1
  ipv4 address 192.168.1.12 255.255.255.254

interface GigabitEthernet0/0/0/0
  ipv4 address 172.18.0.1 255.255.255.254

router static
  address-family ipv4 unicast
    10.1.1.14/32 192.168.1.13

router ospf 1
  router-id 10.1.1.13
  area 0
  interface Loopback0
  interface Loopback1
  interface MgmtEth0/RP0/CPU0/1
  interface GigabitEthernet0/0/0/0

cosm
  user-name <device username>
  user-password <device password>
  redundancy peer-ip 10.1.1.14
  redundancy gateway-ip <gateway>
  redundancy interface-name Loopback1
  auto-onboard enable
  mgmt-interface-name Loopback0
```

NCS 1010-B configuration

```
hostname COSM1-NCS1010-B
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600

interface Loopback0
  ipv4 address 10.1.1.2 255.255.255.255
  shutdown

interface Loopback1
  ipv4 address 10.1.1.14 255.255.255.255

interface MgmtEth0/RP0/CPU0/1
  ipv4 address 192.168.1.13 255.255.255.254

interface GigabitEthernet0/0/0/0
  ipv4 address 172.18.0.2 255.255.255.254

router static
  address-family ipv4 unicast
    10.1.1.13/32 192.168.1.12
```

```

router ospf 1
  router-id 10.1.1.14
  area 0
  interface Loopback0
  interface Loopback1
  interface MgmtEth0/RP0/CPU0/1
  interface GigabitEthernet0/0/0/0

cosm
  user-name <device username>
  user-password <device password>
  redundancy peer-ip 10.1.1.13
  redundancy gateway-ip <gateway>
  redundancy interface-name Loopback1
  auto-onboard enable
  mgmt-interface-name Loopback0

```

Deployment with devices interconnected with redundancy and managed remotely via OSC

This deployment model describes the management of a remote node, a 2-degrees ROADM, with physical redundancy, where Cisco Optical Site Manager is configured in high availability and reachable over the Optical Service Channel.

Requirements for devices interconnected with redundancy and managed remotely via OSC

This HA deployment model requires these conditions:

- Devices in the remote node are interconnected with physical redundancy and lack direct DCN connectivity.
- Cisco Optical Site Manager instances are configured in high availability, accessible via OSC from other nodes connected to the customer's DCN.
- Devices within the remote node (Location 2) achieve DCN reachability through multiple paths over the OSC with varying degrees.
- Two devices hosting Cisco Optical Site Manager in high availability are directly interconnected through both an Ethernet cable plugged into MgmtEth interfaces and an external switch.
- Cisco Optical Site Manager redundancy and management interfaces are configured as Loopback interfaces to ensure reachability if failures occur.


Implementing this deployment model requires specific interface configurations and routing to ensure high availability and remote manageability, even with physical redundancy.

- Both Cisco Optical Site Manager redundancy and management interfaces must be configured as Loopback interfaces to ensure reachability independent of potential failures.
- IP addresses assigned to the MgmtEth interfaces (used for device interconnection) and GigabitEthernet interfaces must be strategically distributed within the network to support interconnection failures.
- Loopback IP addresses must be distributed within the DCN and be reachable from the Centralized Operations and Network Control (CONC) system.
- The two devices hosting Cisco Optical Site Manager in high availability in the remote location require a static route or routing protocol configuration.

- This routing configuration must define how to reach the redundancy interface for Cisco Optical Site Manager on the peer device (e.g., Loopback 1 interface) using the peer's MgmtEth interface as the next hop.

This figure illustrates the connection diagram of three Cisco Optical Site Manager instances in three different locations, configured in HA mode on NCS 1000 family devices. The device in the middle, Cisco Optical Site Manager-2, is managed as a remote device.

Figure 7: Conceptual explanation of deployment with devices interconnected with redundancy and managed remotely via OSC deployment



IP addressing schema for devices interconnected with redundancy and managed remotely via OSC deployment


This table details the IP addressing for the devices interconnected with redundancy and managed remotely via OSC deployment model, with the *MgmtEth* interfaces of the devices in subnets **192.168.1.0/24** and **192.168.2.12/31** and the *Loopback* interfaces distributed in the DCN as part of the subnet **10.1.1.0/27**.

Table 4: IP addressing schema for devices interconnected with redundancy and managed remotely via OSC deployment

Cisco Optical Site Manager instance	NCS device	NCS device interface	NCS device IP/Mask	Connected to switch	Connected to switch interface
Cisco Optical Site Manager 2	NCS 1010-1	MgmtEth0/RP0/CPU0/0	192.168.1.12/24	Ext Switch	—
		MgmtEth0/RP0/CPU0/1	192.168.2.12/31	Peer NCS1K	MgmtEth0/RP0/CPU0/1
		GigabitEthernet0/0/0/0	172.18.0.1/31	Neighbor NCS1K	GigabitEthernet0/0/0/0
		Loopback 0	10.1.1.2/32	—	—
		Loopback 1	10.1.1.13/32	—	—
	NCS 1010-2	MgmtEth0/RP0/CPU0/0	192.168.1.13/24	Ext Switch	—
		MgmtEth0/RP0/CPU0/1	192.168.2.13/31	Peer NCS1K	MgmtEth0/RP0/CPU0/1
		GigabitEthernet0/0/0/0	172.18.0.2/31	Neighbor NCS1K	GigabitEthernet0/0/0/0
		Loopback 0	10.1.1.2/32	—	—
		Loopback 1	10.1.1.14/32	—	—

Practical example of devices interconnected with redundancy and managed remotely via OSC deployment

This figure provides a practical example of this deployment model, implemented with one Catalyst 9300 switch and two NCS 1010 devices.

Figure 8: Example of deployment model with two NCS 1010 configured as 2-degrees ROADM**Example configuration for the deployment**

This example describes the configuration of two NCS 1010 devices set up as a 2-degree ROADM with redundancy and remote management through the OSC.

NCS 1010-A configuration

```
hostname COSM1-NCS1010-A
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600
interface Loopback0
ipv4 address 10.1.1.2 255.255.255.255
shutdown
interface Loopback1
ipv4 address 10.1.1.13 255.255.255.255
interface MgmtEth0/RP0/CPU0/0
ipv4 address 192.168.1.12 255.255.255.0
interface MgmtEth0/RP0/CPU0/1
ipv4 address 192.168.2.12 255.255.255.254
interface GigabitEthernet0/0/0/0
ipv4 address 172.18.0.1 255.255.255.254
router static
address-family ipv4 unicast
10.1.1.14/32 192.168.2.13
router ospf 1
router-id 10.1.1.13
area 0
interface Loopback0
interface Loopback1
interface MgmtEth0/RP0/CPU0/0
interface MgmtEth0/RP0/CPU0/1
interface GigabitEthernet0/0/0/0
cosm
user-name <device username>
user-password <device password>
redundancy peer-ip 10.1.1.14
redundancy gateway-ip <gateway>
redundancy interface-name Loopback1
```

```
auto-onboard enable
mgmt-interface-name Loopback0
```

NCS 1010-B configuration

```
hostname COSM1-NCS1010-B
netconf-yang agent ssh
ssh server v2
ssh server netconf
ssh server rate-limit 600
interface Loopback0
ipv4 address 10.1.1.2 255.255.255.255
shutdown
interface Loopback1
ipv4 address 10.1.1.14 255.255.255.255
interface MgmtEth0/RP0/CPU0/0
ipv4 address 192.168.1.13 255.255.255.0
interface MgmtEth0/RP0/CPU0/1
ipv4 address 192.168.2.13 255.255.255.254
interface GigabitEthernet0/0/0/0
ipv4 address 172.18.0.2 255.255.255.254
router static
address-family ipv4 unicast
10.1.1.13/32 192.168.2.12
router ospf 1
router-id 10.1.1.14
area 0
interface Loopback0
interface Loopback1
interface MgmtEth0/RP0/CPU0/0
interface MgmtEth0/RP0/CPU0/1
interface GigabitEthernet0/0/0/0
cosm
user-name <device username>
user-password <device password>
redundancy peer-ip 10.1.1.13
redundancy gateway-ip <gateway>
redundancy interface-name Loopback1
auto-onboard enable
mgmt-interface-name Loopback0
```