



Perform Preliminary Checks

After successfully logging into the console, you must perform some preliminary checks to verify the default setup. If any setup issue is detected when these checks are performed, take corrective action before making further configurations. These preliminary checks are:

- [Verify Status of Hardware Components, on page 1](#)
- [Verify Node Status, on page 5](#)
- [Verify Software Version, on page 7](#)
- [Verify Firmware Version, on page 8](#)
- [Verify Management Interface Status, on page 10](#)
- [Verify Alarms, on page 12](#)
- [Verify Environmental Parameters, on page 12](#)
- [Verify Inventory, on page 15](#)

Verify Status of Hardware Components

To verify the status of all the hardware components installed on the NCS 1001, perform the following procedure.

Before you begin

Ensure that all the required hardware components have been installed on the NCS 1001. For installation details, see *Cisco Network Convergence System 1001 Hardware Installation Guide*.

SUMMARY STEPS

1. `show platform`
2. `admin`
3. `show platform`
4. `show platform detail`
5. `show inventory`

DETAILED STEPS

Step 1 `show platform`

When you execute this command from the Cisco IOS XR EXEC mode, the status of the Cisco IOS XR is displayed.

Example:

```
RP/0/RP0/CPU0:ios# show platform
```

```
Sun Mar 5 02:33:53.075 CET
```

Node	Type	State	Config state
0/0	NCS1001-K9	OPERATIONAL	NSHUT
0/3	NCS1K-EDFA	OPERATIONAL	NSHUT
0/RP0/CPU0	NCS1K-CNTRLR2 (Active)	IOS XR RUN	NSHUT
0/FT0	NCS1K1-FAN	OPERATIONAL	NSHUT
0/FT1	NCS1K1-FAN	OPERATIONAL	NSHUT
0/FT2	NCS1K1-FAN	OPERATIONAL	NSHUT
0/FT3	NCS1K1-FAN	OPERATIONAL	NSHUT

- a) If the Cisco IOS XR is not operational, no output is shown in the result. In this case, verify the state of service domain router (SDR) on the node using the **show sdr** command in Cisco IOS XR mode.

The following example shows sample output from the **show sdr** command in Cisco IOS XR mode.

```
RP/0/RP0/CPU0:ios# show sdr
```

```
Sun Mar 5 02:37:09.174 CET
```

Type	NodeName	NodeState	RedState	PartnerName
NCS1001-K9	0/0	OPERATIONAL		N/A
NCS1K-EDFA	0/3	OPERATIONAL		N/A
RP	0/RP0/CPU0	IOS XR RUN	ACTIVE	NONE
NCS1K-CNTRLR2	0/RP0	OPERATIONAL		N/A
NCS1K1-FAN	0/FT0	OPERATIONAL		N/A
NCS1K1-FAN	0/FT1	OPERATIONAL		N/A
NCS1K1-FAN	0/FT2	OPERATIONAL		N/A
NCS1K1-FAN	0/FT3	OPERATIONAL		N/A

Step 2 admin

Enters System Admin EXEC mode.

Example:

```
RP/0/RP0/CPU0:ios# admin
```

Step 3 show platform

Displays information and status for each node in the system.

Example:

```
sysadmin-vm:0_RP0# show platform
```

```
Sun Mar 5 01:38:22.282 UTC
```

Location	Card Type	HW State	SW State	Config State
0/0	NCS1001-K9	OPERATIONAL	N/A	NSHUT
0/3	NCS1K-EDFA	OPERATIONAL	N/A	NSHUT
0/RP0	NCS1K-CNTRLR2	OPERATIONAL	OPERATIONAL	NSHUT
0/FT0	NCS1K1-FAN	OPERATIONAL	N/A	NSHUT
0/FT1	NCS1K1-FAN	OPERATIONAL	N/A	NSHUT

0/FT2	NCS1K1-FAN	OPERATIONAL	N/A	NSHUT
0/FT3	NCS1K1-FAN	OPERATIONAL	N/A	NSHUT

Verify that all components of the NCS 1001 are displayed in the result. The software state and the hardware state must be in the OPERATIONAL state. The various hardware and software states are:

Hardware states:

- OPERATIONAL—Node is operating normally and is fully functional.
- POWERED_ON—Power is on and the node is booting up.
- FAILED—Node is powered on but has experienced some internal failure.
- PRESENT—Node is in the shutdown state.
- OFFLINE—User has changed the node state to OFFLINE. The node is accessible for diagnostics.

Software states:

- OPERATIONAL—Software is operating normally and is fully functional.
- SW_INACTIVE—Software is not completely operational.
- FAILED—Software is operational but the card has experienced some internal failure.
- N/A—Valid option for modules where software is not running.

Step 4 show platform detail

Displays the hardware and software states, and other details of the node.

Example:

```
sysadmin-vm:0_RP0# show platform detail
Sun Mar  5 01:39:45.411 UTC
```

```
Platform Information for 0/0
PID : NCS1001-K9
Description : "Network Convergence System 1001 line system 3 slots"
VID/SN : V00
HW Oper State : OPERATIONAL
SW Oper State : N/A
Configuration : "NSHUT RST"
HW Version : 0.1
Last Event : HW_EVENT_OK
Last Event Reason : "HW Event OK"
```

```
Platform Information for 0/3
PID : NCS1K-EDFA
Description : "Network Convergence System 1000 amplifier module"
VID/SN : V01
HW Oper State : OPERATIONAL
SW Oper State : N/A
Configuration : "NSHUT RST"
HW Version : 0.1
Last Event : HW_EVENT_OK
Last Event Reason : "HW Operational"
```

```
Platform Information for 0/RP0
PID : NCS1K-CNTRLR2
Description : "Network Convergence System 1000 Controller 2"
VID/SN : V01
```

```

HW Oper State :      OPERATIONAL
SW Oper State :      OPERATIONAL
Configuration :      "NSHUT RST"
HW Version :         0.1
Last Event :         HW_EVENT_OK
Last Event Reason :  UNKNOWN

```

```

Platform Information for 0/FT0
PID :                NCS1K1-FAN
Description :        "Network Convergence System 1001 Fan"
VID/SN :            V01
HW Oper State :      OPERATIONAL
SW Oper State :      N/A
Configuration :      "NSHUT RST"
HW Version :         0.0
Last Event :         HW_EVENT_OK
Last Event Reason :  "HW Operational"

```

```

Platform Information for 0/FT1
PID :                NCS1K1-FAN
Description :        "Network Convergence System 1001 Fan"
VID/SN :            V01
HW Oper State :      OPERATIONAL
SW Oper State :      N/A
Configuration :      "NSHUT RST"
HW Version :         0.0
Last Event :         HW_EVENT_OK
Last Event Reason :  "HW Operational"

```

Step 5 show inventory

Displays the details of the physical entities of the NCS 1001 when you execute this command in the Cisco IOS XR EXEC mode.

Example:

```

RP/0/RP0/CPU0:ios# show inventory
Sun Mar  5 02:42:04.865 CET
NAME: "0/0", DESCR: "Network Convergence System 1001 line system 3 slots"
PID: NCS1001-K9      , VID: V00, SN: CAT2018B033

NAME: "0/3", DESCR: "Network Convergence System 1000 amplifier module"
PID: NCS1K-EDFA     , VID: V01, SN: IIF2044002L

NAME: "0/3-PORT-0", DESCR: "Cisco SFP Pluggable Optics Module"
PID: ONS-SC-Z3-1510 , VID: V02 , SN: FNS200801EK

NAME: "0/RP0", DESCR: "Network Convergence System 1000 Controller 2"
PID: NCS1K-CNTRLR2  , VID: V01, SN: CAT2051B0R5

NAME: "0/RP0-SFP-PORT", DESCR: "Unqualified SFP Pluggable Optics Module"
PID: UNQUALIFIED-SFP , VID: N/A, SN: N/A

NAME: "Rack 0", DESCR: "Network Convergence System 1001 line system 3 slots"
PID: NCS1001-K9      , VID: V00, SN: CAT2018B033

NAME: "0/FT0", DESCR: "Network Convergence System 1001 Fan"
PID: NCS1K1-FAN     , VID: V01, SN: N/A

NAME: "0/FT1", DESCR: "Network Convergence System 1001 Fan"
PID: NCS1K1-FAN     , VID: V01, SN: N/A

NAME: "0/FT2", DESCR: "Network Convergence System 1001 Fan"
PID: NCS1K1-FAN     , VID: V01, SN: N/A

```

```

NAME: "0/FT3", DESCR: "Network Convergence System 1001 Fan"
PID: NCS1K1-FAN      , VID: V01, SN: N/A

NAME: "0/PM0", DESCR: "Network Convergence System 1000 2KW AC PSU 2"
PID: NCS1K-2KW-AC2  , VID: V01, SN: POG2049JT21

NAME: "0/PM1", DESCR: "Network Convergence System 1000 2KW AC PSU 2"
PID: NCS1K-2KW-AC2  , VID: V01, SN: POG2049JT01

```

Verify Node Status

You can verify the operational status of all the nodes using the **show platform** command. You can execute this command independently from both the Cisco IOS XR EXEC and System Admin EXEC modes.

To verify the operational status of all the nodes, perform the following procedure.

SUMMARY STEPS

1. **show platform**
2. **admin**
3. **show platform**
4. **show platform detail**

DETAILED STEPS

Step 1 **show platform**

When you execute this command from the XR EXEC mode, the status of the Cisco IOS XR is displayed.

Example:

```

RP/0/RP0/CPU0:ios# show platform
Sun Mar  5 02:53:27.755 CET
Node                Type                               State          Config state
-----
0/0                 NCS1001-K9                        OPERATIONAL    NSHUT
0/3                 NCS1K-EDFA                        OPERATIONAL    NSHUT
0/RP0/CPU0         NCS1K-CNTRLR2 (Active)           IOS XR RUN     NSHUT
0/FT0              NCS1K1-FAN                        OPERATIONAL    NSHUT
0/FT1              NCS1K1-FAN                        OPERATIONAL    NSHUT
0/FT2              NCS1K1-FAN                        OPERATIONAL    NSHUT
0/FT3              NCS1K1-FAN                        OPERATIONAL    NSHUT

```

If the Cisco IOS XR is not operational, no output is shown in the result. In this case, verify the state of SDR on the node using the **show sdr** command in the System Admin EXEC mode.

Step 2 **admin**

Enters System Admin EXEC mode.

Example:

```
RP/0/RP0/CPU0:ios# admin
```

Step 3 **show platform**

Displays information and status for each node in the system.

Example:

```

sysadmin-vm:0_RP0# show platform
Sun Mar  5  01:56:15.749 UTC
Location  Card Type                HW State    SW State    Config State
-----
0/0       NCS1001-K9               OPERATIONAL N/A         NSHUT
0/3       NCS1K-EDFA               OPERATIONAL N/A         NSHUT
0/RP0     NCS1K-CNTLR2            OPERATIONAL OPERATIONAL NSHUT
0/FT0     NCS1K1-FAN              OPERATIONAL N/A         NSHUT
0/FT1     NCS1K1-FAN              OPERATIONAL N/A         NSHUT
0/FT2     NCS1K1-FAN              OPERATIONAL N/A         NSHUT
0/FT3     NCS1K1-FAN              OPERATIONAL N/A         NSHUT

```

Verify that all the modules of NCS 1001 are displayed in the result. The software state and the hardware state must be in the OPERATIONAL state. The various hardware and software states are:

Hardware states:

- OPERATIONAL—Node is operating normally and is fully functional.
- POWERED_ON—Power is on and the node is booting up.
- FAILED—Node is powered on but has experienced some internal failure.
- PRESENT—Node is in the shutdown state.
- OFFLINE—User has changed the node state to OFFLINE. The node is accessible for diagnostics.

Software states:

- OPERATIONAL—Software is operating normally and is fully functional.
- DIAG_MODE—User has changed the card state to OFFLINE for diagnosis.
- SW_INACTIVE—Software is not completely operational.
- FAILED—Software is operational but the card has experienced some internal failure.
- N/A—Valid option for modules where software is not running.

Step 4 **show platform detail**

Displays the hardware and software states, and other details of the node.

Example:

```

sysadmin-vm:0_RP0# show platform detail
Sun Mar  5  01:57:40.918 UTC

Platform Information for 0/0
PID :                NCS1001-K9
Description :        "Network Convergence System 1001 line system 3 slots"
VID/SN :             V00
HW Oper State :      OPERATIONAL
SW Oper State :      N/A
Configuration :      "NSHUT RST"
HW Version :         0.1
Last Event :         HW_EVENT_OK

```

```
Last Event Reason : "HW Event OK"
```

```
Platform Information for 0/3
```

```
PID : NCS1K-EDFA
Description : "Network Convergence System 1000 amplifier module"
VID/SN : V01
HW Oper State : OPERATIONAL
SW Oper State : N/A
Configuration : "NSHUT RST"
HW Version : 0.1
Last Event : HW_EVENT_OK
Last Event Reason : "HW Operational"
```

```
Platform Information for 0/RP0
```

```
PID : NCS1K-CNTRLR2
Description : "Network Convergence System 1000 Controller 2"
VID/SN : V01
HW Oper State : OPERATIONAL
SW Oper State : OPERATIONAL
Configuration : "NSHUT RST"
HW Version : 0.1
Last Event : HW_EVENT_OK
Last Event Reason : UNKNOWN
```

```
Platform Information for 0/FT0
```

```
PID : NCS1K1-FAN
Description : "Network Convergence System 1001 Fan"
VID/SN : V01
HW Oper State : OPERATIONAL
SW Oper State : N/A
Configuration : "NSHUT RST"
HW Version : 0.0
Last Event : HW_EVENT_OK
Last Event Reason : "HW Operational"
```

```
Platform Information for 0/FT1
```

```
PID : NCS1K1-FAN
Description : "Network Convergence System 1001 Fan"
VID/SN : V01
HW Oper State : OPERATIONAL
SW Oper State : N/A
Configuration : "NSHUT RST"
HW Version : 0.0
Last Event : HW_EVENT_OK
Last Event Reason : "HW Operational"
```

Verify Software Version

The NCS 1001 is shipped with the Cisco IOS XR software pre-installed. Verify that the latest version of the software is installed. If a newer version is available, perform a system upgrade. This will install the newer version of the software and provide the latest feature set on the NCS 1001.

To verify the version of Cisco IOS XR software running on the NCS 1001, perform the following procedure.

SUMMARY STEPS

1. **show version**

DETAILED STEPS**show version**

Displays the software version and details such as system uptime.

Example:

```
RP/0/RP0/CPU0:ios# show version
Fri Aug 10 10:38:09.569 CEST
Cisco IOS XR Software, Version 6.5.1
Copyright (c) 2013-2018 by Cisco Systems, Inc.

Build Information:
Built By      : ahoang
Built On     : Wed Aug  8 16:47:10 PDT 2018
Built Host   : iox-ucs-027
Workspace    : /auto/srcarchive17/prod/6.5.1/ncs1001/ws
Version     : 6.5.1
Location    : /opt/cisco/XR/packages/

cisco NCS-1001 () processor
System uptime is 5 minutes
```

What to do next

Verify the result to ascertain whether a system upgrade is required. If the upgrade is required, see the [Perform System Upgrade and Install Feature Packages](#) chapter.

Verify Firmware Version

The firmware on various hardware components of the NCS 1001 must be compatible with the installed Cisco IOS XR image. Incompatibility may cause the NCS 1001 to malfunction.

To verify the firmware version, perform the following procedure.

SUMMARY STEPS

1. **show hw-module fpd**

DETAILED STEPS**show hw-module fpd**

```
Sun Mar  5 02:10:42.676 UTC

                                FPD Versions
                                =====
Location  Card type      HWver FPD device  ATR Status  Run   Programd
-----
0/0       NCS1001-K9      0.1   Control_BKP   B  CURRENT    1.10
0/0       NCS1001-K9      0.1   Control_FPGA  CURRENT    1.10   1.10
```


0/1	NCS1K-EDFA	0.0	FW_EDFAv1		CURRENT	1.43	1.43
0/2	NCS1K-PSM	0.0	FW_PSMv1		CURRENT	1.45	1.45
0/3	NCS1K-EDFA	0.0	FW_EDFAv1		CURRENT	1.43	1.43
0/RP0	NCS1K-CNTLR2	0.1	BIOS_Backup	BS	CURRENT		14.20
0/RP0	NCS1K-CNTLR2	0.1	BIOS_Primary	S	CURRENT	14.20	14.20
0/RP0	NCS1K-CNTLR2	0.1	Daisy_Duke_BKP	BS	CURRENT		0.17
0/RP0	NCS1K-CNTLR2	0.1	Daisy_Duke_FPGA	S	CURRENT	0.17	0.17
0/PM0	NCS1K-2KW-AC2	0.0	PO-PrimCU		CURRENT	4.00	4.00
0/PM1	NCS1K-2KW-AC2	0.0	PO-PrimCU		CURRENT	4.00	4.00

Displays the firmware information of various hardware components of the NCS 1001 in the Cisco IOS XR EXEC mode.

In the above output, some of the significant fields are:

- FPD Device—Name of the hardware component such as FPD, CFP, and so on.
- ATR—Attribute of the hardware component. Some of the attributes are:
 - B—Backup Image
 - S—Secure Image
 - P—Protected Image
- Status— Upgrade status of the firmware. The different states are:
 - CURRENT—The firmware version is the latest version.
 - READY—The firmware of the FPD is ready for an upgrade.
 - NOT READY—The firmware of the FPD is not ready for an upgrade.
 - NEED UPGD—A newer firmware version is available in the installed image. It is recommended that an upgrade be performed.
 - RLOAD REQ—The upgrade has been completed, and the ISO image requires a reload.
 - UPGD DONE—The firmware upgrade is successful.
 - UPGD FAIL— The firmware upgrade has failed.
 - BACK IMG—The firmware is corrupted. Reinstall the firmware.
 - UPGD SKIP—The upgrade has been skipped because the installed firmware version is higher than the one available in the image.
- Running—Current version of the firmware running on the FPD.

What to do next

Upgrade all the FPDs using the **upgrade hw-module location all fpd all** command in the Cisco IOS XR EXEC mode. After an upgrade is completed, the Status column shows RLOAD REQ if the software requires reload.

If Reload is Required

If the FPGA location is 0/RP0, use the **admin hw-module location 0/RP0 reload** command. This command reboots only the control card. As a result, traffic is not impacted. If the FPGA location is 0/0, use the **admin hw-module location all reload** command. This command reboots the chassis. As a result, traffic is impacted. After the reload is completed, the new FPGA runs the current version.

If Firmware Upgrade Fails

If the firmware upgrade fails, use the **show logging** command to view the details and upgrade the firmware again using the above commands.

Verify Management Interface Status

To verify the management interface status, perform the following procedure.

SUMMARY STEPS

1. **show interfaces mgmtEth *instance***

DETAILED STEPS**show interfaces mgmtEth *instance***

Displays the management interface configuration.

Example:

```
RP/0/RP0/CPU0:ios# show interfaces MgmtEth 0/RP0/CPU0/0
Sun Mar  5 03:21:33.272 CET
MgmtEth0/RP0/CPU0/0 is up, line protocol is up
  Interface state transitions: 1
  Hardware is Management Ethernet, address is 6c9c.ed50.2aa2 (bia 6c9c.ed50.2aa2
)
  Internet address is 10.58.229.131/22
  MTU 1514 bytes, BW 1000000 Kbit (Max: 1000000 Kbit)
    reliability 255/255, txload 0/255, rxload 0/255
  Encapsulation ARPA,
  Full-duplex, 1000Mb/s, CX, link type is autonegotiation
  loopback not set,
  Last link flapped 2d12h
  ARP type ARPA, ARP timeout 04:00:00
  Last input 00:00:00, output 00:00:00
  Last clearing of "show interface" counters never
  5 minute input rate 16000 bits/sec, 22 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    4959018 packets input, 462164262 bytes, 0 total input drops
    0 drops for unrecognized upper-level protocol
  Received 3531513 broadcast packets, 1419827 multicast packets
    0 runts, 0 giants, 0 throttles, 0 parity
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  20720 packets output, 1284846 bytes, 0 total output drops
```

```

Output 0 broadcast packets, 0 multicast packets
0 output errors, 0 underruns, 0 applique, 0 resets
0 output buffer failures, 0 output buffers swapped out
1 carrier transitions

```

In the above result, the management interface is administratively down.

You can also use the **show interfaces summary** and **show interfaces brief** commands in the Cisco IOS XR EXEC mode to verify the management interface status.

- The following example shows sample output from the **show interfaces summary** command.

```

RP/0/RP0/CPU0:ios# show interfaces summary
Sun Mar  5 03:22:45.830 CET
Interface Type          Total    UP      Down    Admin Down
-----
ALL TYPES                2        2       0       0
-----
IFT_ETHERNET            1        1       0       0
IFT_NULL                1        1       0       0

```

- The following example shows sample output from the **show interfaces brief** command.

```

RP/0/RP0/CPU0:ios# show interfaces brief
Sun Mar  5 03:23:55.330 CET

          Intf      Intf      LineP      Encap  MTU      BW
          Name      State     State      Type   (byte)   (Kbps)
-----
          Nu0        up        up          Null   1500      0
Mg0/RP0/CPU0/0      up        up          ARPA   1514    1000000

```

What to do next

If the management interface is administratively down, perform the following steps:

- Check the Ethernet cable connection.
- Verify the IP configuration of the management interface. For details on configuring the management interface, see the *Bring-up NCS 1001* chapter.
- Verify whether the management interface is in the no shut state using the **show running-config interface mgmtEth** command.

The following example shows sample output from the **show running-config interface mgmtEth** command.

```

RP/0/RP0/CPU0:ios#show running-config interface mgmtEth 0/RP0/CPU0/0
Sun Mar  5 03:25:26.191 CET
interface MgmtEth0/RP0/CPU0/0
  ipv4 address 10.58.229.131 255.255.252.0
!
```

In the above output, the management interface is in the no shut state.

Verify Alarms

You can view the alarm information using the **show alarms** command.

SUMMARY STEPS

1. **show alarms** [**brief** [**card** | **rack** | **system**] [**location** *location*] [**active** | **history**] | **detail** [**card** | **rack** | **system**] [**location** *location*] [**active** | **clients** | **history** | **stats**]]

DETAILED STEPS

```
show alarms [ brief [ card | rack | system ] [ location location ] [ active | history ] | detail [ card | rack | system ] [ location location ] [ active | clients | history | stats ] ]
```

Displays alarms in brief or detail.

Example:

```
RP/0/RP0/CPU0:ios# show alarms brief card location 0/RP0/CPU0 active
Sun Mar 5 03:27:57.137 CET
```

```
-----
Active Alarms
-----
```

Location	Severity	Group	Set Time	Description
0/3	Critical	Controller	03/02/2017 14:51:45 CET	Ots0/3/0/2 - Output OTS Power Reading Below The Fail-Low Threshold
0/3	Minor	Controller	03/04/2017 06:32:27 CET	Optics0/3/0/4 - Optics Low Receive Power

What to do next

For more information about alarms and steps to clear them, see the *Alarm Troubleshooting* chapter of the *Cisco NCS 1001 Troubleshooting Guide*.

Verify Environmental Parameters

The **show environment** command displays the environmental parameters of the NCS 1001.

To verify that the environmental parameters are as expected, perform the following procedure.

SUMMARY STEPS

1. **admin**

2. show environment [all | fan | power | voltages | current | temperatures] [location | location]

DETAILED STEPS

Step 1 admin

Enters System Admin EXEC mode.

Example:

```
RP/0/RP0/CPU0:ios# admin
```

Step 2 show environment [all | fan | power | voltages | current | temperatures] [location | location]

Displays the environmental parameters of the NCS 1001.

Example:

The following example shows sample output from the **show environment** command with the **fan** keyword.

```
sysadmin-vm:0_RP0# show environment fan
Sun Mar 5 02:33:51.700 UTC
=====
Location          Fan speed (rpm)
FRU Type          FAN_0
-----
0/FT0             NCS1K1-FAN      11640
0/FT1             NCS1K1-FAN      11640
0/FT2             NCS1K1-FAN      11400
0/FT3             NCS1K1-FAN      11640
0/PM0             NCS1K-2KW-AC2   9696
0/PM1             NCS1K-2KW-AC2   9760
```

The following example shows sample output from the **show environment** command with the **temperatures** keyword.

```
sysadmin-vm:0_RP0# show environment temperatures location 0/RP0
Sun Mar 5 02:34:55.985 UTC
=====
Location TEMPERATURE          Value  Crit Major Minor Minor Major Crit
          Sensor              (deg C) (Lo) (Lo) (Lo) (Hi) (Hi) (Hi)
-----
0/RP0
    Thermistor 1                40    -10   0   0   55   55   85
    Thermistor 2                41    -10   0   0   55   55   85
    Hot Spot Temperature         40    -10   0   0   55   55   85
```

The following example shows sample output from the **show environment** command with the **power** keyword.

```
sysadmin-vm:0_RP0# show environment power
Sun Mar 5 02:36:17.380 UTC
=====
CHASSIS LEVEL POWER INFO: 0
```

```

=====
Total output power capacity (N + 1)      : 2000W + 2000W
Total output power required              : 269W
Total power input                        : 211W
Total power output                       : 67W

Power Group 0:
=====

Power Module      Supply Type      -----Input-----  -----Output-----  Status
                Type              Volts    Amps    Volts    Amps
=====

0/PM0            2kW-AC      235.0    0.4    12.0    1.1    OK

Total of Power Group 0:                94W/ 0.4A    13W/ 1.1A

Power Group 1:
=====

Power Module      Supply Type      -----Input-----  -----Output-----  Status
                Type              Volts    Amps    Volts    Amps
=====

0/PM1            2kW-AC      234.5    0.5    12.0    4.5    OK

Total of Power Group 1:                117W/ 0.5A    54W/ 4.5A

=====

Location          Card Type              Power Allocated  Power Used  Status
                  (Watts)           (Watts)
=====

0/0              NCS1001-K9            30             -          ON
0/1              -                      68             -          RESERVED
0/2              -                      68             -          RESERVED
0/3              NCS1K-EDFA           68             -          ON
0/RP0            NCS1K-CNTRLR2        35             -          ON
0/FT0            NCS1K1-FAN           0              -          ON
0/FT1            NCS1K1-FAN           0              -          ON
0/FT2            NCS1K1-FAN           0              -          ON
0/FT3            NCS1K1-FAN           0              -          ON

```

The following example shows sample output from the **show environment** command with the **voltages** keyword.

```
sysadmin-vm:0_RP0# show environment voltages location 0/RP0
```

```
Sun Mar 5 02:37:24.468 UTC
```

```

=====
Location  VOLTAGE              Value  Crit Minor Minor  Crit
          Sensor              (mV)  (Lo) (Lo) (Hi) (Hi)
-----
0/RP0
  VP1P0_CPU              1002   900  950 1050 1100
  CPU_CORE_VCC           713    400  450 1350 1400
  CPU_CORE_VNN           952    400  450 1350 1400
  VP1P1                  1077   990 1050 1160 1210
  VP1P2                  1206  1080 1140 1260 1320
  VP1P35_DDR             1353  1220 1280 1420 1490
  VP1P35                  1346  1220 1280 1420 1490
  VP1P5                  1503  1350 1430 1580 1650

```

VP1P8_CPU	1801	1620	1710	1890	1980
VP3P3_STBY	3323	2970	3140	3470	3630
VP3P3	3346	2970	3140	3470	3630
VP5P0	5029	4500	4750	5250	5500
VP12P0	12047	10800	11400	12600	13200
VREF	1224	1190	1200	1240	1250
12V Input Voltage	11208	8000	10000	14000	16000

What to do next

Environment parameter anomalies are logged in the syslog. As a result, if an environment parameter displayed in the **show environment** command output is not as expected, check the syslog using the **show logging** command. The syslog provides details on any logged problems.

Verify Inventory

The **show inventory** command displays details of the hardware inventory of the NCS 1001.

To verify the inventory information for all the physical entities, perform the following procedure.

SUMMARY STEPS

1. **show inventory**
2. **admin**
3. **show inventory**

DETAILED STEPS

Step 1 show inventory

Displays the details of the NCS 1001 when you execute this command in the Cisco IOS XR EXEC mode.

Example:

```
RP/0/RP0/CPU0:ios# show inventory
```

```
Sun Mar 5 02:42:57.359 UTC
```

```
Name: Rack 0          Descr: Network Convergence System 1001 line system 3 slots
PID: NCS1001-K9      VID: V00              SN: CAT2018B033

Name: 0/0            Descr: Network Convergence System 1001 line system 3 slots
PID: NCS1001-K9      VID: V00              SN: CAT2018B033

Name: 0/3            Descr: Network Convergence System 1000 amplifier module
PID: NCS1K-EDFA      VID: V01              SN: IIF2044002L

Name: 0/RP0-SFP-PORT Descr: Unqualified SFP Pluggable Optics Module
PID: UNQUALIFIED-SFP VID:                   SN:

Name: 0/RP0          Descr: Network Convergence System 1000 Controller 2
PID: NCS1K-CNTRLR2  VID: V01              SN: CAT2051B0R5

Name: 0/FT0          Descr: Network Convergence System 1001 Fan
```

```

PID: NCS1K1-FAN          VID: V01          SN: N/A
Name: 0/FT1              Descr: Network Convergence System 1001 Fan
PID: NCS1K1-FAN          VID: V01          SN: N/A
Name: 0/FT2              Descr: Network Convergence System 1001 Fan
PID: NCS1K1-FAN          VID: V01          SN: N/A
Name: 0/FT3              Descr: Network Convergence System 1001 Fan
PID: NCS1K1-FAN          VID: V01          SN: N/A
Name: 0/PM0              Descr: Network Convergence System 1000 2KW AC PSU 2
PID: NCS1K-2KW-AC2       VID: V01          SN: POG2049JT21
Name: 0/PM1              Descr: Network Convergence System 1000 2KW AC PSU 2
PID: NCS1K-2KW-AC2       VID: V01          SN: POG2049JT01

```

Step 2 admin

Enters System Admin EXEC mode.

Example:

```
RP/0/RP0/CPU0:router# admin
```

Step 3 show inventory

Displays inventory information for all the physical entities of the NCS 1001.

Example:

```

sysadmin-vm:0_RP0# show inventory
Sun Mar  5  02:44:30.350 UTC

Name: Rack 0              Descr: Network Convergence System 1001 line system 3 slots
PID: NCS1001-K9          VID: V01          SN: CAT2018B033

Name: 0/0                 Descr: Network Convergence System 1001 line system 3 slots
PID: NCS1001-K9          VID: V01          SN: CAT2018B033

Name: 0/3                 Descr: Network Convergence System 1000 amplifier module
PID: NCS1K-EDFA          VID: V01          SN: IIF2044002L

Name: 0/RP0-SFP-PORT      Descr: Unqualified SFP Pluggable Optics Module
PID: UNQUALIFIED-SFP     VID:              SN:

Name: 0/RP0               Descr: Network Convergence System 1000 Controller 2
PID: NCS1K-CNTRLR2       VID: V01          SN: CAT2051B0R5

Name: 0/FT0               Descr: Network Convergence System 1001 Fan
PID: NCS1K1-FAN          VID: V01          SN: N/A

Name: 0/FT1               Descr: Network Convergence System 1001 Fan
PID: NCS1K1-FAN          VID: V01          SN: N/A

Name: 0/FT2               Descr: Network Convergence System 1001 Fan
PID: NCS1K1-FAN          VID: V01          SN: N/A

Name: 0/FT3               Descr: Network Convergence System 1001 Fan
PID: NCS1K1-FAN          VID: V01          SN: N/A

Name: 0/PM0               Descr: Network Convergence System 1000 2KW AC PSU 2
PID: NCS1K-2KW-AC2       VID: V01          SN: POG2049JT21

```


