



Supported Yang Models

- [Supported Yang Models, on page 1](#)
- [Structure of Yang Models, on page 2](#)
- [Configure Flex Grid in OLT, on page 9](#)
- [Configure Flex Grid in ILA card, on page 10](#)
- [Configure OTS Controller, on page 12](#)
- [Configure OCH Controller, on page 16](#)
- [Configure Optical Cross-Connect, on page 17](#)
- [Configure OMS Controller, on page 19](#)
- [Configure DFB Controller, on page 20](#)
- [Configure OSC Controller, on page 22](#)
- [Configure FPD Package, on page 24](#)
- [View NCS 1010 Platform Details, on page 26](#)
- [View Performance Monitoring Parameters, on page 28](#)
- [Configure Equipment Mismatch Alarm, on page 31](#)
- [View the List of Alarms on the NCS 1010 Node, on page 32](#)
- [Configure Optical Amplifier on OLT Line Card Using Open Config Model, on page 34](#)
- [Configure Optical Amplifier on ILA Line Card Using Open Config Model, on page 35](#)
- [Configure Optical Attenuator on OLT Line Card Using Open Config Model, on page 37](#)
- [Configure Optical Attenuator on ILA Line Card Using Open Config Model, on page 38](#)

Supported Yang Models

The following is the list of supported config, and oper YANG models for NCS 1010:

| Config Models | Oper Models |
|--------------------------------------|---|
| Cisco-IOS-XR-osa-linesystem-cfg.yang | Cisco-IOS-XR-osa-hwmod-linesys-oper.yang |
| Cisco-IOS-XR-controller-ots-cfg.yang | Cisco-IOS-XR-controller-ots-oper.yang |
| Cisco-IOS-XR-ots-och-cfg.yang | Cisco-IOS-XR-controller-ots-och-oper.yang |
| Cisco-IOS-XR-controller-oms-cfg | Cisco-IOS-XR-controller-oms-oper.yang |
| Cisco-IOS-XR-controller-och-cfg | Cisco-IOS-XR-controller-och-oper.yang |
| Cisco-IOS-XR-controller-osc-cfg.yang | Cisco-IOS-XR-controller-osc-oper.yang |

| Config Models | Oper Models |
|--------------------------------------|---------------------------------------|
| Cisco-IOS-XR-controller-dfb-cfg.yang | Cisco-IOS-XR-controller-dfb-oper.yang |
| Cisco-IOS-XR-pmengine-cfg.yang | Cisco-IOS-XR-pmengine-oper.yang |
| Cisco-IOS-XR-olc-cfg.yang | Cisco-IOS-XR-olc-oper.yang |
| Cisco-IOS-XR-fpd-infra-cfg | Cisco-IOS-XR-show-fpd-loc-ng-oper |
| Cisco-IOS-XR-osa-ct-cfg | Cisco-IOS-XR-alarmgr-server-oper.yang |
| | Cisco-IOS-XR-platform-oper |

The following is the list of supported Open Config models:

openconfig-optical-amplifier@2019-12-06

openconfig-optical-attenuator@2019-07-19

Structure of Yang Models

YANG data models can be represented in a hierarchical, tree-based structure with nodes, which makes them more easily understandable. YANG defines four nodes types. Each node has a name, and depending on the node type, the node might either define a value or contain a set of child nodes. The nodes types (for data modeling) are:

- leaf node—Contains a single value of a specific type
- list node—Contains a sequence of list entries, each of which is uniquely identified by one or more keys leafs
- leaf-list node—Contains a sequence of leaf nodes
- container node—Contains a grouping of related nodes containing only child nodes, which can be any of the four node types

The following is the tree structure of the openconfig-optical-amplifier model.



Note Cisco NCS 1010 supports only the leaves that are highlighted as bold in the following open configuration models.

```

+--rw optical-amplifier
+--rw amplifiers
| +--rw amplifier* [name]
| +--rw name -> ../config/name
| +--rw config
| | +--rw name? string
| | +--rw type? identityref
| | +--rw target-gain? decimal64
| | +--rw min-gain? decimal64
| | +--rw max-gain? decimal64
| | +--rw target-gain-tilt? decimal64
| | +--rw gain-range? identityref

```

```

| | +--rw amp-mode? identityref
| | +--rw target-output-power? decimal64
| | +--rw max-output-power? decimal64
| | +--rw enabled? boolean
| | +--rw fiber-type-profile? identityref
| +--ro state
| +--ro name? string
| +--ro type? identityref
| +--ro target-gain? decimal64
| +--ro min-gain? decimal64
| +--ro max-gain? decimal64
| +--ro target-gain-tilt? decimal64
| +--ro gain-range? identityref
| +--ro amp-mode? identityref
| +--ro target-output-power? decimal64
| +--ro max-output-power? decimal64
| +--ro enabled? boolean
| +--ro fiber-type-profile? identityref
| +--ro component? -> /oc-platform:components/component/name
| +--ro ingress-port? -> /oc-platform:components/component/name
| +--ro egress-port? -> /oc-platform:components/component/name
| +--ro actual-gain
| +--ro actual-gain-tilt
| +--ro input-power-total
| +--ro input-power-c-band
| +--ro input-power-l-band
| +--ro output-power-total
| +--ro output-power-c-band
| +--ro output-power-l-band
| +--ro laser-bias-current
| +--ro optical-return-loss
+--rw supervisory-channels
+--rw supervisory-channel* [interface]
+--rw interface -> ../config/interface

```

The following is a tree structure of the openconfig-optical-attenuator model.

```

+--rw optical-attenuator
+--rw attenuators
+--rw attenuator* [name]
+--rw name -> ../config/name
+--rw config
| +--rw name? string
| +--rw attenuation-mode?
| +--rw target-output-power? decimal64
| +--rw attenuation? decimal64
| +--rw enabled? boolean
+--ro state
+--ro name? string
+--ro attenuation-mode? identityref
+--ro target-output-power? decimal64
+--ro attenuation? decimal64
+--ro enabled? boolean
+--ro component? -> /oc-platform:components/component/name
+--ro ingress-port? -> /oc-platform:components/component/name
+--ro egress-port? -> /oc-platform:components/component/name
+--ro actual-attenuation
+--ro output-power-total
+--ro optical-return-loss

```

The following is a sample tree structure of Cisco-IOS-XR-controller-ots-oper model.

```

+--ro ots-oper
  +--ro ots-ports
    +--ro ots-port* [name]

```

```

+--ro ots-info
| +--ro raman-tx-power
| | +--ro raman-tx-power*
| |   +--ro raman-tx-power-instance?  uint32
| |   +--ro raman-tx-power-value?    uint32
| |   +--ro raman-tx-wavelength?     uint32
| +--ro transmit-n-power
| | +--ro transmit-power*
| |   +--ro instance?  uint32
| |   +--ro value?    int32
| +--ro receive-n-power
| | +--ro receive-power*
| |   +--ro instance?  uint32
| |   +--ro value?    int32
| +--ro ingress-channel-slice-attenuation
| | +--ro ingress-channel-slice*
| |   +--ro ingress-channel-slice?      uint32
| |   +--ro ingress-channel-slice-attenuation?  int32
| +--ro egress-channel-slice-attenuation
| | +--ro egress-channel-slice*
| |   +--ro egress-channel-slice?      uint32
| |   +--ro egress-channel-slice-attenuation?  int32
| +--ro raman-tx-power-config
| | +--ro raman-tx-power*
| |   +--ro raman-tx-power-instance?  uint32
| |   +--ro raman-tx-power-value?    uint32
| +--ro ingress-channel-slice-attenuation-configured
| | +--ro ingress-channel-slice*
| |   +--ro ingress-channel-slice?      uint32
| |   +--ro ingress-channel-slice-attenuation?  int32
| +--ro egress-channel-slice-attenuation-configured
| | +--ro egress-channel-slice*
| |   +--ro egress-channel-slice?      uint32
| |   +--ro egress-channel-slice-attenuation?  int32
| +--ro channel-attenuation-info
| | +--ro total-channel-attenuation-slice-count?  uint32
| | +--ro channel-attenuation-slice-spacing?      uint32
| | +--ro channel-attenuation-first-slice-wavelength?  uint32
| | +--ro channel-attenuation-first-slice-frequency?  uint32
| | +--ro ingress-channel-attenuation-info*
| | | +--ro slice-num?      uint32
| | | +--ro ingress-attenuation?  uint32
| | +--ro egress-channel-attenuation-info*
| |   +--ro slice-num?      uint32
| |   +--ro egress-attenuation?  uint32
| +--ro otdr-info-rx
| | +--ro scan-status?      Otdr-scan-status
| | +--ro tracepoint-file?  string
| | +--ro total-events?    uint32
| | +--ro scan-timestamp?  string
| | +--ro event-info*
| | | +--ro event-number?    uint32
| | | +--ro detected-event?  uint32
| | | +--ro location?       int64
| | | +--ro accuracy?       int64
| | | +--ro magnitude?      int64
| | | +--ro attenuation?    int64
| +--ro otdr-info-tx
| | +--ro scan-status?      Otdr-scan-status
| | +--ro tracepoint-file?  string
| | +--ro total-events?    uint32
| | +--ro scan-timestamp?  string
| | +--ro event-info*
| | | +--ro event-number?    uint32

```

```

| |      +--ro detected-event?   uint32
| |      +--ro location?         int64
| |      +--ro accuracy?         int64
| |      +--ro magnitude?        int64
| |      +--ro attenuation?      int64
| +--ro rx-los-p
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro rx-loc
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro tx-power-fail-low
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro ingress-auto-laser-shut
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro ingress-auto-pow-red
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro ingress-ampli-gain-low
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro ingress-ampli-gain-high
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro egress-auto-laser-shut
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro egress-auto-pow-red
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro egress-ampli-gain-low
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro egress-ampli-gain-high
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro high-tx-br-pwr
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro high-rx-br-pwr
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro span-too-short-tx
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro span-too-short-rx
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro raman-auto-pow-red
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro raman1-low-pwr
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro raman2-low-pwr
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro raman3-low-pwr
| |      +--ro is-detected?      boolean
| |      +--ro counter?          uint32
| +--ro raman4-low-pwr
| |      +--ro is-detected?      boolean

```

```

| | +--ro counter?      uint32
| +--ro raman5-low-pwr
| | +--ro is-detected? boolean
| | +--ro counter?     uint32
| +--ro raman1-high-pwr
| | +--ro is-detected? boolean
| | +--ro counter?     uint32
| +--ro raman2-high-pwr
| | +--ro is-detected? boolean
| | +--ro counter?     uint32
| +--ro raman3-high-pwr
| | +--ro is-detected? boolean
| | +--ro counter?     uint32
| +--ro raman4-high-pwr
| | +--ro is-detected? boolean
| | +--ro counter?     uint32
| +--ro raman5-high-pwr
| | +--ro is-detected? boolean
| | +--ro counter?     uint32
| +--ro ots-och-alamr-info
| | +--ro rx-los-p
| | | +--ro is-detected? boolean
| | | +--ro counter?     uint32
| | +--ro tx-power-fail-low
| | | +--ro is-detected? boolean
| | | +--ro counter?     uint32
| +--ro ots-tone-info
| | +--ro tone-freq?      string
| | +--ro tone-rate?     uint32
| | +--ro pattern?       string
| | +--ro pattern-expected? string
| | +--ro dectected-oob? uint32
| | +--ro state?         Conn-verfcn-state
| | +--ro pattern-received? string
| +--ro transport-admin-state?           Ots-tas
| +--ro rx-pow-low-threshold?            int32
| +--ro rx-pow-high-threshold?           int32
| +--ro tx-pow-low-threshold?            int32
| +--ro tx-pow-high-threshold?           int32
| +--ro pm-enable?                       uint32
| +--ro controller-state?                Ots-controller-state
| +--ro rx-voa-attenuation?              int32
| +--ro tx-voa-attenuation?              int32
| +--ro channel-width?                   int32
| +--ro central-frequency?                uint32
| +--ro add-drop-channel?                 string
| +--ro line-channel?                    string
| +--ro ingress-ampli-gain?              int32
| +--ro ingress-ampli-tilt?              int32
| +--ro ingress-amp-gain-deg-thres-low?   uint32
| +--ro ingress-amp-gain-deg-thres-high?  uint32
| +--ro ingress-ampli-gain-range?         Ots-amplifier-gain-range
|
| +--ro egress-ampli-gain?                int32
| +--ro egress-ampli-tilt?               int32
| +--ro egress-amp-gain-deg-thres-low?    uint32
| +--ro egress-amp-gain-deg-thres-high?   uint32
| +--ro egress-ampli-gain-range?         Ots-amplifier-gain-range
|
| +--ro composite-raman-power?           uint32
| +--ro wavelength?                     uint32
| +--ro transmit-power?                  int32
| +--ro receive-power?                   int32
| +--ro total-cl-tx-power?               int32

```

```

| +--ro total-cl-rx-power? int32
| +--ro receive-signal-power? int32
| +--ro transmit-signal-power? int32
| +--ro ingress-ampli-osri? boolean
| +--ro egress-ampli-osri? boolean
| +--ro ingress-ampli-force-apr? boolean
| +--ro egress-ampli-force-apr? boolean
| +--ro ingress-ampli-safety-control-mode?
Ots-amplifier-safety-control-mode
| +--ro egress-ampli-safety-control-mode?
Ots-amplifier-safety-control-mode
| +--ro ingress-ampli-safety-control-mode-configured?
Ots-amplifier-safety-control-mode
| +--ro egress-ampli-safety-control-mode-configured?
Ots-amplifier-safety-control-mode
| +--ro ingress-ampli-osri-configured? boolean
| +--ro egress-ampli-osri-configured? boolean
| +--ro ingress-ampli-force-apr-configured? boolean
| +--ro egress-ampli-force-apr-configured? boolean
| +--ro raman-safety-control-mode?
Ots-amplifier-safety-control-mode
| +--ro raman-safety-control-mode-configured?
Ots-amplifier-safety-control-mode
| +--ro raman-osri? boolean
| +--ro raman-force-apr? boolean
| +--ro raman-osri-configured? boolean
| +--ro raman-force-apr-configured? boolean
| +--ro rx-pow-low-warning-threshold? int32
| +--ro rx-pow-high-warning-threshold? int32
| +--ro tx-pow-low-warning-threshold? int32
| +--ro tx-pow-high-warning-threshold? int32
| +--ro description? string
| +--ro channel-attenuation? int32
| +--ro rx-voa-attenuation-config-val? int32
| +--ro tx-voa-attenuation-config-val? int32
| +--ro ampli-control-mode-config-val?
Ots-amplifier-control-mode
| +--ro rx-low-th-psd-config-val? int32
| +--ro total-rx-power? int32
| +--ro total-tx-power? int32
| +--ro ingress-ampli-gain-range-config-val? Ots-amplifier-gain-range
| +--ro ingress-ampli-gain-config? uint32
| +--ro ingress-ampli-tilt-config? int32
| +--ro ingress-ampli-thr-deg-low-config? uint32
| +--ro ingress-ampli-thr-deg-high-config? uint32
| +--ro egress-ampli-gain-range-config-val? Ots-amplifier-gain-range
| +--ro egress-ampli-gain-config? uint32
| +--ro egress-ampli-tilt-config? int32
| +--ro egress-ampli-gain-thr-deg-low-config? uint32
| +--ro egress-ampli-gain-thr-deg-high-config? uint32
| +--ro channel-attenuation-configured? int32
| +--ro br-power? int32
| +--ro raman-br-power? int32
| +--ro led-state? Led-state
+--ro ots-spectrum-info
| +--ro spectrum-info
|   +--ro total-spectrum-slice-count? uint32
|   +--ro spectrum-slice-spacing? uint32
|   +--ro first-slice-wavelength? uint32
|   +--ro first-slice-frequency? uint32
|   +--ro spectrum-slice-power-info*
|     +--ro slice-num? uint32

```

```

|           +---ro rx-power?      int16
|           +---ro tx-power?      int16
+---ro name                               xr:Interface-name

```

The following is a sample tree structure of Cisco-IOS-XR-controller-ots-cfg model.

```

augment /al:interface-configurations/al:interface-configuration:
  +---rw ots
    +---rw ingress-channel-slice-attns
      | +---rw ingress-channel-slice-attn* [ingress-channel-slice-attn]
      |   +---rw ingress-channel-slice-attn          uint32
      |   +---rw ingress-channel-slice-attnvalue     uint32
    +---rw raman-tx-power-disables
      | +---rw raman-tx-power-disable* [raman-tx-power-disable-instance]
      |   +---rw raman-tx-power-disable-instance    uint32
    +---rw raman-tx-powers
      | +---rw raman-tx-power* [raman-tx-power-instance]
      |   +---rw raman-tx-power-instance            uint32
      |   +---rw raman-tx-power-value              uint32
    +---rw ots-otdr
      | +---rw ots-otdr-rx
      | | +---rw ots-otdr-rx-expert
      | | | +---rw ots-otdr-rx-capture-start?      uint32
      | | | +---rw ots-otdr-rx-scan-duration?      uint32
      | | | +---rw ots-otdr-rx-pulse-width?       uint32
      | | | +---rw ots-otdr-rx-capture-end?       uint32
      | | +---rw ots-otdr-rx-auto
      | | | +---rw ots-otdr-rx-excess-reflection-threshold? int32
      | | | +---rw ots-otdr-rx-splice-loss-threshold?   uint32
      | | | +---rw ots-otdr-rx-raman-setpoint?         uint32
      | | | +---rw ots-otdr-rx-reflectance-threshold?  int32
      | | +---rw ots-otdr-rx-back-scattering?        int32
      | | +---rw ots-otdr-rx-refractive-index?      uint32
      | +---rw ots-otdr-scan-mode
      | | +---rw ots-otdr-scan-mode-expert?         empty
    +---rw ots-otdr-tx
      | +---rw ots-otdr-tx-expert
      | | +---rw ots-otdr-tx-capture-end?          uint32
      | | +---rw ots-otdr-tx-scan-duration?        uint32
      | | +---rw ots-otdr-tx-capture-start?        uint32
      | | +---rw ots-otdr-tx-pulse-width?         uint32
      | +---rw ots-otdr-tx-auto
      | | +---rw ots-otdr-tx-splice-loss-threshold? uint32
      | | +---rw ots-otdr-tx-excess-reflection-threshold? int32
      | | +---rw ots-otdr-tx-raman-setpoint?       uint32
      | | +---rw ots-otdr-tx-reflectance-threshold? int32
      | +---rw ots-otdr-tx-refractive-index?      uint32
      | +---rw ots-otdr-tx-back-scattering?       int32
    +---rw egress-channel-slice-attns
      | +---rw egress-channel-slice-attn* [egress-channel-slice-attn]
      |   +---rw egress-channel-slice-attn          uint32
      |   +---rw egress-channel-slice-attnvalue     uint32
    +---rw ots-egress-safety-control-mode?         Ots-safety-control-mode
    +---rw ots-ingress-amplifier-gain?             uint32
    +---rw ots-tone-pattern-expected?             string
    +---rw ots-ingress-osri?                       boolean
    +---rw ots-ingress-amplifier-gain-degrade-high-threshold? uint32
    +---rw ots-tx-voa-attenuation?                 uint32
    +---rw ots-ingress-safety-control-mode?       Ots-safety-control-mode
    +---rw ots-tone-detect-oob?                   empty
    +---rw ots-ingress-force-apr?                  boolean
    +---rw ots-raman-force-apr?                    boolean
    +---rw ots-egress-amplifier-gain-degrade-low-threshold? uint32
    +---rw ots-ingress-amplifier-gain-degrade-low-threshold? uint32
    +---rw ots-egress-amplifier-tilt?             int32

```

```

+--rw ots-raman-safety-control-mode?           Ots-safety-control-mode
+--rw ots-tone-frequency?                       string
+--rw ots-egress-amplifier-gain?                uint32
+--rw ots-tone-pattern?                        string
+--rw ots-egress-amplifier-gain-degrade-high-threshold?  uint32
+--rw ots-raman-osri?                          boolean
+--rw ots-egress-osri?                         boolean
+--rw ots-egress-amplifier-gain-range?
Ots-ingress-egress-ampli-gain-range
  +--rw ots-ingress-amplifier-gain-range?
Ots-ingress-egress-ampli-gain-range
  +--rw ots-ingress-amplifier-tilt?             int32
+--rw ots-tone-rate?                           uint32
+--rw ots-egress-force-apr?                     boolean

```

Configure Flex Grid in OLT

Step 1 Use the Cisco-IOS-XR-osa-linesystem-cfg.yang Yang model to configure flex grid channel in the OLT card.

| Yang Model | Example |
|--------------------------------------|--|
| Cisco-IOS-XR-osa-linesystem-cfg.yang | <pre> <rpc xmlns="urn:iETF:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <active-nodes xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-config-mdm-cfg"> <active-node> <node-name>0/0/NXR0</node-name> <terminal-amplifier xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-osa-linesystem-cfg"> <olt-grid-mode> <olt-channel-identifiers> <olt-channel-identifier> <channel-number>1</channel-number> <centre-frequency>191.375</centre-frequency> <channel-width>75</channel-width> </olt-channel-identifier> </olt-channel-identifiers> </olt-grid-mode> </terminal-amplifier> </active-node> </active-nodes> </config> </edit-config> </rpc> </pre> |

Step 2 Use the Cisco-IOS-XR-osa-hwmod-linesys-oper.yang Yang model to get the operational data of the flex grid channel configured on the OLT card.

| Yang Model | Example |
|---|---|
| Cisco-IOS-XR-osa-hwmod-linesys-operyang | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:0b9fd0cf-b58c-4af2-8503-7b20f933145d" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <osa xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-osa-hwmod-linesys-oper"> <node-ids> <node-id> <node-name>0/0/NXR0</node-name> <terminal-ampli> <status>slice-config-complete</status> <flexi-grid-info> <channel-number>1</channel-number> </flexi-grid-info> </terminal-ampli> <centre-frequency-thz>191.375000</centre-frequency-thz> <channel-width-ghz>75.000</channel-width-ghz> </node-id> </node-ids> </osa> </data> </rpc-reply> </pre> |

Configure Flex Grid in ILA card

Step 1 Use the Cisco-IOS-XR-osa-linesystem-cfg.yang Yang model to configure the flex grid channel in the ILA card.

| Yang Model | Example |
|--------------------------------------|--|
| Cisco-IOS-XR-osa-linesystem-cfg.yang | <pre> <rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <active-nodes xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-config-mdm-cfg"> <active-node> <node-name>0/0/NXR0</node-name> <inline-amplifier xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-osa-linesystem-cfg"> <ila-grid-mode> <ila-channel-identifiers> <ila-channel-identifier> <channel-number>1</channel-number> <centre-frequency>191.375</centre-frequency> <channel-width>75</channel-width> </ila-channel-identifier> </ila-channel-identifiers> </ila-grid-mode> </inline-amplifier> </active-node> </active-nodes> </config> </edit-config> </rpc> </pre> |

Step 2 Use the Cisco-IOS-XR-osa-hwmod-linesys-oper.yang Yang model to get the operational data for the flex grid channel configured on the ILA card.

| Yang Model | Example |
|---|--|
| Cisco-IOS-XR-osa-hwmod-linesys-operyang | <pre> <rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <active-nodes xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-config-mdm-cfg"> <active-node> <node-name>0/0/NXR0</node-name> <inline-amplifier xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-osa-linesystem-cfg"> <ila-grid-mode> <ila-channel-identifiers> <ila-channel-identifier> <channel-number>1</channel-number> <centre-frequency>191.375</centre-frequency> <channel-width>75</channel-width> </ila-channel-identifier> </ila-channel-identifiers> </ila-grid-mode> </inline-amplifier> </active-node> </active-nodes> </config> </edit-config> </rpc> </pre> |

Configure OTS Controller

Step 1 Use the Cisco-IOS-XR-controller-ots-cfg.yang Yang model to configure the OTS controller.

| Yang Model | Example |
|--------------------------------------|--|
| Cisco-IOS-XR-controller-ots-cfg.yang | <pre> <rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <interface-configurations xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-ifmgr-cfg"> <interface-configuration> <active>act</active> <interface-name>Ots0/0/0/0</interface-name> <ots xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-ots-cfg"> <ots-egress-safety-control-mode>auto</ots-egress-safety-control-mode> <ots-ingress-amplifier-gain>160</ots-ingress-amplifier-gain> <ots-ingress-osri>true</ots-ingress-osri> <ots-tx-voa-attenuation>200</ots-tx-voa-attenuation> <ots-ingress-force-apr>false</ots-ingress-force-apr> <ots-egress-amplifier-tilt>-40</ots-egress-amplifier-tilt> <ots-egress-amplifier-gain>180</ots-egress-amplifier-gain> <ots-egress-osri>false</ots-egress-osri> <ots-ingress-amplifier-gain-range>normal</ots-ingress-amplifier-gain-range> <ots-ingress-amplifier-tilt>50</ots-ingress-amplifier-tilt> <ots-egress-force-apr>true</ots-egress-force-apr> </ots> </interface-configuration> </interface-configurations> </config> </edit-config> </rpc> </pre> |

Step 2 Use the Cisco-IOS-XR-controller-ots-oper.yang Yang model to view the parameters of the OTS controller.

Note In the current release, all the controller models are mapped to the OTS controller model. Hence the operational data of all the controllers display "ots-state-up" as the controller state, and "ots-tas-ui-is" as transport-admin-sate, irrespective of the functionality.

| Yang Model | Example |
|---------------------------------------|---------|
| Cisco-IOS-XR-controller-ots-oper.yang | |

| Yang Model | Example |
|------------|--|
| | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:1ecef265-e94d-4b42-ad53-adb137a58efc" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <ots-oper xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-ots-oper"> <ots-ports> <ots-port> <name>Ots0/0/0/0</name> <ots-info> <transport-admin-state>ots-tas-ui-is</transport-admin-state> <controller-state>ots-state-up</controller-state> <tx-voa-attenuation>200</tx-voa-attenuation> <ingress-ampli-gain>160</ingress-ampli-gain> <ingress-ampli-tilt>50</ingress-ampli-tilt> <ingress-ampli-gain-range>ots-amplifier-gain-range-normal</ingress-ampli-gain-range> <egress-ampli-gain>180</egress-ampli-gain> <egress-ampli-tilt>-40</egress-ampli-tilt> <total-cl-tx-power>2000</total-cl-tx-power> <total-cl-rx-power>-1000</total-cl-rx-power> <receive-signal-power>2000</receive-signal-power> <transmit-signal-power>2000</transmit-signal-power> <ingress-ampli-osri>true</ingress-ampli-osri> <egress-ampli-osri>>false</egress-ampli-osri> <tx-power>-105</tx-power> </spectrum-slice-power-info> <spectrum-slice-power-info> <slice-num>1546</slice-num> <rx-power>-105</rx-power> <tx-power>-105</tx-power> </spectrum-slice-power-info> <spectrum-slice-power-info> <slice-num>1547</slice-num> <rx-power>-105</rx-power> <tx-power>-105</tx-power> </spectrum-slice-power-info> <spectrum-slice-power-info> <slice-num>1548</slice-num> <rx-power>-105</rx-power> <tx-power>-105</tx-power> </spectrum-slice-power-info> </spectrum-info> </ots-spectrum-info> </ots-port> </ots-ports> </ots-oper> </pre> |

| Yang Model | Example |
|------------|---|
| | <pre></data> </rpc-reply></pre> |

Configure OCH Controller

Step 1 Use the Cisco-IOS-XR-controller-och-cfg.yang Yang model to configure the OCH controller.

| Yang Model | Example |
|--------------------------------------|--|
| Cisco-IOS-XR-controller-och-cfg.yang | <pre><rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <interface-configurations xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-ifmgr-cfg"> <interface-configuration> <active>act</active> <interface-name>Och0/3/0/31</interface-name> <och xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-och-cfg"> <och-tone-pattern-expected>1234abcd</och-tone-pattern-expected> <och-tone-rate>20</och-tone-rate> </och> </interface-configuration> </interface-configurations> </config> </edit-config> </rpc></pre> |

Step 2 Use Cisco-IOS-XR-controller-och-oper.yang Yang model to view the OCH controller parameters.

| Yang Model | Example |
|---------------------------------------|--|
| Cisco-IOS-XR-controller-och-oper.yang | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:50bela71-e729-442d-aec7-14f486cd6028" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <och-oper xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-och-oper"> <och-ports> <och-port> <name>Och0/3/0/31</name> <och-info> <rx-power>0</rx-power> <tx-power>-5000</tx-power> <channel-frequency>191375</channel-frequency> <channel-width>1500</channel-width> <channel-wavelength>156652</channel-wavelength> <controller-state>ots-state-up</controller-state> <led-state>off</led-state> <rx-los-p> <is-detected>>false</is-detected> <counter>0</counter> </rx-los-p> <tx-power-fail-low> <is-detected>>false</is-detected> <counter>0</counter> </tx-power-fail-low> <och-tone-info> <tone-rate>20</tone-rate> <pattern-expected>1234abcd</pattern-expected> <dectected-oob>0</dectected-oob> <state>conn-vrfcn-state-not-running</state> </och-tone-info> <transport-admin-state>ots-tas-ui-is</transport-admin-state> </och-info> </och-port> </och-ports> </och-oper> </data> </rpc-reply> </pre> |

Configure Optical Cross-Connect

Step 1 Use the Cisco-IOS-XR-Ots-Och-cfg.yang Yang model to configure an optical cross-connect (OTS-OCH controller).

| Yang Model | Example |
|-------------------------------|---|
| Cisco-IOX-XR-Ots-Och-cfg.yang | <pre><rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <interface-configurations xmlns="http://cisco.com/ns/yang/Cisco-IOX-XR-ifmgr-cfg"> <interface-configuration> <active>act</active> <interface-name>Ots-Och0/0/0/0/1</interface-name> <ots-och xmlns="http://cisco.com/ns/yang/Cisco-IOX-XR-Ots-Och-cfg"> <add-drop-channel>Ots-Och0/0/0/2/1</add-drop-channel> </ots-och> </interface-configuration> </interface-configurations> </config> </edit-config></pre> |

Step 2 Use the Cisco-IOX-XR-controller-ots-och-oper.yang Yang model to view the parameters of the OTS-OCH controller.

| Yang Model | Example |
|---|--|
| Cisco-IOX-XR-controller-ots-och-oper.yang | <pre><?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:71601b7f-caee-4e65-9627-b5043e66436d" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <ots-och-oper xmlns="http://cisco.com/ns/yang/Cisco-IOX-XR-controller-ots-och-oper"> <ots-och-ports> <ots-och-port> <name>Ots-Och0/0/0/0/1</name> <ots-och-info> <transport-admin-state>ots-tas-ui-is</transport-admin-state> <controller-state>ots-state-up</controller-state> <add-drop-channel>Ots-Och0/0/0/2/1</add-drop-channel> <total-rx-power>-1050</total-rx-power> <total-tx-power>-1050</total-tx-power> </ots-och-info> </ots-och-port> </ots-och-ports> </ots-och-oper> </data> </rpc-reply></pre> |

Configure OMS Controller

Step 1 Use the Cisco-IOS-XR-controller-oms-cfg.yang Yang model to configure the OMS controller.

| Yang Model | Example |
|--------------------------------------|--|
| Cisco-IOS-XR-controller-oms-cfg.yang | <pre> <rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <interface-configurations xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-ifmgr-cfg"> <interface-configuration> <active>act</active> <interface-name>Oms0/3/0/32</interface-name> <oms xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-oms-cfg"> <oms-tone-rate>20</oms-tone-rate> <oms-tone-pattern-expected>abcd1234</oms-tone-pattern-expected> <oms-tone-detect-oob/> </oms> </interface-configuration> </interface-configurations> </config> </edit-config> </rpc> </pre> |

Step 2 Use the Cisco-IOS-XR-controller-oms-oper.yang Yang model to view the parameters of the OMS controller.

| Yang Model | Example |
|----------------------------------|--|
| Cisco-IOS-XR-controller-oms-oper | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:ba7b0faf-3762-4a8e-b9fe-e8d190a2dbe7" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <oms-oper xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-oms-oper"> <oms-ports> <oms-port> <name>Oms0/3/0/32</name> <oms-info> <rx-power>0</rx-power> <tx-power>0</tx-power> <controller-state>ots-state-up</controller-state> <led-state>off</led-state> <rx-los-p> <is-detected>>false</is-detected> <counter>0</counter> </rx-los-p> <tx-power-fail-low> <is-detected>>false</is-detected> <counter>0</counter> </tx-power-fail-low> <oms-tone-info> <tone-rate>20</tone-rate> <pattern-expected>abcd1234</pattern-expected> <decteded-oob>1</decteded-oob> <state>conn-vrfcn-state-not-running</state> </oms-tone-info> <transport-admin-state>ots-tas-ui-is</transport-admin-state> </oms-info> </oms-port> </oms-ports> </oms-oper> </data> </rpc-reply> </pre> |

Configure DFB Controller

Step 1 Use the Cisco-IOS-XR-controller-dfb-cfg.yang Yang model to configure the DFB controller.

| Yang Model | Example |
|--------------------------------------|--|
| Cisco-IOS-XR-controller-dfb-cfg.yang | <pre> <rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <interface-configurations xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-ifmgr-cfg"> <interface-configuration> <active>act</active> <interface-name>Dfb0/0/0/0</interface-name> <dfb xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-dfb-cfg"> <dfb-tx-voa-attenuation>150</dfb-tx-voa-attenuation> </dfb> </interface-configuration> </interface-configurations> </config> </edit-config> </rpc> </pre> |

Step 2 Use the Cisco-IOS-XR-controller-dfb-oper.yang Yang model to view the DFB controller parameters.

| Yang Model | Example |
|---------------------------------------|---|
| Cisco-IOS-XR-controller-dfb-oper.yang | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:41205dcf-f92f-4b73-bdf3-ba64438d15ac" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <dfb-oper xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-dfb-oper"> <dfb-ports> <dfb-port> <name>Dfb0/0/0/0</name> <dfb-info> <laser-state>on</laser-state> <controller-state>ots-state-up</controller-state> <transport-admin-state>ots-tas-ui-is</transport-admin-state> <total-rx-power>1000</total-rx-power> <total-tx-power>2000</total-tx-power> <tx-voa-attenuation>150</tx-voa-attenuation> <tx-voa-attenuation-config-val>150</tx-voa-attenuation-config-val> <rx-los-p> <is-detected>>false</is-detected> <counter>0</counter> </rx-los-p> <tx-power-fail-low> <is-detected>>false</is-detected> <counter>0</counter> </tx-power-fail-low> </dfb-info> </dfb-port> </dfb-ports> </dfb-oper> </data> </rpc-reply> </pre> |

Configure OSC Controller

Step 1 Use the Cisco-IOS-XR-controller-osc-cfg.yang Yang model to configure the OSC controller.

| Yang Model | Example |
|--------------------------------------|--|
| Cisco-IOS-XR-controller-osc-cfg.yang | <pre> <rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <interface-configurations xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-ifmgr-cfg"> <interface-configuration> <active>act</active> <interface-name>Osc0/0/0/0</interface-name> <osc xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-osc-cfg"> <osc-transmit-power>20</osc-transmit-power> <osc-transmit-shutdown>>false</osc-transmit-shutdown> </osc> </interface-configuration> </interface-configurations> </config> </edit-config> </rpc> </pre> |

Step 2 Use Cisco-IOS-XR-controller-osc-oper.yang Yang model to view the OSC controller parameters.

| Yang Model | Example |
|---------------------------------------|---|
| Cisco-IOS-XR-controller-osc-oper.yang | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:57794a6c-fe5b-425e-8df7-7c09a789b757" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <osc-oper xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-controller-osc-oper"> <osc-ports> <osc-port> <name>Osc0/0/0/0</name> <osc-info> <laser-state>off</laser-state> </osc-info> </osc-port> </osc-ports> </osc-oper> </data> </rpc-reply> </pre> |

Configure FPD Package

Step 1 Use the Cisco-IOS-XR-fpd-infra-cfg.yang Yang model to configure FPD package.

| Yang Model | Example |
|---------------------------------|---|
| Cisco-IOS-XR-fpd-infra-cfg.yang | <pre><rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <fpd xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-fpd-infra-cfg"> <auto-upgrade>enable</auto-upgrade> </fpd> </config> </edit-config> </rpc></pre> |

Step 2 Use Cisco-IOS-XR-show-fpd-loc-ng-oper.yang Yang model to view the operational data for FPD package details

| Yang Model | Example |
|--|--|
| Cisco-IOS-XR-show-fpd-loc-ng-oper.yang | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:a69ef4eb-f4c8-461e-8858-4d70169df583" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <show-fpd xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-show-fpd-loc-ng-oper"> <locations> <location> <location-name>0-RP0-CPU0</location-name> <fpds> <fpd> <fpd-name>fpd_list</fpd-name> <upgrade-status>No upgrade in progress</upgrade-status> <fpd-info-detaile> <location>0/RP0/CPU0</location> <card-name>NCS1010-CNTRLR-K9</card-name> <fpd-name>ADMConfig</fpd-name> <hw-version>0.1 </hw-version> <secure-boot-attr </secure-boot-attr> <status>NEED UPGD</status> <running-version> 7.01 </running-version> <programd-version> 7.01 </programd-version> <reload-location>0/RP0</reload-location> </fpd-info-detaile> <fpd-info-detaile> <location>0/RP0/CPU0</location> <card-name>NCS1010-CNTRLR-K9</card-name> <fpd-name>BIOS</fpd-name> <hw-version>0.1 </hw-version> . . . </fpds> </location> </locations> <set-timestamp>1654756033</set-timestamp> <clear-time>-</clear-time> <clear-timestamp>0</clear-timestamp> <description>Ots0/0/0/0 - APC blocked</description> </alarm-info> </active> </brief-system> </alarms> </data> </rpc-reply> </pre> |

View NCS 1010 Platform Details

Use the Cisco-IOS-XR-platform-oper.yang Yang model to view the platform details of the NCS 1010 node.

| Yang Models | Example |
|---------------------------------|---|
| Cisco-IOS-XR-platform-oper.yang | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:5323a66f-728c-45a8-a8be-96751fe7081a" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <platform xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-platform-oper"> <racks> <rack> <rack-name>0</rack-name> <slots> <slot> <slot-name>RP0</slot-name> <instances> <instance> <instance-name>CPU0</instance-name> <state> <card-type>NCS1010-CNTRLR-K9</card-type> <card-redundancy-state>active</card-redundancy-state> <state>not-applicable</state> <admin-state>NSHUT,NMON</admin-state> <node-name>0/RP0/CPU0</node-name> <oper-state>IOS XR RUN</oper-state> </state> </instance> </instances> </slot> <slot> . . . <card-type>NCS1K-MD-32E-C</card-type> <card-redundancy-state>red-state-none</card-redundancy-state> <state>not-applicable</state> <admin-state>NSHUT,NMON</admin-state> <node-name>0/3</node-name> <oper-state>OPERATIONAL</oper-state> </state> </slot> </slots> </rack> </racks> </platform> </data> </rpc-reply> </pre> |

View Performance Monitoring Parameters

Use Cisco-IOS-XR-pmengine-oper.yang Yang model to view the performance monitoring parameters on the controllers.

| Yang Model | Example |
|---------------------------------|---------|
| Cisco-IOS-XR-pmengine-oper.yang | |

| Yang Model | Example |
|------------|---|
| | <pre> rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <get> <filter> <performance-management xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-pmengine-oper"> <optics> <optics-ports> <optics-port> <name>Ots0/0/0/0</name> <optics-current> <optics-second30> <optics-second30-optics/> </optics-second30> </optics-current> </optics-port> </optics-ports> </optics> </performance-management> </filter> </get> </rpc> #####Response##### <?xml version="1.0"?> <rpc-reply message-id="101" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <performance-management xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-pmengine-oper"> <optics> <optics-ports> <optics-port> <name>Ots0/0/0/0</name> <optics-current> <optics-second30> <optics-second30-optics> <optics-second30-optic> <number>1</number> <index>0</index> <valid>true</valid> <timestamp>10:00:00 - 10:00:15 Thu Jun 16 2022</timestamp> <last-clear30-sec-time>never</last-clear30-sec-time> <sec30-support>true</sec30-support> <flex-bin-support>true</flex-bin-support> <flex-bin-interval>10</flex-bin-interval> <opt> <valid>true</valid> <minimum>20.00</minimum> <average>20.00</average> <maximum>20.00</maximum> <minimum-threshold>-20.00</minimum-threshold> <configured-min-thresh>NA</configured-min-thresh> <minimum-tca-report>>false</minimum-tca-report> . . . <valid>true</valid> <minimum>0.00</minimum> <average>0.00</average> <maximum>0.00</maximum> </pre> |

| Yang Model | Example |
|------------|---|
| | <pre> <minimum-threshold>-5.00</minimum-threshold> <configured-min-thresh>NA</configured-min-thresh> <minimum-tca-report>>false</minimum-tca-report> <maximum-threshold>5.00</maximum-threshold> <configured-max-thresh>NA</configured-max-thresh> <maximum-tca-report>>false</maximum-tca-report> <min-time>1655373600749422903</min-time> <max-time>1655373600749422903</max-time> </eat1> <iagn> <maximum-tca-report>>false</maximum-tca-report> <min-time>1655373600749422903</min-time> <max-time>1655373600749422903</max-time> -thresh> <minimum>40.00</minimum> <average>40.00</average> eport> <maximum-threshold>190.00</maximum-threshold> <configured-max-thresh>NA</configured-max-thresh> <maximum-tca-report>>false</maximum-tca-report> <min-time>1655373600749422903</min-time> <max-time>1655373600749422903</max-time> </raman-5> </optics-second30-optic> </optics-second30-optics> </optics-second30> </optics-current> </optics-port> </optics-ports> </optics> </performance-management> </data> </rpc-reply> </pre> |

Configure Equipment Mismatch Alarm

Use the Cisco-IOS-XR-osa-ct-cfg.yang Yang model to configure the equipment mismatch alarm. For example, when the NCS 1010 node is loaded with the OLT- C card and if you try to configure the node with a different line card configuration, the equipment mismatch alarm rises.

| Yang Model | Example |
|------------------------------|--|
| Cisco-IOS-XR-osa-ct-cfg.yang | <pre> <rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="101"> <edit-config> <target> <candidate/> </target> <config> <resrv-cli xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-osa-ct-cfg"> <slot-info-cli> <lc-slot>0_0_NXR0</lc-slot> <card-type-cli>ncslk-olt-r-c</card-type-cli> </slot-info-cli> </resrv-cli> </config> </edit-config> </rpc> </pre> |

View the List of Alarms on the NCS 1010 Node

Use the Cisco-IOS-XR-alarmgr-server-oper.yang Yang model to view the list of alarms generated on the NCS 1010 node.

| Yang Model | Example |
|---------------------------------------|--|
| Cisco-IOS-XR-alarmgr-server-oper.yang | <pre> <?xml version="1.0" ?> <rpc-reply message-id="urn:uuid:518e2c10-c837-4b36-9bab-93f935148ce5" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <data> <alarms xmlns="http://cisco.com/ns/yang/Cisco-IOS-XR-alarmgr-server-oper"> <brief> <brief-system> <active> <alarm-info> <location>0/Rack</location> <severity>major</severity> <group>fpd-infra</group> <set-time>06/09/2022 06:26:48 UTC</set-time> <set-timestamp>1654756008</set-timestamp> <clear-time>-</clear-time> <clear-timestamp>0</clear-timestamp> <description>One Or More FPDs Need Upgrade Or Not In Current State</description> </alarm-info> <alarm-info> <location>0/RP0/CPU0</location> <severity>major</severity> <group>fpd-infra</group> <set-time>06/09/2022 06:26:49 UTC</set-time> <set-timestamp>1654756009</set-timestamp> <clear-time>-</clear-time> <clear-timestamp>0</clear-timestamp> <description>One Or More FPDs Need Upgrade Or Not In Current State</description> </alarm-info> <alarm-info> <location>0/0/NXR0</location> <severity>major</severity> <group>fpd-infra</group> <set-time>06/09/2022 06:26:51 UTC</set-time> <set-timestamp>1654756011</set-timestamp> <clear-time>-</clear-time> <clear-timestamp>0</clear-timestamp> <description>One Or More FPDs Need Upgrade Or Not In Current State</description> </alarm-info> <alarm-info> <location>0/0/NXR0</location> <severity>minor</severity> <group>software</group> <set-time>06/09/2022 06:27:13 UTC</set-time> <set-timestamp>1654756033</set-timestamp> <clear-time>-</clear-time> <clear-timestamp>0</clear-timestamp> <description>Ots0/0/0/0 - APC blocked</description> </alarm-info> </active> </brief-system> </brief> </alarms> </data> </rpc-reply> </pre> |

Configure Optical Amplifier on OLT Line Card Using Open Config Model

The openconfig-optical-amplifier Yang model uses the following naming convention for the preamplifier and the booster amplifier in the OLT line card:

R/S-<AMP TYPE><ID>

- *R*—Rack.
- *S*—Slot.
- *<AMP TYPE>*—AMP-PRE (for preamplifier) or AMP-BST (for booster amplifier).
- *ID*—The value is 0 in openconfig.

For example, the amplifiers are mentioned as 0/0-AMP-PRE0 or 0/0-AMP-BST0 which is a line port 0/0/0 in the IOS-XR.

Step 1 Use the openconfig-optical-amplifier Yang model to configure the amplifier on the OLT line card.

| Openconfig Model | Example |
|------------------------------|--|
| openconfig-optical-amplifier | <pre>{ "openconfig-optical-amplifier:optical-amplifier": { "amplifiers": { "amplifier": [{ "name": "0/0-AMP-PRE0", "config": { "name": "0/0-AMP-PRE0", "target-gain": "19.00", "gain-range": "MID_GAIN_RANGE", "target-gain-tilt": "3.90", "enabled": true } }, { "name": "0/0-AMP-BST0", "config": { "name": "0/0-AMP-BST0", "target-gain": "19.00", "target-gain-tilt": "-1.5", "enabled": true } }] } } }</pre> |

Step 2 Get the operational data using GNMI.

```

{
  "openconfig-optical-amplifier": {
    "optical-amplifier": {
      "amplifiers": {
        "amplifier": {
          "0/0-AMP-BST0": {
            "state": {
              "enabled": true,
              "name": "0/0-AMP-BST0",
              "target-gain": 19.00,
              "target-gain-tilt": -1.5
            }
          },
          "0/0-AMP-PRE0": {
            "state": {
              "enabled": true,
              "gain-range": "MID_GAIN_RANGE",
              "name": "0/0-AMP-PRE0",
              "target-gain": 19.00,
              "target-gain-tilt": 3.90
            }
          }
        }
      }
    }
  }
}

```

Configure Optical Amplifier on ILA Line Card Using Open Config Model

The openconfig-optical-amplifier Yang model uses the following naming convention for the two booster amplifiers in the ILA line card:

*R/S-**<AMP TYPE>****<ID>***

- *R*—Rack.
- *S*—Slot.
- *<AMP TYPE>*—AMP-BST for the booster amplifier.
- *ID*—The value is 0 or 2 in openconfig.

For example, the amplifiers are mentioned as 0/0-AMP-BST0 and 0/0-AMP-BST2 which are the line ports ots0/0/0/0 and ots0/0/0/2 respectively in the IOS-XR.

Step 1 Use the openconfig-optical-amplifier Yang model to configure the amplifier on the ILA line card.

| Openconfig model | Example |
|------------------------------|---|
| openconfig-optical-amplifier | <pre> { "openconfig-optical-amplifier:optical-amplifier": { "amplifiers": { "amplifier": [{ "name": "0/0-AMP-BST0", "config": { "name": "0/0-AMP-BST0", "target-gain": "24.00", "target-gain-tilt": "-3.90", "enabled": false, "gain-range": "HIGH_GAIN_RANGE", } }, { "name": "0/0-AMP-BST2", "config": { "name": "0/0-AMP-BST2", "target-gain": "24.00", "target-gain-tilt": "-3.20", "enabled": false, "gain-range": "HIGH_GAIN_RANGE" } }] } } } </pre> |

Step 2 Get the operational data using GNMI.

```

{
  "openconfig-optical-amplifier": {
    "optical-amplifier": {
      "amplifiers": {
        "amplifier": {
          "0/0-AMP-BST0": {
            "state": {
              "enabled": false,
              "gain-range": "HIGH_GAIN_RANGE",
              "name": "0/0-AMP-BST0",
              "target-gain": 24.00,
              "target-gain-tilt": -3.90
            }
          },
          "0/0-AMP-BST2": {
            "state": {
              "enabled": false,
              "gain-range": "HIGH_GAIN_RANGE",
              "name": "0/0-AMP-BST2",
              "target-gain": 24.00,
              "target-gain-tilt": -3.20
            }
          }
        }
      }
    }
  }
}

```

Configure Optical Attenuator on OLT Line Card Using Open Config Model

The openconfig-attenuator Yang model uses the following naming convention for the Variable Optical Attenuator (VOA) on the Line-TX of the OLT line card:

R/S-VOA-BST<ID>

- *R*—Rack.
- *S*—Slot.
- *ID*—The value is 0 in openconfig.

For example, the VOA is mentioned as 0/0-VOA-BST0 which is a line port ots0/0/0/0 in the IOS-XR.

Step 1 Use the openconfig-attenuator Yang model to configure the attenuator on the OLT line card.

| Openconfig Model | Example |
|-------------------------------|--|
| openconfig-optical-attenuator | <pre>{ "openconfig-optical-attenuator:optical-attenuator": { "attenuators": { "attenuator": [{ "name": "0/0-VOA-BST0", "config": { "name": "0/0-VOA-BST0", "attenuation": "20.00" } }] } } }</pre> |

Step 2 Get the operational data using GNMI.

```
{
  "openconfig-optical-attenuator": {
    "optical-attenuator": {
      "attenuators": {
        "attenuator": {
          "0/0-VOA-BST0": {
            "state": {
              "attenuation": 20.00,
              "enabled": true,
              "name": "0/0-VOA-BST0"
            }
          }
        }
      }
    }
  }
}
```

}

Configure Optical Attenuator on ILA Line Card Using Open Config Model

The openconfig-attenuator Yang model uses the following naming convention for the VOAs on the Line-1 TX and Line-2 TX of the ILA line card:

R/S-VOA-BST<*ID*>

- *R*—Rack.
- *S*—Slot.
- *ID*—The value is 0 or 2 in openconfig to identify the line port.

For example, the VOAs are mentioned as 0/0-VOA-BST0 and 0/0-VOA-BST2 which are the line ports ots0/0/0/0 and ots0/0/0/2 respectively, in the IOS-XR.

Step 1 Use the openconfig-attenuator Yang model to configure the attenuator on the ILA line card.

| Openconfig Model | Example |
|-------------------------------|--|
| openconfig-optical-attenuator | <pre>{ "openconfig-optical-attenuator:optical-attenuator": { "attenuators": { "attenuator": [{ "name": "0/0-VOA-BST0", "config": { "name": "0/0-VOA-BST0", "attenuation": "15.00" } }, { "name": "0/0-VOA-BST2", "config": { "name": "0/0-VOA-BST2", "attenuation": "14.00" } }] } } }</pre> |

Step 2 Get the operational data using GNMI.

```
{
  "openconfig-optical-attenuator": {
    "optical-attenuator": {
      "attenuators": {
        "attenuator": {
```

```
"0/0-VOA-BST0": {
  "state": {
    "attenuation": 15.00,
    "enabled": true,
    "name": "0/0-VOA-BST0"
  }
},
"0/0-VOA-BST2": {
  "state": {
    "attenuation": 14.00,
    "enabled": true,
    "name": "0/0-VOA-BST2"
  }
}
}
}
}
}
```
