



CHAPTER 1

Overview of Cisco 4000 Series ISRs	1-1
Chassis Views	1-2
Cisco 4461 ISR Chassis	1-3
Platform Summary	1-8
Cisco 4451-X ISR Chassis	1-9
Platform Summary	1-12
Cisco 4431 ISR Chassis	1-12
Platform Summary	1-15
Cisco 4351 ISR Chassis	1-16
Platform Summary	1-18
Cisco 4331 ISR Chassis	1-19
Platform Summary	1-20
Cisco 4321 ISR Chassis	1-21
Platform Summary	1-22
Cisco 4221 ISR Chassis	1-23
Platform Summary	1-25
Locate Product Identification Details	1-26
Labels on Cisco 4000 Series ISRs	1-26
Additional Help for Locating Cisco 4000 Series ISRs Labels	1-27
Hardware Features of Cisco 4000 Series ISRs	1-27
Built-In Interface Ports	1-27
Dual Mode GE or SFP Ports	1-28
USB Serial Console Port	1-28
Front Panel PoE+ Ports	1-28
Internal PoE Daughter Card	1-28
LED Indicators	1-29
Removable and Interchangeable Modules and Cards	1-35
Network Interface Modules and Service Modules	1-35
Cisco UCS E-Series Server Modules	1-36
System Flash	1-36
Solid State Drives	1-36
Packet Voice Digital Signal Processor Modules	1-36
Memory	1-37

- Power Supply 1-37
- Fans, Ventilation, and Airflow 1-38
- Slots, Subslots (Bay), Ports, and Interfaces in Cisco 4000 Series ISRs 1-40
 - Slot Numbering 1-42
 - About Slot 0 1-42
 - Subslot/Bay Numbering 1-42
 - Gigabit Ethernet Management 1-42
- Specifications 1-43
- Periodic Inspection and Cleaning 1-45

CHAPTER 2

Cisco 4000 Series ISRs Preinstallation 2-1

- Standard Warning Statements 2-1
 - General Safety Warnings 2-2
- Safety Recommendations 2-5
 - Safety with Electricity 2-6
 - Prevent Electrostatic Discharge Damage 2-7
- General Site Requirements 2-7
 - General Precautions 2-7
 - Site Selection Guidelines 2-8
 - Site Environmental Requirements 2-8
 - Physical Characteristics 2-9
- Rack Requirements 2-9
- Router Environmental Requirements 2-9
- Power Guidelines and Requirements 2-10
- Network Cabling Specifications 2-10
 - Console and Auxiliary Port Considerations 2-11
 - Console Port Connections 2-11
 - Auxiliary Port Connections 2-12
 - Prepare for Network Connections 2-13
 - Ethernet Connections 2-13
- Required Tools and Equipment for Installation and Maintenance 2-13
- Installation Checklist 2-15
- Creating a Site Log 2-16

CHAPTER 3

Install and Connect Cisco 4000 Series ISRs 3-1

- Before You Begin 3-3
- Unpack the Router 3-4
- Install the Router 3-4

Set Chassis on Desktop	3-4
Attach Chassis to Wall or Mount Chassis in Rack	3-5
Install Cisco 4400 or 4300 ISR	3-5
Install Cisco 4200 Series ISR	3-12
Chassis Grounding	3-19
Connect Power	3-20
Connect to AC Power	3-21
Connect to Console Terminal or Modem	3-22
Connect to Serial Port with Microsoft Windows	3-22
Connect to Console Port with Mac OS X	3-23
Connect to Console Port with Linux	3-24
Install Cisco Microsoft Windows USB Device Driver	3-24
Install Cisco Microsoft Windows XP USB Driver	3-25
Install Cisco Microsoft Windows 2000 USB Driver	3-25
Install Cisco Microsoft Windows Vista USB Driver	3-25
Uninstall Cisco Microsoft Windows USB Driver	3-26
Uninstall Cisco Microsoft Windows XP and 2000 USB Driver	3-26
Uninstall Cisco Microsoft Windows Vista USB Driver	3-27
Connect WAN, LAN, and Voice Interfaces	3-27
Ports and Cabling	3-28
Connection Procedures and Precautions	3-29
Configure Initial Router Settings on Cisco 4000 Series ISRs	3-29
ROM Monitor Overview and Basic Procedures	3-29

CHAPTER 4**Configure Initial Router Settings on Cisco 4000 Series ISRs** 4-1

Perform Initial Configuration on Cisco 4000 Series ISRs	4-1
Use Cisco Setup Command Facility	4-1
Complete the Configuration	4-4
Use Cisco IOS XE CLI—Manual Configuration	4-5
Configure Cisco 4000 Series ISR Hostname	4-6
Configure the Enable and Enable Secret Passwords	4-7
Configure the Console Idle Privileged EXEC Timeout	4-8
Gigabit Ethernet Management Interface Overview	4-10
Default Gigabit Ethernet Configuration	4-10
Gigabit Ethernet Port Numbering	4-10
Configure Gigabit Ethernet Interfaces	4-11
Configuration Examples	4-12
Specify a Default Route or Gateway of Last Resort	4-13
Configure IP Routing and IP Protocols	4-13

- Default Routes 4-13
- Default Network 4-13
- Gateway of Last Resort 4-14
- Configuration Examples 4-15
- Configure Virtual Terminal Lines for Remote Console Access 4-16
- Configuration Examples 4-17
- Configure the Auxiliary Line 4-18
- Verify Network Connectivity 4-19
- Save Your Device Configuration 4-20
- Save Backup Copies of Configuration and System Image 4-20
- Configuration Examples 4-21
- Verify Initial Configuration on Cisco 4000 Series ISRs 4-23

CHAPTER 5

Install and Upgrade Internal Modules and FRUs 5-1

- Safety Warnings 5-2
- Modules Supported 5-4
- Access Internal Modules 5-4
 - Remove and Replace Chassis Cover 5-4
 - Remove Cover from Cisco 4400 or 4200 ISR 5-4
 - Remove Cover from Cisco 4300 ISR 5-5
 - Replace Cover on Cisco 4400 or 4200 ISR 5-5
 - Replace Cover on Cisco 4300 ISR 5-6
- Locate Internal and External Slots 5-6
 - Locate Internal and External Slots for Modules on Cisco 4461 ISR 5-7
 - Locate NEBS Module 5-8
 - Locate Internal and External Slots for Modules on Cisco 4451 ISR 5-8
 - Locate Internal and External Slots for Modules on Cisco 4351 ISR 5-10
 - Locate Internal and External Slots for Modules on Cisco 4331 ISR 5-11
- 5-11
- Overview of the SSD Carrier Card NIM (NIM-SSD) 5-11
 - Overview 5-12
 - LEDs on NIM-SSD 5-13
 - Solid State Drives 5-15
 - Install SSD Drives into the NIM Carrier Card 5-17
 - Remove SSD Drives from the NIM-SSD 5-18
- Overview of NIM-HDD Card 5-20
 - Cisco NIM-HDD LEDs 5-22
- Remove and Replace Cisco NIM-SSD or NIM-HDD 5-22
 - Remove NIM-SSD or NIM-HDD 5-24

Replace NIM-SSD or NIM-HDD	5-25
Install and Remove DDR DIMMs on Cisco 4400 or 4300 Series ISRs	5-25
Locate and Orient DIMM	5-25
Remove DIMM	5-26
Install DIMM	5-28
Install and Remove NIMs and SM-Xs on Cisco 4000 Series ISRs	5-30
Software Requirement for SM-Xs	5-31
Locate SM-X or NIM	5-31
Remove SM-X or NIM	5-31
Install SM-X	5-31
Verify SM-X Installation	5-32
Install and Remove PVD4 on Cisco 4400 or 4300 Series ISRs	5-32
Tools and Equipment Requirements	5-33
PVD4 Location and Orientation	5-33
Install PVD4 on the Motherboard of Cisco 4400 Series ISRs	5-34
Remove the PVD4 from the Motherboard of Cisco 4400 ISRs	5-35
Install the PVD4 on the Motherboard of Cisco 4331 ISR	5-36
Remove the PVD4 from the Motherboard of Cisco 4331 ISR	5-37
Install the PVD4 on Cisco Fourth-Generation T1/E1 Voice and WAN NIM	5-38
Remove the PVD4 from Cisco Fourth-Generation T1/E1 Voice and WAN NIM	5-39
Remove and Replace the USB Flash Token Memory Stick	5-39
Remove and Replace Cisco 4000 Series ISRs Power Supplies	5-40
AC Power Supplies	5-41
Overview of the AC Power Supply	5-41
Replace AC Power Supply	5-42
Overview of DC Power Supply	5-45
Remove DC Input Power from Cisco 4461 or 4431 ISR	5-47
Install DC Input Power on Cisco 4431 ISR	5-48
Replace the Power Supply Module the Cisco 4331 Router	5-51
Remove DC Input Power from Cisco 4331 ISR	5-52
Install DC Input Power on Cisco 4331 ISR	5-53
PoE Converter Power Supply Unit	5-56
Overview of the PoE Converter Power Supply Unit	5-56
Remove PoE Power Supply Slot Filler	5-57
Install the PoE Converter Power Supply	5-57
Remove PoE Converter Power Supply	5-58
Install the PoE Power Supply Slot Filler	5-58
Replace a Fan Tray	5-60
Before Hot-Swapping a Fan Tray	5-60

- Replace Fan Tray **5-60**
- Replace Fan Tray on Cisco 4331 ISR **5-62**
- Remove and Install a CompactFlash Memory Card **5-65**
 - Prevent Electrostatic Discharge Damage **5-65**
 - Remove the CompactFlash Memory Card **5-66**
 - Install the CompactFlash Memory Card **5-67**
- Remove and Install the Flash Memory Card **5-67**
 - Prevent Electrostatic Discharge Damage **5-68**
 - Install the Flash Memory Card **5-68**
 - Remove the Flash Memory Card **5-70**
- Install and Remove an SSD mSATA Storage Device **5-70**
 - Prevent Electrostatic Discharge Damage **5-70**
 - Install the SSD mSATA Storage Device **5-71**
 - Remove the SSD mSATA Storage Device **5-72**
- Install and Remove SFP Modules **5-73**
 - Install SFPs **5-75**
 - Laser Safety Guidelines **5-75**
 - Remove SFP Modules: **5-76**
- Remove, Replace, and Install the Internal PoE Daughter Card **5-77**

APPENDIX A

Online Insertion and Removal and Hot-Swapping A-1

- OIR Procedures **A-2**
 - Remove a Module **A-2**
 - Insert a Module **A-2**
 - Hot-Swapping Procedures **A-2**