



Managing Cisco Enhanced Services and Network Interface Modules

The router supports Cisco Enhanced Services Modules (SMs) and Cisco Network Interface Modules (NIMs). The modules are inserted into the router using an adapter, or carrier card, into various slots. For more information, see the [Hardware Installation Guide for the Cisco 4000 Series Integrated Services Routers](#).

The following sections are included in this chapter:

- [Information About Cisco Enhanced Services and Network Interface Modules, on page 1](#)
- [Modules Supported, on page 2](#)
- [Network Interface Modules, on page 2](#)
- [Enhanced Service Modules, on page 4](#)
- [Implementing SMs and NIMs on Your Router, on page 6](#)
- [Managing Modules and Interfaces, on page 13](#)
- [Monitoring and Troubleshooting Modules and Interfaces, on page 17](#)
- [Configuration Examples, on page 24](#)

Information About Cisco Enhanced Services and Network Interface Modules

The router configures, manages, and controls the supported Cisco Enhanced Services Modules (SMs) and Network Interface Modules (NIMs) using the module management facility built in its architecture. This new centralized module management facility provides a common way to control and monitor all the modules in the system regardless of their type and application. All Cisco Enhanced Service and Network Interface Modules supported on your router use standard IP protocols to interact with the host router. Cisco IOS software uses alien data path integration to switch between the modules.

- [Modules Supported, on page 2](#)
- [Network Interface Modules, on page 2](#)
- [Enhanced Service Modules, on page 4](#)

Modules Supported

For information about the interfaces and modules supported by the Cisco ISR 4400 series and Cisco ISR 4300 series routers, see <http://www.cisco.com/c/en/us/products/routers/4000-series-integrated-services-routers-isr/relevant-interfaces-and-modules.html>.

Network Interface Modules

The following Network Interface Modules are supported:

- [Cisco Fourth-Generation LTE Network Interface Module, on page 2](#)
- [Cisco 4-Port and 8-Port Layer 2 Gigabit EtherSwitch Network Interface Module, on page 2](#)
- [Cisco Fourth-Generation T1/E1 Voice and WAN Network Interface Module, on page 2](#)
- [Cisco SSD/HDD Carrier Card NIM, on page 3](#)
- [Upgrading the SSD or HDD Firmware, on page 3](#)
- [Error Monitoring, on page 4](#)

Cisco Fourth-Generation LTE Network Interface Module

Cisco 4G LTE NIM addresses the modular 4G LTE cellular connectivity on the Cisco 4000 Series ISRs. This is the first wireless NIM, though it is not the first wireless module in the ISR product line. The closest modular card to Cisco 4G LTE NIM is the Cisco EHWIC 4G LTE, which accepts a single LTE modem. Cisco 4G LTE NIM is feature-compatible with Cisco EHWIC 4G LTE. For more information, see the [Cisco Fourth-Generation LTE Network Interface Module Software Configuration Guide](#).

Cisco 4-Port and 8-Port Layer 2 Gigabit EtherSwitch Network Interface Module

The Cisco 4-Port and 8-Port Layer 2 Gigabit EtherSwitch Network Interface Module (NIM) integrates the Layer 2 features and provides a 1-Gbps connection to the multigigabit fabric (MGF) for intermodule communication. For more information on configuring the Cisco 4-Port and 8-Port Layer 2 Gigabit EtherSwitch NIM, see http://www.cisco.com/c/en/us/td/docs/routers/access/interfaces/NIM/software/configuration/guide/4_8PortGENIM.html.

Cisco Fourth-Generation T1/E1 Voice and WAN Network Interface Module

The Cisco Fourth-Generation T1/E1 Voice and WAN Network Interface Module (NIM) is inserted into the NIM slot of the router and provides data and voice support on T1/E1 trunks. To support voice-related and other DSP features, the Cisco PVD4 (Cisco Packet Voice Digital Signal Processor Module) is also required. See the following documents for more information:

- [Installing the Cisco Fourth-Generation T1/E1 Voice and WAN Network Interface Module](#)
- [Configuring the Cisco Fourth-Generation T1/E1 Voice and WAN Network Interface Module](#)

- [Installing the Cisco PVDM4](#)

Cisco SSD/HDD Carrier Card NIM

The router supports a single Cisco SSD and HDD Carrier Card NIM, which must be placed in slot 0 and subslot 1, 2, or 3.

A Cisco SSD/HDD Carrier Card NIM can be one of the following:

- Cisco SSD Carrier Card NIM—Supports one or two Solid-State Drives (SSDs).
- Cisco HDD Carrier Card NIM—Supports one Hard Disk Drive (HDD).

For more information on the hardware characteristics of the SSD/HDD Carrier Card NIM, see the [Hardware Installation Guide for the Cisco 4000 Series Integrated Services Routers](#).

For more information on deactivating or reactivating a SSD/HDD Carrier Card NIM, see [Deactivating and Reactivating an SSD/HDD Carrier Card NIM, on page 9](#).

Cisco 1-, 2-, and 4-Port Serial NIM

The Cisco 1-, 2-, and 4-port Serial NIMs are multi-protocol synchronous serial network interface modules (NIMs) supported on the Cisco 4400 Series ISRs. The Cisco 1-, 2-, and 4-port Serial NIMs expand the capabilities of the router to provide connectivity for synchronous interfaces in a wide range of applications including up to 8Mbps data rate for high speed high-level data link control (HDLC). These capabilities can be utilized as Point-to-Point Cisco HDLC WAN interface or frame relay interface. The Cisco 1-, 2-, and 4-port Serial NIMs have their own serial communication controllers (SCC) and they do not rely on the host router for SCCs. For further information on configuring this NIM, see the [Configuring the Cisco 1-, 2-, and 4-port Serial Network Interface Modules for the Cisco 4400 Series ISRs](#) document.

Upgrading the SSD or HDD Firmware

You can upgrade the firmware for the SSD or HDD using the **upgrade hw-programmable module filename bootflash:filename slot/sub-slot** command.

A typical *filename* has the form: *nim_ssd_manufacturer_firmware-version-number.bin*

The firmware file can also be available in other locations other than **bootflash:**

For example, you can provide any one of the following locations in place of **bootflash:filename**:

- **flash:***filename*
- **harddisk:***filename*
- **usb1:***filename*



Note For a Cisco SSD carrier card NIM or Cisco HDD carrier card NIM, only slot 0 and one of the subslots 1, 2, or 3 must be used.

The following example shows how to upgrade a Micron P400m disk to firmware revision 200 using the **upgrade hw-programmable module filename bootflash:filename slot/sub-slot** command:

```
Router# upgrade hw-programmable module filename bootflash:nim_ssd_Micr np400m_E200.bin
Info: Trying to upgrade Module in 0/3 with nim_ssd_MicronP400m_E200.bin
Info: Current NIM-SSD disk config.
Info: Disk1: rev: 0200 model: MicronP400m-MTFDDAK200MAN
Info: Disk2: rev: 0200 model: MicronP400m-MTFDDAK200MAN
/dev/sde:
fwdownload: xfer_mode=3 min=1 max=255 size=512
.....
Done.
/dev/sdf:
fwdownload: xfer_mode=3 min=1 max=255 size=512
.....
Done.
Info: Performing post upgrade check .....
Info: Upgrade to Firmware version E200 on disk1 successful.
Info: Upgrade to Firmware version E200 on disk2 successful.
Info: Current NIM-SSD disk config.
Info: Disk1: rev: E200 model: MicronP400m
```

Error Monitoring

The drives in the Cisco SDD/HDD Carrier Card NIM are monitored for SMART errors. If a SMART error occurs, a Cisco IOS error message is displayed, as shown in the following example:

```
%IOSXE-5-PLATFORM:logger: INFO:/dev/sde:SMART error present:please do
'more bootflash:/tracelogs/smart_errors.log'.
```

You can find additional information in the error log at: `bootflash:/tracelogs/smart_errors.log`

Enhanced Service Modules

The following service modules are supported on the router:

- [Cisco SM-1 T3/E3 Service Module, on page 4](#)
- [Cisco UCS E-Series Server, on page 4](#)
- [Cisco SM-X Layer 2/3 EtherSwitch Service Module, on page 5](#)
- [Cisco 6-Port GE SFP Service Module, on page 5](#)

Cisco SM-1 T3/E3 Service Module

For more information, see the [Cisco SM-1T3/E3 Enhanced Service Module Configuration Guide](#).

Cisco UCS E-Series Server

For more information, see the documentation listed in the [Cisco UCS E-Series Server Roadmap](#).

Cisco SM-X Layer 2/3 EtherSwitch Service Module

This module provides the following features:

- Integration of Layer 2 and Layer 3 switching features and the ability of the router to use the Cisco SM-X Layer 2/3 ESM (16-port and 24-port) as an independent Layer 3 switch.
- 1 Gbps connection to the multigigabit fabric (MGF) for intermodule communication without burdening the CPU of the router.
- Up to 30 watts of power per port with the robust Power over Ethernet Plus (PoE+) feature along with IEEE 802.3AE Media Access Control Security (MACSec) port-based, hop-to-hop, encryption, and Cisco TrustSec.

For more information, see the following documents:

- [Cisco SM-X Layer 2/3 EtherSwitch Service Module Configuration Guide for Cisco 4451-X ISR](#)
- [Connecting Cisco SM-X Layer 2/3 EtherSwitch Service Module to the Network](#)

Cisco 6-Port GE SFP Service Module

The Cisco 6-port GE SFP service module is a Gigabit Ethernet module that can be inserted into the router's SM slot to provide Gigabit Ethernet features on routable external interfaces. For more information about configuring this service module, see the [Software Configuration Guide for the Cisco 6-port GE SFP Service Module](#).

Cisco 4-port GE SFP and 1-port 10 GE SFP Service Module

The Cisco 4-port GE SFP and 1-port 10 GE SFP Service Module (SM-X-4x1GE-1x10GE) is software-configurable high-speed connectivity routing port service module for the Cisco ISR 4400 Series routers. This service module provides increased density of Ethernet interfaces on the Cisco ISR 4400 Series routers. For further information on configuring this service module, see: the [Software Configuration Guide for the Cisco 6-port GE SFP Service Module and Cisco 4-port GE SFP and 1-port 10 GE SFP Service Module](#)

Cisco 1GE-CU-SFP and 2GE-CU-SFP Network Interface Modules

The Cisco 1GE-CU-SFP and 2GE-CU-SFP Network Interface Modules (NIMs) are software-configurable high-speed connectivity routing port network interface modules for the Cisco 4000 and Cisco ISR 4300 Series Integrated Services Routers (ISR). These network interface modules provide increased density of Ethernet interfaces on the Cisco 4000 ISR. For further information on configuring this NIM, see the [Configuring the Cisco 1GE-CU-SFP and 2GE-CU-SFP Network Interface Modules in Cisco 4000 Series Integrated Services Routers](#).



Note Cisco 4221 ISR does not support 2GE-CU-SFP Network Interface Module.

Implementing SMs and NIMs on Your Router

- [Downloading the Module Firmware, on page 6](#)
- [Installing SMs and NIMs, on page 6](#)
- [Accessing Your Module Through a Console Connection or Telnet, on page 6](#)
- [Online Insertion and Removal, on page 7](#)

Downloading the Module Firmware

Module firmware must be loaded to the router to be able to use a service module. For more information, see [Installing a Firmware Subpackage](#).

The modules connect to the RP via the internal eth0 interface to download the firmware. Initially, the module gets an IP address for itself via BOOTP. The BOOTP also provides the address of the TFTP server used to download the image. After the image is loaded and the module is booted, the module provides an IP address for the running image via DHCP.

Installing SMs and NIMs

For more information, see "Installing and Removing NIMs and SMs" in the [Hardware Installation Guide for the Cisco 4000 Series Integrated Services Routers](#).

Accessing Your Module Through a Console Connection or Telnet

Before you can access the modules, you must connect to the host router through the router console or through Telnet. After you are connected to the router, you must configure an IP address on the Gigabit Ethernet interface connected to your module. Open a session to your module using the **hw-module session** command in privileged EXEC mode on the router.

To establish a connection to the module, connect to the router console using Telnet or Secure Shell (SSH) and open a session to the switch using the **hw-module session slot/subslot** command in privileged EXEC mode on the router.

Use the following configuration examples to establish a connection:

- The following example shows how to open a session from the router using the **hw-module session** command:

```
Router# hw-module session slot/card
Router# hw-module session 0/1 endpoint 0

Establishing session connect to subslot 0/1
```

- The following example shows how to exit a session from the router, by pressing **Ctrl-A** followed by **Ctrl-Q** on your keyboard:

```
type ^a^q
picocom v1.4

port is          : /dev/ttyDASH2
flowcontrol     : none
```

```

baudrate is      : 9600
parity is       : none
databits are    : 8
escape is      : C-a
noinit is      : no
noreset is     : no
nolock is      : yes
send_cmd is    : ascii_xfr -s -v -l10
receive_cmd is : rz -vv

```

Online Insertion and Removal

The router supports online insertion and removal (OIR) of Cisco Enhanced Services Modules and Cisco Network Interface Modules. You can perform the following tasks using the OIR function:

- [Preparing for Online Removal of a Module, on page 7](#)
- [Deactivating a Module, on page 7](#)
- [Deactivating Modules and Interfaces in Different Command Modes, on page 8](#)
- [Deactivating and Reactivating an SSD/HDD Carrier Card NIM, on page 9](#)
- [Reactivating a Module, on page 10](#)
- [Verifying the Deactivation and Activation of a Module, on page 10](#)

Preparing for Online Removal of a Module

The router supports the OIR of a module, independent of removing another module installed in your router. This means that an active module can remain installed in your router, while you remove another module from one of the subslots. If you are not planning to immediately replace a module, ensure that you install a blank filler plate in the subslot.

Deactivating a Module

A module can be removed from the router without first being deactivated. However, we recommend that you perform a graceful deactivation (or graceful power down) of the module before removing it. To perform a graceful deactivation, use the **hw-module subslot slot/subslot stop** command in EXEC mode.



Note When you are preparing for an OIR of a module, it is not necessary to independently shut down each of the interfaces before deactivating the module. The **hw-module subslot slot/subslot stop** command in EXEC mode automatically stops traffic on the interfaces and deactivates them along with the module in preparation for OIR. Similarly, you do not have to independently restart any of the interfaces on a module after OIR.

The following example shows how to use the **show facility-alarm status** command to verify if any critical alarm is generated when a module is removed from the system:

```

Router# show facility-alarm status
System Totals  Critical: 5  Major: 1  Minor: 0

Source          Severity      Description [Index]
-----
Power Supply Bay 1  CRITICAL     Power Supply/FAN Module Missing [0]

```

```

GigabitEthernet0/0/0    CRITICAL    Physical Port Link Down [1]
GigabitEthernet0/0/1    CRITICAL    Physical Port Link Down [1]
GigabitEthernet0/0/2    CRITICAL    Physical Port Link Down [1]
GigabitEthernet0/0/3    CRITICAL    Physical Port Link Down [1]
xcvr container 0/0/0     INFO        Transceiver Missing [0]
xcvr container 0/0/1     INFO        Transceiver Missing [0]
xcvr container 0/0/2     INFO        Transceiver Missing [0]
xcvr container 0/0/3     INFO        Transceiver Missing [0]
V: 1.0v PCH R0/18      MAJOR      Volt Above Normal [3]

```



Note A critical alarm (Active Card Removed OIR Alarm) is generated even if a module is removed after performing graceful deactivation.

Deactivating Modules and Interfaces in Different Command Modes

You can deactivate a module and its interfaces using the **hw-module subslot** command in one of the following modes:

- If you choose to deactivate your module and its interfaces by executing the **hw-module subslot slot/subslot shutdown unpowered** command in global configuration mode, you are able to change the configuration in such a way that no matter how many times the router is rebooted, the module does not boot. This command is useful when you need to shut down a module located in a remote location and ensure that it does not boot automatically when the router is rebooted.
- If you choose to use the **hw-module subslot slot/subslot stop** command in EXEC mode, you cause the module to gracefully shut down. The module is rebooted when the **hw-module subslot slot/subslot start** command is executed.

To deactivate a module and all of its interfaces before removing the module, use one of the following commands in global configuration mode.

Procedure

	Command or Action	Purpose
Step 1	hw-module subslot slot/subslot shutdown unpowered Example: Router# hw-module subslot 0/2 shutdown unpowered	Deactivates the module located in the specified slot and subslot of the router, where: <ul style="list-style-type: none"> • <i>slot</i>—Specifies the chassis slot number where the module is installed. • <i>subslot</i>—Specifies the subslot number of the chassis where the module is installed. • shutdown—Shuts down the specified module. • unpowered—Removes all interfaces on the module from the running configuration and the module is powered off.
Step 2	hw-module subslot slot/subslot [reload stop start] Example:	Deactivates the module in the specified slot and subslot, where:

	Command or Action	Purpose
	<pre>Router# hw-module subslot 0/2 stop</pre>	<ul style="list-style-type: none"> • <i>slot</i>—Specifies the chassis slot number where the module is installed. • <i>subslot</i>—Specifies the subslot number of the chassis where the module is installed. • reload—Stops and restarts the specified module. • stop—Removes all interfaces from the module and the module is powered off. • start—Powers on the module similar to a physically inserted module in the specified slot. The module firmware reboots and the entire module initialization sequence is executed in the IOSd and Input/Output Module daemon (IOMd) processes.

Deactivating and Reactivating an SSD/HDD Carrier Card NIM

The following restrictions apply:

- Deactivating or reactivating an SSD/HDD Carrier Card NIM without an SSD or HDD disk is not supported.
- Only a single (SSD or HDD) Carrier Card NIM can be plugged into a bay. If you plug an additional (SSD or HDD) Carrier Card NIM into another bay, the module powers down and kernel, log, or error messages are displayed on the Cisco IOS console. In rare cases, the file system may get corrupted on the additional drive.



Caution Deactivation of an SSD/HDD Carrier Card NIM may cause loss of data.

To deactivate an SSD/HDD Carrier Card NIM, perform the following steps:

Procedure

	Command or Action	Purpose
<p>Step 1</p>	<pre>virtual-service name</pre> <p>Example:</p> <pre>Router(config)# virtual-service my-kwaas-instance</pre>	<p>Identifies the kWAAS service (by name), supported on your router, in preparation for the router to be shut down by the no activate command. We recommend that you use this command before reseating or replacing an SSD or HDD.</p>
<p>Step 2</p>	<pre>no activate</pre> <p>Example:</p> <pre>Router(config-virt-serv)# no activate</pre>	<p>Shuts down the kWAAS instance on your router. kWAAS services remain installed. The service will have to be reactivated after the HDD/SSD NIM (module) is restarted.</p>
<p>Step 3</p>	<pre>hw-module subslot slot/subslot [reload stop start]</pre> <p>Example:</p> <pre>Router# hw-module subslot 0/2 stop Proceed with stop of module? [confirm]</pre>	<p>Deactivates or reactivates the module in the specified slot and subslot.</p> <ul style="list-style-type: none"> • <i>slot</i>—The chassis slot number where the module is installed.

	Command or Action	Purpose
	<pre>Router# *Mar 6 15:13:23.997: %SPA_OIR-6-OFFLINECARD: SPA (NIM-SSD) offline in subslot 0/2 ...</pre>	<ul style="list-style-type: none"> • subslot—The subslot number of the chassis where the module is installed. • reload—Deactivates and reactivates (stops and restarts) the specified module. • stop—Removes all interfaces from the module and the module is powered off. • start—Powers on the module similar to a physically inserted module in the specified slot. The module firmware reboots and the entire module initialization sequence is executed in the IOSd and IOMd processes.
Step 4	Wait for the EN (Enable) LED to turn off, and then remove the SSD/HDD Carrier Card NIM.	

Reactivating a Module

If, after deactivating a module using the **hw-module subslot slot/subslot stop** command, you want to reactivate it without performing an OIR, use one of the following commands (in privileged EXEC mode):

- **hw-module subslot slot/subslot start**
- **hw-module subslot slot/subslot reload**

Verifying the Deactivation and Activation of a Module

When you deactivate a module, the corresponding interfaces are also deactivated. This means that these interfaces will no longer appear in the output of the **show interface** command.

1. To verify the deactivation of a module, enter the **show hw-module subslot all oir** command in privileged EXEC configuration mode.

Observe the "Operational Status" field associated with the module that you want to verify. In the following example, the module located in subslot 1 of the router is administratively down.

```
Router# show hw-module subslot all oir

Module           Model           Operational Status
-----
subslot 0/0      ISR4451-4X1GE   ok
subslot 1/0      SM-X-T1/E1      ok
```

2. To verify activation and proper operation of a module, enter the **show hw-module subslot all oir** command and observe "ok" in the **Operational Status** field as shown in the following example:

```
Router# show hw-module subslot all oir

Module           Model           Operational Status
-----
subslot 0/1      NIM-8MFT-T1/E1  ok
```

subslot 1/0 SM-X T1/E1 ok

Router# show platform hardware backplaneswitch-manager R0 status

slot	bay	port	enable	link status	speed(Mbps)	duplex	autoneg	pause_tx	pause_rx	mtu
------	-----	------	--------	-------------	-------------	--------	---------	----------	----------	-----

0	0	CP	True	Up	1000	Full	ENABLED	ENABLED		
ENABLED		10240								
1	0	GE1	True	Up	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
1	0	GE0	True	Up	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
2	0	GE1	True	Up	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
2	0	GE0	True	Up	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	1	GE1	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	1	GE0	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	2	GE1	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	2	GE0	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	3	GE1	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	3	GE0	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	4	GE1	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	4	GE0	True	Down	1000	Full	DISABLED	ENABLED		
ENABLED		10240								
0	0	FFP	True	Up	10000	Full	ENABLED	DISABLED		
DISABLED		10240								

slot	bay	port	mac	vid	modid	flags - Layer 2
------	-----	------	-----	-----	-------	-----------------

0	0	FFP	2c54.2dd2.661b	2351	1	0x20
0	0	FFP	2c54.2dd2.661b	2352	1	0x20
0	0	CP	2c54.2dd2.661e	2351	0	0xC60
0	0	CP	2c54.2dd2.661e	2352	0	0x20
1	0	GE0	58bf.ea3a.00f6	2350	0	0x460
0	0	FFP	2c54.2dd2.661b	2350	1	0x20
1	0	GE0	58bf.ea3a.00f6	2352	0	0x20
0	0	CP	2c54.2dd2.661e	2350	0	0x20
1	0	GE0	58bf.ea3a.00f6	2351	0	0xC60

Port block masks: rows=from port, columns=to port, u=unknown unicast, m=unknown multicast, b=broadcast, A=all

	CP	FFP	1/0/1	1/0/0	2/0/1	2/0/0	0/1/1	0/1/0	0/2/1	0/2/0	0/3/1
--	----	-----	-------	-------	-------	-------	-------	-------	-------	-------	-------

0/3/0	0/4/1	0/4/0	drops								
CP	-	A	um	um	um	um	um	um	um	um	um
um	um	um	1								
FFP	A	-	-	-	-	-	-	-	-	-	-
-	-	-	0								
1/0/1	um	umb	-	umb	umb	umb	umb	umb	umb	umb	umb
umb	umb	umb	0								
1/0/0	um	umb	umb	-	umb	umb	umb	umb	umb	umb	umb
umb	umb	umb	6								
2/0/1	um	umb	umb	umb	-	umb	umb	umb	umb	umb	umb
umb	umb	umb	0								
2/0/0	um	umb	umb	umb	umb	-	umb	umb	umb	umb	umb
umb	umb	umb	6								
0/1/1	um	umb	umb	umb	umb	umb	-	umb	umb	umb	umb

Verifying the Deactivation and Activation of a Module

```

umb    umb    umb    0
0/1/0    um    umb    umb    umb    umb    umb    umb    umb    -    umb    umb    umb
umb    umb    umb    0
0/2/1    um    umb    umb    umb    umb    umb    umb    umb    umb    -    umb    umb
umb    umb    umb    0
0/2/0    um    umb    umb    umb    umb    umb    umb    umb    umb    umb    -    umb
umb    umb    umb    0
0/3/1    um    umb    umb    umb    umb    umb    umb    umb    umb    umb    umb    -
umb    umb    umb    0
0/3/0    um    umb    umb    umb    umb    umb    umb    umb    umb    umb    umb    umb
-    umb    umb    0
0/4/1    um    umb    umb    umb    umb    umb    umb    umb    umb    umb    umb    umb
umb    -    umb    0
0/4/0    um    umb    umb    umb    umb    umb    umb    umb    umb    umb    umb    umb
umb    umb    -    0
    
```

Port VLAN membership: [untagged vlan] U=untagged T=tagged <VLAN range begin>-<VLAN range end>

```

CP [2352] U:0001-0001 T:0002-2351 U:2352-2352 T:2353-4095
FFP [2352] T:0001-4095
1/0/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
1/0/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
2/0/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
2/0/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/1/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/1/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/2/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/2/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/3/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/3/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/4/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/4/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
    
```

show platform hardware backplaneswitch-manager rp active ffp statistics: Example

Router# **show platform hardware backplaneswitch-manager rp active ffp statistics**
 Broadcom 10G port (e.g: FFP) status:

	Rx pkts	Rx Bytes	Tx Pkts	Tx Bytes
All	0	0	0	0
=64	0		0	
65~127	0		0	
128~255	0		0	
256~511	0		0	
512~1023	0		0	
1024~1518	0		0	
1519~2047	0		0	
2048~4095	0		0	
4096~9216	0		0	
9217~16383	0		0	
Max	0		0	
Good	0		0	
CoS 0			0	0
CoS 1			0	0
CoS 2			0	0
CoS 3			0	0
CoS 4			0	0
CoS 5			0	0
CoS 6			0	0
CoS 7			0	0
Unicast	0		0	

Multicast	0	0	
Broadcast	0	0	
Control	0		
Errored			
FCS	0	0	
Undersize	0		
Ether len	0		
Fragment	0	0	
Jabber	0		
MTU ck, good	0		
MTU ck, bad	0		
Tx underflow			0
err symbol	0		
frame err	0		
junk	0		
Drops			
CoS 0		0	0
CoS 1		0	0
CoS 2		0	0
CoS 3		0	0
CoS 4		0	0
CoS 5		0	0
CoS 6		0	0
CoS 7		0	0
STP	0		
backpress	0		
congest	0	0	
purge/cell	0		
no destination	0		
Pause PFC	0	0	
CoS 0	0		
CoS 1	0		
CoS 2	0		
CoS 3	0		
CoS 4	0		
CoS 5	0		
CoS 6	0		
CoS 7	0		

Managing Modules and Interfaces

The router supports various modules. For a list of supported modules, see [Modules Supported, on page 2](#). The module management process involves bringing up the modules so that their resources can be utilized. This process consists of tasks such as module detection, authentication, configuration by clients, status reporting, and recovery. For detailed information about module configuration, see the module documentation referred to in the [Documentation Roadmap for the Cisco 4000 Series Integrated Services Routers](#).

For a list of small-form-factor pluggable (SFP) modules supported on your router, see the "Installing and Upgrading Internal Modules and FRUs" section in the [Hardware Installation Guide for the Cisco 4000 Series Integrated Services Routers](#).

The following sections provide additional information on managing the modules and interfaces:

- [Managing Module Interfaces, on page 14](#)
- [Managing Modules and Interfaces Using Backplane Switch, on page 14](#)

Managing Module Interfaces

After a module is in service, you can control and monitor its module interface. Interface management includes configuring clients with **shut** or **no shut** commands and reporting on the state of the interface and the interface-level statistics.

Monitor the module status and other statistical information using the **show** commands listed in [Monitoring and Troubleshooting Modules and Interfaces](#), on page 17.

Managing Modules and Interfaces Using Backplane Switch

- [Backplane Ethernet Switch](#), on page 14
- [Viewing Module and Interface Card Status on a Router](#), on page 14
- [Viewing Backplane Switch Statistics](#), on page 15
- [Viewing Backplane Switch Port Statistics](#), on page 15
- [Viewing Slot Assignments](#), on page 16

Backplane Ethernet Switch

The backplane Ethernet switch on your router provides connectivity to Enhanced Service Modules and Network Interface Modules (NIMs). The backplane Ethernet switch facilitates all packet transfers between the host router and its pluggable modules.

The backplane Ethernet switch act as a manager for the host router and controls the module and exchanges logical flow-control information with the module to ensure accurate feedback to the router features. See [Managing Modules and Interfaces](#), on page 13 for more information. The backplane Ethernet switch also facilitates control plane traffic flow from the host router to the modules. The backplane switch manages modules and interface cards and is used to communicate with the modules. Module drivers integrate with the backplane switch to configure packet flow and control traffic buffering.

You are not required to perform any configuration tasks on the backplane switch; all the configurations are performed from the module, which may or may not lead to changes on the backplane switch. For more information on installing an adapter, see the [Hardware Installation Guide for the Cisco ISR 4000 Series Integrated Services Routers](#).



Note Layer 2 protocols, such as the IEEE 802.1D Spanning Tree Protocol (STP), are not supported in the backplane Ethernet switch.

Viewing Module and Interface Card Status on a Router

You can view the module and interface card details using the **show platform** command in privileged EXEC mode.

The following example shows the sample output for the **show platform** command:

```
Router# show platform
Chassis type: ISR4451/K9

Slot          Type                               State          Insert time (ago)
```

```

-----
0          ISR4451/K9          ok          15:57:33
0/0       ISR4451-4X1GE       ok          15:55:24
0/3       NIM-SSD             ok          15:55:24
1          ISR4451/K9          ok          15:57:33
1/0       SM-1T3/E3           ok          15:55:24
2          ISR4451/K9          ok          15:57:33
2/0       SM-1T3/E3           ok          15:55:24
R0        ISR4451/K9          ok, active  15:57:33
F0        ISR4451-FP          ok, active  15:57:33
P0        Unknown             ps, fail   never
P1        XXX-XXXX-XX         ok          15:56:58
P2        ACS-4450-ASSY       ok          15:56:58

Slot      CPLD Version          Firmware Version
-----
0          12090323          15.3(01r)S   [ciscouser-ISRRO...
1          12090323          15.3(01r)S   [ciscouser-ISRRO...
2          12090323          15.3(01r)S   [ciscouser-ISRRO...
R0        12090323          15.3(01r)S   [ciscouser-ISRRO...
F0        12090323          15.3(01r)S   [ciscouser-ISRRO...
    
```

Viewing Backplane Switch Statistics

Statistics reports for each slot show incoming and outgoing packets or bytes. You can use the information to check traffic flow on the various ports of the backplane switch. The following example shows a sample output for the **show platform hardware backplaneswitch-manager rp active summary** command:

```

Router# show platform hardware backplaneswitch-manager rp active summary
slot      bay      port      InBytes      InPkts      OutBytes      OutPkts
-----
0          0          CP          6242          9361008      6241          403209
1          0          GE1          0              0              0              0
1          0          GE0          6306          407477       6241          9360934
2          0          GE1          0              0              0              0
2          0          GE0          0              0              0              0
0          1          GE1          0              0              0              0
0          1          GE0          0              0              0              0
0          2          GE1          0              0              0              0
0          2          GE0          0              0              0              0
0          3          GE1          0              0              0              0
0          3          GE0          0              0              0              0
0          4          GE1          0              0              0              0
0          4          GE0          0              0              0              0
0          0          FFP          0              0              0              0
0          0          FFP          0              0              0              0
    
```

Viewing Backplane Switch Port Statistics

You can view statistical information related to the port connected to the backplane switch using the **show platform hardware backplaneswitch-manager rp active subslot GEO statistics** command. The following example displays statistical information related to the backplane switch and ports connected to it:

```

Router# show platform hardware backplaneswitch-manager rp active subslot 1/0 GEO statistics
Broadcom 1G port(e.g: NIM, ESM, CP) status:
              Rx pkts      Rx Bytes      Tx Pkts      Tx Bytes
-----
All          6306          407477       6241          9360934
=64          6237          72
65~127      66              3
    
```

```

128~255                0                0
256~511                1                3
512~1023               2                0
1024~1518              0                6163
1519~2047              0                0
2048~4095              0                0
4096~9216              0                0
Good                   6306              6241
  CoS 0                 0                6171          9356426
  CoS 1                 0                0                0
  CoS 2                 0                0                0
  CoS 3                 0                0                0
  CoS 4                 0                0                0
  CoS 5                 0                0                0
  CoS 6                 70               4508
  CoS 7                 0                0                0
  Unicast               6294              6241
  Multicast             6                0
  Broadcast             6                0
  Control               0                0
  VLAN                 0                0
Errored
  FCS                  0                0
  Runts                0                0
  Undersize            0
  Ether len            0
  Fragment             0                0
  Jabber               0                0
  MTU                  0
Drops
  CoS 0                0                0
  CoS 1                0                0
  CoS 2                0                0
  CoS 3                0                0
  CoS 4                0                0
  CoS 5                0                0
  CoS 6                0                0
  CoS 7                0                0
  STP                  0
  backpress            0
  congest              0                0
  purge/cell          0
  no destination      65
Pause                  0                0

```

Viewing Slot Assignments

Use the **show inventory** command in privileged EXEC mode to view the slot assignments, as shown in the following example:

```

Router# show inventory
NAME: "Chassis", DESCR: "Cisco ISR4451 Chassis"
PID: ISR4451/K9          , VID: V01, SN: FGL163910CM

NAME: "Power Supply Module 1", DESCR: "Cisco 4451-X ISR 450W AC Power Supply"
PID: XXX-XXXX-XX       , VID: XXX, SN: DCA1623X05N

NAME: "Fan Tray", DESCR: "Cisco 4451-X ISR Fan tray"
PID: ACS-4450-FANASSY  , VID:   , SN:

NAME: "module 0", DESCR: "Cisco ISR4451 Built-In NIM controller"
PID: ISR4451/K9        , VID:   , SN:

```



```

NAME: "NIM subslot 0/1", DESCR: " NIM-1MFT-T1/E1 - T1/E1 Serial Module"
PID: NIM-1MFT-T1/E1 , VID: V01, SN: FOC16254E71

NAME: "subslot 0/1 db module 0", DESCR: "PVDM4-TDM-280 Voice DSP Module"
PID: PVDM4-TDM-280 , VID: V01, SN: FOC16290GRT

NAME: "NIM subslot 0/0", DESCR: "Front Panel 4 ports Gigabitethernet Module"
PID: ISR4451-X-4x1GE , VID: V01, SN: JAB092709EL

NAME: "module 1", DESCR: "Cisco ISR4451 Built-In SM controller"
PID: ISR4451/K9 , VID: , SN:

NAME: "module 2", DESCR: "Cisco ISR4451 Built-In SM controller"
PID: ISR4451/K9 , VID: , SN:

NAME: "SM subslot 2/0", DESCR: "SM-X-1T3/E3 - Clear T3/E3 Serial Module"
PID: SM-1T3/E3 , VID: V01, SN: FOC15495HSE

NAME: "module R0", DESCR: "Cisco ISR 4451-X Route Processor"
PID: ISR4451/K9 , VID: V01, SN: FOC163679GH

NAME: "module F0", DESCR: "Cisco ISR4451-X Forwarding Processor"
PID: ISR4451/K9 , VID: , SN:

```

Monitoring and Troubleshooting Modules and Interfaces

Use the following commands in global configuration mode to monitor and troubleshoot the modules and interfaces:

- **show platform**
- **show platform software backplaneswitch-manager RP [active [detail]]**
- **show platform hardware backplaneswitch-manager RPactive CP statistics**
- **show platform hardware backplaneswitch-manager RP active summary**
- **show platform hardware backplaneswitch-manager [R0 [status] | RP]**
- **show diag all eeprom details**

show platform

```

Router# show platform
Chassis type: ISR4451/K9

```

Slot	Type	State	Insert time (ago)
0	ISR4451/K9	ok	15:57:33
0/0	ISR4451-4X1GE	ok	15:55:24
1	ISR4451/K9	ok	15:57:33
1/0	SM-1T3/E3	ok	15:55:24
2	ISR4451/K9	ok	15:57:33
2/0	SM-1T3/E3	ok	15:55:24
R0	ISR4451/K9	ok, active	15:57:33
F0	ISR4451-FP	ok, active	15:57:33
P0	Unknown	ps, fail	never
P1	XXX-XXXX-XX	ok	15:56:58
P2	ACS-4450-FANASSY	ok	15:56:58

Slot	CPLD Version	Firmware Version	
0	12090323	15.3(01r)S	[ciscouser-ISRRO...
1	12090323	15.3(01r)S	[ciscouser-ISRRO...
2	12090323	15.3(01r)S	[ciscouser-ISRRO...
R0	12090323	15.3(01r)S	[ciscouser-ISRRO...
F0	12090323	15.3(01r)S	[ciscouser-ISRRO...

Table 1: show platform Field Descriptions

Field	Description
Slot	Slot number
Type	Type of module
State	Status of module
Insert Time	Time since the module has been up and running

show platform software backplaneswitch-manager RP [active [detail]]

Router# **show platform software backplaneswitch-manager RP active detail**
 BSM Software Display

module port	port type	alien type	traf type
0/1/0	NGIO	TRUNK	NGIO
0/1/1	NGIO	TRUNK	NGIO
0/2/0	NGIO	TRUNK	NGIO
0/2/1	NGIO	TRUNK	NGIO
0/3/0	NGIO	TRUNK	NGIO
0/3/1	ALIEN	TRUNK	NGIO
0/4/0	NGIO	TRUNK	NGIO
0/4/1	NGIO	TRUNK	NGIO
1/0/0	NGIO	TRUNK	NGIO
1/0/1	NGIO	TRUNK	NGIO
2/0/0	NGIO	TRUNK	NGIO
2/0/1	NGIO	TRUNK	NGIO

show platform hardware backplaneswitch-manager RPactive CP statistics

Router# **show platform hardware backplaneswitch-manager RP active CP statistics**
 Broadcom 1G port(e.g: NIM, NGSM, CP) status:

	Rx pkts	Rx Bytes	Tx Pkts	Tx Bytes
All	6242	9361008	6241	403209
=64	72		6178	
65~127	4		60	
128~255	0		0	
256~511	3		1	
512~1023	0		2	
1024~1518	6163		0	
1519~2047	0		0	
2048~4095	0		0	
4096~9216	0		0	
Good	6242		6241	
CoS 0			0	0
CoS 1			0	0
CoS 2			0	0

```

CoS 3                6241                403209
CoS 4                  0                    0
CoS 5                  0                    0
CoS 6                  0                    0
CoS 7                  0                    0
Unicast                6241                6235
Multicast              1                    0
Broadcast              0                    6
Control                0                    0
VLAN                   0                    0
Errored
FCS                    0                    0
Runts                  0                    0
Undersize              0                    0
Ether len              0                    0
Fragment               0                    0
Jabber                 0                    0
MTU                    0                    0
Drops
CoS 0                  0                    0
CoS 1                  0                    0
CoS 2                  0                    0
CoS 3                  0                    0
CoS 4                  0                    0
CoS 5                  0                    0
CoS 6                  0                    0
CoS 7                  0                    0
STP                    0                    0
backpress              0                    0
congest                0                    0
purge/cell             0                    0
no destination         1                    0
Pause                  0                    0
    
```

show platform hardware backplaneswitch-manager RP active summary

```

Router# show platform hardware backplaneswitch-manager RP active summary
slot      bay      port      InBytes      InPkts      OutBytes      OutPkts
-----
0         0         CP        242          0           0            0
1         0         GE1       0            0           0            0
1         0         GE0       0            0           0            0
2         0         GE1       0            0           0            0
2         0         GE0       0            0           0            0
0         1         GE1       0            0           0            0
0         1         GE0       0            0           0            0
0         2         GE1       0            0           0            0
0         2         GE0       0            0           0            0
0         3         GE1       0            0           0            0
0         3         GE0       0            0           0            0
0         4         GE1       0            0           0            0
0         4         GE0       0            0           0            0
0         0         FFP       0            0           0            0
    
```

show platform hardware backplaneswitch-manager [R0 [status] | RP]

```

Router# show platform hardware backplaneswitch-manager R0 status
slot bay  port  enable  link status  speed(Mbps)  duplex  autoneg  pause_tx
pause_rx  mtu
-----
0      0    CP    True    Up          1000         Full    ENABLED  ENABLED
ENABLED 10240
    
```

Monitoring and Troubleshooting Modules and Interfaces

1	0	GE1	True	Up	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
1	0	GE0	True	Up	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
2	0	GE1	True	Up	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
2	0	GE0	True	Up	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	1	GE1	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	1	GE0	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	2	GE1	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	2	GE0	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	3	GE1	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	3	GE0	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	4	GE1	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	4	GE0	True	Down	1000	Full	DISABLED	ENABLED	
ENABLED		10240							
0	0	FFP	True	Up	10000	Full	ENABLED	DISABLED	
DISABLED		10240							

slot	bay	port	mac	vid	modid	flags - Layer 2
0	0	FFP	2c54.2dd2.661b	2351	1	0x20
0	0	FFP	2c54.2dd2.661b	2352	1	0x20
0	0	CP	2c54.2dd2.661e	2351	0	0xC60
0	0	CP	2c54.2dd2.661e	2352	0	0x20
1	0	GE0	58bf.ea3a.00f6	2350	0	0x460
0	0	FFP	2c54.2dd2.661b	2350	1	0x20
1	0	GE0	58bf.ea3a.00f6	2352	0	0x20
0	0	CP	2c54.2dd2.661e	2350	0	0x20
1	0	GE0	58bf.ea3a.00f6	2351	0	0xC60

Port block masks: rows=from port, columns=to port, u=unknown unicast, m=unknown multicast, b=broadcast, A=all

	CP	FFP	1/0/1	1/0/0	2/0/1	2/0/0	0/1/1	0/1/0	0/2/1	0/2/0	0/3/1	0/3/0
CP	-	A	um	um	um	um	um	um	um	um	um	um
um	um	1										
FFP	A	-	-	-	-	-	-	-	-	-	-	-
-	-	0										
1/0/1	um	umb	-	umb	umb	umb	umb	umb	umb	umb	umb	umb
umb	umb	0										
1/0/0	um	umb	umb	-	umb	umb	umb	umb	umb	umb	umb	umb
umb	umb	6										
2/0/1	um	umb	umb	umb	-	umb	umb	umb	umb	umb	umb	umb
umb	umb	0										
2/0/0	um	umb	umb	umb	umb	-	umb	umb	umb	umb	umb	umb
umb	umb	6										
0/1/1	um	umb	umb	umb	umb	umb	-	umb	umb	umb	umb	umb
umb	umb	0										
0/1/0	um	umb	umb	umb	umb	umb	umb	-	umb	umb	umb	umb
umb	umb	0										
0/2/1	um	umb	umb	umb	umb	umb	umb	umb	-	umb	umb	umb
umb	umb	0										
0/2/0	um	umb	umb	umb	umb	umb	umb	umb	umb	-	umb	umb
umb	umb	0										
0/3/1	um	umb	umb	umb	umb	umb	umb	umb	umb	umb	-	umb

```

umb      umb      0
0/3/0    um      umb      umb      umb      umb      umb      umb      umb      umb      umb      umb      -
umb      umb      0
0/4/1    um      umb      umb      umb      umb      umb      umb      umb      umb      umb      umb      umb
-        umb      0
0/4/0    um      umb      umb      umb      umb      umb      umb      umb      umb      umb      umb      umb
umb      -        0
    
```

Port VLAN membership: [untagged vlan] U=untagged T=tagged <VLAN range begin>-<VLAN range end>

```

CP [2352] U:0001-0001 T:0002-2351 U:2352-2352 T:2353-4095
FFP [2352] T:0001-4095
1/0/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
1/0/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
2/0/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
2/0/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/1/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/1/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/2/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/2/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/3/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/3/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/4/1 [2352] T:0002-2351 U:2352-2352 T:2353-4095
0/4/0 [2352] T:0002-2351 U:2352-2352 T:2353-4095
    
```

show diag all eeprom details

Router# **show diag all eeprom details**

MIDPLANE EEPROM data:

```

EEPROM version      : 4
Compatible Type     : 0xFF
PCB Serial Number   : FOC15520B7L
Controller Type     : 1902
Hardware Revision   : 1.0
PCB Part Number     : 73-13854-02
Top Assy. Part Number : 800-36894-01
Board Revision      : 05
Deviation Number    : 123968
Fab Version         : 02
Product Identifier (PID) : ISR4451/K9
Version Identifier (VID) : V01
CLEI Code          : TDBTDBTDBT
Processor type      : D0
Chassis Serial Number : FGL1601129D
Chassis MAC Address  : 30f7.0d53.c7e0
MAC Address block size : 144
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Asset ID           : P1B-R2C
    
```

Power/Fan Module P0 EEPROM data:

```

EEPROM version      : 4
Compatible Type     : 0xFF
Controller Type     : 1509
Unknown Field (type 00DF): 1.85.1.236.1
Deviation Number    : 0
PCB Serial Number   : DCA1547X037
RMA Test History    : 00
RMA Number         : 0-0-0-0
RMA History        : 00
Version Identifier (VID) : XXX
Product Identifier (PID) : XXX-XXXX-XX
CLEI Code          : 0000000000
    
```

```

Environment Monitor Data : 41 01 C2 42 00 05 F8 00
                          50 01 F4 1B 58 03 E8 1F
                          4A 05 DC 21 34 07 D0 21
                          FC 09 C4 22 60 0B B8 22
                          92 0D AC 22 D8 0F A0 22
                          F8 11 94 22 F6 13 88 23
                          3C 15 7C 23 28 17 70 23
                          00 19 64 22 D8 1B 58 22
                          C4 1D 4C 22 BA 1F 40 22
                          A6 21 34 22 9C 23 28 22
                          92 25 1C 22 88 27 10 22
                          60
Board Revision           : P0
Power/Fan Module P1 EEPROM data is not initialized

Power/Fan Module P2 EEPROM data is not initialized

Slot R0 EEPROM data:

EEPROM version          : 4
Compatible Type         : 0xFF
PCB Serial Number       : FOC15520B7L
Controller Type         : 1902
Hardware Revision       : 1.0
PCB Part Number         : 73-13854-02
Top Assy. Part Number   : 800-36894-01
Board Revision          : 05
Deviation Number        : 123968
Fab Version              : 02
Product Identifier (PID) : ISR4451/K9
Version Identifier (VID) : V01
CLEI Code                : TDBTDBTDBT
Processor type          : D0
Chassis Serial Number   : FGL1601129D
Chassis MAC Address     : 30f7.0d53.c7e0
MAC Address block size  : 144
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Asset ID                 : P1B-R2C
Asset ID                 :

Slot F0 EEPROM data:

EEPROM version          : 4
Compatible Type         : 0xFF
Controller Type         : 3567
Hardware Revision       : 4.1
PCB Part Number         : 73-12387-01
MAC Address block size  : 15
Chassis MAC Address     : aabb.ccdd.eeff
Product Identifier (PID) : ISR4451-FP
Version Identifier (VID) : V00
PCB Serial Number       : FP123456789
Asset ID                 :

Slot 0 EEPROM data:

EEPROM version          : 4
Compatible Type         : 0xFF
Controller Type         : 1612
Hardware Revision       : 4.1
PCB Part Number         : 73-12387-01
MAC Address block size  : 15
Chassis MAC Address     : aabb.ccdd.eeff
Product Identifier (PID) : ISR4451-NGSM
Version Identifier (VID) : V00
PCB Serial Number       : NGSM1234567

```

```

Asset ID :
Slot 1 EEPROM data:

EEPROM version : 4
Compatible Type : 0xFF
Controller Type : 1612
Hardware Revision : 4.1
PCB Part Number : 73-12387-01
MAC Address block size : 15
Chassis MAC Address : aabb.ccdd.eeff
Product Identifier (PID) : ISR4451-NGSM
Version Identifier (VID) : V00
PCB Serial Number : NGSM1234567
Asset ID :

Slot 2 EEPROM data:

EEPROM version : 4
Compatible Type : 0xFF
Controller Type : 1612
Hardware Revision : 4.1
PCB Part Number : 73-12387-01
MAC Address block size : 15
Chassis MAC Address : aabb.ccdd.eeff
Product Identifier (PID) : ISR4451-NGSM
Version Identifier (VID) : V00
PCB Serial Number : NGSM1234567
Asset ID :

SPA EEPROM data for subslot 0/0:

EEPROM version : 5
Compatible Type : 0xFF
Controller Type : 1902
Hardware Revision : 2.2
Boot Timeout : 400 msec
PCB Serial Number : JAB092709EL
PCB Part Number : 73-8700-01
PCB Revision : A0
Fab Version : 01
RMA Test History : 00
RMA Number : 0-0-0-0
RMA History : 00
Deviation Number : 78409
Product Identifier (PID) : ISR4451-4X1GE
Version Identifier (VID) : V01
Top Assy. Part Number : 68-2236-01
Top Assy. Revision : A0
IDPROM Format Revision : 36
System Clock Frequency : 00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00
CLEI Code : CNUIAHSAAA
Base MAC Address : 00 00 00 00 00 00
MAC Address block size : 0
Manufacturing Test Data : 00 00 00 00 00 00 00 00
Field Diagnostics Data : 00 00 00 00 00 00 00 00
Calibration Data : Minimum: 0 dBmV, Maximum: 0 dBmV
Calibration values :
Power Consumption : 13100 mWatts (Maximum)
Environment Monitor Data : 03 30 0C E4 46 32 09 C4
                        46 32 05 DC 46 32 05 DC
                        46 32 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00
                        00 00 00 00 00 00 00 00

```

```

                                00 00 FE 02 F9 6E
Processor Label                 : 00 00 00 00 00 00 00
Platform features               : 00 00 00 00 00 00 00 00
                                00 00 00 00 00 00 00 00
                                00 00 00 00 00 00 00 00
                                00 00 00 00 00 00 00
Asset ID                        :
Asset Alias                     :
SPA EEPROM data for subslot 0/1 is not available
SPA EEPROM data for subslot 0/2 is not available
SPA EEPROM data for subslot 0/3 is not available
SPA EEPROM data for subslot 0/4 is not available
SPA EEPROM data for subslot 1/0 is not available
SPA EEPROM data for subslot 1/1 is not available
SPA EEPROM data for subslot 1/2 is not available
SPA EEPROM data for subslot 1/3 is not available
SPA EEPROM data for subslot 1/4 is not available
SPA EEPROM data for subslot 2/0 is not available
SPA EEPROM data for subslot 2/1 is not available
SPA EEPROM data for subslot 2/2 is not available
SPA EEPROM data for subslot 2/3 is not available
SPA EEPROM data for subslot 2/4 is not available

```

Configuration Examples

This section provides examples of deactivating and activating modules.

Deactivating a Module Configuration: Example

You can deactivate a module to perform OIR of that module. The following example shows how to deactivate a module (and its interfaces) and remove power to the module. In this example, the module is installed in subslot 0 of the router.

```
Router(config)# hw-module slot 1 subslot 1/0 shutdown unpowered
```

Activating a Module Configuration: Example

You can activate a module if you have previously deactivated it. If you have not deactivated a module and its interfaces during OIR, then the module is automatically reactivated upon reactivation of the router.

The following example shows how to activate a module. In this example, the module is installed in subslot 0, located in slot 1 of the router:

```
Router(config)# hw-module slot 1 subslot 1/0 start
```