



Layer 2 Access List Commands

For detailed information about Ethernet services ACL concepts, configuration tasks, and examples, see the *Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Configuration Guide*.

- [copy access-list ethernet-service](#), on page 2
- [deny \(ES ACL\)](#), on page 4
- [ethernet-service access-group](#), on page 7
- [ethernet-services access-list](#), on page 9
- [permit \(ES ACL\)](#), on page 11
- [resequence access-list ethernet-service](#), on page 14
- [show access-lists ethernet-services](#), on page 16
- [show access-lists ethernet-services trace](#), on page 20
- [show access-list ethernet-service usage pfilter](#), on page 22
- [show lpts pifib hardware entry optimized](#), on page 24

copy access-list ethernet-service

To create a copy of an existing Ethernet services access list, use the **copy access-list ethernet-services** command in EXEC mode.

copy access-list ethernet-service *source-acl destination-acl*

Syntax Description	<i>source-acl</i>	Name of the access list to be copied.
	<i>destination-acl</i>	Name of the destination access list where the contents of the <i>source-acl</i> argument is copied.
Command Default	None	
Command Modes	EXEC	
Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **copy access-list ethernet-service** command to copy a configured Ethernet services access list. Use the *source-acl* argument to specify the access list to be copied and the *destination-acl* argument to specify where to copy the contents of the source access list. The *destination-acl* argument must be a unique name; if the *destination-acl* argument name already exists for an access list, the access list is not copied. The **copy access-list ethernet-service** command checks that the source access list exists then checks the existing list names to prevent overwriting existing access lists.

Task ID	Task ID	Operations
	acl	read, write
	filesystem	execute

Examples

In the following example, a copy of access list list-1 is created as list-2:

```
RP/0/RSP0/CPU0:router# show access-list ethernet-service list-1

ethernet service access-list list-1
  10 permit any any
  20 permit 2.3.4 5.4.3
RP/0/RSP0/CPU0:router# copy access-list ethernet-service list-1 list-2
RP/0/RSP0/CPU0:router# show access-list ethernet-service list-2
ethernet service access-list list2
```

```
10 permit any any
20 permit 2.3.4 5.4.3
```

Related Commands	Command	Description
	deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list
	ethernet-service access-group, on page 7	Controls access to an interface.
	ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
	permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.
	resequence access-list ethernet-service, on page 14	Renumbers existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
	show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
	show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.
	show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

deny (ES ACL)

To set conditions for an Ethernet services access list, use the **deny** command in Ethernet services access list configuration mode. To remove a condition, use the **no** form of the command.

```
[sequence-number] deny {src-mac-address src-mac-mask | any | host | dest-mac-address dest-mac-mask}
[{ethertype-number | capture | vlan min-vlan-ID [max-vlan-ID]]} [cos cos-value] [dei] [inner-vlan
min-vlan-ID [max-vlan-ID]] [inner-cos cos-value] [inner-dei]
no sequence-number
```

Syntax Description

<i>sequence-number</i>	(Optional) Number of the deny statement in the access list. This number determines the order of the statements in the access list. The number can be from 1 to 2147483646. (By default, the first statement is number 10, and the subsequent statements are incremented by 10.) Use the resequence access-list ethernet-service command to change the number of the first statement and increment subsequent statements of a configured access list.
<i>src-mac-address</i>	Source MAC address in format <i>H.H.H</i> .
<i>src-mac-mask</i>	Source MAC mask in format <i>H.H.H</i> .
any	Denies any source MAC address and mask.
host	Denies host with a specific host source MAC address and mask, in format <i>H.H.H</i> .
<i>dest-mac-address</i>	Destination MAC address in format <i>H.H.H</i> .
<i>dest-mac-mask</i>	Destination MAC mask in format <i>H.H.H</i> .
<i>ethertype-number</i>	16-bit ethertype number in hexadecimal. Range is 0x1 to 0xffff.
capture	(Optional) Captures packets using the traffic mirroring feature and copies this to a capture file.
vlan	(Optional) Denies a specific VLAN or a range of VLANs.
<i>min-vlan-ID</i>	ID for a specific VLAN or the beginning of a range of VLAN IDs.
<i>max-vlan-ID</i>	(Optional) ID for the end of a range of VLAN IDs.
cos	(Optional) Denies based on class of service value.
<i>cos-value</i>	Class of service value. Range is from 0 to 7.
dei	(Optional) Denies based on the setting of the discard eligibility indicator (DEI).
inner-vlan	(Optional) Denies a specific VLAN ID or range of VLAN IDs for the inner header.
<i>min-vlan-ID</i>	ID for a specific VLAN or the beginning of a range of VLAN IDs.
<i>max-vlan-ID</i>	(Optional) ID for the end of a range of VLAN IDs.
inner-cos	(Optional) Denies based on inner header class of service value.

<i>cos-value</i>	Inner header class of service value. Range is from 0 to 7.
inner-dei	(Optional) Denies based on inner header discard eligibility indicator.

Command Default

There is no default condition under which a packet is denied passing the Ethernet services access list.

Command Modes

Ethernet services access list configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **deny** command following the **ethernet-service access-list** command to specify conditions under which a packet can pass the access list.

By default, the first statement in an access list is number 10, and the subsequent statements are incremented by 10.

You can add **permit** or **deny** statements to an existing access list without retyping the entire list. To add a new statement anywhere other than at the end of the list, create a new statement with an appropriate entry number that falls between two existing entry numbers to indicate where it belongs.

If you want to add a statement between two consecutively numbered statements (for example, between lines 10 and 11), first use the [resequence access-list ethernet-service, on page 14](#) command to renumber the first statement and increment the entry number of each subsequent statement.

Task ID

Task ID	Operations
acl	read, write

Examples

The following example shows how to define an Ethernet services access list named L2ACL1:

```
RP/0/RSP0/CPU0:router(config)# ethernet-services access-list L2ACL1
RP/0/RSP0/CPU0:router(config-es-acl)# 10 permit 00ff.eedd.0010 ff00.0000.00ff 0011.ab10.cdef
ffff.0000.ff00 vlan 1000-1100 inner-vlan 100 inner-cos 7 inner-dei
RP/0/RSP0/CPU0:router(config-es-acl)# 20 deny host eedd.0011.ff1c ff00.0000.00ff any vlan
300 cos 1 dei inner-vlan 30 inner-cos 6
RP/0/RSP0/CPU0:router(config-es-acl)# 30 permit any any vlan 500 cos 2 inner-vlan 600
inner-cos 5 inner-dei
```

Related Commands

Command	Description
copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
ethernet-service access-group, on page 7	Controls access to an interface.

Command	Description
ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.
resequence access-list ethernet-service, on page 14	Renumbers existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.
show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

ethernet-service access-group

To control access to an interface, use the **ethernet-service access-group** command in interface configuration mode. To remove the specified access group, use the **no** form of the command.

ethernet-service access-group *access-list-name* {**ingress** | **egress**}
no ethernet-service access-group *access-list-name* {**ingress** | **egress**}

Syntax Description

<i>access-list-name</i>	Name of an Ethernet services access list as specified by the ethernet-service access-list command.
ingress	Filters on inbound packets.
egress	Filters on outbound packets.

Command Default

The interface does not have an Ethernet services access list applied to it.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **ethernet-service access-group** command to control access to an interface. To remove the specified access group, use the **no** form of the command. Use the *acl-name* argument to specify a particular Ethernet services access list. Use the **ingress** keyword to filter on inbound packets or the **egress** keyword to filter on outbound packets.

If the list permits the addresses, the software continues to process the packet. If the access list denies the address, the software discards the packet and returns a host unreachable message.

If the specified access list does not exist, all packets are passed.

By default, the unique or per-interface ACL statistics are disabled.

Task ID

Task ID	Operations
acl	read, write

Examples

The following example show how to apply filters on packets inbound and outbound from GigabitEthernet interface 0/2/0/0:

```

RP/0/RSP0/CPU0:router(config)# interface gigabitethernet 0/2/0/2
RP/0/RSP0/CPU0:router(config-if)# ethernet-service access-group p-ingress-filter ingress
RP/0/RSP0/CPU0:router(config-if)# ethernet-service access-group p-egress-filter egress

```

Related Commands

Command	Description
copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list
ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.
resequence access-list ethernet-service, on page 14	Renums existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.
show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

ethernet-services access-list

To define an Ethernet services (Layer 2) access list by name, use the **ethernet-services access-list** command in global configuration mode. To remove all entries in an Ethernet services access list, use the **no** form of the command.

ethernet-services access-list *access-list-name*
no ethernet-services access-list *access-list-name*

Syntax Description	<i>access-list-name</i> Name of the Ethernet services access list. The name cannot contain a spaces or quotation marks, but can include numbers.
---------------------------	--

Command Default	No Ethernet services access list is defined.
------------------------	--

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The **ethernet-services access-list** command places the router in access list configuration mode, in which the denied or permitted access conditions must be defined with the **deny** (ES ACL) or **permit** (ES ACL) command.

Use the [resequence access-list ethernet-service, on page 14](#) command if you need to add a **permit** or **deny** statement between consecutive entries in an existing Ethernet services access lists.

Task ID	Task ID	Operations
	acl	read, write

Examples	The following example shows how to define an Ethernet services access list named L2ACL1:
-----------------	--

```
RP/0/RSP0/CPU0:router(config)# ethernet-services access-list L2ACL1
```

Related Commands	Command	Description
	copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
	deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list
	ethernet-service access-group, on page 7	Controls access to an interface.

Command	Description
permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.
resequence access-list ethernet-service, on page 14	Renumbers existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.
show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

permit (ES ACL)

To set conditions for an Ethernet services access list, use the **permit** command in Ethernet services access list configuration mode. To remove a condition, use the **no** form of the command.

```
[sequence-number] permit {src-mac-address src-mac-mask | any | host | dest-mac-address dest-mac-mask}
[{ethertype-number | capture | vlan min-vlan-ID [max-vlan-ID]]} [cos cos-value] [dei] [inner-vlan
min-vlan-ID [max-vlan-ID]] [inner-cos cos-value] [inner-dei]
no sequence-number
```

Syntax Description

<i>sequence-number</i>	(Optional) Number of the permit statement in the access list. This number determines the order of the statements in the access list. The number can be from 1 to 2147483646. (By default, the first statement is number 10, and the subsequent statements are incremented by 10.) Use the resequence access-list ethernet-service command to change the number of the first statement and increment subsequent statements of a configured access list.
<i>src-mac-address</i>	Source MAC address in format <i>H.H.H</i> .
<i>src-mac-mac</i>	Source MAC mask in format <i>H.H.H</i> .
any	Permits any source MAC address and mask.
host	Permits host with a specific host source MAC address and mask, in format <i>H.H.H</i> .
<i>dest-mac-address</i>	Destination MAC address in format <i>H.H.H</i> .
<i>dest-mac-mac</i>	Destination MAC mask in format <i>H.H.H</i> .
<i>ethertype-number</i>	16-bit ethertype number in hexadecimal. Range is 0x1 to 0xffff.
capture	(Optional) Captures packets using the traffic mirroring feature and copies this to a capture file.
vlan	(Optional) Permits a specific VLAN or a range of VLANs.
<i>min-vlan-ID</i>	ID for a specific VLAN or the beginning of a range of VLAN IDs.
<i>max-vlan-ID</i>	(Optional) ID for the end of a range of VLAN IDs.
cos	(Optional) Permits based on class of service value.
<i>cos-value</i>	Class of service value. Range is from 0 to 7.
dei	(Optional) Permits based on the setting of the discard eligibility indicator (DEI).
inner-vlan	(Optional) Permits a specific VLAN ID or range of VLAN IDs for the inner header.
<i>min-vlan-ID</i>	ID for a specific VLAN or the beginning of a range of VLAN IDs.
<i>max-vlan-ID</i>	(Optional) ID for the end of a range of VLAN IDs.
inner-cos	(Optional) Permits based on inner header class of service value.

<i>cos-value</i>	Inner header class of service value. Range is from 0 to 7.
inner-dei	(Optional) Permits based on inner header discard eligibility indicator.

Command Default

There is no specific default condition under which a packet is permitted passing the Ethernet services ACL.

Command Modes

Ethernet services access list configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **permit** command following the **ethernet-service access-list** command to specify conditions under which a packet can pass the access list.

By default, the first statement in an access list is number 10, and the subsequent statements are incremented by 10.

You can add **permit** or **deny** statements to an existing access list without retyping the entire list. To add a new statement anywhere other than at the end of the list, create a new statement with an appropriate entry number that falls between two existing entry numbers to indicate where it belongs.

If you want to add a statement between two consecutively numbered statements (for example, between lines 10 and 11), first use the [resequence access-list ethernet-service, on page 14](#) command to renumber the first statement and increment the entry number of each subsequent statement.

Task ID

Task ID	Operations
acl	read, write

Examples

The following example show how to set a permit condition for an access list named L2ACL1:

```
RP/0/RSP0/CPU0:router(config)# ethernet-services access-list L2ACL1
RP/0/RSP0/CPU0:router(config-es-al)# 10 permit 00ff.eedd.0010 ff00.0000.00ff 0011.ab10.cdef
ffff.0000.ff00 vlan 1000-1100 inner-vlan 100 inner-cos 7 inner-dei
RP/0/RSP0/CPU0:router(config-es-al)# 20 permit any host 000a.000b.000c 0800 vlan 500 cos 2
inner-vlan 600 inner-cos 5 inner-dei
RP/0/RSP0/CPU0:router(config-es-al)# 30 permit any host 000a.000b.000c 8137 vlan 500 cos 2
inner-vlan 600 inner-cos 5 inner-dei
```

Related Commands

Command	Description
copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list

Command	Description
ethernet-service access-group, on page 7	Controls access to an interface.
ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
resequence access-list ethernet-service, on page 14	Renums existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.
show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

resequence access-list ethernet-service

To renumber existing statements and increment subsequent statements to allow a new Ethernet services access list statement, use the **resequence access-list ethernet-service** command in EXEC mode.

resequence access-list ethernet-service *access-list-name* [*starting-sequence-number* [*increment*]]

Syntax Description

<i>access-list-name</i>	Name of the Ethernet services access list. The name cannot contain a spaces or quotation marks, but can include numbers.
<i>starting-sequence-number</i>	(Optional) Number of the first statement in the specified access list, which determines its order in the access list. Maximum value is 2147483646. Default is 10.
<i>increment</i>	(Optional) Number by which the base sequence number is incremented for subsequent statements. Maximum value is 2147483646. Default is 10.

Command Default

starting-sequence-number: 10
increment: 10

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **resequence access-list ethernet-service** command to add a permit or deny statement between consecutive entries in an existing Ethernet services access list. Specify the first entry number (the *start-sequence-number*) and the increment by which to separate the entry numbers of the statements. the software remembers the existing statements, thereby making room to add new statements with the unused entry numbers.

Task ID

Task ID	Operations
acl	read, write

Examples

In the following example, suppose you have an existing access list:

```
ethernet service access-list L2ACL1
  10 permit 1.2.3 4.5.6
```

```
20 deny 2.3.4 5.4.3
30 permit 3.1.2 5.3.4 cos 5
```

You need to add additional entries in the access list ahead of the first permit statement. First, you resequence the entries, renumbering the statements starting with number 20 and an increment of 10, and then you have room for additional statements between each of the existing statements:

```
RP/0/RSP0/CPU0:router# resequence access-list ethernet-service L2ACL1 20 10
RP/0/RSP0/CPU0:router# show access-list ethernet-services L2ACL1

ethernet service access-list L2ACL1
 20 permit 1.2.3 4.5.6
 30 deny 2.3.4 5.4.3
 40 permit 3.1.2 5.3.4 cos 5
```

Related Commands

Command	Description
copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list
ethernet-service access-group, on page 7	Controls access to an interface.
ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.
show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.
show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

show access-lists ethernet-services

To display the contents of current Ethernet services access lists, use the **show access-lists ethernet-services** command in EXEC mode.

show access-lists ethernet-services [{*access-list-name* | **maximum** | **standby** | **summary**}] [{**hardware** | **usage**}] [{**ingress** | **egress**}] [{**implicit** | **detail** | **sequence** | **location** *location*}]

Syntax Description	<p><i>access-list-name</i> (Optional) Name of a specific Ethernet services access list. The name cannot contain a spaces or quotation marks, but can include numbers.</p> <p>maximum (Optional) Show the maximum number of configurable Ethernet services ACLs and ACEs.</p> <p>standby (Optional) Display all access lists in standby mode.</p> <p>summary (Optional) Display a summary of Ethernet services access lists.</p> <p>hardware (Optional) Display Ethernet services access list entries in hardware including the match count for a specific ACL in a particular direction across the line card.</p> <p>usage (Optional) Display the usage of this ACL in a given location.</p> <p>ingress (Optional) Filters on inbound packets.</p> <p>egress (Optional) Filters on outbound packets.</p> <p>implicit (Optional) Display the count of packets implicitly denied by a particular ACL.</p> <p>detail (Optional) Display TCAM entries.</p> <p>sequence (Optional) Display statistics for a specific sequence number.</p> <p><i>sequence-number</i> Sequence number value. Range is 1 to 2147483647.</p> <p>location (Optional) Display information for a specific node number.</p> <p><i>location</i> Fully qualified location specification</p>	
Command Default	The contents of all Ethernet services access lists are displayed.	
Command Modes	EXEC	
Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	

Task ID	Task ID	Operations
	acl	read, write

Examples

The following examples lists defined Ethernet services access list maximum thresholds:

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services maximum
```

```
Max configurable ACLs: 10000
Max configurable ACEs: 350000
```

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services maximum detail
```

```
Total ACLs configured: 2
Total ACEs configured: 3
Max configurable ACLs: 10000
Max configurable ACEs: 350000
```

The following example lists the Ethernet services access-list standby:

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services standby
```

```
ethernet-services access-list i
 10 permit host 0001.0002.0003 host 000a.000b.000c
ethernet-services access-list l2_acl
 10 permit any any
 20 deny host 0002.0003.0004 host 000.50004.0003
```

The following example displays a summary of the number of Ethernet services ACLs configured on the system:

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services summary
```

```
ACL Summary:
Total ACLs configured: 2
Total ACEs configured: 3
```

The following example displays the number of packets matching the access list l2_acl for each ACE:

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services l2_ACL hardware ingress location 0/0/CPU0
```

```
ethernet service access-list l2_acl
 10 permit any any ( 3524 hw matches)
 20 deny host 0002.0003.0004 host 0005.0004.0003 (5394 hw matches)
```

The following example displays the number of packets matching the implicit deny in access list l2_acl:

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services l2_ACL hardware ingress implicit location 0/0/CPU0
```

```
ethernet-services access-list l1_acl
2147483647 implicit deny any any (2300 hw matches)
```

The following example displays the number of packets matching a particular sequence number:

show access-lists ethernet-services

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services l2_ACL hardware ingress sequence
20 location 0/0/CPU0
```

```
ethernet-services access-list l2_acl
20 deny host 0002.0003.0004 host 0005.0004.0003 (5394 hw matches)
```

The following example displays statistics for the TCAM entry for Ethernet services access list l2acl_4:

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services l2acl_4 hardware ingress sequence
10 detail location 0/6/CPU0
Wed Jun 24 00:28:51.367 UTC
```

```
ACL name: l2acl_4
Format type : 1
Channel ID: 2
Sequence Number: 10
Grant: permit
Logging: OFF
Hits: 0
Statistics pointer: 0x150628
Number of TCAM entries: 1
idx = 0
Entry : 0 for ACE : 10
RAW value : 40 04 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
RAW mask : 00 03 ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
```

```
-----Field Details-----
outer_vlan_id value      : 0000
outer_vlan_id mask       : 0ffff
outer_vlan discard eligibility value: 00
outer_vlan discard eligibility mask : 01
outer_vlan_id cos value: 00
outer_vlan_id cos mask: 07
Ethernet type value      : 0000
Ethernet type mask       : ffff
Base app id value        : 02
Base app id value        : 00
Base acl id value        : 0001
Base acl id mask         : 0000
outer_vlan id present value : 0
outer_vlan id present mask : 1
inner_vlan id present value : 0
inner_vlan id present mask : 1
Mac source address value  : 0000 0000 0000
Mac source address mask   : ffff ffff ffff
Mac destination address value : 0000 0000 0000
Mac destination address mask : ffff ffff ffff
RP/0/RSP0/CPU0:router#
```

Related Commands

Command	Description
copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list
ethernet-service access-group, on page 7	Controls access to an interface.
ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.

Command	Description
resequence access-list ethernet-service, on page 14	Renums existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.
show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

show access-lists ethernet-services trace

To display Ethernet services access list trace information use the **show access-lists ethernet-services trace** command in EXEC mode.

show access-lists ethernet-services trace {client | intermittent | critical | both | all}

Syntax Description

client	Trace data for ES ACL client.
intermittent	Trace data for intermittent failures.
critical	Trace data for server-critical failures
both	Trace data for server-critical and intermittent failures.
all	Trace data for server-critical and intermittent failures.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
acl	read

Examples

The following examples show how to display Ethernet services access list trace information:

```
RP/0/RSP0/CPU0:router# show access-lists ethernet-services trace all
1 unique entries (256 possible, 0 filtered)
Jun 15 06:42:56.980 es/acl_mgr_un 0/RSP0/CPU0 1#t3 Manager state is active
3 wrapping entries (1024 possible, 0 filtered, 3 total)
Jun 15 06:42:57.053 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
1 batches
Jun 16 02:23:30.075 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
1 batches
Jun 16 02:29:41.383 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
2 batches

RP/0/RSP0/CPU0:router# show access-lists ethernet-services trace both
1 unique entries (256 possible, 0 filtered)
Jun 15 06:42:56.980 es/acl_mgr_un 0/RSP0/CPU0 1#t3 Manager state is active
3 wrapping entries (1024 possible, 0 filtered, 3 total)
Jun 15 06:42:57.053 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
```

```

1 batches
Jun 16 02:23:30.075 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
1 batches
Jun 16 02:29:41.383 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
2 batches

RP/0/RSP0/CPU0:router# show access-lists ethernet-services trace critical
1 unique entries (256 possible, 0 filtered)
Jun 15 06:42:56.980 es/acl_mgr_un 0/RSP0/CPU0 1#t3 Manager state is active

RP/0/RSP0/CPU0:router# show access-lists ethernet-services trace intermittent
3 wrapping entries (1024 possible, 0 filtered, 3 total)
Jun 15 06:42:57.053 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
1 batches
Jun 16 02:23:30.075 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
1 batches
Jun 16 02:29:41.383 es/acl_mgr/es_acl_mgr_wr 0/RSP0/CPU0t1 es_aclmgr_verify acl_add: verifying
2 batches

```

Related Commands

Command	Description
copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list
ethernet-service access-group, on page 7	Controls access to an interface.
ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.
resequence access-list ethernet-service, on page 14	Renumbers existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
show access-list ethernet-service usage pfilter, on page 22	Identifies the modes and interfaces on which a particular ACL is applied.

show access-list ethernet-service usage pfilter

To identify the modes and interfaces on which a particular ACL is applied, use the **show access-list ethernet-service usage pfilter** command in EXEC mode. Information displayed includes the application of all or specific ACLs, the interfaces on which they have been applied and the direction in which they are applied.

show access-list ethernet-services [*access-list-name*] **usage pfilter location** {*location* | **all**}

Syntax Description

<i>access-list-name</i>	(Optional) Name of a specific Ethernet services access list. The name cannot contain a spaces or quotation marks, but can include numbers.
location	Interface card on which the access list information is needed.
<i>location</i>	Fully qualified location specification.
all	Displays packet filtering usage for all interface cards.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
acl	read, write

Examples

The following example shows how to display packet filter usage at a specific location:

```
RP/0/RSP0/CPU0:router# show access-list ethernet-services usage pfilter location 0/0/cpu0
pfilter location 0/0/cpu0
Interface : GigabitEthernet0/0/0/9
  Input ACL : l2_acl
  Output ACL : N/A
Interface : GigabitEthernet0/0/0/30
  Input ACL : N/A
  Output ACL : i
```

The following example shows the results of the command for a specific ACL:

```
RP/0/RSP0/CPU0:router# show access-list ethernet-services l2_acl usage pfilter location
```

```

0/0/CPU0
Interface : GigabitEthernet0/0/0/9
  Input ACL : l2_acl
  Output ACL : N/A

```

Related Commands

Command	Description
copy access-list ethernet-service, on page 2	Creates a copy of an existing Ethernet services access list.
deny (ES ACL), on page 4	Sets conditions for an Ethernet services access list
ethernet-service access-group, on page 7	Controls access to an interface.
ethernet-services access-list, on page 9	Defines an Ethernet services (Layer 2) access list by name.
permit (ES ACL), on page 11	Sets conditions for an Ethernet services access list.
resequence access-list ethernet-service, on page 14	Renums existing statements and increment subsequent statements to allow a new Ethernet services access list statement.
show access-lists ethernet-services, on page 16	Displays the contents of current Ethernet services access lists.
show access-lists ethernet-services trace, on page 20	Displays Ethernet services access list trace information.

show lpts pifib hardware entry optimized

To display a set of optimized entries that are combined as a single entry, inside the Ternary Content Addressable Memory (TCAM), use the **show lpts pifib hardware entry optimized** command in EXEC mode.

show lpts pifib hardware entry optimized *location*

Syntax Description	<i>location</i> Mandatory. The location of the line card where the interface is present.				
Command Default	None				
Command Modes	EXEC				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 4.1.1</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 4.1.1	This command was introduced.
Release	Modification				
Release 4.1.1	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>lpts</td><td>read</td></tr> </table>	Task ID	Operation	lpts	read
Task ID	Operation				
lpts	read				

The following example shows the output of the **show lpts pifib hardware entry optimized** command:

```
RP/0/RSP0/CPU0:router# show lpts pifib hardware entry optimized location 0/4/CPU0
Node: 0/4/CPU0:
```

```
-----
Protocol - Layer4 Protocol; Intf - Interface in optimized list
```

Protocol	laddr.Port, raddr.Port	Intf	VRF id	State
IGMP	224.0.0.22.any , any.any	Te0/4/0/0	*	Uldb Set
		Te0/4/0/1	*	Uldb Set
	224.0.0.22.any , any.any	Te0/4/0/0	*	Uldb Set
		Te0/4/0/1	*	Uldb Set
	any.any , any.any	Te0/4/0/0	*	Uldb Set
		Te0/4/0/1	*	Uldb Set