



Global Interface Commands

This module describes the global command line interface (CLI) commands for configuring interfaces on the Cisco ASR 9000 Series Router.

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

- [bandwidth \(global\), on page 2](#)
- [clear interface, on page 3](#)
- [dampening, on page 4](#)
- [interface \(global\), on page 6](#)
- [lacp system , on page 8](#)
- [mlacp reset priority, on page 9](#)
- [mlacp switchback, on page 10](#)
- [mlacp switchover maximize, on page 11](#)
- [mlacp switchover type, on page 12](#)
- [mtu, on page 13](#)
- [replace, on page 16](#)
- [show im dampening, on page 19](#)
- [show interfaces, on page 22](#)
- [show ethernet cfm interfaces bandwidth-notifications, on page 32](#)
- [show mlacp inconsistencies, on page 34](#)
- [shutdown \(global\), on page 35](#)

bandwidth (global)

To configure the bandwidth of an interface, use the **bandwidth** command in interface configuration mode. Bandwidth defines the maximum transmission speed for a given interface. For example, you can use the allocate lower bandwidth for a lower bandwidth consumption service, such as voice calling. And use higher bandwidth for video calling service.

bandwidth *rate*

Syntax Description	<i>rate</i> Amount of bandwidth to be allocated on the interface, in Kilobits per second (kbps). Range is from 0 through 4294967295.				
Command Default	The default bandwidth depends on the interface type.				
Command Modes	Interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				

Usage Guidelines



Note To obtain the default bandwidth for a specific interface, use the **show interfaces** command after you first bring up the interface. The default interface bandwidth is displayed in the **show interfaces** command output.

Task ID	Task ID	Operations
	interface	execute
	basic-services	read, write

Examples

This example shows how to configure the bandwidth on a Ten Gigabit Ethernet interface:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router# interface TenGigE 0/4/1/0
RP/0/RSP0/CPU0:router# bandwidth 4000000
```

Related Commands	Command	Description
	shutdown (global) , on page 35	Disables an interface (forces an interface to be administratively down).

clear interface

To clear interface statistics or packet counters, use the **clear interface** command in EXEC mode .

clear interface *type interface-path-id*

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.		
Command Default	No default behavior or values	
Command Modes	EXEC	
Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Task ID	Task ID	Operations
	interface	execute
	basic-services	read, write
Examples	This example shows how to use the clear interface command to clear the loopback interface 2: RP/0/RSP0/CPU0:router# clear interface loopback 2	
Related Commands	Command	Description
	shutdown (global), on page 35	Disables an interface (forces an interface to be administratively down).

dampening

To limit propagation of transient or frequently changing interface states on Interface Manager (IM) clients, turn on event dampening by using the **dampening** command in interface configuration mode. To turn dampening off, use the **no** form of this command.

dampening [*half-life* [*reuse suppress max-suppress-time*]]

Syntax Description	<table> <tr> <td data-bbox="334 533 548 569"><i>half-life</i></td><td data-bbox="548 533 1497 680">(Optional) Time (in minutes) after which a penalty is decreased. Once the interface has been assigned a penalty, the penalty is decreased by half after the half-life period. The process of reducing the penalty happens every 5 seconds. The range of the half-life period is 1 to 45 minutes. The default is 1 minute.</td></tr> <tr> <td data-bbox="334 680 548 716"><i>reuse</i></td><td data-bbox="548 680 1497 753">(Optional) Penalty value below which a stable interface is unsuppressed. Range is from 1 through 20000. Default value is 750.</td></tr> <tr> <td data-bbox="334 753 548 789"><i>suppress</i></td><td data-bbox="548 753 1497 879">(Optional) Limit at which an interface is suppressed when its penalty exceeds that limit. Range is from 1 through 20000, and must be greater than the reuse threshold. The default value is 2000.</td></tr> <tr> <td data-bbox="334 879 548 915"><i>max-suppress-time</i></td><td data-bbox="548 879 1497 1014">(Optional) Maximum time (in minutes) that an interface can be suppressed. This value effectively acts as a ceiling that the penalty value cannot exceed. Default value is four times the half-life period.</td></tr> </table>	<i>half-life</i>	(Optional) Time (in minutes) after which a penalty is decreased. Once the interface has been assigned a penalty, the penalty is decreased by half after the half-life period. The process of reducing the penalty happens every 5 seconds. The range of the half-life period is 1 to 45 minutes. The default is 1 minute.	<i>reuse</i>	(Optional) Penalty value below which a stable interface is unsuppressed. Range is from 1 through 20000. Default value is 750.	<i>suppress</i>	(Optional) Limit at which an interface is suppressed when its penalty exceeds that limit. Range is from 1 through 20000, and must be greater than the reuse threshold. The default value is 2000.	<i>max-suppress-time</i>	(Optional) Maximum time (in minutes) that an interface can be suppressed. This value effectively acts as a ceiling that the penalty value cannot exceed. Default value is four times the half-life period.
<i>half-life</i>	(Optional) Time (in minutes) after which a penalty is decreased. Once the interface has been assigned a penalty, the penalty is decreased by half after the half-life period. The process of reducing the penalty happens every 5 seconds. The range of the half-life period is 1 to 45 minutes. The default is 1 minute.								
<i>reuse</i>	(Optional) Penalty value below which a stable interface is unsuppressed. Range is from 1 through 20000. Default value is 750.								
<i>suppress</i>	(Optional) Limit at which an interface is suppressed when its penalty exceeds that limit. Range is from 1 through 20000, and must be greater than the reuse threshold. The default value is 2000.								
<i>max-suppress-time</i>	(Optional) Maximum time (in minutes) that an interface can be suppressed. This value effectively acts as a ceiling that the penalty value cannot exceed. Default value is four times the half-life period.								
Command Default	<p>Dampening is turned off by default. When you use the dampening command, the following default values are enabled for any optional parameters that you do not enter:</p> <ul style="list-style-type: none"> • <i>half-life</i>: 1 minute • <i>reuse</i>: 750 • <i>suppress</i>: 2000 • <i>max-suppress-time</i>: Four times the half-life 								
Command Modes	Interface configuration								
Command History	<table> <tr> <th data-bbox="334 1302 500 1358">Release</th><th data-bbox="500 1302 1497 1358">Modification</th></tr> <tr> <td data-bbox="334 1358 500 1394">Release 3.7.2</td><td data-bbox="500 1358 1497 1394">This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.				
Release	Modification								
Release 3.7.2	This command was introduced.								
Usage Guidelines	<p>Event dampening suppresses a constantly unstable interface until it remains stable for a period of time. Enabling dampening on an interface that already has dampening configured has the effect of resetting the penalty associated with that interface to zero. The reuse threshold must always be less than the suppress threshold.</p> <p>Consider the following guidelines when configuring event dampening:</p> <ul style="list-style-type: none"> • Configuring dampening on both a subinterface and its parent is usually unnecessary because their states are almost always the same and dampening would be triggered at the same time on each interface. • If all subinterfaces require dampening, then apply dampening to the main interface only. Applying configuration to large numbers of subinterfaces requires an abundance of memory and increases the time required to process the configuration during boot and failover. 								

- When dampening is enabled, an interface has a penalty value associated with it. The value starts at 0 and is increased by 1000 whenever the underlying state of the interface changes from up to down.
- The penalty value decreases exponentially while the interface state is stable. If the penalty value exceeds a configured suppress threshold, then the state of the interface is suppressed and IM will not notify upper layers of further state transitions. The suppressed state remains until the penalty value decreases past a configured reuse threshold.

Task ID**Task ID Operations**

interface read,
 write

Examples

This example shows how to enable dampening with default values on an interface:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/4/0/0  
RP/0/RSP0/CPU0:router(config-if)# dampening
```

Related Commands**Command****Description**

[show im dampening, on page 19](#)

Displays the state of all interfaces on which dampening has been configured.

interface (global)

To configure an interface or to create or configure a virtual interface, use the **interface** command in Global Configuration mode . To delete the interface configuration, use the **no** form of this command.

interface *type interface-path-id*

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	<p>Note</p> <p>Use the show interfaces command to see a list of all interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>	
Command Default	No interfaces are configured	
Command Modes	Global Configuration	
Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Usage Guidelines	The interface command enters interface configuration mode to allow you to configure interfaces. If a virtual interface is configured, then the interface is created if it did not already exist.	
	The no form of this command applies only to virtual interfaces or to subinterfaces (that is, interfaces that have been created in global configuration mode).	
	Until Release 6.5.1, when you create an interface with some configurations, upon router or interface reload, interface configurations are lost. From Release 6.5.1, onwards, automatic shutdown config behavior is persistent and no shutdown configs are lost on interface or router reload.	
Task ID	Task ID	Operations
	interface	read, write
Examples	<p>In the following example, the interface command is given for the card in location 0/2/0/1, and interface configuration mode is entered for that interface:</p> <pre>RP/0/RSP0/CPU0:router(config)# interface POS 0/2/0/1</pre>	

Related Commands

Command	Description
clear interface, on page 3	Clears interface statistics or packet counters.
shutdown (global), on page 35	Disables an interface (forces an interface to be administratively down).

lACP system

To set the default system parameters for the Link Aggregation Control Protocol (LACP) bundles, use the **lACP system** command in Global Configuration mode .

lACP system { **mac** | **priority** }

Syntax Description

mac	Unique MAC address used to identify the system in LACP negotiations.
priority	Priority for this system. Lower value is higher priority. Range is from 1 to 65535.

Command Default

System priority is 32768. MAC address is automatically assigned from the backplane pool.

Command Modes

Global Configuration

Command History

Release	Modification
Release 4.0.0	This command was introduced.

Usage Guidelines

The parameters are the system MAC address and the priority of the system. The MAC address must be unique to the system (if it matches a partner system, LACP negotiations fail). The combination of the MAC address and the set system priority determine the priority of the LACP bundles.

Task ID

Task ID	Operation
bundle	read, write

Example

The following example shows how to configure the MAC address on an LACP system:

```
RP/0/RSP0/CPU0:router(config)#lACP system mac 000c.15c0.bd15
```


mlacp reset priority

To reset operational priorities of mlacp members to their configured mLACP priorities, use the **mlacp reset priority** command in EXEC mode .

mlacp reset priority **bundle-ether** *interface-path-id*

Syntax Description	bundle-ether <i>interface-path-id</i> Specifies a physical interface instance or a virtual interface instance.	
Command Default	No default behavior or values.	
Command Modes	EXEC	
Command History	Release	Modification
	Release 4.0	This command was introduced.
Usage Guidelines	This command is for aggregated ethernet interfaces only. The command cannot be used if brute-force switchover is employed.	
Task ID	Task ID	Operation
	bundle	execute

Example

The following example shows how to use the **mlacp reset priority** command:

```
RP/0/RSP0/CPU0:router #mlacp reset priority bundle-ether 10
```

mlacp switchback

To force a switchback to the local mlacp device for a specified bundle, use the **mlacp switchback** command in the EXEC mode .

mlacp switchback interface *interface-path-id* [**at** | **in** | **no prompt**]

Syntax Description	interface <i>interface-path-id</i>	Specifies a physical interface instance or a virtual interface instance.
	at	Schedules the operation for a future time and date.
	in	Schedules the operation for a specified delay.
	no prompt	Attempts to carry out the command without prompting.
Command Default	No default behavior or values.	
Command Modes	EXEC	
Command History	Release	Modification
	Release 4.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	bundle	read, write
	interface	read, write

Example

The following example shows how to schedule the operation at a specified time and date on a bundle-ether interface:

```
RP/0/RSP0/CPU0:router#mlacp switchback bundle-ether 20 at march 21 08:30:10
```

mlacp switchover maximize

To set the maximum number of links or bandwidth in the bundle, use the **mlacp switchover maximize** command in the bundle interface configuration mode.

mlacp switchover maximize { **links** | **bandwidth** } [**threshold** *value*]

Syntax Description	links	Compares the operational links, with respect to the total number of links.
	bandwidth	Compares the available bandwidth, with respect to the total bandwidth.
	threshold	Sets the threshold value to switch to the peer, if its has more links/ bandwidth available.
	<i>value</i>	<ul style="list-style-type: none"> When used with the links keyword, sets the minimum number of links, below which the device switches to the peer if more links are available. Range is 1-64. When used with the bandwidth keyword, sets the minimum bandwidth (in kbps), below which the device switches to the peer if more bandwidth is available. Range is 1-4294967295.
Command Default	No default behavior or value.	
Command Modes	Bundle interface configuration.	
Command History	Release	Modification
	Release 4.0.0	This command was introduced.
Usage Guidelines	This command allows switchovers to take place such that the active device is the one with most bandwidth or maximum links in the bundle.	
Task ID	Task ID	Operation
	bundle	read,write
	interface	read,write

Example

The following example shows how to maximize the links:

```
RP/0/RSP0/CPU0:router(config-if)#interface bundle-ether 10 mlacp switchover maximize links
threshold 20
```

mlacp switchover type

To specify a non-default switchover method , use the **mlacp switchover type** command in the bundle interface configuration mode.

mlacp switchover type [**brute-force** | **revertive**]

Syntax Description	brute-force	Force switchover by disabling all local member links.
	revertive	Revert based on configured priority values.
Command Default	The default switchover type is non-revertive.	
Command Modes	Bundle interface configuration.	
Command History	Release	Modification
	Release 4.0.0	This command was introduced.
Usage Guidelines	The brute-force and revertive options are mutually exclusive, and the value must match on the bundle on both POAs. They determine whether the dynamic priority management or brute force mechanism is used, and whether the behavior is revertive or non-revertive.	
Task ID	Task ID	Operation
	interface	read, write

Example

The following example shows how to force a switchover by disabling all local member links on an bundle-ether interface:

```
RP/0/RSP0/CPU0:router(config-if)#mlacp switchover type brute-force
```

mtu

To adjust the maximum transmission unit (MTU) value for packets on the interface, use the **mtu** command in interface configuration mode. To return the interface to the default MTU for the interface type, use the **no** form of this command.

mtu *bytes*

Syntax Description

bytes Maximum number of bytes in a Layer 2 frame. Range is from 64 through 65535.

Command Default

The default MTU for each interface is as follows:

- Ethernet—1514 bytes
- POS—4474 bytes
- Tunnel—1500 bytes
- Loopback—1514 bytes
- ATM—4470 bytes

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **mtu** command to set a specific MTU value for an interface, or use the **no mtu** command to return the interface to the default MTU value for that interface type. The MTU value can be increased or decreased using the **mtu** command, subject to minimum and maximum MTU limits for the interface type.

If the MTU value is not configured, then each interface will have a default MTU value that is specific to the interface type. The default MTU value is generally the largest Layer 2 frame size possible for the interface type.

The default/configured MTU value on an atm interface includes the L2 header.

The MTU size consists of L2 header that includes either SNAP(8bytes)/MUX(0)/NLPID(2) header or the AAL5 SDU. The AAL5 SDU includes the L3 datagram and the optional Logical Link Control/Subnetwork Access Protocol (LLC/SNAP) header.

The Ethernet interface is the Layer 3 datagram plus 14 bytes. For ATM main interface, the MTU is L3 datagram + 0 bytes.

For ATM L3 sub interface, mtu is as follows:

- SNAP - L3 datagram + 8 bytes
- NLPID - L3 datagram + 2 bytes
- MUX - L3datagram + 0 bytes
- When no pvc is configured under sub interface - L3datagram + 0 bytes

You can use the **show interfaces** command to determine if the MTU value has been changed. The **show interfaces** command output displays the MTU size for each interface in the MTU (byte) field. Note that the MTU size that is displayed includes the Layer 2 header bytes used for each encapsulation type.



Note You can use the **show interfaces** command to determine if the MTU value has been changed. The **show interfaces** command output displays the MTU size for each interface in the MTU (byte) field. Note that the MTU size that is displayed includes the Layer 2 header bytes used for each encapsulation type.



Note Changing the MTU on an interface triggers a change on the protocols and encapsulations configured on that interface, although some protocol-specific configurations can override the interface MTU. For example, specifically changing the interface MTU configuration does not affect the IP MTU configuration, but may affect the resulting MTU on that node.



Note For the 10x10GigE CPAK (10 ports with only 8 profiles), it is not possible to support 10 different MTUs on 10 different 10GigE ports. One of the profiles needs to be reserved for the default MTU, in case you need to change the configured MTU back to the default MTU. Therefore on the 10x10g CPAK, you can configure different MTU sizes on 7 ports and the other 3 ports have the default MTU size. If you configure the 8th port, the configuration command succeeds but an error appears on the console.

Task ID

Task ID Operations

interface read,
write

Examples

In this example, the MTU value for all interfaces is verified. The MTU value is shown in the next-to-last column:

```
RP/0/RSP0/CPU0:router# show interfaces all brief
```

Intf Name	Intf State	LineP State	Encap Type	MTU (byte)	BW (Kbps)
Nu0	up	up	Null	1500	Unknown
TenGigE6/0/0/0	up	up	HDLC	4474	2488320
TenGigE6/0/0/1	up	up	HDLC	4474	2488320
TenGigE6/0/0/2	admin-down	admin-down	HDLC	4474	2488320
TenGigE6/0/0/3	admin-down	admin-down	HDLC	4474	2488320
Mg0/RSP0/CPU0/0	up	up	ARPA	1514	100000

```
RP/0/RSP0/CPU0:router# configure
```

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 6/0/0/0
```

```
RP/0/RSP0/CPU0:router(config-if)# mtu 1000
```

After the **mtu** command is used to decrease the MTU Layer 2 frame size for the POS interface on 6/0/0/0 to 1000 bytes, the **show interfaces all brief** command is used again to verify that the MTU Layer 2 frame size has been changed:

```
RP/0/RSP0/CPU0:router# show interfaces all brief
```

Intf Name	Intf State	LineP State	Encap Type	MTU (byte)	BW (Kbps)
Nu0	up	up	Null	1500	Unknown
PO6/0/0/0	up	up	HDLC	1000	2488320
PO6/0/0/1	up	up	HDLC	4474	2488320
PO6/0/0/2	admin-down	admin-down	HDLC	4474	2488320
PO6/0/0/3	admin-down	admin-down	HDLC	4474	2488320
Mg0/RSP0/CPU0/0	up	up	ARPA	1514	100000

Related Commands

Command	Description
shutdown (global), on page 35	Disables an interface (forces an interface to be administratively down).

replace

To substitute any configuration in the router with new settings, use the **replace** command in Global Configuration mode.

replace **interface** *interface_name_before* **with** *interface_name_after*

replace **pattern** *string_before* **with** *string_after* [**dry-run**]

Syntax Description	interface	Specifies the details of interface configuration replacement follows.
	<i>interface_name_before</i>	Specifies the name of an interface in the router that you want to replace. For more information about the syntax for the router, use the question mark (?) online help function.
	<i>interface_name_after</i>	Specifies the new interface name that replaces the current interface name specified in the <i>interface_name_before</i> variable. For more information about the syntax for the router, use the question mark (?) online help function.
	pattern	Specifies that the details of string replacement follow.
	<i>string_before</i>	Specify the configuration string in the router that you need to replace. The <i>string_before</i> can be any regular expression that specifies a match pattern in text. Note You must specify the <i>string_before</i> in a single quote.
	<i>string_after</i>	Specify the new string that replaces the configuration matching the <i>string_before</i> variable. Note You must specify the <i>string_after</i> in a single quote.
	dry-run	Displays the configuration after the pattern replacement without preparing the config changes for a commit. This option facilitates verifying the pattern replacement changes and provides an extra layer of protection to avoid accidentally committing unwanted configuration changes.
Command Default	No default behavior or values.	
Command Modes	Global Configuration	
Command History	Release	Modification
	Release 5.3.2	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	

Task ID**Task ID Operations**

```
interface read,
write
```

Examples

The following example shows how to use the **replace** command:

```
Router# config
Router(config)# replace interface gigabitEthernet 0/0/0/0 with loopback 450
Loading.
4 bytes parsed in 1 sec (3)bytes/sec
```

```
Router# config
Router(config)# replace pattern '10\.20\.30\.40' with '100.200.250.225'
Loading.
232 bytes parsed in 1 sec (230)bytes/sec
```

Examples

The following example details configuration changes on using the **replace** command:

Original Configuration:

```
Router(config-ospf-ar-if)#show configuration
Building configuration...
!! IOS XR Configuration 0.0.0
interface GigabitEthernet0/0/0/0
  description first
  ipv4 address 10.20.30.40 255.255.0.0
  shutdown
!
router ospf 10
  cost 100
  area 200
  cost 200
  interface GigabitEthernet0/0/0/0
    transmit-delay 5
  !
```

Using **replace** command:

```
Router(config-ospf-ar-if)# replace interface gigabitEthernet 0/0/0/0 with loopback 450
Building configuration...
Loading.
232 bytes parsed in 1 sec (230)bytes/sec
```

Configuration changes on using **replace** command:

```
Router(config-ospf-ar-if)#show configuration
Building configuration...
!! IOS XR Configuration 0.0.0
interface Loopback450
  description first
  ipv4 address 10.20.30.40 255.255.0.0
  shutdown
```

```

!
no interface GigabitEthernet0/0/0/0
router ospf 10
area 200
    interface Loopback450
        transmit-delay 5
    !
no interface GigabitEthernet0/0/0/0

```

Examples

The following example shows how to use the **dry-run** option in the **replace** command:

```

Router# config
Router(config)# replace pattern 'vrf thr' with 'vrf three' dry-run
no vrf thr
vrf three
    address-family ipv4 unicast
        import route-target
            65321:3
    !
    export route-target
        65321:3
    !
!
exit
router static
no vrf thr
vrf three
    address-family ipv4 unicast
        192.168.3.0/24 vrf one 192.168.1.1
        192.168.3.0/24 vrf two 192.168.2.2
    !
exit
end
Router(config)# commit
No configuration changes to commit.

```

show im dampening

To display the state of all interfaces on which dampening has been configured, use the **show im dampening** command in EXEC mode .

show im dampening [**interface** *type* | **ifhandle** *handle*]

Syntax Description	<p>interface <i>type</i> (Optional) Interface type. For more information, use the question mark (?) online help function.</p> <p>ifhandle <i>handle</i> (Optional) Identifies the caps node whose Interface Manager (IM) dampening information you want to display.</p>				
Command Default	If you do not specify an interface, then the system displays brief details about all dampened interfaces.				
Command Modes	EXEC				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	<p>If you do not specify an interface, then the system displays brief details about all dampened interfaces.</p> <p>The physical hardware (layer 1) is not the only part of an interface that can change state. L2 keepalive failure event is one of the many instances that can have a similar impact on routing protocols despite the underlying interface state staying UP. To take account of such events, when dampening is configured on an interface, it is applied independently to every layer. They all use the same parameters as the interface but they have their own penalty value which is incremented when that layer changes state.</p> <p>Capsulations that may be dampened in this way include these:</p> <ul style="list-style-type: none"> • L2 basecaps, such as HDLC and PPP, which may flap if keepalives are not received due to events such as intermittent packet loss. • L3 capsulations (for example ipv4, ipv6). These may be brought down if another link has a conflicting IP address configured. • Other locations where negotiation takes place with a peer router, as in the case of PPP control protocols such as IPCP. If the negotiation fails, then the caps is brought down. 				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>interface</td><td>read</td></tr> </table>	Task ID	Operations	interface	read
Task ID	Operations				
interface	read				
Examples	<p>This example shows the output from the show im dampening command issued with default values:</p> <pre>RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/4/0/0 RP/0/RSP0/CPU0:router(config-if)# no shutdown RP/0/RSP0/CPU0:router(config-if)# dampening</pre>				

show im dampening

```
RP/0/RSP0/CPU0:router# show im dampening
```

Interface	Proto	Caps	Penalty	Suppressed
TenGigE0/4/0/0	0	0	0	NO

```
RP/0/RSP0/CPU0:router# show im dampening interface TenGigE 0/4/0/0
```

```
TenGigE0/4/0/0 (0x05000d00)
Dampening enabled: penalty 0, not suppressed
  underlying state: Up
  half_life: 1      reuse: 750
  suppress: 3000    max-suppress-time: 4
  restart-penalty: 0
```

```
RP/0/RSP0/CPU0:router# show interfaces TenGigE 0/4/0/0
```

```
TenGigE0/4/0/0 is up, line protocol is down
Dampening enabled: penalty 0, not suppressed
  half_life: 1      reuse: 750
  suppress: 3000    max-suppress-time: 4
  restart-penalty: 0
Hardware is Ten Gigabit Ethernet
Description: ensoft-gsr5 TenGigE 4\2
Internet address is Unknown
MTU 4474 bytes, BW 155520 Kbit
  reliability 255/255, txload 1/255, rxload 1/255
Encapsulation HDLC, crc 16, controller loopback not set, keepalive set (10 sec)
Last clearing of "show interface" counters never
30 second input rate 0 bits/sec, 0 packets/sec
30 second output rate 0 bits/sec, 0 packets/sec
  0 packets input, 0 bytes, 0 total input drops
  0 drops for unrecognized upper-level protocol
Received 0 broadcast packets, 0 multicast packets
  0 runs, 0 giants, 0 throttles, 0 parity
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
48 packets output, 1504 bytes, 0 total output drops
Output 0 broadcast packets, 0 multicast packets
0 output errors, 0 underruns, 0 applique, 0 resets
0 output buffer failures, 0 output buffers swapped out
```

This sample output shows a POS interface with PPP basecaps and IPCP. The subsequent output for **show im dampening interface <ifname>** contains a table of any capsulations which have their own penalty as shown below:

```
RP/0/RSP0/CPU0:router# show im dampening
```

Interface	Protocol	Capsulation	Pen	Sup
GigabitEthernet0/0/0/0			629	NO
GigabitEthernet0/0/0/1			2389	YES
POS0/2/0/0			0	NO
POS0/2/0/0	<base>	ppp	0	NO
POS0/2/0/0	ipv4	ipcp	0	NO

```
RP/0/RSP0/CPU0:router# show im dampening interface TenGigE 0/1/0/0
```

```
TenGigE 0/1/0/0 (0x01180020)
```

```

Dampening enabled: Penalty 1625, SUPPRESSED (42 secs remaining)
Underlying state: Down
half-life: 1      reuse: 1000
suppress: 1500    max-suppress-time: 4
restart-penalty: 0

```

Protocol	Capsulation	Pen	Suppression	U-L State
ipv6	ipv6	1625	YES 42s remaining	Down



Note When dampening is configured on an interface it is also applied independently to all encapsulations on that interface. For example, the ppp or hdlc basecaps state can flap even while the interface stays up and if keepalives fail. The **show im dampening interface** command contains one line for each such encapsulation as well as the interface itself.

Table 1: show im dampening Field Descriptions

Field	Description
Dampening	Indicates the dampening state and penalty value: not suppressed, suppressed.
underlying state	Underlying state of the interface: up, down, administratively down (if an interface has been configured to be “shutdown”).
half_life	This is the time (in minutes) at which the penalty on the interface would be half that of the original penalty (of 1000) when the interface transitions from UP to DOWN. It ranges from 1 to 45 minutes and the default is 1 minute.
reuse	Penalty value below which a stable interface is unsuppressed. It ranges from 1 to 20000 and the default value is 750.
suppress	Limit at which an unstable interface is suppressed when the penalty value exceeds the suppress value. It ranges from 1 to 20000 and the default value is 2000.
max-suppress-time	Maximum time (in minutes) that an interface can be suppressed. The default is 4 minutes.
restart-penalty	Penalty assigned to the interface when it flaps.

Related Commands

Command	Description
dampening, on page 4	Turns on event dampening.
shutdown (global), on page 35	Disables an interface (forces an interface to be administratively down).

show interfaces

To display statistics, state and other information such as mac address etc. for all interfaces configured on the router or for a specific node, use the **show interfaces** command in EXEC mode.

show interfaces [**summary** | [*type interface-path-id* | **all** | **local**] [**non-dynamic**] [**brief** | **description** | **detail** | **sparse** | **accounting**]] [**location** *node-id*]

Syntax Description

<i>type</i>	(Optional) Specifies the type of interface for which you want to display statistics. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces brief command to see a list of all interfaces configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
all	(Optional) Displays interface information for all interfaces. This is the default.
local	(Optional) Displays interface information for all interfaces in the local card.
location <i>node-id</i>	(Optional) Displays information about all interfaces on the specified node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
accounting	(Optional) Displays the number of packets of each protocol type that have been sent through the interface.
brief	(Optional) Displays brief information of each interface (one line per interface).

description	(Optional) Displays the status, protocol, and description of each interface (one line per interface).
detail	(Optional) Displays detailed information about each interface. This is the default.
summary	(Optional) Displays a summary of interface information by interface type.
sparse	(Optional) Displays sparse per interface information excluding interface statistics.
non-dynamic	(Optional) Displays interface information excluding dynamic interfaces.

Command Default By default, executing **show interface** command without any option works similar as **show interface all**, and it displays the information for all interfaces in the system.

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 3.9.0	The err-disable interface state was added as a possible Interface state output value for bundle member links that have been administratively shut down.
	Release 4.2.0	Support for Bundle-POS and CEM interfaces was included.

Usage Guidelines The **show interfaces** command displays statistics, state and other information such as mac address etc. for the network interfaces.

For example, if you type the **show interfaces** command without an interface type, you receive information for all the interfaces installed in the networking device. Only by specifying the interface *type*, *slot*, and *port* arguments can you display information for a particular interface.

If you enter a **show interfaces** command for an interface type that has been removed from the networking device, an error message is displayed: “Interface not found.”

The output displayed depends on the network for which an interface has been configured.



Note Executing **show interfaces** command without filters obtains and displays interface statistics for all interfaces. Hence, it is recommended to execute the command with filters to select specific interfaces or interface types of interest for a faster response. Executing **show interfaces** with options **brief** or **sparse** excludes interface statistics thus providing a faster response.



Note The 5-minute input and output rates should be used only as an approximation of traffic per second during a given 5-minute period. These rates are exponentially weighted averages with a time constant of 5 minutes. A period of four time constants must pass before the average is within 2 percent of the instantaneous rate of a uniform stream of traffic over that period.

Task ID

Task ID Operations

interface read

Examples

This example shows the output from the **show interfaces** command. The output displayed depends on the type and number of interface cards in the networking device.

```
Router# show interfaces HundredGigE 0/3/0/35
```

```
HundredGigE0/3/0/35 is up, line protocol is up
Interface state transitions: 1
Hardware is HundredGigE, address is e666.9aa0.223c (bia e666.9aa0.223c)
Description: **To RouterX Hu0/7/0/2**
Internet address is 192.168.1.29/30
MTU 1514 bytes, BW 100000000 Kbit (Max: 100000000 Kbit)
  reliability 255/255, txload 239/255, rxload 238/255
Encapsulation ARPA,
Full-duplex, 100000Mb/s, unknown, link type is force-up
output flow control is off, input flow control is off
Carrier delay (up) is 10 msec
loopback not set,
Last link flapped 3w3d
ARP type ARPA, ARP timeout 04:00:00
Last input 00:00:00, output 00:00:00
Last clearing of "show interface" counters never
30 second input rate 93725392000 bits/sec, 32528692 packets/sec
30 second output rate 93726416000 bits/sec, 32527860 packets/sec
 68118736643563 packets input, 24783244282360579 bytes, 0 total input drops
 0 drops for unrecognized upper-level protocol
Received 0 broadcast packets, 0 multicast packets
 0 runts, 0 giants, 0 throttles, 0 parity
174 input errors, 174 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
68115867305777 packets output, 24782409845763776 bytes, 0 total output drops
Output 0 broadcast packets, 0 multicast packets
 0 output errors, 0 underruns, 0 applique, 0 resets
 0 output buffer failures, 0 output buffers swapped out
 0 carrier transitions
```

This example shows bundle member links whose link interface status is “err-disable” and line protocol state is “admin-down” after the bundle interface has been administratively shut down using the **shutdown** command:

```
Router# show interfaces brief
```

```
Thu May 6 06:30:55.797 DST
```

Intf Name	Intf State	LineP State	Encap Type	MTU (byte)	BW (Kbps)

BE10	down	down	ARPA	1514	0
BE100	up	up	ARPA	1514	100000000
BE101	up	up	ARPA	1514	100000000
Lo0	up	up	Loopback	1500	0
Nu0	up	up	Null	1500	0
Fo0/3/0/26	admin-down	admin-down	ARPA	1514	40000000
Hu0/3/0/0	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/1	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/2	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/3	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/4	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/5	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/6	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/7	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/8	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/9	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/10	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/11	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/12	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/13	down	down	ARPA	1514	100000000
Hu0/3/0/14	up	up	ARPA	1514	100000000
Hu0/3/0/15	up	up	ARPA	1514	100000000
Hu0/3/0/16	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/17	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/18	up	up	ARPA	1514	100000000
Hu0/3/0/19	up	up	ARPA	1514	100000000
Hu0/3/0/20	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/21	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/22	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/23	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/24	up	up	ARPA	1514	100000000
Hu0/3/0/25	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/27	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/28	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/29	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/30	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/31	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/32	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/33	admin-down	admin-down	ARPA	1514	100000000
Hu0/3/0/34	down	down	ARPA	1514	100000000
Hu0/3/0/35	up	up	ARPA	1514	100000000
Mg0/RP0/CPU0/0	up	up	ARPA	1514	1000000
Mg0/RP1/CPU0/0	up	up	ARPA	1514	1000000

This example shows the output from the **show interfaces interface-path-id sparse** command.

```
Router#show interfaces gigabitEthernet 0/1/0/0 sparse
Wed Apr 5 18:05:34.000 IST
```

```
Interface name : GigabitEthernet0/1/0/0
Operational state : administratively down
Admin state : administratively down
MAC address : 02:7d:42:e9:bd:36
Burned In Address : 027d.42e9.bd36
IPv4 Address : 2.2.2.2/24
Max. Bandwidth (Kbit) : 1000000
Effective Bandwidth (Kbit) : 1000000
MTU (in bytes) : 1514
Duplexity : Full-duplex
Link type : force-up
```

Table 2: show interfaces Field Descriptions

Field	Description
Interface name	Displays the name of the current interface. In the example, the interface name is TenGigE0/1/0/1.
Interface state	Displays the state of the interface. In the example, the interface is in the administratively down state.
Interface state transitions	<p>Displays the number of times the interface has changed the state.</p> <p>Note</p> <ul style="list-style-type: none"> Interface state transitions command counts only if the interface stays up. If the line protocol flaps, then it is not counted. Interface state transitions counts the state when the line protocol state changes the state from up to down/admin-down or admin-down/down to up. If an interface changes the state from down to admin-down or admin-down to down, the counter is not incremented. Use the clear state-transitions command to clear the counter for the current or all interfaces.
line protocol state	<p>Displays the state of the Layer 2 line protocol. This field may be different from the interface state if, for example, a keepalive failure has brought down the Layer 2.</p> <p>Note</p> <p>The line protocol state is not the same as the protocol state displayed in the show ip interfaces command, because it is the state of Layer 2 (media) rather than Layer 3 (IP protocol).</p>
Hardware	Displays the current hardware type.
address is <i>n.n.n.n/n</i>	<p>Displays the Layer 2 address (MAC address for Ethernet interfaces).</p> <p>Note</p> <p>Enter the mac-address command to configure the hardware address.</p>
bia	<p>Displays the burned-in address (BIA) for the interface. The BIA is the default L2 (MAC) address for the interface.</p> <p>Note</p> <p>The BIA is not configurable.</p>

Field	Description
description	<p>Displays the user-defined string that is associated with the interface.</p> <p>Note Enter the description command to configure the description associated with the interface.</p>
Internet address	<p>Displays the Layer 3 (IP) address for the interface.</p> <p>Note Enter the ipv4 address command to configure the internet address for the interface.</p>
MTU	<p>Displays the maximum transmission unit (MTU) for the interface. The MTU is the maximum packet size that can be transmitted over the interface.</p> <p>Note The MTU field indicates the interface MTU. Enter the mtu command to configure a lower MTU value at the Layer 3 level.</p>
BW	Displays the bandwidth of the interface in kbps.
reliability	<p>Displays the proportion of packets that are not dropped and do not have errors.</p> <p>Note The reliability is shown as a fraction of 255.</p>
txload	<p>Indicates the traffic flowing out of the interface as a proportion of the bandwidth.</p> <p>Note The txload is shown as a fraction of 255.</p>
rxload	<p>Indicates the traffic flowing into the interface as a proportion of the bandwidth.</p> <p>Note The rxload is shown as a fraction of 255.</p>
Encapsulation	Layer 2 encapsulation installed on the interface.
CRC	<p>Indicates the length of the cyclic redundancy check (CRC), in bytes.</p> <p>Note The CRC is not present for all interface types.</p> <p>Note Enter the pos crc command to configure the CRC.</p>

Field	Description
loopback or controller loopback	Indicates whether the hardware has been configured to be looped back. Note Enter the loopback command to configure the loopback or controller loopback.
keepalive	Displays the configured keepalive value, in seconds. Note Enter the keepalive command to configure the value of the keepalive field. Note The <i>keepalive</i> field may not be present if it is not applicable to the interface type.
Duplexity	Displays the duplexity of the link. Note This field is present only for shared media. Note For some interface types, you can configure the duplexity by entering the full-duplex and half-duplex commands.
Speed	Speed and bandwidth of the link in Mbps. This field is present only when other parts of the media info line are also displayed (see duplexity and media type).
Media Type	Media type of the interface.
output flow control	Whether output flow control is enabled on the interface.
input flow control	See output flow control.
ARP type	Address Resolution Protocol (ARP) type used on the interface. This value is not displayed on interface types that do not use ARP.
ARP timeout	ARP timeout in <i>hours:mins:secs</i> . This value is configurable using the arp timeout command.
Last clearing of counters	Time since the following counters were last cleared using the clear counters exec command in <i>hours:mins:secs</i> .

Field	Description
Input rate	<p>Average number of bits and packets received per second during the load-interval. If the interface is not in promiscuous mode, it senses network traffic that it sends and receives (rather than all network traffic).</p> <p>Note Load duration is based on load-interval configured under the interface. The default load duration is 5 minutes, if load-interval is not configured under the interface.</p> <p>Note The input rate should be used only as an approximation of traffic per second during a given load duration. This rate is exponentially weighted average with a time constant of load duration. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.</p>
packets input	Number of packets received on the interface that were successfully delivered to higher layers.
bytes input	<p>Total number of bytes successfully received on the interface.</p> <p>Note This does not include FCS bytes.</p>
total input drops	Total number of packets that were dropped after they were received. This includes packets that were dropped due to configured quality of service (QoS) or access control list (ACL) policies. This does not include drops due to unknown Layer 3 protocol.
drops for unrecognized upper-level protocol	Total number of packets that could not be delivered because the necessary protocol was not configured on the interface.
Received broadcast packets	Total number of Layer 2 broadcast packets received on the interface. This is a subset of the total input packet count.
Received multicast packets	Total number of Layer 2 multicast packets received on the interface. This is a subset of the total input packet count.
runts	Number of received packets that were too small to be handled. This is a subset of the input errors count.

Field	Description
giants	Number of received packets that were too large to be handled. This is a subset of the input errors count.
throttles	Number of packets dropped due to throttling (because the input queue was full).
parity	Number of packets dropped because the parity check failed.
input errors	Total number of received packets that contain errors and hence cannot be delivered. Compare this to total input drops, which counts packets that were not delivered despite containing no errors.
CRC	Number of packets that failed the CRC check.
frame	Number of packets with bad framing bytes.
overrun	Number of overrun errors experienced by the interface. Overruns represent the number of times that the receiver hardware is unable to send received data to a hardware buffer because the input rate exceeds the receiver's ability to handle the data.
ignored	Total number of ignored packet errors. Ignored packets are those that are discarded because the interface hardware does not have enough internal buffers. Broadcast storms and bursts of noise can result in an increased number of ignored packets.
abort	Total number of abort errors on the interface.
packets output	Number of packets received on the interface that were successfully delivered to higher layers.
bytes output	<p>Total number of bytes successfully received on the interface.</p> <p>Note This does not include FCS bytes.</p>
total output drops	Number of packets that were dropped before being transmitted
Received broadcast packets	Number of Layer 2 broadcast packets transmitted on the interface. This is a subset of the total input packet count.
Received multicast packets	Total number of Layer 2 multicast packets transmitted on the interface. This is a subset of the total input packet count.

Field	Description
output errors	Number of times that the receiver hardware was unable to handle received data to a hardware buffer because the input rate exceeded the receiver's ability to handle the data.
underruns	Number of underrun errors experienced by the interface. Underruns represent the number of times that the hardware is unable to transmit data to a hardware buffer because the output rate exceeds the transmitter's ability to handle the data.
applique	Number of applique errors.
resets	Number of times that the hardware has been reset. The triggers and effects of this event are hardware-specific.
output buffer failures	Number of times that a packet was not output from the output hold queue because of a shortage of MEMD shared memory.
output buffers swapped out	Number of packets stored in main memory when the output queue is full; swapping buffers to main memory prevents packets from being dropped when output is congested. The number is high when traffic is bursty.
carrier transitions	Number of times the carrier detect (CD) signal of a serial interface has changed state.

Related Commands

Command	Description
show controller interface	Displays information that is specific to the interface hardware statistics for all interfaces configured on the networking device.

show ethernet cfm interfaces bandwidth-notifications

To display detailed information about Ethernet CFM interfaces and bandwidth notifications, use the `show ethernet cfm interfaces bandwidth-notifications detail` command in XR EXEC mode.

show ethernet cfm interfaces bandwidth-notifications detail

Command Default	No default behavior or values	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 7.1.1	This command was introduced.
Task ID	Task ID	Operation
	interface	read

This example shows the output from the `show ethernet cfm interfaces bandwidth-notifications detail` command.

```
RP/0/RP0/CPU0:router#show ethernet cfm interfaces bandwidth-notifications detail
BNM Enabled Links at Level 3 (Down MEP) for GigabitEthernet/1
  MAC Address 000a.000a.000a
    State (OK):
      Nominal Bandwidth:                3000 Mbps
      Reported Bandwidth:               1000 Mbps
      Elapsed time in this state:       00:00:13.000
      Transitions into degraded state: 5000
      Hold-off:                        111s remaining
    Last BNM received 00:00:10 ago
      Nominal Bandwidth:                1000 Mbps
      Current Bandwidth:               2000 Mbps
      Interval:                        10s
      Packet-type:                     Cisco BW-VSM
    Packets received:                   20000

  Port ID 7 (MAC Address 000c.000c.000c)
    State (DEGRADED):
      Nominal Bandwidth:                6000 Mbps
      Reported Bandwidth:               2000 Mbps
      Elapsed time in this state:       00:00:39.000
      Transitions into degraded state: 10000
      Wait-to-restore:                  111s remaining
    Last BNM received 00:00:33 ago
      Nominal Bandwidth:                2000 Mbps
      Current Bandwidth:               4000 Mbps
      Interval:                        1min
      Packet-type:                     Cisco BW-VSM
    Packets received:                   40000
```


**Note**

This feature is supported only on 64-bit Linux-based IOS XR ASR 9000 operating system.

show mlacp inconsistencies

To check and highlight inconsistencies and misconfigurations in mlacp setup, use the **show mlacp inconsistencies** command in EXEC mode .

show mlacp inconsistencies

Syntax Description	This command has no keywords or arguments.	
Command Default	No default behavior or values.	
Command Modes	EXEC	
Command History	Release	Modification
	Release 4.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	bundle	read

Example

The followig example shows how to view mlacp inconsistencies:

```
RP/0/RSP0/CPU0:router # show mlacp inconsistencies
```

shutdown (global)

To disable an interface (to force an interface to be administratively down), use the **shutdown** command in interface configuration mode. To enable an interface that has been shut down, use the **no** form of this command.

shutdown

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	The interface is enabled by default and is disabled only when shutdown is configured.
------------------------	---



Note	When you add an interface to the system, or when all the configuration for an interface is lost or deleted, the interface is put in the shutdown state by the system adding the interface.
-------------	--

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	Use the shutdown command to move the state of an interface to administratively down, which stops traffic flowing through the interface. This state does not stop other action from happening on the interface such as changes in configuration, protocols, encapsulations, and so forth.
-------------------------	---

The **shutdown** command also marks the interface as unavailable. To check whether the state of an interface is down, use the **show interfaces** command in EXEC mode, which displays the current state of the interface. An interface that has been shut down is shown as administratively down in the display from the **show interfaces** command.

Task ID	Task ID	Operations
	interface	read, write

Examples

In this example, TenGigE interface 0/4/0/2 is turned off:

```
RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/4/0/2
RP/0/RSP0/CPU0:router(config-if)# shutdown
```

shutdown (global)