



Authentication, Authorization, and Accounting Commands

This module describes the commands used to configure authentication, authorization, and accounting (AAA) services.

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

For detailed information about AAA concepts, configuration tasks, and examples, see the *Configuring AAA Services on Cisco IOS XR Software* chapter in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

- [aaa accounting](#), on page 4
- [aaa accounting service](#), on page 6
- [aaa accounting system default](#), on page 8
- [aaa accounting system rp-failover](#), on page 10
- [aaa accounting update](#), on page 11
- [aaa attribute format](#), on page 12
- [aaa authentication](#) , on page 15
- [aaa authentication subscriber](#), on page 18
- [aaa authorization](#) , on page 20
- [aaa authorization \(System Admin-VM\)](#), on page 24
- [aaa authorization policy-intf](#), on page 26
- [aaa authorization prepaid](#), on page 27
- [aaa authorization subscriber](#), on page 28
- [aaa default-taskgroup](#), on page 30
- [aaa group server diameter \(BNG\)](#), on page 31
- [aaa group server radius](#), on page 32
- [aaa group server tacacs+](#), on page 34
- [aaa intercept](#), on page 36
- [aaa password-policy](#), on page 37
- [aaa radius attribute](#), on page 41
- [aaa service-accounting](#), on page 42
- [aaa server radius dynamic-author](#), on page 43
- [aaa radius attribute nas-port-type](#), on page 45

- accounting (line), on page 46
- accounting aaa list, on page 48
- accounting aaa list type service, on page 49
- accounting prepaid, on page 50
- authorization (line), on page 52
- clear tacacs counters, on page 54
- deadtime (server-group configuration), on page 56
- description (AAA), on page 58
- group (AAA), on page 59
- holddown-time (TACACS+), on page 61
- inherit taskgroup, on page 63
- inherit usergroup, on page 65
- key (RADIUS), on page 67
- key (TACACS+), on page 69
- login authentication, on page 70
- nacm enable-external-policies, on page 72
- password (AAA), on page 73
- aaa display-login-failed-users, on page 75
- radius-server attribute, on page 76
- radius-server attribute 11 default direction inbound, on page 77
- radius-server dead-criteria, on page 78
- radius-server dead-criteria time, on page 79
- radius-server dead-criteria tries, on page 81
- radius-server deadtime(BNG), on page 83
- radius-server disallow null-username, on page 84
- radius-server ipv4 dscp, on page 85
- radius-server host (BNG), on page 86
- radius-server key(BNG), on page 88
- radius-server load-balance, on page 90
- radius-server retransmit(BNG), on page 91
- radius-server source-port, on page 92
- radius-server timeout(BNG), on page 93
- radius-server throttle, on page 94
- radius-server vsa attribute ignore unknown, on page 95
- radius source-interface(BNG), on page 96
- restrict-consecutive-characters, on page 98
- retransmit (RADIUS), on page 100
- secret, on page 101
- server (RADIUS), on page 104
- server (TACACS+), on page 106
- server-private (RADIUS), on page 107
- server-private (TACACS+), on page 110
- show aaa , on page 112
- show aaa password-policy, on page 118
- show aaa trace, on page 120
- show nacm (XR-VM), on page 122

- show radius, on page 125
- show radius accounting, on page 127
- show radius authentication, on page 129
- show radius client, on page 131
- show radius dead-criteria, on page 133
- show radius server-groups, on page 135
- show radius server-groups detail, on page 138
- show subscriber database configuration brief service-profile, on page 140
- show tacacs, on page 141
- show tacacs counters, on page 143
- show tacacs details, on page 145
- show tacacs server-groups, on page 147
- show tacacs source-interface, on page 149
- show user, on page 150
- single-connection, on page 154
- single-connection-idle-timeout, on page 155
- statistics period service-accounting, on page 157
- tacacs-server host, on page 158
- tacacs-server key, on page 161
- tacacs-server timeout, on page 163
- tacacs-server ipv4, on page 164
- tacacs source-interface, on page 166
- task, on page 168
- taskgroup, on page 171
- timeout (RADIUS), on page 173
- timeout (TACACS+), on page 174
- timeout login response, on page 175
- usergroup, on page 176
- username, on page 178
- users group, on page 186
- vrf (RADIUS), on page 188
- vrf (TACACS+), on page 189

aaa accounting

To create a method list for accounting, use the **aaa accounting** command in Global Configuration mode. To remove a list name from the system, use the **no** form of this command.

```
aaa accounting {commands | exec | mobile | network | subscriber | system} {default | list-name}
{start-stop | stop-only} {none | method}
```

Syntax Description

commands	Enables accounting for EXEC shell commands.
exec	Enables accounting of an EXEC session.
mobile	Enables Mobile IP related accounting events.
network	Enables accounting for all network-related service requests, such as Internet Key Exchange (IKE) and Point-to-Point Protocol (PPP).
subscriber	Sets accounting lists for subscribers.
system	Enables accounting for all system-related events.
default	Uses the listed accounting methods that follow this keyword as the default list of methods for accounting services.
<i>list-name</i>	Character string used to name the accounting method list.
start-stop	Sends a “start accounting” notice at the beginning of a process and a “stop accounting” notice at the end of a process. The requested user process begins regardless of whether the “start accounting” notice was received by the accounting server.
stop-only	Sends a “stop accounting” notice at the end of the requested user process. Note: This is not supported with system accounting.
none	Uses no accounting.
<i>method</i>	Method used to enable AAA system accounting. The value is one of the following options: <ul style="list-style-type: none"> • group tacacs+—Uses the list of all TACACS+ servers for accounting. • group radius—Uses the list of all RADIUS servers for accounting. • group named-group—Uses a named subset of TACACS+ or RADIUS servers for accounting, as defined by the aaa group server tacacs+ or aaa group server radius command.

Command Default

AAA accounting is disabled.

Command Modes

Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
	Release 5.3.0	The mobile keyword was added.

Usage Guidelines

Use the **aaa accounting** command to create default or named method lists defining specific accounting methods and that can be used on a per-line or per-interface basis. You can specify up to four methods in the method list. The list name can be applied to a line (console, aux, or vty template) to enable accounting on that particular line.

The Cisco IOS XR software supports both TACACS+ and RADIUS methods for accounting. The router reports user activity to the security server in the form of accounting records, which are stored on the security server.

Method lists for accounting define the way accounting is performed, enabling you to designate a particular security protocol that is used on specific lines or interfaces for particular types of accounting services.

For minimal accounting, include the **stop-only** keyword to send a “stop accounting” notice after the requested user process. For more accounting, you can include the **start-stop** keyword, so that TACACS+ sends a “start accounting” notice at the beginning of the requested process and a “stop accounting” notice after the process. The accounting record is stored only on the TACACS+ server.

The requested user process begins regardless of whether the “start accounting” notice was received by the accounting server.



Note This command cannot be used with TACACS or extended TACACS.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to define a default commands accounting method list, where accounting services are provided by a TACACS+ security server, with a stop-only restriction:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa accounting commands default stop-only group tacacs+
```

Related Commands	Command	Description
	aaa authorization , on page 20	Creates a method list for authorization.

aaa accounting service

To create an accounting list for service accounting, use the **aaa accounting service** command in Global Configuration mode or Admin Configuration mode. To disable the service authentication method, use the **no** form of this command.

```
aaa accounting service {list_name | default} {broadcast group {group_name | diameter | radius}
| group {group_name | diameter | radius}}
```

Syntax Description	default	Uses the listed authentication methods that follow this keyword as the default list of methods for authentication.
	<i>list-name</i>	Represents the character string of the list name for AAA authentication.
	broadcast	Specifies the broadcast accounting for the service.
	group	Specifies the server-group.
	<i>group_name</i>	Specifies the server group name.
	diameter	Specifies the list of all DIAMETER peers.
	radius	Specifies the list of all RADIUS hosts.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.3.1	This command was introduced.
	Release 5.3.0	The diameter keyword was added for DIAMETER protocol support in BNG.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	aaa	read, write

This is an example of configuring the **aaa accounting service** command for the grpFR server group:

```
RP/0/RSP0/CPU0:router(config)# aaa accounting service default group grpFR
```

This example shows how to configure the **aaa accounting service** command with DIAMETER protocol to carry subscriber service accounting records to DIAMETER server using base accounting application:

aaa accounting system default

To enable authentication, authorization, and accounting (AAA) system accounting, use the **aaa accounting system default** command in Global Configuration mode. To disable system accounting, use the **no** form of this command.

aaa accounting system default {start-stop | stop-only} {none | method}

Syntax Description

start-stop	Sends a “start accounting” notice during system bootup and a “stop accounting” notice during system shutdown or reload.
stop-only	Sends a “stop accounting” notice during system shutdown or reload.
none	Uses no accounting.
<i>method</i>	Method used to enable AAA system accounting. The value is one of the following options: <ul style="list-style-type: none"> • group tacacs+—Uses the list of all TACACS+ servers for accounting. • group radius—Uses the list of all RADIUS servers for accounting. • group named-group—Uses a named subset of TACACS+ or RADIUS servers for accounting, as defined by the aaa group server tacacs+ or aaa group server radius command.

Command Default

AAA accounting is disabled.

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

System accounting does not use named accounting lists; you can define only the default list for system accounting.

The default method list is automatically applied to all interfaces or lines. If no default method list is defined, then no accounting takes place.

You can specify up to four methods in the method list.

Task ID

Task ID	Operations
aaa	read, write

Examples

This example shows how to cause a “start accounting” record to be sent to a TACACS+ server when a router initially boots. A “stop accounting” record is also sent when a router is shut down or reloaded.


```
RP/0/RSP0/CPU0:router# configure  
RP/0/RSP0/CPU0:router(config)# aaa accounting system default start-stop group tacacs+
```

Related Commands

Command	Description
aaa authentication , on page 15	Creates a method list for authentication.
aaa authorization , on page 20	Creates a method list for authorization.

aaa accounting system rp-failover

To create an accounting list to send rp-failover or rp-switchover start or stop accounting messages, use the **aaa accounting system rp-failover** command in Global Configuration mode. To disable the system accounting for rp-failover, use the **no** form of this command.

```
aaa accounting system rp-failover {list_name {start-stop|stop-only} | default {start-stop|stop-only}}
```

Syntax Description		
	<i>list_name</i>	Specifies the accounting list name.
	default	Specifies the default accounting list.
	start-stop	Enables the start and stop records.
	stop-only	Enables the stop records only.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task	Operation
	aaa	read, write

This is an example of configuring the **aaa accounting system rp-failover** command for default accounting list:

```
RP/0/RSP0/CPU0:router(config)# aaa accounting system rp-failover default start-stop none
```

Related Commands

Command	Description
aaa attribute format	Create an AAA attribute format name.

aaa accounting update

To enable periodic interim accounting records to be sent to the accounting server, use the **aaa accounting update** command in Global Configuration mode. To disable the interim accounting updates, use the **no** form of this command.

aaa accounting update {**periodic** *minutes*}

Syntax Description	periodic <i>minutes</i>	(Optional) Sends an interim accounting record to the accounting server periodically, as defined by the <i>minutes</i> argument, which is an integer that specifies the number of minutes. The range is from 1 to 35791394 minutes.
---------------------------	-----------------------------------	--

Command Default AAA accounting update is disabled.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines When used with the **periodic** keyword, interim accounting records are sent periodically as defined by the *minutes* argument. The interim accounting record contains all the accounting information recorded for that user up to the time the accounting record is sent.



Caution Using the **aaa accounting update** command with the **periodic** keyword can cause heavy congestion when many users are logged into the network.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to send periodic interim accounting records to the RADIUS server at 30-minute intervals:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa accounting update periodic 30
```

Related Commands	Command	Description
	aaa accounting , on page 4	Creates a method list for accounting.
	aaa authorization , on page 20	Creates a method list for authorization.

aaa attribute format

To create an AAA attribute format name and to enter the configuration ID format sub mode, use the **aaa attribute format** command in Global Configuration mode. To disable this AAA attribute format, use the **no** form of this command.

```
aaa attribute format format_name [ circuit-id[plus][ mac-address| remote-id ] [ separator separator ]
| format-string [ length length ] { string [Identity-Attribute] } | mac-address [plus][ circuit-id |
remote-id ] [ separator separator ] | remote-id [plus][ circuit-id | mac-address ] [ separator separator ]
| username-strip { prefix-delimiter | suffix-delimiter } { delimiter } ]
```

Syntax Description

<i>format_name</i>	Specifies the name of the format.
circuit-id	Specifies the construction of the AAA attribute format name for subscribers based on the circuit-ID.
format-string	Specifies the extended string format of the AAA attribute format name.
<i>string</i>	Specifies the regular ASCII characters that includes conversion specifiers. The value is enclosed in double quotes.
<i>Identity-Attribute</i>	Identifies a session. For more information about the syntax for the router, use the question mark (?) online help function.
length	Specifies the length of the formatted attribute string.
<i>length</i>	Length of the formatted string, in integer. The range is from 1 to 253.
mac-address	Specifies the construction of the AAA attribute format name for subscribers based on the mac-address. The MAC address must be in the form of three 4-digit values (12 digits in dotted decimal notation).
remote-id	Specifies the construction of the AAA attribute format name for subscribers based on the remote-ID.
plus	Specifies the use of additional identifiers.
separator	Specifies the separator to be used between keys.
<i>separator</i>	Separator to be used between keys, default is a semicolon.
username-strip	Configures a network access server (NAS) to strip both suffixes and/or prefixes from the username before forwarding the username to the remote RADIUS server.

prefix-delimiter	Enables prefix stripping and specifies the character that will be recognized as a prefix delimiter.
suffix-delimiter	Enables suffix stripping and specifies the character that will be recognized as a suffix delimiter.
<i>Delimiter</i>	Suffix or prefix delimiter.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 4.2.0	This command was introduced.
Release 4.2.1	The support for format-string keyword was added.
Release 6.2.1	Introduced support for a new MAC address format, client-mac-address-custom1 , which is in 01.23.45.67.89.AB format.
Release 6.4.1	Introduced support for dhcpv6-client-id-enterprise-identifier , dhcpv6-vendor-class-spl , dhcpv4-client-id-spl and dhcpv4-vendor-class as part of enabling AAA username formation using DHCP option 1 and option 16.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operation
aaa	read, write

This is an example of configuring the **aaa attribute format** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)# aaa attribute format form1
RP/0/RSP0/CPU0:router(config-id-format)# format-string "%s%s"
RP/0/RSP0/CPU0:router(config-id-format)# username-strip prefix-delimiter @
```

This is an example of configuring MAC address in "01.23.45.67.89.AB" format:

```
RP/0/RSP0/CPU0:router(config)# aaa attribute format form1
RP/0/RSP0/CPU0:router(config-id-format)# format-string length 253 "%s"
client-mac-address-custom1
```

This example shows how to enable AAA username formation using DHCP option 1 and option 16 in BNG:

```
RP/0/RSP0/CPU0:router(config)# aaa attribute format format_v6  
RP/0/RSP0/CPU0:router(config-id-format)# format-string length 233 "%s@%s"  
dhcpv6-client-id-enterprise-identifier dhcpv6-vendor-class-string
```

aaa authentication

To create a method list for authentication, use the **aaa authentication** command. To disable this authentication method, use the **no** form of this command.

```
aaa authentication {login | ppp} {default|list-name | remote} method-list
```

Syntax Description

login	Sets authentication for login.
ppp	Sets authentication for Point-to-Point Protocol.
default	Uses the listed authentication methods that follow this keyword as the default list of methods for authentication.
subscriber	Sets the authentication list for the subscriber.
<i>list-name</i>	Character string used to name the authentication method list.
remote	Uses the listed authentication methods that follow this keyword as the default list of methods for administrative authentication on a remote non-owner secure domain router. The remote keyword is used only with the login keyword and not with the ppp keyword.
Note	The remote keyword is available only on the administration plane.

method-list Method used to enable AAA system accounting. The value is one of the following options:

- **group tacacs+**—Specifies a method list that uses the list of all configured TACACS+ servers for authentication.
- **group radius**—Specifies a method list that uses the list of all configured RADIUS servers for authentication.
- **group named-group**—Specifies a method list that uses a named subset of TACACS+ or RADIUS servers for authentication, as defined by the **aaa group server tacacs+** or **aaa group server radius** command.
- **local**—Specifies a method list that uses the local username database method for authentication. AAA method rollover happens beyond the local method if username is not defined in the local group.
- **line**—Specifies a method list that uses the line password for authentication.

Command Default

Default behavior applies the local authentication on all ports.

Command Modes

Global Configuration mode

Admin Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **aaa authentication** command to create a series of authentication methods, or method list. You can specify up to four methods in the method list. A *method list* is a named list describing the authentication methods (such as TACACS+ or RADIUS) in sequence. The subsequent methods of authentication are used only if the initial method is not available, not if it fails.

The default method list is applied for all interfaces for authentication, except when a different named method list is explicitly specified—in which case the explicitly specified method list overrides the default list.

For console and vty access, if no authentication is configured, a default of local method is applied.

**Note**

- The **group tacacs+**, **group radius**, and **group group-name** forms of this command refer to a set of previously defined TACACS+ or RADIUS servers.
- Use the **tacacs-server host** or **radius-server host** command to configure the host servers.
- Use the **aaa group server tacacs+** or **aaa group server radius** command to create a named subset of servers.
- The **login** keyword, **remote** keyword, **local** option, and **group** option are available only in administration configuration mode.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to specify the default method list for authentication, and also enable authentication for console in global configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa authentication login default group tacacs+
```

The following example shows how to specify the remote method list for authentication, and also enable authentication for console in administration configuration mode:

```
RP/0/RSP0/CPU0:router# admin
RP/0/RSP0/CPU0:router (admin)# configure
RP/0/RSP0/CPU0:router(admin-config)# aaa authentication login remote local group tacacs+
```

Related Commands

Command	Description
aaa accounting, on page 4	Creates a method list for accounting.
aaa authorization, on page 20	Creates a method list for authorization.
aaa group server radius, on page 32	Groups different RADIUS server hosts into distinct lists and distinct methods.

Command	Description
aaa group server tacacs+, on page 34	Groups different TACACS+ server hosts into distinct lists and distinct methods.
login authentication, on page 70	Enables AAA authentication for logins.
tacacs-server host, on page 158	Specifies a TACACS+ host.

aaa authentication subscriber

To create a method list for subscriber authentication, use the **aaa authentication subscriber** command in Global Configuration mode. To disable this subscriber authentication method, use the **no** form of this command.

aaa authentication subscriber {*list_name* | **default**} **group** {*server_group_name* | **diameter** | **radius**}

Syntax Description		
	default	Uses the listed authentication methods that follow this keyword as the default list of methods for authentication.
	<i>list-name</i>	Represents the character string for the list name for AAA authentication.
	group	Specifies the server-group.
	diameter	Specifies the list of all DIAMETER peers.
	radius	Specifies the list of all RADIUS hosts.
	<i>server_group_name</i>	Specifies the server group name.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.
	Release 5.3.0	The diameter keyword was added for DIAMETER protocol support in BNG.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	aaa	read, write

This is an example of configuring the **aaa authentication subscriber** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)# aaa authentication subscriber sub1 group sg1 group sg2
```

This example shows how to configure the **aaa authentication subscriber** command with DIAMETER protocol to carry subscriber authentication with DIAMETER protocol using NASREQ application:

```
RP/0/RSP0/CPU0:router(config)# aaa authentication subscriber default group diameter
```

Related Commands

Command	Description
aaa authorization subscriber, on page 28	Creates authorization-related configurations

aaa authorization

To create a method list for authorization, use the **aaa authorization** command in Global Configuration mode. To disable authorization for a function, use the **no** form of this command.

```
aaa authorization { commands | eventmanager | exec | network | subscriber | nacm } { default
list-name } { none | local | prefer-external | only-external | group { tacacs + | radius group-name
} }
```

Syntax Description	
commands	Configures authorization for all EXEC shell commands.
eventmanager	Applies an authorization method for authorizing an event manager (fault manager).
exec	Configures authorization for an interactive (EXEC) session.
network	Configures authorization for network services, such as PPP or Internet Key Exchange (IKE).
subscriber	Sets the authorization lists for the subscriber.
nacm	Enables the nacm functionality.
default	Uses the listed authorization methods that follow this keyword as the default list of methods for authorization.
<i>list-name</i>	Character string used to name the list of authorization methods.
none	Uses no authorization. If you specify none , no subsequent authorization methods is attempted. However, the task ID authorization is always required and cannot be disabled.
local	Uses local authorization. While this method of authorization is already supported, it is available for command authorization only from Cisco IOS XR Software Release 7.5.1 and later.
prefer-external	Adds the external group names to the list of local group names to determine the access control rules.
only-external	Uses the external group names to determine the access control rules.
group tacacs+	Uses the list of all configured TACACS+ servers for authorization.
group radius	Uses the list of all configured RADIUS servers for authorization. This method of authorization is not available for command authorization.
group group-name	Uses a named subset of TACACS+ or RADIUS servers for authorization as defined by the aaa group server tacacs+ or aaa group server radius command.

Command Default Authorization is disabled for all actions (equivalent to the method **none** keyword).

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 7.5.1	The command was modified to make the local option available for command authorization as well.
	Release 7.4.1	NACM prefer-external and only-external keywords are introduced.
	Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **aaa authorization** command to create method lists defining specific authorization methods that can be used on a per line or a per interface basis. You can specify up to four methods in the method list.



Note NACM authorization cannot be configured on a per line or a per interface basis.



Note The NACM authorization mentioned here applies to the one performed by an external AAA server and *not* for task-based authorization.

Method lists for authorization define the ways authorization will be performed and the sequence in which these methods will be performed. A method list is a named list describing the authorization methods (such as TACACS+), in sequence. Method lists enable you to designate one or more security protocols for authorization, thus ensuring a backup system in case the initial method fails. Cisco IOS XR software uses the first method listed to authorize users for specific network services; if that method fails to respond, Cisco IOS XR software selects the next method listed in the method list. This process continues until there is successful communication with a listed authorization method or until all methods defined have been exhausted.



Note Cisco IOS XR software attempts authorization with the next listed method only when there is no response (not a failure) from the previous method. If authorization fails at any point in this cycle—meaning that the security server or local username database responds by denying the user services—the authorization process stops and no other authorization methods are attempted.

The Cisco IOS XR software supports the following methods for authorization:

- **none**—The router does not request authorization information; authorization is not performed over this line or interface.
- **local**—Use the local database for authorization.
- **prefer-external**—Use the external database for authorization. The external group names are added to the list of local group names list to determine the access control rules. External group names are preferred from the list. If the option is not mentioned, the local group names are preferred from the list.
- **only-external**—Use only external group names to determine the access control rules.
- **group tacacs+**—Use the list of all configured TACACS+ servers for authorization.
- **group radius**—Use the list of all configured RADIUS servers for authorization.
- **group group-name**—Uses a named subset of TACACS+ or RADIUS servers for authorization.



Note The group RADIUS is not applicable to NACM and command authorizations.

Method lists are specific to the type of authorization being requested. Cisco IOS XR software supports four types of AAA authorization:

- **Commands authorization**—Applies to the EXEC mode commands a user issues. Command authorization attempts authorization for all EXEC mode commands.



Note “Command” authorization is distinct from “task-based” authorization, which is based on the task profile established during authentication.

- **EXEC authorization**—Applies authorization for starting an EXEC session.



Note The **exec** keyword is no longer used to authorize the fault manager service. The **eventmanager** keyword (fault manager) is used to authorize the fault manager service. The **exec** keyword is used for EXEC authorization.

- **Network authorization**—Applies authorization for network services, such as IKE.
- **Event manager authorization**—Applies an authorization method for authorizing an event manager (fault manager). You are allowed to use TACACS+ or LOCAL.



Note The **eventmanager** keyword (fault manager) replaces the **exec** keyword to authorize event managers (fault managers).

When you create a named method list, you are defining a particular list of authorization methods for the indicated authorization type. When defined, method lists must be applied to specific lines or interfaces before any of the defined methods are performed.

To know more about command authorization using local user account feature which was introduced in Cisco IOS XR Software Release 7.5.1, see the *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to define the network authorization method list named listname1, which specifies that TACACS+ authorization is used:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa authorization commands listname1 group tacacs+
```

Examples

The following example shows how to enable the NACM authorization to use the external group names for determining the access control rules. NACM is disabled by default. To enable NACM, you must have `root-lr` or `aaa write task privilege` to enable or disable NACM.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa authorization nacm default only-external local
```

The following examples show how to configure command authorization using local user account:

```
Router#configure
Router(config)#aaa authorization commands default group tacacs+ local
Router(config)#commit
```

OR

```
Router(config)#aaa authorization commands default local
Router(config)#commit
```

Related Commands

Command	Description
aaa accounting , on page 4	Creates a method list for accounting.

aaa authorization (System Admin-VM)

To create command rules and data rules on System Admin VM for user authorization, use the **aaa authorization** command in Admin Configuration mode. To delete the command rules and data rules, use the **no** form of this command.

```
aaa authorization { cmdrules cmdrule { integer | range integer } [{ action action-type |
command cmd-name | context context-name | group group-name | ops ops-type }] | commands
group { none | tacacs } | datarules datarule { integer | range integer } [{ action action-type
| context context-name | group group-name | keypath keypath-name | namespace namespace-string
| ops ops-type }]} }
```

Syntax Description		
cmdrules		Configures command rules.
cmdrule <i>integer</i>		Specifies the command rule number.
range <i>integer</i>		Specifies the range of the command rules or data rules to be configured.
action		Specifies whether users are permitted or not allowed to perform the operation specified for the ops keyword.
<i>action-type</i>		Specifies the action type for the command rule or data rule. Available options are: accept , accept_log and reject .
command <i>cmd-name</i>		Specifies the command to which the command rule applies. The command must be entered within double-quotes. Example, get .
context <i>context-name</i>		Specifies to which type of connection the command rule or data rule applies. The connection type can be netconf, cli, or xml.
group <i>group-name</i>		Specifies the group to which the command rule or data rule applies. Example, admin-r .
ops <i>ops-type</i>		Specifies whether the user has read, execute, or read and execute permissions for the command. Available options for command rules are: r , rx , and x . To know the available options for data rules, use a ? after the ops keyword.
commands group		Sets the command authorization lists for server groups. Available options are none that specifies no authorization and tacacs that specifies use of the list of all tacacs+ hosts.
datarules		Configures data rules.
datarule <i>integer</i>		Specifies the data rule number.
keypath		Specifies the keypath of the data element. If you enter an asterisk '*' for keypath, it indicates that the command rule is applicable to all configuration data.

namespace	Enter asterisk "*" to indicate that the data rule is applicable for all namespace values.
------------------	---

Command Default	None
------------------------	------

Command Modes	Admin Configuration mode
----------------------	--------------------------

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

Usage Guidelines

From Cisco IOS XR Software Release 7.4.1 and later, the system internally maps the users configured on the XR VM to System Admin VM of the router, based on the task table of the user on the XR VM. With this feature, NETCONF and gRPC users can access the admin-related information on the router even if their user profiles do not exist on System Admin VM. For a sample configuration, see the example section.

For more details, see the *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

This example shows how to create a command rule:

```
sysadmin-vm:0_RP0#config
sysadmin-vm:0_RP0(config)#aaa authorization cmdrules cmdrule 10 action accept command "show
platform" context cli group group1 ops rx
```

This example shows how to create a data rule:

```
sysadmin-vm:0_RP0#config
sysadmin-vm:0_RP0(config)#aaa authorization datarules datarule 20 action accept context cli
group group10 keypath * namespace * ops rwx
```

This example shows how to configure a command rule for a NETCONF or gRPC session to allow read access for **admin-r** group users:

```
sysadmin-vm:0_RP0(config)#aaa authorization cmdrules cmdrule 6 context netconf command get
group admin-r ops rx action accept
```

aaa authorization policy-intf

To configure authorization lists for DIAMETER policy interface (Gx interface), use the **aaa authorization policy-intf** command in Global Configuration mode. To remove the authorization lists for DIAMETER policy interface (Gx interface), use the **no** form of this command.

```
aaa authorization policy-if {list-name | default} group {server-group-name | diameter}
```

Syntax Description	Parameter	Description
	<i>list-name</i>	Specifies the list name for AAA authorization.
	default	Specifies default list name for AAA authorization.
	group	Specifies the server-group.
	<i>server-group-name</i>	Specifies the server-group name.
	diameter	Specifies the list of all DIAMETER peers.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task	Operation
	aaa	read, write

This example shows how to configure authorization lists for DIAMETER policy interface (Gx interface) in BNG:

```
RP/0/RSP0/CPU0:router(config)# aaa authorization policy-intf default group diameter
```

Related Commands	Command	Description
	aaa authorization prepaid, on page 27	Configures authorization lists for DIAMETER prepaid interface (Gy interface).

aaa authorization prepaid

To configure authorization lists for DIAMETER prepaid interface (Gy interface), use the **aaa authorization prepaid** command in Global Configuration mode. To remove the authorization lists for DIAMETER prepaid interface (Gy interface), use the **no** form of this command.

```
aaa authorization prepaid {list-name | default} group {server-group-name | diameter}
```

Syntax Description	Parameter	Description
	<i>list-name</i>	Specifies the list name for AAA authorization.
	default	Specifies default list name for AAA authorization.
	group	Specifies the server-group.
	<i>server-group-name</i>	Specifies the server-group name.
	diameter	Specifies the list of all DIAMETER peers.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	aaa	read, write

This example shows how to configure authorization lists for DIAMETER prepaid interface (Gy interface) in BNG:

```
RP/0/RSP0/CPU0:router(config)# aaa authorization prepaid default group diameter
```

Related Commands	Command	Description
	aaa authorization policy-intf, on page 26	Configures authorization lists for DIAMETER policy interface (Gx interface).

aaa authorization subscriber

To create authorization-related configurations, use the **aaa authorization subscriber** command in Global Configuration mode. To disable this subscriber authorization method, use the **no** form of this command.

aaa authorization subscriber *{list_name | default}* **group** *{server_group_name | diameter | radius}*

Syntax Description	Key	Description
	default	Uses the listed authentication methods that follow this keyword as the default list of methods for authentication.
	<i>list-name</i>	Represents the character string for the list name for AAA authorization.
	group	Specifies the server-group.
	diameter	Specifies the list of all DIAMETER peers.
	radius	Specifies the list of all RADIUS hosts.
	<i>server_group_name</i>	Specifies the server group name.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.
	Release 5.3.0	The diameter keyword was added for DIAMETER protocol support in BNG.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	aaa	read, write

This is an example of configuring the **aaa authorization subscriber** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)# aaa authorization subscriber sub1 group sg1 group sg2
```

This example shows how to configure the **aaa authorization subscriber** command to carry subscriber authorization with DIAMETER protocol using NASREQ application:

```
RP/0/RSP0/CPU0:router(config)# aaa authorization subscriber default group diameter
```

Related Commands	Command	Description
	aaa authentication subscriber, on page 18	Creates a method list for subscriber authentication.

aaa default-taskgroup

To specify a task group for both remote TACACS+ authentication and RADIUS authentication, use the **aaa default-taskgroup** command in Global Configuration mode. To remove this default task group, enter the **no** form of this command.

aaa default-taskgroup *taskgroup-name*

Syntax Description	<i>taskgroup-name</i> Name of an existing task group.
---------------------------	---

Command Default	No default task group is assigned for remote authentication.
------------------------	--

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use the **aaa default-taskgroup** command to specify an existing task group for remote TACACS+ authentication.

Task ID	Task ID	Operations
	aaa	read, write

Examples	The following example shows how to specify taskgroup1 as the default task group for remote TACACS+ authentication:
-----------------	--

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa default-taskgroup taskgroup1
```

aaa group server diameter (BNG)

To configure the named server group for DIAMETER, and to enter the server group sub-mode, use the **aaa group server diameter** command in Global Configuration mode. To remove the named server group for DIAMETER, use the **no** form of this command.

```
aaa group server diameter server-group-name
```

Syntax Description	<i>server-group-name</i> Specifies the server-group name.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	aaa	read, write

This example shows how to configure the named server group for DIAMETER, and to enter the server group sub-mode in BNG:

```
RP/0/RSP0/CPU0:router(config)# aaa group server diameter GX_SG
```

aaa group server radius

To group different RADIUS server hosts into distinct lists, use the **aaa group server radius** command in Global Configuration mode. To remove a group server from the configuration list, enter the **no** form of this command.

aaa group server radius *group-name*

Syntax Description	<i>group-name</i> Character string used to name the group of servers.
---------------------------	---

Command Default	This command is not enabled.
------------------------	------------------------------

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	Use the aaa group server radius command to group existing server hosts, which allows you to select a subset of the configured server hosts and use them for a particular service. A server group is used in conjunction with a global server-host list. The server group lists the IP addresses or hostnames of the selected server hosts.
-------------------------	---

Server groups can also include multiple host entries for the same server, as long as each entry has a unique identifier. The combination of an IP address and User Datagram Protocol (UDP) port number creates a unique identifier, allowing different ports to individually defined as RADIUS hosts providing a specific authentication, authorization, and accounting (AAA) service. In other words, this unique identifier enables RADIUS requests to be sent to different UDP ports on a server at the same IP address. If two different host entries on the same RADIUS server are configured for the same service, for example, accounting, the second host entry acts as an automatic switchover backup to the first host entry. Using this example, if the first host entry fails to provide accounting services, the network access server tries the second host entry on the same device for accounting services. The RADIUS host entries are tried in the order in which they are configured in the server group.

All members of a server group must be the same type, that is, RADIUS.

The server group cannot be named radius or tacacs.

This command enters server group configuration mode. You can use the server command to associate a particular RADIUS server with the defined server group.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows the configuration of an AAA group server named radgroup1, which comprises three member servers:

```
RP/0/RSP0/CPU0:router# configure
```



```

RP/0/RSP0/CPU0:router(config)# aaa group server radius radgroup1
RP/0/RSP0/CPU0:router(config-sg-radius)# server 10.0.0.5 auth-port 1700 acct-port 1701
RP/0/RSP0/CPU0:router(config-sg-radius)# server 10.0.0.10 auth-port 1702 acct-port 1703
RP/0/RSP0/CPU0:router(config-sg-radius)# server 10.0.0.20 auth-port 1705 acct-port 1706

```



Note If the **auth-port** *port-number* and **acct-port** *port-number* keywords and arguments are not specified, the default value of the *port-number* argument for the **auth-port** keyword is 1645 and the default value of the *port-number* argument for the **acct-port** keyword is 1646.

Related Commands

Command	Description
key (RADIUS), on page 67	Specifies the authentication and encryption key that is used between the router and the RADIUS daemon running on the RADIUS server.
radius source-interface(BNG), on page 96	Forces RADIUS to use the IP address of a specified interface or subinterface for all outgoing RADIUS packets.
retransmit (RADIUS), on page 100	Specifies the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly.
server (RADIUS), on page 104	Associates a RADIUS server with a defined server group.
server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.
timeout (RADIUS), on page 173	Specifies the number of seconds the router waits for the RADIUS server to reply before retransmitting.
vrf (RADIUS), on page 188	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.

aaa group server tacacs+

To group different TACACS+ server hosts into distinct lists, use the **aaa group server tacacs+** command in Global Configuration mode. To remove a server group from the configuration list, enter the **no** form of this command.

```
aaa group server tacacs+ group-name
```

Syntax Description

group-name Character string used to name a group of servers.

Command Default

This command is not enabled.

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 5.3.0	IPv6 support was introduced on this command.

Usage Guidelines

The AAA server-group feature introduces a way to group existing server hosts. The feature enables you to select a subset of the configured server hosts and use them for a particular service.

The **aaa group server tacacs+** command enters server group configuration mode. The **server** command associates a particular TACACS+ server with the defined server group.

A *server group* is a list of server hosts of a particular type. The supported server host type is TACACS+ server hosts. A server group is used with a global server host list. The server group lists the IP addresses or hostnames of the selected server hosts.

The server group cannot be named radius or tacacs.



Note Group name methods refer to a set of previously defined TACACS+ servers. Use the **tacacs-server host** command to configure the host servers.

From Cisco IOS XR Software Release 7.4.1 and later, you can configure a hold-down timer for TACACS+ server. For details, see the **holddown-time** command.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows the configuration of an AAA group server named tacgroup1, which comprises three member servers:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server tacacs+ tacgroup1
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server 192.168.200.226
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server 192.168.200.227
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server 192.168.200.228
```

Related Commands

Command	Description
aaa accounting, on page 4	Creates a method list for accounting.
aaa authentication , on page 15	Creates a method list for authentication.
aaa authorization , on page 20	Creates a method list for authorization.
server (TACACS+), on page 106	Specifies the host name or IP address of an external TACACS+ server.
tacacs-server host, on page 158	Specifies a TACACS+ host.

aaa intercept

To enable RADIUS-based Lawful Intercept (LI) feature on a router, use the **aaa intercept** command in Global Configuration mode. To disable RADIUS-based Lawful Intercept feature, use the **no** form of this command.

aaa intercept

Syntax Description This command has no keywords or arguments.

Command Default RADIUS-based Lawful Intercept feature is not enabled.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.3.0	This command was introduced.
	Release 4.3.2	By default, Lawful Intercept (LI) is not a part of the Cisco IOS XR software. The LI package needs to be installed separately. So, this command is enabled only after installing and activating the asr9k-li-px.pie.

Usage Guidelines To use **aaa intercept** command, you must install and activate the **asr9k-li-px.pie**.

Use the **aaa intercept** command to enable a RADIUS-Based Lawful Intercept solution on your router. Intercept requests are sent (through Access-Accept packets or CoA-Request packets) to the network access server (NAS) or the Layer 2 Tunnel Protocol (L2TP) access concentrator (LAC) from the RADIUS server. All data traffic going to, or from, a PPP or L2TP session is passed to a mediation device.

Task ID	Task ID	Operation
	aaa	read, write
	li	read

This example shows how to configure **aaa intercept** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa intercept
```

aaa password-policy

To define a AAA password security policy, use the **aaa password-policy** command in Global Configuration mode. To remove the AAA password security policy, use the **no** form of this command.

```
aaa password-policy policy-name {min-length min-length | max-length max-length | special-char
special-char | upper-case upper-case | lower-case lower-case | numeric numeric | lifetime {years |
months | days | hours | minutes | seconds} lifetime | min-char-change min-char-change |
authen-max-attempts authen-max-attempts | lockout-time {days | hours | minutes | seconds} lockout-time
| warn-interval { years | months | days | hours | minutes | seconds } | restrict-old-time { years
| months | days } | max-char-repetition max-char-repetition | restrict-old-count restrict-old-count
| restrict-password-advanced | restrict-password-reverse | restrict-username |
restrict-username-reverse }
```

Syntax Description

policy-name	Specifies the name of the password, in characters.
min-length	Specifies the minimum length of the password, in integer.
max-length	Specifies the maximum length of the password, in integer.
special-char	Specifies the number of special characters allowed in the password policy, in integer.
upper-case	Specifies the number of upper case alphabets allowed in the password policy, in integer.
lower-case	Specifies the number of lower case alphabets allowed in the password policy, in integer.
numeric	Specifies the number of numerals allowed in the password policy, in integer.
lifetime	Specifies the maximum lifetime for the password, the value of which is specified in integer, as years, months, days, hours, minutes or seconds.
min-char-change	Specifies the number of character change required between subsequent passwords, in integer.
authen-max-attempts	Specifies, in integer, the maximum number of authentication failure attempts allowed for a user, in order to restrict users who authenticate with invalid login credentials.
lockout-time	Specifies, in integer, the duration (in days, hours, minutes or seconds) for which the user is locked out when he exceeds the maximum limit of authentication failure attempts allowed.
warn-interval	Specifies the amount of time to notify the user about an expiring password, the value of which is specified in integer, as years, months, days, hours, minutes or seconds.
restrict-old-time	Specifies, in integer, the amount of time for which an old password is considered as valid. The value is specified in years, months, or days.

max-char-repetition	Specifies the consecutive number of times a character can be repeated in a password.
restrict-old-count	Specifies the count for the number of old passwords that cannot be reused.
restrict-password-advanced	Specifies the advanced restrictions on a new password.
restrict-password-reverse	Restricts the new password from being the same as the reversed old password.
restrict-username	Restricts the use of an associated username as a password.
restrict-username-reverse	Restricts the usage of associated username reversed as a password.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 6.2.1	This command was introduced.

Usage Guidelines AAA password security policy works as such for Cisco IOS XR platforms. Whereas, this feature is supported only on XR VM, for Cisco IOS XR 64 bit platforms.

For more details on the usage of each option of this command, refer the section on *AAA Password Security for FIPS Compliance* in *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

You must configure both **authen-max-attempts** and **lockout-time** in order for the lock out functionality to take effect.

The **min-char-change** option is effective only for password change through logon, and not for password change by configuration.

Use **username** command along with **password-policy** option, in the Global Configuration mode, to associate the password policy with a particular user.

When **warn-interval** is enabled and it expires, the user is prompted at login to change the password or has the option to skip. If **warn-interval** and **lifetime** have both expired, the user must change their password.

From Cisco IOS XR Software Release 7.2.1 and later, most of the options of the **aaa password-policy** command listed in the syntax above are applicable to user password as well as secret. Whereas, the options listed below are supported only for password, and not for secret:

- **max-char-repetition**
- **min-char-change**
- **restrict-password-reverse**
- **restrict-password-advanced**

This table lists the default, maximum and minimum values of various command variables:

Command Variables	Default Value	Maximum Value	Minimum Value
<i>policy-name</i>	None	253	1
<i>max-length</i>	253	253	2
<i>min-length</i>	2	253	2
<i>special-char</i>	0	253	0
<i>upper-case</i>	0	253	0
<i>lower-case</i>	0	253	0
<i>numeric</i>	0	253	0
For lifetime :			
years	0	99	1
months	0	11	1
days	0	30	1
hours	0	23	1
minutes	0	59	1
seconds	0	59	1
<i>min-char-change</i>	4	253	0
<i>authen-max-attempts</i>	0	24	1
For lockout-time :			
days	0	225	1
hours	0	23	1
minutes	0	59	1
seconds	0	59	1
For warn-interval :			
years	0	99	1
months	0	11	1
days	0	30	1
hours	0	23	1
minutes	0	59	1
seconds	0	59	1

Command Variables	Default Value	Maximum Value	Minimum Value
For restrict-old-time :			
years	0	99	1
months	0	11	1
days	0	30	1
<i>max-char-repetition</i>	0	5	2
<i>restrict-old-count</i>	0	10	1

Task ID**Task ID Operation**

aaa	read, write
-----	----------------

This example shows how to define a AAA password security policy:

```
RP/0/RSP0/CPU0:router(config)#aaa password-policy test-policy
RP/0/RSP0/CPU0:router(config-aaa)#min-length 8
RP/0/RSP0/CPU0:router(config-aaa)#max-length 15
RP/0/RSP0/CPU0:router(config-aaa)#lifetime months 3
RP/0/RSP0/CPU0:router(config-aaa)#min-char-change 5
RP/0/RSP0/CPU0:router(config-aaa)#authen-max-attempts 3
RP/0/RSP0/CPU0:router(config-aaa)#lockout-time days 1
RP/0/RSP0/CPU0:router(config-aaa)#warn-interval months 2
RP/0/RSP0/CPU0:router(config-aaa)#restrict-old-time years 3
RP/0/RSP0/CPU0:router(config-aaa)#max-char-repetition 3
RP/0/RSP0/CPU0:router(config-aaa)#restrict-old-count 3
RP/0/RSP0/CPU0:router(config-aaa)#restrict-password-reverse
RP/0/RSP0/CPU0:router(config-aaa)#restrict-password-advanced
RP/0/RSP0/CPU0:router(config-aaa)#restrict-username
RP/0/RSP0/CPU0:router(config-aaa)#restrict-username-reverse
```

Related Commands

Command	Description
show aaa password-policy, on page 118	Displays the details of AAA password policy.
username, on page 178	

aaa radius attribute

To configure a format e encode string for particular interface or NAS-Port type and to create an AAA radius attribute format configuration, use the **aaa radius attribute** command in Global Configuration mode. To disable this AAA Radius attribute, use the **no** form of this command.

```
aaa radius attribute {called-station-id {format format_name | type value} | calling-station-id {format
format_name | type value} | nas-port {format e format_name | type value} | nas-port-id {format e
format_name | type value}}
```

Syntax Description		
	called-station-id	Specifies the AAA nas-port attribute.
	calling-station-id	Specifies the AAA nas-port attribute.
	nas-port	Specifies the AAA nas-port attribute.
	nas-port-id	Specifies the AAA nas-port-id attribute.
	format	Specifies the AAA nas-port attribute format.
	e	Specifies the AAA format type.
	<i>format_name</i>	Specifies a 32 character string representing the format to be used.
	type	Specifies the AAA nas-port attribute format.
	<i>value</i>	Specifies the Nas-Port-Type value to apply format string on. The nas port value ranges from 0-44.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	ip-services	read, write

This is an example of configuring the **aaa radius attribute** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)# aaa radius attribute format e red type 40
```

aaa service-accounting

To set accounting parameters for service, use the **aaa service-accounting** command in Global Configuration mode or Admin Configuration mode. To disable this behavior, use the **no** form of this command.

aaa service-accounting [{**extended** | **brief**}]

Syntax Description	
extended	Sends extended service accounting records.
brief	Sends brief service accounting records.

Command Default The default setting is **extended**.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.3.1	This command was introduced.

Usage Guidelines The **extended** keyword allows to report all the subscriber accounting identities and state attributes within all the service accounting records. While, the **brief** keyword allows to report only brief information about service accounting records without any parent accounting record details.

Task ID	Task ID	Operation
	aaa	read, write

This example shows how to set service accounting parameters to send brief information about service accounting records:

```
RP/0/RSP0/CPU0:router (config) # aaa service-accounting brief
```

aaa server radius dynamic-author

To configure radius dynamic author server, use the **aaa server radius dynamic-author** command in Global Configuration mode or Admin Configuration mode. To disable this subscriber authentication method, use the **no** form of this command.

```
aaa server radius dynamic-author {client hostname | ignore {server-key | session-key} | port
port_number | server-key {0 | 7 | line_number}}
```

Syntax Description

session-key	Specifies that the session-key could be ignored.
client	Represents the CoA client configuration.
<i>hostname</i>	Specifies the hostname (IPv4 address or domain or IPv6 address) of the CoA client. IPv6 domain name is not supported.
ignore	Specifies the ignore options.
port	Specifies the CoA server port to listen on.
server-key	Sets the shared secret to verify client CoA requests.
<i>port_number</i>	Represents the port number and the value ranges from 1000 to 5000.
0	Specifies that the unencrypted key will follow.
7	Specifies that the encrypted key will follow.
<i>line_number</i>	Represents the unencrypted (cleartext) key.

Command Default

No default behavior or values

Command Modes

Global Configuration mode.

Command History

Release	Modification
Release 4.2.0	This command was introduced.
Release 4.2.1	The support for the keywords, auth-key and ignore {session-key} were removed.
Release 5.3.1	The command was modified to add IPv6 address support for aaa server radius dynamic-author client configuration, as part of RADIUS over IPv6 feature.

Usage Guidelines

If multiple session identification keys are present in the CoA request, an AND operation is performed such that all the keys participate in the session selection. That is, if the CoA request contains the Accounting-Session-ID attribute and a Framed-IP-Address, then these parameters must match on the targeted session. For example, if the Session-ID referenced is 00001111 and the Framed-IP-Address is 10.0.0.10, and

if the BNG is having a subscriber session with ID as 00001111 but with address as 10.10.10.1, then the session is not subjected to the CoA action. A CoA NACK is returned in this case.

Task ID	Task ID	Operation
	aaa	read, write

```
RP/0/RSP0/CPU0:router(config)# aaa server radius dynamic-author ignore server-key
```

aaa radius attribute nas-port-type

To configure the AAA RADIUS attribute `nas-port-type` for a physical interface or a VLAN sub-interface, use the `aaa radius attribute nas-port-type` command in the interface configuration mode. To remove the configuration of `nas-port-type` from the interface or VLAN sub-interface, use the `no` form of this command.

```
aaa radius attribute nas-port-type {value string}
```

Syntax Description

value The nas-port-type value for the interface or VLAN sub-interface.
The range is from 0 to 44.

string The nas-port-type name for the interface or VLAN sub-interface.

Command Default

None

Command Modes

Interface or VLAN sub-interface configuration

Command History

Release	Modification
Release 4.3.1	This command was introduced.

Usage Guidelines

The permissible values for `nas-port-type` within the given range are 0 - 6, 9, 15 and 30 - 44.

Task ID

Task ID	Operation
aaa	read, write

This example shows how to configure the AAA RADIUS attribute, `nas-port-type` for each physical interface :

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface gigabitEthernet 0/0/0/0
RP/0/RSP0/CPU0:router(config-if)# aaa radius attribute nas-port-type 15
```

Related Commands

Command	Description
aaa radius attribute, on page 41	Configures a format e encode string for particular interface or NAS-Port type.

accounting (line)

To enable authentication, authorization, and accounting (AAA) accounting services for a specific line or group of lines, use the **accounting** command in line template configuration mode. To disable AAA accounting services, use the **no** form of this command.

accounting {**commands** | **exec**} {**default***list-name*}

Syntax Description

commands Enables accounting on the selected lines for all EXEC shell commands.

exec Enables accounting of EXEC session.

default The name of the default method list, created with the **aaa accounting** command.

list-name Specifies the name of a list of accounting methods to use. The list is created with the **aaa accounting** command.

Command Default

Accounting is disabled.

Command Modes

Line template configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

After you enable the **aaa accounting** command and define a named accounting method list (or use the default method list) for a particular type of accounting, you must apply the defined lists to the appropriate lines for accounting services to take place. Use the **accounting** command to apply the specified method lists to the selected line or group of lines. If a method list is not specified this way, no accounting is applied to the selected line or group of lines.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to enable command accounting services using the accounting method list named *listname2* on a line template named *configure*:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# line template configure
RP/0/RSP0/CPU0:router(config-line)# accounting commands listname2
```

Related Commands

Command	Description
aaa accounting, on page 4	Creates a method list for accounting.

accounting aaa list

To configure the subscriber accounting feature, use the **accounting aaa list** command in the dynamic template configuration mode. To disable this feature, use the **no** form of this command.

```
accounting aaa list {method_list_name | default} type session {dual-stack-delay time | periodic-interval time}
```

Syntax Description

<i>method_list_name</i>	Specifies the preconfigured method list name.
default	Specifies the default method list.
type	Specifies the type of accounting performed.
session	Applies the accounting to a session.
dual-stack-delay	Specifies the dual stack set delay wait in seconds.
<i>time</i>	Specifies the value of the dual stack delay time in seconds. The value ranges from 1-30.
periodic-interval	Specifies the periodic accounting interval in minutes.
<i>time</i>	Specifies the value of the periodic accounting interval in minutes. The value ranges from 1-65535.

Command Default

None

Command Modes

Dynamic template configuration

Command History

Release	Modification
Release 4.2.0	This command was introduced.

Usage Guidelines

Use the **dynamic-template** command to enter dynamic template configuration mode.

Task ID

Task ID	Operation
config-services	read, write

This is an example of configuring **accounting aaa list** command for periodic accounting interval of 456 minutes:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# dynamic-template
RP/0/RSP0/CPU0:router(config-dynamic-template)# type service s1
RP/0/RSP0/CPU0:router(config-dynamic-template-type)# accounting aaa list l1 type session
periodic-interval 456
```


accounting aaa list type service

To configure the service accounting feature, use the **accounting aaa list type service** command in the dynamic template configuration mode. To disable this feature, use the **no** form of this command.

```
accounting aaa list {method_list_name | default} type service [periodic-interval time]
```

Syntax Description	
<i>method_list_name</i>	Specifies the pre-configured method list name.
default	Specifies the default method list.
type	Specifies the type of accounting performed.
service	Applies the accounting to a service.
periodic-interval	Specifies the periodic accounting interval in minutes.
<i>time</i>	Value of the periodic accounting interval in minutes. The range is from 1 to 65535.

Command Default None

Command Modes Dynamic template configuration

Command History	Release	Modification
	Release 4.3.1	This command was introduced.

Usage Guidelines Use the **dynamic-template** command to enter dynamic template configuration mode.

Task ID	Task ID	Operation
	config-services	read, write

This is an example of configuring service accounting for periodic accounting interval of 600 minutes:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# dynamic-template
RP/0/RSP0/CPU0:router(config-dynamic-template)# type service s1
RP/0/RSP0/CPU0:router(config-dynamic-template-type)# accounting aaa list l1 type service
periodic-interval 600
```

accounting prepaid

To configure accounting information for subscriber prepaid feature in BNG, use the **accounting prepaid** command in subscriber configuration mode. To remove this configuration, use the **no** form of this command.

```
accounting prepaid name [{method-list authorization list-name | password password | quota-holding time quota-holding-time | quota-validity time quota-validity-time | threshold {time time-threshold | volume volume-threshold } | traffic {both | inbound | outbound}]
```

Syntax Description		
	<i>name</i>	Prepaid configuration name or default.
	method-list	Specifies method list configuration.
	authorization	Specifies authorization method list.
	<i>list-name</i>	Name of the authorization method list.
	password	Specifies the password to be used when placing prepaid authorization or re-authorization requests.
	<i>password</i>	Password string.
	quota-holding time	Specifies quota holding time.
	quota-validity time	Specifies quota validity time.
	<i>quota-holding-time</i>	Quota holding time, in seconds. The range is from 0 to 99000; the default is 100.
	<i>quota-validity-time</i>	Quota validity time, in seconds. The range is from 0 to 99000; the default is 50.
	threshold	Specifies the threshold configuration for prepaid feature.
	time	Specifies the time threshold.
	<i>time-threshold</i>	Time threshold, in seconds. The range is 0 to 4294967295; the default is 100.
	volume	Specifies the volume threshold.

<i>volume-threshold</i>	Volume threshold, in bytes. The range is 0 to 4294967295; the default is 100.
traffic	Specifies the traffic direction to be considered while deriving the volume. The default is inbound .
both	Considers both inbound and outbound traffic while deriving the volume.
inbound	Considers inbound traffic while deriving the volume.
outbound	Considers outbound traffic while deriving the volume.

Command Default None

Command Modes Subscriber configuration

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

Usage Guidelines To configure the authorization method list, the accounting network name must already be created using **aaa accounting network** command in global configuration mode.

Task ID	Task ID	Operation
	config-services	read, write

This example shows how to configure accounting information for subscriber prepaid feature in BNG:

```
RP/0/RSP0/CPU0:router(config)# subscriber
RP/0/RSP0/CPU0:router(config-subscriber)# accounting prepaid feat1
RP/0/RSP0/CPU0:router(config-prepaid)# traffic both
```

authorization (line)

To enable authentication, authorization, and accounting (AAA) authorization for a specific line or group of lines, use the **authorization** command in line template configuration mode. To disable authorization, use the **no** form of this command.

authorization {**commands** | **exec** | **eventmanager**} {**default***list-name*}

Syntax Description

commands	Enables authorization on the selected lines for all commands.
exec	Enables authorization for an interactive (EXEC) session.
default	Applies the default method list, created with the aaa authorization command.
eventmanager	Sets eventmanager authorization method. This method is used for the embedded event manager.
<i>list-name</i>	Specifies the name of a list of authorization methods to use. If no list name is specified, the system uses the default. The list is created with the aaa authorization command.

Command Default

Authorization is not enabled.

Command Modes

Line template configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

After you use the **aaa authorization** command to define a named authorization method list (or use the default method list) for a particular type of authorization, you must apply the defined lists to the appropriate lines for authorization to take place. Use the **authorization** command to apply the specified method lists (or, if none is specified, the default method list) to the selected line or group of lines.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to enable command authorization using the method list named *listname4* on a line template named *configure*:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# line template configure
RP/0/RSP0/CPU0:router(config-line)# authorization commands listname4
```

Related Commands

Command	Description
aaa authorization , on page 20	Creates a method list for authorization.

clear tacacs counters

To clear AAA counters for all the TACACS+ servers in the system, use the **clear tacacs counters** command in the EXEC mode.

clear tacacs counters

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

Usage Guidelines Use the **clear tacacs counters** command to clear all AAA counter statistics for all the TACACS+ server configured in the system.

Task ID	Task ID	Operations
	aaa	read

Examples

The following is sample output from the **clear tacacs counters** command:

```
Router:ios# show tacacs counters
TACACS+ Server: 10.105.236.101/4010 [global]

Authentication:
 10 requests, 4 accepts, 3 failure, 2 error, 1 timeout

Exec Authorization:
 0 requests, 0 accepts, 0 denied, 0 error, 0 timeout

Command Authorization:
 6 requests, 6 accepts, 0 denied, 0 error, 0 timeout

Exec Accounting:
 0 requests, 0 accepts, 0 fail, 0 error, 0 timeout

Command Accounting:
 6 requests, 6 accepts, 0 fail, 0 error, 0 timeout

TACACS+ Server: 10.105.236.101/2201 [private] vrf = default

Authentication:
 0 requests, 0 accepts, 0 failure, 0 error, 0 timeout

Exec Authorization:
 0 requests, 0 accepts, 0 denied, 0 error, 0 timeout
```

```
Command Authorization:
  0 requests, 0 accepts, 0 denied, 0 error, 0 timeout

Exec Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout

Command Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout

Router:ios# clear tacacs counters
Router:ios# show tacacs counters
TACACS+ Server: 10.105.236.101/4010 [global]

Authentication:
  0 requests, 0 accepts, 0 failure, 0 error, 0 timeout

Exec Authorization:
  0 requests, 0 accepts, 0 denied, 0 error, 0 timeout

Command Authorization:
  0 requests, 0 accepts, 0 denied, 0 error, 0 timeout

Exec Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout

Command Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout

TACACS+ Server: 10.105.236.101/2201 [private] vrf = default

Authentication:
  0 requests, 0 accepts, 0 failure, 0 error, 0 timeout

Exec Authorization:
  0 requests, 0 accepts, 0 denied, 0 error, 0 timeout

Command Authorization:
  0 requests, 0 accepts, 0 denied, 0 error, 0 timeout

Exec Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout

Command Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout
```

deadtime (server-group configuration)

To configure the deadtime value at the RADIUS server group level, use the **deadtime** command in server-group configuration mode. To set deadtime to 0, use the **no** form of this command.

deadtime *minutes*

Syntax Description	<i>minutes</i> Length of time, in minutes, for which a RADIUS server is skipped over by transaction requests, up to a maximum of 1440 (24 hours). The range is from 1 to 1440.				
Command Default	Deadtime is set to 0.				
Command Modes	Server-group configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	The value of the deadtime set in the server groups overrides the deadtime that is configured globally. If the deadtime is omitted from the server group configuration, the value is inherited from the primary list. If the server group is not configured, the default value of 0 applies to all servers in the group. If the deadtime is set to 0, no servers are marked dead.				

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example specifies a one-minute deadtime for RADIUS server group **group1** when it has failed to respond to authentication requests for the **deadtime** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server radius group1
RP/0/RSP0/CPU0:router(config-sg-radius)# server 10.1.1.1 auth-port 1645 acct-port 1646
RP/0/RSP0/CPU0:router(config-sg-radius)# server 10.2.2.2 auth-port 2000 acct-port 2001
RP/0/RSP0/CPU0:router(config-sg-radius)# deadtime 1
```

Related Commands	Command	Description
	aaa group server tacacs+ , on page 34	Groups different RADIUS server hosts into distinct lists and distinct methods.
	radius-server dead-criteria time , on page 79	Forces one or both of the criteria that is used to mark a RADIUS server as dead.

Command	Description
radius-server deadtime(BNG), on page 83	Defines the length of time in minutes for a RADIUS server to remain marked dead.

description (AAA)

To create a description of a task group or user group during configuration, use the **description** command in task group configuration or user group configuration mode. To delete a task group description or user group description, use the **no** form of this command.

description *string*

Syntax Description

string Character string describing the task group or user group.

Command Default

None

Command Modes

Task group configuration

User group configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **description** command inside the task or user group configuration submode to define a description for the task or user group, respectively.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows the creation of a task group description:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# taskgroup alpha
RP/0/RSP0/CPU0:router(config-tg)# description this is a sample taskgroup
```

The following example shows the creation of a user group description:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# usergroup alpha
RP/0/RSP0/CPU0:router(config-ug)# description this is a sample user group
```

Related Commands

Command	Description
taskgroup, on page 171	Accesses task group configuration mode and configures a task group by associating it with a set of task IDs.
usergroup, on page 176	Accesses user group configuration mode and configures a user group by associating it with a set of task groups.

group (AAA)

To add a user to a group, use the **group** command in username configuration mode. To remove the user from a group, use the **no** form of this command.

group {**root-system** | **root-lr** | **netadmin** | **sysadmin** | **operator** | **cisco-support** | **serviceadmin** *group-name*}

Syntax Description

root-system	Adds the user to the predefined root-system group and provides access to commands included in the cisco-support group. Only users with root-system authority may use this option.
root-lr	Adds the user to the predefined root-lr group. Only users with root-system authority or root-lr authority may use this option.
netadmin	Adds the user to the predefined network administrators group.
sysadmin	Adds the user to the predefined system administrators group.
operator	Adds the user to the predefined operator group.
cisco-support	Adds the user to the predefined Cisco support personnel group.
Note	Starting from IOS XR 4.3.1 release, the cisco-support group is combined with the root-system group. This means a user who is part of the root-system group can also access commands that are included in the cisco-support group.
serviceadmin	Adds the user to the predefined service administrators group.
group-name	Adds the user to a named user group that has already been defined with the usergroup command.

Command Modes

Username configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.3.0	The root-system group includes privileges for cisco-support groupd.

Usage Guidelines

The predefined group root-system may be specified only by root-system users while configuring administration.

Use the **group** command in username configuration mode. To access username configuration mode, use the [username, on page 178](#) command in global configuration mode.

If the **group** command is used in administration configuration mode, only root-system and cisco-support keywords can be specified.

The privileges associated with the cisco-support group are now included in the root-system group. The cisco-support group is no longer required to be used for configuration.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to assign the user group operator to the user named user1:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router (config)# username user1
RP/0/RSP0/CPU0:router (config-un)# group operator
```

Related Commands

Command	Description
password (AAA), on page 73	Creates a login password for a user.
usergroup, on page 176	Configures a user group and associates it with a set of task groups.
username, on page 178	Accesses username configuration mode, configures a new user with a username, and establishes a password and permissions for that user.

holddown-time (TACACS+)

To specify a duration for which an unresponsive TACACS+ server is to be marked as down, and not be used for sending further client requests for that duration, use the **holddown-time** command in various configuration modes. To disable this feature, use the **no** form of this command or configure the hold down timer value as zero.

holddown-time *time*

Syntax Description	<i>time</i> Specifies the hold-down timer value, in seconds. The range is from 0 to 1200. Zero indicates that the hold-down timer feature is disabled.
---------------------------	---

Command Default	By default, the TACACS+ hold-down timer is disabled.
------------------------	--

Command Modes	TACACS server TACACS+ server group TACACS+ private server
----------------------	---

Command History	Release	Modification
	Release 7.4.1	This command was introduced for Cisco IOS XR 64-bit platforms.
	Release 6.8.1	This command was introduced for Cisco IOS XR 32-bit platforms.

Usage Guidelines



Note	To set the hold-down timer at global level, use the tacacs-server holddown-time command in Global Configuration mode.
-------------	--

While selecting the timer at various configuration levels, the system gives preference to the one which is more specific to the server. That is, the server-level timer has the highest precedence, followed by server group-level and finally, the global-level.

Also, see the *Guidelines for Configuring Hold-Down Timer for TACACS+* section in the *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

Task ID	Task ID	Operations
	aaa	read, write

Examples

This example shows how to mark an unresponsive TACACS+ server as being down, and not to use it for sending further client requests for a duration of 35 seconds:

```
Router(config)#tacacs-server host 10.105.236.102 port 2020
Router(config-tacacs-host)#holddown-time 35
```

This example shows how to set a hold-down timer at global level:

```
Router#configure
Router(config)#tacacs-server holddown-time 30
```

This example shows how to set a hold-down timer at server-group level:

```
Router#configure
Router(config)#aaa group server tacacs+ test-group
Router(config-sg-tacacs)#holddown-time 40
```

This example shows how to set a hold-down timer at private server level:

```
Router(config)#aaa group server tacacs+ test-group
Router(config-sg-tacacs)#server-private 10.105.236.109 port 2020
Router(config-sg-tacacs-private)#holddown-time 55
Router(config-sg-tacacs-private)#commit
```

Related Commands

Command	Description
aaa group server tacacs+, on page 34	Groups different TACACS+ server hosts into distinct lists.
server-private (TACACS+), on page 110	Configures the IP address of the private TACACS+ server for the group server.
tacacs-server host, on page 158	Configures a TACACS+ host server.

inherit taskgroup

To enable a task group to derive permissions from another task group, use the **inherit taskgroup** command in task group configuration mode.

```
inherit taskgroup {taskgroup-name | netadmin | operator | sysadmin | cisco-support | root-lr | root-system | serviceadmin}
```

Syntax Description

<i>taskgroup-name</i>	Name of the task group from which permissions are inherited.
netadmin	Inherits permissions from the network administrator task group.
operator	Inherits permissions from the operator task group.
sysadmin	Inherits permissions from the system administrator task group.
cisco-support	Inherits permissions from the cisco support task group.
root-lr	Inherits permissions from the root-lr task group.
root-system	Inherits permissions from the root system task group.
serviceadmin	Inherits permissions from the service administrators task group.

Command Default

None

Command Modes

Task group configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **inherit taskgroup** command to inherit the permissions (task IDs) from one task group into another task group. Any changes made to the taskgroup from which they are inherited are reflected immediately in the group from which they are inherited.

Task ID

Task ID	Operations
aaa	read, write

Examples

In the following example, the permissions of task group tg2 are inherited by task group tg1:

```
RP/0/RSP0/CPU0:router# configure
```

```
RP/0/RSP0/CPU0:router(config)# taskgroup tg1
RP/0/RSP0/CPU0:router(config-tg)# inherit taskgroup tg2
RP/0/RSP0/CPU0:router(config-tg)# end
```


inherit usergroup

To enable a user group to derive characteristics of another user group, use the **inherit usergroup** command in user group configuration mode.

inherit usergroup *usergroup-name*

Syntax Description	<i>usergroup-name</i> Name of the user group from which permissions are to be inherited.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	User group configuration
----------------------	--------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines Each user group is associated with a set of task groups applicable to the users in that group. A task group is defined by a collection of task IDs. Task groups contain task ID lists for each class of action. The task permissions for a user are derived (at the start of the EXEC or XML session) from the task groups associated with the user groups to which that user belongs.

User groups support inheritance from other user groups. Use the **inherit usergroup** command to copy permissions (task ID attributes) from one user group to another user group. The “destination” user group inherits the properties of the inherited group and forms a union of all task IDs specified in those groups. For example, when user group A inherits user group B, the task map of the user group A is a union of that of A and B. Cyclic inclusions are detected and rejected. User groups cannot inherit properties from predefined groups, such as root-system users, root-sdr users, netadmin users, and so on. Any changes made to the usergroup from which it is inherited are reflected immediately in the group from which it is inherited.

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to enable the purchasing user group to inherit properties from the sales user group:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# usergroup purchasing
RP/0/RSP0/CPU0:router(config-ug)# inherit usergroup sales
```

Related Commands	Command	Description
	description (AAA), on page 58	Creates a description of a task group in task group configuration mode, or creates a description of a user group in user group configuration mode.

Command	Description
taskgroup, on page 171	Configures a task group to be associated with a set of task IDs.
usergroup, on page 176	Configures a user group to be associated with a set of task groups.

key (RADIUS)

To specify the authentication and encryption key that is used between the router and the RADIUS daemon running on the RADIUS server, use the **key (RADIUS)** command in RADIUS server-group private configuration mode.

key {**0** *clear-text-key* | **7** *encrypted-key**clear-text-key*}

Syntax Description

0 *clear-text-key* Specifies an unencrypted (cleartext) shared key.

7 *encrypted-key* Specifies an encrypted shared key.

clear-text-key Specifies an unencrypted (cleartext) user password.

Command Default

For submode **key** commands, the default is to use the **radius-server key** command in global configuration mode, if defined. If the global key is also not defined, the configuration is not complete.

Command Modes

RADIUS server-group private configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to set the encrypted key to anykey:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server radius group1
RP/0/RSP0/CPU0:router(config-sg-radius)# server-private 10.1.1.1 auth-port 300
RP/0/RSP0/CPU0:router(config-sg-radius-private)# key anykey
```

Related Commands

Command	Description
aaa group server tacacs+, on page 34	Groups different RADIUS server hosts into distinct lists.
radius-server key(BNG), on page 88	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.

Command	Description
retransmit (RADIUS), on page 100	Specifies the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly.
server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.
timeout (RADIUS), on page 173	Specifies the number of seconds the router waits for the RADIUS server to reply before retransmitting.

key (TACACS+)

To specify an authentication and encryption key shared between the AAA server and the TACACS+ server, use the **key (TACACS+)** command in TACACS host configuration mode. To disable this feature, use the **no** form of this command.

key {**0** *clear-text-key* | **7** *encrypted-keyauth-key*}

Syntax Description	
0 <i>clear-text-key</i>	Specifies an unencrypted (cleartext) shared key.
7 <i>encrypted-key</i>	Specifies an encrypted shared key.
<i>auth-key</i>	Specifies the unencrypted key between the AAA server and the TACACS+ server.

Command Default None

Command Modes TACACS host configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines The TACACS+ packets are encrypted using the key, and it must match the key used by the TACACS+ daemon. Specifying this key overrides the key set by the **tacacs-server key** command for this server only.

The key is used to encrypt the packets that are going from TACACS+, and it should match with the key configured on the external TACACS+ server so that the packets are decrypted properly. If a mismatch occurs, the result fails.

Task ID	Task	Operations
	aaa	read, write

Examples

The following example shows how to set the encrypted key to anykey

```
RP/0/RSP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RSP0/CPU0:router(config-tacacs-host)# key anykey
```

Related Commands	Command	Description
	tacacs-server host, on page 158	Specifies a TACACS+ host.
	tacacs-server key, on page 161	Globally sets the authentication encryption key used for all TACACS+ communications between the router and the TACACS+ daemon.

login authentication

To enable authentication, authorization, and accounting (AAA) authentication for logins, use the **login authentication** command in line template configuration mode. To return to the default authentication settings, use the **no** form of this command.

login authentication {*default**list-name*}

Syntax Description

default Default list of AAA authentication methods, as set by the **aaa authentication login** command.

list-name Name of the method list used for authenticating. You specify this list with the **aaa authentication login** command.

Command Default

This command uses the default set with the **aaa authentication login** command.

Command Modes

Line template configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

The **login authentication** command is a per-line command used with AAA that specifies the name of a list of AAA authentication methods to try at login.



Caution If you use a *list-name* value that was not configured with the **aaa authentication login** command, the configuration is rejected.

Entering the **no** form of the **login authentication** command has the same effect as entering the command with the **default** keyword.

Before issuing this command, create a list of authentication processes by using the **aaa authentication login** command.

Task ID

Task ID	Operations
aaa	read, write
tty-access	read, write

Examples

The following example shows that the default AAA authentication is used for the line template *template1*:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# line template template1
RP/0/RSP0/CPU0:router(config-line)# login authentication default
```

The following example shows that the AAA authentication list called *list1* is used for the line template *template2*:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# line template template2
RP/0/RSP0/CPU0:router(config-line)# login authentication list1
```

Related Commands

Command	Description
aaa authentication , on page 15	Creates a method list for authentication.

nacm enable-external-policies

To enable dynamic NETCONF Access Control Model (NACM) policy authorization on a router, use the **nacm enable-external-policies** command in the Global Configuration mode. To remove the configuration, use the **no** form of this command.

nacm enable-external-policies

Syntax Description This command has no keywords or arguments.

Command Default Disabled, by default.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Usage Guidelines If this configuration is not present, update the NACM policies manually on each router.

Task ID	Task	Operation
	nacm	read, write

This example shows how to enable the dynamic NACM on a router.

```
Router#configure
Router(config)# nacm enable-external-policies
Router(config)# commit
```


password (AAA)

To create a login password for a user, use the **password** command in username configuration mode or line template configuration mode. To remove the password, use the **no** form of this command.

```
password {[0] | 7 password}
```

Syntax Description	0	(Optional) Specifies that an unencrypted clear-text password follows.
	7	Specifies that an encrypted password follows.
	<i>password</i>	Specifies the unencrypted password text to be entered by the user to log in, for example, "lab". If encryption is configured, the password is not visible to the user. Can be up to 253 characters in length.

Command Default The password is in unencrypted clear text.

Command Modes Username configuration
Line template configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines You can specify one of two types of passwords: encrypted or clear text.

When an EXEC process is started on a line that has password protection, the process prompts for the password. If the user enters the correct password, the process issues the prompt. The user can try three times to enter a password before the process exits and returns the terminal to the idle state.

Passwords are two-way encrypted and should be used for applications such as PPP that need decryptable passwords that can be decrypted.



Note The **show running-config** command always displays the clear-text login password in encrypted form when the **0** option is used.

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to establish the unencrypted password *pwd1* for user. The output from the **show** command displays the password in its encrypted form.

```

RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# username user1
RP/0/RSP0/CPU0:router(config-un)# password 0 pwd1
RP/0/RSP0/CPU0:router(config-un)# commit
RP/0/RSP0/CPU0:router(config-un)# show running-config
Building configuration...
username user1
password 7 141B1309

```

Related Commands

Command	Description
group (AAA), on page 59	Adds a user to a group.
usergroup, on page 176	Accesses user group configuration mode and configures a user group, associating it with a set of task groups.
username, on page 178	Accesses username configuration mode and configures a new user with a username, establishing a password and granting permissions for that user.
line	Enters line template configuration mode for the specified line template. For more information, see the Cisco IOS XR <i>System Management Command Reference</i> .

aaa display-login-failed-users

aaa display-login-failed-users

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	Disabled, by default
------------------------	----------------------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 7.10.1	The command was introduced to make the display-login-failed-users option available to display user ID for failed user login attempts.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	aaa	read, write

This example shows how to enable the functionality to display the username for a failed authentication:

```
Router#Configure
Router(config)# aaa display-login-failed-users
Router(config)#commit
```

radius-server attribute

To customize the selected radius attributes, use the **radius-server attribute** command in the Global Configuration mode. To disable the Radius server attribute, use the **no** form of this command.

radius-server attribute list *list_name* [**attribute** {*list* | **vendor-id** *value*}]

Syntax Description	list	Specifies a list of attributes that are used in conjunction with server-groups to accept or reject a list of attributes.
	<i>list_name</i>	Specifies the list name.
	attribute	Specifies a list of Radius attributes.
	<i>list</i>	Specifies the list of comma-delimited Radius attributes.
	vendor-id	Specifies the vendor-id of the RADIUS attribute.
	<i>value</i>	Specifies the vendor-id value. The value ranges from 0 to 429496729.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read, write

Examples

This is an example of configuring the **radius-server attribute** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)# radius-server attribute list list1
RP/0/RSP0/CPU0:router(config-attribute-filter)# attribute list_1
RP/0/RSP0/CPU0:router(config-attribute-filter)# radius-server attribute vendor-id 429
```

radius-server attribute 11 default direction inbound

To change the direction in which the Remote Authentication Dial In User Service (RADIUS) filter-ID attribute is applied, use the **radius-server attribute 11 default direction inbound** command in Global Configuration mode.

radius-server attribute 11 default direction inbound

Syntax Description	This command has no keywords or arguments.	
Command Default	RADIUS filter-ID attribute is applied by default in the output direction of the corresponding subscriber interface.	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 5.3.2	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	ethernet-services	read, write

Example

This example shows how to change the direction of the RADIUS filter-ID attribute:

```
RP/0/RSP0/CPU0:router # configure
RP/0/RSP0/CPU0:router(config)# radius-server attribute 11 default direction inbound
```

radius-server dead-criteria

To configure the dead server detection criteria for a configured RADIUS server, use the **radius-server dead-criteria** command in the Global Configuration mode. To disable the Radius server dead-criteria, use the **no** form of this command.

radius-server dead-criteria {**time** *value* | **tries** *number_of_tries*}

Syntax Description	time	tries
	Specifies the minimum time that must elapse since a response was received from this RADIUS server.	Specifies the minimum number of transmissions (original attempts plus retransmits) to this RADIUS server.
	<i>value</i>	<i>number_of_tries</i>
	Specifies the time in seconds. The value ranges from 1 to 120.	Specifies the number of tries. The range is from 1 to 100.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read, write

Examples

This is an example of configuring the **radius-server dead-criteria** command with 100s time and 34 tries:

```
RP/0/RSP0/CPU0:router(config)#radius-server dead-criteria time 100
RP/0/RSP0/CPU0:router(config)#radius-server dead-criteria tries 34
```

radius-server dead-criteria time

To specify the minimum amount of time, in seconds, that must elapse from the time that the router last received a valid packet from the RADIUS server to the time the server is marked as dead, use the **radius-server dead-criteria time** command in Global Configuration mode. To disable the criteria that were set, use the **no** form of this command.

radius-server dead-criteria time *seconds*

Syntax Description	<i>seconds</i> Length of time, in seconds. The range is from 1 to 120 seconds. If the <i>seconds</i> argument is not configured, the number of seconds ranges from 10 to 60, depending on the transaction rate of the server.				
	Note The time criterion must be met for the server to be marked as dead.				
Command Default	If this command is not used, the number of seconds ranges from 10 to 60 seconds, depending on the transaction rate of the server.				
Command Modes	Global Configuration mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				

Usage Guidelines



Note If you configure the **radius-server dead-criteria time** command before the **radius-server deadtime** command, the **radius-server dead-criteria time** command may not be enforced.

If a packet has not been received since the router booted and there is a timeout, the time criterion is treated as though it were met.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to establish the time for the dead-criteria conditions for a RADIUS server to be marked as dead for the **radius-server dead-criteria time** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# radius-server dead-criteria time 5
```

Related Commands

Command	Description
radius-server dead-criteria tries, on page 81	Specifies the number of consecutive timeouts that must occur on the router before the RADIUS server is marked as dead.
radius-server deadtime(BNG), on page 83	Defines the length of time, in minutes, for a RADIUS server to remain marked dead.
show radius dead-criteria, on page 133	Displays information for the dead-server detection criteria.

radius-server dead-criteria tries

To specify the number of consecutive timeouts that must occur on the router before the RADIUS server is marked as dead, use the **radius-server dead-criteria tries** command in Global Configuration mode. To disable the criteria that were set, use the **no** form of this command.

radius-server dead-criteria tries

Syntax Description

tries Number of timeouts from 1 to 100. If the *tries* argument is not configured, the number of consecutive timeouts ranges from 10 to 100, depending on the transaction rate of the server and the number of configured retransmissions.

Note The tries criterion must be met for the server to be marked as dead.

Command Default

If this command is not used, the number of consecutive timeouts ranges from 10 to 100, depending on the transaction rate of the server and the number of configured retransmissions.

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

If the server performs both authentication and accounting, both types of packet are included in the number. Improperly constructed packets are counted as though they were timeouts. All transmissions, including the initial transmit and all retransmits, are counted.



Note If you configure the **radius-server dead-criteria tries** command before the **radius-server deadtime** command, the **radius-server dead-criteria tries** command may not be enforced.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to establish the number of tries for the dead-criteria conditions for a RADIUS server to be marked as dead for the **radius-server dead-criteria tries** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# radius-server dead-criteria tries 4
```

Related Commands

Command	Description
radius-server dead-criteria time, on page 79	Defines the length of time in seconds that must elapse from the time that the router last received a valid packet from the RADIUS server to the time the server is marked as dead.
radius-server deadtime(BNG), on page 83	Defines the length of time, in minutes, for a RADIUS server to remain marked dead.
show radius dead-criteria, on page 133	Displays information for the dead-server detection criteria.

radius-server deadline(BNG)

To improve RADIUS response times when some servers are unavailable and cause the unavailable servers to be skipped immediately, use the **radius-server deadline** command in Global Configuration mode. To set deadline to 0, use the **no** form of this command.

radius-server deadline *minutes*

Syntax Description	<i>minutes</i> Length of time, in minutes, for which a RADIUS server is skipped over by transaction requests, up to a maximum of 1440 (24 hours). The range is from 1 to 1440. The default value is 0.
---------------------------	--

Command Default	Dead time is set to 0.
------------------------	------------------------

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	A RADIUS server marked as dead is skipped by additional requests for the duration of minutes unless all other servers are marked dead and there is no rollover method.
-------------------------	--

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example specifies five minutes of deadline for RADIUS servers that fail to respond to authentication requests for the **radius-server deadline** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# radius-server deadline 5
```

radius-server disallow null-username

To drop radius access-requests that has blank or no username, use the **radius-server disallow null-username** command in the Global Configuration mode. To disable the Radius server disallow null-username, use the **no** form of this command.

radius-server disallow null-username

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read, write

Examples This is an example of configuring the **radius-server disallow null-username** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router (config)#radius-server disallow null-username
```

radius-server ipv4 dscp

To mark the dscp bit for the ipv4 packets, use the **radius-server ipv4 dscp** command in the Global Configuration mode. To disable the Radius server IPv4 dscp, use the **no** form of this command.

radius-server ipv4 dscp *value*

Syntax Description	<i>value</i> Specifies the differentiated services codepoint value. The value ranges from 1 to 63.				
Command Default	None				
Command Modes	Global Configuration mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>aaa</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	aaa	read, write
Task ID	Operations				
aaa	read, write				
Examples	<p>This is an example of configuring the radius-server ipv4 dscp command in the Global Configuration mode:</p> <pre>RP/0/RSP0/CPU0:router(config)#radius-server ipv4 dscp 34</pre>				

radius-server host (BNG)

To specify a RADIUS server host, use the **radius-server host** command in Global Configuration mode. To delete the specified RADIUS host, use the **no** form of this command.

radius-server host *ip-address* [**auth-port** *port-number*] [**acct-port** *port-number*] [**timeout** *seconds*] [**retransmit** *retries*] [**key** *string*]

Syntax Description

<i>ip-address</i>	IP address of the RADIUS server host.
auth-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) destination port for authentication requests; the host is not used for authentication if set to 0. If unspecified, the port number defaults to 1645.
acct-port <i>port-number</i>	(Optional) Specifies the UDP destination port for accounting requests; the host is not used for accounting if set to 0. If unspecified, the port number defaults to 1646.
timeout <i>seconds</i>	(Optional) The time interval (in seconds) that the router waits for the RADIUS server to reply before retransmitting. This setting overrides the global value of the radius-server timeout command. If no timeout value is specified, the global value is used. Enter a value in the range from 1 to 1000. Default is 5.
retransmit <i>retries</i>	(Optional) The number of times a RADIUS request is re-sent to a server, if that server is not responding or is responding slowly. This setting overrides the global setting of the radius-server retransmit command. If no retransmit value is specified, the global value is used. Enter a value in the range from 1 to 100. Default is 3.
key <i>string</i>	(Optional) Specifies the authentication and encryption key used between the router and the RADIUS server. This key overrides the global setting of the radius-server key command. If no key string is specified, the global value is used. The key is a text string that must match the encryption key used on the RADIUS server. Always configure the key as the last item in the radius-server host command syntax. This is because the leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in the key, do not enclose the key in quotation marks unless the quotation marks themselves are part of the key.

Command Default

No RADIUS host is specified; use global **radius-server** command values.

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 4.2.0	This command was supported on BNG.
Release 5.3.1	The command was modified to add IPv6 address support for the RADIUS server host configuration.

Usage Guidelines

You can use multiple **radius-server host** commands to specify multiple hosts. The Cisco IOS XR software searches for hosts in the order in which you specify them.

If no host-specific timeout, retransmit, or key values are specified, the global values apply to each host.

Task ID

Task ID	Operations
aaa	read, write

Examples

This example shows how to establish the host with IP address 172.29.39.46 as the RADIUS server, use ports 1612 and 1616 as the authorization and accounting ports, set the timeout value to 6, set the retransmit value to 5, and set “rad123” as the encryption key, matching the key on the RADIUS server:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# radius-server host 172.29.39.46 auth-port 1612 acct-port
1616 timeout 6 retransmit 5 key rad123
```

To use separate servers for accounting and authentication, use the zero port value as appropriate.

Related Commands

Command	Description
aaa accounting subscriber	Creates a method list for accounting.
aaa authentication subscriber	Creates a method list for authentication.
aaa authorization subscriber	Creates a method list for authorization.
radius-server key(BNG), on page 88	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.
radius-server retransmit(BNG), on page 91	Specifies how many times Cisco IOS XR software retransmits packets to a server before giving up.
radius-server timeout(BNG), on page 93	Sets the interval a router waits for a server host to reply.

radius-server key(BNG)

To set the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon, use the **radius-server key** command in Global Configuration mode. To disable the key, use the **no** form of this command.

```
radius-server key {0 clear-text-key | 7 encrypted-keyclear-text-key}
```

Syntax Description	0	Specifies an unencrypted (cleartext) shared key. <i>clear-text-key</i>
	7	Specifies a encrypted shared key. <i>encrypted-key</i>
	<i>clear-text-key</i>	Specifies an unencrypted (cleartext) shared key.
Command Default	The authentication and encryption key is disabled.	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Usage Guidelines	The key entered must match the key used on the RADIUS server. All leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks themselves are part of the key.	
Task ID	Task ID	Operations
	aaa	read, write
Examples	<p>The following example shows how to set the cleartext key to “samplekey”:</p> <pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# radius-server key 0 samplekey</pre> <p>The following example shows how to set the encrypted shared key to “anykey”:</p> <pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# radius-server key 7 anykey</pre>	

Related Commands

Command	Description
key (RADIUS)	Specifies the authentication and encryption key that is used between the router and the RADIUS daemon running on the RADIUS server.
server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.

radius-server load-balance

To configure the RADIUS load-balancing options, use the **radius-server load-balance** command in the Global Configuration mode. To disable the Radius server load-balance, use the **no** form of this command.

radius-server load-balance method least-outstanding [{**batch-size** *value* | **ignore-preferred-server**}]

Syntax Description	Parameter	Description
	method	Specifies the method by which the next host will be picked.
	least-outstanding	Picks the server with the least transactions outstanding.
	batch-size	Specifies the batch size for the selection of the server.
	<i>value</i>	Specifies the batch size value. The value ranges from 1 to 1500. The default is 25.
	ignore-preferred-server	Disables the preferred server for this server group.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read, write

Examples

This is an example of configuring the **radius-server load-balance** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)#radius-server load-balance method lead-outstanding batch-size
25
RP/0/RSP0/CPU0:router(config)#radius-server load-balance method lead-outstanding batch-size
ignore-preferred-server
```

radius-server retransmit(BNG)

To specify the number of times the Cisco IOS XR software retransmits a packet to a server before giving up, use the **radius-server retransmit** command in Global Configuration mode. To disable retransmission, use the **no** form of this command.

radius-server retransmit *retries*

Syntax Description	<i>retries</i> Maximum number of retransmission attempts. The range is from 1 to 100. Default is 3.
---------------------------	---

Command Default	The RADIUS servers are retried three times, or until a response is received.
------------------------	--

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	The RADIUS client tries all servers, allowing each one to time out before increasing the retransmit count.
-------------------------	--

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to specify a retransmit counter value of five times:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# radius-server retransmit 5
```

Related Commands	Command	Description
	radius-server key(BNG), on page 88	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.
	retransmit (RADIUS)	Specifies the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly.
	server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.

radius-server source-port

To configure the NAS to use a total of 50 ports as the source ports for sending out RADIUS requests, use the **radius-server source-port** command in the Global Configuration mode. To disable the Radius server source-port, use the **no** form of this command.

radius-server source-port extended

Syntax Description	extended Specifies that the source-port can be extended to 50.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines	Having 200 source ports allows up to 256*200 authentication and accounting requests to be outstanding at one time. During peak call volume, typically when a router first boots or when an interface flaps, the extra source ports allow sessions to recover more quickly on large-scale aggregation platforms.
-------------------------	---

Task ID	Task ID	Operations
	aaa	read, write

Examples	This is an example of configuring the radius-server source-port command in the Global Configuration mode:
-----------------	--

```
RP/0/RSP0/CPU0:router(config)#radius-server source-port extended
```

radius-server timeout(BNG)

To set the interval for which a router waits for a server host to reply before timing out, use the **radius-server timeout** command in Global Configuration mode. To restore the default, use the **no** form of this command.

radius-server timeout *seconds*

Syntax Description	<i>seconds</i> Number that specifies the timeout interval, in seconds. Range is from 1 to 1000.				
Command Default	5 seconds				
Command Modes	Global Configuration mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	Use the radius-server timeout command to set the number of seconds a router waits for a server host to reply before timing out.				

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to change the interval timer to 10 seconds:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# radius-server timeout 10
```

Related Commands	Command	Description
	radius-server key(BNG), on page 88	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.
	server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.
	timeout (RADIUS)	Specifies the number of seconds the router waits for the RADIUS server to reply before retransmitting.

radius-server throttle

To configure RADIUS throttling options for access and accounting to flow control the number of access and accounting requests sent to a RADIUS server, use the **radius-server throttle** command in the Global Configuration mode. To disable the radius server throttle, use the **no** form of this command.

radius-server throttle {*access value* {*access-timeout time* | *accounting value*} | *accounting acc_value*}

Syntax Description

access	Controls the number of access requests sent to a radius server.
<i>value</i>	Specifies the number of outstanding access requests after which throttling should be performed. The value ranges from 0 to 65535 and the preferred value 100.
access-timeout	Specifies the number of timeouts exceeding which a throttled access request is dropped.
<i>time</i>	Specifies the number of timeouts for a transaction. The default value is 3.
accounting	Controls the number of accounting requests sent to a radius server.
<i>acc_value</i>	Specifies the number of outstanding accounting transactions after which throttling should be performed. The value ranges from 0 to 65535 and the preferred value 100.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 4.2.1	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operation
aaa	read, write

This is an example of configuring the **radius-server throttle** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)# radius-server throttle access 10 access-timeout 5 accounting 10
```

radius-server vsa attribute ignore unknown

To specify the unknown vsa ignore configuration for RADIUS server, use the **radius-server vsa attribute ignore unknown** command in the Global Configuration mode. To disable this feature, use the **no** form of this command.

radius-server vsa attribute ignore unknown

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read, write

Examples This is an example of configuring the **radius-server vsa attribute ignore unknown** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router(config)#radius-server vsa attribute ignore unknown
```

radius source-interface(BNG)

To force RADIUS to use the IP address of a specified interface or subinterface for all outgoing RADIUS packets, use the **radius source-interface** command in Global Configuration mode. To prevent only the specified interface from being the default and not from being used for all outgoing RADIUS packets, use the **no** form of this command.

radius source-interface *interface-name* [**vrf** *vrf-id*]

Syntax Description	
<i>interface-name</i>	Name of the interface that RADIUS uses for all of its outgoing packets.
vrf <i>vrf-id</i>	Specifies the name of the assigned VRF.

Command Default If a specific source interface is not configured, or the interface is down or does not have an IP address configured, the system selects an IP address.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines Use the **radius source-interface** command to set the IP address of the specified interface or subinterface for all outgoing RADIUS packets. This address is used as long as the interface or subinterface is in the up state. In this way, the RADIUS server can use one IP address entry for every network access client instead of maintaining a list of IP addresses.

The specified interface or subinterface must have an IP address associated with it. If the specified interface or subinterface does not have an IP address or is in the down state, then RADIUS reverts to the default. To avoid this, add an IP address to the interface or subinterface or bring the interface to the up state.

The **radius source-interface** command is especially useful in cases in which the router has many interfaces or subinterfaces and you want to ensure that all RADIUS packets from a particular router have the same IP address.

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to make RADIUS use the IP address of subinterface s2 for all outgoing RADIUS packets:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# radius source-interface Loopback 10 vrf vrf-1
```


Related Commands

Command	Description
aaa group server tacacs+ , on page 34	Groups different RADIUS server hosts into distinct lists.
radius-server key(BNG) , on page 88	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.

restrict-consecutive-characters

To restrict consecutive characters (that includes regular English alphabets, and English alphabets from QWERTY keyboard layout and numbers), for user passwords and secrets, use the **restrict-consecutive-characters** command in *aaa password-policy* configuration mode. To disable the feature, use the **no** form of the command.

restrict-consecutive-characters { **english-alphabet** | **qwerty-keyboard** } *num-of-chars* [**cyclic-wrap**]

Syntax Description

english-alphabet	Restricts consecutive English alphabets for user passwords and secrets. For example, "abcd", "wxyz", and so on.
qwerty-keyboard	Restricts consecutive English alphabets from QWERTY keyboard layout and numbers, for user passwords and secrets. For example, "qwer", "mnbv", "7890", and so on.
<i>num-of-chars</i>	Specifies the number of consecutive characters to be restricted for user passwords and secrets. Range is 2 to 26, for english-alphabet . Range is 2 to 10, for qwerty-keyboard .
cyclic-wrap	Restricts cyclic wrapping of the alphabet or the number for user passwords and secrets. For example, "yzab", "opqw", "9012", and so on.

Command Default

Disabled, by default.

Command Modes

aaa password-policy configuration mode

Command History

Release	Modification
Release 7.7.1	This command was introduced.

Usage Guidelines

All password policies are applicable only to locally configured users.

After creating the password policy, you must explicitly apply that policy to the user profiles to have an effect of that policy in the password and secret configuration.

For more details about the feature and configuration task, see the section *Enhanced Security for User Passwords and Secrets in Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

Task ID

Task ID	Operation
aaa	read, write

This example shows how to configure a AAA password policy that restricts cyclic wrapping of 4 consecutive English alphabets and 6 consecutive characters from QWERTY keyboard.

```
Router(config)#aaa password-policy test-policy
Router(config-pp)#restrict-consecutive-characters english-alphabet 4 cyclic-wrap
Router(config-pp)#restrict-consecutive-characters qwerty-keyboard 6
```

This example shows how to apply the password policy to the user profile, *user1*:

```
Router(config)#username user1
Router(config-un)#policy test-policy
Router(config-un)#commit
```

Related Commands

Command	Description
aaa password-policy, on page 37	Defines the FIPS-compliant AAA password security policy.

retransmit (RADIUS)

To specify the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly, use the **retransmit** command in RADIUS server-group private configuration mode.

retransmit *retries*

Syntax Description	<i>retries</i> The <i>retries</i> argument specifies the retransmit value. The range is from 1 to 100. If no retransmit value is specified, the global value is used.
---------------------------	---

Command Default	The default value is 3.
------------------------	-------------------------

Command Modes	RADIUS server-group private configuration
----------------------	---

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to set the retransmit value:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server radius group1
RP/0/RSP0/CPU0:router(config-sg-radius)# server-private 10.1.1.1 auth-port 300
RP/0/RSP0/CPU0:router(config-sg-radius-private)# retransmit 100
```

Related Commands	Command	Description
	aaa group server tacacs+, on page 34	Groups different RADIUS server hosts into distinct lists.
	server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.
	timeout (RADIUS), on page 173	Specifies the number of seconds the router waits for the RADIUS server to reply before retransmitting.

secret

To configure an encrypted or clear-text password for the user, use the **secret** command in username configuration mode or line template configuration mode. To remove this configuration, use the **no** form of this command.

```
secret [{0 [enc-type enc-type-value] | 5 | 8 | 9 | 10}] secret-login
```

Syntax Description

0	(Optional) Specifies that an unencrypted (clear-text) password follows.
5	Specifies that an MD5-encrypted password (secret) follows.
8	(Optional) Specifies that SHA256-encrypted password follows.
9	(Optional) Specifies that scrypt-encrypted password follows.
10	(Optional) Specifies that SHA512-encrypted password follows.
<i>secret-login</i>	Configures the specified secret for the user. Can be clear text (for Type 0 secret) or text string in alphanumeric characters that is stored as encrypted password entered by the user in association with the user's login ID. Can be up to 253 characters in length. Note The characters entered must conform to the respective encryption standards.
enc-type	(Optional) Configures the encryption type for a password entered in clear text.
<i>enc-type-value</i>	Specifies the encryption type to be used. Prior to Release 6.3.1, the only supported value was 5. (See Release History and Usage Guidelines sections for the currently supported values).

Command Default

No password is specified.

Command Modes

Username configuration
Line template configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 6.3.1	Added the support for Type 8 (SHA256) and Type 9 (scrypt) encryption for secret configuration on classic Cisco IOS XR (32-bit) operating system. Added the support for enc-type option under secret 0 to specify the type of encryption for password entered in clear-text format.

Release	Modification
Release 7.0.1	Extended the support for Type 8 (SHA256) and Type 9 (scrypt) encryption for secret configuration on Cisco IOS XR 64-bit operating system as well. Added support for Type 10 (SHA512) encryption for secret configuration on Cisco IOS XR 64-bit operating system only.

Usage Guidelines

From Release 7.0.1 and later, Type 10 encryption is applied as the default encryption type for the **secret** on Cisco IOS XR 64-bit operating systems. Prior to this, Type 5 (MD5) was the default one.

Prior to Release 7.0.1, Cisco IOS XR software allows you to configure only Message Digest 5 (MD5) encryption for username logins and passwords. MD5 encryption is a one-way hash function that makes reversal of an encrypted password impossible, providing strong encryption protection. Using MD5 encryption, you cannot retrieve clear-text passwords. Therefore, MD5 encrypted passwords cannot be used with protocols that require the clear-text password to be retrievable, such as Challenge Handshake Authentication Protocol (CHAP).

When an EXEC process is started on a line that has password protection, the process prompts for the secret. If the user enters the correct secret, the process issues the prompt. The user can try entering the secret thrice before the terminal returns to the idle state.

Secrets are one-way encrypted and should be used for login activities that do not require a decryptable secret.

To verify that respective password encryption has been enabled, use the **show running-config** command. For example, if the command output shows “username name secret 5”, it means that enhanced password security with MD5 encryption is enabled.



Note The **show running-config** command does not display the login password in clear text when the **0** option is used to specify an unencrypted password. See the “Examples” section.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to establish the clear-text secret “lab” for the user *user2*:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# username user2
RP/0/RSP0/CPU0:router(config-un)# secret 0 lab
RP/0/RSP0/CPU0:router(config-un)# commit
RP/0/RSP0/CPU0:router(config-un)# show running-config
Building configuration...
username user2
  secret 5 $1$DTmd$q7C6fhzje7Cc7Xzmu2FrX1
!
end
```

The following examples show how to configure a Type 10 (SHA512) password for the user, *user10*. You can also see the examples and usage of the [username, on page 178](#) command.

You can specify Type as '10' under the **secret** keyword, to explicitly configure Type 10 password.

```
Router#configure
Router(config)#username user10 secret 10
$6$9UvJidvsTEgkAPU$3CL1Ei/F.E4v/Hi.UaqlwX8UsSEr9ApG6c5pzhMjMzTgW4jObAQ7meAwyhu5VM/aRFJqe/jxZG17h6xPrvJWF1
Router(config-un)#commit
```

You can also use the **enc-type** keyword under the **secret 0** option, to specify Type 10 as the encryption for a password entered in clear text.

```
Router#configure
Router(config)#username user10 secret 0 enc-type 10 testpassword
Router(config-un)#commit
```

Related Commands

Command	Description
group (AAA), on page 59	Adds a user to a group.
password (AAA), on page 73	Creates a login password for a user.
usergroup, on page 176	Accesses user group configuration mode and configures a user group, associating it with a set of task groups.
username, on page 178	Accesses username configuration mode and configures a new user with a username, establishing a password and granting permissions for that user.

server (RADIUS)

To associate a particular RADIUS server with a defined server group, use the **server** command in RADIUS server-group configuration mode. To remove the associated server from the server group, use the **no** form of this command.

```
server ip-address [auth-port port-number] [acct-port port-number]
```

Syntax Description

<i>ip-address</i>	IP address of the RADIUS server host.
auth-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) destination port for authentication requests. The <i>port-number</i> argument specifies the port number for authentication requests. The host is not used for authentication if this value is set to 0. Default is 1645.
acct-port <i>port-number</i>	(Optional) Specifies the UDP destination port for accounting requests. The <i>port-number</i> argument specifies the port number for accounting requests. The host is not used for accounting services if this value is set to 0. Default is 1646.

Command Default

If no port attributes are defined, the defaults are as follows:

- Authentication port: 1645
- Accounting port: 1646

Command Modes

RADIUS server-group configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **server** command to associate a particular RADIUS server with a defined server group.

There are two different ways in which you can identify a server, depending on the way you want to offer AAA services. You can identify the server simply by using its IP address, or you can identify multiple host instances or entries using the optional **auth-port** and **acct-port** keywords.

When you use the optional keywords, the network access server identifies RADIUS security servers and host instances associated with a group server based on their IP address and specific UDP port numbers. The combination of the IP address and UDP port number creates a unique identifier, allowing different ports to be individually defined as RADIUS host entries providing a specific AAA service. If two different host entries on the same RADIUS server are configured for the same service, for example, accounting, the second host entry configured acts as an automatic switchover backup to the first one. Using this example, if the first host entry fails to provide accounting services, the network access server tries the second host entry configured on the same device for accounting services. (The RADIUS host entries are tried in the order they are configured.)

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to use two different host entries on the same RADIUS server that are configured for the same services—authentication and accounting. The second host entry configured acts as switchover backup to the first one.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server radius group1
RP/0/RSP0/CPU0:router(config-sg-radius)# server 10.1.1.1 auth-port 1645 acct-port 1646
RP/0/RSP0/CPU0:router(config-sg-radius)# server 10.2.2.2 auth-port 2000 acct-port 2001
```

Related Commands

Command	Description
aaa group server radius, on page 32	Groups different RADIUS server hosts into distinct lists and distinct methods.
deadtime (server-group configuration), on page 56	Configures the deadtime value at the RADIUS server group level.
server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.

server (TACACS+)

To associate a particular TACACS+ server with a defined server group, use the **server** command in TACACS+ server-group configuration mode. To remove the associated server from the server group, use the **no** form of this command.

```
server {hostnameip-address}
```

Syntax Description	<i>hostname</i> Character string used to name the server host.
	<i>ip-address</i> IP address of the server host.

Command Default	None
------------------------	------

Command Modes	TACACS+ server-group configuration
----------------------	------------------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	Use the server command to associate a particular TACACS+ server with a defined server group. The server need not be accessible during configuration. Later, you can reference the configured server group from the method lists used to configure authentication, authorization, and accounting (AAA).
-------------------------	---

Task ID	Task ID	Operations
	aaa	read, write

Examples	The following example shows how to associate the TACACS+ server with the IP address 192.168.60.15 with the server group tac1:
-----------------	---

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server tacacs+ tac1
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server 192.168.60.15
```

Related Commands	Command	Description
	aaa group server tacacs+, on page 34	Groups different TACACS+ server hosts into distinct lists.

server-private (RADIUS)

To configure the IP address of the private RADIUS server for the group server, use the **server-private** command in RADIUS server-group configuration mode. To remove the associated private server from the AAA group server, use the **no** form of this command.

```
server-private ip-address [auth-port port-number] [acct-port port-number] [timeout seconds]
[retransmit retries] [key string]
```

Syntax Description	
<i>ip-address</i>	IP address of the RADIUS server host.
auth-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) destination port for authentication requests. The <i>port-number</i> argument specifies the port number for authentication requests. The host is not used for authentication if this value is set to 0. The default value is 1645.
acct-port <i>port-number</i>	(Optional) Specifies the UDP destination port for accounting requests. The <i>port-number</i> argument specifies the port number for accounting requests. The host is not used for accounting services if this value is set to 0. The default value is 1646.
timeout <i>seconds</i>	(Optional) Specifies the number of seconds the router waits for the RADIUS server to reply before retransmitting. The setting overrides the global value of the radius-server timeout command. If no timeout is specified, the global value is used. The <i>seconds</i> argument specifies the timeout value in seconds. The range is from 1 to 1000. If no timeout is specified, the global value is used.
retransmit <i>retries</i>	(Optional) Specifies the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly. The setting overrides the global setting of the radius-server transmit command. The <i>retries</i> argument specifies the retransmit value. The range is from 1 to 100. If no retransmit value is specified, the global value is used.
key <i>string</i>	(Optional) Specifies the authentication and encryption key that is used between the router and the RADIUS daemon running on the RADIUS server. This key overrides the global setting of the radius-server key command. If no key string is specified, the global value is used.

Command Default	
	If no port attributes are defined, the defaults are as follows: <ul style="list-style-type: none"> • Authentication port: 1645 • Accounting port: 1646

Command Modes	
	RADIUS server-group configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **server-private** command to associate a particular private server with a defined server group. Possible overlapping of IP addresses between VRF instances are permitted. Private servers (servers with private addresses) can be defined within the server group and remain hidden from other groups, while the servers in the global pool (for example, default radius server group) can still be referred to by IP addresses and port numbers. Thus, the list of servers in server groups includes references to the hosts in the configuration and the definitions of private servers.

Both the **auth-port** and **acct-port** keywords enter RADIUS server-group private configuration mode.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to define the group1 RADIUS group server, to associate private servers with it, and to enter RADIUS server-group private configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router (config)# aaa group server radius group1
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.1.1.1 timeout 5
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.1.1.1 retransmit 3
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.1.1.1 key coke
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.1.1.1 auth-port 300
RP/0/RSP0/CPU0:router (config-sg-radius-private)# exit
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.2.2.2 timeout 5
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.2.2.2 retransmit 3
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.2.2.2 key coke
RP/0/RSP0/CPU0:router (config-sg-radius)# server-private 10.2.2.2 auth-port 300
RP/0/RSP0/CPU0:router (config-sg-radius-private)#
```

Related Commands

Command	Description
aaa group server tacacs+, on page 34	Groups different RADIUS server hosts into distinct lists and distinct methods.
radius-server key(BNG), on page 88	Sets the authentication and encryption key for all RADIUS communication between the router and the RADIUS daemon.
radius-server retransmit(BNG), on page 91	Specifies the number of times the Cisco IOS XR software retransmits a packet to a server before giving up.
radius-server timeout(BNG), on page 93	Sets the interval for which a router waits for a server host to reply before timing out.
key (RADIUS), on page 67	Specifies the authentication and encryption key that is used between the router and the RADIUS daemon running on the RADIUS server.
retransmit (RADIUS), on page 100	Specifies the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly.
timeout (RADIUS), on page 173	Specifies the number of seconds the router waits for the RADIUS server to reply before retransmitting.

Command	Description
vrf (RADIUS), on page 188	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.

server-private (TACACS+)

To configure the IP address of the private TACACS+ server for the group server, use the **server-private** command in TACACS+ server-group configuration mode. To remove the associated private server from the AAA group server, use the **no** form of this command.

```
server-private {hostnameip-address} [holddown-time time ][port port-number] [timeout seconds]
[key string]
```

Syntax Description		
hostname	Character string used to name the server host.	
ip-address	IP address of the TACACS+ server host. Both IPv4 and IPv6 addresses are supported.	
holddown-time time	Specifies a duration, in seconds, for which an unresponsive TACACS+ server is to be marked as DOWN. The range is from 0 to 1200. Zero indicates that the hold-down timer feature is disabled.	
port port-number	(Optional) Specifies a server port number. This option overrides the default, which is port 49. Valid port numbers range from 1 to 65535.	
timeout seconds	(Optional) Specifies, in seconds, a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server. This option overrides the global timeout value set with the tacacs-server timeout command for only this server. The range is from 1 to 1000. The default is 5.	
key string	(Optional) Specifies the authentication and encryption key that is used between the router and the TACACS+ daemon running on the TACACS+ server. This key overrides the global setting of the tacacs-server key command. If no key string is specified, the global value is used.	

Command Default The *port-name* argument, if not specified, defaults to the standard port 49.
The *seconds* argument, if not specified, defaults to 5 seconds.

Command Modes TACACS+ server-group configuration

Command History	Release	Modification
	Release 7.4.1	This command was modified for Cisco IOS XR 64-bit platforms to include holddown-time option.
	Release 6.8.1	This command was modified for Cisco IOS XR 32-bit platforms to include holddown-time option.
	Release 5.3.0	IPv6 support was introduced.
	Release 4.1.0	This command was introduced.

Usage Guidelines

Use the **server-private** command to associate a particular private server with a defined server group. Possible overlapping of IP addresses between VRF instances are permitted. Private servers (servers with private addresses) can be defined within the server group and remain hidden from other groups, while the servers in the global pool (for example, default tacacs+ server group) can still be referred by IP addresses and port numbers. Therefore, the list of servers in server groups includes references to the hosts in the global configuration and the definitions of private servers.

For details on TACACS+ hold-down timer, see the **holddown-time** command.

Task ID

Task ID	Operations
aaa	read, write

Examples

This example shows how to define the myserver TACACS+ group server, to associate private servers with it, and to enter TACACS+ server-group private configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server tacacs+ myserver
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server-private 10.1.1.1 timeout 5
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server-private 10.1.1.1 key a_secret
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server-private 10.1.1.1 port 51
RP/0/RSP0/CPU0:router(config-sg-tacacs-private)# exit
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server-private 10.2.2.2 timeout 5
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server-private 10.2.2.2 key coke
RP/0/RSP0/CPU0:router(config-sg-tacacs)# server-private 10.2.2.2 port 300
RP/0/RSP0/CPU0:router(config-sg-tacacs-private)#
```

Related Commands

Command	Description
aaa group server tacacs+, on page 34	Groups different TACACS+ server hosts into distinct lists and distinct methods.
tacacs-server key, on page 161	Sets the authentication encryption key used for all TACACS+ communications between the router and the TACACS+ daemon.
tacacs-server timeout, on page 163	Sets the interval for which a router waits for a server host to reply before timing out.
key (TACACS+), on page 69	Specifies an authentication and encryption key shared between the AAA server and the TACACS+ server.
timeout (TACACS+), on page 174	Specifies a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server.
vrf (TACACS+), on page 189	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA TACACS+ server group.

show aaa

To display information about an Internet Key Exchange (IKE) Security Protocol group, user group, local user, login traces, or task group; to list all task IDs associated with all IKE groups, user groups, local users, or task groups in the system; or to list all task IDs for a specified IKE group, user group, local user, or task group, use the **show aaa** command in EXEC mode.

```
show aaa {ikegroup ikegroup-name | login trace | usergroup [usergroup-name] | trace | userdb [username] | task supported | taskgroup [{root-lr | netadmin | operator | sysadmin | root-system | service-admin | cisco-support | askgroup-name}]}
```

Syntax	Description
ikegroup	Displays details for all IKE groups.
<i>ikegroup-name</i>	(Optional) IKE group whose details are to be displayed.
login trace	Displays trace data for login subsystem.
usergroup	Displays details for all user groups.
root-lr	(Optional) Usergroup name.
netadmin	(Optional) Usergroup name.
operator	(Optional) Usergroup name.
sysadmin	(Optional) Usergroup name.
root-system	(Optional) Usergroup name.
cisco-support	(Optional) Usergroup name.
<i>usergroup-name</i>	(Optional) Usergroup name.
trace	Displays trace data for AAA subsystem.
userdb	Displays details for all local users and the usergroups to which each user belongs.
<i>username</i>	(Optional) User whose details are to be displayed.
task supported	Displays all AAA task IDs available.
taskgroup	Displays details for all task groups.
Note	For taskgroup keywords, see optional usergroup name keyword list.
<i>taskgroup-name</i>	(Optional) Task group whose details are to be displayed.

Command Default Details for all user groups, or all local users, or all task groups are listed if no argument is entered.

Command Modes EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines Use the **show aaa** command to list details for all IKE groups, user groups, local users, or task groups in the system. Use the optional *ikegroup-name*, *usergroup-name*, *username*, or *taskgroup-name* argument to display the details for a specified IKE group, user group, user, or task group, respectively.

Task ID	Task ID	Operations
	aaa	read

Examples

The following sample output is from the **show aaa** command, using the **ikegroup** keyword:

```
RP/0/RSP0/CPU0:router# show aaa ikegroup

IKE Group ike-group
    Max-Users = 50
IKE Group ikeuser
    Group-Key = test-password
    Default Domain = cisco.com
IKE Group ike-user
```

The following sample output is from the **show aaa** command, using the **usergroup** command:

```
RP/0/RSP0/CPU0:router# show aaa usergroup operator

User group 'operator'
    Inherits from task group 'operator'
User group 'operator' has the following combined set
of task IDs (including all inherited groups):
Task:      basic-services  : READ    WRITE    EXECUTE  DEBUG
Task:      cdp             : READ
Task:      diag            : READ
Task:      ext-access      : READ          EXECUTE
Task:      logging         : READ
```

The following sample output is from the **show aaa** command, using the **taskgroup** keyword for a task group named netadmin:

```
RP/0/RSP0/CPU0:router# show aaa taskgroup netadmin

Task group 'netadmin'

Task group 'netadmin' has the following combined set
of task IDs (including all inherited groups):

Task:      aaa             : READ
Task:      acl             : READ    WRITE    EXECUTE  DEBUG
Task:      admin           : READ
Task:      ancp            : READ    WRITE    EXECUTE  DEBUG
Task:      atm             : READ    WRITE    EXECUTE  DEBUG
Task:      basic-services  : READ    WRITE    EXECUTE  DEBUG
Task:      bcdl            : READ
Task:      bfd             : READ    WRITE    EXECUTE  DEBUG
Task:      bgp             : READ    WRITE    EXECUTE  DEBUG
```

show aaa

```

Task:          boot   : READ   WRITE   EXECUTE  DEBUG
Task:          bundle : READ   WRITE   EXECUTE  DEBUG
Task:          cdp    : READ   WRITE   EXECUTE  DEBUG
Task:          cef    : READ   WRITE   EXECUTE  DEBUG
Task:          cgn    : READ   WRITE   EXECUTE  DEBUG
Task:          config-mgmt : READ  WRITE   EXECUTE  DEBUG
Task:          config-services : READ  WRITE   EXECUTE  DEBUG
Task:          crypto : READ   WRITE   EXECUTE  DEBUG
Task:          diag   : READ   WRITE   EXECUTE  DEBUG
Task:          drivers : READ
Task:          dwdm   : READ   WRITE   EXECUTE  DEBUG
Task:          eem    : READ   WRITE   EXECUTE  DEBUG
Task:          eigrp  : READ   WRITE   EXECUTE  DEBUG
Task:          ethernet-services : READ
Task:          ext-access : READ  WRITE   EXECUTE  DEBUG
Task:          fabric : READ   WRITE   EXECUTE  DEBUG
Task:          fault-mgr : READ  WRITE   EXECUTE  DEBUG
Task:          filesystem : READ  WRITE   EXECUTE  DEBUG
Task:          firewall : READ  WRITE   EXECUTE  DEBUG
Task:          fr     : READ   WRITE   EXECUTE  DEBUG
Task:          hdlc   : READ   WRITE   EXECUTE  DEBUG
Task:          host-services : READ  WRITE   EXECUTE  DEBUG
Task:          hsrp   : READ   WRITE   EXECUTE  DEBUG
Task:          interface : READ  WRITE   EXECUTE  DEBUG
Task:          inventory : READ
Task:          ip-services : READ  WRITE   EXECUTE  DEBUG
Task:          ipv4   : READ   WRITE   EXECUTE  DEBUG
Task:          ipv6   : READ   WRITE   EXECUTE  DEBUG
Task:          isis   : READ   WRITE   EXECUTE  DEBUG
Task:          l2vpn  : READ   WRITE   EXECUTE  DEBUG
Task:          li     : READ   WRITE   EXECUTE  DEBUG
Task:          logging : READ  WRITE   EXECUTE  DEBUG
Task:          lpts   : READ   WRITE   EXECUTE  DEBUG
Task:          monitor : READ
Task:          mpls-ldp : READ  WRITE   EXECUTE  DEBUG
Task:          mpls-static : READ  WRITE   EXECUTE  DEBUG
Task:          mpls-te  : READ  WRITE   EXECUTE  DEBUG
Task:          multicast : READ  WRITE   EXECUTE  DEBUG
Task:          netflow : READ  WRITE   EXECUTE  DEBUG
Task:          network : READ  WRITE   EXECUTE  DEBUG
Task:          ospf    : READ   WRITE   EXECUTE  DEBUG
Task:          ouni    : READ   WRITE   EXECUTE  DEBUG
Task:          pkg-mgmt : READ
Task:          pos-dpt : READ  WRITE   EXECUTE  DEBUG
Task:          ppp     : READ   WRITE   EXECUTE  DEBUG
Task:          qos     : READ   WRITE   EXECUTE  DEBUG
Task:          rib     : READ   WRITE   EXECUTE  DEBUG
Task:          rip     : READ   WRITE   EXECUTE  DEBUG
Task:          root-lr  : READ
Task:          route-map : READ  WRITE   EXECUTE  DEBUG
Task:          route-policy : READ  WRITE   EXECUTE  DEBUG
Task:          sbc     : READ   WRITE   EXECUTE  DEBUG
Task:          snmp    : READ   WRITE   EXECUTE  DEBUG
Task:          sonet-sdh : READ  WRITE   EXECUTE  DEBUG
Task:          static   : READ   WRITE   EXECUTE  DEBUG
Task:          sysmgr   : READ
Task:          system  : READ   WRITE   EXECUTE  DEBUG
Task:          transport : READ  WRITE   EXECUTE  DEBUG
Task:          tty-access : READ  WRITE   EXECUTE  DEBUG
Task:          tunnel   : READ   WRITE   EXECUTE  DEBUG
Task:          universal : READ
Task:          vlan    : READ   WRITE   EXECUTE  DEBUG
Task:          vrrp    : READ   WRITE   EXECUTE  DEBUG

```

(reserved)

(reserved)

The following sample output is from the **show aaa** command, using the **taskgroup** keyword for an operator. The task group operator has the following combined set of task IDs, which includes all inherited groups:

```
Task:      basic-services : READ    WRITE    EXECUTE    DEBUG
Task:      cdp            : READ
Task:      diag          : READ
Task:      ext-access    : READ                EXECUTE
Task:      logging       : READ
```

The following sample output is from the **show aaa** command, using the **taskgroup** keyword for a root system. The task-group root system has the following combined set of task IDs, which includes all inherited groups:

```
Task:      aaa           : READ    WRITE    EXECUTE    DEBUG
Task:      aaa acl      : READ    WRITE    EXECUTE    DEBUG
Task:      acl admin    : READ    WRITE    EXECUTE    DEBUG
Task:      admin atm    : READ    WRITE    EXECUTE    DEBUG
Task:      atm basic-services : READ    WRITE    EXECUTE    DEBUG
Task:      basic-services bcdl : READ    WRITE    EXECUTE    DEBUG
Task:      bcdl bfd     : READ    WRITE    EXECUTE    DEBUG
Task:      bfd bgp     : READ    WRITE    EXECUTE    DEBUG
Task:      bgp boot    : READ    WRITE    EXECUTE    DEBUG
Task:      boot bundle  : READ    WRITE    EXECUTE    DEBUG
Task:      bundle cdp   : READ    WRITE    EXECUTE    DEBUG
Task:      cdp cef     : READ    WRITE    EXECUTE    DEBUG
Task:      cef config-mgmt : READ    WRITE    EXECUTE    DEBUG
Task:      config-mgmt services : READ    WRITE    EXECUTE    DEBUG
Task:      config-services crypto : READ    WRITE    EXECUTE    DEBUG
Task:      crypto diag  : READ    WRITE    EXECUTE    DEBUG
Task:      diag drivers : READ    WRITE    EXECUTE    DEBUG
Task:      drivers ext-access : READ    WRITE    EXECUTE    DEBUG
Task:      ext-access fabric : READ    WRITE    EXECUTE    DEBUG
Task:      fabric fault-mgr : READ    WRITE    EXECUTE    DEBUG
Task:      fault-mgr filesystem : READ    WRITE    EXECUTE    DEBUG
Task:      filesystem fr : READ    WRITE    EXECUTE    DEBUG
Task:      fr hdlc    : READ    WRITE    EXECUTE    DEBUG
Task:      hdlc host-services : READ    WRITE    EXECUTE    DEBUG
Task:      host-services hsrp : READ    WRITE    EXECUTE    DEBUG
Task:      hsrp interface : READ    WRITE    EXECUTE    DEBUG
Task:      interface inventory : READ    WRITE    EXECUTE    DEBUG
Task:      inventory ip-services : READ    WRITE    EXECUTE    DEBUG
Task:      ip-services ipv4 : READ    WRITE    EXECUTE    DEBUG
Task:      ipv4 ipv6    : READ    WRITE    EXECUTE    DEBUG
Task:      ipv6 isis   : READ    WRITE    EXECUTE    DEBUG
Task:      isis logging : READ    WRITE    EXECUTE    DEBUG
Task:      logging lpts  : READ    WRITE    EXECUTE    DEBUG
Task:      lpts monitor : READ    WRITE    EXECUTE    DEBUG
Task:      monitor mpls-ldp : READ    WRITE    EXECUTE    DEBUG
Task:      mpls-ldp static : READ    WRITE    EXECUTE    DEBUG
Task:      mpls-static te  : READ    WRITE    EXECUTE    DEBUG
Task:      mpls-te multicast : READ    WRITE    EXECUTE    DEBUG
Task:      multicast netflow : READ    WRITE    EXECUTE    DEBUG
Task:      netflow network : READ    WRITE    EXECUTE    DEBUG
Task:      network ospf  : READ    WRITE    EXECUTE    DEBUG
Task:      ospf ouni    : READ    WRITE    EXECUTE    DEBUG
Task:      ouni pkg-mgmt : READ    WRITE    EXECUTE    DEBUG
Task:      pkg pos-mgmt dpt : READ    WRITE    EXECUTE    DEBUG
Task:      ppp          : READ    WRITE    EXECUTE    DEBUG
Task:      qos         : READ    WRITE    EXECUTE    DEBUG
Task:      rib         : READ    WRITE    EXECUTE    DEBUG
Task:      rip         : READ    WRITE    EXECUTE    DEBUG
```

```

Task:          root-lr   : READ   WRITE   EXECUTE  DEBUG
Task:          root-system : READ   WRITE   EXECUTE  DEBUG
Task:          route-map  : READ   WRITE   EXECUTE  DEBUG
Task:          route-policy : READ   WRITE   EXECUTE  DEBUG
Task:          snmp       : READ   WRITE   EXECUTE  DEBUG
Task:          sonet-sdh   : READ   WRITE   EXECUTE  DEBUG
Task:          static      : READ   WRITE   EXECUTE  DEBUG
Task:          sysmgr      : READ   WRITE   EXECUTE  DEBUG
Task:          system      : READ   WRITE   EXECUTE  DEBUG
Task:          transport   : READ   WRITE   EXECUTE  DEBUG
Task:          tty-access  : READ   WRITE   EXECUTE  DEBUG
Task:          tunnel      : READ   WRITE   EXECUTE  DEBUG
Task:          universal   : READ   WRITE   EXECUTE  DEBUG
Task:          vlan        : READ   WRITE   EXECUTE  DEBUG
Task:          vrrp        : READ   WRITE   EXECUTE  DEBUG

```

The following sample output is from **show aaa** command with the **userdb** keyword:

```

RP/0/RSP0/CPU0:router# show aaa userdb

Username lab (admin plane)
User group root-system
User group cisco-support
Username acme
User group root-system

```

The following sample output is from the **show aaa** command, using the **task supported** keywords. Task IDs are displayed in alphabetic order.

```

RP/0/RSP0/CPU0:router# show aaa task supported

aaa
acl
admin
atm
basic-services
bcdl
bfd
bgp
boot
bundle
cdp
cef
cisco-support
config-mgmt
config-services
crypto
diag
disallowed
drivers
eigrp
ext-access
fabric
fault-mgr
filesystem
firewall
fr
hdlc
host-services
hsrp
interface
inventory
ip-services

```

ipv4
ipv6
isis
logging
lpts
monitor
mpls-ldp
mpls-static
mpls-te
multicast
netflow
network
ospf
ouni
pkg-mgmt
pos-dpt
ppp
qos
rib
rip
User group root-systemlr
root-system
route-map
route-policy
sbc
snmp
sonet-sdh
static
sysmgr
system
transport
tty-access
tunnel
universal
vlan
vrrp

Related Commands

Command	Description
show user, on page 150	Displays task IDs enabled for the currently logged-in user.

show aaa password-policy

To display the details of AAA password policy configured in a system, use the **show aaa password-policy** command in EXEC mode.

show aaa password-policy [*policy-name*]

Syntax Description	<i>policy-name</i> Specifies the name of password policy.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	Release 6.2.1	This command was introduced.
	Release 7.2.1	This release introduces the following output: <ul style="list-style-type: none"> • Warning Interval • Restrict Old Time • Maximum Char Repetition • Restrict Old Count • Restrict Username • Restrict Username Reverse • Restrict Password Reverse • Restrict Password Advanced

Usage Guidelines	If the option <i>policy-name</i> is not specified, the command output displays the details of all password policies configured in the system.
-------------------------	---

Refer **aaa password-policy** command details of each field in this command output.

Task ID	Task ID	Operation
	aaa	read

This is a sample out of **show aaa password-policy** command:

```
RP/0/RSP0/CPU0:router#show aaa password-policy test-policy

Fri Feb  3 16:50:58.086 EDT
Password Policy Name : test-policy
```

```

Number of Users : 1
Minimum Length : 2
Maximum Length : 253
Special Character Len : 0
Uppercase Character Len : 0
Lowercase Character Len : 1
Numeric Character Len : 0
Policy Life Time :
  seconds : 0
  minutes : 0
  hours : 0
  days : 0
  months : 0
  years : 0
Warning Interval :
  seconds : 0
  minutes : 0
  hours : 0
  days : 0
  months : 2
  years : 0
Lockout Time :
  seconds : 0
  minutes : 0
  hours : 0
  days : 0
  months : 0
  years : 0
Restrict Old Time :
  days : 0
  months : 0
  years : 3
Character Change Len : 4
Maximum Failure Attempts : 3
Reference Count : 0
Error Count : 0
Lockout Count Attempts : 0
Maximum char repetition : 3
Restrict Old count : 3
Restrict Username : 1
Restrict Username Reverse : 1
Restrict Password Reverse : 1
Restrict Password Advanced : 1
RP/0/RSP0/CPU0:ios#

```

Related Commands	Command	Description
	aaa password-policy, on page 37	Defines the FIPS-compliant AAA password security policy.

show aaa trace

To display all trace data for AAA sub-system, use the **show aaa trace** command in the EXEC mode.

```
show aaa trace [{basic | errors | file | func | hexdump | job | last | location | reverse | stats | tailf | unique
| usec | verbose | wide | wrapping}]
```

Syntax Description		
basic	Displays the data for AAA basic events.	
errors	Displays the data for AAA client library errors.	
file	Displays the specific file.	
func	Displays the data for AAA function.	
hexdump	Displays the traces in hexadecimal.	
job	Displays the job ID.	
last	Displays the last n entries.	
location	Displays the card location.	
reverse	Displays the latest traces first.	
stats	Displays the statistics.	
tailf	Displays the new traces as they were added.	
unique	Displays the unique entries with counts.	
verbose	Displays the internal debugging information.	
wrapping	Displays the wrapping entries.	
	Displays the output modifiers.	

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	aaa	read

This is the sample output of the **show aaa trace** command:

```
RP/0/RSP0/CPU0:router# show aaa trace func
Tue Jan 15 07:59:10.381 UTC
4 wrapping entries (1088 possible, 64 allocated, 0 filtered, 4 total)
Jan 15 06:11:00.958 aaa/func 0/RSP0/CPU0 t5 ENTERING aaa_connect2
Jan 15 06:11:00.962 aaa/func 0/RSP0/CPU0 t5 ENTERING get_unique_context
Jan 15 06:11:00.963 aaa/func 0/RSP0/CPU0 t5 EXITTING get_unique_context
Jan 15 06:11:00.963 aaa/func 0/RSP0/CPU0 t5 EXITTING aaa_connect2
```

show nacm (XR-VM)

To display information about NETCONF Access Control information such as users, groups, rule-lists and traces, use the **show nacm** command in Global Configuration mode. To disable authorization for a function, use the **no** form of this command.

```
show nacm {summary | users [<user-name>] | groups [<group-name>] | rule-list [<rule-list-name>] | rule [<rule-name>] } | trace}
```

Syntax Description	
summary	Displays NACM summary information.
Users	Displays list of users in NACM database.
user-name	Displays info for a given user-name.
groups	Displays list of groups in the NACM database.
<i>group-name</i>	Displays information for a given group name.
rule-list	Displays list of rule-lists in the NACM database.
<i>rule-list-name</i>	Displays info for given rule-list-name.
rule	Displays list of rules under the rule-list in the NACM database.
<i>rule-name</i>	Displays info for given rule-name under rule-name in the NACM database.
trace tacacs+	Displays NACM process traces.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 6.4.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	nacm	read

Examples The following example shows how to use the show nacm command:

```
RP/0/RP0/CPU0:xr-nacm #show nacm summary
NACM SUMMARY
```

```

-----
Enable Nacm : False
Enable External Groups : True
Number of Groups : 2
Number of Users : 2
Number of Rules : 2
Number of Rulelist : 2
Default Read : permit
Default Write : permit
Default Exec : permit
Denied Operations : 0
Denied Data Writes : 0
Denied Notifications : 0
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm users
USERS LIST:
-----
lab,      admin,
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm users lab

USER NAME: lab
-----
Groups List For User:
root-lr,  root-system,
-----
RP/0/RP0/CPU0:xr-nacm#

RP/0/RP0/CPU0:xr-nacm#show nacm groups

GROUPS LIST:
-----
root-system,  root-lr,
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm groups root-system

GROUP NAME: root-system
-----
Users List:
admin,      lab,
Rules List:
rule-list-1,  rule-list-2,
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list
RULELISTS:
-----
Rulelist Index      Rulelist Name
rule-list-2         rule-list-2
rule-list-1         rule-list-1
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list rule-list-1,rule-list-1
RULELIST NAME: rule-list-1
-----
Rule Index          Rule Name
rule1               rule1
rule2               rule2
Group List

```

show nacm (XR-VM)

```

root-system,      root-lr,
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list rule-list-1,rule-list-1 rule

Rule Info:
  Name:                rule1
  Index:               rule1
  Value:               edit-config
  ModuleName:         *
  Action:              permit
  RuleType:            Rpc
  Comment:
  AccessOperations:    All
  HitCount:            0
-----

Rule Info:
  Name:                rule2
  Index:               rule2
  Value:               /nacm/rule-list
  ModuleName:         ietf-netconf-acm
  Action:              deny
  RuleType:            Data
  Comment:
  AccessOperations:    Read,
  HitCount:            0
-----

RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list rule-list-1,rule-list-1 rule rule2,rule2
RULELIST NAME: rule-list-1
-----

Rule Info:
  Name:                rule2
  Index:               rule2
  Value:               /nacm/rule-list
  ModuleName:         ietf-netconf-acm
  Action:              deny
  RuleType:            Data
  Comment:
  AccessOperations:    Read,
  HitCount:            0
-----

RP/0/RP0/CPU0:xr-nacm#

```

Related Commands

Command	Description
aaa accounting, on page 4	Creates a method list for accounting.

show radius

To display information about the RADIUS servers that are configured in the system, use the **show radius** command in EXEC mode.

show radius

Syntax Description	This command has no keywords or arguments.						
Command Default	If no radius servers are configured, no output is displayed.						
Command Modes	EXEC mode						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.		
Release	Modification						
Release 3.7.2	This command was introduced.						
Usage Guidelines	Use the show radius command to display statistics for each configured RADIUS server.						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Task</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td></td> <td>aaa</td> <td>read</td> </tr> </tbody> </table>	Task ID	Task	Operations		aaa	read
Task ID	Task	Operations					
	aaa	read					

Examples

The following sample output is for the **show radius** command:

Output for IPV4 server

```
RP/0/RSP0/CPU0:router# show radius

Global dead time: 0 minute(s)
Number of Servers: 1

Server: 2.3.4.5/2000/2001 is UP
  Address family: IPv6
  Total Deadtime: 0s Last Deadtime: 0s
  Timeout: 5 sec, Retransmit limit: 3
  Quarantined: No
```

Output for IPV6 server

```
RP/0/RSP0/CPU0:router# show radius

Global dead time: 0 minute(s)
Number of Servers: 1

Server: 2001:b::2/2000/2001 is UP
  Address family: IPv6
  Total Deadtime: 0s Last Deadtime: 0s
  Timeout: 5 sec, Retransmit limit: 3
```

Quarantined: No

This table describes the significant fields shown in the display.

Table 1: show radius Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests/UDP destination port for accounting requests.
Timeout	Number of seconds the router waits for a server host to reply before timing out.
Retransmit limit	Number of times the Cisco IOS XR software searches the list of RADIUS server hosts before giving up.

Related Commands

Command	Description
vrf (RADIUS), on page 188	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.
radius-server retransmit(BNG), on page 91	Specifies how many times Cisco IOS XR software searches the list of RADIUS server hosts before giving up.
radius-server timeout(BNG), on page 93	Sets the interval for which a router waits for a server host to reply.

show radius accounting

To obtain information and detailed statistics for the RADIUS accounting server and port, use the **show radius accounting** command in EXEC mode.

show radius accounting

Syntax Description This command has no keywords or arguments.

Command Default If no RADIUS servers are configured on the router, the output is empty. If the default values are for the counter (for example, request and pending), the values are all zero because the RADIUS server was just defined and not used yet.

Command Modes EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read

Examples

The following sample output is displayed on a per-server basis for the **show radius accounting** command:

```
RP/0/RSP0/CPU0:router# show radius accounting

Server: 12.26.25.61, port: 1813
0 requests, 0 pending, 0 retransmits
0 responses, 0 timeouts, 0 bad responses
0 bad authenticators, 0 unknown types, 0 dropped
0 ms latest rtt

Server: 12.26.49.12, port: 1813
0 requests, 0 pending, 0 retransmits
0 responses, 0 timeouts, 0 bad responses
0 bad authenticators, 0 unknown types, 0 dropped
0 ms latest rtt

Server: 12.38.28.18, port: 29199
0 requests, 0 pending, 0 retransmits
0 responses, 0 timeouts, 0 bad responses
0 bad authenticators, 0 unknown types, 0 dropped
0 ms latest rtt
```

This table describes the significant fields shown in the display.

Table 2: show radius accounting Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests; UDP destination port for accounting requests.

Related Commands

Command	Description
aaa accounting, on page 4	Creates a method list for accounting.
aaa authentication , on page 15	Creates a method list for authentication.
show radius authentication, on page 129	Obtains information and detailed statistics for the RADIUS authentication server and port.

show radius authentication

To obtain information and detailed statistics for the RADIUS authentication server and port, use the **show radius authentication** command in EXEC mode.

show radius authentication

Syntax Description	This command has no keywords or arguments.						
Command Default	If no RADIUS servers are configured on the router, the output is empty. If the default values are for the counter (for example, request and pending), the values are all zero because the RADIUS server was just defined and not used yet.						
Command Modes	EXEC mode						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.		
Release	Modification						
Release 3.7.2	This command was introduced.						
Usage Guidelines	No specific guidelines impact the use of this command.						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Task</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td></td> <td>aaa</td> <td>read</td> </tr> </tbody> </table>	Task ID	Task	Operations		aaa	read
Task ID	Task	Operations					
	aaa	read					

Examples

The following sample output is for the **show radius authentication** command:

```
RP/0/RSP0/CPU0:router# show radius authentication

Server: 12.26.25.61, port: 1812
0 requests, 0 pending, 0 retransmits
0 accepts, 0 rejects, 0 challenges
0 timeouts, 0 bad responses, 0 bad authenticators
0 unknown types, 0 dropped, 0 ms latest rtt

Server: 12.26.49.12, port: 1812
0 requests, 0 pending, 0 retransmits
0 accepts, 0 rejects, 0 challenges
0 timeouts, 0 bad responses, 0 bad authenticators
0 unknown types, 0 dropped, 0 ms latest rtt

Server: 12.38.28.18, port: 21099
0 requests, 0 pending, 0 retransmits
0 accepts, 0 rejects, 0 challenges
0 timeouts, 0 bad responses, 0 bad authenticators
0 unknown types, 0 dropped, 0 ms latest rtt
```

This table describes the significant fields shown in the display.

Table 3: show radius authentication Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests; UDP destination port for accounting requests.

Related Commands

Command	Description
aaa accounting, on page 4	Creates a method list for accounting.
aaa authentication , on page 15	Creates a method list for authentication.
show radius accounting, on page 127	Obtains information and detailed statistics for the RADIUS accounting server and port.

show radius client

To obtain general information about the RADIUS client on Cisco IOS XR software, use the **show radius client** command in EXEC mode.

show radius client

Syntax Description This command has no keywords or arguments.

Command Default The default value for the counters (for example, an invalid address) is 0. The network access server (NAS) identifier is the hostname that is defined on the router.

Command Modes EXEC mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines The **show radius client** command displays the authentication and accounting responses that are received from the invalid RADIUS servers, for example, unknown to the NAS. In addition, the **show radius client** command displays the hostname or NAS identifier for the RADIUS authentication client, accounting client, or both.

Task ID

Task ID	Task	Operations
	aaa	read

Examples

The following sample output is for the **show radius client** command:

```
RP/0/RSP0/CPU0:router# show radius client

Client NAS identifier:                miniq
Authentication responses from invalid addresses: 0
Accounting responses from invalid addresses:    0
```

This table describes the significant fields shown in the display.

Table 4: show radius client Field Descriptions

Field	Description
Client NAS identifier	Identifies the NAS-identifier of the RADIUS authentication client.

Related Commands

Command	Description
server (RADIUS), on page 104	Associates a particular RADIUS server with a defined server group.

Command	Description
show radius, on page 125	Displays information about the RADIUS servers that are configured in the system.

show radius dead-criteria

To obtain information about the dead server detection criteria, use the **show radius dead-criteria** command in EXEC mode.

```
show radius dead-criteria host ip-addr [auth-port auth-port] [acct-port acct-port]
```

Syntax Description	host ip-addr	Specifies the name or IP address of the configured RADIUS server.
	auth-port auth-port (Optional)	Specifies the authentication port for the RADIUS server. The default value is 1645.
	acct-port acct-port (Optional)	Specifies the accounting port for the RADIUS server. The default value is 1646.

Command Default The default values for time and tries are not fixed to a single value; therefore, they are calculated and fall within a range of 10 to 60 seconds for time and 10 to 100 for tries.

Command Modes EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read

Examples

The following sample output is for the **show radius dead-criteria** command:

```
RP/0/RSP0/CPU0:router# show radius dead-criteria host 12.26.49.12 auth-port 11000 acct-port 11001
```

```
Server: 12.26.49.12/11000/11001
Dead criteria time: 10 sec (computed) tries: 10 (computed)
```

This table describes the significant fields shown in the display.

Table 5: show radius dead-criteria Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests/UDP destination port for accounting requests.
Timeout	Number of seconds the router waits for a server host to reply before timing out.

show radius dead-criteria

Field	Description
Retransmits	Number of times Cisco IOS XR software searches the list of RADIUS server hosts before giving up.

Related Commands

Command	Description
radius-server dead-criteria time, on page 79	Forces one or both of the criteria that is used to mark a RADIUS server as dead.
radius-server deadtime(BNG), on page 83	Defines the length of time in minutes for a RADIUS server to remain marked dead.

show radius server-groups

To display information about the RADIUS server groups that are configured in the system, use the **show radius server-groups** command in EXEC mode.

```
show radius server-groups [group-name [detail]]
```

Syntax Description	
	<i>group-name</i> (Optional) Name of the server group. The properties are displayed.
	detail (Optional) Displays properties for all the server groups.

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines Use the **show radius server-groups** command to display information about each configured RADIUS server group, including the group name, numbers of servers in the group, and a list of servers in the named server group. A global list of all configured RADIUS servers, along with authentication and accounting port numbers, is also displayed.

Task ID	Task ID	Operations
	aaa	read

Examples

The inherited global message is displayed if no group level deadtime is defined for this group; otherwise, the group level deadtime value is displayed and this message is omitted. The following sample output is for the **show radius server-groups** command:

```
RP/0/RSP0/CPU0:router# show radius server-groups

Global list of servers
  Contains 2 server(s)
    Server 10.1.1.1/1645/1646
    Server 10.2.2.2/1645/1646

Server group 'radgrp1' has 2 server(s)
  Dead time: 0 minute(s) (inherited from global)
  Contains 2 server(s)
    Server 10.1.1.1/1645/1646
    Server 10.2.2.2/1645/1646

Server group 'radgrp-priv' has 1 server(s)
  Dead time: 0 minute(s) (inherited from global)
  Contains 1 server(s)
    Server 10.3.3.3/1645/1646 [private]
```

The following sample output shows the properties for all the server groups in group “radgrp1:”

```
RP/0/RSP0/CPU0:router# show radius server-groups radgrp1 detail

Server group 'radgrp1' has 2 server(s)
  VRF default (id 0x60000000)
  Dead time: 0 minute(s) (inherited from global)
  Contains 2 server(s)
    Server 10.1.1.1/1645/1646
  Authentication:
    0 requests, 0 pending, 0 retransmits
    0 accepts, 0 rejects, 0 challenges
    0 timeouts, 0 bad responses, 0 bad authenticators
    0 unknown types, 0 dropped, 0 ms latest rtt
  Accounting:
    0 requests, 0 pending, 0 retransmits
    0 responses, 0 timeouts, 0 bad responses
    0 bad authenticators, 0 unknown types, 0 dropped
    0 ms latest rtt
    Server 10.2.2.2/1645/1646
  Authentication:
    0 requests, 0 pending, 0 retransmits
    0 accepts, 0 rejects, 0 challenges
    0 timeouts, 0 bad responses, 0 bad authenticators
    0 unknown types, 0 dropped, 0 ms latest rtt
  Accounting:
    0 requests, 0 pending, 0 retransmits
    0 responses, 0 timeouts, 0 bad responses
    0 bad authenticators, 0 unknown types, 0 dropped
    0 ms latest rtt
```

The following sample output shows the properties for all the server groups in detail in the group “radgrp-priv:”

```
RP/0/RSP0/CPU0:router# show radius server-groups radgrp-priv detail

Server group 'radgrp-priv' has 1 server(s)
  VRF default (id 0x60000000)
  Dead time: 0 minute(s) (inherited from global)
  Contains 1 server(s)
    Server 10.3.3.3/1645/1646 [private]
  Authentication:
    0 requests, 0 pending, 0 retransmits
    0 accepts, 0 rejects, 0 challenges
    0 timeouts, 0 bad responses, 0 bad authenticators
    0 unknown types, 0 dropped, 0 ms latest rtt
  Accounting:
    0 requests, 0 pending, 0 retransmits
    0 responses, 0 timeouts, 0 bad responses
    0 bad authenticators, 0 unknown types, 0 dropped
    0 ms latest rtt
```

This table describes the significant fields shown in the display.

Table 6: show radius server-groups Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests/UDP destination port for accounting requests.

Related Commands

Command	Description
vrf (RADIUS), on page 188	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.

show radius server-groups detail

To display the detailed summary of the RADIUS server group information, use the **show radius server-groups detail** command in the EXEC mode.

show radius server-groups *server_group_name* **detail**

Syntax Description	<i>server_group_name</i> Specifies the name of the RADIUS server group.				
Command Default	None				
Command Modes	EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>aaa</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	aaa	read
Task ID	Operation				
aaa	read				

This is sample output of the **show radius server-groups detail** command:

```
RP/0/RSP0/CPU0:router# show radius server-groups SG1 detail
Wed Jan 18 06:04:59.432 EST

Server group 'SG1' has 1 server(s)
  VRF (id 0x0)
  Dead time: 0 minute(s) (inherited from global)
  Contains 1 server(s)
Server 99.0.0.10/1812/1813
  Authentication:
    100 requests, 0 pending, 0 retransmits
    100 accepts, 0 rejects, 0 challenges
    0 timeouts, 0 bad responses, 0 bad authenticators
    0 unknown types, 0 dropped, 0 ms latest rtt
  Throttled: 0 transactions, 0 timeout, 0 failures
  Estimated Throttled Access Transactions: 0
  Maximum Throttled Access Transactions: 0

  Automated TEST Stats:
    0 requests, 0 timeouts, 0 response, 0 pending
```

This table describes the significant fields shown in the display.

Table 7: show radius Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests/UDP destination port for accounting requests.
Deadtime	Length of time in minutes for a RADIUS server to remain marked dead.
Authentication	Specifies the authentication details.
Automated TEST Stats	Specifies the total time taken for sending requests, total timeouts, and the response time.

show subscriber database configuration brief service-profile

The command displays a list of downloaded service profile in cache and whether service profile is being used or not.

show subscriber database configuration brief service-profile

Command Default None

Command Modes Global Configuration Mode

Command History

Release	Modification
6.6.3	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

This example displays a list of downloaded service profile in cache:

```
RP/0/0/CPU0:router#show subscriber database configuration brief service-profile
Wed Apr 24 14:55:11.173 IST
```

```
Location 0/0/CPU0
```

ServiceName:MethodList	In Use By Subscriber
1_Mbps_FQOS:default	True
2_Mbps_FQOS:default	False

show tacacs

To display information about the TACACS+ servers that are configured in the system, use the **show tacacs** command in EXEC mode.

show tacacs

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Release 5.3.0	IPv6 support was introduced on this command.	

Usage Guidelines Use the **show tacacs** command to display statistics for each configured TACACS+ server.

Task ID	Task ID	Operations
	aaa	read

Examples

The following is sample output from the **show tacacs** command:

```
RP/0/RSP0/CPU0:router# show tacacs

For IPv4 IP addresses:
Server:10.1.1.1/21212 opens=0 closes=0 aborts=0 errors=0
      packets in=0 packets out=0
      status=up single-connect=false

Server:10.2.2.2/21232 opens=0 closes=0 aborts=0 errors=0
      packets in=0 packets out=0
      status=up single-connect=false

For IPv6 IP addresses:
Server: 10.2.3.5/49 family = AF_INET opens=0 closes=0 aborts=0 errors=0
      packets in=0 packets out=0
      status=up single-connect=false
```

This table describes the significant fields shown in the display.

Table 8: show tacacs Field Descriptions

Field	Description
Server	Server IP address.

Field	Description
opens	Number of socket opens to the external server.
closes	Number of socket closes to the external server.
aborts	Number of tacacs requests that have been terminated midway.
errors	Number of error replies from the external server.
packets in	Number of TCP packets that have been received from the external server.
packets out	Number of TCP packets that have been sent to the external server.

show tacacs counters

To display statistics of authentication, executive and command authorization, and executive and command accounting for each TACACS+ servers configured in the system, use the **show tacacs counters** command in the EXEC mode.

show tacacs counters

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	aaa	read

Examples

The following is a sample output from the **show tacacs counters** command:

```
RP/0/RSP0/CPU0:router# show tacacs counters
TACACS+ Server: 10.105.236.101/4010 [global]
  Authentication:
    10 requests, 4 accepts, 3 failure, 2 error, 1 timeout
  Exec Authorization:
    0 requests, 0 accepts, 0 denied, 0 error, 0 timeout
  Command Authorization:
    6 requests, 6 accepts, 0 denied, 0 error, 0 timeout
  Exec Accounting:
    0 requests, 0 accepts, 0 fail, 0 error, 0 timeout
  Command Accounting:
    6 requests, 6 accepts, 0 fail, 0 error, 0 timeout
TACACS+ Server: 10.105.236.101/2201 [private] vrf = default
  Authentication:
    0 requests, 0 accepts, 0 failure, 0 error, 0 timeout
  Exec Authorization:
    0 requests, 0 accepts, 0 denied, 0 error, 0 timeout
```

```
show tacacs counters
```

```
Command Authorization:
  0 requests, 0 accepts, 0 denied, 0 error, 0 timeout

Exec Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout

Command Accounting:
  0 requests, 0 accepts, 0 fail, 0 error, 0 timeout
```


show tacacs details

To display detailed information about the TACACS+ server and server groups that are configured in the system, use the **show tacacs details** command in the EXEC mode.

show tacacs details

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

Usage Guidelines Use the **show tacacs details** command to display information about each configured TACACS+ server, including the group name, numbers of servers in the group, and a list of servers in the named server group. A global list of all configured TACACS+ servers is also displayed.

Task ID	Task ID	Operations
	aaa	read

Examples

The following is sample output from the **show tacacs details** command:

```
RP/0/RSP0/CPU0:router# show tacacs details

TACACS+ Server                               : 10.105.236.101/4010
[Global]
  Family                                       : IPv4
  Timeout(in secs)                           : 3
  Connection Opens                            : 8
  Connection Closes                           : 8
  Requests sent                               : 6
  Response received                           : 6
  Packets Abort                               : 2
  Server State                                : Down
  Server On-Hold                              : True
  Tacacs-Single-Connect                       : False
  Tacacs-Single-Connect-Idle-Timeout(in secs) : 0
  Last Connection Attempted                   : 08:32:43 UTC Tue Aug
02 2022

TACACS+ Server                               : 10.105.236.101/8010
[Private] vrf=default
  Family                                       : IPv4
  Timeout(in secs)                           : 3
  Connection Opens                            : 8
  Connection Closes                           : 7
```

show tacacs details

```

Requests sent                : 7
Response received           : 7
Packets Abort               : 0
Server State                 : Up
Server On-Hold               : False
Tacacs-Single-Connect       : False
Tacacs-Single-Connect-Idle-Timeout(in secs) : 0
Last Connection Attempted   : 08:32:52 UTC Tue Aug
02 2022

```

TACACS+ Server-groups:

Global list of servers

```
Server 10.105.236.101/4010 family=IPv4
```

Server group 'tac1' has 1 servers

```
Servers in this group are under 'default' vrf
Server 10.105.236.101/8010 [private] family=IPv4
```

TACACS+ Source-Interface:

Interface	IPV4-Address	VRF Id
GigabitEthernet0/0/0/0	0.0.0.0	0x60000001
MgmtEth0/RP0/CPU0/0	192.168.122.222	0x60000000

Interface	IPV6-Address	VRF Id
GigabitEthernet0/0/0/0	::	0x60000001
MgmtEth0/RP0/CPU0/0	::	0x60000000

show tacacs server-groups

To display information about the TACACS+ server groups that are configured in the system, use the **show tacacs server-groups** command in EXEC mode.

show tacacs server-groups

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines Use the **show tacacs server-groups** command to display information about each configured TACACS+ server group, including the group name, numbers of servers in the group, and a list of servers in the named server group. A global list of all configured TACACS+ servers is also displayed.

Task ID

Task ID	Task	Operations
	aaa	read

Examples

The following is sample output from the **show tacacs server-groups** command:

```
RP/0/RSP0/CPU0:router# show tacacs server-groups

Global list of servers
  Server 192.168.25.61/23456
  Server 192.168.49.12/12345
  Server 192.168.49.12/9000
  Server 192.168.25.61/23432
  Server 10.5.5.5/23456
  Server 10.1.1.1/49
Server group 'tac100' has 1 servers
Server 192.168.49.12
```

This table describes the significant fields shown in the display.

Table 9: show tacacs server-groups Field Descriptions

Field	Description
Server	Server IP address.

show tacacs server-groups**Related Commands**

Command	Description
tacacs-server host, on page 158	Specifies a TACACS+ host.

show tacacs source-interface

To display information about the source interface for the TACACS+ server that are configured in the system, use the **show tacacs source-interface** command in the EXEC mode.

show tacacs source-interface

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

Usage Guidelines Use the **show tacacs source-interface** command to display source interface information about each configured TACACS+ server, including the interface name, vrf-id, and IPv4 and IPv6 address.

Task ID	Task ID	Operations
	aaa	read

Examples

The following is sample output from the **show tacacs source-interface** command:

```
RP/0/RSP0/CPU0:router# show tacacs source-interface
Interface                               VRF Id                                IPv4-Address
-----                               -
MgmtEth0/RP0/CPU0/0                    0x60000000                            192.168.122.222

Interface                               VRF Id                                IPv6-Address
-----                               -
MgmtEth0/RP0/CPU0/0                    0x60000000                             ::
RP/0/RP0/CPU0:ios#
```

show user

To display all user groups and task IDs associated with the currently logged-in user, use the **show user** command in EXEC mode.

show user [{**all** | **authentication** | **group** | **tasks**}]

Syntax Description	
all	(Optional) Displays all user groups and task IDs for the currently logged-in user.
authentication	(Optional) Displays authentication method parameters for the currently logged-in user.
group	(Optional) Displays the user groups associated with the currently logged-in user.
tasks	(Optional) Displays task IDs associated with the currently logged-in user. The tasks keyword indicates which task is reserved in the sample output.

Command Default When the **show user** command is used without any option, it displays the ID of the user who is logged in currently.

Command Modes EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines Use the **show user** command to display all user groups and task IDs associated with the currently logged-in user.

Task ID	Task ID	Operations
	none	—

Examples

The following sample output displays the authentication method parameters from the **show user** command:

```
RP/0/RSP0/CPU0:router# show user authentication
local
```

The following sample output displays the groups from the **show user** command:

```
RP/0/RSP0/CPU0:router# show user group
root-system
```

The following sample output displays all the information for the groups and tasks from the **show user** command:

```

RP/0/RSP0/CPU0:router# show user all
Username: lab
Groups: root-system
Authenticated using method local
User lab has the following Task ID(s):

Task:          aaa : READ    WRITE    EXECUTE  DEBUG
Task:          aaa : READ    WRITE    EXECUTE  DEBUG
Task:          acl : READ    WRITE    EXECUTE  DEBUG
Task:          admin : READ    WRITE    EXECUTE  DEBUG
Task:          atm : READ    WRITE    EXECUTE  DEBUG
Task:    basic-services : READ    WRITE    EXECUTE  DEBUG
Task:          bcdl : READ    WRITE    EXECUTE  DEBUG
Task:          bfd : READ    WRITE    EXECUTE  DEBUG
Task:          bgp : READ    WRITE    EXECUTE  DEBUG
Task:          boot : READ    WRITE    EXECUTE  DEBUG
Task:          bundle : READ    WRITE    EXECUTE  DEBUG
Task:          cdp : READ    WRITE    EXECUTE  DEBUG
Task:          cef : READ    WRITE    EXECUTE  DEBUG
Task:    config-mgmt : READ    WRITE    EXECUTE  DEBUG
Task:    config-services : READ    WRITE    EXECUTE  DEBUG
Task:          crypto : READ    WRITE    EXECUTE  DEBUG
Task:          diag : READ    WRITE    EXECUTE  DEBUG
Task:          drivers : READ    WRITE    EXECUTE  DEBUG
Task:          eigrp : READ    WRITE    EXECUTE  DEBUG
Task:    ext-access : READ    WRITE    EXECUTE  DEBUG
Task:          fabric : READ    WRITE    EXECUTE  DEBUG
Task:          fault-mgr : READ    WRITE    EXECUTE  DEBUG
Task:          filesystem : READ    WRITE    EXECUTE  DEBUG
Task:          firewall : READ    WRITE    EXECUTE  DEBUG
Task:          fr : READ    WRITE    EXECUTE  DEBUG
Task:          hdlc : READ    WRITE    EXECUTE  DEBUG
Task:    host-services : READ    WRITE    EXECUTE  DEBUG
Task:          hsrp : READ    WRITE    EXECUTE  DEBUG
Task:          interface : READ    WRITE    EXECUTE  DEBUG
Task:          inventory : READ    WRITE    EXECUTE  DEBUG
Task:    ip-services : READ    WRITE    EXECUTE  DEBUG
Task:          ipv4 : READ    WRITE    EXECUTE  DEBUG
Task:          ipv6 : READ    WRITE    EXECUTE  DEBUG
Task:          isis : READ    WRITE    EXECUTE  DEBUG
Task:          logging : READ    WRITE    EXECUTE  DEBUG
Task:          lpts : READ    WRITE    EXECUTE  DEBUG
Task:          monitor : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-ldp : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-static : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-te : READ    WRITE    EXECUTE  DEBUG
Task:          multicast : READ    WRITE    EXECUTE  DEBUG
Task:          netflow : READ    WRITE    EXECUTE  DEBUG
Task:          network : READ    WRITE    EXECUTE  DEBUG
Task:          ospf : READ    WRITE    EXECUTE  DEBUG
Task:          ouni : READ    WRITE    EXECUTE  DEBUG
Task:          pkg-mgmt : READ    WRITE    EXECUTE  DEBUG
Task:          ppp : READ    WRITE    EXECUTE  DEBUG
Task:          qos : READ    WRITE    EXECUTE  DEBUG
Task:          rib : READ    WRITE    EXECUTE  DEBUG
Task:          rip : READ    WRITE    EXECUTE  DEBUG
Task:          root-lr : READ    WRITE    EXECUTE  DEBUG (reserved)
Task:    root-system : READ    WRITE    EXECUTE  DEBUG (reserved)
Task:          route-map : READ    WRITE    EXECUTE  DEBUG
Task:    route-policy : READ    WRITE    EXECUTE  DEBUG
Task:          sbc : READ    WRITE    EXECUTE  DEBUG
Task:          snmp : READ    WRITE    EXECUTE  DEBUG
Task:          sonet-sdh : READ    WRITE    EXECUTE  DEBUG

```

show user

```

Task:          static  : READ    WRITE    EXECUTE  DEBUG
Task:          sysmgr  : READ    WRITE    EXECUTE  DEBUG
Task:          system  : READ    WRITE    EXECUTE  DEBUG
Task:          transport : READ    WRITE    EXECUTE  DEBUG
Task:          tty-access : READ    WRITE    EXECUTE  DEBUG
Task:          tunnel   : READ    WRITE    EXECUTE  DEBUG
Task:          universal : READ    WRITE    EXECUTE  DEBUG (reserved)
Task:          vlan     : READ    WRITE    EXECUTE  DEBUG
Task:          vrrp     : READ    WRITE    EXECUTE  DEBUG

```

The following sample output displays the tasks and indicates which tasks are reserved from the **show user** command:

```

RP/0/RSP0/CPU0:router# show user tasks

Task:          aaa      : READ    WRITE    EXECUTE  DEBUG
Task:          aaa      : READ    WRITE    EXECUTE  DEBUG
Task:          acl      : READ    WRITE    EXECUTE  DEBUG
Task:          admin    : READ    WRITE    EXECUTE  DEBUG
Task:          atm      : READ    WRITE    EXECUTE  DEBUG
Task:          basic-services : READ    WRITE    EXECUTE  DEBUG
Task:          bcdl     : READ    WRITE    EXECUTE  DEBUG
Task:          bfd      : READ    WRITE    EXECUTE  DEBUG
Task:          bgp      : READ    WRITE    EXECUTE  DEBUG
Task:          boot     : READ    WRITE    EXECUTE  DEBUG
Task:          bundle   : READ    WRITE    EXECUTE  DEBUG
Task:          cdp      : READ    WRITE    EXECUTE  DEBUG
Task:          cef      : READ    WRITE    EXECUTE  DEBUG
Task:          config-mgmt : READ    WRITE    EXECUTE  DEBUG
Task:          config-services : READ    WRITE    EXECUTE  DEBUG
Task:          crypto   : READ    WRITE    EXECUTE  DEBUG
Task:          diag     : READ    WRITE    EXECUTE  DEBUG
Task:          drivers  : READ    WRITE    EXECUTE  DEBUG
Task:          eigrp    : READ    WRITE    EXECUTE  DEBUG
Task:          ext-access : READ    WRITE    EXECUTE  DEBUG
Task:          fabric   : READ    WRITE    EXECUTE  DEBUG
Task:          fault-mgr : READ    WRITE    EXECUTE  DEBUG
Task:          filesystem : READ    WRITE    EXECUTE  DEBUG
Task:          firewall : READ    WRITE    EXECUTE  DEBUG
Task:          fr       : READ    WRITE    EXECUTE  DEBUG
Task:          hdlc     : READ    WRITE    EXECUTE  DEBUG
Task:          host-services : READ    WRITE    EXECUTE  DEBUG
Task:          hsrp     : READ    WRITE    EXECUTE  DEBUG
Task:          interface : READ    WRITE    EXECUTE  DEBUG
Task:          inventory : READ    WRITE    EXECUTE  DEBUG
Task:          ip-services : READ    WRITE    EXECUTE  DEBUG
Task:          ipv4     : READ    WRITE    EXECUTE  DEBUG
Task:          ipv6     : READ    WRITE    EXECUTE  DEBUG
Task:          isis     : READ    WRITE    EXECUTE  DEBUG
Task:          logging  : READ    WRITE    EXECUTE  DEBUG
Task:          lpts     : READ    WRITE    EXECUTE  DEBUG
Task:          monitor  : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-ldp  : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-static : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-te   : READ    WRITE    EXECUTE  DEBUG
Task:          multicast : READ    WRITE    EXECUTE  DEBUG
Task:          netflow  : READ    WRITE    EXECUTE  DEBUG
Task:          network   : READ    WRITE    EXECUTE  DEBUG
Task:          ospf     : READ    WRITE    EXECUTE  DEBUG
Task:          ouni     : READ    WRITE    EXECUTE  DEBUG
Task:          pkg-mgmt  : READ    WRITE    EXECUTE  DEBUG
Task:          ppp      : READ    WRITE    EXECUTE  DEBUG
Task:          qos      : READ    WRITE    EXECUTE  DEBUG

```



```

Task:          rib  : READ  WRITE  EXECUTE  DEBUG
Task:          rip  : READ  WRITE  EXECUTE  DEBUG
Task:          root-lr : READ  WRITE  EXECUTE  DEBUG (reserved)
Task:          root-system : READ  WRITE  EXECUTE  DEBUG (reserved)
Task:          route-map : READ  WRITE  EXECUTE  DEBUG
Task:          route-policy : READ  WRITE  EXECUTE  DEBUG
Task:          sbc   : READ  WRITE  EXECUTE  DEBUG
Task:          snmp  : READ  WRITE  EXECUTE  DEBUG
Task:          sonet-sdh : READ  WRITE  EXECUTE  DEBUG
Task:          static : READ  WRITE  EXECUTE  DEBUG
Task:          sysmgr : READ  WRITE  EXECUTE  DEBUG
Task:          system : READ  WRITE  EXECUTE  DEBUG
Task:          transport : READ  WRITE  EXECUTE  DEBUG
Task:          tty-access : READ  WRITE  EXECUTE  DEBUG
Task:          tunnel  : READ  WRITE  EXECUTE  DEBUG
Task:          universal : READ  WRITE  EXECUTE  DEBUG (reserved)
Task:          vlan   : READ  WRITE  EXECUTE  DEBUG
Task:          vrrp   : READ  WRITE  EXECUTE  DEBUG

```

Related Commands

Command	Description
show aaa , on page 112	Displays the task maps for selected user groups, local users, or task groups.

single-connection

To multiplex all TACACS+ requests to this server over a single TCP connection, use the **single-connection** command in TACACS host configuration mode. To disable the single TCP connection for all new sessions that use a separate connection, use the **no** form of this command.

single-connection

Syntax Description

This command has no keywords or arguments.

Command Default

By default, a separate connection is used for each session.

Command Modes

TACACS host configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

The **single-connection** command allows the TACACS+ server to handle a greater number of TACACS operations than would be possible if multiple TCP connections were used to send requests to a server.

The TACACS+ server that is being used must support single-connection mode for this to be effective; otherwise, the connection between the network access server and the TACACS+ server locks up or you can receive unauthentic errors.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to configure a single TCP connection to be made with the TACACS+ server (IP address 209.165.200.226) and all authentication, authorization, accounting requests to use this TCP connection. This works only if the TACACS+ server is also configured in single-connection mode. To configure the TACACS+ server in single connection mode, refer to the respective server manual.

```
RP/0/RSP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RSP0/CPU0:router(config-tacacs-host)# single-connection
```

Related Commands

Command	Description
tacacs-server host, on page 158	Specifies a TACACS+ host.

single-connection-idle-timeout

To set the idle timeout value for the single TCP connection to the TACACS+ server, use the **single-connection-idle-timeout** command in *tacacs-server host* configuration mode. To remove the configuration or to disable the idle timeout for the single connection, use the **no** form of this command.

single-connection-idle-timeout *time-in-seconds*

Syntax Description

time-in-seconds Specifies the single connection timeout value, in seconds.

The range is:

- 500 to 7200 (prior to Cisco IOS XR Software Release 7.4.1/Release 7.3.2/Release 6.8.1)
- 5 to 7200 (from Cisco IOS XR Software Release 7.4.1/Release 7.3.2/Release 6.8.1, and later)

Command Default

Single connection idle timeout is not set, by default.

Command Modes

tacacs-server host

Command History

Release	Modification
Release 6.8.1	This command was modified to change the timeout range (for Cisco IOS XR 32-bit routers).
Release 7.3.2	This command was modified to change the timeout range (for Cisco IOS XR 64-bit routers).
Release 7.4.1	
Release 6.6.3	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
aaa	read, write

Examples

This example shows how to set an idle timeout value of 500 seconds for the single TCP connections to the TACACS+ server:

```
RP/0/RSP0/CPU0:router(config)#tacacs-server host 209.165.200.226
RP/0/RSP0/CPU0:router(config-tacacs-host)#single-connection-idle-timeout 500
RP/0/RSP0/CPU0:router(config-tacacs-host)#commit
```

Related Commands

Command	Description
single-connection , on page 154	Multiplexes all TACACS+ requests to the server over a single TCP connection.

statistics period service-accounting

To set collection period for statistics collectors, use the **statistics period service-accounting** command in Global Configuration mode or Admin Configuration mode. To disable this behavior, use the **no** form of this command.

statistics period service-accounting {*period* | **disable**}

Syntax Description	<i>period</i> Collection period in seconds. The range is from 30 to 3600. The default is 900.				
	disable Disables periodic statistics collection.				
Command Default	Default collection period is 900 seconds.				
Command Modes	Global Configuration mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.3.1	This command was introduced.
Release	Modification				
Release 4.3.1	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>diag</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	diag	read, write
Task ID	Operation				
diag	read, write				

This example shows how to change the collection period or polling interval for statistics collector:

```
RP/0/RSP0/CPU0:router(config)# statistics period service-accounting 2000
```

tacacs-server host

To specify a TACACS+ host server, use the **tacacs-server host** command in Global Configuration mode. To delete the specified name or address, use the **no** form of this command.

```
tacacs-server host host-name [ holddown-time time ][port port-number] [timeout seconds] [key
[{0 | 7}] auth-key] [single-connection]
[ single-connection-idle-timeout time-in-seconds ]
```

Syntax Description	
<i>host-name</i>	Host or domain name or IP address of the TACACS+ server.
holddown-time <i>time</i>	Specifies a duration, in seconds, for which an unresponsive TACACS+ server is to be marked as DOWN. The range is from 0 to 1200. Zero indicates that the hold-down timer feature is disabled.
port <i>port-number</i>	(Optional) Specifies a server port number. This option overrides the default, which is port 49. Valid port numbers range from 1 to 65535.
timeout <i>seconds</i>	(Optional) Specifies a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server. This option overrides the global timeout value set with the tacacs-server timeout command for this server only. The valid timeout range is from 1 to 1000 seconds. Default is 5. Note: You can use this parameter only in the config-tacacs-host sub-mode.
key [0 7] <i>auth-key</i>	(Optional) Specifies an authentication and encryption key shared between the AAA server and the TACACS+ server. The TACACS+ packets are encrypted using this key. This key must match the key used by the TACACS+ daemon. Specifying this key overrides the key set by the tacacs-server key command for this server only. (Optional) Entering 0 specifies that an unencrypted (clear-text) key follows. (Optional) Entering 7 specifies that an encrypted key follows. The <i>auth-key</i> argument specifies the unencrypted key between the AAA server and the TACACS+ server. Note: You can use this parameter only in the config-tacacs-host sub-mode.
single-connection	(Optional) Multiplexes all TACACS+ requests to this server over a single TCP connection. By default, a separate connection is used for each session. Note: You can use this parameter only in the config-tacacs-host sub-mode.

single-connection-idle-timeout (Optional) Specifies the single connection idle timeout value, in seconds.
time-in-seconds

The range is:

- 500 to 7200 (prior to Cisco IOS XR Software Release 7.4.1/Release 7.3.2/Release 6.8.1)
- 5 to 7200 (from Cisco IOS XR Software Release 7.4.1/Release 7.3.2/Release 6.8.1, and later)

Command Default

No TACACS+ host is specified.

The *port-name* argument, if not specified, defaults to the standard port 49.

The *seconds* argument, if not specified, defaults to 5 seconds.

Single connection idle timeout is not set, by default.

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 5.3.0	IPv6 support is introduced on this command.
Release 6.6.3	This command was modified to include single-connection-idle-timeout option.
Release 6.8.1	This command was modified for 32-bit Cisco IOS XR routers to include these: <ul style="list-style-type: none"> • holddown-time option • modified the range for single-connection-idle-timeout parameter.
Release 7.3.2	This command was modified for 64-bit Cisco IOS XR routers to change the range for single-connection-idle-timeout parameter.
Release 7.4.1	This command was modified for Cisco IOS XR 64-bit platforms to include holddown-time option.

Usage Guidelines

You can use multiple **tacacs-server host** commands to specify additional hosts. Cisco IOS XR software searches for hosts in the order in which you specify them.

For details on TACACS+ hold-down timer, see the **holddown-time** command.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to specify a TACACS+ host with the IP address 209.165.200.226:

```
RP/0/RSP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RSP0/CPU0:router(config-tacacs-host)#
```

The following example shows that the default values from the **tacacs-server host** command are displayed from the **show run** command:

```
RP/0/RSP0/CPU0:router# show run

Building configuration...
!! Last configuration change at 13:51:56 UTC Mon Nov 14 2005 by lab
!
tacacs-server host 209.165.200.226 port 49
  timeout 5
!
```

The following example shows how to specify that the router consult the TACACS+ server host named host1 on port number 51. The timeout value for requests on this connection is 30 seconds; the encryption key is a_secret.

```
RP/0/RSP0/CPU0:router(config)# tacacs-server host host1 port 51
RP/0/RSP0/CPU0:router(config-tacacs-host)# timeout 30
RP/0/RSP0/CPU0:router(config-tacacs-host)# key a_secret
```

Related Commands

Command	Description
key (TACACS+), on page 69	Specifies an authentication and encryption key shared between the AAA server and the TACACS+ server.
single-connection, on page 154	Multiplexes all TACACS+ requests to this server over a single TCP connection.
single-connection-idle-timeout, on page 155	Sets the idle timeout value for the single TCP connection to the TACACS+ server.
tacacs-server key, on page 161	Globally sets the authentication encryption key used for all TACACS+ communications between the router and the TACACS+ daemon.
tacacs-server timeout, on page 163	Globally sets the interval that the router waits for a server host to reply.
timeout (TACACS+), on page 174	Specifies a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server.

tacacs-server key

To set the authentication encryption key used for all TACACS+ communications between the router and the TACACS+ daemon, use the **tacacs-server key** command in Global Configuration mode. To disable the key, use the **no** form of this command.

```
tacacs-server key {0 clear-text-key | 7 encrypted-keyauth-key}
```

Syntax Description	
0 <i>clear-text-key</i>	Specifies an unencrypted (cleartext) shared key.
7 <i>encrypted-key</i>	Specifies an encrypted shared key.
<i>auth-key</i>	Specifies the unencrypted key between the AAA server and the TACACS+ server.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines The key name entered must match the key used on the TACACS+ daemon. The key name applies to all servers that have no individual keys specified. All leading spaces are ignored; spaces within and after the key are not. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks themselves are part of the key.

The key name is valid only when the following guidelines are followed:

- The *clear-text-key* argument must be followed by the **0** keyword.
- The *encrypted-key* argument must be followed by the **7** keyword.

The TACACS server key is used only if no key is configured for an individual TACACS server. Keys configured for an individual TACACS server always override this global key configuration.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example sets the authentication and encryption key to key1:

```
RP/0/RSP0/CPU0:router (config) # tacacs-server key key1
```

Related Commands

Command	Description
key (TACACS+), on page 69	Specifies an authentication and encryption key shared between the AAA server and the TACACS+ server.
tacacs-server host, on page 158	Specifies a TACACS+ host.

tacacs-server timeout

To set the interval that the server waits for a server host to reply, use the **tacacs-server timeout** command in Global Configuration mode. To restore the default, use the **no** form of this command.

tacacs-server timeout *seconds*

Syntax Description	<i>seconds</i> Integer that specifies the timeout interval (in seconds) from 1 to 1000.
---------------------------	---

Command Default	5 seconds
------------------------	-----------

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	The TACACS+ server timeout is used only if no timeout is configured for an individual TACACS+ server. Timeout intervals configured for an individual TACACS+ server always override this global timeout configuration.
-------------------------	--

Task ID	Task ID	Operations
	aaa	read, write

Examples	The following example shows the interval timer being changed to 10 seconds:
-----------------	---

```
RP/0/RSP0/CPU0:router(config)# tacacs-server timeout 10
```

Related Commands	Command	Description
	tacacs-server host, on page 158	Specifies a TACACS+ host.

tacacs-server ipv4

To set the Differentiated Services Code Point (DSCP), which is represented by the first six bits in the Type of Service (ToS) byte of the IP header, use the **tacacs-server ipv4** command in Global Configuration mode.

tacacs-server ipv4 dscp *dscp-value*

Syntax Description	
ipv4	Specifies the dscp bit for the IPv4 packets.
dscp	Sets the DSCP in the IP header.
<i>dscp-value</i>	Specifies the options for setting the value of DSCP. The available options are: <ul style="list-style-type: none"> • <0-63> Differentiated services codepoint value • af11 Match packets with AF11 dscp (001010) • af12 Match packets with AF12 dscp (001100) • af13 Match packets with AF13 dscp (001110) • af21 Match packets with AF21 dscp (010010) • af22 Match packets with AF22 dscp (010100) • af23 Match packets with AF23 dscp (010110) • af31 Match packets with AF31 dscp (011010) • af32 Match packets with AF32 dscp (011100) • af33 Match packets with AF33 dscp (011110) • af41 Match packets with AF41 dscp (100010) • af42 Match packets with AF42 dscp (100100) • af43 Match packets with AF43 dscp (100110) • cs1 Match packets with CS1(precedence 1) dscp (001000) • cs2 Match packets with CS2(precedence 2) dscp (010000) • cs3 Match packets with CS3(precedence 3) dscp (011000) • cs4 Match packets with CS4(precedence 4) dscp (100000) • cs5 Match packets with CS5(precedence 5) dscp (101000) • cs6 Match packets with CS6(precedence 6) dscp (110000) • cs7 Match packets with CS7(precedence 7) dscp (111000) • default Match packets with default dscp (000000) • ef Match packets with EF dscp (101110)

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	aaa	read, write

Examples The following example sets the DSCP value to Assured Forwarding (AF)11:

```
RP/0/RSP0/CPU0:router(config)# tacacs-server ipv4 dscp af11
```

tacacs source-interface

To specify the source IP address of a selected interface for all outgoing TACACS+ packets, use the **tacacs source-interface** command in Global Configuration mode. To disable use of the specified interface IP address, use the **no** form of this command.

tacacs source-interface *type path-id* [**vrf** *vrf-id*]

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>path-id</i>	Physical interface or virtual interface.
Note	Use the show interfaces command in EXEC mode to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.
vrf <i>vrf-id</i>	Specifies the name of the assigned VRF.

Command Default

If a specific source interface is not configured, or the interface is down or does not have an IP address configured, the system selects an IP address.

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 4.1.0	The vrf keyword was added.

Usage Guidelines

Use the **tacacs source-interface** command to set the IP address of the specified interface for all outgoing TACACS+ packets. This address is used as long as the interface is in the *up* state. In this way, the TACACS+ server can use one IP address entry associated with the network access client instead of maintaining a list of all IP addresses.

This command is especially useful in cases where the router has many interfaces and you want to ensure that all TACACS+ packets from a particular router have the same IP address.

When the specified interface does not have an IP address or is in a *down* state, TACACS+ behaves as if no source interface configuration is used.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to set the IP address of the specified interface for all outgoing TACACS+ packets:

```
RP/0/RSP0/CPU0:router# configure  
RP/0/RSP0/CPU0:router(config)# tacacs source-interface GigabitEthernet 0/0/0/29 vrf abc
```

Related Commands

Command	Description
aaa group server tacacs+, on page 34	Groups different server hosts into distinct lists and distinct methods.

task

To add a task ID to a task group, use the **task** command in task group configuration mode. To remove a task ID from a task group, use the **no** form of this command.

task {**read** | **write** | **execute** | **debug**} *taskid-name*

Syntax Description

read	Enables read-only privileges for the named task ID.
write	Enables write privileges for the named task ID. The term “write” implies read also.
execute	Enables execute privileges for the named task ID.
debug	Enables debug privileges for the named task ID.
<i>taskid-name</i>	Name of the task ID.

Command Default

No task IDs are assigned to a newly created task group.

Command Modes

Task group configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **task** command in task group configuration mode. To access task group configuration mode, use the **taskgroup** command in global configuration mode.

Task IDs are the base of command authorization. Only users who have the required permissions can execute a particular command on the router. To execute a command, the user must be part of a user group that consists of task group(s) that includes required task IDs and privileges. Cisco IOS XR software supports multiple task IDs. For example, **aaa**, **config-services**, **crypto**, **system**, and so on. To see the list of task IDs available for the user, use the **show user tasks** command.

Likewise, all commands are associated with one or more task IDs, and their corresponding operations (such as **read**, **write**, **execute**, and **debug**) that denote the permissions required to execute those commands. You can use the **describe** command to know the task ID and permissions that are required to execute a particular command.

For example, the following output shows that the user needs **aaa** task ID with **read** and **write** permission to execute the **show run aaa** command. So, users can execute this command if they belong to a user group associated with a task group that includes this **aaa** task ID having read and write privileges.

```
Router# describe show run aaa
The command is defined in aaa_cmds.parser

User needs ALL of the following taskids:

  aaa (READ WRITE) ----->

It will take the following actions:
Wed Mar 16 07:58:01.451 UTC
```



```

    Spawn the process:
      nvgen "-c" "-q" "gl/aaa/"
Router#

```

Root users (users in **root-lr** or **root-system** user group) have all task IDs, and hence will be able to execute all commands. Also, certain commands might not require any task ID as such to execute it. So, all users will have permission to execute such commands. If you do not have the required permission to execute a command, the command authorization fails. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

A few other examples that describe the commands to list the task ID:

```

Router#describe show interfaces
The command is defined in show_interface.parser

```

```

show_interface.parser
User needs ALL of the following taskids:

```

```

    interface (READ)----->

```

```

It will take the following actions:

```

```

Thu Mar 17 06:42:08.264 UTC

```

```

    Spawn the process:

```

```

      show_interface "-a"

```

```

Router#

```

```

Router(config)#describe ssh server
The command is defined in ssh.parser

```

```

ssh.parser
User needs ALL of the following taskids:

```

```

    crypto (READ WRITE) ----->

```

```

It will take the following actions:

```

```

    Create/Set the configuration item:

```

```

      Path: gl/crypto/ssh/server/sshd/vrf/default

```

```

      Value: packed[ 0x1 <string> <string> ]

```

```

Router(config)#

```

For more details, see *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to enable execute privileges for the config-services task ID and associate that task ID with the task group named taskgroup1:

```

RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# taskgroup taskgroup1
RP/0/RSP0/CPU0:router(config-tg)# task execute config-services

```

Related Commands

Command	Description
taskgroup, on page 171	Configures a task group to be associated with a set of task IDs.

taskgroup

To configure a task group to be associated with a set of task IDs, and to enter task group configuration mode, use the **taskgroup** command in Global Configuration mode. To delete a task group, use the **no** form of this command.

```
taskgroup taskgroup-name [{description string | task {read | write | execute | debug} taskid-name | inherit taskgroup taskgroup-name}]
```

Syntax Description	
<i>taskgroup-name</i>	Name of a particular task group.
description	(Optional) Enables you to create a description for the named task group.
<i>string</i>	(Optional) Character string used for the task group description.
task	(Optional) Specifies that a task ID is to be associated with the named task group.
read	(Optional) Specifies that the named task ID permits read access only.
write	(Optional) Specifies that the named task ID permits read and write access only.
execute	(Optional) Specifies that the named task ID permits execute access.
debug	(Optional) Specifies that the named task ID permits debug access only.
<i>taskid-name</i>	(Optional) Name of a task: the task ID.
inherit taskgroup	(Optional) Copies permissions from the named task group.
<i>taskgroup-name</i>	(Optional) Name of the task group from which permissions are to be inherited.

Command Default Five predefined user groups are available by default.

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines Task groups are configured with a set of task IDs for each action type. Deleting a task group that is still referenced in the system results in a warning and rejection of the deletion. For more details on task IDs, see the Usage Guidelines section of the **task** command.

You can use the **show user group** command in Global Configuration mode to know the group(s) that the current user is part of. Similarly, you can use the **show user all** to know the group or task information (such as username, groups, authentication method, task IDs, and so on) of the current user.

From global configuration mode, you can display all the configured task groups. However, you cannot display all the configured task groups in taskgroup configuration mode.

Entering the **taskgroup** command with no keywords or arguments enters task group configuration mode, in which you can use the **description**, **inherit**, **show**, and **task** commands.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example assigns read bgp permission to the task group named alpha:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# taskgroup alpha
RP/0/RSP0/CPU0:router(config-tg)# task read bgp
```

Related Commands

Command	Description
description (AAA), on page 58	Creates a task group description in task configuration mode.
task, on page 168	Adds a task ID to a task group.

timeout (RADIUS)

To specify the number of seconds the router waits for the RADIUS server to reply before retransmitting, use the **timeout** command in RADIUS server-group private configuration mode. To disable this command and return to the default timeout value of 5 seconds, use the **no** form of this command.

timeout *seconds*

Syntax Description	<i>seconds</i> Timeout value (in seconds). The range is from 1 to 1000. If no timeout is specified, the global value is used.
---------------------------	---

Command Default	<i>seconds: 5</i>
------------------------	-------------------

Command Modes	RADIUS server-group private configuration
----------------------	---

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task	Operations
	aaa	read, write

Examples The following example shows how to set the number of seconds for the timeout value:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server radius group1
RP/0/RSP0/CPU0:router(config-sg-radius)# server-private 10.1.1.1 auth-port 300
RP/0/RSP0/CPU0:router(config-sg-radius-private)# timeout 500
```

Related Commands	Command	Description
	radius-server timeout(BNG), on page 93	Sets the interval for which a router waits for a server host to reply before timing out.
	retransmit (RADIUS), on page 100	Specifies the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly.
	server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.

timeout (TACACS+)

To specify a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server, use the **timeout** (TACACS+) command in TACACS host configuration mode. To disable this command and return to the default timeout value of 5 seconds, use the **no** form of this command.

timeout *seconds*

Syntax Description	<i>seconds</i> Timeout value (in seconds). The range is from 1 to 1000. If no timeout is specified, the global value is used.
---------------------------	---

Command Default	<i>seconds</i> : 5
------------------------	--------------------

Command Modes	TACACS host configuration
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	The timeout (TACACS+) command overrides the global timeout value set with the tacacs-server timeout command for this server only.
-------------------------	---

Task ID	Task ID	Operations
	aaa	read, write

Examples	The following example shows how to set the number of seconds for the timeout value:
-----------------	---

```
RP/0/RSP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RSP0/CPU0:router(config-tacacs-host)# timeout 500
```

Related Commands	Command	Description
	tacacs-server host, on page 158	Specifies a TACACS+ host.

timeout login response

To set the interval that the server waits for a reply to a login, use the **timeout login response** command in line template configuration mode. To restore the default, use the **no** form of this command.

timeout login response *seconds*

Syntax Description	<i>seconds</i> Integer that specifies the timeout interval (in seconds) from 0 to 300.
---------------------------	--

Command Default	<i>seconds</i> : 30
------------------------	---------------------

Command Modes	Line template configuration
----------------------	-----------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	Use the timeout login response command in line template configuration mode to set the timeout value. This timeout value applies to all terminal lines to which the entered line template is applied. This timeout value cannot be applied to the line console. After the timeout value has expired, the user is prompted again. The retry is allowed three times.
-------------------------	--

Task ID	Task ID	Operations
	aaa	read, write

Examples	The following example shows how to change the interval timer to 20 seconds:
-----------------	---

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# line template alpha
RP/0/RSP0/CPU0:router(config-line)# timeout login response 20
```

Related Commands	Command	Description
	login authentication, on page 70	Enables AAA authentication for logging in.

usergroup

To configure a user group and associate it with a set of task groups, and to enter user group configuration mode, use the **usergroup** command in Global Configuration mode. To delete a user group, or to delete a task-group association with the specified user group, use the **no** form of this command.

usergroup *usergroup-name*

Syntax Description	<i>usergroup-name</i> Name of the user group. The <i>usergroup-name</i> argument can be only one word. Spaces and quotation marks are not allowed.
---------------------------	--

Command Default	Five predefined user groups are available by default.
------------------------	---

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	User groups are configured with the command parameters for a set of users, such as task groups. You can remove specific user groups by using the no form of the usergroup command. You can remove the user group itself by using the no form of the command without giving any parameters. Deleting a user group that is still referenced in the system results in a warning and a rejection of the deletion.
-------------------------	--

Use the [inherit usergroup, on page 65](#) command to copy permissions from other user groups. The user group is inherited by the parent group and forms a union of all task IDs specified in those groups. Circular inclusions are detected and rejected. User groups cannot inherit properties from predefined groups, such as root-system and owner-sdr.

From global configuration mode, you can display all the configured user groups. However, you cannot display all the configured user groups in usergroup configuration mode.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to add permissions from the user group beta to the user group alpha:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# usergroup alpha
RP/0/RSP0/CPU0:router(config-ug)# inherit usergroup beta
```


Related Commands

Command	Description
description (AAA), on page 58	Creates a description of a task group during configuration.
inherit usergroup, on page 65	Enables a user group to derive permissions from another user group.
taskgroup, on page 171	Configures a task group to be associated with a set of task IDs.

username

To configure a new user with a username, establish a password, associate a password policy with the user, grant permissions for the user, and to enter username configuration mode, use the **username** command in Global Configuration mode or Admin Configuration mode. To delete a user from the database, use the **no** form of this command.

```
username name [{ group name | [ password-policy name ] { password | masked-password } [ type ] password | { secret | masked-secret } [{ type | 0 [ enc-type type ] secret | login-history { enable | disable } } ] } ]
no username name [{ group name | password | masked-password | secret | masked-secret | password-policy name [ masked-password [ type ] password ] | login-history { enable | disable } }
```

Syntax Description

<i>name</i>	Name of the user. The <i>name</i> argument can be only one word. Spaces and quotation marks are not allowed. The allowed range for a user-defined username is 2-253 characters.
group <i>name</i>	Enables a user to be associated with a user group, as defined with the usergroup command.
policy <i>name</i>	Configures a password policy that is common to user password and secret.
password-policy <i>name</i>	(Optional) Specifies the password policy for cleartext and Type 7 password authentication.
password	Enables a password to be created for the specified user.
masked-password	Enables a password to be created for the specified user. When you key in the password, it is not visible on the screen.

<i>type password</i>	<p>Specifies the password type and the password to be keyed in.</p> <p>Enter 0 or 7 for the <i>type</i> argument. 0 specifies a cleartext password, and 7 specifies a Type 7 encrypted password.</p> <p>If Type 7 encryption is enabled with the password keyword, the password is not visible to the user. The password can be up to 253 characters in length.</p> <p>(Optional) <i>type</i> argument</p>
secret	Enables a secret to be created for the specified user.
masked-secret	Enables a secret to be created for the specified user. When you key in the secret, it is not visible on the screen.
<i>type secret</i>	<p>Specifies the secret type and the secret to be keyed in.</p> <p>Enter 0, or enter 5, 8, 9, or 10, for the <i>type</i> argument. Details:</p> <ul style="list-style-type: none"> • 0 specifies a cleartext secret that will be encrypted for use. • 5 specifies a Type 5 password that uses MD5 hashing algorithm. • 8 specifies a Type 8 password that uses SHA256 hashing algorithm. • 9 specifies a Type 9 password that uses scrypthashing algorithm. • 10 specifies a Type 10 password that uses SHA512 hashing algorithm. <p>Note Type 10 is only available for Cisco IOS XR 64 bit platforms.</p> <p>(Optional) <i>type</i> argument.</p>

0 enc-type *type secret*

Specifies that you enter a cleartext secret to be encrypted by a specified encryption method.

- 0 specifies that you should enter a cleartext secret.
- **enc-type** specifies that you enter 5, 8, 9, or 10, for the *type* argument.
- Enter the cleartext secret for the *secret* argument.

(Optional) **enc-type** *type*
keyword-argument combination.

login-history { **enable** | **disable** }

Enables or disables the login history for a specified user.

Command Default

No usernames are defined in the system.

Command Modes

Global Configuration mode

Admin Configuration mode

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 6.2.1	Added support for password-policy , as part of AAA password security for FIPS compliance.
Release 6.3.1	Added the support for Type 8 (SHA256) and Type 9 (scrypt) encryption for secret configuration on classic Cisco IOS XR (32-bit) operating system.
Release 7.0.1	Extended the support for Type 8 (SHA256) and Type 9 (scrypt) encryption for secret configuration on Cisco IOS XR 64-bit operating system as well.
Release 7.0.1	Added support for Type 10 (SHA512) encryption for secret configuration only on Cisco IOS XR 64-bit operating system.
Release 7.0.1	The login-history keyword was added.
Release 7.3.1	Password Masking feature options (masked-password and masked-secret) were added. When you key in a password or secret, it is not displayed on the screen

Usage Guidelines
**Note**

- A user is never allowed to have cisco-support privileges as the only group.
- The Type 10 for the **secret** configuration is available only on Cisco IOS XR 64-bit operating system.
- From Release 7.0.1 and later, Type 10 (SHA512) is applied as the default type for the **secret** configuration. Prior to this, Type 5 (MD5) was the default one.
- The support for Type 8 and 9 for the secret configuration on Cisco IOS XR 64-bit operating system is available only from Release 7.0.1 and later.

Use the **username** command to identify the user and enter username configuration mode. Password and user group assignments can be made from either Global Configuration mode or username configuration submode. Permissions (task IDs) are assigned by associating the user with one or more defined user groups.

From global configuration mode, you can display all the configured usernames. However, you cannot display all the configured usernames in username configuration mode.

Each user is identified by a username that is unique across the administrative domain. Each user should be made a member of at least one user group. Deleting a user group may orphan the users associated with that group. The AAA server authenticates orphaned users, but most commands are not authorized.

The **username** command is associated with a particular user for local login authentication by default. Alternatively, a user and password can be configured in the database of the TACACS+ server for TACACS+ login authentication. For more information, see the description of the [aaa authentication](#), on page 15 command.

The predefined group root-system may be specified only by root-system users while administration is configured.

**Note**

To enable the local networking device to respond to remote Challenge Handshake Authentication Protocol (CHAP) challenges, one **username** command entry must be the same as the hostname entry that has already been assigned to the other networking device.

For more details on defining a password policy, see the **aaa password-policy** command. The AAA password security policy feature works as such for Cisco IOS XR platforms. Whereas, it is supported only on XR VM, for Cisco IOS XR 64 bit platforms.

Password Masking guidelines for various command forms

- **username** *name* **password** *type password*

username *name* **masked-password** *type password*

Enter 0 or 7 for the *type* argument. 0 specifies a cleartext password, and 7 specifies a Type 7 encrypted password.

- **secret** *type secret*

masked-secret *type secret*

Enter 0, or enter 5, 8, 9, or 10, for the *type* argument. 0 specifies a cleartext secret, and 5, 8, 9, and 10 specify a Type 5, Type 8, Type 9, and Type 10 secret, respectively.

- **secret 0 enc-type type secret**

masked-secret 0 enc-type type secret

Enter 5, 8, 9, or 10, for the *type* argument.

- **masked-password type password**

masked-secret type secret

After specifying the password encryption type, press **Enter** or **return** on your keyboard. The password/secret option appears in the next line. Example:

```
Router(config)# masked-secret 10
```

```
Enter secret:
```

```
Re-enter secret:
```

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows the commands available after executing the **username** command:

```
Router# config
Router(config)# username user1
Router(config-un)# ?
```

clear	Clear the uncommitted configuration
commit	Commit the configuration changes to running
describe	Describe a command without taking real actions
do	Run an exec command
exit	Exit from this submode
group	User group in which this user will be a member of
login-history	Option to set whether to display previous login details
no	Negate a command or set its defaults
password	Specify the password for the user
password-policy	Specify the password policy for the user
pwd	Commands used to reach current submode
root	Exit to the global configuration mode
secret	Specify the secure password for the user
show	Show contents of configuration

The following example shows how to establish the clear-text password *password1* for the user name *user1*:

```
Router# configure
Router(config)# username user1
Router(config-un)# password 0 password1
```

The following example shows how to establish a secured secret for the user *user1* in administration configuration mode:

```
Router(admin-config)# username user1
Router(admin-config-un)# secret 0 lab
Router(admin-config-un)# commit
Router(admin-config)# do show run username
username user1 secret 5 $1$QB03$3H29k3ZT.0PMQ8GQQKXCF0
!
```

This example shows how to apply a AAA password policy for a user:

```
Router# config
Router(config)# username user1 password-policy test-policy password abc
```

The following example shows how to configure a Type 8 (SHA256) password for the user, *user8*. You can also see the examples and usage of the [secret, on page 101](#) command.

You can specify Type as '8' under the **secret** keyword, to explicitly configure Type 8 password.

```
Router#configure
Router(config)#username user8 secret 8
$8$ZYKGL1dZIw73D1$IUWJOqTLoMyExhsNKoL5vMtvCOYguM5ajXf4uGeQj6I
Router(config-un)#commit
```

This example shows how to configure Type 9 password:

```
Router#configure
Router(config)#username user9 secret 9
$9$/rIQ1LB3rplRBL$oS2fLWKfYH6B/kApkkkXmIqbPAHPrZkPEoh3WqGbvWQ
Router(config-un)#commit
```

Similarly, this example shows how to configure Type 10 password :

```
Router#configure
Router(config)#username user10 secret 10
$6$9UvJidvsTEqkAPU$3CL1Ei/F.E4v/Hi.UaqLwX8UsSEr9ApG6c5pzhMmZtgW4jObAQ7meAwyhu5VM/aRFJqe/jxZG17h6xPrvJWF1
Router(config-un)#commit
```

This example shows how to specify the Type 10 password in System Admin VM:

```
Router#admin
sysadmin-vm:0_RP0# configure
sysadmin-vm:0_RP0(config)# aaa authentication users user user10 password testpassword
sysadmin-vm:0_RP0(config)# commit
```

This example shows how to enable login-history for user1:

```
Router(config)# username user1 login-history enable
```

This example shows login history information for a successful and an unsuccessful login from user1:

```

Username: user1
Password:
RP/0/RSP0/CPU0:Aug 21 17:20:35.566 UTC: exec[68609]: %SECURITY-LOGIN-4-AUTHEN_FAILED :
Failed authentication attempt by user '<unknown>' from 'console' on 'con0_RSP0_CPU0'

```

User Access Verification

```

Username: user1
Password:
User user1 failed to login 1 time(s)
Most recent Failure Fri Aug 21 2020 17:20:35 UTC
to con0_RSP0_CPU0 from console

```

```

User user1 last logged in successfully Fri Aug 21 2020 17:20:03 UTC
to con0_RSP0_CPU0 from console

```

Password Masking Examples

The following example shows how to enable password masking for a cleartext password entry:

In this example, for user us3, a cleartext password is entered.

```
Router(config)# username us3 masked-password 0
```

```
Enter password:
Re-enter password:

```

```
Router(config)#commit
```

In the **show** command output, you can see the encrypted password:

```
Router# show run aaa
..
username us3
password 7 105A1D0D

```

The encrypted password 105A1D0D is entered in the **Enter password:** and **Re-enter password:** fields, for Type 7 password encryption:

```
Router(config)# username us3 masked-password 7
```

```
Enter password:
Re-enter password:

```

```
Router(config)#commit
```

If there is a password mismatch between the two entries, an error message is displayed.

The following example shows how to enable password masking for a AAA password policy:

In this example, for user us6, a cleartext password is entered.

```
Router(config)# aaa password-policy security
Router(config)# username us6 password-policy security masked-password 0

```

```
Enter password:
Re-enter password:

```

```
Router(config)#commit
```

In the **show** command output, you can see the encrypted password.


```

Router# show run aaa
..

aaa password-policy security
..
username us6
  password-policy security password 7 0835585A

```

The encrypted password 0835585A is entered in the **Enter password:** and **Re-enter password:** fields for Type 7 password encryption.

```

Router(config)# username us6 password-policy test-policy masked-password 7

Enter password:
Re-enter password:

Router(config)#commit

```

Related Commands

Command	Description
aaa authentication , on page 15	Defines a method list for authentication.
aaa password-policy, on page 37	Defines the FIPS-compliant AAA password security policy
group (AAA), on page 59	Adds a user to a group.
password (AAA), on page 73	Creates a login password for a user.
secret, on page 101	Creates a secure login secret for a user.

users group

To associate a user group and its privileges with a line, use the **users group** command in line template configuration mode. To delete a user group association with a line, use the **no** form of this command.

users group {*usergroup-name* | **cisco-support** | **netadmin** | **operator** | **root-lr** | **root-system** | **sysadmin**}

Syntax Description

<i>usergroup-name</i>	Name of the user group. The <i>usergroup-name</i> argument can be only one word. Spaces and quotation marks are not allowed.
cisco-support	Specifies that users logging in through the line are given Cisco support personnel privileges.
netadmin	Specifies that users logging in through the line are given network administrator privileges.
operator	Specifies that users logging in through the line are given operator privileges.
root-lr	Specifies that users logging in through the line are given root logical router (LR) privileges.
root-system	Specifies that users logging in through the line are given root system privileges.
serviceadmin	Specifies that users logging in through the line are given service administrator group privileges.
sysadmin	Specifies that users logging in through the line are given system administrator privileges.

Command Default

None

Command Modes

Line template configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **users group** command to enable a user group and its privileges to be associated with a line, meaning that users logging in through the line are given the privileges of the particular user group.

Task ID

Task ID	Operations
aaa	read, write

Examples

In the following example, if a vty-pool is created with line template *vt*, users logging in through vty are given operator privileges:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa authen login vty-authen line
RP/0/RSP0/CPU0:router(config)# commit
RP/0/RSP0/CPU0:router(config)# line template vty
```

```
RP/0/RSP0/CPU0:router(config-line)# users group operator  
RP/0/RSP0/CPU0:router(config-line)# login authentication
```

vrf (RADIUS)

To configure the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group, use the **vrf** command in RADIUS server-group configuration mode. To enable server groups to use the global (default) routing table, use the **no** form of this command.

vrf *vrf-name*

Syntax Description

vrf-name Name assigned to a VRF.

Command Default

The default VRF is used.

Command Modes

RADIUS server-group configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **vrf** command to specify a VRF for an AAA RADIUS server group and enable dial-up users to use AAA servers in different routing domains.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to use the **vrf** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server radius group1
RP/0/RSP0/CPU0:router(config-sg-radius)# vrf vrf1
```

Related Commands

Command	Description
radius source-interface(BNG), on page 96	Forces RADIUS to use the IP address of a specified interface or subinterface for all outgoing RADIUS packets.
server-private (RADIUS), on page 107	Configures the IP address of the private RADIUS server for the group server.

vrf (TACACS+)

To configure the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA TACACS+ server group, use the **vrf** command in TACACS+ server-group configuration mode. To enable server groups to use the global (default) routing table, use the **no** form of this command.

vrf *vrf-name*

Syntax Description

vrf-name Name assigned to a VRF.

Command Default

The default VRF is used.

Command Modes

TACACS+ server-group configuration

Command History

Release	Modification
Release 4.1.0	This command was introduced.

Usage Guidelines

Use the **vrf** command to specify a VRF for an AAA TACACS+ server group and enable dial-up users to use AAA servers in different routing domains.

Task ID

Task ID	Operations
aaa	read, write

Examples

This example shows how to use the **vrf** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# aaa group server tacacs+ myserver
RP/0/RSP0/CPU0:router(config-sg-tacacs+)# server 9.27.10.6
RP/0/RSP0/CPU0:router(config-sg-tacacs+)# vrf abc
```

Related Commands

Command	Description
aaa group server tacacs+, on page 34	Groups different TACACS+ server hosts into distinct lists and distinct methods.
server (TACACS+), on page 106	Specifies the source IP address of a selected interface for all outgoing TACACS+ packets.
server-private (TACACS+), on page 110	Configures the IP address of the private TACACS+ server for the group server.

