



# Configuring Ethernet Connectivity Fault Management in a Service Provider Network

Ethernet Connectivity Fault Management (CFM) is an end-to-end per-service-instance Ethernet layer operations, administration, and maintenance (OAM) protocol. It includes proactive connectivity monitoring, fault verification, and fault isolation for large Ethernet metropolitan-area networks (MANs) and WANs.

The advent of Ethernet as a MAN and WAN technology imposes a new set of OAM requirements on Ethernet's traditional operations, which were centered on enterprise networks only. The expansion of Ethernet technology into the domain of service providers, where networks are substantially larger and more complex than enterprise networks and the user base is wider, makes operational management of link uptime crucial. More importantly, the timeliness in isolating and responding to a failure becomes mandatory for normal day-to-day operations, and OAM translates directly to the competitiveness of the service provider.



## Note

As an alternative, CFM can be configured over an Ethernet flow point (EFP) interface by using the cross connect functionality. For more information about this alternative, see [Configuring the CFM over EFP Interface with Cross Connect Feature](#).

- [Prerequisites for Configuring Ethernet CFM in a Service Provider Network, on page 1](#)
- [Restrictions for Configuring Ethernet CFM in a Service Provider Network, on page 2](#)
- [CFM Configuration over EFP Interface with Cross Connect Feature, on page 2](#)
- [Information About Configuring Ethernet CFM in a Service Provider Network, on page 3](#)
- [How to Set Up Ethernet CFM in a Service Provider Network, on page 12](#)
- [Troubleshooting CFM Features, on page 27](#)
- [Additional References, on page 29](#)
- [Glossary, on page 29](#)

## Prerequisites for Configuring Ethernet CFM in a Service Provider Network

### Business Requirements

- Network topology and network administration have been evaluated.

- Business and service policies have been established.

## Restrictions for Configuring Ethernet CFM in a Service Provider Network

- CFM loopback messages will not be confined within a maintenance domain according to their maintenance level. The impact of not having CFM loopback messages confined to their maintenance levels occurs at these levels:
  - Architecture—CFM layering is violated for loopback messages.
  - Deployment—A user may potentially misconfigure a network and have loopback messages succeed.
  - Security—A malicious device that recognizes devices' MAC addresses and levels may potentially explore a network topology that should be transparent.
- CFM is not fully supported on a Multiprotocol Label Switching (MPLS) provider edge (PE) device. There is no interaction between CFM and an Ethernet over MPLS (EoMPLS) pseudowire.
- CFM configuration is not supported on an EtherChannel in FastEthernet Channel (FEC) mode.
- QinQ encapsulation is not supported on the Cisco ASR 1000 Series Aggregation Services Router for CFM for routed subinterfaces.
- The client hog message is seen with scaled hardware offloaded CFM sessions for both local and remote MEP statistics.

## CFM Configuration over EFP Interface with Cross Connect Feature

Ethernet Connectivity Fault Management (CFM) is an end-to-end per-service-instance Ethernet layer OAM protocol that includes proactive connectivity monitoring, fault verification, and fault isolation. Currently, Ethernet CFM supports Up facing and Down facing Maintenance Endpoints (MEPs).

For information on Ethernet Connectivity Fault Management, see [http://www.cisco.com/en/US/docs/ios/12\\_2sr/12\\_2sra/feature/guide/srethcfm.html](http://www.cisco.com/en/US/docs/ios/12_2sr/12_2sra/feature/guide/srethcfm.html).

The CFM over EFP Interface with xconnect feature allows you to:

- Forward continuity check messages (CCM) towards the core over cross connect pseudowires.
- Receive CFM messages from the core.
- Forward CFM messages to the access side (after Continuity Check Database [CCDB] based on maintenance point [MP] filtering rules).

## Restrictions for CFM Configuration over EFP Interface with Cross Connect Feature

### RSP2 Module

- Configuration of CCM sampling rate for the offloaded sessions using **offload sampling** command is not supported.
- Parsing multiple organizational-specific Type Length Value (TLV) is not supported.
- Priority-tagged encapsulation type is not supported.
- Error-objects are seen on active and standby RSP after reboot when CFM is globally disabled and MIP filter is enabled.
- CFM Traceroute with (forwarding database) FDB only option is not supported on Up MEP.
- CFM CC/Ping/Traceroute for Down MEP, CFM Ping/Traceroute for Up MEP use the bypass EAID, so these packets cannot be mirrored in the egress direction. Only Up MEP CFM CC can be mirrored.
- CFM Traceroute to expired RMEPs are flooded only to port where it was last learned. CFM Traceroute for new RMEPs are not initiated on their own. However ping to both expired and new RMEPs are flooded to all EFPs in the BD.

### RSP3 Module

- L2VPN VC statistics are not supported on the RSP3 module.

## Information About Configuring Ethernet CFM in a Service Provider Network

### Ethernet CFM

Ethernet CFM is an end-to-end per-service-instance Ethernet layer OAM protocol that includes proactive connectivity monitoring, fault verification, and fault isolation. End to end can be PE to PE or CE to CE. A service can be identified as a service provider VLAN (S-VLAN) or an EVC service.

Being an end-to-end technology is the distinction between CFM and other metro-Ethernet OAM protocols. For example, MPLS, ATM, and SONET OAM help in debugging Ethernet wires but are not always end-to-end. 802.3ah OAM is a single-hop and per-physical-wire protocol. It is not end to end or service aware.


Troubleshooting carrier networks offering Ethernet Layer 2 services is challenging. Customers contract with service providers for end-to-end Ethernet service and service providers may subcontract with operators to provide equipment and networks. Compared to enterprise networks, where Ethernet traditionally has been implemented, these constituent networks belong to distinct organizations or departments, are substantially larger and more complex, and have a wider user base. Ethernet CFM provides a competitive advantage to service providers for which the operational management of link uptime and timeliness in isolating and responding to failures is crucial to daily operations.

## Benefits of Ethernet CFM

- End-to-end service-level OAM technology
- Reduced operating expense for service provider Ethernet networks
- Competitive advantage for service providers
- Supports both distribution and access network environments with the outward facing MEPs enhancement


## Customer Service Instance

A customer service instance is an Ethernet virtual connection (EVC), which is identified by an S-VLAN within an Ethernet island, and is identified by a globally unique service ID. A customer service instance can be point-to-point or multipoint-to-multipoint. The figure below shows two customer service instances. Service Instance Green is point to point; Service Instance Blue is multipoint to multipoint.



## Maintenance Domain

A maintenance domain is a management space for the purpose of managing and administering a network. A domain is owned and operated by a single entity and defined by the set of ports internal to it and at its boundary. The figure below illustrates a typical maintenance domain.




A unique maintenance level in the range of 0 to 7 is assigned to each domain by a network administrator. Levels and domain names are useful for defining the hierarchical relationship that exists among domains. The hierarchical relationship of domains parallels the structure of customer, service provider, and operator. The larger the domain, the higher the level value. For example, a customer domain would be larger than an operator domain. The customer domain may have a maintenance level of 7 and the operator domain may have a maintenance level of 0. Typically, operators would have the smallest domains and customers the largest domains, with service provider domains between them in size. All levels of the hierarchy must operate together.

Domains should not intersect because intersecting would mean management by more than one entity, which is not allowed. Domains may nest or touch but when two domains nest, the outer domain must have a higher maintenance level than the domain nested within it. Nesting maintenance domains is useful in the business model where a service provider contracts with one or more operators to provide Ethernet service to a customer. Each operator would have its own maintenance domain and the service provider would define its domain—a superset of the operator domains. Furthermore, the customer has its own end-to-end domain which is in turn a superset of the service provider domain. Maintenance levels of various nesting domains should be communicated among the administering organizations. For example, one approach would be to have the service provider assign maintenance levels to operators.

CFM exchanges messages and performs operations on a per-domain basis. For example, running CFM at the operator level does not allow discovery of the network by the higher provider and customer levels.

Network designers decide on domains and configurations. The figure below illustrates a hierarchy of operator, service provider, and customer domains and also illustrates touching, intersecting, and nested domains.



## Maintenance Associations and Maintenance Points

A maintenance association (MA) identifies a service that can be uniquely identified within the maintenance domain. The CFM protocol runs within a maintenance association. A maintenance point is a demarcation point on an interface that participates in CFM within a maintenance domain. Maintenance points drop all lower-level frames and forward all higher-level frames. There are two types of maintenance points:

- Maintenance end points (MEPs) are points at the edge of the domain that define the boundaries and confine CFM messages within these boundaries. Outward facing or Down MEPs communicate through the wire side (connected to the port). Inward facing or Up MEPs communicate through the relay function side, not the wire side.

CFM 802.1ag supports up and down per-VLAN MEPs, as well as port MEPs, which are untagged down MEPs that are not associated with a VLAN.

Port MEPs are configured to protect a single hop and used to monitor link state through CFM. If a port MEP is not receiving continuity check messages from its peer (static remote MEP), for a specified interval, the port is put into an operational down state in which only CFM and OAM packets pass through, and all other data and control packets are dropped.

- **Up MEP**—An up MEP sends and receives CFM frames through the relay function. It drops all CFM frames at its level or lower that come from the wire side, except traffic going to the down MEP. For CFM frames from the relay side, it processes the frames at its level and drops frames at a lower level. The MEP transparently forwards all CFM frames at a higher level, regardless of whether they are received from the relay or wire side. If the port on which MEP is configured is blocked by STP, the MEP can still send or receive CFM messages through the relay function. CFM

runs at the provider maintenance level (UPE-to-UPE), specifically with up MEPs at the user network interface (UNI).



---

**Note** The device rate-limits all incoming CFM messages at a fixed rate of 500 frames per second.

---

- **Down MEP**—A down MEP sends and receives CFM frames through the wire connected to the port on which the MEP is configured. It drops all CFM frames at its level or lower that come from the relay side. For CFM frames from the wire side, it processes all CFM frames at its level and drops CFM frames at lower levels except traffic going to the other lower-level down MEP. The MEP transparently forwards all CFM frames at a higher level, regardless of whether they are received from the relay or through the wire.
- Maintenance intermediate points (MIPs) are internal to a domain, not at the boundary, and respond to CFM only when triggered by traceroute and loopback messages. They forward CFM frames received from MEPs and other MIPs, drop all CFM frames at a lower level (if MIP filtering is enabled), and forward all CFM frames at a higher level and at a lower level and regardless of whether they are received from the relay or wire side. When MIP filtering is enabled, the MIP drops CFM frames at a lower level. MIPs also catalog and forward continuity check messages (CCMs), but do not respond to them.

MIP filtering is disabled by default, and you can configure it to be enabled or disabled. When MIP filtering is disabled, all CFM frames are forwarded.

You can manually configure a MIP or configure the device to automatically create a MIP. You can configure a MEP without a MIP. In case of a configuration conflict, manually created MIPs take precedence over automatically created MIPs.

If port on which the MEP is configured is blocked by Spanning-Tree Protocol (STP), the MIP can receive and might respond to CFM messages from both the wire and relay side, but cannot forward any CFM messages.

## Maintenance Point

A maintenance point is a demarcation point on an interface (port) that participates in CFM within a maintenance domain. Maintenance points on device ports act as filters that confine CFM frames within the bounds of a domain by dropping frames that do not belong to the correct level. Maintenance points must be explicitly configured on Cisco devices. Two classes of maintenance points exist, MEPs and MIPs.

## Maintenance Endpoints

Maintenance endpoints (MEPs) have the following characteristics:

- Per maintenance domain (level) and service (S-VLAN or EVC)
- At the edge of a domain, define the boundary
- Within the bounds of a maintenance domain, confine CFM messages
- When configured to do so, proactively transmit Connectivity Fault Management (CFM) continuity check messages (CCMs)
- At the request of an administrator, transmit traceroute and loopback messages

### Inward Facing MEPs

Inward facing means the MEP communicates through the Bridge Relay function and uses the Bridge-Brain MAC address. An inward facing MEP performs the following functions:

- Sends and receives CFM frames at its level through the relay function, not via the wire connected to the port on which the MEP is configured.
- Drops all CFM frames at its level (or lower level) that come from the direction of the wire.
- Processes all CFM frames at its level coming from the direction of the relay function.
- Drops all CFM frames at a lower level coming from the direction of the relay function.
- Transparently forwards all CFM frames at its level or a higher level, independent of whether they come in from the relay function side or the wire side.



#### Note

A MEP of level L (where L is less than 7) requires a MIP of level  $M > L$  on the same port; hence, CFM frames at a level higher than the level of the MEP will be catalogued by this MIP.

- If the port on which the inward MEP is configured is blocked by Spanning-Tree Protocol, the MEP can no longer transmit or receive CFM messages.

### Outward Facing MEPs for Port Channels

Outward facing means that the MEP communicates through the wire. Outward facing MEPs can be configured on port channels (using cross connect functionality). A MIP configuration at a level higher than the level of the outward facing MEP is not required.

Outward facing MEPs on port channels use the Bridge-Brain MAC address of the first member link. When port channel members change, the identities of outward facing MEPs do not have to change.

An outward facing MEP performs the following functions:

- Sends and receives CFM frames at its level via the wire connected to the port where the MEP is configured.
- Drops all CFM frames at its level (or at a lower level) that come from the direction of the relay function.
- Processes all CFM frames at its level coming from the direction of the wire.
- Drops all CFM frames at a lower level coming from the direction of the wire.
- Transparently forwards all CFM frames at levels higher than the level of the outward facing MEP, independent of whether they come in from the relay function side or the wire side.
- If the port on which the outward MEP is configured is blocked by the Spanning-Tree Protocol, the MEP can still transmit and receive CFM messages via the wire.

## Maintenance Intermediate Points

MIPs have the following characteristics:

- Per maintenance domain (level) and for all S-VLANs enabled or allowed on a port.
- Internal to a domain, not at the boundary.




- CFM frames received from MEPs and other MIPs are cataloged and forwarded, using both the wire and the relay function.
- All CFM frames at a lower level are stopped and dropped, independent of whether they originate from the wire or relay function.
- All CFM frames at a higher level are forwarded, independent of whether they arrive from the wire or relay function.
- MIPs respond only when triggered by CFM traceroute and loopback messages.
- Bridge-Brain MAC addresses are used.

If the port on which a MIP is configured is blocked by Spanning-Tree Protocol, the MIP cannot receive CFM messages or relay them toward the relay function side. The MIP can, however, receive and respond to CFM messages from the wire.

A MIP has only one level associated with it and the command-line interface (CLI) does not allow you to configure a MIP for a domain that does not exist.

The figure below illustrates MEPs and MIPs at the operator, service provider, and customer levels.



## CFM Messages

CFM uses standard Ethernet frames. CFM frames are distinguishable by EtherType and for multicast messages by MAC address. CFM frames are sourced, terminated, processed, and relayed by bridges. Routers can support only limited CFM functions.

Bridges that cannot interpret CFM messages forward them as normal data frames. All CFM messages are confined to a maintenance domain and to an S-VLAN (PE-VLAN or Provider-VLAN). Three types of messages are supported:

- Continuity Check
- Loopback
- Traceroute

### Continuity Check Messages

CFM CCMs are heartbeat messages exchanged periodically among MEPs. They allow MEPs to discover other MEPs within a domain and allow MIPs to discover MEPs. CCMs are confined to a domain and S-VLAN.

CFM CCMs have the following characteristics:

- Transmitted at a configurable periodic interval by MEPs. The interval can be from 10 seconds to 65535 seconds, the default is 30.
- Contains a configurable hold-time value to indicate to the receiver the validity of the message. The default is 2.5 times the transmit interval.
- Catalogued by MIPs at the same maintenance level.
- Terminated by remote MEPs at the same maintenance level.
- Unidirectional and do not solicit a response.
- Carry the status of the port on which the MEP is configured.

### Loopback Messages

CFM loopback messages are unicast frames that a MEP transmits, at the request of an administrator, to verify connectivity to a particular maintenance point. A reply to a loopback message indicates whether a destination is reachable but does not allow hop-by-hop discovery of the path. A loopback message is similar in concept to an Internet Control Message Protocol (ICMP) Echo (ping) message.

A CFM loopback message can be generated on demand using the CLI. The source of a loopback message must be a MEP; the destination may be a MEP or a MIP. CFM loopback messages are unicast; replies to loopback messages also are unicast. CFM loopback messages specify the destination MAC address, VLAN, and maintenance domain.

### Traceroute Messages

CFM traceroute messages are multicast frames that a MEP transmits, at the request of an administrator, to track the path (hop-by-hop) to a destination MEP. They allow the transmitting node to discover vital connectivity data about the path, and allow the discovery of all MIPs along the path that belong to the same maintenance domain. For each visible MIP, traceroute messages indicate ingress action, relay action, and egress action. Traceroute messages are similar in concept to User Datagram Protocol (UDP) traceroute messages.

Traceroute messages include the destination MAC address, VLAN, and maintenance domain and they have Time To Live (TTL) to limit propagation within the network. They can be generated on demand using the CLI. Traceroute messages are multicast; reply messages are unicast.

## Cross-Check Function

The cross-check function is a timer-driven post-provisioning service verification between dynamically discovered MEPs (via CCMs) and expected MEPs (via configuration) for a service. The cross-check function verifies that all endpoints of a multipoint or point-to-point service are operational. The function supports notifications when the service is operational; otherwise it provides alarms and notifications for unexpected endpoints or missing endpoints.

The cross-check function is performed one time. You must initiate the cross-check function from the CLI every time you want a service verification.

## Ethernet CFM and Ethernet OAM Interaction

To understand how CFM and OAM interact, you should understand the following concepts:

### Ethernet Virtual Circuit

An EVC as defined by the Metro Ethernet Forum is a port-level point-to-point or multipoint-to-multipoint Layer 2 circuit. EVC status can be used by a CE device either to find an alternative path in to the service provider network or in some cases, to fall back to a backup path over Ethernet or over another alternative service such as ATM.

### OAM Manager

The OAM manager is an infrastructure element that streamlines interaction between OAM protocols. The OAM manager requires two interworking OAM protocols, in this case Ethernet CFM and Ethernet OAM. Interaction is unidirectional from the OAM manager to the CFM protocol and the only information exchanged is the user network interface (UNI) port status. Additional port status values available include

- REMOTE\_EE—Remote excessive errors
- LOCAL\_EE—Local excessive errors
- TEST—Either remote or local loopback

After CFM receives the port status, it communicates that status across the CFM domain.

### CFM over Bridge Domains

Connectivity Fault Management (CFM) over bridge domains allows untagged CFM packets to be associated with a maintenance end point (MEP). An incoming untagged customer CFM packet has an EtherType of CFM and is mapped to an Ethernet virtual circuit (EVC) or bridge domain based on the encapsulation configured on the Ethernet flow point (EFP). The EFP is configured specifically to recognize these untagged packets.

An EFP is a logical demarcation point of an EVC on an interface and can be associated with a bridge domain. The VLAN ID is used to match and map traffic to the EFP. VLAN IDs have local significance per port similar to an ATM virtual circuit. CFM is supported on a bridge domain associated with an EFP. The association between the bridge domain and the EFP allows CFM to use the encapsulation on the EFP. All EFPs in the same bridge domain form a broadcast domain. The bridge domain ID determines the broadcast domain.

The distinction between a VLAN port and the EFP is the encapsulation. VLAN ports use a default dot1q encapsulation. For EFPs, untagged, single tagged, and double tagged encapsulation exists with dot1q and IEEE dot1ad EtherTypes. Different EFPs belonging to the same bridge domain can use different encapsulations.

Both up MEP, down MEP and MIP are supported. If an up MEP is configured under an EFP within a bridge domain, CFM messages would be routed into the bridge, and the rest members of the same bridge domain would be able to receive messages from this MEP. If a down MEP is configured, the messages will not go into the bridge domain.

# How to Set Up Ethernet CFM in a Service Provider Network

## Designing CFM Domains



**Note** To have an operator, service provider, or customer domain is optional. A network may have a single domain or multiple domains. The steps listed here show the sequence when all three types of domains will be assigned.

### Before you begin

- Knowledge and understanding of the network topology.
- Understanding of organizational entities involved in managing the network; for example, operators, service providers, network operations centers (NOCs), and customer service centers.
- Understanding of the type and scale of services to be offered.
- Agreement by all organizational entities on the responsibilities, roles, and restrictions for each organizational entity.
- Determination of the number of maintenance domains in the network.
- Determination of the nesting and disjoint maintenance domains.
- Assignment of maintenance levels and names to domains based on agreement between the service provider and operator or operators.
- Determination of whether the domain should be inward or outward.

### SUMMARY STEPS

1. Determine operator level MIPs.
2. Determine operator level MEPs.
3. Determine service provider MIPs.
4. Determine service provider MEPs.
5. Determine customer MIPs.
6. Determine customer MEPs.

### DETAILED STEPS

|        | Command or Action              | Purpose  |
|--------|--------------------------------|--|
| Step 1 | Determine operator level MIPs. | Follow these steps: <ul style="list-style-type: none"> <li>• Starting at lowest operator level domain, assign a MIP at every interface internal to the operator network to be visible to CFM.</li> <li>• Proceed to next higher operator level and assign MIPs.</li> </ul> |

|               | Command or Action                | Purpose   |
|---------------|----------------------------------|---|
|               |                                  | <ul style="list-style-type: none"> <li>• Verify that every port that has a MIP at a lower level does not have maintenance points at a higher level.</li> <li>• Repeat steps a through d until all operator MIPs are determined.</li> </ul>  |
| <b>Step 2</b> | Determine operator level MEPs.   | <p>Follow these steps:</p> <ul style="list-style-type: none"> <li>• Starting at the lowest operator level domain, assign a MEP at every UNI that is part of a service instance.</li> <li>• Assign a MEP at the network to network interface (NNI) between operators, if there is more than one operator.</li> <li>• Proceed to next higher operator level and assign MEPs.</li> <li>• A port with a MIP at a lower level cannot have maintenance points at a higher level. A port with a MEP at a lower level should have either a MIP or MEP at a higher level.</li> </ul> |
| <b>Step 3</b> | Determine service provider MIPs. | <p>Follow these steps:</p> <ul style="list-style-type: none"> <li>• Starting at the lowest service provider level domain, assign service provider MIPs at the NNI between operators (if more than one).</li> <li>• Proceed to next higher service provider level and assign MIPs.</li> <li>• A port with a MIP at a lower level cannot have maintenance points at a higher level. A port with a MEP at a lower level should not have either a MIP or a MEP at a higher level.</li> </ul>  |
| <b>Step 4</b> | Determine service provider MEPs. | <p>Follow these steps:</p> <ul style="list-style-type: none"> <li>• Starting at the lowest service provider level domain, assign a MEP at every UNI that is part of a service instance.</li> <li>• Proceed to next higher service provider level and assign MEPs.</li> <li>• A port with a MIP at a lower level cannot have maintenance points at a higher level. A port with a MEP at a lower level should have either a MIP or a MEP at a higher level.</li> </ul>  |
| <b>Step 5</b> | Determine customer MIPs.         | Customer MIPs are allowed only on the UNIs at the uPEs if the service provider allows the customer to run CFM.  |

|               | Command or Action        | Purpose  |
|---------------|--------------------------|--|
|               |                          | <p>Otherwise, the service provider can configure Cisco devices to block CFM frames.</p> <ul style="list-style-type: none"> <li>• Configure a MIP on every uPE, at the UNI port, in the customer maintenance domain.</li> <li>• Ensure the MIPs are at a maintenance level that is at least one higher than the highest level service provider domain.</li> </ul> |
| <b>Step 6</b> | Determine customer MEPs. | Customer MEPs are on customer equipment. Assign an outward facing MEP within an outward domain at the appropriate customer level at the handoff between the service provider and the customer.   |

## Configuring Ethernet CFM

Configuring Ethernet CFM consists of the following tasks:

### Configuring CFM

#### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ethernet cfm domain** *domain-name* **level** *level-id*
4. **service** *short-ma-name* **evc** *evc-name* **vlan** *vlanid* **direction** **down**
5. **continuity-check**
6. **continuity-check** [**interval** *cc-interval*]
7. **exit**
8. **mep archive-hold-time** *minutes*
9. **exit**
10. **ethernet cfm global**
11. **etheret cfm ieee**
12. **ethernet cfm traceroute cache**
13. **ethernet cfm traceroute cache** **size** *entries*
14. **ethernet cfm traceroute cache** **hold-time** *minutes*
15. **snmp-server enable traps ethernet cfm cc** [**mep-up**] [**mep-down**] [**config**] [**loop**] [**cross-connect**]
16. **snmp-server enable traps ethernet cfm crosscheck** [**mep-unknown** | **mep-missing** | **service-up**]
17. **end**
18. **interface** *type number*
19. **service instance** *id* **ethernet** [*evc-name*]
20. **encapsulation** *encapsulation-type*
21. **bridge-domain** *bridge-id*
22. **cfm mep domain** *domain-name* **mpid** *id*
23. **end**

## DETAILED STEPS

|        | Command or Action  | Purpose   |
|--------|--|---|
| Step 1 | <b>enable</b><br><b>Example:</b><br>Device> enable   | Enables privileged EXEC mode.<br><ul style="list-style-type: none"><li>• Enter your password if prompted.</li></ul>   |
| Step 2 | <b>configure terminal</b><br><b>Example:</b><br>Device# configure terminal   | Enters global configuration mode.   |
| Step 3 | <b>ethernet cfm domain</b> <i>domain-name</i> <b>level</b> <i>level-id</i><br><b>Example:</b><br>Device(config)# ethernet cfm domain Customer level 7  | Defines a CFM maintenance domain at a particular maintenance level and enters Ethernet CFM configuration mode.  |
| Step 4 | <b>service</b> <i>short-ma-name</i> <b>evc</b> <i>evc-name</i> <b>vlan</b> <i>vlanid</i><br><b>direction down</b><br><b>Example:</b><br>Device(config-ecfm)# service s41 evc 41 vlan 41 direction down | Configures a maintenance association within a maintenance domain and enters Ethernet connectivity fault management (CFM) service configuration mode.<br><b>Note</b> The <b>direction down</b> is used only for Down or Outward-facing MEPs. For Up MEPs or Inward-facing MEPs, do not specify <b>direction down</b> .<br><b>Note</b> To configure MA CFM service for EoMPLS, use <b>service</b> <i>short-ma-name</i> <b>evc</b> <i>evc-name</i> . |
| Step 5 | <b>continuity-check</b><br><b>Example:</b><br>Device(config-ecfm-srv)# continuity-check  | Enables the transmission of continuity check messages (CCMs).   |
| Step 6 | <b>continuity-check</b> [ <b>interval</b> <i>cc-interval</i> ]<br><b>Example:</b><br>Device(config-ecfm-srv)# continuity-check interval 10s  | Configures the time period between CCMs transmission. The default interval is 10 seconds.   |
| Step 7 | <b>exit</b><br><b>Example:</b><br>Device(config-ecfm-srv)# exit  | Returns to Ethernet connectivity fault management configuration mode.   |
| Step 8 | <b>mep archive-hold-time</b> <i>minutes</i><br><b>Example:</b><br>Device(config-ecfm)# mep archive-hold-time 60  | Sets the amount of time that data from a missing MEP is kept in the continuity check database or that entries are held in the error database before they are purged.  |
| Step 9 | <b>exit</b><br><b>Example:</b><br>Device(config-ecfm)# exit  | Returns to global configuration mode.   |


|                | Command or Action   | Purpose   |
|----------------|---|---|
| <b>Step 10</b> | <b>ethernet cfm global</b><br><b>Example:</b><br>Device(config)# ethernet cfm global  | Enables CFM processing globally on the device.  |
| <b>Step 11</b> | <b>etheret cfm ieee</b><br><b>Example:</b><br>Router(config)# ethernef cfm ieee   | Enables CFM IEEE version of CFM.<br><br>This command is automatically issued when the ethernet cfm global command is issued.  |
| <b>Step 12</b> | <b>ethernet cfm traceroute cache</b><br><b>Example:</b><br>Device(config)# ethernet cfm traceroute cache  | Enables caching of CFM data learned through traceroute messages.  |
| <b>Step 13</b> | <b>ethernet cfm traceroute cache size entries</b><br><b>Example:</b><br>Device(config)# ethernet cfm traceroute cache size<br>200   | Sets the maximum size for the CFM traceroute cache table.   |
| <b>Step 14</b> | <b>ethernet cfm traceroute cache hold-time minutes</b><br><b>Example:</b><br>Device(config)# ethernet cfm traceroute cache<br>hold-time 60  | Sets the amount of time that CFM traceroute cache entries are retained.   |
| <b>Step 15</b> | <b>snmp-server enable traps ethernet cfm cc [mep-up] [mep-down] [config] [loop] [cross-connect]</b><br><b>Example:</b><br>Device(config)# snmp-server enable traps ethernet<br>cfm cc mep-up mep-down config loop cross-connect | Enables SNMP trap generation for Ethernet CFM continuity check events.  |
| <b>Step 16</b> | <b>snmp-server enable traps ethernet cfm crosscheck [mep-unknown   mep-missing   service-up]</b><br><b>Example:</b><br>Device(config)# snmp-server enable traps ethernet<br>cfm crosscheck mep-unknown mep-missing service-up   | Enables SNMP trap generation for Ethernet CFM continuity check events in relation to the cross-check operation between statically configured MEPS and those learned via CCMs. |
| <b>Step 17</b> | <b>end</b><br><b>Example:</b><br>Device(config)# end  | Returns to privileged EXEC mode.  |
| <b>Step 18</b> | <b>interface type number</b><br><b>Example:</b><br>Device(config)# interface gigabitethernet0/0/1   | Specifies an interface and enters interface configuration mode.   |



|         | Command or Action   | Purpose   |
|---------|---|---|
| Step 19 | <b>service instance</b> <i>id</i> <b>ethernet</b> [ <i>evc-name</i> ]<br><b>Example:</b><br>Device(config-if)# service instance 333 ethernet evc1 | Configures an Ethernet service instance on an interface and enters Ethernet service configuration mode. |
| Step 20 | <b>encapsulation</b> <i>encapsulation-type</i><br><b>Example:</b><br>Device(config-if-srv)# encapsulation dot1q 5                                 | Sets the encapsulation method used by the interface.  |
| Step 21 | <b>bridge-domain</b> <i>bridge-id</i><br><b>Example:</b><br>Device(config-if-srv)# bridge-domain 100  | Binds a service instance to a bridge domain instance.   |
| Step 22 | <b>cfm mep domain</b> <i>domain-name</i> <b>mpid</b> <i>id</i><br><b>Example:</b><br>Device(config-if-srv)# cfm mep domain L4 mpid 4001           | Configures the MEP domain and the ID.   |
| Step 23 | <b>end</b><br><b>Example:</b><br>Device(config-if-srv)# end   | Returns to privileged EXEC mode.  |

**Example: Configuring CFM**

The below example explains CFM configuration over Layer2 VPN (EoMPLS) network.



**CFM Sessions Hardware Offload**

*Table 1: Feature History Table*

| Feature Name                  | Release Information           | Description  |
|-------------------------------|-------------------------------|--|
| CFM Sessions Hardware Offload | Cisco IOS XE Bengaluru 17.5.1 | This feature enables for effective CPU utilization by offloading the one second CCM interval sessions on the hardware. |



**Note** Effective Cisco IOS XE Bengaluru 17.5.1, the router offloads the one second interval CCM sessions on hardware as well.

You can enable this feature for 1 second offload sampling rate by configuring the **offload sampling 6000** command on the router. This is **not** mandatory for all CFM sessions.

To offload CCM sessions with 1 second, you must configure the hardware offload sampling rate.

This task explains minimal basic configuration for CFM.

## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ethernet cfm domain** *domain-name* **level** *level-id*
4. **service** *short-ma-name* **evc** *evc-name* **vlan** *vlanid* **direction down**
5. **continuity-check**
6. **continuity-check interval 1s**
7. **offload sampling 6000**
8. **exit**

## DETAILED STEPS

|               | Command or Action   | Purpose   |
|---------------|---|---|
| <b>Step 1</b> | <b>enable</b><br><b>Example:</b><br>Device> enable  | Enables privileged EXEC mode.<br><ul style="list-style-type: none"><li>• Enter your password if prompted.</li></ul>   |
| <b>Step 2</b> | <b>configure terminal</b><br><b>Example:</b><br>Router# configure terminal  | Enters global configuration mode.   |
| <b>Step 3</b> | <b>ethernet cfm domain</b> <i>domain-name</i> <b>level</b> <i>level-id</i><br><b>Example:</b><br>Router(config)# ethernet cfm domain Customer level<br>7  | Defines a CFM maintenance domain at a particular maintenance level and enters Ethernet CFM configuration mode.  |
| <b>Step 4</b> | <b>service</b> <i>short-ma-name</i> <b>evc</b> <i>evc-name</i> <b>vlan</b> <i>vlanid</i><br><b>direction down</b><br><b>Example:</b><br>Router(config-ecfm)# service s41 evc 41 vlan 41<br>direction down | Configures a maintenance association within a maintenance domain and enters Ethernet connectivity fault management (CFM) service configuration mode.<br><br><b>Note</b> The <b>direction down</b> is used only for Down or Outward-facing MEPs. For Up MEPs or Inward-facing MEPs, do not specify <b>direction down</b> . |

|        | Command or Action   | Purpose   |
|--------|---|---|
| Step 5 | <b>continuity-check</b><br><b>Example:</b><br>Router(config-ecfm-srv)# continuity-check                         | Enables the transmission of continuity check messages (CCMs).                             |
| Step 6 | <b>continuity-check interval 1s</b><br><b>Example:</b><br>Router(config-ecfm-srv)# continuity-check interval 1s | Configures the time period between CCMs transmission. The default interval is 10 seconds. |
| Step 7 | <b>offload sampling 6000</b><br><b>Example:</b><br>Router(config-ecfm-srv)# offload sampling 6000               | Configures the offload sampling rate as 6000 seconds.                                     |
| Step 8 | <b>exit</b><br><b>Example:</b><br>Router(config-ecfm-srv)# exit   | Exits the privileged mode.  |

*Verification for CFM Sessions Hardware Offload*

```

Router#show ethernet cfm maintenance-points local detail
Local MEPs:
-----
MPID: 5000
DomainName: SMDL1
Domain ID: SMDL1
MA Name: SMA1
Level: 3
Direction: Down
EVC: evc2
Bridge Domain: 4001
Service Instance: 2
Interface: Te0/3/0
CC Offload: Yes
CC Offload Status: Succeeded
CC Offload Sampling: 6000
CC-Status: Enabled
CC Loss Threshold: 3
MAC: f84f.5783.d59b
CC Transmission Mode: Multicast
LCK-Status: Enabled
LCK Period: 60000(ms)
LCK Expiry Threshold: 3.5
Level to transmit LCK: Default
Defect Condition: No Defect
presentRDI: FALSE
AIS-Status: Enabled
AIS Period: 60000(ms)
AIS Expiry Threshold: 3.5
Level to transmit AIS: Default
Suppress Alarm configuration: Enabled
Suppressing Alarms: No
Source: Static

Total Local MEPs: 1
    
```

```
MIP Settings:
-----
Local MIPs: None
```

## Example For Configuring CFM over EoMPLS



**Note** Ensure that EoMPLS configuration are UP and running before configuring CFM.

### PE1 Configuration

```

ethernet cfm ieee
ethernet cfm global          ! enable CFM on the router
ethernet cfm domain PE1-2 level 6    ! define domain PE1-2
  17

service EVC-PE-200 evc evc-200
  continuity-check
  continuity-check interval 1s
!

ethernet cfm logging
ethernet evc evc-200
!
interface GigabitEthernet0/1 /0
no ip address
negotiation auto
  service instance 200 ethernet evc-200
  encapsulation dot1q 200-300
  cfm mep domain PE1-2 mpid 1200          ! created MEP

exit
interface pseudowire 200
  encapsualtion mpls
  neighbor 10.10.4.4
!
l2vpn xconnect context PW200
member GigabitEthernet0/1/0 service-instance 200
member 10.10.4.4 200 encapsulation mpls
```

### PE2 Configuration

```

ethernet cfm ieee
ethernet cfm global          ! enable CFM on the router
ethernet cfm domain PE1-2 level 6
service EVC-PE-200 evc evc-200
  continuity-check
  continuity-check interval 1s

!
ethernet cfm logging
ethernet evc evc-200
!
interface GigabitEthernet0/1/0
  no ip address
  negotiation auto
  service instance 200 ethernet evc -200
  encapsulation dot1q 200-300
  cfm mep domain PE1-2 mpid 1201    ! mpid must be different from remote end

!
```

```

interface pseudowire200
  encapsulation mpls
  neighbor 10.10.3.3 200

!
l2vpn xconnect context PW200
member gigabitethernet0/1/0
service-instance 200 pseudowire200

```

## Example for Verifying CFM

### show ethernet cfm maintenance-points local

```

Router# show ethernet cfm maintenance-points local
Local MEPs:

```

```

-----
MPID Domain Name                               Lvl  MacAddress  Type CC
Ofld Domain Id                               Dir  Port        Id
MA Name                                       SrvcInst  Source
EVC name
-----
1201 PE1-2                                     6     7010.5c51.a4bf XCON Y
No PE1-2                                       Up    Gi0/1/0      N/A
EVC-PE-200                                     200   Static
evc-200
Total Local MEPs: 1

```

### show ethernet cfm maintenance-points remote

```

ASR903-PE2# show ethernet cfm maintenance-points remote

```

```

-----
MPID Domain Name                               MacAddress  IfSt PtSt
Lvl Domain ID                               Ingress
RDI MA Name                                  Type Id     SrvcInst
EVC Name                                     Age
Local MEP Info
-----
1200 PE1-2                                     7010.5c51.8fbf  Up    Up
6 PE1-2                                       Gi0/1/0:(10.10.3.3, 200)
- EVC-PE-200                                   XCON N/A      200
  evc-200                                       0s
  MPID: 1201 Domain: PE1-2 MA: EVC-PE-200
Total Remote MEPs: 1

```

## CFM Use Cases

### Example For Configuring CFM over Bridge Domain

```

ethernet cfm ieee
ethernet cfm global
ethernet cfm domain cust1 level 7
  service s1 evc 1 vlan 1
  continuity-check
  continuity-check interval 3.3ms

service instance 1 ethernet 1
  encapsulation dot1q 1
  bridge-domain 1
  cfm mep domain cust1 mpid 1

```

## Example For Configuring CFM over Trunk EFP



**Note** For trunk EFP, MEP is configured under the interface level configuration.

```

ethernet cfm domain oper2 level 7
service strunk evc 1000 vlan 800 direction down
  continuity-check
  continuity-check interval 3.3ms

ethernet cfm mep domain oper2 mpid 8191 service strunk --- this creates MEP
service instance trunk 1000 ethernet
  encapsulation dot1q 500-1000
  rewrite ingress tag pop 1 symmetric
  bridge-domain from-encapsulation

```

## Example For Configuring CFM over VPLS



**Note** The EVC name used should be similar to the EVC configured in CFM configuration.

CFM over VPLS: Using the **legacy l2 vfi** command

```

ethernet cfm ieee
ethernet cfm global
ethernet cfm domain dom01 level 5

service serv01 evc evc26 vlan 26
  continuity-check
  continuity-check interval 3.3ms

service instance 26 ethernet evc26
  encapsulation dot1q 26
  rewrite ingress tag pop 1 symmetric
  bridge-domain 26
  cfm mep domain dom01 mpid 1

l2 vfi test manual evc26 ===== The evc name should be same as configured in CFM config
vpn id 26
bridge-domain 26
neighbor 2.2.2.2 encapsulation mpls

```

CFM over VPLS: Using **l2vpn vfi** context command

```

ethernet cfm ieee
ethernet cfm global
ethernet cfm domain dom01 level 5
service serv01 evc evc26 vlan 26
  continuity-check
  continuity-check interval 3.3ms
l2vpn vfi context vpls26
  vpn id 26
  evc evc26
  member 2.2.2.2 encapsulation mpls
  member 1.1.1.1 encapsulation mpls
Int gi0/0/1
Service instance 26 ethernet evc26
Encapsulation dot1q 26
cfm mep domain dom01 mpid 1

```

```
bridge-domain 26
  member GigabitEthernet0/0/1 service-instance 26
  member vfi vpls26
```



**Note** The EVC name used should be similar to the EVC configured in CFM configuration.

### Example For Configuring CFM over Default Encapsulation

```
ethernet cfm domain oper2 level 7
service cust1 evc 1000 vlan 1500 direction down
  continuity-check
  continuity-check interval 3.3ms

service instance 1000 ethernet 1000
  encapsulation default
  bridge-domain 1500
  cfm mep domain cust1 mpid 8191
  cfm encapsulation dot1q 1500
```

### Verification Commands for CFM

Use the following commands to verify CFM:

- **show ethernet cfm maintenance-points local**
- **show ethernet cfm maintenance-points remote**
- **show ethernet cfm statistics**
- **show ethernet cfm ccm-learning-database**
- **show ethernet cfm errors**

### SNMP Traps

The support provided by the Cisco IOS XE software implementation of Ethernet CFM traps is Cisco proprietary information. MEPs generate two types of Simple Network Management Protocol (SNMP) traps, continuity check (CC) traps and cross-check traps.

#### CC Traps

- **MEP up--**Sent when a new MEP is discovered, the status of a remote port changes, or connectivity from a previously discovered MEP is restored after interruption.
- **MEP down--**Sent when a timeout or last gasp event occurs.
- **Cross-connect--**Sent when a service ID does not match the VLAN.
- **Loop--**Sent when a MEP receives its own CCMs.
- **Configuration error--**Sent when a MEP receives a continuity check with an overlapping MPID.

#### Cross-Check Traps

- **Service up--**Sent when all expected remote MEPs are up in time.

- MEP missing--Sent when an expected MEP is down.
- Unknown MEP--Sent when a CCM is received from an unexpected MEP.

### Steps to Generate SNMP Traps for CFM

To generate SNMP traps, following commands need to be configured on the router.

```

ethernet cfm logging
logging snmp-trap 0 7
logging history debugging

```

### Send Trap to SNMP Server

```

snmp-server enable traps ethernet cfm cc [mep-up] [mep-down] [config] [loop] [cross-connect]
snmp-server enable traps ethernet cfm crosscheck [mep-unknown] [mep-missing] [ service-up]

```



#### Note

If syslog trap is enabled, by default trap is generated for messages of severity level emergency, alert, critical, error and warning (0-4). For other severity levels need to enable **logging snmp-trap 0 7** and **logging history debugging**

```

Router(config)#ethernet cfm logging
Router(config)#logging snmp-trap 0 7
Router(config)#logging history debugging
Router(config)#snmp-server enable traps ethernet cfm cc
Router(config)#snmp-server enable traps ethernet cfm crosscheck

```

### Logs for MEP going DOWN

Console-logs:

```

Router(config)#
*Oct 26 21:32:06.663 IST: %E_CFM-3-REMOTE_MEP_DOWN: Remote MEP mpid 10 evc 2 vlan 2 MA name
s2 in domain cust2 changed state to down with event code TimeOut.
*Oct 26 21:32:06.664 IST: %E_CFM-6-ENTER_AIS: local mep with mpid 20 level 2 BD/VLAN 2 dir
D Interface Te0/3/1 enters AIS defect condition
*Oct 26 21:32:09.147 IST: %E_CFM-3-FAULT_ALARM: A fault has occurred in the network for the
local MEP having mpid 20 evc 2 vlan 2 for service MA name s2 with the event code
DefRemoteCCM.

```

### SNMP Server Side Logs

#### Received SNMPv2c Trap

```

Community: public
From: 7.32.22.154
sysUpTimeInstance = 04:00:54.27
snmpTrapOID.0 = clogMessageGenerated
clogHistFacility.76 = E_CFM
clogHistSeverity.76 = error(4)
clogHistMsgName.76 = REMOTE_MEP_DOWN
clogHistMsgText.76 = Remote MEP mpid 10 evc 2 vlan 2 MA name s2 in domain cust2 changed

```



```
state to down with event code TimeOut.
clogHistTimestamp.76 = 04:00:54.27
```

### Received SNMPv2c Trap

```
Community: public
From: 7.32.22.154
sysUpTimeInstance = 04:00:54.27
snmpTrapOID.0 = clogMessageGenerated
clogHistFacility.77 = E_CFM
clogHistSeverity.77 = info(7)
clogHistMsgName.77 = ENTER_AIS
clogHistMsgText.77 = local mep with mpid 20 level 2 BD/VLAN 2 dir D Interface Te0/3/1 enters
  AIS defect condition
clogHistTimestamp.77 = 04:00:54.27
```

### Received SNMPv2c Trap

```
Community: public
From: 7.32.22.154
sysUpTimeInstance = 04:00:56.75
snmpTrapOID.0 = dotlagCfmFaultAlarm
dotlagCfmMepHighestPrDefect.10.2.20 = defRemoteCCM(3)
```

### Received SNMPv2c Trap

```
Community: public
From: 7.32.22.154
sysUpTimeInstance = 04:00:56.75
snmpTrapOID.0 = clogMessageGenerated
clogHistFacility.78 = E_CFM
clogHistSeverity.78 = error(4)
clogHistMsgName.78 = FAULT_ALARM
clogHistMsgText.78 = A fault has occurred in the network for the local MEP having mpid 20
  evc 2 vlan 2 for service MA name s2 with the event code DefRemoteCCM.
clogHistTimestamp.78 = 04:00:56.75
```

## Logs for MEP Coming Up

### Console-logs

```
=====
Router(config)#
*Oct 26 21:35:03.780 IST: %E_CFM-6-REMOTE_MEP_UP: Continuity Check message is received from
  a remote MEP with mpid 10 evc 2 vlan 2 MA name s2 domain cust2 interface status Up event
  code Returning.
*Oct 26 21:35:03.781 IST: %E_CFM-6-EXIT_AIS: local mep with mpid 20 level 2 BD/VLAN 2 dir
  D Interface Te0/3/1 exited AIS defect condition
```

## SNMP Server Side Logs

### Received SNMPv2c Trap

```

=====
Community: public
From: 7.32.22.154
sysUpTimeInstance = 04:03:51.39
snmpTrapOID.0 = clogMessageGenerated
clogHistFacility.79 = E_CFM
clogHistSeverity.79 = info(7)
clogHistMsgName.79 = REMOTE_MEP_UP
clogHistMsgText.79 = Continuity Check message is received from a remote MEP with mpid 10
evc 2 vlan 2 MA name s2 domain cust2 interface status Up event code Returning.
clogHistTimestamp.79 = 04:03:51.38

```

### Received SNMPv2c Trap

```

Community: public
From: 7.32.22.154
sysUpTimeInstance = 04:03:51.39
snmpTrapOID.0 = clogMessageGenerated
clogHistFacility.80 = E_CFM
clogHistSeverity.80 = info(7)
clogHistMsgName.80 = EXIT_AIS
clogHistMsgText.80 = local mep with mpid 20 level 2 BD/VLAN 2 dir D Interface Te0/3/1 exited
AIS defect condition
clogHistTimestamp.80 = 04:03:51.38

```

## Configuring and Enabling Cross-Checking for MEP

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **mep crosscheck mpid *id* vlan *vlan-id* [mac *mac-address*]**
4. **ethernet cfm mep crosscheck start-delay *delay***
5. **ethernet cfm mep crosscheck {enable | disable} level {*level-id* | *level-id-level-id* [, *level-id-level-id*]} vlan {*vlan-id* | any | *vlan-id-vlan-id* [, *vlan-id-vlan-id*]}**

### DETAILED STEPS

|        | Command or Action  | Purpose  |
|--------|--|--|
| Step 1 | <b>enable</b><br><b>Example:</b><br>Device> enable                         | Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul> |
| Step 2 | <b>configure terminal</b><br><b>Example:</b><br>Device# configure terminal | Enters global configuration mode.  |

|               | <b>Command or Action</b>   | <b>Purpose</b>   |
|---------------|--|--|
| <b>Step 3</b> | <p><b>mep crosscheck mpid id vlan vlan-id [mac mac-address]</b></p> <p><b>Example:</b></p> <pre>Device(config-ether-cfm)# mep crosscheck mpid 402 vlan 100</pre>   | Statically defines a remote MEP on a specified VLAN within the domain.   |
| <b>Step 4</b> | <p><b>ethernet cfm mep crosscheck start-delay delay</b></p> <p><b>Example:</b></p> <pre>Device(config)# ethernet cfm mep crosscheck start-delay 60</pre>   | Configures the maximum amount of time that the device waits for remote MEPs to come up before the cross-check operation is started |
| <b>Step 5</b> | <p><b>ethernet cfm mep crosscheck {enable   disable} level {level-id   level-id-level-id [,level-id-level-id]} vlan {vlan-id   any   vlan-id-vlan-id [,vlan-id-vlan-id]}</b></p> <p><b>Example:</b></p> <pre>Device# ethernet cfm mep crosscheck enable level 4 vlan 100</pre> | Enables cross-checking between remote MEPs in the domain and MEPs learned through CCMs.  |

### Configuring Cross-checking on MEP

```
Router(config)# ethernet cfm domain ServiceProvider level 4
ethernet cfm domain ServiceProvider level 4
mep crosscheck mpid 402 vlan 100
!
ethernet cfm mep crosscheck start-delay 60
```

## Troubleshooting Tips

To verify and isolate a fault, start at the highest level maintenance domain and do the following:

- Check the device error status.
- When an error exists, perform a loopback test to confirm the error.
- Run a traceroute to the destination to isolate the fault.
- If the fault is identified, correct the fault.
- If the fault is not identified, go to the next lower maintenance domain and repeat these four steps at that maintenance domain level.
- Repeat the first four steps, as needed, to identify and correct the fault.

## Troubleshooting CFM Features

Provides troubleshooting solutions for the CFM features.

Table 2: Troubleshooting Scenarios for CFM Features

| Problem  | Solution  |       |                |                        |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
|--|---|-------|----------------|------------------------|------------|--------|--|--|--|------------|--|---|-----|-----|----------------|------------------------|-------|------|------|------------|--------|--|--|--|------------|--|---|-----|-----|----------------|------------------------|
| CFM configuration errors   | CFM configuration error occurs when when a MEP receives a continuity check with an overlapping MPID. To verify the source of the error, use the command <b>show ethernet cfm errors configuration</b> or <b>show ethernet cfm errors</b> .  |       |                |                        |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
| CFM ping and traceroute result is "not found"                        | Complete these steps: <ol style="list-style-type: none"> <li>1. Use <b>show run   i ethernet cfm</b> to view all CFM global configurations.</li> <li>2. Use <b>show ethernet cfm statistics</b> to view local MEPs and their CCM statistics</li> <li>3. Use <b>show ethernet cfm peer meps</b> command to View CFM CCM received from Peer MEPs.</li> <li>4. Use <b>trace ethernet cfm</b> command to start a CFM trace.</li> </ol>  |       |                |                        |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
| CFM connectivity is down and issues at the maintenance domain levels | Use the <b>ping ethernet {mac-address   mpid id   multicast} domain domain-name { vlan vlan-id   port   evc evc-name}</b> or the <b>traceroute ethernet {mac-address   mpid id } domain domain-name { vlan vlan-id   port   evc evc-name}</b> commands to verify ethernet CFM connectivity. Share the output with TAC for further investigation.  |       |                |                        |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
| Loop trap error  | Use the <b>show ethernet cfm error</b> command to check for Loop Trap errors as shown here: <pre>CE(config-if)#do sh ethernet cfm err</pre> <table border="1"> <thead> <tr> <th>Level</th> <th>Vlan</th> <th>MPID</th> <th>Remote MAC</th> <th>Reason</th> </tr> <tr> <th></th> <th></th> <th></th> <th>Service ID</th> <th></th> </tr> </thead> <tbody> <tr> <td>5</td> <td>711</td> <td>550</td> <td>1001.1001.1001</td> <td>Loop Trap Error<br/>OUT</td> </tr> </tbody> </table> <pre>PE#sh ethernet cfm err</pre> <table border="1"> <thead> <tr> <th>Level</th> <th>Vlan</th> <th>MPID</th> <th>Remote MAC</th> <th>Reason</th> </tr> <tr> <th></th> <th></th> <th></th> <th>Service ID</th> <th></th> </tr> </thead> <tbody> <tr> <td>5</td> <td>711</td> <td>550</td> <td>1001.1001.1001</td> <td>Loop Trap Error<br/>OUT</td> </tr> </tbody> </table> | Level | Vlan           | MPID                   | Remote MAC | Reason |  |  |  | Service ID |  | 5 | 711 | 550 | 1001.1001.1001 | Loop Trap Error<br>OUT | Level | Vlan | MPID | Remote MAC | Reason |  |  |  | Service ID |  | 5 | 711 | 550 | 1001.1001.1001 | Loop Trap Error<br>OUT |
| Level  | Vlan  | MPID  | Remote MAC     | Reason                 |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
|  |   |       | Service ID     |                        |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
| 5  | 711   | 550   | 1001.1001.1001 | Loop Trap Error<br>OUT |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
| Level  | Vlan  | MPID  | Remote MAC     | Reason                 |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
|  |   |       | Service ID     |                        |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
| 5  | 711   | 550   | 1001.1001.1001 | Loop Trap Error<br>OUT |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |
| ethernet cfm logging   | In a scale scenario, you configure either the console logging rate-limiting using <b>logging rate-limit</b> or using <b>logging buffered</b> instead of using <b>logging console</b> . The suggested rate-limit is around 30 messages per second.   |       |                |                        |            |        |  |  |  |            |  |   |     |     |                |                        |       |      |      |            |        |  |  |  |            |  |   |     |     |                |                        |

# Additional References

## Related Documents

| Related Topic      | Document Title   |
|--------------------|--|
| Cisco IOS commands | <a href="#">Cisco IOS Master Commands List, All Releases</a> |

## Standards and RFCs

| Standard/RFC   | Title |
|--|-------|
| No specific Standards and RFCs are supported by the features in this document. | —     |

## MIBs

| MB | MIBs Link  |
|----|--|
| —  | To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:<br><br><a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a> |

## Technical Assistance

| Description   | Link  |
|---|---|
| <p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p> | <a href="http://www.cisco.com/support">http://www.cisco.com/support</a> |

# Glossary

**CCM**—continuity check message. A multicast CFM frame that a MEP transmits periodically to ensure continuity across the maintenance entities to which the transmitting MEP belongs, at the MA level on which the CCM is sent. No reply is sent in response to receiving a CCM.

**EVC**—Ethernet virtual connection. An association of two or more user-network interfaces.

**fault alarm**—An out-of-band signal, typically an SNMP notification, that notifies a system administrator of a connectivity failure.

**inward-facing MEP**—A MEP that resides in a bridge and transmits to and receives CFM messages from the direction of the bridge relay entity.

**maintenance domain**—The network or part of the network belonging to a single administration for which faults in connectivity are to be managed. The boundary of a maintenance domain is defined by a set of DSAPs, each of which may become a point of connectivity to a service instance.

**maintenance domain name**—The unique identifier of a domain that CFM is to protect against accidental concatenation of service instances.

**MEP**—maintenance endpoint. An actively managed CFM entity associated with a specific DSAP of a service instance, which can generate and receive CFM frames and track any responses. It is an endpoint of a single MA, and terminates a separate maintenance entity for each of the other MEPs in the same MA.

**MEP CCDB**—A database, maintained by every MEP, that maintains received information about other MEPs in the maintenance domain.

**MIP**—maintenance intermediate point. A CFM entity, associated with a specific pair of ISS SAPs or EISS Service Access Points, which reacts and responds to CFM frames. It is associated with a single maintenance association and is an intermediate point within one or more maintenance entities.

**MIP CCDB**—A database of information about the MEPs in the maintenance domain. The MIP CCDB can be maintained by a MIP.

**MP**—maintenance point. Either a MEP or a MIP.

**MPID**—maintenance endpoint identifier. A small integer, unique over a given MA, that identifies a specific MEP.

**OAM**—operations, administration, and maintenance. A term used by several standards bodies to describe protocols and procedures for operating, administrating, and maintaining networks. Examples are ATM OAM and IEEE Std. 802.3ah OAM.

**operator**—Entity that provides a service provider a single network of provider bridges or a single Layer 2 or Layer 3 backbone network. An operator may be identical to or a part of the same organization as the service provider. For purposes of IEEE P802.1ag, Draft Standard for Local and Metropolitan Area Networks, the operator and service provider are presumed to be separate organizations.

Terms such as “customer,” “service provider,” and “operator” reflect common business relationships among organizations and individuals that use equipment implemented in accordance with IEEE P802.1ag.

**UNI**—user-network interface. A common term for the connection point between an operator's bridge and customer equipment. A UNI often includes a C-VLAN-aware bridge component. The term UNI is used broadly in the IEEE P802.1ag standard when the purpose for various features of CFM are explained. UNI has no normative meaning.