



Configuring SFP+

SUMMARY STEPS

1. **enable source-interface gigabitethernet slot/port**
2. **configure terminal**
3. **interface tengigabitethernet slot/port**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|---|--|
| Step 1 | enable source-interface gigabitethernet slot/port Example: Router# enable | Enables the privileged EXEC mode. If prompted, enter your password. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters the global configuration mode. |
| Step 3 | interface tengigabitethernet slot/port Example: Router(config)# interface tengigabitethernet 4/11 | Specifies the 10-Gigabit Ethernet interface to be configured. Here: slot/port—Specifies the location of the interface. |

