



Cloud Native BNG Control Plane Command Reference Guide, Release 2022.01.0

First Published: 2022-01-31

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on standards documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2022 Cisco Systems, Inc. All rights reserved.



CONTENTS

PREFACE

About this Guide	xv
Conventions Used	xv

CHAPTER 1

cnBNG CP Commands	1
aaa	8
cd	9
cdl clear	9
cdl show sessions	10
cdl show status	11
clear l2tp-tunnel	11
clear subscriber	12
clear subscriber	14
client http header	15
client http ping	15
client inbound interface	16
client inbound interface limit overload	16
client inbound interface limit pending	17
client inbound limit overload	17
client inbound limit pending	17
client outbound host ping	18
client outbound interface	18
client outbound interface host ping	19
client outbound interface limit consecutive failure	19
client outbound interface limit pending	20
client outbound limit consecutive failure	20
client outbound limit pending	21

commit	21
compare	22
config	22
datastore dbs	23
datastore dbs endpoints	23
datastore notification-ep	23
datastore session-db	24
datastore session-db endpoints	24
deployment	25
deployment resource	25
describe	26
dump transactionhistory	27
edr	27
edr edrsubscribers	28
edr file files	28
edr file files disable	29
edr file files flush	29
edr file files limit	30
edr file files procedure-id disable-event-id	30
edr file files procedure-id disable-event-id disable-inner disable	30
edr file files procedure-id disable-event-id disable-inner event-id disable-field-id	31
edr file files procedure-id disable-event-id disable-inner event-id disable-field-id disable	31
exit	32
geo maintenance	32
geo reset-role	32
geo switch-role	33
geomonitor podmonitor pods	33
geomonitor remoteclustermonitor	34
geomonitor trafficMonitor	34
geomonitor vipmonitor	35
geomonitor vipmonitor instance	35
geomonitor vipmonitor instance vips	35
helm	36
helm charts	37

helm repository	37
help	38
history	39
id	39
idle-timeout	40
ignore-leading-space	40
infra metrics experimental	40
infra metrics verbose verboseLevels	41
infra metrics verbose verboseLevels metrics metricsList	41
infra transaction limit	42
infra transaction limit consecutive same	42
infra transaction loop	43
infra transaction loop category	43
infra transaction loop category threshold	44
infra transaction loop category threshold thresholds	44
instance instance-id	45
instance instance-id endpoint ep	45
instance instance-id endpoint ep cpu	46
instance instance-id endpoint ep interface	47
instance instance-id endpoint ep interface dispatcher	48
instance instance-id endpoint ep interface internal base-port	50
instance instance-id endpoint ep interface sla	50
instance instance-id endpoint ep interface vip	50
instance instance-id endpoint ep interface vip6	51
instance instance-id endpoint ep memory	52
instance instance-id endpoint ep retransmission	52
instance instance-id endpoint ep service	53
instance instance-id endpoint ep service interface	53
instance instance-id endpoint ep service interface dispatcher	54
instance instance-id endpoint ep service interface internal base-port	56
instance instance-id endpoint ep service interface overload-control client threshold critical	56
instance instance-id endpoint ep service interface overload-control client threshold high	57
instance instance-id endpoint ep service interface overload-control client threshold low	57
instance instance-id endpoint ep service interface overload-control endpoint threshold critical	58

instance instance-id endpoint ep service interface overload-control endpoint threshold high 58

instance instance-id endpoint ep service interface overload-control endpoint threshold low 59

instance instance-id endpoint ep service interface overload-control msg-type messageConfigs 59

instance instance-id endpoint ep service interface sla 60

instance instance-id endpoint ep service interface vip 61

instance instance-id endpoint ep service interface vip6 61

instance instance-id endpoint ep system-health-level crash 62

instance instance-id endpoint ep system-health-level critical 62

instance instance-id endpoint ep system-health-level warn 63

instance instance-id endpoint ep vip 64

instance instance-id endpoint ep vip6 64

instances instance 65

ipam instance 65

ipam instance address-pool 66

ipam instance address-pool ipv4 address-range 67

ipam instance address-pool ipv4 prefix-range 67

ipam instance address-pool ipv4 split-size 68

ipam instance address-pool ipv4 threshold 69

ipam instance address-pool ipv6 address-ranges address-range 69

ipam instance address-pool ipv6 address-ranges prefix-range 70

ipam instance address-pool ipv6 address-ranges split-size 70

ipam instance address-pool ipv6 address-ranges threshold 71

ipam instance address-pool ipv6 prefix-ranges prefix-range 72

ipam instance address-pool ipv6 prefix-ranges split-size 72

ipam instance address-pool ipv6 prefix-ranges threshold 73

ipam instance address-pool static 73

ipam instance min-dp-addr-size 74

ipam instance source 74

ipam instance source external ipam 75

ipam instance threshold 75

ipam show dp 76

ipam show dp-tag 76

ipam show ipam pool 77

job 77

k8 bng	77
k8 bng tracing	78
k8 label pod-group-config	79
kubernetes	80
kubernetes nodes	81
leaf-prompting	81
license smart deregister	82
license smart register	82
license smart renew	82
local-instance	83
logging async application enable	83
logging async monitor-subscriber enable	84
logging async tracing enable	84
logging async transaction enable	85
logging error	85
logging level	85
logging logger	87
logging logger level	87
logging transaction	89
logout	90
monitor protocol	90
monitor subscriber	91
nf-tls ca-certificates	91
nf-tls certificate-status	92
nf-tls certificates	92
no	92
paginate	93
profile aaa	93
profile aaa accounting	93
profile aaa authentication	94
profile aaa authorization	94
profile aaa authorization type subscriber	95
profile aaa authorization username	95
profile attribute-format	97

profile coa	98
profile coa client	99
profile dhcp	99
profile dhcp ipv4	99
profile dhcp ipv4 class	100
profile dhcp ipv4 class matches	100
profile dhcp ipv4 class matches match	101
profile dhcp ipv4 class server	101
profile dhcp ipv4 class server hold-time	103
profile dhcp ipv4 class server lease	103
profile dhcp ipv4 class server netbios-node-type	104
profile dhcp ipv4 class server option-codes	104
profile dhcp ipv4 class server option-codes option-code	105
profile dhcp ipv4 class server static-ip-key	106
profile dhcp ipv4 server	106
profile dhcp ipv4 server hold-time	107
profile dhcp ipv4 server lease	108
profile dhcp ipv4 server netbios-node-type	108
profile dhcp ipv4 server option-codes	109
profile dhcp ipv4 server option-codes option-code	109
profile dhcp ipv4 server static-ip-key	110
profile dhcp ipv6	111
profile dhcp ipv6 class	111
profile dhcp ipv6 class server	112
profile dhcp ipv6 class server hold-time	113
profile dhcp ipv6 class server lease	113
profile dhcp ipv6 class server static-ip-key	114
profile dhcp ipv6 server	114
profile dhcp ipv6 server hold-time	115
profile dhcp ipv6 server lease	115
profile dhcp ipv6 server static-ip-key	116
profile feature-template	116
profile feature-template ipv4	117
profile feature-template ipv4 verify-unicast-source	118

profile feature-template ipv6	118
profile feature-template ipv6 verify-unicast-source	119
profile feature-template ppp	119
profile feature-template ppp chap	120
profile feature-template ppp ipcp	120
profile feature-template ppp ipcp dns	121
profile feature-template ppp ipcp renegotiation	121
profile feature-template ppp ipcp wins	121
profile feature-template ppp ipv6cp renegotiation	122
profile feature-template ppp keepalive	122
profile feature-template ppp lcp delay	123
profile feature-template ppp lcp renegotiation	123
profile feature-template ppp pap	124
profile feature-template ppp timeout	124
profile feature-template ppp timeout absolute	124
profile feature-template qos	125
profile feature-template service-accounting	125
profile feature-template session-accounting	126
profile l2tp	127
profile l2tp domain	129
profile l2tp ip-tos	129
profile l2tp ipv4	130
profile l2tp ipv4 destination	130
profile l2tp retransmit initial	131
profile l2tp retransmit initial timeout	131
profile l2tp retransmit timeout	131
profile l2tp tcp	132
profile l2tp terminate-from	132
profile l2tp tunnel	133
profile l2tp tunnel timeout	133
profile pppoe	133
profile pppoe max-payload	135
profile pppoe session-limit circuit-id	135
profile pppoe session-limit mac	136

profile pppoe session-limit max	136
profile pppoe session-limit outer-vlan	136
profile radius	137
profile radius accounting	138
profile radius accounting attribute	138
profile radius accounting attribute called-station-id	139
profile radius accounting attribute called-station-id format	139
profile radius accounting attribute calling-station-id	140
profile radius accounting attribute calling-station-id format	140
profile radius accounting attribute nas-identifier-format	141
profile radius accounting attribute nas-identifier-format format	141
profile radius accounting attribute nas-port	142
profile radius accounting attribute nas-port format-e-list	142
profile radius accounting attribute nas-port-id	143
profile radius accounting attribute nas-port-id format	143
profile radius accounting detect-dead-server	144
profile radius attribute	144
profile radius attribute called-station-id	144
profile radius attribute called-station-id format	145
profile radius attribute calling-station-id	145
profile radius attribute calling-station-id format	146
profile radius attribute nas-identifier-format	146
profile radius attribute nas-identifier-format format	147
profile radius attribute nas-port	147
profile radius attribute nas-port format-e-list	148
profile radius attribute nas-port-id	148
profile radius attribute nas-port-id format	149
profile radius detect-dead-server	149
profile radius server	149
profile radius server-group	150
profile radius server-group server	151
profile server-group	151
profile subscriber	152
profile subscriber aaa	153

profile subscriber class	153
profile subscriber class aaa	154
profile subscriber class matches	154
profile subscriber class matches match	155
profile subscriber event	156
profile subscriber event aaa	157
profile subscriber event class	157
profile subscriber event class aaa	158
profile subscriber event class matches	158
profile subscriber event class matches match	159
quit	160
rcm switchover	160
reconcile ipam	161
resource pod	161
resource pod cpu	161
resource pod labels	162
resource pod memory	162
router bfd instance instance-id	163
router bfd instance instance-id interface-list	163
router bfd instance instance-id interface-list neighbors	163
router bgplist	164
router bgplist bfd	165
router bgplist interfaceList	165
router bgplist interfaceList bondingInterfaces	166
router bgplist interfaceList neighbors	166
router bgplist policies	167
router monitor-interface interface-list	168
screen-length	168
screen-width	169
send	169
show	169
show bfd-neighbor	170
show bgp-global	170
show bgp-kernel-route	170

show bgp-neighbors	171
show bgp-route-summary	171
show bgp-routes	171
show config-error info	172
show diagnostics info	172
show edr	172
show endpoint all	172
show endpoint info	173
show geo-maintenance-mode	173
show georeplication	173
show l2tp-tunnel	174
show l2tp-tunnel filter	174
show local-interface-status	175
show peers all	175
show radius	176
show radius acct-server	176
show radius auth-server	176
show radius-dyn-auth	176
show radius-dyn-auth clients	177
show resources info	177
show role	177
show rpc all	177
show running-status info	178
show sessions	178
show sessions affinity	178
show sessions commit-pending	178
show subscriber	179
show subscriber	179
show subscriber filter	180
show subscriber opts	184
show subscriber synchronize	185
show test-radius accounting	185
show test-radius authentication	186
show-defaults	188

smiuser	188
subscriber	189
subscriber route-synchronize	190
subscriber session-synchronize	190
subscriber session-synchronize-cp	191
system	191
terminal	192
timestamp	192
user-plane	193
user-plane peer-address	193
user-plane port-id	193
who	194

CHAPTER 2**Input Pattern Types 195**

arg-type	195
crypt-hash	196
date-and-time	197
domain-name	197
dotted-quad	198
hex-list	198
hex-string	199
ipv4-address	199
ipv4-address-and-prefix-length	199
ipv4-address-no-zone	199
ipv4-prefix	199
ipv6-address	200
ipv6-address-and-prefix-length	200
ipv6-address-no-zone	201
ipv6-prefix	201
mac-address	202
object-identifier	202
object-identifier-128	202
octet-list	203
phys-address	203

sha-256-digest-string	203
sha-512-digest-string	204
size	204
uuid	205
yang-identifier	205



About this Guide



Note The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. While any existing biased terms are being substituted, exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

This guide provides details about the CLI commands available for the Cloud Native Broadband Network Gateway (cnBNG) Control Plane (CP).

- [Conventions Used, on page xv](#)

Conventions Used

The following tables describe the conventions used throughout this documentation.

Notice Type	Description
Information Note	Provides information about important features or instructions.
Caution	Alerts you of potential damage to a program, device, or system.
Warning	Alerts you of potential personal injury or fatality. May also alert you of potential electrical hazards.

Typeface Conventions	Description
Text represented as a screen display	This typeface represents displays that appear on your terminal screen, for example: Login:

Typeface Conventions	Description
Text represented as commands	This typeface represents commands that you enter, for example: show ip access-list This document always gives the full form of a command in lowercase letters. Commands are not case sensitive.
Text represented as a command <i>variable</i>	This typeface represents a variable that is part of a command, for example: show card <i>slot_number</i> <i>slot_number</i> is a variable representing the desired chassis slot number.
Text represented as menu or sub-menu names	This typeface represents menus and sub-menus that you access within a software application, for example: Click the File menu, then click New



CHAPTER 1

cnBNG CP Commands

This guide describes the CLI commands that are used to configure a control plane in cnBNG.

Some keywords and commands are common across multiple commands and configuration modes respectively. Use the information in the Command Modes section only as a reference to navigate to the command in the applicable configuration modes.

- [aaa, on page 8](#)
- [cd, on page 9](#)
- [cdl clear, on page 9](#)
- [cdl show sessions, on page 10](#)
- [cdl show status, on page 11](#)
- [clear l2tp-tunnel, on page 11](#)
- [clear subscriber, on page 12](#)
- [clear subscriber, on page 14](#)
- [client http header, on page 15](#)
- [client http ping, on page 15](#)
- [client inbound interface, on page 16](#)
- [client inbound interface limit overload, on page 16](#)
- [client inbound interface limit pending, on page 17](#)
- [client inbound limit overload, on page 17](#)
- [client inbound limit pending, on page 17](#)
- [client outbound host ping, on page 18](#)
- [client outbound interface, on page 18](#)
- [client outbound interface host ping, on page 19](#)
- [client outbound interface limit consecutive failure, on page 19](#)
- [client outbound interface limit pending, on page 20](#)
- [client outbound limit consecutive failure, on page 20](#)
- [client outbound limit pending, on page 21](#)
- [commit, on page 21](#)
- [compare, on page 22](#)
- [config, on page 22](#)
- [datastore dbs, on page 23](#)
- [datastore dbs endpoints, on page 23](#)
- [datastore notification-ep, on page 23](#)
- [datastore session-db, on page 24](#)

- [datastore session-db endpoints](#), on page 24
- [deployment](#), on page 25
- [deployment resource](#), on page 25
- [describe](#), on page 26
- [dump transactionhistory](#), on page 27
- [edr](#), on page 27
- [edr edrsubscribers](#), on page 28
- [edr file files](#), on page 28
- [edr file files disable](#), on page 29
- [edr file files flush](#), on page 29
- [edr file files limit](#), on page 30
- [edr file files procedure-id disable-event-id](#), on page 30
- [edr file files procedure-id disable-event-id disable-inner disable](#), on page 30
- [edr file files procedure-id disable-event-id disable-inner event-id disable-field-id](#), on page 31
- [edr file files procedure-id disable-event-id disable-inner event-id disable-field-id disable](#), on page 31
- [exit](#), on page 32
- [geo maintenance](#), on page 32
- [geo reset-role](#), on page 32
- [geo switch-role](#), on page 33
- [geomonitor podmonitor pods](#), on page 33
- [geomonitor remotecustermonitor](#), on page 34
- [geomonitor trafficMonitor](#), on page 34
- [geomonitor vipmonitor](#), on page 35
- [geomonitor vipmonitor instance](#), on page 35
- [geomonitor vipmonitor instance vips](#), on page 35
- [helm](#), on page 36
- [helm charts](#), on page 37
- [helm repository](#), on page 37
- [help](#), on page 38
- [history](#), on page 39
- [id](#), on page 39
- [idle-timeout](#), on page 40
- [ignore-leading-space](#), on page 40
- [infra metrics experimental](#), on page 40
- [infra metrics verbose verboseLevels](#), on page 41
- [infra metrics verbose verboseLevels metrics metricsList](#), on page 41
- [infra transaction limit](#), on page 42
- [infra transaction limit consecutive same](#), on page 42
- [infra transaction loop](#), on page 43
- [infra transaction loop category](#), on page 43
- [infra transaction loop category threshold](#), on page 44
- [infra transaction loop category threshold thresholds](#), on page 44
- [instance instance-id](#), on page 45
- [instance instance-id endpoint ep](#), on page 45
- [instance instance-id endpoint ep cpu](#), on page 46
- [instance instance-id endpoint ep interface](#), on page 47

- [instance instance-id endpoint ep interface dispatcher, on page 48](#)
- [instance instance-id endpoint ep interface internal base-port, on page 50](#)
- [instance instance-id endpoint ep interface sla, on page 50](#)
- [instance instance-id endpoint ep interface vip, on page 50](#)
- [instance instance-id endpoint ep interface vip6, on page 51](#)
- [instance instance-id endpoint ep memory, on page 52](#)
- [instance instance-id endpoint ep retransmission, on page 52](#)
- [instance instance-id endpoint ep service, on page 53](#)
- [instance instance-id endpoint ep service interface, on page 53](#)
- [instance instance-id endpoint ep service interface dispatcher, on page 54](#)
- [instance instance-id endpoint ep service interface internal base-port, on page 56](#)
- [instance instance-id endpoint ep service interface overload-control client threshold critical, on page 56](#)
- [instance instance-id endpoint ep service interface overload-control client threshold high, on page 57](#)
- [instance instance-id endpoint ep service interface overload-control client threshold low, on page 57](#)
- [instance instance-id endpoint ep service interface overload-control endpoint threshold critical, on page 58](#)
- [instance instance-id endpoint ep service interface overload-control endpoint threshold high, on page 58](#)
- [instance instance-id endpoint ep service interface overload-control endpoint threshold low, on page 59](#)
- [instance instance-id endpoint ep service interface overload-control msg-type messageConfigs, on page 59](#)
- [instance instance-id endpoint ep service interface sla, on page 60](#)
- [instance instance-id endpoint ep service interface vip, on page 61](#)
- [instance instance-id endpoint ep service interface vip6, on page 61](#)
- [instance instance-id endpoint ep system-health-level crash, on page 62](#)
- [instance instance-id endpoint ep system-health-level critical, on page 62](#)
- [instance instance-id endpoint ep system-health-level warn, on page 63](#)
- [instance instance-id endpoint ep vip, on page 64](#)
- [instance instance-id endpoint ep vip6, on page 64](#)
- [instances instance, on page 65](#)
- [ipam instance, on page 65](#)
- [ipam instance address-pool, on page 66](#)
- [ipam instance address-pool ipv4 address-range, on page 67](#)
- [ipam instance address-pool ipv4 prefix-range, on page 67](#)
- [ipam instance address-pool ipv4 split-size, on page 68](#)
- [ipam instance address-pool ipv4 threshold, on page 69](#)
- [ipam instance address-pool ipv6 address-ranges address-range, on page 69](#)
- [ipam instance address-pool ipv6 address-ranges prefix-range, on page 70](#)
- [ipam instance address-pool ipv6 address-ranges split-size, on page 70](#)
- [ipam instance address-pool ipv6 address-ranges threshold, on page 71](#)
- [ipam instance address-pool ipv6 prefix-ranges prefix-range, on page 72](#)
- [ipam instance address-pool ipv6 prefix-ranges split-size, on page 72](#)
- [ipam instance address-pool ipv6 prefix-ranges threshold, on page 73](#)
- [ipam instance address-pool static, on page 73](#)
- [ipam instance min-dp-addr-size, on page 74](#)
- [ipam instance source, on page 74](#)
- [ipam instance source external ipam, on page 75](#)

- ipam instance threshold, on page 75
- ipam show dp, on page 76
- ipam show dp-tag, on page 76
- ipam show ipam pool, on page 77
- job, on page 77
- k8 bng, on page 77
- k8 bng tracing, on page 78
- k8 label pod-group-config, on page 79
- kubernetes, on page 80
- kubernetes nodes, on page 81
- leaf-prompting, on page 81
- license smart deregister, on page 82
- license smart register, on page 82
- license smart renew, on page 82
- local-instance, on page 83
- logging async application enable, on page 83
- logging async monitor-subscriber enable, on page 84
- logging async tracing enable, on page 84
- logging async transaction enable, on page 85
- logging error, on page 85
- logging level, on page 85
- logging logger, on page 87
- logging logger level, on page 87
- logging transaction, on page 89
- logout, on page 90
- monitor protocol, on page 90
- monitor subscriber, on page 91
- nf-tls ca-certificates, on page 91
- nf-tls certificate-status, on page 92
- nf-tls certificates, on page 92
- no, on page 92
- paginate, on page 93
- profile aaa, on page 93
- profile aaa accounting, on page 93
- profile aaa authentication, on page 94
- profile aaa authorization, on page 94
- profile aaa authorization type subscriber, on page 95
- profile aaa authorization username, on page 95
- profile attribute-format, on page 97
- profile coa, on page 98
- profile coa client, on page 99
- profile dhcp, on page 99
- profile dhcp ipv4, on page 99
- profile dhcp ipv4 class, on page 100
- profile dhcp ipv4 class matches, on page 100
- profile dhcp ipv4 class matches match, on page 101

- [profile dhcp ipv4 class server](#), on page 101
- [profile dhcp ipv4 class server hold-time](#), on page 103
- [profile dhcp ipv4 class server lease](#), on page 103
- [profile dhcp ipv4 class server netbios-node-type](#), on page 104
- [profile dhcp ipv4 class server option-codes](#), on page 104
- [profile dhcp ipv4 class server option-codes option-code](#), on page 105
- [profile dhcp ipv4 class server static-ip-key](#), on page 106
- [profile dhcp ipv4 server](#), on page 106
- [profile dhcp ipv4 server hold-time](#), on page 107
- [profile dhcp ipv4 server lease](#), on page 108
- [profile dhcp ipv4 server netbios-node-type](#), on page 108
- [profile dhcp ipv4 server option-codes](#), on page 109
- [profile dhcp ipv4 server option-codes option-code](#), on page 109
- [profile dhcp ipv4 server static-ip-key](#), on page 110
- [profile dhcp ipv6](#), on page 111
- [profile dhcp ipv6 class](#), on page 111
- [profile dhcp ipv6 class server](#), on page 112
- [profile dhcp ipv6 class server hold-time](#), on page 113
- [profile dhcp ipv6 class server lease](#), on page 113
- [profile dhcp ipv6 class server static-ip-key](#), on page 114
- [profile dhcp ipv6 server](#), on page 114
- [profile dhcp ipv6 server hold-time](#), on page 115
- [profile dhcp ipv6 server lease](#), on page 115
- [profile dhcp ipv6 server static-ip-key](#), on page 116
- [profile feature-template](#), on page 116
- [profile feature-template ipv4](#), on page 117
- [profile feature-template ipv4 verify-unicast-source](#), on page 118
- [profile feature-template ipv6](#), on page 118
- [profile feature-template ipv6 verify-unicast-source](#), on page 119
- [profile feature-template ppp](#), on page 119
- [profile feature-template ppp chap](#), on page 120
- [profile feature-template ppp ipcp](#), on page 120
- [profile feature-template ppp ipcp dns](#), on page 121
- [profile feature-template ppp ipcp renegotiation](#), on page 121
- [profile feature-template ppp ipcp wins](#), on page 121
- [profile feature-template ppp ipv6cp renegotiation](#), on page 122
- [profile feature-template ppp keepalive](#), on page 122
- [profile feature-template ppp lcp delay](#), on page 123
- [profile feature-template ppp lcp renegotiation](#), on page 123
- [profile feature-template ppp pap](#), on page 124
- [profile feature-template ppp timeout](#), on page 124
- [profile feature-template ppp timeout absolute](#), on page 124
- [profile feature-template qos](#), on page 125
- [profile feature-template service-accounting](#), on page 125
- [profile feature-template session-accounting](#), on page 126
- [profile l2tp](#), on page 127

- [profile l2tp domain](#), on page 129
- [profile l2tp ip-tos](#), on page 129
- [profile l2tp ipv4](#), on page 130
- [profile l2tp ipv4 destination](#), on page 130
- [profile l2tp retransmit initial](#), on page 131
- [profile l2tp retransmit initial timeout](#), on page 131
- [profile l2tp retransmit timeout](#), on page 131
- [profile l2tp tcp](#), on page 132
- [profile l2tp terminate-from](#), on page 132
- [profile l2tp tunnel](#), on page 133
- [profile l2tp tunnel timeout](#), on page 133
- [profile pppoe](#), on page 133
- [profile pppoe max-payload](#), on page 135
- [profile pppoe session-limit circuit-id](#), on page 135
- [profile pppoe session-limit mac](#), on page 136
- [profile pppoe session-limit max](#), on page 136
- [profile pppoe session-limit outer-vlan](#), on page 136
- [profile radius](#), on page 137
- [profile radius accounting](#), on page 138
- [profile radius accounting attribute](#), on page 138
- [profile radius accounting attribute called-station-id](#), on page 139
- [profile radius accounting attribute called-station-id format](#), on page 139
- [profile radius accounting attribute calling-station-id](#), on page 140
- [profile radius accounting attribute calling-station-id format](#), on page 140
- [profile radius accounting attribute nas-identifier-format](#), on page 141
- [profile radius accounting attribute nas-identifier-format format](#), on page 141
- [profile radius accounting attribute nas-port](#), on page 142
- [profile radius accounting attribute nas-port format-e-list](#), on page 142
- [profile radius accounting attribute nas-port-id](#), on page 143
- [profile radius accounting attribute nas-port-id format](#), on page 143
- [profile radius accounting detect-dead-server](#), on page 144
- [profile radius attribute](#), on page 144
- [profile radius attribute called-station-id](#), on page 144
- [profile radius attribute called-station-id format](#), on page 145
- [profile radius attribute calling-station-id](#), on page 145
- [profile radius attribute calling-station-id format](#), on page 146
- [profile radius attribute nas-identifier-format](#), on page 146
- [profile radius attribute nas-identifier-format format](#), on page 147
- [profile radius attribute nas-port](#), on page 147
- [profile radius attribute nas-port format-e-list](#), on page 148
- [profile radius attribute nas-port-id](#), on page 148
- [profile radius attribute nas-port-id format](#), on page 149
- [profile radius detect-dead-server](#), on page 149
- [profile radius server](#), on page 149
- [profile radius server-group](#), on page 150
- [profile radius server-group server](#), on page 151

- profile server-group, on page 151
- profile subscriber, on page 152
- profile subscriber aaa, on page 153
- profile subscriber class, on page 153
- profile subscriber class aaa, on page 154
- profile subscriber class matches, on page 154
- profile subscriber class matches match, on page 155
- profile subscriber event, on page 156
- profile subscriber event aaa, on page 157
- profile subscriber event class, on page 157
- profile subscriber event class aaa, on page 158
- profile subscriber event class matches, on page 158
- profile subscriber event class matches match, on page 159
- quit, on page 160
- rcm switchover, on page 160
- reconcile ipam, on page 161
- resource pod, on page 161
- resource pod cpu, on page 161
- resource pod labels, on page 162
- resource pod memory, on page 162
- router bfd instance instance-id, on page 163
- router bfd instance instance-id interface-list, on page 163
- router bfd instance instance-id interface-list neighbors, on page 163
- router bgplist, on page 164
- router bgplist bfd, on page 165
- router bgplist interfaceList, on page 165
- router bgplist interfaceList bondingInterfaces, on page 166
- router bgplist interfaceList neighbors, on page 166
- router bgplist policies, on page 167
- router monitor-interface interface-list, on page 168
- screen-length, on page 168
- screen-width, on page 169
- send, on page 169
- show, on page 169
- show bfd-neigbor, on page 170
- show bgp-global, on page 170
- show bgp-kernel-route, on page 170
- show bgp-neighbors, on page 171
- show bgp-route-summary, on page 171
- show bgp-routes, on page 171
- show config-error info, on page 172
- show diagnostics info, on page 172
- show edr, on page 172
- show endpoint all, on page 172
- show endpoint info, on page 173
- show geo-maintenance-mode, on page 173

- [show georeplication](#), on page 173
- [show l2tp-tunnel](#), on page 174
- [show l2tp-tunnel filter](#), on page 174
- [show local-interface-status](#), on page 175
- [show peers all](#), on page 175
- [show radius](#), on page 176
- [show radius acct-server](#), on page 176
- [show radius auth-server](#), on page 176
- [show radius-dyn-auth](#), on page 176
- [show radius-dyn-auth clients](#), on page 177
- [show resources info](#), on page 177
- [show role](#), on page 177
- [show rpc all](#), on page 177
- [show running-status info](#), on page 178
- [show sessions](#), on page 178
- [show sessions affinity](#), on page 178
- [show sessions commit-pending](#), on page 178
- [show subscriber](#), on page 179
- [show subscriber](#), on page 179
- [show subscriber filter](#), on page 180
- [show subscriber opts](#), on page 184
- [show subscriber synchronize](#), on page 185
- [show test-radius accounting](#), on page 185
- [show test-radius authentication](#), on page 186
- [show-defaults](#), on page 188
- [smiuser](#), on page 188
- [subscriber](#), on page 189
- [subscriber route-synchronize](#), on page 190
- [subscriber session-synchronize](#), on page 190
- [subscriber session-synchronize-cp](#), on page 191
- [system](#), on page 191
- [terminal](#), on page 192
- [timestamp](#), on page 192
- [user-plane](#), on page 193
- [user-plane peer-address](#), on page 193
- [user-plane port-id](#), on page 193
- [who](#), on page 194

aaa

Configures AAA-based user management parameters.

Command Modes

Exec

Syntax Description

```
aaa { authentication { users list_of_local_users admin change-password
old-password user_password new-password user_password confirm-password
user_password } }
```

users *list_of_local_users*

Specify the user name.

Must be a string.

old-password *user_password*

Specify the user's current password.

Must be a string.

new-password *user_password*

Specify the user's new password.

Must be a string.

confirm-password *user_password*

Reenter the user's new password.

Must be a string.

Usage Guidelines

Use this command to configure the AAA based user management parameters.

cd

Configures the change directory command.

Command Modes

Exec

Syntax Description

```
cd directory.ssh
```

directory

Specify the directory path.

Must be an alphanumeric string.

Usage Guidelines

Use this command to configure the change directory command.

cdl clear

Configures the Cisco Common Data Layer (CDL) parameters to delete the database sessions.

Command Modes

Exec

Syntax Description `cdl clear sessions [db-name db_name | filter { condition { ends-with | match | starts-with } key key_value } | map-id map_id]`

db-name *db_name*

Specifies the database name to be queried for deleting the data.

Must be a string of 1 to 16 characters.

key *key_value*

Specifies the query value.

Must be a string of 0 to 512 characters.

map-id *map_id*

Specifies the map ID to delete the data for a map.

Must be an integer in the range of 0-1024.

filter condition { ends-with | match | starts-with }

Specify the query expression to filter the results of query.

Usage Guidelines Use this command to delete the CDL database sessions.

cdl show sessions

Configures the CDL parameters to display the session details.

Command Modes Exec

Syntax Description `cdl show sessions count { detailed { db-name db_name | filter { condition { ends-with | match | starts-with } | key key_value } | limit limit | map-id map_id } | summary { db-name db_name | filter { condition { ends-with | match | starts-with } | key key_value } | limit limit | map-id map_id }`

count

Display the session count information.

detailed

Display the session details with data.

summary

Display the session details without data.

db-name *db_name*

Specifies the database name to be queried for displaying the session details.

Must be a string of 1 to 16 characters.

key *key_value*

Specifies the query value.

Must be a string of 0 to 512 characters.

map-id *map_id*

Specifies the map ID to display the data for a map.

Must be an integer in the range of 0-1024.

limit *limit*

Specifies the maximum number of records to display.

Must be an integer in the range of 1 to 500 characters.

filter condition { ends-with | match | starts-with }

Specify the query expression to filter the results of query.

Usage Guidelines

Use this command to display the session details.

cdl show status

Configures the CDL parameters to display the status of the database.

Command Modes

Exec

Syntax Description

cdl status db-name *db_name*

db-name *db_name*

Specifies the database name for displaying the corresponding status.

Must be a string of 1 to 16 characters.

Usage Guidelines

Use this command to display the status of the queried database.

clear l2tp-tunnel

Clears l2tp tunnel.

Command Modes

Exec

Syntax Description

clear l2tp tunnel { **upf** *upf_name* } [**tunnel-type** *tunnel_type* | **tunnel-id** *tunnel_id* | **force**]

force

Specify to force tunnel deletion, even if UP is down.

tunnel-id *tunnel_id*

Specify the tunnel ID.

Must be an integer in the range of 1-65535.

tunnel-type *tunnel_type*

Specify the tunnel type.

Must be one of the following:

- **lac**
- **lms**

upf *upf_name*

Specify name of the User Plane Function.

Must be a string of 1-64 characters.

Usage Guidelines

Use this command to clear l2tp tunnel.

clear subscriber

Clears BNG subscriber data.

Command Modes

Exec

Syntax Description

```
clear subscriber type [ upf upf_name | port-id upf_port_id | mac mac_address |
sublabel subscriber_label | up-subs-id up_subscriber_id | ipv4-pool ipv4_pool_name
| ipv6-addr-pool ipv6_address_pool_name | ipv6-pfx-pool ipv6_prefix_pool_name |
ipv4-range ipv4_address_range | ipv6-addr-range ipv6_address_range | ipv6-pfx-range
ipv6_prefix_range | ppp-type ppp_session_type | session-id session_id | tunnel-id
tunnel_id ]
```

force

Specify to force session deletion, even if UP is down.

ipv4-pool *ipv4_pool_name*

Specify name of the IPv4 address pool.

Must be a string of 1-64 characters.

ipv4-range *ipv4_address_range*

Specify the IPv4 address range in the format "*poolName/start-ip*".

Must be a string of 1-64 characters.

ipv6-addr-pool *ipv6_address_pool_name*

Specify name of the IPv6 address pool.

Must be a string of 1-64 characters.

ipv6-addr-range *ipv6_address_range*

Specify the IPv6 address range in the format "*poolName/start-ip*".

Must be a string of 1-64 characters.

ipv6-pfx-pool *ipv6_prefix_pool_name*

Specify name of the IPv6 prefix pool.

Must be a string of 1-64 characters.

ipv6-pfx-range *ipv6_prefix_range*

Specify the IPv6 prefix range in the format "*poolName/start-pfx*".

Must be a string of 1-64 characters.

mac *mac_address*

Specify the MAC address in the format "*aabb.ccdd.eeff*".

Must be a string of 1-64 characters.

port-id *upf_port_id*

Specify port ID of the user plane function in the "*upf/port-id*" format.

Must be a string of 1-64 characters.

ppp-type *ppp_session_type*

Specify the PPP session type.

Must be one of the following:

- **lac**
- **pta**

session-id *session_id*

Specify the session ID information.

Must be a string of 1-64 characters.

sublabel *subscriber_label*

Specify the subscriber label.

Must be a string of 1-64 characters.

tunnel-id *tunnel_id*

Specify the tunnel ID information.

Must be a string of 1-64 characters.

upf *upf_name*

Specify name of the user plane function.

Must be a string of 1-64 characters.

type

Specify the type.

Must be one of the following:

- **dhcp**
- **lns**
- **pppoe**
- **sessmgr**

Usage Guidelines Use this command to clear BNG subscriber data.

clear subscriber

Clears subscriber data.

Command Modes Exec

Syntax Description `clear subscriber { all | gr-instance gr_instance | imei imei_id | namespace namespace | nf-service nf_service | supi supi_id | config_specific_options }`

all

Specify to remove all subscriber data.

gr-instance *gr_instance*

Specify the subscribers from the GR instance.

imei *imei_id*

Specify the International Mobile Equipment Identity.

Must be a string of 15-16 characters.

namespace *namespace*

NOTE: This keyword is deprecated, use nf-service instead. Specifies the product namespace under which to search.

Default Value: cisco-mobile-infra:none.

nf-service *nf_service*

Specify the network function service under which to search.

Default Value: cisco-mobile-infra:none.

supi *supi_id*

Specify to remove subscriber data associated with the SUPI ID.

Must be a string of 1-63 characters.

Usage Guidelines Use this command to clear subscriber data.

client http header

Configures HTTP header parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client http header user-agent user_agent_header`

user-agent *user_agent_header*

Specify the user agent header.

Must be one of the following:

- **app-name**
- **cluster-name**
- **disable**

Default Value: app-name.

Usage Guidelines Use this command to configure HTTP header parameters.

client http ping

Configures HTTP ping parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client http ping { [interval ping_interval] [timeout ping_timeout] }`

interval *ping_interval*

Specify, in milliseconds, the time interval between two HTTP pings.

Must be an integer in the range of 0-30000.

Default Value: 10000.

timeout *ping_timeout*

Specify, in milliseconds, the ping timeout duration to detect if remote host is down.

Must be an integer in the range of 0-15000.

Default Value: 5000.

Usage Guidelines Use this command to configure HTTP ping parameters.

client inbound interface

Configures inbound client interface parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound interface interface_name`

interface *interface_name*

Specify name of the interface. Must be one of the following: bfd, bgp, coa-nas, geo-external, geo-internal, gtpu, n4.

Usage Guidelines Use this command to configure inbound client interface parameters. The CLI prompt changes to the Interface Configuration mode (config-interface-<interface_name>).

client inbound interface limit overload

Configures Overload configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound limit overload reject-code response_code`

reject-code *response_code*

Specify the response code to be used when pending limit exceeds.

Must be an integer.

Usage Guidelines Use this command to configure Overload configuration parameters.

client inbound interface limit pending

Configures pending request limit parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound limit pending request max_pending_request_limit`
`request max_pending_request_limit`

Specify the maximum pending request limit to allow.

Must be an integer.

Default Value: 10240.

Usage Guidelines Use this command to configure the pending request limit parameter.

client inbound limit overload

Configures Overload configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound limit overload reject-code response_code`
`reject-code response_code`

Specify the response code to be used when pending limit exceeds.

Must be an integer.

Usage Guidelines Use this command to configure Overload configuration parameters.

client inbound limit pending

Configures pending request limit parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound limit pending request max_pending_request_limit`
`request max_pending_request_limit`

Specify the maximum pending request limit to allow.

Must be an integer.

Default Value: 10240.

Usage Guidelines Use this command to configure the pending request limit parameter.

client outbound host ping

Configures outbound host ping parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description `client outbound host ping { [backoff backoff_interval] [interval ping_interval] [timeout ping_timeout] }`

backoff *backoff_interval*

Specify, in milliseconds, the backoff time interval to wait when remote host is detected down before pinging again.

Must be an integer in the range of 0-3600000.

Default Value: 0.

interval *ping_interval*

Specify, in milliseconds, the time interval between two pings.

Must be an integer in the range of 0-30000.

Default Value: 0.

timeout *ping_timeout*

Specify the ping timeout duration, in milliseconds, to detect remote host down.

Must be an integer in the range of 0-15000.

Default Value: 0.

Usage Guidelines Use this command to configure outbound host ping parameter.

client outbound interface

Configures outbound client interface parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client outbound interface interface_name`

interface *interface_name*

Specify the interface.

Usage Guidelines Use this command to configure outbound client interface parameters. The CLI prompt changes to the Interface Configuration mode (config-interface-<interface_name>).

client outbound interface host ping

Configures outbound host ping parameter.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
client outbound host ping { [ backoff backoff_interval ] [ interval ping_interval ] [ timeout ping_timeout ] }
```

backoff *backoff_interval*

Specify, in milliseconds, the backoff time interval to wait when remote host is detected down before pinging again.

Must be an integer in the range of 0-3600000.

Default Value: 0.

interval *ping_interval*

Specify, in milliseconds, the time interval between two pings.

Must be an integer in the range of 0-30000.

Default Value: 0.

timeout *ping_timeout*

Specify the ping timeout duration, in milliseconds, to detect remote host down.

Must be an integer in the range of 0-15000.

Default Value: 0.

Usage Guidelines

Use this command to configure outbound host ping parameter.

client outbound interface limit consecutive failure

Configures consecutive failure configuration parameters.

Command Modes

Exec > Global Configuration

Syntax Description

```
consecutive failure count failure_limit_count codes failure_codes
```

codes *failure_codes*

Specify the list of failure codes to be considered, such as timeout, 503, etc.

Must be a string.

You can configure a maximum of 10 elements with this keyword.

count *consecutive_failure_count*

Specify the consecutive failure limit count to detect remote host as down.

Must be an integer.

Default Value: 0.

Usage Guidelines Use this command to configure consecutive failure configuration parameters.

client outbound interface limit pending

Configures pending limit configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description **client outbound limit pending response** *response_message_limit*

Command Modes Exec > Global Configuration (config) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **pending response** *response_message_limit*

response *response_message_limit*

Specify the pending response message limit to detect remote host as down.

Must be an integer.

Default Value: 1024.

Usage Guidelines Use this command to configure pending limit configuration.

client outbound limit consecutive failure

Configures consecutive failure configuration parameters.

Command Modes Exec > Global Configuration

Syntax Description **consecutive failure count** *failure_limit_count* **codes** *failure_codes*

codes *failure_codes*

Specify the list of failure codes to be considered, such as timeout, 503, etc.

Must be a string.

You can configure a maximum of 10 elements with this keyword.

count *consecutive_failure_count*

Specify the consecutive failure limit count to detect remote host as down.

Must be an integer.

Default Value: 0.

Usage Guidelines Use this command to configure consecutive failure configuration parameters.

client outbound limit pending

Configures pending limit configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description **client outbound limit pending response** *response_message_limit*

Command Modes Exec > Global Configuration (config) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **pending response** *response_message_limit*

response response_message_limit

Specify the pending response message limit to detect remote host as down.

Must be an integer.

Default Value: 1024.

Usage Guidelines Use this command to configure pending limit configuration.

commit

Configures the commit parameters.

Command Modes Exec

Syntax Description **commit** [**abort** { **persist-id** *persist_id* } | **confirm** { **persist-id** *persist_id* } | **persist-id** *persist_id*]

abort persist-id persist_id

Specify to abort commit. Specify the persistence ID for the commit operation.

Must be an integer.

confirm persist-id persist_id

Specify to confirm commit. Specify the persistence ID for the commit operation.

Must be an integer.

persist-id persist_id

Specify the persistence ID for the commit operation.

Must be an integer.

Usage Guidelines Use this command to configure the commit parameters.

compare

Compares the running configuration to another configuration or a file.

Command Modes Exec

Syntax Description `compare file { filename [.kube | .ssh/] | configuration }`

***filename* [.kube | .ssh/]**

Specify the file name or the directory path of the file to be compared.

Must be a string.

configuration

Specify the desired configuration to be compared against.

Must be a string.

Usage Guidelines Use this command to compare the files.

config

Manipulates the software configuration information.

Command Modes Exec

Syntax Description `config [exclusive | no-confirm | shared | terminal]`

exclusive

Specify to enter the exclusive configuration mode.

no-confirm

Specify to apply the command without asking for confirmation.

shared

Specify to enter the shared configuration mode.

terminal

Specify to enter the terminal configuration mode.

Usage Guidelines Use this command to manipulate the software configuration information.

datastore dbs

Configures DBS parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **datastore dbs** *db_name* **endpoints** *endpoint_name* **port** *port_number*

db *db_name*

Specify name of the DBS.

Must be a string.

Usage Guidelines Use this command to configure the DBS parameters. The CLI prompt changes to the DBS Configuration mode (config-dbs-<db_name>).

datastore dbs endpoints

Configures endpoint parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **datastore session-db endpoints** *host_name* **port** *port_number*

Command Modes Exec > Global Configuration (config) > DBS Configuration (config-dbs-*db_name*)

Syntax Description **endpoints** *endpoint_name* **port** *port_number*

endpoints *endpoint_name*

Specify name of the endpoint host.

Must be a string.

port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure endpoint parameters.

datastore notification-ep

Configures notification endpoint parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `datastore notification-ep { [host host_name] [port port_number] }`

host *host_name*

Specify name of the host.

Must be a string.

port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure notification endpoint parameters.

datastore session-db

Configures Session DB parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `datastore session-db endpoints endpoint_name port port_number`

Usage Guidelines Use this command to configure Session DB parameters.

datastore session-db endpoints

Configures endpoint parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `datastore session-db endpoints host_name port port_number`

Command Modes Exec > Global Configuration (config) > DBS Configuration (config-dbs-*dbs_name*)

Syntax Description `endpoints endpoint_name port port_number`

endpoints *endpoint_name*

Specify name of the endpoint host.

Must be a string.

port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure endpoint parameters.

deployment

Configures the product deployment parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **deployment** { **app-name** *application_name* | **cluster-name** *cluster_name* | **dc-name** *datacenter_name* | **logical-nf-instance-id** *logical_nf_instance_id* | **model** *deployment_model* }

app-name *application_name*

Specify name of the application.

Must be a string.

cluster-name *cluster_name*

Specify name of the cluster.

Must be a string.

dc-name *datacenter_name*

Specify name of the datacenter.

Must be a string.

logical-nf-instance-id *logical_nf_instance_id*

Specify the logical NF instance ID.

Must be an integer.

Default Value: 0.

model *deployment_model*

Specify the deployment model. Default: Large.

Must be one of the following:

- **small**

Usage Guidelines Use this command to configure product deployment parameters.

deployment resource

Configures the deployment CPU resource parameter.

Command Modes Exec > Global Configuration (config) > Deployment Configuration (config-deployment)

Syntax Description `resource cpu cpu_size`

cpu *cpu_size*

Specify the CPU size in millicores.

Must be an integer in the range of 2000-1000000.

Default Value: 18000.

Usage Guidelines Use this command to configure the deployment CPU resource parameter.

describe

Displays the command information.

Command Modes Exec

Syntax Description `describe command`

command

Specify the command name to display detailed information about the command.

The command must be one of the following:

- **aaa**
- **cd**
- **cdl**
- **commit**
- **compare**
- **config**
- **describe**
- **dump**
- **exit**
- **help**
- **history**
- **id**
- **idle-timeout**
- **ignore-leading-space**
- **job**
- **leaf-prompting**

- **license**
- **logout**
- **monitor**
- **no**
- **paginate**
- **quit**
- **rcm**
- **screen-length**
- **screen-width**
- **send**
- **show**
- **show-defaults**
- **smiuser**
- **system**
- **terminal**
- **timestamp**
- **who**

Usage Guidelines Use this command to display the command specific information.

dump transactionhistory

Creates dump of transaction history.

Command Modes Exec

Syntax Description `dump transactionhistory`

Usage Guidelines Use this command to create dump of transaction history.

edr

Configures EDR reporting parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `edr { [reporting reporting_status] [subscribers subscribers_edr_reporting] }`

reporting *reporting_status*

Specify to enable or disable EDR reporting.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines Use this command to configure EDR parameters.

edr edrsubscribers

Configures subscriber EDR reporting.

Command Modes Exec > Global Configuration (config)

Syntax Description **edr subscribers** *subscribers_for_edr_reporting*

Syntax Description **edr reporting { enable | disable } subscribers** *subscribers_for_edr_reporting*

subscribers *subscribers_for_edr_reporting*

Specify the subscribers to enable EDR reporting. For example, imsi-123456789012345.

Must be a string.

You can configure a maximum of 10 elements with this keyword.

Usage Guidelines Use this command to configure subscriber EDR reporting.

edr file files

Configures EDR file parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **edr file { transaction | transaction-collision } [reporting *reporting_status*] [verbose *verbosity_status*]**

file { transaction | transaction-collision }

Specify name of the EDR file.

reporting *reporting_status*

Specify to enable or disable reporting of this file.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

verbose *verbosity_status*

Specify to enable or disable field description or long names in the file.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines Use this command to configure EDR file parameters.

edr file files disable

Disables procedure IDs.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description **disable procedure-id** *procedure_ids*

procedure-id *procedure_ids*

Specify the procedure ID value(s)/name(s).

Must be a string.

Usage Guidelines Use this command to disable specific procedure IDs.

edr file files flush

Configures EDR file flush parameters.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description **flush interval** *file_flush_interval*

interval *file_flush_interval*

Specify, in milliseconds, the file flush interval.

Must be an integer.

Default Value: 1000.

Usage Guidelines Use this command to configure the EDR file flush parameters.

edr file files limit

Configures EDR file limit parameters.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description `limit { [count max_files_to_preserve] [size max_single_file_size] }`

count *max_files_to_preserve*

Specify the maximum number of files to be preserved.

Must be an integer.

Default Value: 10.

size *max_single_file_size*

Specify the maximum single file size limit in MB.

Must be an integer.

Default Value: 100.

Usage Guidelines Use this command to configure the EDR file limit parameters.

edr file files procedure-id disable-event-id

Disables transaction-level procedure ID configuration.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description `procedure-id procedure_id`

procedure *procedure_id*

Specify the procedure ID value/name.

Must be a string.

Usage Guidelines Use this command to disable transaction-level procedure ID configuration.

edr file files procedure-id disable-event-id disable-inner disable

Disables event IDs.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*) > Procedure ID Configuration (config-procedure-id-*procedure_id*)

Syntax Description `disable event-id event_ids`

event-id *event_ids*

Specify the event ID value(s)/name(s).

Must be a string.

Usage Guidelines Use this command to disable event IDs.

edr file files procedure-id disable-event-id disable-inner event-id disable-field-id

Disables procedure-level event ID configuration.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*) > Procedure ID Configuration (config-procedure-id-*procedure_id*)

Syntax Description `event-id event_id`

event *event_id*

Specify the event ID value/name.

Must be a string.

Usage Guidelines Use this command to disable procedure-level event ID configuration.

edr file files procedure-id disable-event-id disable-inner event-id disable-field-id disable

Disables field IDs.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*) > Procedure ID Configuration (config-procedure-id-*procedure_id*)

Syntax Description `disable field-id field_ids`

field-id *field_ids*

Specify the field ID value(s)/name(s).

Must be a string.

Usage Guidelines Use this command to disable field IDs.

exit

Exits the current configuration mode and returns to the previous configuration mode.

Command Modes

Exec

Syntax Description

exit

Usage Guidelines

Use this command to exit the current configuration mode and return to the previous configuration mode. When used in the Exec mode, exits the management session.

geo maintenance

Configures Geo Admin Controller to enable or disable maintenance mode.

Command Modes

Exec

Syntax Description

geo maintenance mode { false | true }

mode { false | true }

Specify whether to enable or disable maintenance mode. To enable, set to true.

Must be one of the following:

- **false**
- **true**

Default Value: false.

Usage Guidelines

Use this command to configure Geo Admin Controller to enable or disable maintenance mode.

geo reset-role

Configures Geo Admin Controller for reset role.

Command Modes

Exec

Syntax Description

geo reset-role { [instance-id *instance_id*] [role *new_role*] }

instance-id *instance_id*

Specify the instance ID for geo command.

role *new_role*

Specify the new role for the specified site.

Usage Guidelines Use this command to configure Geo Admin Controller for reset role.

geo switch-role

Configures Geo Admin Controller for trigger failover.

Command Modes Exec

Syntax Description `geo switch-role { [failback-interval failback_interval] [instance-id instance_id] [role new_role] }`

failback-interval *failback_interval*

Specify, in seconds, the interval between notify failover and actual failover.

Must be a string.

instance-id *instance_id*

Specify the instance ID for geo command.

role *new_role*

Specify the new role for the specified site.

Usage Guidelines Performs instance role manipulation. Use this command to configure Geo Admin Controller for trigger failover.

geomonitor podmonitor pods

Configures configuration of pods to be monitored.

Command Modes Exec > Global Configuration (config)

Syntax Description `geomonitor podmonitor pods pod_name [[failedReplicaPercent failed_replica_precentage] [retryCount retry_count] [retryFailOverInterval retry_interval] [retryInterval retry_interval]]`

failedReplicaPercent *failed_replica_precentage*

Specify the percentage of failed replica after which GR failover will get triggered.

Must be an integer in the range of 10-100.

pods *pod_name*

Specify the name of the pod to be monitored.

Must be a string.

retryCount *retry_count*

Specify the counter value to retry if pod failed to ping after which pod is marked as down.

Must be an integer in the range of 1-10.

retryFailOverInterval *retry_interval*

Specify, in milliseconds, the retry interval if pod ping fails.

Must be an integer in the range of 200-10000.

retryInterval *retry_interval*

Specify, in milliseconds, the retry interval if pod ping is successful.

Must be an integer in the range of 200-10000.

Usage Guidelines

Use this command to configure configuration of pods to be monitored.

geomonitor remotecclustermonitor

Configures remote cluster monitoring parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
geomonitor remotecclustermonitor retryCount retry_count retryInterval  
retry_interval
```

retryCount *retry_count*

Specify the retry count if remote cluster is not reachable. To disable, set to 0.

Must be an integer in the range of 0-10.

Default Value: 3.

retryInterval *retry_interval*

Specify, in milliseconds, the retry interval after which status of the remote site will be fetched.

Must be an integer in the range of 200-50000.

Default Value: 3000.

Usage Guidelines

Use this command to configure remote cluster monitoring parameters.

geomonitor trafficMonitor

Configures traffic monitoring configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description `geomonitor trafficMonitor thresholdCount threshold_count thresholdInterval threshold_interval`

thresholdCount *threshold_count*

Specify the number of calls received for standby instance. To disable, set to 0.

Must be an integer in the range of 0-10000.

Default Value: 0.

thresholdInterval *threshold_interval*

Specify, in milliseconds, the maximum duration window to hit the threshold count value.

Must be an integer in the range of 100-10000.

Default Value: 3000.

Usage Guidelines Use this command to configure traffic monitoring configuration.

geomonitor vipmonitor

Configures VIP monitoring configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description `geomonitor vipmonitor instance-id instance_id`

Usage Guidelines Use this command to configure VIP monitoring configuration.

geomonitor vipmonitor instance

Configures VIP monitoring parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `vipmonitor instance instance-id instance_id`

instance-id *instance_id*

Specify the instance ID.

Must be an integer in the range of 1-8.

Usage Guidelines Configuration of VIPs to be monitored. Use this command to configure the instance ID.

geomonitor vipmonitor instance vips

Configures VIP interface monitoring parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
geomonitor vipmonitor instance instance_id vips vip_interface_name [ retryCount
retry_count | retryFailOverInterval retry_interval | retryInterval retry_interval
| vipIp vip_ip | vipPort vip_port_number ]
```

retryCount *retry_count*

Specify the counter value to retry if VIP failed to ping after which VIP is marked as down.

Must be an integer in the range of 1-10.

retryFailOverInterval *retry_interval*

Specify, in milliseconds, the retry interval if VIP failed to ping.

Must be an integer in the range of 200-10000.

retryInterval *retry_interval*

Specify, in milliseconds, the retry interval if VIP pinged successfully.

Must be an integer in the range of 200-10000.

vipIp *vip_ip*

Specify the IPv4 address.

Must be a string.

vipPort *vip_port_number*

Specify the diagnostic port number.

Must be an integer.

vip_interface_name

Specify name of the interface to monitor.

Must be a string.

Usage Guidelines

Use this command to configure VIP monitoring configuration.

helm

Configures Helm configuration parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
helm default-repository default_repository_name
```

default-repository *default_repository_name*

Specify the name of the default Helm repository.

Usage Guidelines Use this command to configure Helm configuration parameters.

helm charts

Displays Helm release details.

Command Modes Exec > Global Configuration (config)

Syntax Description **charts**

Usage Guidelines Use this command to view Helm release details.

helm repository

Configures Helm repository parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **helm repository** *helm_repo_name* [[**access-token** *access_token*] [**password** *helm_repo_password*] [**url** *helm_repo_url*] [**username** *helm_repo_username*]]

access-token *helm_repo_access_token*

Specify the access token for the Helm repository.

Must be a string.

helm repository *helm_repo_name*

Specify the name of the Helm repository.

Must be a string.

password *helm_repo_password*

Specify the password for the Helm repository.

url *helm_repo_url*

Specify the URL for the Helm repository.

Must be a string.

username *helm_repo_username*

Specify the username for the Helm repository.

Must be a string.

Usage Guidelines Use this command to configure the Helm repository parameters.

help

Displays help information for a specified command.

Command Modes

Exec

Syntax Description

help *command*

command

Specify the command name to display the corresponding help information.

The command must be one of the following:

- **aaa**
- **cd**
- **cdl**
- **commit**
- **compare**
- **config**
- **describe**
- **dump**
- **exit**
- **help**
- **history**
- **id**
- **idle-timeout**
- **ignore-leading-space**
- **job**
- **leaf-prompting**
- **license**
- **logout**
- **monitor**
- **no**
- **paginate**
- **quit**
- **rcm**

- **screen-length**
- **screen-width**
- **send**
- **show**
- **show-defaults**
- **smiuser**
- **system**
- **terminal**
- **timestamp**
- **who**

Usage Guidelines Use this command to view help information for a specified command.

history

Configures the command history cache size.

Command Modes Exec

Syntax Description **history** *history_size*

history_size

Specify the command history cache size.

Must be an integer in the range of 0-1000.

Usage Guidelines Use this command to configure the command history cache size.

id

Displays user ID information.

Command Modes Exec

Syntax Description **id**

Usage Guidelines Use this command to view the user ID information.

idle-timeout

Configures the maximum duration a command can remain idle in seconds after which the system automatically terminates the connection.

Command Modes Exec

Syntax Description `idle-timeout duration`

duration

Specify the idle timeout duration in seconds.

Must be an integer in the range of 1-8192.

Usage Guidelines Use this command to configure the maximum duration a command can remain idle.

ignore-leading-space

Configures whether to ignore or consider the leading whitespace at the beginning of a command.

Command Modes Exec

Syntax Description `ignore-leading-space { false | true }`

`{ false | true }`

Specify false to ignore the leading whitespace, and true to consider it.

Must be either "false" or "true".

Usage Guidelines Use this command to configure whether to ignore or consider leading whitespace at the beginning of a command.

infra metrics experimental

Configures the experimental metrics version to be enabled.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra metrics experimental version experimental_metrics_version`

`version experimental_metrics_version`

Specify the experimental metrics version to be enabled.

Must be an integer in the range of 0-4.

Default Value: 0.

Usage Guidelines Use this command to configure the experimental metrics version to be enabled.

infra metrics verbose verboseLevels

Configures verbose configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra metrics verbose pod_type level verbose_level`

level *verbose_level*

Specify the default verbosity level.

Must be one of the following:

- **debug**
- **off**
- **production**
- **trace**

Default Value: trace.

pod_type

Specify the pod type.

Must be one of the following:

- **application**
- **load-balancer**
- **protocol**
- **service**

Usage Guidelines Use this command to configure verbose configuration parameters.

infra metrics verbose verboseLevels metrics metricsList

Configures metrics verbose level parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra metrics verbose pod_type metrics metrics_name granular-labels granular_labels
level metrics_verbose_level`

granular-labels *granular_labels*

Specify the granular labels.

Must be a string.

level *metrics_verbose_level*

Specify the metrics verbosity level.

Must be one of the following:

- **debug**
- **off**
- **production**
- **trace**

Default Value: trace.

metrics *metrics_name*

Specify the name of the metrics.

Must be a string.

Usage Guidelines Use this command to configure metrics verbose level parameters.

infra transaction limit

Configures the maximum stage limit per transaction.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra transaction limit stage max_stage_limit`

stage *max_stage_limit*

Specify the maximum stage limit per transaction.

Must be an integer.

Default Value: 100.

Usage Guidelines Use this command to configure the maximum stage limit per transaction.

infra transaction limit consecutive same

Configures the maximum consecutive stage limit per transaction.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra transaction limit consecutive same stage max_consecutive_stage_limit`

stage *max_consecutive_stage_limit*

Specify the maximum consecutive stage limit per transaction.

Must be an integer.

Default Value: 10.

Usage Guidelines Use this command to configure the maximum consecutive stage limit per transaction.

infra transaction loop

Configures the transaction loop detection parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra transaction loop detection detection_status`

detection *detection_status*

Specify to enable or disable loop detection.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines Use this command to configure the transaction loop detection parameter.

infra transaction loop category

Configures the loop category.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra transaction loop category loop_category`

category *loop_category*

Specify the category.

Usage Guidelines Use this command to configure the loop category. The CLI prompt changes to the Loop Category Configuration mode(config-category-<category>).

infra transaction loop category threshold

Configures the loop detection interval parameter.

Command Modes Exec > Global Configuration (config) > Loop Category Configuration (config-category-*category*)

Syntax Description **threshold interval** *loop_detect_interval*

interval *loop_detect_interval*

Specify, in seconds, the loop detection interval.

Must be an integer.

Default Value: 5.

Usage Guidelines Use this command to configure the loop detection interval parameter.

infra transaction loop category threshold thresholds

Configures thresholds.

Command Modes Exec > Global Configuration (config) > Loop Category Configuration (config-category-*category*)

Syntax Description **thresholds** *threshold_level* [[**action** *threshold_action*] [**count** *max_transactions*]]

action *threshold_action*

Specify the action to take on threshold breach.

Must be one of the following:

- **kill-session**
- **log-event**
- **noop**

Default Value: noop.

count *max_transactions*

Specify the maximum number of transactions for the threshold interval.

Must be an integer.

Default Value: 100.

thresholds *threshold_level*

Specify the threshold level.

Must be one of the following:

- **high**
- **low**

Usage Guidelines Use this command to configure thresholds.

instance instance-id

Configures instance ID of GR instance.

Command Modes Exec > Global Configuration (config)

Syntax Description **instance instance-id** *instance_id*

instance-id *instance_id*

Specify the instance ID.

Usage Guidelines GR instance-specific parameters. Use this command to configure the instance ID of GR instance. The CLI prompt changes to the Instance ID Configuration mode (config-instance-id-<instance_id>).

instance instance-id endpoint ep

Configures endpoint parameters.

Command Modes Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id-*instance_id*)

Syntax Description **endpoint** *endpoint_type* [[**instancetype** *ep_local_interface_type*] [**loopbackEth** *loopbackEth*] [**loopbackPort** *loopbackPort*] [**nodes** *node_replicas_for_resiliency*] [**replicas** *replicas_per_node*] [**uri-scheme** *uri_scheme*]]

certificate-name *certificate_alias_name*

Specify the alias name for the certificate.

endpoint *endpoint_type*

Specify the endpoint type. Must be one of the following: bgpspeaker, dhcp, geo, l2tp-tunnel, n4-protocol, nodemgr, ppoe, radius, sbi, sm, udp-proxy.

instancetype *ep_local_interface_type*

Specify the endpoint local interface type.

Must be one of the following:

- **Dual**
- **IPv4**

- **IPv6**

Default Value: IPv4.

internal-vip

Specify the internal VIP.

Must be a string of 1-128 characters.

loopbackEth *loopbackEth*

Specify the endpoint local interface name or host IP.

Must be a string.

loopbackPort *loopbackPort*

Specify the endpoint local port.

Must be an integer.

nodes *node_replicas_for_resiliency*

Specify the number of node replicas for resiliency.

Must be an integer.

Default Value: 1.

replicas *replicas_per_node*

Specify the number of replicas per node.

Must be an integer.

Default Value: 1.

uri-scheme *uri_scheme*

Specify the URI scheme.

Must be one of the following:

- **http**
- **https**

Default Value: http.

Usage Guidelines

Use this command to configure endpoint parameters.

instance instance-id endpoint ep cpu

Configures K8 pod CPU configuration.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Syntax Description `cpu { [max-process max_parallel_os_threads] [request cpu_resource_request] }`

max-process *max_parallel_os_threads*

Specify the maximum parallel OS threads to use.

Must be an integer in the range of 1-32.

request *cpu_resource_request*

Specify the CPU resource request in millicores.

Must be an integer in the range of 100-1000000.

Usage Guidelines Use this command to configure K8 pod CPU configuration.

instance instance-id endpoint ep interface

Configures endpoint interfaces.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service*)

Syntax Description `interface interface_type [[instancetype ep_local_interface_type] [loopbackEth loopback_eth] [loopbackPort loopback_port_number] [uri-scheme uri_scheme]]`

certificate-name *certificate_alias_name*

Specify the alias name for certificate.

instancetype *ep_local_interface_type*

Specify the endpoint local interface type.

Must be one of the following:

- Dual
- IPv4
- IPv6

Default Value: IPv4.

interface *interface_type*

Specify the interface type.

loopbackEth *loopback_eth*

Specify the Loopback Eth pod interface.

Must be a string.

loopbackPort *loopback_port_number*

Specify the loopback port number.

Must be an integer.

uri-scheme *uri_scheme*

Specify the URI scheme.

Must be one of the following:

- **http**
- **https**

Default Value: http.

Usage Guidelines Use this command to configure endpoint interfaces.

instance instance-id endpoint ep interface dispatcher

Configures dispatcher queue support for the interface.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **dispatcher** [[**cache** { **false** | **true** }] [**capacity** *queue_capacity*] [**count** *dispatcher_queue_count*] [**expiry** *cache_entry_expiry_duration*] [**nonresponsive** *cache_entry_expiry_duration*] [**outbound** { **false** | **true** }] [**rate-limit** *queue_rate_limit*] [**threshold** *outstanding_requests*]

cache { false | true }

Specify whether to disable or enable retransmission cache support. To enable, set to false.

Must be one of the following:

- **false**
- **true**

Default Value: false.

capacity *queue_capacity*

Specify the capacity of each queue.

Must be an integer.

Default Value: 5000.

count *dispatcher_queues_count*

Specify the count of dispatcher queues.

Must be an integer.

Default Value: 0.

expiry *expiry_duration*

Specify the responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 60000.

nonresponsive *nonresponsive_duration*

Specify the not responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 30000.

outbound { false | true }

Specify whether to disable or enable queue support for outbound messages. To enable, set to false.

Must be one of the following:

- false
- true

Default Value: true.

rate-limit *rate_limit*

Specify the rate limit for each queue.

Must be an integer.

Default Value: 0.

threshold *outstanding_requests*

Specify the outstanding requests per queue cache.

Must be an integer.

Default Value: 30000.

Usage Guidelines Use this command to configure dispatcher queue support for the interface.

instance instance-id endpoint ep interface internal base-port

Configures base-port to start endpoint parameter.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description `internal base-port start base_port_to_start_ep`

start base_port_to_start_ep

Specify the base-port to start endpoint.

Must be an integer in the range of 1024-65535.

Usage Guidelines Use this command to configure the base-port to start endpoint parameter.

instance instance-id endpoint ep interface sla

Configures SLA parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description `sla { [response response_time] [procedure procedure_time] }`

procedure procedure_time

Specify, in milliseconds, the procedure time.

Must be an integer in the range of 1000-120000.

response response_time

Specify, in milliseconds, the response time.

Must be an integer in the range of 1000-180000.

Usage Guidelines Use this command to configure SLA parameters.

instance instance-id endpoint ep interface vip

Configures Virtual IP parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip-ip** *vip_ip_address* [[**offline**] [**vip-interface** *interface_name*] [**vip-port** *vip_port_number*]]

offline

Specify to mark the vip-ip as offline.

vip-interface *interface_name*

Specify the interface name to advertise BGP router.

Must be a string.

vip-ip *vip_ip_address*

Specify the IP address of the host.

Must be a string.

vip-port *vip_port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure Virtual IP parameters.

instance instance-id endpoint ep interface vip6

Configures VIP IP6 parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip6 vip-ip6** *vip_ip6* [[**offline**] [**vip-ipv6-port** *port_number*]]

offline

Specify the VIP IP as offline.

vip-ip6 *vip_ip6*

Specify the host detail.

Must be a string.

vip-ipv6-port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure VIP IP6 parameters.

instance instance-id endpoint ep memory

Configures K8 pod memory configuration.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Syntax Description `memory { [limit max_memory_resource] [request memory_resource_request] }`

limit *max_memory_resource*

Specify the maximum memory resource in use in megabytes.

Must be an integer in the range of 100-200000.

request *memory_resource_request*

Specify the memory resource request in megabytes.

Must be an integer in the range of 100-200000.

Usage Guidelines Use this command to configure K8 pod memory configuration.

instance instance-id endpoint ep retransmission

Configures PFCP retransmission configuration.

Command Modes Exec > Global Configuration

Syntax Description `retransmission max-retry max_retry timeout pfcp_retransmission_interval`

max-retry *max_retry*

Specify the maximum number of times PFCP request retry attempts. To disable retransmission, set to 0.

Must be an integer in the range of 0-1.

Default Value: 1.

timeout *pfcp_retransmission_interval*

Specify the PFCP retransmission interval in seconds.

Must be an integer in the range of 0-15.

Default Value: 15.

Usage Guidelines Use this command to configure PFCP retransmission configuration.

instance instance-id endpoint ep service

Configures VIP IPv6 parameters.

Command Modes Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id-*instance_id*) > Endpoint *endpoint_type* Configuration (config-endpoint-*endpoint_type*)

Syntax Description **service service-name** *service_name*

service-name *service_name*

Specify the service name.

Must be a string in the pattern [A-Za-z0-9-].*[0-9].*

Usage Guidelines Use this command to configure VIP IPv6 parameters.

instance instance-id endpoint ep service interface

Configures endpoint interfaces.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service*)

Syntax Description **interface** *interface_type* [[**instancetype** *ep_local_interface_type*] [**loopbackEth** *loopback_eth*] [**loopbackPort** *loopback_port_number*] [**uri-scheme** *uri_scheme*]]

certificate-name *certificate_alias_name*

Specify the alias name for certificate.

instancetype *ep_local_interface_type*

Specify the endpoint local interface type.

Must be one of the following:

- **Dual**
- **IPv4**
- **IPv6**

Default Value: IPv4.

interface *interface_type*

Specify the interface type.

loopbackEth *loopback_eth*

Specify the Loopback Eth pod interface.

Must be a string.

loopbackPort *loopback_port_number*

Specify the loopback port number.

Must be an integer.

uri-scheme *uri_scheme*

Specify the URI scheme.

Must be one of the following:

- **http**
- **https**

Default Value: http.

Usage Guidelines Use this command to configure endpoint interfaces.

instance instance-id endpoint ep service interface dispatcher

Configures dispatcher queue support for the interface.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **dispatcher** [[**cache** { **false** | **true** }] [**capacity** *queue_capacity*] [**count** *dispatcher_queue_count*] [**expiry** *cache_entry_expiry_duration*] [**nonresponsive** *cache_entry_expiry_duration*] [**outbound** { **false** | **true** }] [**rate-limit** *queue_rate_limit*] [**threshold** *outstanding_requests*]

cache { false | true }

Specify whether to disable or enable retransmission cache support. To enable, set to false.

Must be one of the following:

- **false**
- **true**

Default Value: false.

capacity *queue_capacity*

Specify the capacity of each queue.

Must be an integer.

Default Value: 5000.

count *dispatcher_queues_count*

Specify the count of dispatcher queues.

Must be an integer.

Default Value: 0.

expiry *expiry_duration*

Specify the responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 60000.

nonresponsive *nonresponsive_duration*

Specify the not responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 30000.

outbound { false | true }

Specify whether to disable or enable queue support for outbound messages. To enable, set to false.

Must be one of the following:

- false
- true

Default Value: true.

rate-limit *rate_limit*

Specify the rate limit for each queue.

Must be an integer.

Default Value: 0.

threshold *outstanding_requests*

Specify the outstanding requests per queue cache.

Must be an integer.

Default Value: 30000.

Usage Guidelines Use this command to configure dispatcher queue support for the interface.

instance instance-id endpoint ep service interface internal base-port

Configures base-port to start endpoint parameter.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **internal base-port start** *base_port_to_start_ep*

start *base_port_to_start_ep*

Specify the base-port to start endpoint.

Must be an integer in the range of 1024-65535.

Usage Guidelines Use this command to configure the base-port to start endpoint parameter.

instance instance-id endpoint ep service interface overload-control client threshold critical

Configures the Overload Control Protection critical threshold parameter.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **overload-control threshold critical** *critical_threshold_limit* **action** *critical_threshold_action*

Syntax Description **overload-control client threshold critical** *critical_threshold_limit* **action** *critical_threshold_action*

action *critical_threshold_action*

Specify the action to be taken if the critical threshold is hit.

critical *critical_threshold_limit*

Specify the critical threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control protection's critical threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control client threshold high

Configures the Overload Control Protection high threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold high *high_threshold_limit* **action** *high_threshold_action*

Syntax Description

overload-control client threshold high *high_threshold_limit* **action**
high_threshold_action

action *high_threshold_action*

Specify the action to be taken when high threshold limit is hit.

high *high_threshold_limit*

Specify the high threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection high threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control client threshold low

Configures the Overload Control Protection low threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold low *low_threshold_limit* **action** *low_threshold_action*

Syntax Description

overload-control client threshold low *low_threshold_limit* **action**
low_threshold_action

action *low_threshold_action*

Specify the action to be taken when low threshold limit is hit.

low *low_threshold_limit*

Specify the low threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection low threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control endpoint threshold critical

Configures the Overload Control Protection critical threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold critical *critical_threshold_limit* **action**
critical_threshold_action

Syntax Description

overload-control client threshold critical *critical_threshold_limit* **action**
critical_threshold_action

action *critical_threshold_action*

Specify the action to be taken if the critical threshold is hit.

critical *critical_threshold_limit*

Specify the critical threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control protection's critical threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control endpoint threshold high

Configures the Overload Control Protection high threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold high *high_threshold_limit* **action** *high_threshold_action*

Syntax Description

overload-control client threshold high *high_threshold_limit* **action**
high_threshold_action

action *high_threshold_action*

Specify the action to be taken when high threshold limit is hit.

high *high_threshold_limit*

Specify the high threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection high threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control endpoint threshold low

Configures the Overload Control Protection low threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold low *low_threshold_limit* **action** *low_threshold_action*

Syntax Description

overload-control client threshold low *low_threshold_limit* **action**
low_threshold_action

action *low_threshold_action*

Specify the action to be taken when low threshold limit is hit.

low *low_threshold_limit*

Specify the low threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection low threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control msg-type message

Configures the message configuration parameters.

Command Modes

Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control msg-type *message_type* **pending-request** *pending_requests*
queue-size *queue_size* **rate-limit** *rate_limit* **reject-threshold** *reject_threshold*

msg-type *message_type*

Specify the message type.

pending-request *pending_requests*

Specify the pending requests count in virtual queue.

Must be an integer.

queue-size *queue_size*

Specify the packet count or capacity of each virtual queue.

Must be an integer.

rate-limit *rate_limit*

Specify the rate limit for virtual queue.

Must be an integer.

reject-threshold *reject_threshold*

Specify the limit to reject incoming messages if this threshold percentage of pending requests are present.

Must be an integer.

Usage Guidelines

Use this command to configure the message configuration parameters.

instance instance-id endpoint ep service interface sla

Configures SLA parameters.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
sla { [ response response_time ] [ procedure procedure_time ] }
```

procedure *procedure_time*

Specify, in milliseconds, the procedure time.

Must be an integer in the range of 1000-120000.

response *response_time*

Specify, in milliseconds, the response time.

Must be an integer in the range of 1000-180000.

Usage Guidelines

Use this command to configure SLA parameters.

instance instance-id endpoint ep service interface vip

Configures Virtual IP parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip-ip** *vip_ip_address* [[**offline**] [**vip-interface** *interface_name*] [**vip-port** *vip_port_number*]]

offline

Specify to mark the vip-ip as offline.

vip-interface *interface_name*

Specify the interface name to advertise BGP router.

Must be a string.

vip-ip *vip_ip_address*

Specify the IP address of the host.

Must be a string.

vip-port *vip_port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure Virtual IP parameters.

instance instance-id endpoint ep service interface vip6

Configures VIP IP6 parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip6 vip-ip6** *vip_ip6* [[**offline**] [**vip-ipv6-port** *port_number*]]

offline

Specify the VIP IP as offline.

vip-ip6 *vip_ip6*

Specify the host detail.

Must be a string.

vip-ipv6-port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure VIP IP6 parameters.

instance instance-id endpoint ep system-health-level crash

Configures system health crash parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description **system-health-level crash** { [**cpu-percent** *cpu_percentage*] [**memory-in-mbs** *memory*] [**num-of-goroutine** *goroutine_per_core*] }

cpu-percent *cpu_percentage*

Specify the CPU percentage.

Must be an integer.

Default Value: 80.

memory-in-mbs *memory*

Specify the memory in MB.

Must be an integer.

Default Value: 2048.

num-of-goroutine *goroutine_per_core*

Specify the number of goroutine per core.

Must be an integer.

Default Value: 45000.

Usage Guidelines Use this command to configure system health crash parameters.

instance instance-id endpoint ep system-health-level critical

Configures system health critical parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description **critical** { [**cpu-percent** *cpu_percent*] [**memory-in-mbs** *memory*] [**num-of-goroutine** *number_of_goroutine*] }

cpu-percent *cpu_percentage*

Specify the CPU percentage.

Must be an integer.

Default Value: 60.

memory-in-mbs *memory*

Specify the memory in MB.

Must be an integer.

Default Value: 1024.

num-of-goroutine *number_of_goroutine*

Specify the number of goroutine per core.

Must be an integer.

Default Value: 35000.

Usage Guidelines

Use this command to configure system health critical parameters.

instance instance-id endpoint ep system-health-level warn

Configures system health warn parameters.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description

```
system-health-level warn { [ cpu-percent cpu_percentage ] [ memory-in-mbs
memory ] [ num-of-goroutine number_of_goroutine ] }
```

cpu-percent *cpu_percentage*

Specify the CPU percentage.

Must be an integer.

Default Value: 50.

memory-in-mbs *memory*

Specify the memory in MBs.

Must be an integer.

Default Value: 512.

num-of-goroutine *goroutine_per_core*

Specify the number of goroutine per core.

Must be an integer.

Default Value: 25000.

Usage Guidelines Use this command to configure system health warn parameters.

instance instance-id endpoint ep vip

Configures VIP parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description **vip-ip** *vip_ipv4_address* [[**offline**] [**vip-interface** *vip_interface_name*] [**vip-port** *port_number*]]

offline

Specify the VIP-IP as offline.

vip-interface *vip_interface_name*

Specify the interface name to advertise BGP router.

Must be a string.

vip-ip *vip_ipv4_address*

Specify the VIP IPv4 address.

Must be a string.

vip-port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure VIP parameters.

instance instance-id endpoint ep vip6

Configures VIP IPv6 parameters.

Command Modes Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description **vip-ipv6** *vip_ipv6_detail* [[**offline**] [**vip-ipv6-port** *vip_ipv6_port_number*]]

offline

Specify the VIP-IP as offline.

vip-ipv6-port vip_ipv6_port_number

Specify the port number.

Must be an integer.

vip-ipv6 vip_ipv6_detail

Specify the IPv6 detail.

Must be a string.

Usage Guidelines Use this command to configure VIP IPv6 parameters.

instances instance

Configures instance configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **instances instance** *instance_id* [[**cluster-id** *cluster_id*] [**system-id** *system_id*] [**slice-name** *slice_name*]]

cluster-id cluster_id

Specify the instance cluster ID.

Must be a string.

instance-id instance_id

Specify the instance ID.

Must be an integer in the range of 1-8.

slice-name slice_name

Specify the CDL slice name associated with instance ID.

Must be a string.

system-id system_id

Specify the instance system ID.

Must be a string.

Usage Guidelines Use this command to configure instance configuration parameters.

ipam instance

Configures IPAM instance parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **ipam instance** *instance_id*

instance *instance_id*

Specify the instance ID.

Must be an integer in the range of 1-8.

Usage Guidelines Use this command to configure IPAM instance parameters. The CLI prompt changes to the Instance Configuration mode (config-instance-<instance_id>).

ipam instance address-pool

Configures IPAM address pools.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **address-pool** *pool_name* [**address-quarantine-qsize** *address_quarantine_queue_size* | **address-quarantine-timer** *address_quarantine_timer_interval* | **offline** | **static** | **vrf-name** *vrf_name*]

address-pool *pool_name*

Specify name of the address pool.

Must be a string of 1-128 characters in the ipam-str pattern. For information on the ipam-str pattern, see the *Input Pattern Types* chapter.

address-quarantine-qsize *address_quarantine_queue_size*

Specify the maximum number of IPs to be held in quarantine queue per-dp, per-af, per-instance. By default, it is set to 0 (no limit).

Must be an integer.

address-quarantine-timer *address_quarantine_timer_interval*

Specify the address quarantine timer interval in seconds.

Must be an integer in the range of 4-3600.

Default Value: 4.

offline

Specify the pool as an offline pool.

vrf-name *vrf_name*

Specify name of the VRF.

Must be a string of 1-128 characters in the ipam-str pattern. For information on the ipam-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPAM address pools. The CLI prompt changes to the Address Pool Configuration mode (config-address-pool-<address_pool_name>).

ipam instance address-pool ipv4 address-range

Configures IPv4 address ranges.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv4 Configuration (config-ipv4)

Syntax Description

address-range *start_ipv4_address end_ipv4_address* [**offline**] [**default-gateway** *ip_address*]

default-gateway ip_address

Specify the default gateway IP address for static pool.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

offline

Specify the IPv4 address range as offline.

end_ipv4_address

Specify the end address of the IPv4 address range.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

start_ipv4_address

Specify the start address of the IPv4 address range.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPv4 address ranges.

ipam instance address-pool ipv4 prefix-range

Configures IPv4 prefix range.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*)

Syntax Description `ipv4 prefix-range range prefix_value prefix_length [offline] [default-gateway ip_address]`

default-gateway ip_address

Specify the default gateway IP address for static pool.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

length prefix_length

Specify the IPv4 prefix length.

Must be an integer in the range of 1-31.

offline

Specify the IPv4 prefix range as offline.

prefix_value

Specify the IPv4 prefix.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure IPv4 prefix range.

ipam instance address-pool ipv4 split-size

Configures chunk split size parameters.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description `split-size [[no-split] [per-cache number_of_addresses] [per-dp number_of_addresses]]`

no-split

Specify not to split the address range into smaller chunks.

per-cache *number_of_addresses*

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

per-dp *number_of_addresses*

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

Usage Guidelines

Use this command to configure chunk split size parameters. The CLI prompt changes to the Split Size Configuration mode (config-split-size).

ipam instance address-pool ipv4 threshold

Configures pool thresholds.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv4 Configuration (config-ipv4)

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description

threshold **upper-threshold** *upper_threshold*

upper-threshold *upper_threshold*

Specify the upper threshold value in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines

Use this command to configure pool thresholds.

ipam instance address-pool ipv6 address-ranges address-range

Configures IPv6 address ranges.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Syntax Description

address-range *start_ipv6_address end_ipv6_address* [**offline**]

offline

Specify the IPv6 address range as offline.

end_ipv6_address

Specify the end address of the IPv6 address range.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

start_ipv6_address

Specify the start address of the IPv6 address range.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPv6 address ranges.

ipam instance address-pool ipv6 address-ranges prefix-range

Configures IPv6 prefix range.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Syntax Description

prefix-range range *prefix_value prefix_length* [**offline**]

length prefix_length

Specify the IPv6 prefix length.

Must be an integer in the range of 96-127.

prefix_value

Specify the IPv6 prefix.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPv6 prefix range.

ipam instance address-pool ipv6 address-ranges split-size

Configures chunk split size parameters.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description **split-size** [[**no-split**] [**per-cache** *number_of_addresses*] [**per-dp** *number_of_addresses*]]

no-split

Specify not to split the address range into smaller chunks.

per-cache *number_of_addresses*

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2. Must be an integer in the range of 2-262144.

per-dp *number_of_addresses*

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2. Must be an integer in the range of 2-262144.

Usage Guidelines Use this command to configure chunk split size parameters. The CLI prompt changes to the Split Size Configuration mode (config-split-size).

ipam instance address-pool ipv6 address-ranges threshold

Configures pool thresholds.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description **threshold upper-threshold** *upper_threshold*

upper-threshold *upper_threshold*

Specify the upper threshold value in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines Use this command to configure pool thresholds.

ipam instance address-pool ipv6 prefix-ranges prefix-range

Configures IPv6 prefix ranges.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-address-*pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description **prefix-range** *prefix_value* **prefix-length** *prefix_length* [**offline**]

offline

Specify the IPv6 prefix range as offline.

prefix-length *prefix_length*

Specify the prefix length.

Must be an integer in the range of 1-63.

prefix-range *prefix_value*

Specify the IPv6 prefix range.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure IPv6 prefix ranges.

ipam instance address-pool ipv6 prefix-ranges split-size

Configures chunk split size parameters.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-address-*pool_name*) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-address-*pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-address-*pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description `split-size [[no-split] [per-cache number_of_addresses] [per-dp number_of_addresses]]`

no-split

Specify not to split the address range into smaller chunks.

per-cache *number_of_addresses*

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

per-dp *number_of_addresses*

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

Usage Guidelines Use this command to configure chunk split size parameters. The CLI prompt changes to the Split Size Configuration mode (config-split-size).

ipam instance address-pool ipv6 prefix-ranges threshold

Configures pool thresholds.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description `threshold upper-threshold upper_threshold`

upper-threshold *upper_threshold*

Specify the upper threshold value in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines Use this command to configure pool thresholds.

ipam instance address-pool static

Configures IPAM static pool parameters.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*)

Syntax Description **static enable user-plane** *user_plane*

enable

Specify to set pool as static.

user-plane *user_plane*

Specify to associate user plane for this static pool.

Must be a string of 1-128 characters in the ipam-str pattern. For information on the ipam-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure IPAM static pool parameters.

ipam instance min-dp-addr-size

Configures the minimum number of addresses to reserve per UPF, per NM, per pool/tag.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **min-dp-addr-size** [[**ipv4-addr** *reserve_min_ipv4_address*] | [**ipv6-addr** *reserve_min_ipv6_address*] | [**ipv6-prefix** *reserve_min_ipv6_prefix*]]

ipv4-addr *reserve_min_ipv4_address*

Specify the minimum number of IPv4 addresses to reserve.

Must be an integer in the range of 16-262144.

ipv6-addr *reserve_min_ipv6_address*

Specify the minimum number of IPv6 addresses to reserve.

Must be an integer in the range of 32-262144.

ipv6-prefix *reserve_min_ipv6_prefix*

Specify the minimum number of IPv6 prefix to reserve.

Must be an integer in the range of 32-262144.

Usage Guidelines Use this command to configure the minimum number of addresses to reserve per UPF, per NM, per pool/tag.

ipam instance source

Configures pool-datastore source selection.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **source local**

local
Specify to use local address pool datastore.

Usage Guidelines Use this command to configure pool-datastore source selection.";

ipam instance source external ipam

Configures external IPAM server for pool information.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **source external ipam [host *ip_address* | port *port_number* | vendor *vendor_id*]**

host *ip_address*

Specify the IP address of the IPAM server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

port *port_number*

Specify the port number of the IPAM server.

Must be an integer in the range of 1-65535.

vendor *vendor_id*

Specify the IPAM server's vendor ID. Default: cisco.

Must be one of the following:

- cisco

Usage Guidelines Use this command to configure external IPAM server for pool information.

ipam instance threshold

Configures global upper thresholds.

Command Modes	Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance- <i>instance_id</i>)
Syntax Description	<p>threshold [[ipv4-addr <i>ipv4_address_threshold</i>] [ipv6-addr <i>ipv6_address_threshold</i>] [ipv6-prefix <i>ipv6_prefix_threshold</i>]]</p> <p>ipv4-addr <i>ipv4_address_threshold</i> Specify the IPv4 address threshold in percentage. Must be an integer in the range of 1-100.</p> <p>ipv6-addr <i>ipv6_address_threshold</i> Specify the IPv6 address threshold in percentage. Must be an integer in the range of 1-100.</p> <p>ipv6-prefix <i>ipv6_prefix_threshold</i> Specify the IPv6 prefix threshold in percentage. Must be an integer in the range of 1-100.</p>
Usage Guidelines	Use this command to configure global upper thresholds.

ipam show dp

Displays IPAM data-plane allocations.

Command Modes	Exec
Syntax Description	<p>show ipam dp [dp-name <i>dataplane_name</i>]</p> <p>dp-name <i>dataplane_name</i> Specify name of the dataplane. Must be a string.</p>
Usage Guidelines	Use this command to view IPAM data-plane allocations.

ipam show dp-tag

Displays data-plane tag-related allocations.

Command Modes	Exec
Syntax Description	show ipam dp-tag <i>dp_tag</i>

dp-tag *dp_tag*

Specify the dataplane name with tag.

Must be a string.

Usage Guidelines

Use this command to view data-plane tag-related allocations. Tag represents DNN or PoolName based on NF.

ipam show ipam pool

Displays pool allocation information.

Command Modes

Exec

Syntax Description

show ipam pool *pool_name*

pool-name *pool_name*

Specify name of the pool.

Must be a string.

Usage Guidelines

Use this command to view pool allocation information.

job

Suspends the jobs that are running in the background.

Command Modes

Exec

Syntax Description

job stop *job_id*

job_id

Specify the job ID for suspending the corresponding job.

Must be an integer.

Usage Guidelines

Use this command to suspend the jobs that are running in the background.

k8 bng

Configures Tracing configuration parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

k8 bng [[**coverage-build** { **false** | **true** }] [**datastore-endpoint** *datastore_endpoint*] [**etcd-endpoint** *etcd_endpoint*]]

coverage-build { false | true }

Specify whether to disable or enable coverage build.

Must be one of the following:

- false
- true

Default Value: false.

datastore-endpoint *datastore_endpoint*

Specify the Datastore Endpoint configuration. For example, *hostname:port*.

Must be a string of 1-128 characters.

Default Value: datastore-ep-session:8882.

etcd-endpoint *etcd_endpoint*

Specify the Etcd Endpoint configuration. For example, *hostname:port*.

Must be a string of 1-128 characters.

Default Value: etcd:2379.

Usage Guidelines

Use this command to configure Tracing configuration parameters. The CLI prompt changes to the BNG Configuration mode (config-bng).

k8 bng tracing

Configures Tracing configuration parameters.

Command Modes

Exec > Global Configuration (config) > BNG Configuration (config-bng)

Syntax Description

```
tracing [ [ append-messages { false | true } ] [ enable ] [
enable-trace-percent tracing_percentage ] [ endpoint tracing_endpoint ] ]
```

append-messages { false | true }

Specify whether to append tracing messages.

Must be one of the following:

- false
- true

Default Value: true.

enable-trace-percent *tracing_percentage*

Specify the tracing percentage.

Must be an integer in the range of 0-100.

Default Value: 100.

enable

Specify to enable tracing.

endpoint *tracing_endpoint*

Specify the Tracing Endpoint configuration. For example, *hostname:port*.

Must be a string of 1-128 characters.

Default Value: jaeger-collector:9411.

Usage Guidelines

Use this command to configure Tracing configuration parameters. The CLI prompt changes to the Tracing Configuration mode (config-tracing).

k8 label pod-group-config

Configures K8 node affinity label pod group configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description

k8 label *pod_group* **key** *label_key* **value** *label_value*

key *label_key*

Specify the key for the label.

Must be a string.

value *label_value*

Specify the value for the label.

Must be a string.

pod_group

Specify the pod group for the VMs.

Must be one of the following:

- **cdl-layer**
- **oam-layer**
- **protocol-layer**
- **service-layer**

Usage Guidelines

Use this command to configure K8 node affinity label pod group configuration.

kubernetes

Configures Kubernetes parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
k8s name k8s_cluster_name [ [ image-pull-secrets image_pull_secrets ] [
ingress-host-name ingress_host_name ] [ namespace k8s_namespace ] [ nf-name nf_name
] [ registry image_registry ] [ single-node { false | true } ] [
use-volume-claims { false | true } ] ]
```

image-pull-secrets *image_pull_secrets*

Specify the image pull secrets stored within K8s.

Must be a string.

ingress-host-name *ingress_host_name*

Specify the generic ingress host name.

Must be a string.

name *k8s_cluster_name*

Specify name of the K8s cluster.

Must be a string.

namespace *k8s_namespace*

Specify the K8s namespace for the network function.

Must be a string.

nf-name *nf_name*

Specify the NF deployed in this k8s namespace.

Must be a string.

registry *image_registry*

This keyword is deprecated.

Must be a string.

single-node { **false** | **true** }

Specify to enable or disable single node deployment.

Must be one of the following:

- **false**
- **true**

Default Value: false.

use-volume-claims { false | true }

Specify to enable or disable using volume claims when deploying.

Must be one of the following:

- false
- true

Default Value: false.

Usage Guidelines

Use this command to configure Kubernetes parameters.

kubernetes nodes

Configures list of k8s nodes.

Command Modes

Exec > Global Configuration (config)

Syntax Description

k8s nodes *k8s_node_name* [[**node-type** *node_type*] [**worker-type** *worker_type*]]

node-type *node_type*

Specify the K8s node type.

Must be a string.

worker-type *worker_type*

Specify the k8s worker type.

Must be a string.

k8s_node_name

Specify name of the K8s node.

Must be a string.

Usage Guidelines

Use this command to configure the list of k8s nodes.

leaf-prompting

Enables or disables automatic querying for leaf values.

Command Modes

Exec

Syntax Description

leaf-prompting { false | true }

{ false | true }

Specify false to disable leaf prompting, and true to enable.

Must be either "false" or "true".

Usage Guidelines Use this command to automatically query for leaf values.

license smart deregister

Configures the license parameters for the VNF deregistration.

Command Modes Exec

Syntax Description `license smart deregister`

deregister

Specify to deregister the VNF for smart licensing.

Usage Guidelines Use this command to configure the license parameters for the VNF deregistration.

license smart register

Configures the license parameters for the VNF registration.

Command Modes Exec

Syntax Description `license smart register force idtoken token_id`

register

Specify to register the VNF for Smart Licensing.

force

Specify to enable the force registration of the agent.

idtoken *token_id*

Specify the ID token to register the agent with.

Must be an integer.

Usage Guidelines Use this command to configure the license parameters for the VNF registration.

license smart renew

Configures the license parameters for the VNF renewal.

Command Modes	Exec
Syntax Description	<pre>license smart renew { ID auth }</pre> <p>renew Renew the smart agent IDs and authentication.</p> <p>ID Specify to renew the smart agent license registration information.</p> <p>auth Initiate the manual update of the license usage information with Cisco.</p>
Usage Guidelines	Use this command to configure the license parameters for the VNF renewal.

local-instance

Configures GR instance for current instance.

Command Modes	Exec > Global Configuration
Syntax Description	<pre>local-instance instance <i>gr_instance_id</i></pre> <p>instance <i>gr_instance_id</i> Specify the GR instance ID of current instance.</p>
Usage Guidelines	Use this command to configure GR instance for current instance.

logging async application enable

Enables async logging.

Command Modes	Exec > Global Configuration (config)
Syntax Description	<pre>logging async application enable buffer-size <i>buffer_size</i></pre>
Syntax Description	<pre>logging async monitor-subscriber enable buffer-size <i>buffer_size</i></pre>
Syntax Description	<pre>logging async tracing enable buffer-size <i>buffer_size</i></pre>
Syntax Description	<pre>logging async transaction enable buffer-size <i>buffer_size</i></pre> <p>buffer-size <i>buffer_size</i> Specify the buffer size for async logging.</p>

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging async monitor-subscriber enable

Enables async logging.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging async application enable buffer-size buffer_size`

Syntax Description `logging async monitor-subscriber enable buffer-size buffer_size`

Syntax Description `logging async tracing enable buffer-size buffer_size`

Syntax Description `logging async transaction enable buffer-size buffer_size`

buffer-size *buffer_size*

Specify the buffer size for async logging.

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging async tracing enable

Enables async logging.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging async application enable buffer-size buffer_size`

Syntax Description `logging async monitor-subscriber enable buffer-size buffer_size`

Syntax Description `logging async tracing enable buffer-size buffer_size`

Syntax Description `logging async transaction enable buffer-size buffer_size`

buffer-size *buffer_size*

Specify the buffer size for async logging.

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging async transaction enable

Enables async logging.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging async application enable buffer-size buffer_size`

Syntax Description `logging async monitor-subscriber enable buffer-size buffer_size`

Syntax Description `logging async tracing enable buffer-size buffer_size`

Syntax Description `logging async transaction enable buffer-size buffer_size`

buffer-size *buffer_size*

Specify the buffer size for async logging.

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging error

Configures error logging parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging error stack status`

stack *status*

Specify to enable or disable error stack.

Must be one of the following:

- **disable**
- **enable**

Default Value: enable.

Usage Guidelines Use this command to configure error logging parameters.

logging level

Configures the logging level.

Command Modes Exec > Global Configuration (config)

Syntax Description

```
logging level logging_level { [ application application_log_level ] [ monitor-subscriber monitor_subscriber_log_level ] [ tracing tracing_log_level ] [ transaction transaction_log_level ] }
```

application *application_log_level*

Specify the application logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

monitor-subscriber *monitor_subscriber_log_level*

Specify the monitor subscriber logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

tracing *tracing_log_level*

Specify the tracing logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

transaction *transaction_log_level*

Specify the transaction logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

Usage Guidelines Use this command to configure the logging level.

logging logger

Configures the log name.

Command Modes Exec > Global Configuration (config)

Syntax Description **logging name** *log_name*

name *log_name*

Specify the log name in "module.component.interface" format.

Must be a string.

Usage Guidelines Use this command to configure the log name.

logging logger level

Configures the logging level.

Command Modes Exec > Global Configuration (config)

Syntax Description **logging level** *logging_level* { [**application** *application_log_level*] [**monitor-subscriber** *monitor_subscriber_log_level*] [**tracing** *tracing_log_level*] [**transaction** *transaction_log_level*] }

application *application_log_level*

Specify the application logging level.

Must be one of the following:

- **debug**

- **error**
- **info**
- **off**
- **trace**
- **warn**

monitor-subscriber *monitor_subscriber_log_level*

Specify the monitor subscriber logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

tracing *tracing_log_level*

Specify the tracing logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

transaction *transaction_log_level*

Specify the transaction logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**

- **trace**
- **warn**

Usage Guidelines Use this command to configure the logging level.

logging transaction

Configures the transaction logging parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging transaction { duplicate | message | persist } { disable | enable }`

duplicate { enable | disable }

Specify whether to enable or disable duplicate logs in transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

max-file-size *max_file_size*

Specify the maximum transaction file size in MB.

Must be an integer in the range of 1-10000.

Default Value: 50.

max-rotation *max_rotations*

Specify the maximum number of file rotations.

Must be an integer in the range of 2-1000.

Default Value: 10.

message { enable | disable }

Specify whether to enable or disable messages in transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

persist { enable | disable }

Specify whether to enable or disable file-based transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines

Use this command to configure the transaction logging parameters.

logout

Logout a specific session or a specific user from all sessions.

Command Modes

Exec

Syntax Description

logout [**session** *session_id* | **user** *user_name*]

session *session_id*

Specify the session ID from the possible completion options.

Must be a string.

user *user_name*

Specify the user name or the user process from the possible completion options.

Must be a string.

Usage Guidelines

Use this command to log out a specific session or a specific user from all sessions.

monitor protocol

Configures the SMF to monitor the protocol.

Command Modes

Exec

Syntax Description

monitor protocol interface *interface_name* [**capture-duration** *duration*]

interface *interface_name*

Specify the name of interface on which PCAP is captured.

Must be a string.

capture-duration *duration*

Specify the duration, in seconds, during which PCAP is captured. The default value is 300 seconds.

Must be an integer.

Usage Guidelines Use this command to monitor the protocol.

monitor subscriber

Configures the SMF to monitor the subscribers.

Command Modes Exec

Syntax Description `monitor subscriber supi supi [capture-duration duration] | subscriber-dump filename file_name | subscriber-list`

supi *supi*

Specify the subscriber identifier.

Must be a string.

capture-duration *duration*

Specify the duration, in seconds, during which PCAP is captured. The default value is 300 seconds.

Must be an integer.

filename *file_name*

Specify the path of the file name to be dumped.

Must be a string.

Usage Guidelines Use this command to monitor the subscribers.

nf-tls ca-certificates

Configure CA certificate parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `nf-tls ca-certificates cert_alias_name cert-data cert_data`

ca-certificates *cert_alias_name*

Specify the alias name of the certificate.

Must be a string.

cert-data *cert_data*

Specify the certificate data in PEM format.

Must be a string.

Usage Guidelines Configures TLS keystore configuration for interfaces. Use this command to configure CA certificate parameters.

nf-tls certificate-status

Displays certificate status information.

Command Modes Exec

Syntax Description `show nf-tls certificate-status`

Usage Guidelines Use this command to view certificate status information.

nf-tls certificates

Configures certificate parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `nf-tls certificates cert_alias_name cert-data cert_data private-key private_key`

cert-data cert_data

Specify the certificate data in PEM format.

Must be a string.

certificates cert_alias_name

Specify the alias name of the certificate.

Must be a string.

private-key private_key

Specify the certificate private key in PEM format.

Must be a string.

Usage Guidelines Configures TLS keystore configuration for interfaces. Use this command to configure certificate parameters.

no

Restores the command history cache size to its default setting. See the [history](#) command.

Command Modes Exec

Syntax Description `no history`

Usage Guidelines

Use this command to configure the command history cache size to its default setting. For more details, see the [history](#) command.

paginate

Configures whether or not to paginate CLI command output.

Command Modes

Exec

Syntax Description

paginate { **false** | **true** }

{ false | true }

Specify false to disable paginating CLI command output, and true to enable.

Must be either "false" or "true".

Usage Guidelines

Use this command to paginate the command output.

profile aaa

Configures AAA profiles.

Command Modes

Exec > Global Configuration (config)

Syntax Description

profile aaa *aaa_profile_name*

aaa_profile_name

Specify name of the AAA profile.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure AAA profiles. Enters the AAA Profile Configuration mode (config-aaa-aaa_<profile_name>).

profile aaa accounting

Configures accounting configuration parameters.

Command Modes

Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_<profile_name>)

Syntax Description

accounting method-order *method_list_order*

method-order *method_list_order*

Specify the method list order.

Must be one of the following:

- **radius**

-Or-

Must be a string of 1-128 characters.

You can configure a maximum of three elements with this keyword.

Usage Guidelines Use this command to configure accounting configuration parameters.

profile aaa authentication

Configures authentication parameters.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name)

Syntax Description **authentication method-order** *method_list_order*

method-order *method_list_order*

Specify the method list order.

Must be one of the following:

- **radius**

-Or-

Must be a string of 1-128 characters.

You can configure a maximum of three elements with this keyword.

Usage Guidelines Use this command to configure authentication parameters.

profile aaa authorization

Configures authorization parameters.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name)

Syntax Description **authorization** [**password** *default_password*]

password *default_password*

Specify the default password.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure AAA authorization parameters. The CLI prompt changes to the Authorization Configuration mode (config-authorization).

profile aaa authorization type subscriber

Configures authorization type subscriber.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name) > Authorization Configuration (config-authorization)

Syntax Description `type subscriber method-order method_list_order`

method-order method_list_order

Specify the method list order.

Must be one of the following:

- radius

-Or-

Must be a string of 1-128 characters.

You can configure a maximum of three elements with this keyword.

Usage Guidelines Use this command to configure authorization type subscriber.

profile aaa authorization username

Configures the default user name.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name) > Authorization Configuration (config-authorization)

Syntax Description `username { format attribute_format | identifier identifier_type | value user_name }`

format attribute_format

Specify the attribute format.

identifier identifier_type

Specify the identifier type.

Must be one of the following:

- addr
- circuit-id-tag
- client-mac-address-custom1
- client-mac-address-custom2

- **client-mac-address-ietf**
- **client-mac-address-raw**
- **client-mac-address**
- **dhcp-client-id-spl**
- **dhcp-client-id**
- **dhcp-user-class**
- **dhcp-vendor-class**
- **dhcpv4-client-id-spl**
- **dhcpv4-vendor-class**
- **dhcpv6-client-id-ent-ident**
- **dhcpv6-interface-id**
- **dhcpv6-vendor-class-string**
- **inner-vlan-id**
- **outer-vlan-id**
- **physical-adapter**
- **physical-chassis**
- **physical-port**
- **physical-slot**
- **physical-subslot**
- **port-type**
- **pppoe-session-id**
- **remote-id-tag**
- **service-name**
- **user-plane**
- **username**

value *user_name*

Specify the user name.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the default user name.

profile attribute-format

Configures AAA attribute templates.

Command Modes Exec > Global Configuration (config)

Syntax Description `profile attribute-format profile_name [format-order attributes format-string format_string]`

format-order attributes

Specify the ordered list of attributes.

Must be one of the following:

- **addr**
- **circuit-id-tag**
- **client-mac-address-custom1**
- **client-mac-address-custom2**
- **client-mac-address-ietf**
- **client-mac-address-raw**
- **client-mac-address**
- **dhcp-client-id-spl**
- **dhcp-client-id**
- **dhcp-user-class**
- **dhcp-vendor-class**
- **dhcpv4-client-id-spl**
- **dhcpv4-vendor-class**
- **dhcpv6-client-id-ent-ident**
- **dhcpv6-interface-id**
- **dhcpv6-vendor-class-string**
- **inner-vlan-id**
- **outer-vlan-id**
- **physical-adapter**
- **physical-chassis**
- **physical-port**
- **physical-slot**

- **physical-subslot**
- **port-type**
- **pppoe-session-id**
- **remote-id-tag**
- **service-name**
- **user-plane**
- **username**

-Or-

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of 32 elements with this keyword.

format-string *format_string*

Specify the format pattern. For example, %sdelimiter⁰%sdelimiter⁰%s.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

profile_name

Specify name of the profile.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure AAA attribute templates. The CLI prompt changes to the Attribute Format Configuration mode (config-attribute-format-<name>).

profile coa

Configures RADIUS Dynamic-author/COA parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

profile coa [**server-key** *server_shared_secret_key*]

server-key *server_shared_secret_key*

Specify the COA server shared secret key.

Must be a string.

Usage Guidelines

Use this command to configure RADIUS Dynamic-author/COA parameters. The CLI prompt changes to the COA Profile Configuration mode (config-coa).

profile coa client

Configures RADIUS COA client parameters.

Command Modes Exec > Global Configuration (config) > COA Profile Configuration (config-coa)

Syntax Description **client** *client_ip_address* **server-key** *client_shared_secret_key*

server-key *client_shared_secret_key*

Specify the client shared secret key.

Must be a string.

client_ip_address

Specify the IP address of the client.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure RADIUS COA client parameters.

profile dhcp

Configures DHCP profile.

Command Modes Exec > Global Configuration (config)

Syntax Description **profile dhcp** *dhcp_profile_name*

dhcp *dhcp_profile_name*

Specify name of the DHCP profile.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure DHCP profiles. Enters the DHCP Profile Configuration mode (config-dhcp-<profile_name>).

profile dhcp ipv4

Configures DHCP IPv4 parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name)

Syntax Description `ipv4 [mode dhcp_mode]`

mode *dhcp_mode*

Specify the DHCP server or proxy mode.

Must be one of the following:

- **proxy**
- **server**

Default Value: server.

Usage Guidelines Use this command to configure DHCP IPv4 parameters. Enters the DHCP IPv4 Configuration mode (config-ipv4).

profile dhcp ipv4 class

Configures DHCP IPv4 class configuration parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4)

Syntax Description `class dhcp_class_name`

dhcp_class_name

Specify name of the DHCP class.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure DHCP IPv4 class configuration parameters. Enters the DHCP Class Configuration mode.

profile dhcp ipv4 class matches

Configures the list of match values.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name)

Syntax Description `matches [match-type match_type]`

match-type *match_type*

Specify to match any or match all.

Must be one of the following:

- **all**

- any

Usage Guidelines

Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile dhcp ipv4 class matches match

Configures match key and value.

Command Modes

Exec > Global Configuration (config) > DHCP Configuration (config-dhcp-profile_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Syntax Description

match match_key { **ascii** ascii_string | **hex** hex_string }

ascii *ascii_string*

Specify the ASCII strings.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

hex *hex_string*

Specify the hexadecimal string.

Must be a string of 1-128 characters.

You can configure a maximum of eight elements with this keyword.

match *match_key*

Specify the match key.

Must be one of the following:

- dhcpv4-circuit-id
- dhcpv4-remote-id
- dhcpv4-user-class
- dhcpv4-vendor-class

Usage Guidelines

Use this command to configure match key and value.

profile dhcp ipv4 class server

Configures DHCP server mode parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name)

Syntax Description **server** [**boot-filename** *boot_file_name* | **dns-servers** *ip_address* | **domain-name** *domain_name* | **netbios-name-server** *ip_address* | **next-server** *ip_address* | **ntp-servers** *ntp_servers* | **pool-name** *pool_name*]

boot-filename *boot_file_name*

Specify name of the boot file.

Must be a string of 1-128 characters.

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

domain-name *domain_name*

Specify the domain name.

Must be a string of 1-128 characters.

netbios-name-server *ip_address*

Specify the NetBIOS name server IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

next-server *ip_address*

Specify the TFTP server IP address to be used by the client.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

ntp-servers *ntp_servers*

Specify the NTP servers.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

pool-name *pool_name*

Specify name of the pool.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure the DHCP server mode parameters. Enters the DHCP Server Configuration mode.

profile dhcp ipv4 class server hold-time

Configures the hold time.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Syntax Description **hold-time minutes** *hold_time_minutes*

minutes *hold_time_minutes*

Specify the hold time in minutes.

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure the hold time in minutes.

profile dhcp ipv4 class server lease

Configures DHCP Server Lease parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description **lease** { [**days** *days*] [**hours** *hours*] [**minutes** *minutes*] }

days *days*

Specify the number of days.

Must be an integer in the range of 0-365.

hours *hours*

Specify the hours.

Must be an integer in the range of 0-23.

minutes *minutes*

Specify the minutes.

Must be an integer in the range of 0-59.

Usage Guidelines Use this command to configure the DHCP Server Lease parameters.

profile dhcp ipv4 class server netbios-node-type

Configures NetBIOS node type.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description `netbios-name-server { broadcast-node | hexadecimal hex_number | hybrid-node | mixed-node | peer-to-peer-node }`

broadcast-node

Specify broadcast node.

hexadecimal hex_number

Specify the hexadecimal number.

Must be a string of 2 characters.

hybrid-node

Specify hybrid node.

mixed-node

Specify mixed node.

peer-to-peer-node

Specify peer-to-peer node.

Usage Guidelines Use this command to configure the NetBIOS node type.

profile dhcp ipv4 class server option-codes

Configures the OptionCode table.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description `option-codes`

Usage Guidelines Use this command to configure the OptionCode table. Enters the Option Codes Configuration mode (config-option-codes).

profile dhcp ipv4 class server option-codes option-code

Configures a DHCP option code.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

Syntax Description `option-code dhcp_option_code [ascii-string ascii_string | force-insert { false | true } | hex-string hex_string | ip-address ip_address]`**ascii-string *ascii_string***

Specify the ASCII string.

Must be a string of 1-128 characters.

force-insert { false | true }

Specify whether to force insert this option.

Must be one of the following:

- **false**
- **true**

hex-string *hex_string*

Specify the hexadecimal string.

Must be a string of 1-128 characters in the pattern `([0-9a-fA-F]{2}([0-9a-fA-F]{2})*)?`.

ip-address *ip_address*

Specify the server's IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

option-code *dhcp_option_code*

Specify the DHCP option code.

Must be an integer in the range of 0-255.

Usage Guidelines Use this command to configure a DHCP option code. Enters the Option Code Configuration mode.

profile dhcp ipv4 class server static-ip-key

Configures the Static IP Key.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Syntax Description **static-ip-key identifier** *identifier_type*

identifier *identifier_type*

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines Use this command to configure the Static IP Key. The CLI prompt changes to the Static IP Key Configuration mode (config-static-ip-key).

profile dhcp ipv4 server

Configures DHCP server mode parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name)

Syntax Description **server** [**boot-filename** *boot_file_name* | **dns-servers** *ip_address* | **domain-name** *domain_name* | **netbios-name-server** *ip_address* | **next-server** *ip_address* | **ntp-servers** *ntp_servers* | **pool-name** *pool_name*]

boot-filename *boot_file_name*

Specify name of the boot file.

Must be a string of 1-128 characters.

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

domain-name *domain_name*

Specify the domain name.

Must be a string of 1-128 characters.

netbios-name-server *ip_address*

Specify the NetBIOS name server IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

next-server *ip_address*

Specify the TFTP server IP address to be used by the client.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

ntp-servers *ntp_servers*

Specify the NTP servers.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

pool-name *pool_name*

Specify name of the pool.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure the DHCP server mode parameters. Enters the DHCP Server Configuration mode.

profile dhcp ipv4 server hold-time

Configures the hold time.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Syntax Description

hold-time *minutes* *hold_time_minutes*

minutes *hold_time_minutes*

Specify the hold time in minutes.

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure the hold time in minutes.

profile dhcp ipv4 server lease

Configures DHCP Server Lease parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description `lease { [days days] [hours hours] [minutes minutes] }`

days days

Specify the number of days.

Must be an integer in the range of 0-365.

hours hours

Specify the hours.

Must be an integer in the range of 0-23.

minutes minutes

Specify the minutes.

Must be an integer in the range of 0-59.

Usage Guidelines Use this command to configure the DHCP Server Lease parameters.

profile dhcp ipv4 server netbios-node-type

Configures NetBIOS node type.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description `netbios-name-server { broadcast-node | hexadecimal hex_number | hybrid-node | mixed-node | peer-to-peer-node }`

broadcast-node

Specify broadcast node.

hexadecimal *hex_number*

Specify the hexadecimal number.

Must be a string of 2 characters.

hybrid-node

Specify hybrid node.

mixed-node

Specify mixed node.

peer-to-peer-node

Specify peer-to-peer node.

Usage Guidelines

Use this command to configure the NetBIOS node type.

profile dhcp ipv4 server option-codes

Configures the OptionCode table.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description

option-codes

Usage Guidelines

Use this command to configure the OptionCode table. Enters the Option Codes Configuration mode (config-option-codes).

profile dhcp ipv4 server option-codes option-code

Configures a DHCP option code.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

Syntax Description `option-code dhcp_option_code [ascii-string ascii_string | force-insert { false | true } | hex-string hex_string | ip-address ip_address]`

ascii-string *ascii_string*

Specify the ASCII string.

Must be a string of 1-128 characters.

force-insert { false | true }

Specify whether to force insert this option.

Must be one of the following:

- false
- true

hex-string *hex_string*

Specify the hexadecimal string.

Must be a string of 1-128 characters in the pattern `([0-9a-fA-F]{2}([0-9a-fA-F]{2})*)?`.

ip-address *ip_address*

Specify the server's IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

option-code *dhcp_option_code*

Specify the DHCP option code.

Must be an integer in the range of 0-255.

Usage Guidelines Use this command to configure a DHCP option code. Enters the Option Code Configuration mode.

profile dhcp ipv4 server static-ip-key

Configures the Static IP Key.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Syntax Description `static-ip-key identifier identifier_type`

identifier *identifier_type*

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines

Use this command to configure the Static IP Key. The CLI prompt changes to the Static IP Key Configuration mode (config-static-ip-key).

profile dhcp ipv6

Configures DHCP IPv6 parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name)

Syntax Description

ipv6 [**mode** *dhcp_mode*]

mode *dhcp_mode*

Specify the DHCP mode server or proxy.

Must be one of the following:

- **proxy**
- **server**

Default Value: server.

Usage Guidelines

Use this command to configure DHCP IPv6 parameters. Enters the DHCP IPv6 Configuration mode.

profile dhcp ipv6 class

Configures DHCP IPv6 class configuration parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description

class *dhcp_class_name*

dhcp_class_name

Specify name of the DHCP class.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure DHCP IPv6 class configuration parameters.

profile dhcp ipv6 class server

Configures DHCP server mode parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name)

Syntax Description

```
server { aftr-name aftr_name | dns-servers ip_address | domain-name domain_name
  | iana-pool-name iana_pool_name | iapd-pool-name iapd_pool_name | preference
  server_preference | rapid-commit }
```

aftr-name *aftr_name*

Specify name of the Address Family Transition Router (AFTR).

Must be a string of 1-128 characters.

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

domain-name *domain_name*

Specify the domain name.

Must be a string of 1-128 characters.

iana-pool-name *iana_pool_name*

Specify name of the IANA pool.

Must be a string of 1-128 characters.

iapd-pool-name *iapd_pool_name*

Specify name of the IAPD pool.

Must be a string of 1-128 characters.

preference *server_preference*

Specify the DHCP server preference.

Must be an integer in the range of 1-255.

rapid-commit

Specify to allow rapid commit.

Usage Guidelines

Use this command to configure the DHCP server mode parameters.

profile dhcp ipv6 class server hold-time

Configures the hold time.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description

hold-time minutes *hold_time_minutes*

minutes *hold_time_minutes*

Specify the hold time in minutes.

Must be an integer in the range of 1-59.

Usage Guidelines

Use this command to configure the hold time in minutes.

profile dhcp ipv6 class server lease

Configures the lease parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description

lease { [**days** *days*] [**hours** *hours*] [**minutes** *minutes*] }

days *days*

Specify the number of days.

Must be an integer in the range of 0-365.

hours *hours*

Specify the hours.

Must be an integer in the range of 0-23.

minutes *minutes*

Specify the minutes.

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure lease parameters.

profile dhcp ipv6 class server static-ip-key

Configures the Static IP Key.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description **static-ip-key identifier** *identifier_type*

identifier *identifier_type*

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines Use this command to configure the Static IP Key.

profile dhcp ipv6 server

Configures DHCP server mode parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name)

Syntax Description **server { aftr-name** *aftr_name* | **dns-servers** *ip_address* | **domain-name** *domain_name* | **iana-pool-name** *iana_pool_name* | **iapd-pool-name** *iapd_pool_name* | **preference** *server_preference* | **rapid-commit** }

aftr-name *aftr_name*

Specify name of the Address Family Transition Router (AFTR).

Must be a string of 1-128 characters.

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

domain-name *domain_name*

Specify the domain name.

Must be a string of 1-128 characters.

iana-pool-name *iana_pool_name*

Specify name of the IANA pool.

Must be a string of 1-128 characters.

iapd-pool-name *iapd_pool_name*

Specify name of the IAPD pool.

Must be a string of 1-128 characters.

preference *server_preference*

Specify the DHCP server preference.

Must be an integer in the range of 1-255.

rapid-commit

Specify to allow rapid commit.

Usage Guidelines

Use this command to configure the DHCP server mode parameters.

profile dhcp ipv6 server hold-time

Configures the hold time.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description

hold-time minutes *hold_time_minutes*

minutes *hold_time_minutes*

Specify the hold time in minutes.

Must be an integer in the range of 1-59.

Usage Guidelines

Use this command to configure the hold time in minutes.

profile dhcp ipv6 server lease

Configures the lease parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description `lease { [days days] [hours hours] [minutes minutes] }`

days days

Specify the number of days.

Must be an integer in the range of 0-365.

hours hours

Specify the hours.

Must be an integer in the range of 0-23.

minutes minutes

Specify the minutes.

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure lease parameters.

profile dhcp ipv6 server static-ip-key

Configures the Static IP Key.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description `static-ip-key identifier identifier_type`

identifier identifier_type

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines Use this command to configure the Static IP Key.

profile feature-template

Configures feature template profile.

Command Modes Exec > Global Configuration (config)

Syntax Description **feature-template** *feature_template_name* [[**vrf-name** *vrf_name*] [**httpr-policy** *httpr_policy_name*]]

feature-template *feature_template_name*

Specify name of the feature template.

Must be a string of 1-128 characters.

httpr-policy *httpr_policy_name*

Specify name of the PBR HTTPR policy.

Must be a string of 1-128 characters.

vrf-name *vrf_name*

Specify name of the VRF.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure feature template profiles. The CLI prompt changes to the Feature Template Configuration mode (config-feature-template-<template_name>)

profile feature-template ipv4

Configures IPv4 features.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*)

Syntax Description **ipv4** [**mtu** *maximum_transmission_unit* | **ingress-acl** *ingress_ipv4_acl_name* | **egress-acl** *egress_ipv4_acl_name* | **disable-unreachables**]

disable-unreachables

Specify to disable sending ICMP Unreachable messages.

egress-acl *egress_ipv4_acl_name*

Specify name of the egress IPv4 ACL.

Must be a string of 1-128 characters.

ingress-acl *ingress_ipv4_acl_name*

Specify name of the ingress IPv4 ACL.

Must be a string of 1-128 characters.

mtu *maximum_transmission_unit*

Specify the Maximum Transmission Unit in bytes.

Must be an integer in the range of 68-65535.

Usage Guidelines Use this command to configure IPv4 features. The CLI prompt changes to the IPv4 Configuration mode (config-ipv4).

profile feature-template ipv4 verify-unicast-source

Enables per-packet validation for unicast.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > IPv4 Configuration (config-ipv4)

Syntax Description **verify-unicast-source reachable-via-rx**

reachable-via-rx

Specify the source is reachable via interface on which packet was received.

Usage Guidelines Use this command to enable per-packet validation for unicast.

profile feature-template ipv6

Configures IPv6 features.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*)

Syntax Description **ipv6 [[egress-acl egress_ipv6_acl_name] [ingress-acl ingress_ipv6_acl_name] [mtu maximum_transmission_unit]]**

disable-unreachables

Specify to disable sending ICMP Unreachable messages.

egress-acl egress_ipv6_acl_name

Specify name of the egress IPV6 ACL.

Must be a string of 1-128 characters.

ingress-acl ingress_ipv6_acl_name

Specify name of the ingress IPV6 ACL.

Must be a string of 1-128 characters.

mtu maximum_transmission_unit

Specify the Maximum Transmission Unit in bytes.

Must be an integer in the range of 1280-65535.

Usage Guidelines Use this command to configure IPv6 features. The CLI prompt changes to the IPv6 Configuration mode (config-ipv6).

profile feature-template ipv6 verify-unicast-source

Configures per packet validation for unicast.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > IPv6 Configuration (config-ipv6)

Syntax Description **verify-unicast-source** [**reachable-via-rx**]

reachable-via-rx

Specify source is reachable via interface on which packet was received.

Usage Guidelines Use this command to configure per packet validation for unicast.

profile feature-template ppp

Configures the PPP authentication parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*)

Syntax Description **ppp authentication** *authentication_method* [[**max-bad-auth** *max_auth_failures*] [**max-configure** *max_configure*] [**max-failure** *max_conf_naks*] [**service-type** *service_type*]]

authentication *authentication_method*

Specify the authentication method.

Must be one of the following:

- **chap**
- **pap**

You can configure a maximum of two elements with this keyword.

max-bad-auth *max_auth_failures*

Specify the maximum authentication failures to allow.

Must be an integer in the range of 0-10.

max-configure *max_configure*

Specify the maximum conf-reqs to send without response.

Must be an integer in the range of 1-10.

max-failure *max_conf_naks*

Specify the maximum conf-naks to receive.

Must be an integer in the range of 1-5.

service-type *service_type*

Specify the service type.

Must be one of the following:

- **outbound**

Usage Guidelines

Use this command to configure the PPP authentication parameters. The CLI prompt changes to the PPP Configuration mode (config-ppp).

profile feature-template ppp chap

Configures CHAP parameters.

Command Modes

Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description

chap **hostname** *chap_host_name* **password** *chap_password*

hostname *chap_host_name*

Specify the CHAP host name.

Must be a string of 1-128 characters of 1-128 characters.

password *chap_password*

Specify the CHAP password.

Must be a string.

Usage Guidelines

Use this command to configure CHAP parameters.

profile feature-template ppp ipcp

Configures PPP IPCP negotiation parameters.

Command Modes

Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description

ipcp [**peer-address-pool** *peer_address_pool_name*]

peer-address-pool *peer_address_pool_name*

Specify name of the peer-address pool.

Must be a string of 1-128 characters of 1-128 characters.

Usage Guidelines Use this command to configure PPP IPCP negotiation parameters.

profile feature-template ppp ipcp dns

Configures DNS address to be used for peer.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description `ipcp dns primary-address primary_address secondary-address secondary_address`

primary-address primary_address

Specify the primary address. The first address is considered as Primary and second address as Secondary.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

secondary-address secondary_address

Specify the secondary address.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure DNS address to be used for peer.

profile feature-template ppp ipcp renegotiation

Configures renegotiation parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description `ipcp renegotiation ignore`

ignore

Specify to ignore attempts by the peer to renegotiate LCP.

Usage Guidelines Use this command to configure renegotiation parameters.

profile feature-template ppp ipcp wins

Configures WINS address to be used for peer.

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>) > PPP Configuration (config-ppp)
Syntax Description	<p>ipcp wins primary-address <i>primary_ip_address</i> secondary-address <i>secondary_ip_address</i></p> <p>primary-address <i>primary_ip_address</i> Specify the primary address. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter.</p> <p>secondary-address <i>secondary_ip_address</i> Specify the secondary address. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter.</p>
Usage Guidelines	Use this command to configure WINS address to be used for peer.

profile feature-template ppp ipv6cp renegotiation

Configures renegotiation parameters.

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>) > PPP Configuration (config-ppp)
Syntax Description	<p>ipv6cp renegotiation ignore</p> <p>ignore Specify to ignore attempts by the peer to renegotiate LCP.</p>
Usage Guidelines	Use this command to configure renegotiation parameters.

profile feature-template ppp keepalive

Configures PPP Keepalive parameters.

Command Modes	Exec > Global Configuration
Syntax Description	<p>keepalive { disable interval <i>keepalive_interval</i> retry <i>keepalive_retries</i> }</p> <p>disable Specify to disable PPP keepalive.</p> <p>interval <i>keepalive_interval</i> Specify the keepalive interval in minutes.</p>

Must be an integer in the range of 10-120.

retry *keepalive_retries*

Specify the number of keepalive retries.

Must be an integer in the range of 1-255.

Usage Guidelines Use this command to configure PPP Keepalive parameters.

profile feature-template ppp lcp delay

Configures the time to delay before starting active LCP negotiations.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **delay seconds** *delay_value* **milliseconds** *delay_value*

milliseconds *delay_value*

Specify the delay value in milliseconds.

Must be an integer in the range of 0-70000000.

seconds *delay_value*

Specify the delay value in seconds.

Must be an integer in the range of 0-255.

Usage Guidelines Configures LCP global configuration parameters. Use this command to configure the time to delay before starting active LCP negotiations.

profile feature-template ppp lcp renegotiation

Configures LCP renegotiation.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **lcp renegotiation ignore**

ignore

Specify to ignore attempts by the peer to renegotiate LCP.

Usage Guidelines Use this command to configure LCP renegotiation.

profile feature-template ppp pap

Configures PAP parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description `pap accept-null-password`

accept-null-password

Specify to accept null-password.

Usage Guidelines Use this command to configure PAP parameters.

profile feature-template ppp timeout

Configures PPP timeout parameters.

Command Modes Exec > Global Configuration (config) > Endpoint N4 Protocol Configuration (config-endpoint-n4-protocol)

Syntax Description `retransmission timeout total_auth_complete_time [retry max_response_time]`

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description `timeout { [authentication total_auth_complete_time] [retry max_response_time] }`

authentication total_auth_complete_time

Specify the total time to allow for authentication to complete.

Must be an integer in the range of 3-30.

retry max_response_time

Specify the maximum time to wait for a response to a Conf-Req in seconds.

Must be an integer in the range of 1-10.

Usage Guidelines Use this command to configure PPP timeout parameters.

profile feature-template ppp timeout absolute

Configures the absolute timeout period for a PPP session.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **timeout absolute minutes** *timeout_minutes*

minutes *timeout_minutes*

Specify the timeout period in minutes.

Must be an integer in the range of 0-70000000.

Usage Guidelines Use this command to configure the absolute timeout period for a PPP session.

profile feature-template qos

Configures QoS input policy parameters.

Command Modes Exec > Global Configuration (config) > Feature Template QoS Profile Configuration (config-feature-template-qos)

Syntax Description **qos** { [**in-policy** *in_policy_name*] [**out-policy** *out_policy_name*] [**merge-level** *merge_level*] }

in-policy *in_policy_name*

Specify name of the QoS input policy.

Must be a string of 1-128 characters.

merge-level *merge_level*

Specify the merge level. To disable merge, set to 0. To enable merge and set the level, set to a value greater than 0.

Must be an integer.

out-policy *out_policy_name*

Specify name of the QoS output policy.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure QoS input policy parameters. The CLI prompt changes to the QoS Configuration mode (config-qos).

profile feature-template service-accounting

Configures service accounting parameters.

Command Modes Exec > Global Configuration (config) > Feature Template QoS Profile Configuration (config-feature-template-qos)

Syntax Description `service-accounting enable [[aaa-profile aaa_profile_name] [periodic-interval interim_interval]]`

aaa-profile *aaa_profile_name*

Specify the AAA profile to use for service accounting.

enable

Specify to enable service accounting.

periodic-interval *interim_interval*

Specify the interim interval in seconds.

Must be an integer in the range of 60-4320000.

Usage Guidelines Use this command to configure service accounting parameters. The CLI prompt changes to the Service Accounting Configuration mode (config-service-accounting).

profile feature-template session-accounting

Configures session accounting parameters.

Command Modes Exec > Global Configuration (config) > Feature Template QoS Profile Configuration (config-feature-template-qos)

Syntax Description `session-accounting enable [[aaa-profile aaa_profile_name] [periodic-interval interim_interval] [dual-stack-delay dual_stack_delay_wait]]`

aaa-profile *aaa_profile_name*

Specify the AAA profile to use for session accounting.

dual-stack-delay *dual_stack_delay_wait*

Specify the dual stack set delay wait in seconds.

Must be an integer in the range of 1-30.

enable

Specify to enable session accounting.

periodic-interval *interim_interval*

Specify the interim interval in seconds.

Must be an integer in the range of 60-4320000.

Usage Guidelines Use this command to configure session accounting parameters. The CLI prompt changes to the Session Accounting Configuration mode (config-session-accounting).

profile l2tp

Configures L2TP subscriber profiles.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
profile l2tp l2tp_profile_name [ [ authentication ] [ force-lcp-renegotiation ] [ congestion-control ] [ dsl-info-forwarding ] [ encrypt-avp ] [ hello-interval hello_message_interval ] [ hostname host_name ] [ mode config_mode ] [ mtu mtu_for_lcp_negotiation ] [ password tunnel_auth_password ] [ receive-window receive_window_size ] [ rx-connect-speed rx_connect_speed ] [ tunnel-load-balancing method ] [ tx-connect-speed tx_connect_speed ] [ vrf vrf_name ] ]
```

authentication

Specify to authenticate the L2TP tunnel.

congestion-control

Specify to enable L2TP Congestion Control.

dsl-info-forwarding

Specify to forward DSL Line Info attributes.

encrypt-avp

Specify to hide AVPs in outgoing control messages.

force-lcp-renegotiation

Specify to force LCP and Auth renegotiation.

hello-interval *hello_message_interval*

Specify the hello message interval in seconds.

Must be an integer in the range of 10-1000.

hostname *host_name*

Specify the local host name of the tunnel.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

mode *config_mode*

Specify the LAC/LNS config mode.

Must be one of the following:

- **lac**: Configures an LAC to request the establishment of an L2TP tunnel to an LNS.

- **lns**: Configures an LNS to accept requests from LAC to establish L2TP tunnel.

mtu *mtu_for_lcp_negotiation*

Specify the MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

password *tunnel_auth_password*

Specify the password for tunnel authentication.

Must be a string.

receive-window *receive_window_size*

Specify the receive window size for the tunnel.

Must be an integer in the range of 1-5000.

Default Value: 256.

rx-connect-speed *rx_connect_speed*

Specify the Rx connect speed in kbps.

Must be an integer in the range of 9-100000000.

tunnel-load-balancing *method*

Specify the Tunnel Load Balancing method.

Must be one of the following:

- **equal**: Equal load sharing.
- **weighted**: Weighted load sharing.

tx-connect-speed *tx_connect_speed*

Specify the Tx connect speed in kbps.

Must be an integer in the range of 9-100000000.

vrf *vrf_name*

Specify the VRF of the tunnel.

Must be a string of 1-128 characters.

l2tp_profile_name

Specify the name of the L2TP profile.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure L2TP subscriber profiles. This command enters the L2TP Profile Configuration mode (config-l2tp-<profile_name>).

profile l2tp domain

Configures domain matching.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **domain** *domain_name* **tun-assign-id** *tunnel_id*

tun-assign-id *tunnel_id*

Specify the domain name with tunnel ID.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

domain_name

Specify the domain name.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure domain matching.

You can configure a maximum of 16 elements with this command.

profile l2tp ip-tos

Configures IP ToS value for tunneled traffic.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **ip-tos value** { *service_type* | **reflect** }

reflect

Specify to reflect IP payload ToS on tunnel.

value *service_type*

Specify the type of service value.

Must be an integer in the range of 1-255.

Usage Guidelines Use this command to configure IP ToS value for tunneled traffic.

profile l2tp ipv4

Configures IPv4 settings for tunnel.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **ipv4** { [**df-bit** *df_bit_state*] [**source** *source_ip_address*] }

df-bit *df_bit_state*

Specify the DF Bit parameter.

Must be one of the following:

- **reflect**: Reflects df bit from inner IP header.
- **set**: Configures df bit.

source *source_ip_address*

Specify the source IP address of the tunnel.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure IPv4 settings for tunnel.

profile l2tp ipv4 destination

Configures destination address of tunnel.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **destination** **dest-ip** *dest_ip_address* **weight** *weight*

dest-ip *dest_ip_address*

Specify the IP address of the destination.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

weight *weight*

Specify the weight for Weighted Load Balancing method.

Must be an integer in the range of 1-65535.

Default Value: 1.

Usage Guidelines Use this command to configure destination address of tunnel.
You can configure a maximum of 64 elements with this command.

profile l2tp retransmit initial

Configures SCCRQ retransmission timeout settings.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **retransmit retries** max_retries

retries max_retries

Specify the maximum number of retries for SCCRQ packets.

Must be an integer in the range of 1-1000.

Default Value: 2.

Usage Guidelines Configures Control message retransmission parameters. Use this command to configure SCCRQ retransmission timeout settings.

profile l2tp retransmit initial timeout

Configures retransmission timeout parameters.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **retransmit timeout max** max_timeout **min** min_timeout

max max_timeout

Specify the max timeout duration in seconds.

Must be an integer in the range of 1-8.

Default Value: 8.

min min_timeout

Specify the min timeout duration in seconds.

Must be an integer in the range of 1-8.

Default Value: 1.

Usage Guidelines Use this command to configure retransmission timeout parameters.

profile l2tp retransmit timeout

Configures Control packet retransmission timeout parameters.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description `timeout max max_timeout min min_timeout`

max max_timeout

Specify the maximum timeout duration in seconds.

Must be an integer in the range of 1-32.

Default Value: 8.

min min_timeout

Specify the minimum timeout duration in seconds.

Must be an integer in the range of 1-8.

Default Value: 1.

Usage Guidelines Use this command to configure Control packet retransmission timeout parameters.

profile l2tp tcp

Configures TCP settings.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description `tcp adjust-mss mss_value`

adjust-mss mss_value

Specify to adjust the MSS value of TCP SYN packets. Specify the MSS value in bytes.

Must be an integer in the range of 500-1500.

Usage Guidelines Use this command to configure TCP settings.

profile l2tp terminate-from

Configures the host name of the remote peer to accept tunnels.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description `profile terminate-from hostname remote_host_name`

hostname remote_host_name

Specify the remote host name.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the host name of the remote peer to accept tunnels.

You can configure a maximum of 16 elements with this command.

profile l2tp tunnel

Configures tunnel parameters.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **tunnel session-limit** *session_limit*

session-limit *session_limit*

Specify the maximum number of L2TP sessions per tunnel.

Must be an integer in the range of 1-64000.

Usage Guidelines Use this command to configure tunnel parameters.

profile l2tp tunnel timeout

Configures tunnel deletion after timeout.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **tunnel timeout no-session** *no_session_timeout*

no-session *no_session_timeout*

Specify the no-session timeout value in seconds.

Must be an integer in the range of 1-86400.

Usage Guidelines Use this command to configure tunnel deletion after timeout.

profile pppoe

Configures PPPOE Subscriber profile.

Command Modes Exec > Global Configuration (config)

Syntax Description **profile pppoe** *pppoe_profile_name* [[**ac-cookie** *ac_cookie*] [**ac-name** *ac_name*] [**ctrl-pkt-priority** *priority*] [**mtu pado_delay**] [**mtu pppoe_mtu**] [**service-name** *pppoe_service_names*] [**service-selection-disable** { **false** | **true** }] [**timeout-completion** *session_completion_timeout*]]

ac-cookie *ac_cookie*

Specify the AC-Cookie to use in PADO packets.

Must be a string of 1-128 characters.

ac-name *ac_name*

Specify the the AC-Name to use in PADO packets.

Must be a string of 1-128 characters.

ctrl-pkt-priority *priority*

Specify the CoS bits to use in PADx packets.

Must be an integer in the range of 0-7.

Default Value: 0.

mtu *pppoe_mtu*

Specify the PPPoE MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

pppoe *pppoe_profile_name*

Specify the name of the PPPOE profile.

Must be a string of 1-128 characters.

service-name *pppoe_service_names*

Specify the supported PPPoE service names. You can simultaneously configure multiple service names.

Must be a string of 1-128 characters.

service-selection-disable { false | true }

Specify to disable or enable the advertising of extra service names in PADO packets.

Must be one of the following:

- false
- true

Default Value: false.

timeout-completion *session_completion_timeout*

Specify the maximum wait time for session to be completed.

Must be an integer in the range of 3-600.

Default Value: 180.

Usage Guidelines

Use this command to configure PPPOE Subscriber profiles. The CLI prompt changes to the PPPOE Profile Configuration mode (config-pppoe-<profile_name>).

profile pppoe max-payload

Configures a range for the ppp-max payload tag value.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-*profile_name*)

Syntax Description **max-payload** { [**deny**] | [**maximum** *maximum_payload_value*] [**minimum** *minimum_payload_value*] }

deny

Specify to deny the PPP-max payload value.

maximum *maximum_payload_value*

Specify the maximum payload value.

Must be an integer in the range of 1-40000.

Default Value: 1500.

minimum *minimum_payload_value*

Specify the minimum value for the payload.

Must be an integer in the range of 1-40000.

Default Value: 1492.

Usage Guidelines Use this command to configure a range for the ppp-max payload tag value.

profile pppoe session-limit circuit-id

Configures the maximum number of sessions allowed per Circuit-ID.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-*profile_name*)

Syntax Description **session-limit circuit-id** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per Circuit-ID.

profile pppoe session-limit mac

Configures the maximum number of sessions allowed per peer MAC address.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description **session-limit mac** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per peer MAC address.

profile pppoe session-limit max

Configures the maximum number of sessions allowed under the PPPoE profile.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description **session-limit max** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed under the PPPoE profile.

profile pppoe session-limit outer-vlan

Configures the maximum number of sessions allowed per outer-vlan, per access interface.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description `session-limit outer-vlan value [threshold threshold_count]`

threshold threshold_count

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per outer-vlan, per access interface.

profile radius

Configures RADIUS client parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `profile radius [[algorithm radius_server_selection_algorithm] [deadtime dead_time] [max-retry max_retry] [timeout retransmit_timeout_duration]]`

algorithm radius_server_selection_algorithm

Specify the algorithm for selecting RADIUS server.

Must be one of the following:

- **first-server**: Highest priority first.
- **round-robin**: Round-robin.

deadtime dead_time

Specify the time to elapse, in minutes, between RADIUS server marked unreachable and when connection can be re-attempted.

Must be an integer in the range of 0-65535.

max-retry max_retry

Specify the maximum number of times the system must attempt retry with the RADIUS server.

Must be an integer in the range of 0-65535.

timeout retransmit_timeout_duration

Specify the time duration to wait for response from the RADIUS server before retransmitting.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure RADIUS client parameters. The CLI prompt changes to the RADIUS Configuration mode (config-radius).

profile radius accounting

Configures RADIUS accounting parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius)

Syntax Description `accounting [[algorithm radius_server_selection_algorithm] [deadtime dead_time] [max-retry max_retry] [timeout retransmit_timeout_duration]]`

algorithm *radius_server_selection_algorithm*

Specify the algorithm for selecting RADIUS server.

Must be one of the following:

- **first-server**: Highest priority first.
- **round-robin**: Round-robin.

deadtime *dead_time*

Specify the time to elapse, in minutes, between RADIUS server marked unreachable and when connection can be re-attempted.

Must be an integer in the range of 0-65535.

max-retry *max_retry*

Specify the maximum number of times the system must attempt retry with the RADIUS server.

Must be an integer in the range of 0-65535.

timeout *retransmit_timeout_duration*

Specify the time duration to wait for response from the RADIUS server before retransmitting.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure RADIUS accounting parameters. The CLI prompt changes to the Accounting Configuration mode (config-accounting).

profile radius accounting attribute

Configures the AAA attribute parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description `attribute [[nas-identifier nas_identifier] [nas-ip nas_ip_address]]`

nas-identifier *nas_identifier*

Specify the attribute name by which the system will be identified in Access-Request messages.

Must be a string of 1-128 characters of 1-32 characters.

nas-ip *nas_ip_address*

Specify the IP address of the AAA NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the AAA attribute parameters. The CLI prompt changes to the Attribute Configuration mode (config-attribute).

profile radius accounting attribute called-station-id

Configures the AAA called-station-id attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

called-station-id { **format-name** *format_name* | *value* }

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA called-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the AAA called-station-id attribute.

profile radius accounting attribute called-station-id format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `called-station-id format-name format_name [nas-port-type nas_port_type]`

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting attribute calling-station-id

Configures the AAA calling-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `calling-station-id { format-name format_name | value }`

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA calling-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA calling-station-id attribute.

profile radius accounting attribute calling-station-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `called-station-id format-name format_name [nas-port-type nas_port_type]`

format-name *format_name*

Specify the attribute format name.
Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.
Must be an integer in the range of 0-44.

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting attribute nas-identifier-format

Configures the AAA nas-identifier-format attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

nas-identifier-format **format-name** *format_name*

format-name *format_name*

Specify the attribute format name.
Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure the AAA nas-identifier-format attribute.

profile radius accounting attribute nas-identifier-format format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

called-station-id **format-name** *format_name* [**nas-port-type** *nas_port_type*]

format-name *format_name*

Specify the attribute format name.
Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.
Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting attribute nas-port

Configures the AAA nas-port attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `nas-port { value | format-e format_e_value }`

format-e *format_e_value*

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLUVQ]*).

value

Specify value of the nas-port attribute.

Must be an integer in the range of 1-maximum.

Usage Guidelines Use this command to configure the AAA nas-port attribute.

profile radius accounting attribute nas-port format-e-list

Configures the AAA nas-port attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `format-e-list nas-port-type nas_port_type_value format-e format_e_value`

format-e *format_e_value*

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLVQ]*).

nas-port-type *nas_port_type_value*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure the AAA nas-port attribute.

profile radius accounting attribute nas-port-id

Configures the AAA nas-port-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **nas-port-id** { *value* | **format-name** *format_name* }

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify value of the AAA nas-port-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA nas-port-id attribute.

profile radius accounting attribute nas-port-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **called-station-id** **format-name** *format_name* [**nas-port-type** *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting detect-dead-server

Configures parameters to detect a dead RADIUS server.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description **detect-dead-server response-timeout** *response_timeout_duration*

response-timeout *response_timeout_duration*

Specify the time duration, in seconds, for a response from the RADIUS server to mark it as unreachable.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure parameters to detect a dead RADIUS server.

profile radius attribute

Configures the AAA attribute parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description **attribute** [[**nas-identifier** *nas_identifier*] [**nas-ip** *nas_ip_address*]]

nas-identifier *nas_identifier*

Specify the attribute name by which the system will be identified in Access-Request messages.

Must be a string of 1-128 characters of 1-32 characters.

nas-ip *nas_ip_address*

Specify the IP address of the AAA NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA attribute parameters. The CLI prompt changes to the Attribute Configuration mode (config-attribute).

profile radius attribute called-station-id

Configures the AAA called-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `called-station-id { format-name format_name | value }`

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA called-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA called-station-id attribute.

profile radius attribute called-station-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `called-station-id format-name format_name [nas-port-type nas_port_type]`

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute calling-station-id

Configures the AAA calling-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `calling-station-id { format-name format_name | value }`

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA calling-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA calling-station-id attribute.

profile radius attribute calling-station-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `called-station-id format-name format_name [nas-port-type nas_port_type]`

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute nas-identifier-format

Configures the AAA nas-identifier-format attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description `nas-identifier-format format-name format_name`

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure the AAA nas-identifier-format attribute.

profile radius attribute nas-identifier-format format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

called-station-id **format-name** *format_name* [**nas-port-type** *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute nas-port

Configures the AAA nas-port attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

nas-port { *value* | **format-e** *format_e_value* }

format-e *format_e_value*

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLUVQ]*).

value

Specify value of the nas-port attribute.

Must be an integer in the range of 1-maximum.

Usage Guidelines Use this command to configure the AAA nas-port attribute.

profile radius attribute nas-port format-e-list

Configures the AAA nas-port attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **format-e-list nas-port-type** *nas_port_type_value* **format-e** *format_e_value*

format-e *format_e_value*

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLVQ]*).

nas-port-type *nas_port_type_value*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure the AAA nas-port attribute.

profile radius attribute nas-port-id

Configures the AAA nas-port-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **nas-port-id** { *value* | **format-name** *format_name* }

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify value of the AAA nas-port-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA nas-port-id attribute.

profile radius attribute nas-port-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **called-station-id format-name** *format_name* [**nas-port-type** *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius detect-dead-server

Configures parameters to detect a dead RADIUS server.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description **detect-dead-server response-timeout** *response_timeout_duration*

response-timeout *response_timeout_duration*

Specify the time duration, in seconds, for a response from the RADIUS server to mark it as unreachable.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure parameters to detect a dead RADIUS server.

profile radius server

Configures RADIUS external server parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius)

Syntax Description **server** *radius_server_ip_address* *radius_server_port_number* [[**priority** *radius_server_priority*] [**secret** *radius_server_secret*] [**type** *server_type*]]

priority radius_server_priority

Specify the priority of the RADIUS server.

Must be an integer in the range of 1-100.

secret radius_server_secret

Specify the secret of the RADIUS server.

Must be a string.

type server_type

Specify the server type.

Must be one of the following:

- **acct**
- **auth**

Default Value: auth.

radius_server_ip_address

Specify the IP address of the RADIUS server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

radius_server_port_number

Specify the port number of the RADIUS server.

Must be an integer in the range of 1-65535.

Usage Guidelines

Use this command to configure RADIUS external server parameters. The CLI prompt changes to the Server Configuration mode (config-server-<ip_address>/<port_number>).

profile radius server-group

Configures association of RADIUS servers to groups.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius)

Syntax Description

server-group *server_group_name*

server_group_name

Specify the name of the RADIUS server group.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to associate RADIUS servers to groups. The CLI prompt changes to the Server Group Configuration mode (config-server-group-<group_name>).

profile radius server-group server

Configures RADIUS server information.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Server Group Configuration (config-server-group-<group_name>)

Syntax Description

server *radius_server_type radius_server_ip_address radius_port_number*

radius_port_number

Specify the port number of the RADIUS server.

radius_server_ip_address

Specify IP address of the RADIUS server.

radius_server_type

Specify the server type.

Must be one of the following:

- **acct**: Server used for accounting requests.
- **auth**: Server is used for authentication/authorization requests.

Usage Guidelines

Use this command to configure RADIUS server information.

profile server-group

Configures AAA custom server groups.

Command Modes

Exec > Global Configuration (config)

Syntax Description

profile server-group *aaa_server_group_name* [**radius-group** *radius_server_group_name*]

radius-group *radius_server_group_name*

Specify name of the RADIUS server group.

aaa_server_group_name

Specify name of the AAA server group.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure AAA custom server groups. The CLI prompt changes to the Server Group Configuration mode (config-server-group-<group_name>).

profile subscriber

Configures subscriber profiles.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
profile subscriber subscriber_profile_name [ activate-feature-templates
template_names | apply-all-class | dhcp-profile dhcp_profile_name | l2tp-profile
l2tp_profile_name | pppoe-profile pppoe_profile_name | session-type session_type ]
```

activate-feature-templates *template_names*

Specify the list of feature templates to activate.

You can configure a maximum of eight elements with this keyword.

apply-all-class

Specify to apply all classes if enabled.

dhcp-profile *dhcp_profile_name*

Specify name of the DHCP-FSOL profile.

l2tp-profile *l2tp_profile_name*

Specify to associate L2TP-FSOL profile.

pppoe-profile *pppoe_profile_name*

Specify name of the PPPOE-FSOL profile.

session-type *session_type*

Specify the allowed session type.

Must be one of the following:

- **ipv4**
- **ipv4v6**
- **ipv6**

Default Value: ipv4v6.

subscriber *subscriber_profile_name*

Specify name of the subscriber profile.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure subscriber profiles. The CLI prompt changes to the Subscriber Configuration mode (config-subscriber-<profile_name>).

profile subscriber aaa

Configures AAA operations.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Class Configuration (config-class-*class_name*)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*) > Class Configuration (config-class-*class_name*)

Syntax Description

aaa *aaa_option* *aaa_profile_name*

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

aaa_profile_name

Specify name of the AAA profile.

Usage Guidelines

Use this command to configure AAA operations.

profile subscriber class

Configures subscriber classification parameters.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*)

Syntax Description `class class_name [activate-feature-templates feature_template_names]`

activate-feature-templates *feature_template_names*

Specify the list of feature template names to activate.

You can configure a maximum of eight elements with this keyword.

class *class_name*

Specify name of the class.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure subscriber classification parameters. The CLI prompt changes to the Class Configuration mode (config-class-<class_name>).

profile subscriber class aaa

Configures AAA operations.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)

Syntax Description `aaa aaa_option profile_name`

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

profile_name

Specify the name of the AAA profile for authentication.

Usage Guidelines Use this command to configure AAA operations.

profile subscriber class matches

Configures the list of match values.

Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)
Syntax Description	<p>matches [match-type <i>match_type</i>]</p> <p>match-type <i>match_type</i></p> <p>Specify the match type.</p> <p>Must be one of the following:</p> <ul style="list-style-type: none"> • all • any
Usage Guidelines	Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile subscriber class matches match

Configures Match Key and value.

Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)
Syntax Description	<p>match <i>match_key</i> { type <i>match_protocol</i> ascii <i>ascii_string</i> regex <i>regex_string</i> }</p> <p>ascii <i>ascii_string</i></p> <p>Specify the ASCII string.</p> <p>Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the <i>Input Pattern Types</i> chapter.</p> <p>You can configure a maximum of eight elements with this keyword.</p> <p>match <i>match_key</i></p> <p>Specify the match key.</p> <p>Must be one of the following:</p> <ul style="list-style-type: none"> • circuit-id • protocol

- **remote-id**
- **source-mac**
- **username**

regex *regex_string*

Specify the regular expression string.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

type *match_protocol*

Specify the match protocol.

Must be one of the following:

- **dhcp**
- **ppp**

You can configure a maximum of two elements with this keyword.

Usage Guidelines

Use this command to configure Match Key and value.

profile subscriber event

Configures subscriber events.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration
(config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*)

Syntax Description

event *event_name* [**activate-feature-templates** *template_names* | **apply-all-class**
| **deactivate-feature-templates** *template_names*]

activate-feature-templates *template_names*

Specify the list of feature templates to activate.

You can configure a maximum of eight elements with this keyword.

apply-all-class

Specify to apply all classes if enabled.

deactivate-feature-templates *template_names*

Specify the list of feature templates to deactivate.

You can configure a maximum of eight elements with this keyword.

event *event_name*

Specify name of the event.

Must be one of the following:

- **session-activate**

Usage Guidelines Use this command to configure subscriber events.

profile subscriber event aaa

Configures AAA operations.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Class Configuration (config-class-*class_name*)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*) > Class Configuration (config-class-*class_name*)

Syntax Description **aaa** *aaa_option* *aaa_profile_name*

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

aaa_profile_name

Specify name of the AAA profile.

Usage Guidelines Use this command to configure AAA operations.

profile subscriber event class

Configures subscriber classification.

Command Modes Exec > Global Configuration

Syntax Description `class { class-name class_name | deactivate-feature-templates template_names | activate-feature-templates template_names }`

activate-feature-templates *template_names*

Specify the list of feature template names to activate.

You can configure a maximum of eight elements with this keyword.

class-name *class_name*

Specify name of the class.

Must be a string of 1-128 characters.

deactivate-feature-templates *template_names*

Specify the list of feature template names to deactivate.

You can configure a maximum of eight elements with this keyword.

Usage Guidelines Use this command to configure subscriber classification.

profile subscriber event class aaa

Configures AAA operations.

Command Modes Exec > Global Configuration

Syntax Description `aaa { aaa-option aaa_option | profile profile_name }`

aaa-option *aaa_option*

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

profile *profile_name*

Specify the AAA profile name for authentication.

Usage Guidelines Use this command to configure AAA operations.

profile subscriber event class matches

Configures the list of match values.

Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)
Syntax Description	<p>matches [match-type match_type]</p> <p>match-type match_type</p> <p>Specify the match type.</p> <p>Must be one of the following:</p> <ul style="list-style-type: none"> • all • any
Usage Guidelines	Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile subscriber event class matches match

Configures Match Key and value.

Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)
Syntax Description	<p>match match_key { type match_protocol ascii ascii_string regex regex_string }</p> <p>ascii ascii_string</p> <p>Specify the ASCII string.</p> <p>Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the <i>Input Pattern Types</i> chapter.</p> <p>You can configure a maximum of eight elements with this keyword.</p> <p>match match_key</p> <p>Specify the match key.</p> <p>Must be one of the following:</p> <ul style="list-style-type: none"> • circuit-id • protocol

- **remote-id**
- **source-mac**
- **username**

regex *regex_string*

Specify the regular expression string.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

type *match_protocol*

Specify the match protocol.

Must be one of the following:

- **dhcp**
- **ppp**

You can configure a maximum of two elements with this keyword.

Usage Guidelines

Use this command to configure Match Key and value.

quit

Exits the management session.

Command Modes

Exec

Syntax Description

quit

Usage Guidelines

Use this command to exit the management session.

rcm switchover

Configures Redundancy and Configuration Manager (RCM) switchover operation.

Command Modes

Exec

Syntax Description

rcm switchover source *ip_address* destination *ip_address*

source *ip_address*

Specify the source IP address.

Must be an IP address.

destination *ip_address*

Specify the destination IP address.

Must be an IP address.

Usage Guidelines Use this command to configure RCM switchover operation.

reconcile ipam

Reconciles IPAM data with CDL records.

Command Modes Exec

Syntax Description **reconcile ipam**

Usage Guidelines Use this reconcile IPAM data with CDL records.

resource pod

Configures Pod resource parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description **resource pod podtype** *pod_type*

gomaxproc *go_max_procedure_cores*

Specify the Go Lang max procedure cores.

Must be an integer in the range of 1-48.

podtype *pod_type*

Specify the pod type.

Usage Guidelines Use this command to configure Pod resource parameter. The CLI prompt changes to the Pod Resource Configuration mode (config-resource-<pod_type>).

resource pod cpu

Configures CPU resource request parameter.

Command Modes Exec > Global Configuration (config) > Pod Resource Configuration (config-resource-*pod_type*)

Syntax Description **cpu request** *cpu_resource_request* **limit** *cpu_resource_limit*

limit *cpu_resource_limit*

Specify the CPU resource limit in milicores.

Must be an integer in the range of 100-1000000.

request *cpu_resource_request*

Specify the CPU resource request in millicores.

Must be an integer in the range of 100-1000000.

Usage Guidelines Use this command to configure CPU resource request parameter.

resource pod labels

Configures K8 Node Affinity label configuration.

Command Modes Exec > Global Configuration (config) > Pod Resource Configuration (config-resource-*pod_type*)

Syntax Description **labels** **key** *label_key* **value** *label_value*

key *label_key*

Specify the key for the label.

Must be a string.

value *label_value*

Specify the value for the label.

Must be a string.

Usage Guidelines Use this command to configure K8 Node affinity label configuration.

resource pod memory

Configures memory resource requests and limit configuration.

Command Modes Exec > Global Configuration (config) > Pod Resource Configuration (config-resource-*pod_type*)

Syntax Description **memory request** *memory_resource_request* **limit** *memory_resource_limit*

limit *memory_resource_limit*

Specify the memory resource limit in megabytes.

Must be an integer in the range of 100-200000.

request *memory_resource_request*

Specify the memory resource request in megabytes.

Must be an integer in the range of 100-200000.

Usage Guidelines

Use this command to configure memory resource requests and limit configuration.

router bfd instance instance-id

Configures Multi-Hop BFD configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description

router bfd instance instance-id *instance_id*

instance-id *instance_id*

Specify the instance ID.

Usage Guidelines

Use this command to configure Multi-Hop BFD configuration. The CLI prompt changes to the Instance ID Configuration mode (config-instance-id-<instance_id>).

router bfd instance instance-id interface-list

Configures monitor interface list configuration.

Command Modes

Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id-*instance_id*)

Syntax Description

router monitor-interface interface-list interface *interface_to_monitor*

gateway-ip *gateway_ip_address*

Specify IP address of the gateway.

Must be a string.

interface *interface_to_monitor*

Specify the interface to monitor.

Must be a string.

Usage Guidelines

Use this command to configure monitor interface list configuration. The CLI prompt changes to the Instance ID Interface Configuration mode (config-instance-id-<interface_name>).

router bfd instance instance-id interface-list neighbors

Configures neighbor details.

Command Modes

Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id-*instance_id*) > Instance ID Interface Configuration (config-instance-id-*interface_name*)

Syntax Description `neighbor neighbor_ip_address`

neighbor neighbor_ip_address

Specify IP address of the neighbor.

Must be a string.

Usage Guidelines Use this command to configure neighbor details.

router bgplist

Configures BGP speaker configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description `router bgp bgp [learnDefaultRoute { false | true } | loopbackBFDPort bfd_local_port_number | loopbackPort bgp_local_port_number]`

bgp bgp

Specify the BGP.

Must be an integer.

learnDefaultRoute { false | true }

Specify whether to enable or disable learning default route and adding it in kernel space.

Must be one of the following:

- **false**
- **true**

Default Value: false.

loopbackBFDPort bfd_local_port_number

Specify the BFD local port number.

Must be an integer.

Default Value: 3784.

loopbackPort bgp_local_port_number

Specify the BGP local port number.

Must be an integer.

Default Value: 179.

Usage Guidelines Use this command to configure the BGP speaker configuration.

router bgplist bfd

Configures BFD configuration.

Command Modes

Exec > Global Configuration (config) > Router Configuration (config-router-router)

Syntax Description

```
bfd { interval bfd_interval | min_rx bfd_min_rx | multiplier bfd_interval_multiplier
}
```

interval *bfd_interval*

Specify, in microseconds, the BFD interval.

Must be an integer.

Default Value: 250000.

min_rx *bfd_min_rx*

Specify, in microseconds, the BFD minimum RX.

Must be an integer.

Default Value: 250000.

multiplier *bfd_interval_multiplier*

Specify the BFD interval multiplier.

Must be an integer.

Default Value: 3.

Usage Guidelines

Use this command to configure the BFD configuration.

router bgplist interfaceList

Configures bonding interface configuration.

Command Modes

Exec > Global Configuration (config) > Router Configuration (config-router-router)

Syntax Description

```
interface bgp_local_interface
```

interface *bgp_local_interface*

Specify the BGP local interface.

Must be a string.

Usage Guidelines

Use this command to configure the bonding interface configuration.

router bgplist interfaceList bondingInterfaces

Configures bonding interface configuration.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router) > Router Interface Configuration (config-router-interface)

Syntax Description **bondingInterface** *linked_bonding_interface*

bondingInterface *linked_bonding_interface*

Specify the linked bonding interface.

Must be a string.

Usage Guidelines Use this command to configure the bonding interface configuration.

router bgplist interfaceList neighbors

Configures neighbor parameters.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router) > Router Interface Configuration (config-router-interface)

Syntax Description **neighbor** *neighbor_ip_address* [**fail-over** *failover_type* | **remote-as** *remote_as_number*]

fail-over *failover_type*

Specify the failover type.

Must be one of the following:

- **bfd**

neighbor *neighbor_ip_address*

Specify the IP address of the neighbor.

Must be a string.

remote-as *remote_as_number*

Specify the Autonomous System (AS) number of the BGP neighbor.

Must be an integer.

Default Value: 65000.

Usage Guidelines Use this command to configure the neighbor parameters.

router bgplist policies

Configures policy parameters.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router)

Syntax Description `policy-name policy_name [as-path-set as_path_set | gateWay gateway_address | interface interface | ip-prefix ip_prefix | isStaticRoute { false | true } | mask-range mask_range | modifySourceIp { false | true }]`

as-path-set as_path_set

Specify the Autonomous System (AS) path set.

Must be a string.

gateWay gateway_address

Specify the gateway address.

Must be a string.

interface interface

Specify the interface to set as source ip.

Must be a string.

ip-prefix ip_prefix

Specify the IP prefix.

Must be a string.

isStaticRoute { false | true }

Specify whether to enable or disable adding static route into kernel space.

Must be one of the following:

- false
- true

Default Value: false.

mask-range mask_range

Specify the mask range.

Must be a string.

modifySourceIp { false | true }

Specify whether to enable or disable modifying source IP of incoming route.

Must be one of the following:

- **false**
- **true**

Default Value: false.

policy-name *policy_name*

Specify name of the policy.

Must be a string.

source-prefix *source_ip_prefix*

Specify the source IP prefix.

Must be a string.

Usage Guidelines

Use this command to configure the policy parameters.

router monitor-interface interface-list

Configures monitor interface list configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description

router monitor-interface interface-list **interface** *interface_to_monitor*
linked-interface *linked_interface_to_monitor*

interface *interface_to_monitor*

Specify the interface to monitor.

Must be a string.

linked-interface *linked_interface_to_monitor*

Specify the linked interface to monitor.

Must be a string.

Usage Guidelines

Use this command to configure monitor interface list configuration.

screen-length

Configures the number of rows of text that the terminal screen displays.

Command Modes

Exec

Syntax Description

screen-length *number_of_rows*

number_of_rows

Specify the number of rows that the terminal screen displays.

Must be an integer.

Usage Guidelines

Use this command to set the number of rows that the terminal screen displays.

screen-width

Configures the number of columns that the terminal screen displays.

Command Modes

Exec

Syntax Description

screen-width *number_of_columns*

number_of_columns

Specify the number of columns that the terminal screen displays.

Must be an integer.

Usage Guidelines

Use this command to set the number of columns that the terminal screen displays.

send

Sends messages to the terminal of a specific user or all users.

Command Modes

Exec

Syntax Description

send *user message*

user

Specify the user to whom the message must be sent.

Must be a string. Select from the possible completion options.

message

Specify the message that must be sent.

Must be a string.

Usage Guidelines

Use this command to send messages to the terminal of a specific user or to all users.

show

Displays the system information.

Command Modes Exec

Syntax Description `show system_component`

system_component

Specify the component to view the information.

Must be a string. Select from the possible completion options.

Usage Guidelines Use this command to view the system information.

show bfd-neighbor

Displays BFD status of neighbors.

Command Modes Exec

Syntax Description `show bfd-neighbor [ip ip_address]`

ip ip_address

Specify the IP address of the neighbor.

Must be a string.

Usage Guidelines Use this command to view BFD status of neighbors.

show bgp-global

Displays BGP global configuration.

Command Modes Exec

Syntax Description `show bgp-global`

Usage Guidelines Use this command to view BGP global configuration.

show bgp-kernel-route

Displays BGP kernel-configured routes.

Command Modes Exec

Syntax Description `show bgp-kernel-route [application { false | true }]`

application { false | true }

Specify whether to display application added routes.

Must be one of the following:

- **false**
- **true**

Default Value: false.

Usage Guidelines Use this command to view BGP kernel-configured routes.

show bgp-neighbors

Displays BGP neighbor's status.

Command Modes Exec

Syntax Description **show bgp-neighbors [ip *ip_address*]**

ip *ip_address*

Specify the IP address of the neighbor.

Must be a string.

Usage Guidelines Use this command to view BGP neighbor's status.

show bgp-route-summary

Displays BGP route summary.

Command Modes Exec

Syntax Description **show bgp-route-summary**

Usage Guidelines Use this command to view BGP route summary.

show bgp-routes

Displays BGP routes information.

Command Modes Exec

Syntax Description **show bgp-routes**

Usage Guidelines Use this command to view BGP routes information.

show config-error info

Displays configuration error information.

Command Modes Exec

Syntax Description `show config-error [info]`

Usage Guidelines Use this command to view configuration error information.

show diagnostics info

Displays diagnostics information.

Command Modes Exec

Syntax Description `show diagnostics [info]`

Usage Guidelines Use this command to view diagnostics information.

show edr

Displays EDR Transaction Procedure Event fields.

Command Modes Exec

Syntax Description `show edr { [event transaction_procedure_event] [transaction-procedure transaction_procedure] }`

event *transaction_procedure_event*

Specify the transaction procedure event name/id/all.

Must be a string.

transaction-procedure *transaction_procedure*

Specify the transaction procedure's name, ID, or all.

Must be a string.

Usage Guidelines Use this command to view EDR Transaction Procedure Event fields.

show endpoint all

Displays endpoint status.

Command Modes	Exec
Syntax Description	<code>show endpoint [all]</code>
Usage Guidelines	Use this command to view the status of endpoints.

show endpoint info

Displays endpoint information.

Command Modes	Exec
Syntax Description	<code>show endpoint info</code>
Usage Guidelines	Use this command to view endpoint information.

show geo-maintenance-mode

Indicates whether maintenance mode is enabled or disabled.

Command Modes	Exec
Syntax Description	<code>show geo-maintenance-mode</code>
Usage Guidelines	Use this command to view whether maintenance mode is enabled or disabled.

show georeplication

Displays ETCD/Cache checksum.

Command Modes	Exec
Syntax Description	<code>show georeplication checksum instance-id <i>instance_id</i></code> checksum Specify checksum. instance-id <i>instance_id</i> Specify the instance ID for which checksum will be displayed. Must be a string.
Usage Guidelines	Use this command to view ETCD/Cache checksum.

show l2tp-tunnel

Show L2TP tunnel information.

Command Modes

Exec

Syntax Description

show l2tp-tunnel [**count** *tunnels_count* | **detail**]

count *tunnels_count*

Specify the number of tunnels.

detail

Specify to display detailed information.

Usage Guidelines

Use this command to view L2TP tunnel information.

show l2tp-tunnel filter

Show L2TP tunnel information for additional filters.

Command Modes

Exec

Syntax Description

show l2tp-tunnel filter { **destination-addr** *destination_address* | **source-addr** *source_address* | **state** *state_info* | **tunnel-id** *l2tp_tunnel_id* | **tunnel-type** *tunnel_type* | **tunnelAssignmentID** *tunnel_assignment_id* | **upf** *upf_info* }

destination-addr *destination_address*

Specify the IP address of the tunnel destination.

Must be a string.

source-addr *source_address*

Specify the IP address of the tunnel source.

Must be a string.

state *state_info*

Specify the state information.

Must be one of the following:

- **complete**
- **incomplete**

tunnel-id *l2tp_tunnel_id*

Specify the L2TP tunnel ID.

Must be an integer in the range of 1-65535.

tunnel-type *tunnel_type*

Specify the tunnel type.

Must be one of the following:

- lac
- lns

tunnelAssignmentID *tunnel_assignment_id*

Specify assignment ID of the tunnel.

Must be a string.

upf *upf_info*

Specify the UPF.

Must be a string.

Usage Guidelines

Use this command to view L2TP tunnel information for additional filters.

show local-interface-status

Displays status of local interface.

Command Modes

Exec

Syntax Description

show local-interface-status interface *local_interface_name*

interface *local_interface_name*

Specify name of the local interface.

Must be a string.

Usage Guidelines

Use this command to view status of local interface .

show peers all

Displays peer information.

Command Modes

Exec

Syntax Description

show peers [*all*]

Usage Guidelines Use this command to view peer information.

show radius

Displays RADIUS client data.

Command Modes Exec

Syntax Description `show radius`

Usage Guidelines Use this command to view RADIUS client data.

show radius acct-server

Displays RADIUS accounting server data.

Command Modes Exec

Syntax Description `show radius acct-server [ip_port]`

ip_port

Specify the ip_address:port_number of the RADIUS server.

Must be a string.

Usage Guidelines Use this command to view RADIUS accounting server data.

show radius auth-server

Displays RADIUS authentication server data.

Command Modes Exec

Syntax Description `show radius auth-server [ip_port]`

ip_port

Specify the ip_address:port_number of the RADIUS server.

Must be a string.

Usage Guidelines Use this command to view RADIUS authentication server data.

show radius-dyn-auth

Displays RADIUS dynamic-author data.

Command Modes	Exec
Syntax Description	<code>show radius radius-dyn-auth</code>
Usage Guidelines	Use this command to view RADIUS dynamic-author data.

show radius-dyn-auth clients

Displays RADIUS dynamic-author information.

Command Modes	Exec
Syntax Description	<code>show radius dynauth clients</code>
Usage Guidelines	Use this command to view RADIUS dynamic-author information.

show resources info

Displays resource information.

Command Modes	Exec
Syntax Description	<code>show resources [info]</code>
Usage Guidelines	Use this command to view information about the configured resources.

show role

Displays current role for the specified instance.

Command Modes	Exec
Syntax Description	<code>show role instance-id <i>instance_id</i></code> <code>instance-id <i>instance_id</i></code> Specify the instance ID for which role must be displayed.
Usage Guidelines	Use this command to view current role for the specified instance.

show rpc all

Displays RPC configuration information.

Command Modes	Exec
----------------------	------

Syntax Description `show rpc [all]`

Usage Guidelines Use this command to view RPC configuration information.

show running-status info

Displays the system's current status information.

Command Modes Exec

Syntax Description `show running-status [info]`

Usage Guidelines Use this command to view the system's current status information.

show sessions

Displays pending session commits in the database.

Command Modes Exec

Syntax Description `show sessions`

Usage Guidelines Use this command to view pending session commits in the database.

show sessions affinity

Displays the affinity count per instance.

Command Modes Exec

Syntax Description `show sessions affinity`

Usage Guidelines Use this command to view the affinity count per instance.

show sessions commit-pending

Displays all pending session commits.

Command Modes Exec

Syntax Description `show sessions commit-pending`

Usage Guidelines Use this command to view all pending session commits.

show subscriber

Displays subscriber information.

Command Modes Exec

Syntax Description `show subscriber { all | supi supi_id }`

all

Specify all SUPIs or IMEIs.

gr-instance *gr_instance*

Specify the network function service under which to search.

imei *imei_id*

Specify the International Mobile Equipment Identity.

Must be a string of 15-16 characters.

namespace *namespace*

NOTE: This keyword is deprecated, use `nf-service` instead. Specify the product namespace under which to search.

Default Value: `cisco-mobile-infra:none`.

nf-service *nf_service*

Specify the network function service under which to search.

Default Value: `cisco-mobile-infra:none`.

supi *supi_id*

Specify the subscriber's SUPI ID.

Must be a string.

Usage Guidelines Use this command to view summary and detailed subscriber information for all subscribers or specific subscribers based on SUPI, IMEI, or all.

show subscriber

Shows BNG subscriber data.

Command Modes Exec

Syntax Description `show subscriber type [count | detail | sublabel subscriber_label]`

acct-sess-id *accounting_session_id*

Specify the accounting session ID.

Must be a string of 1-64 characters.

count

Specify to display the number of sessions.

debug

Specify debug information.

detail

Specify to display detailed information.

sublabel *subscriber_label*

Specify the subscriber label.

Must be a string of 1-64 characters.

type

Specify the type.

Must be one of the following:

- **dhcp**: DHCP information.
- **lns**: Lns information.
- **pppoe**: PPPoE information.
- **session**: SessionManager information.

Usage Guidelines Use this command to view BNG subscriber data.

show subscriber filter

Configures additional filters.

Command Modes Exec

Syntax Description

```
show subscriber type filter [ afi address_family | iana-state-bound
iana_bound_state | iapd-state-bound iapd_bound_state | ipv4-addr ipv4_address |
ipv4-pool ipv4_pool_name | ipv4-range ipv4_address_range | ipv4-state-bound
ipv4_bound_state | ipv6-addr ipv6_address | ipv6-addr-pool ipv6_address_pool_name |
ipv6-addr-range ipv6_address_range | ipv6-pfx ipv6_prefix | ipv6-pfx-pool
ipv6_prefix_pool | ipv6-pfx-range ipv6_prefix_range | mac mac_address | port-id
upf_port_id | state session_state | up-subs-id up_subscriber_id | upf upf_name |
upmgr sm_up_info | username session_user_name | vrf vrf_name ]
```

afi address_family

Specify the address family.

Must be one of the following:

- **dual**: Dual-Stack sessions.
- **ipv4**: IPv4-only sessions.
- **ipv6**: IPv6-only sessions.
- **pending**: Inflight sessions (applicable for SessMgr).

feat-template feature_template_profile_name

Specify name of the feature-template profile.

Must be a string.

iana-state-bound iana_bound_state

Specify the IANA bound state.

Must be one of the following:

- **iana-state-bound**

iapd-state-bound iapd_bound_state

Specify the IAPD bound state.

Must be one of the following:

- **iapd-state-bound**

ipv4-addr ipv4_address

Specify the IPv4 address in the format "*pool-name/ipv4-addr*".

Must be a string.

ipv4-pool ipv4_pool_name

Specify name of the IPv4 pool.

Must be a string.

ipv4-range ipv4_address_range

Specify the IPv4 address range in the format "*poolName/start-ip*".

Must be a string.

ipv4-state-bound ipv4_bound_state

Specify the IPv4 bound state.

Must be one of the following:

- **ipv4-state-bound**

ipv6-addr-pool *ipv6_address_pool_name*

Specify name of the IPv6 address pool.

Must be a string.

ipv6-addr-range *ipv6_address_range*

Specify the IPv6 address range in the format "*poolName/start-ip*".

Must be a string.

ipv6-addr *ipv6_address*

Specify the IPv6 address in the format "*pool-name/ipv6-addr*".

Must be a string.

ipv6-pfx-pool *ipv6_prefix_pool*

Specify name of the IPv6 prefix pool.

Must be a string.

ipv6-pfx-range *ipv6_prefix_range*

Specify the IPv6 prefix range in the format "*poolName/start-pfx*".

Must be a string.

ipv6-pfx *ipv6_prefix*

Specify the IPv6 prefix in the format "*pool-name/ipv6-pfx*".

Must be a string.

mac *mac_address*

Specify the MAC address in the "aabb.ccdd.eeff" format.

Must be a string.

port-id *upf_port_id*

Specify the user plane function port ID in the format "*upf/portid*".

Must be a string.

ppp-type *ppp_session_type*

Specify the PPP session type.

Must be one of the following:

- **lac**

- **pta**: PPPoE PTA subscriber.

session-id *session_id*

Specify the L2TP session ID.

Must be an integer in the range of 1-65535.

sesstype *session_type*

Specify the SM subscriber session type.

Must be one of the following:

- **ipoe**: IPOE subscribers.
- **lac**
- **lms**
- **ppp**: PPP subscribers.

smstate *sm_session_state*

Specify the state of the SM session.

Must be one of the following:

- **created**
- **deleted**
- **established**

smupstate *smup_session_state*

Specify the state of the SMUP session.

Must be one of the following:

- **smUpSessionCreated**
- **smUpSessionDeleted**
- **smUpSessionWait4SmCreate**

state *session_state*

Specify the session state.

Must be one of the following:

- **complete**: Specify the state is complete.
- **incomplete**: Specify the state is incomplete.

tunnel-dest-addr *tunnel_dest_address*

Specify the L2TP tunnel destination address.

Must be a string.

tunnel-id *tunnel_id*

Specify the L2TP tunnel ID.

Must be an integer in the range of 1-65535.

up-sub-ids *up_subscriber_id*

Specify the UP subscriber ID.

Must be a string.

upf *upf_name*

Specify name of the user plane function.

Must be a string.

username *session_user_name*

Specify the user name of the session.

Must be a string.

Usage Guidelines Use this command to configure additional filters.

show subscriber opts

Configures command output modifiers.

Command Modes Exec

Syntax Description *detail*

Syntax Description *count*

count

Displays count of number of sessions.

detail

Displays detailed information.

Usage Guidelines Use this command to configure output modifiers.

show subscriber synchronize

Synchronize info.

Command Modes Exec

Syntax Description `show subscriber synchronize upf upf_info`

Syntax Description `show subscriber synchronize-cp upf upf_info`

synchronise-cp

Specify to synchronise CP information.

Must be one of the following:

- **synchronize-cp**

synchronise

Specify to synchronise UP information.

Must be one of the following:

- **synchronize**

upf upf_info

Specify UPF information.

Must be a string of 1-64 characters.

Usage Guidelines Use this command to synchronise info.

show test-radius accounting

Tests RADIUS accounting server function.

Command Modes Exec

Syntax Description `test-radius accounting { all [[client-nas nas_ip_address] [username user_name]] | server server_ip_address { [client-nas nas_ip_address] port server_port_number [username user_name] } | server-group [[client-nas nas_ip_address] [username user_name]] }`

all

Specify to test all configured servers.

Must be one of the following:

- **all**

client-nas *nas_ip_address*

Specify the IP address of the client NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

port *server_port_number*

Specify the RADIUS server port number.

Must be an integer in the range of 1-65535.

server-group *server_group_name*

Specify name of the sever group.

Must be a string of 1-64 characters.

server *server_ip_address*

Specify IP address of the RADIUS server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

username *user_name*

Specify the user name.

Must be a string of 1-64 characters.

Default Value: test.

Usage Guidelines

Use this command to test RADIUS accounting server function.

show test-radius authentication

Tests RADIUS authentication server.

Command Modes

Exec

Syntax Description

```
test-radius authentication { all [ [ client-nas nas_ip_address ] [ password
  user_password ] [ username user_name ] ] | server server_ip_address { [ client-nas
  nas_ip_address ] [ password user_password ] port server_port_number [ username
```

```
user_name ] } | server-group [ [ client-nas nas_ip_address ] [ password
user_password ] [ username user_name ] ] }
```

all

Specify to test all configured servers.

Must be one of the following:

- all

client-nas nas_ip_address

Specify the IP address of the client NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

password user_password

Specify the password for user with authentication verified.

Must be a string of 1-64 characters.

Default Value: test.

port server_port_number

Specify the RADIUS server port number.

Must be an integer in the range of 1-65535.

server-group server_group_name

Specify name of the sever group.

Must be a string of 1-64 characters.

server server_ip_address

Specify IP address of the RADIUS server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

username user_name

Specify the user name.

Must be a string of 1-64 characters.

Default Value: test.

Usage Guidelines Use this command to test RADIUS authentication server.

show-defaults

Displays the default configuration.

Command Modes Exec

Syntax Description `show-defaults { false | true }`

`{ false | true }`

Specify whether to display or hide the default values. To display, select true. Otherwise, select false.

Must be either "false" or "true".

Usage Guidelines Use this command to view the default configuration.

smiuser

Configures the Subscriber Microservices Infrastructure (SMI) user account parameters.

Command Modes Exec

Syntax Description `smiuser { add-group groupname group_name | add-user { username username | password password } | change-password { username username | current_password current_password | new_password new_password | confirm_password new_password | password_expire_days expire_days } | change-self-password { current_password current_password | new_password new_password | confirm_password new_password | password_expire_days expire_days } | delete-group groupname group_name | delete-user username username | unassign-user-group { groupname groupname_pam | username username_pam } | update-password-length length password_length }`

username *username*

Specify the username.

Must be a string.

password *password*

Specify the user password.

Must be a string.

confirm_password *new_password*

Confirm the new password.

Must be a string.

current_password *current_password*

Specify the current password.

Must be a string.

new_password *new_password*

Specify the new password.

Must be a string.

password_expire_days *expire_days*

Specify the number of days before the password expires.

Must be an integer.

groupname *group_name*

Specify the group name.

Must be a string.

groupname *groupname_pam*

Specify the group name in PAM.

Must be a string.

username *username_pam*

Specify the user name in PAM.

Must be a string.

length *password_length*

Specify the minimum password length.

Must be an integer.

Usage Guidelines Use this command to configure the smiuser parameters.

subscriber

Configures subscriber parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `subscriber event-trace-disable`

Usage Guidelines Use this command to configure subscriber parameters.

subscriber route-synchronize

Synchronizes routes to UPF.

Command Modes Exec

Syntax Description `subscriber route-synchronize upf user_plane_name`

upf user_plane_name

Specify name of the user plane function.

Must be a string of 1-64 characters.

Usage Guidelines Use this command to synchronize routes to UPF.

subscriber session-synchronize

Synchronizes sessions to UPF.

Command Modes Exec

Syntax Description `subscriber session-synchronize upf user_plane_name [abort | timeout sla_timeout]`

abort

Specify to abort synchronization.

timeout *sla_timeout*

Specify the SLA timeout duration in seconds.

Must be an integer in the range of 10-1800.

upf user_plane_name

Specify name of the user plane function.

Must be a string of 1-64 characters.

Usage Guidelines Use this command to synchronize sessions to UPF.

subscriber session-synchronize-cp

Synchronizes sessions on CP.

Command Modes Exec

Syntax Description `subscriber session-synchronize-cp upf user_plane_name [abort | timeout timeout_value | tps tps]`

abort

Specify to abort synchronization.

timeout *timeout_value*

Specify the timeout duration in minutes.
Must be an integer in the range of 2-100.

tps *tps*

Specify the TPS.
Must be an integer in the range of 40-4000.

upf *user_plane_name*

Specify name of the user plane function.
Must be a string of 1-64 characters.

Usage Guidelines Use this command to synchronize sessions on CP.

system

Configures the NF's system operations.

Command Modes Exec

Syntax Description `system { ops-center stop | synch { start | stop } | upgrade | uuid-override new-uuid uuid_value }`

ops-center stop

Stop the synching of configuration.

synch { start | stop }

Starts or stops the synching of configuration,

upgrade

Initiates the upgrade of a product.

uuid-override new-uuid *uuid_value*

Change the Universally Unique Identifier (UUID) to a new value.

Must be a string.

Usage Guidelines

Use this command to display the NF's system operations.

terminal

Configures the type of terminal.

Command Modes

Exec

Syntax Description

terminal *terminal_type*

terminal_type

Specify the terminal type.

Must be one of the following:

- ansi
- generic
- linux
- vt100
- xterm

Usage Guidelines

Use this command to configure the terminal type.

timestamp

Configures the timestamp parameters.

Command Modes

Exec

Syntax Description

timestamp { **disable** | **enable** }

{ disable | enable }

Enable or disable the timestamp display.

Usage Guidelines

Use this command to configure the timestamp.

user-plane

Configures the userplane configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description

user-plane *userplane_name* [[**offline**] [**subscriber-profile** *subscriber_profile*]]

offline

Specify as offline.

subscriber-profile *subscriber_profile*

Specify the Subscriber Profile to associate at current level.

user-plane *userplane_name*

Specify name of the userplane.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure the userplane configuration. The CLI prompt changes to the Userplane Configuration mode (config-user-plane-<userplane_name>).

user-plane peer-address

Configures the userplane IP address.

Command Modes

Exec > Global Configuration > Userplane Configuration (config-user-plane-*userplane_name*)

Syntax Description

peer-address **ipv4** *ipv4_address*

ipv4 *ipv4_address*

Specify the IPv4 address.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the userplane IP address.

user-plane port-id

Configures Port Identifier parameter.

Command Modes

Exec > Global Configuration > Userplane Configuration (config-user-plane-*userplane_name*)

Syntax Description `port-id port_id [subscriber-profile subscriber_profile]`

port-id port_id

Specify the port identifier.

Must be a string of 1-128 characters.

subscriber-profile subscriber_profile

Specify the Subscriber Profile to associate to the Port Identifier level.

Usage Guidelines Use this command to configure the Port Identifier parameter. The CLI prompt changes to the Port ID Configuration mode (config-port-id-<port_id>).

who

Displays information on currently logged on users.

Command Modes Exec

Syntax Description `who`

Usage Guidelines Use this command to view information on currently logged on users. The command output displays the Session, User, Context, From (IP address), Protocol, Date, and Mode information.



CHAPTER 2

Input Pattern Types

- [arg-type](#), on page 195
- [crypt-hash](#), on page 196
- [date-and-time](#), on page 197
- [domain-name](#), on page 197
- [dotted-quad](#), on page 198
- [hex-list](#), on page 198
- [hex-string](#), on page 199
- [ipv4-address](#), on page 199
- [ipv4-address-and-prefix-length](#), on page 199
- [ipv4-address-no-zone](#), on page 199
- [ipv4-prefix](#), on page 199
- [ipv6-address](#), on page 200
- [ipv6-address-and-prefix-length](#), on page 200
- [ipv6-address-no-zone](#), on page 201
- [ipv6-prefix](#), on page 201
- [mac-address](#), on page 202
- [object-identifier](#), on page 202
- [object-identifier-128](#), on page 202
- [octet-list](#), on page 203
- [phys-address](#), on page 203
- [sha-256-digest-string](#), on page 203
- [sha-512-digest-string](#), on page 204
- [size](#), on page 204
- [uuid](#), on page 205
- [yang-identifier](#), on page 205

arg-type

Pattern:
`'[^*]*.*|..+'; // must not be single '*'`

Pattern:
`'*'`

This statement can be used to hide a node from some, or all, northbound interfaces. All nodes with the same value are considered a hide group and are treated the same with regards to being visible or not in a northbound interface.

A node with an hidden property is not shown in the northbound user interfaces (CLI and Web UI) unless an 'unhide' operation is performed in the user interface.

The hidden value 'full' indicates that the node must be hidden from all northbound interfaces, including programmatical interfaces such as NETCONF. The value '*' is not valid. A hide group can be unhidden only if this is explicitly allowed in the confd.conf(5) daemon configuration.

Multiple hide groups can be specified by giving this statement multiple times. The node is shown if any of the specified hide groups is given in the 'unhide' operation. If a mandatory node is hidden, a hook callback function (or similar) might be needed in order to set the element

crypt-hash

Pattern:

```
'$0$.*'
'|$1$[a-zA-Z0-9./]{1,8}$[a-zA-Z0-9./]{22}'
'|$5$(rounds=\d+)$?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{43}'
'|$6$(rounds=\d+)$?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{86}'
```

The **crypt-hash** type is used to store passwords using a hash function. The algorithms for applying the hash function and encoding the result are implemented in various UNIX systems as the function crypt(3).

A value of this type matches one of the forms:

- `0<clear text password>`
- `$<id>$<salt>$<password hash>`
- `$<id>$<parameter>$<salt>$<password hash>`

The '\$0\$' prefix signals that the value is clear text. When such a value is received by the server, a hash value is calculated, and the string '\$<id>\$<salt>\$' or '\$<id>\$<parameter>\$<salt>\$' is prepended to the result. This value is stored in the configuration data store.

If a value starting with '\$<id>\$', where <id> is not '0', is received, the server knows that the value already represents a hashed value, and stores it as is in the data store.

When a server needs to verify a password given by a user, it finds the stored password hash string for that user, extracts the salt, and calculates the hash with the salt and given password as input. If the calculated hash value is the same as the stored value, the password given by the client is accepted.

This type defines the following hash functions:

Id	Hash Function	Feature
1	MD5	crypt-hash-md5
5	SHA-256	crypt-hash-sha-256
6	SHA-512	crypt-hash-sha-512

The server indicates support for the different hash functions by advertising the corresponding feature.

Reference:

- IEEE Std 1003.1-2008 - crypt() function
- RFC 1321: The MD5 Message-Digest Algorithm
- FIPS.180-3.2008: Secure Hash Standard

date-and-time

Pattern:

```
'\d{4}-\d{2}-\d{2}T\d{2}:\d{2}:\d{2}(\.\d+)?'
'(Z|[\+\-]\d{2}:\d{2})'
```

The date-and-time type is a profile of the ISO 8601 standard for representation of dates and times using the Gregorian calendar. The profile is defined by the date-time production in Section 5.6 of RFC 3339. The date-and-time type is compatible with the dateTime XML schema type with the following notable exceptions:

1. The date-and-time type does not allow negative years.
2. The date-and-time time-offset -00:00 indicates an unknown time zone (see RFC 3339) while -00:00 and +00:00 and Z all represent the same time zone in dateTime.
3. The canonical format (see below) of data-and-time values differs from the canonical format used by the dateTime XML schema type, which requires all times to be in UTC using the time-offset 'Z'.

This type is not equivalent to the DateAndTime textual convention of the SMIV2 since RFC 3339 uses a different separator between full-date and full-time and provides higher resolution of time-secfrac. The canonical format for date-and-time values with a known time zone uses a numeric time zone offset that is calculated using the device's configured known offset to UTC time.

A change of the device's offset to UTC time will cause date-and-time values to change accordingly. Such changes might happen periodically in case a server follows automatically daylight saving time (DST) time zone offset changes. The canonical format for date-and-time values with an unknown time zone (usually referring to the notion of local time) uses the time-offset -00:00.

Reference:

- RFC 3339: Date and Time on the Internet: Timestamps
- RFC 2579: Textual Conventions for SMIV2
- XSD-TYPES: XML Schema Part 2: Datatypes Second Edition

domain-name

Pattern:

```
'((([a-zA-Z0-9_]([a-zA-Z0-9\-\_]){0,61})?[a-zA-Z0-9]\.)*'
'([a-zA-Z0-9_]([a-zA-Z0-9\-\_]){0,61})?[a-zA-Z0-9]\.?'
'|\.'
```

The domain-name type represents a DNS domain name. The name must fully qualified whenever possible. Internet domain names are only loosely specified. Section 3.5 of RFC 1034 recommends a syntax (modified in Section 2.1 of RFC 1123). The Pattern above is intended to allow for current practice in domain name use, and some possible future expansion. It is designed to hold various types of domain names, including names used for A or AAAA records (host names) and other records, such as SRV records.

The Internet host names have a stricter syntax (described in RFC 952) than the DNS recommendations in RFCs 1034 and 1123, and that systems that want to store host names in schema nodes using the domain-name type are recommended to adhere to this stricter standard to ensure interoperability.

The encoding of DNS names in the DNS protocol is limited to 255 characters. Since the encoding consists of labels prefixed by a length bytes and there is a trailing NULL byte, only 253 characters can appear in the textual dotted notation.

The description clause of schema nodes using the domain-name type must describe when and how these names are resolved to IP addresses. The resolution of a domain-name value may require to query multiple DNS records. For example, A for IPv4 and AAAA for IPv6. The order of the resolution process and which DNS record takes precedence can either be defined explicitly or may depend on the configuration of the resolver.

Domain-name values use the US-ASCII encoding. Their canonical format uses lowercase US-ASCII characters. Internationalized domain names MUST be A-labels as per RFC 5890.

Reference:

- RFC 952: DoD Internet Host Table Specification
- RFC 1034: Domain Names - Concepts and Facilities
- RFC 1123: Requirements for Internet Hosts -- Application and Support
- RFC 2782: A DNS RR for specifying the location of services (DNS SRV)
- RFC 5890: Internationalized Domain Names in Applications (IDNA): Definitions and Document Framework

dotted-quad

Pattern:

```
'(( [0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5] ) \. ) {3} '
' ( [0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5] ) '
```

An unsigned 32-bit number expressed in the dotted-quad notation, that is, four octets written as decimal numbers and separated with the '.' (full stop) character.

hex-list

Pattern:

```
' ( ( [0-9a-fA-F] ) {2} ( : ( [0-9a-fA-F] ) {2} ) * ) ? '
```

DEPRECATED: Use yang:hex-string instead. There are no plans to remove tailf:hex-list. A list of colon-separated hexa-decimal octets, for example '4F:4C:41:71'.

The statement tailf:value-length can be used to restrict the number of octets. Using the 'length' restriction limits the number of characters in the lexical representation

hex-string

Pattern:

```
' ([0-9a-fA-F]{2} (: [0-9a-fA-F]{2}) *) ?'
```

A hexadecimal string with octets represented as hex digits separated by colons. The canonical representation uses lowercase characters.

ipv4-address

Pattern:

```
' (([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) \. ) {3} '  
' ([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) '  
' (% [\p{N} \p{L} ]+ ) ?'
```

The ipv4-address type represents an IPv4 address in dotted-quad notation. The IPv4 address may include a zone index, separated by a % sign. The zone index is used to disambiguate identical address values. For link-local addresses, the zone index will typically be the interface index number or the name of an interface. If the zone index is not present, the default zone of the device will be used. The canonical format for the zone index is the numerical format.

ipv4-address-and-prefix-length

Pattern:

```
' (([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) \. ) {3} '  
' ([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) '  
' / ( ([0-9] ) | ( [1-2] [0-9] ) | ( 3 [0-2] ) )'
```

The ipv4-address-and-prefix-length type represents a combination of an IPv4 address and a prefix length. The prefix length is given by the number following the slash character and must be less than or equal to 32.

ipv4-address-no-zone

Pattern:

```
' [0-9\. ] *'
```

An IPv4 address is without a zone index and derived from ipv4-address that is used in situations where the zone is known from the context and hence no zone index is needed.

ipv4-prefix

Pattern:

```
' (([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) \. ) {3} '  
' ([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) '  
' / ( ([0-9] ) | ( [1-2] [0-9] ) | ( 3 [0-2] ) )'
```

The ipv4-prefix type represents an IPv4 address prefix. The prefix length is given by the number following the slash character and must be less than or equal to 32.

A prefix length value of 'n' corresponds to an IP address mask that has n contiguous 1-bits from the most significant bit (MSB) and all other bits set to 0.

The canonical format of an IPv4 prefix has all bits of the IPv4 address set to zero that are not part of the IPv4 prefix.

ipv6-address

Pattern:

```
'((:| [0-9a-fA-F]{0,4}) : ) ([0-9a-fA-F]{0,4} : ) {0,5}'
'((( [0-9a-fA-F]{0,4} : ) ? ( : | [0-9a-fA-F]{0,4} ) ) | )'
'((( (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) \. ) {3} | Pattern:'
' (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) ) )'
' (% [\p{N} \p{L} ] + ) ?'
```

Pattern:

```
'( ([^: ] + ) {6} ( ([^: ] + : [^: ] + ) | ( . * \. . * ) ) ) |'
' ( ( ([^: ] + : ) * [^: ] + ) ? : : ( ([^: ] + : ) * [^: ] + ) ? )'
' (% . + ) ?'
```

The ipv6-address type represents an IPv6 address in full, mixed, shortened, and shortened-mixed notation. The IPv6 address may include a zone index, separated by a % sign.

The zone index is used to disambiguate identical address values. For link-local addresses, the zone index will typically be the interface index number or the name of an interface. If the zone index is not present, the default zone of the device will be used.

The canonical format of IPv6 addresses uses the textual representation defined in Section 4 of RFC 5952. The canonical format for the zone index is the numerical format as described in Section 11.2 of RFC 4007.

Reference:

- RFC 4291: IP Version 6 Addressing Architecture
- RFC 4007: IPv6 Scoped Address Architecture
- RFC 5952: A Recommendation for IPv6 Address Text Representation

ipv6-address-and-prefix-length

Pattern:

```
'((:| [0-9a-fA-F]{0,4}) : ) ([0-9a-fA-F]{0,4} : ) {0,5}'
'((( [0-9a-fA-F]{0,4} : ) ? ( : | [0-9a-fA-F]{0,4} ) ) | )'
'((( (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) \. ) {3} |'
' (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) ) )'
' ( / ( ( [0-9] ) | ( [0-9] {2} ) | ( 1 [0-1] [0-9] ) | ( 12 [0-8] ) ) ) )'
```

Pattern:

```
'( ([^: ] + ) {6} ( ([^: ] + : [^: ] + ) | ( . * \. . * ) ) ) |'
```



```
' ((([^:]+:)*[^:]+)? :: ((([^:]+:)*[^:]+)?) '
' (/ .+)
```

The `ipv6-address-and-prefix-length` type represents a combination of an IPv6 address and a prefix length. The prefix length is given by the number following the slash character and must be less than or equal to 128.

ipv6-address-no-zone

Pattern:

```
' [0-9a-fA-F:\.]* '
```

An IPv6 address without a zone index. This type, derived from `ipv6-address`, may be used in situations where the zone is known from the context and hence no zone index is needed.

Reference:

- RFC 4291: IP Version 6 Addressing Architecture
- RFC 4007: IPv6 Scoped Address Architecture
- RFC 5952: A Recommendation for IPv6 Address Text Representation

ipv6-prefix

Pattern:

```
' ((:| [0-9a-fA-F] {0,4}) : ) ( [0-9a-fA-F] {0,4} : ) {0,5} '
' ((( [0-9a-fA-F] {0,4} : ) ? ( : | [0-9a-fA-F] {0,4} ) ) | '
' (( (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) \. ) {3} ' Pattern:
' (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) ) ) '
' ( / ( ( [0-9] ) | ( [0-9] {2} ) | ( 1 [0-1] [0-9] ) | ( 12 [0-8] ) ) ) ' ;
```

Pattern:

```
' (( [^:]+: ) {6} ( ( [^:]+: [^:]+ ) | ( .* \. .* ) ) ) | '
' ((( [^:]+: ) * [^:]+ ) ? :: ( ( [^:]+: ) * [^:]+ ) ? ) '
' (/ .+)
```

The `ipv6-prefix` type represents an IPv6 address prefix. The prefix length is given by the number following the slash character and must be less than or equal to 128.

A prefix length value of *n* corresponds to an IP address mask that has *n* contiguous 1-bits from the most significant bit (MSB) and all other bits set to 0.

The IPv6 address should have all bits that do not belong to the prefix set to zero. The canonical format of an IPv6 prefix has all bits of the IPv6 address set to zero that are not part of the IPv6 prefix. Furthermore, the IPv6 address is represented as defined in Section 4 of RFC 5952

Reference:

- RFC 5952: A Recommendation for IPv6 Address Text Representation

mac-address

Pattern:

```
' [0-9a-fA-F] {2} ( : [0-9a-fA-F] {2} ) {5} '
```

The mac-address type represents an IEEE 802 MAC address. The canonical representation uses lowercase characters. In the value set and its semantics, this type is equivalent to the MacAddress textual convention of the SMIV2.

Reference:

- IEEE 802: IEEE Standard for Local and Metropolitan Area Networks: Overview and Architecture
- RFC 2579: Textual Conventions for SMIV2

object-identifier

Pattern:

```
' ( ([0-1] (\ . [1-3]? [0-9])) | (2 \ . (0 | ([1-9] \d*))) ) '
' (\ . (0 | ([1-9] \d*))) * '
```

The object-identifier type represents administratively assigned names in a registration-hierarchical-name tree. The values of this type are denoted as a sequence of numerical non-negative sub-identifier values. Each sub-identifier value MUST NOT exceed $2^{32}-1$ (4294967295). The Sub-identifiers are separated by single dots and without any intermediate whitespace.

The ASN.1 standard restricts the value space of the first sub-identifier to 0, 1, or 2. Furthermore, the value space of the second sub-identifier is restricted to the range 0 to 39 if the first sub-identifier is 0 or 1. Finally, the ASN.1 standard requires that an object identifier has always at least two sub-identifiers. The pattern captures these restrictions.

Although the number of sub-identifiers is not limited, module designers should realize that there may be implementations that stick with the SMIV2 limit of 128 sub-identifiers.

This type is a superset of the SMIV2 OBJECT IDENTIFIER type since it is not restricted to 128 sub-identifiers. Hence, this type SHOULD NOT be used to represent the SMIV2 OBJECT IDENTIFIER type; the object-identifier-128 type SHOULD be used instead.

Reference:

- ISO9834-1: Information technology - Open Systems
- Interconnection - Procedures for the operation of OSI
- Registration Authorities: General procedures and top arcs of the ASN.1 Object Identifier tree

object-identifier-128

Pattern:

```
' \d* (\ . \d* ) {1,127} '
```

This type represents object-identifiers restricted to 128 sub-identifiers. In the value set and its semantics, this type is equivalent to the OBJECT IDENTIFIER type of the SMIV2.

Reference:

- RFC 2578: Structure of Management Information Version 2 (SMIV2)

octet-list

Pattern:

```
'(\d*(.\d*)*)?'
```

A list of dot-separated octets, for example '192.168.255.1.0'. The statement tailf:value-length can be used to restrict the number of octets. Using the 'length' restriction limits the number of characters in the lexical representation.

phys-address

Pattern:

```
'([0-9a-fA-F]{2}(:[0-9a-fA-F]{2})*)?'
```

Represents media- or physical-level addresses represented as a sequence octets, each octet represented by two hexadecimal numbers. Octets are separated by colons. The canonical representation uses lowercase characters. In the value set and its semantics, this type is equivalent to the PhysAddress textual convention of the SMIV2.

Reference:

- RFC 2579: Textual Conventions for SMIV2

sha-256-digest-string

Pattern:

```
'$0$.*'
'|$5$(rounds=\d+)$?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{43}'
```

The sha-256-digest-string type automatically computes a SHA-256 digest for a value adhering to this type. A value of this type matches one of the forms:

- \$0\$<clear text password>
- \$5\$<salt>\$<password hash>
- \$5\$rounds=<number>\$<salt>\$<password hash>

The '\$0\$' prefix signals that this is plain text. When a plain text value is received by the server, a SHA-256 digest is calculated, and the string '\$5\$<salt>\$' is prepended to the

result, where <salt> is a random 16 character salt used to generate the digest. This value is stored in the configuration data store. The algorithm can be tuned through the /confdConfig/cryptHash/rounds parameter, which if set to a number other than the default will cause '\$5\$rounds=<number>\$<salt>\$' to be prepended instead of only '\$5\$<salt>\$'.

If a value starting with '\$5\$' is received, the server knows that the value already represents a SHA-256 digest, and stores it as is in the data store.

If a default value is specified, it must have a '\$5\$' prefix.

The digest algorithm used is the same as the SHA-256 crypt function used for encrypting passwords for various UNIX systems.

Reference:

- IEEE Std 1003.1-2008 - crypt() function FIPS.180-3.2008: Secure Hash Standard

sha-512-digest-string

Pattern:

```
'$0$.*'
'|$6$(rounds=\d+$)?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{86}'
```

The sha-512-digest-string type automatically computes a SHA-512 digest for a value adhering to this type. A value of this type matches one of the forms

- \$0\$<clear text password>
- \$6\$<salt>\$<password hash>
- \$6\$rounds=<number>\$<salt>\$<password hash>

The '\$0\$' prefix signals that this is plain text. When a plain text value is received by the server, a SHA-512 digest is calculated, and the string '\$6\$<salt>\$' is prepended to the

result, where <salt> is a random 16 character salt used to generate the digest. This value is stored in the configuration data store. The algorithm can be tuned through the

/confdConfig/cryptHash/rounds parameter, which if set to a number other than the default will cause '\$6\$rounds=<number>\$<salt>\$' to be prepended instead of only '\$6\$<salt>\$'.

If a value starting with '\$6\$' is received, the server knows that the value already represents a SHA-512 digest, and stores it as is in the data store.

If a default value is specified, it must have a '\$6\$' prefix. The digest algorithm used is the same as the SHA-512 crypt function used for encrypting passwords for various UNIX systems.

Reference:

- IEEE Std 1003.1-2008 - crypt() function FIPS.180-3.2008: Secure Hash Standard

size

Pattern:

```
'S(\d+G)?(\d+M)?(\d+K)?(\d+B)?'
```

A value that represents a number of bytes. An example could be S1G8M7K956B; meaning 1GB + 8MB + 7KB + 956B = 1082138556 bytes.

The value must start with an S. Any byte magnifier can be left out, for example, S1K1B equals 1025 bytes. The order is significant though, that is S1B56G is not a valid byte size.

In ConfD, a 'size' value is represented as an uint64.

uuid

Pattern:

```
'[0-9a-fA-F]{8}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-'
'[0-9a-fA-F]{4}-[0-9a-fA-F]{12}'
```

A Universally Unique IDentifier in the string representation defined in RFC 4122. The canonical representation uses lowercase characters. The following is an example of a UUID in string representation: f81d4fae-7dec-11d0-a765-00a0c91e6bf6.

Reference:

- RFC 4122: A Universally Unique Identifier (UUID) URN Namespace

yang-identifier

Pattern:

```
'[a-zA-Z_][a-zA-Z0-9\-\_\.]*'
```

Pattern:

```
'\.\.\. | [^xX] .* | [^mM] .* | \.\.\. [^1L] .*'
```

A YANG identifier string as defined by the 'identifier' rule in Section 12 of RFC 6020. An identifier must start with an alphabetic character or an underscore followed by an arbitrary sequence of alphabetic or numeric characters, underscores, hyphens, or dots. A YANG identifier MUST NOT start with any possible combination of the lowercase or uppercase character sequence 'xml'.

Reference:

- RFC 6020: YANG - A Data Modeling Language for the Network Configuration Protocol (NETCONF)

