



cnBNG CP Commands

This guide describes the CLI commands that are used to configure a control plane in cnBNG.

Some keywords and commands are common across multiple commands and configuration modes respectively. Use the information in the Command Modes section only as a reference to navigate to the command in the applicable configuration modes.

- [aaa, on page 8](#)
- [cd, on page 9](#)
- [cdl clear, on page 9](#)
- [cdl show sessions, on page 10](#)
- [cdl show status, on page 11](#)
- [clear l2tp-tunnel, on page 11](#)
- [clear subscriber, on page 12](#)
- [clear subscriber, on page 14](#)
- [client http header, on page 15](#)
- [client http ping, on page 15](#)
- [client inbound interface, on page 16](#)
- [client inbound interface limit overload, on page 16](#)
- [client inbound interface limit pending, on page 17](#)
- [client inbound limit overload, on page 17](#)
- [client inbound limit pending, on page 17](#)
- [client outbound host ping, on page 18](#)
- [client outbound interface, on page 18](#)
- [client outbound interface host ping, on page 19](#)
- [client outbound interface limit consecutive failure, on page 19](#)
- [client outbound interface limit pending, on page 20](#)
- [client outbound limit consecutive failure, on page 20](#)
- [client outbound limit pending, on page 21](#)
- [commit, on page 21](#)
- [compare, on page 22](#)
- [config, on page 22](#)
- [datastore dbs, on page 23](#)
- [datastore dbs endpoints, on page 23](#)
- [datastore notification-ep, on page 23](#)
- [datastore session-db, on page 24](#)

- [datastore session-db endpoints, on page 24](#)
- [deployment, on page 25](#)
- [deployment resource, on page 25](#)
- [describe, on page 26](#)
- [dump transactionhistory, on page 27](#)
- [edr, on page 27](#)
- [edr edrsubscribers, on page 28](#)
- [edr file files, on page 28](#)
- [edr file files disable, on page 29](#)
- [edr file files flush, on page 29](#)
- [edr file files limit, on page 30](#)
- [edr file files procedure-id disable-event-id, on page 30](#)
- [edr file files procedure-id disable-event-id disable-inner disable, on page 30](#)
- [edr file files procedure-id disable-event-id disable-inner event-id disable-field-id, on page 31](#)
- [edr file files procedure-id disable-event-id disable-inner event-id disable-field-id disable, on page 31](#)
- [exit, on page 32](#)
- [geo maintenance, on page 32](#)
- [geo reset-role, on page 32](#)
- [geo switch-role, on page 33](#)
- [geomonitor podmonitor pods, on page 33](#)
- [geomonitor remoteclustermonitor, on page 34](#)
- [geomonitor trafficMonitor, on page 34](#)
- [geomonitor vipmonitor, on page 35](#)
- [geomonitor vipmonitor instance, on page 35](#)
- [geomonitor vipmonitor instance vips, on page 35](#)
- [helm, on page 36](#)
- [helm charts, on page 37](#)
- [helm repository, on page 37](#)
- [help, on page 38](#)
- [history, on page 39](#)
- [id, on page 39](#)
- [idle-timeout, on page 40](#)
- [ignore-leading-space, on page 40](#)
- [infra metrics experimental, on page 40](#)
- [infra metrics verbose verboseLevels, on page 41](#)
- [infra metrics verbose verboseLevels metrics metricsList, on page 41](#)
- [infra transaction limit, on page 42](#)
- [infra transaction limit consecutive same, on page 42](#)
- [infra transaction loop, on page 43](#)
- [infra transaction loop category, on page 43](#)
- [infra transaction loop category threshold, on page 44](#)
- [infra transaction loop category threshold thresholds, on page 44](#)
- [instance instance-id, on page 45](#)
- [instance instance-id endpoint ep, on page 45](#)
- [instance instance-id endpoint ep cpu, on page 46](#)
- [instance instance-id endpoint ep interface, on page 47](#)

- instance instance-id endpoint ep interface dispatcher, on page 48
- instance instance-id endpoint ep interface internal base-port, on page 50
- instance instance-id endpoint ep interface sla, on page 50
- instance instance-id endpoint ep interface vip, on page 50
- instance instance-id endpoint ep interface vip6, on page 51
- instance instance-id endpoint ep memory, on page 52
- instance instance-id endpoint ep retransmission, on page 52
- instance instance-id endpoint ep service, on page 53
- instance instance-id endpoint ep service interface, on page 53
- instance instance-id endpoint ep service interface dispatcher, on page 54
- instance instance-id endpoint ep service interface internal base-port, on page 56
- instance instance-id endpoint ep service interface overload-control client threshold critical, on page 56
- instance instance-id endpoint ep service interface overload-control client threshold high, on page 57
- instance instance-id endpoint ep service interface overload-control client threshold low, on page 57
- instance instance-id endpoint ep service interface overload-control endpoint threshold critical, on page 58
- instance instance-id endpoint ep service interface overload-control endpoint threshold high, on page 58
- instance instance-id endpoint ep service interface overload-control endpoint threshold low, on page 59
- instance instance-id endpoint ep service interface overload-control msg-type messageConfigs, on page 59
- instance instance-id endpoint ep service interface sla, on page 60
- instance instance-id endpoint ep service interface vip, on page 61
- instance instance-id endpoint ep service interface vip6, on page 61
- instance instance-id endpoint ep system-health-level crash, on page 62
- instance instance-id endpoint ep system-health-level critical, on page 62
- instance instance-id endpoint ep system-health-level warn, on page 63
- instance instance-id endpoint ep vip, on page 64
- instance instance-id endpoint ep vip6, on page 64
- instances instance, on page 65
- ipam instance, on page 65
- ipam instance address-pool, on page 66
- ipam instance address-pool ipv4 address-range, on page 67
- ipam instance address-pool ipv4 prefix-range, on page 67
- ipam instance address-pool ipv4 split-size, on page 68
- ipam instance address-pool ipv4 threshold, on page 69
- ipam instance address-pool ipv6 address-ranges address-range, on page 69
- ipam instance address-pool ipv6 address-ranges prefix-range, on page 70
- ipam instance address-pool ipv6 address-ranges split-size, on page 70
- ipam instance address-pool ipv6 address-ranges threshold, on page 71
- ipam instance address-pool ipv6 prefix-ranges prefix-range, on page 72
- ipam instance address-pool ipv6 prefix-ranges split-size, on page 72
- ipam instance address-pool ipv6 prefix-ranges threshold, on page 73
- ipam instance address-pool static, on page 73
- ipam instance min-dp-addr-size, on page 74
- ipam instance source, on page 74
- ipam instance source external ipam, on page 75

- ipam instance threshold, on page 75
- ipam show dp, on page 76
- ipam show dp-tag, on page 76
- ipam show ipam pool, on page 77
- job, on page 77
- k8 bng, on page 77
- k8 bng tracing, on page 78
- k8 label pod-group-config, on page 79
- kubernetes, on page 80
- kubernetes nodes, on page 81
- leaf-prompting, on page 81
- license smart deregister, on page 82
- license smart register, on page 82
- license smart renew, on page 82
- local-instance, on page 83
- logging async application enable, on page 83
- logging async monitor-subscriber enable, on page 84
- logging async tracing enable, on page 84
- logging async transaction enable, on page 85
- logging error, on page 85
- logging level, on page 85
- logging logger, on page 87
- logging logger level, on page 87
- logging transaction, on page 89
- logout, on page 90
- monitor protocol, on page 90
- monitor subscriber, on page 91
- nf-tls ca-certificates, on page 91
- nf-tls certificate-status, on page 92
- nf-tls certificates, on page 92
- no, on page 92
- paginate, on page 93
- profile aaa, on page 93
- profile aaa accounting, on page 93
- profile aaa authentication, on page 94
- profile aaa authorization, on page 94
- profile aaa authorization type subscriber, on page 95
- profile aaa authorization username, on page 95
- profile attribute-format, on page 97
- profile coa, on page 98
- profile coa client, on page 99
- profile dhcp, on page 99
- profile dhcp ipv4, on page 99
- profile dhcp ipv4 class, on page 100
- profile dhcp ipv4 class matches, on page 100
- profile dhcp ipv4 class matches match, on page 101

- profile dhcp ipv4 class server, on page 101
- profile dhcp ipv4 class server hold-time, on page 103
- profile dhcp ipv4 class server lease, on page 103
- profile dhcp ipv4 class server netbios-node-type, on page 104
- profile dhcp ipv4 class server option-codes, on page 104
- profile dhcp ipv4 class server option-codes option-code, on page 105
- profile dhcp ipv4 class server static-ip-key, on page 106
- profile dhcp ipv4 server, on page 106
- profile dhcp ipv4 server hold-time, on page 107
- profile dhcp ipv4 server lease, on page 108
- profile dhcp ipv4 server netbios-node-type, on page 108
- profile dhcp ipv4 server option-codes, on page 109
- profile dhcp ipv4 server option-codes option-code, on page 109
- profile dhcp ipv4 server static-ip-key, on page 110
- profile dhcp ipv6, on page 111
- profile dhcp ipv6 class, on page 111
- profile dhcp ipv6 class server, on page 112
- profile dhcp ipv6 class server hold-time, on page 113
- profile dhcp ipv6 class server lease, on page 113
- profile dhcp ipv6 class server static-ip-key, on page 114
- profile dhcp ipv6 server, on page 114
- profile dhcp ipv6 server hold-time, on page 115
- profile dhcp ipv6 server lease, on page 115
- profile dhcp ipv6 server static-ip-key, on page 116
- profile feature-template, on page 116
- profile feature-template ipv4, on page 117
- profile feature-template ipv4 verify-unicast-source, on page 118
- profile feature-template ipv6, on page 118
- profile feature-template ipv6 verify-unicast-source, on page 119
- profile feature-template ppp, on page 119
- profile feature-template ppp chap, on page 120
- profile feature-template ppp ipcp, on page 120
- profile feature-template ppp ipcp dns, on page 121
- profile feature-template ppp ipcp renegotiation, on page 121
- profile feature-template ppp ipcp wins, on page 121
- profile feature-template ppp ipv6cp renegotiation, on page 122
- profile feature-template ppp keepalive, on page 122
- profile feature-template ppp lcp delay, on page 123
- profile feature-template ppp lcp renegotiation, on page 123
- profile feature-template ppp pap, on page 124
- profile feature-template ppp timeout, on page 124
- profile feature-template ppp timeout absolute, on page 124
- profile feature-template qos, on page 125
- profile feature-template service-accounting, on page 125
- profile feature-template session-accounting, on page 126
- profile l2tp, on page 127

- profile l2tp domain, on page 129
- profile l2tp ip-tos, on page 129
- profile l2tp ipv4, on page 130
- profile l2tp ipv4 destination, on page 130
- profile l2tp retransmit initial, on page 131
- profile l2tp retransmit initial timeout, on page 131
- profile l2tp retransmit timeout, on page 131
- profile l2tp tcp, on page 132
- profile l2tp terminate-from, on page 132
- profile l2tp tunnel, on page 133
- profile l2tp tunnel timeout, on page 133
- profile pppoe, on page 133
- profile pppoe max-payload, on page 135
- profile pppoe session-limit circuit-id, on page 135
- profile pppoe session-limit mac, on page 136
- profile pppoe session-limit max, on page 136
- profile pppoe session-limit outer-vlan, on page 136
- profile radius, on page 137
- profile radius accounting, on page 138
- profile radius accounting attribute, on page 138
- profile radius accounting attribute called-station-id, on page 139
- profile radius accounting attribute called-station-id format, on page 139
- profile radius accounting attribute calling-station-id, on page 140
- profile radius accounting attribute calling-station-id format, on page 140
- profile radius accounting attribute nas-identifier-format, on page 141
- profile radius accounting attribute nas-identifier-format format, on page 141
- profile radius accounting attribute nas-port, on page 142
- profile radius accounting attribute nas-port format-e-list, on page 142
- profile radius accounting attribute nas-port-id, on page 143
- profile radius accounting attribute nas-port-id format, on page 143
- profile radius accounting detect-dead-server, on page 144
- profile radius attribute, on page 144
- profile radius attribute called-station-id, on page 144
- profile radius attribute called-station-id format, on page 145
- profile radius attribute calling-station-id, on page 145
- profile radius attribute calling-station-id format, on page 146
- profile radius attribute nas-identifier-format, on page 146
- profile radius attribute nas-identifier-format format, on page 147
- profile radius attribute nas-port, on page 147
- profile radius attribute nas-port format-e-list, on page 148
- profile radius attribute nas-port-id, on page 148
- profile radius attribute nas-port-id format, on page 149
- profile radius detect-dead-server, on page 149
- profile radius server, on page 149
- profile radius server-group, on page 150
- profile radius server-group server, on page 151

- profile server-group, on page 151
- profile subscriber, on page 152
- profile subscriber aaa, on page 153
- profile subscriber class, on page 153
- profile subscriber class aaa, on page 154
- profile subscriber class matches, on page 154
- profile subscriber class matches match, on page 155
- profile subscriber event, on page 156
- profile subscriber event aaa, on page 157
- profile subscriber event class, on page 157
- profile subscriber event class aaa, on page 158
- profile subscriber event class matches, on page 158
- profile subscriber event class matches match, on page 159
- quit, on page 160
- rcm switchover, on page 160
- reconcile ipam, on page 161
- resource pod, on page 161
- resource pod cpu, on page 161
- resource pod labels, on page 162
- resource pod memory, on page 162
- router bfd instance instance-id, on page 163
- router bfd instance instance-id interface-list, on page 163
- router bfd instance instance-id interface-list neighbors, on page 163
- router bgplist, on page 164
- router bgplist bfd, on page 165
- router bgplist interfaceList, on page 165
- router bgplist interfaceList bondingInterfaces, on page 166
- router bgplist interfaceList neighbors, on page 166
- router bgplist policies, on page 167
- router monitor-interface interface-list, on page 168
- screen-length, on page 168
- screen-width, on page 169
- send, on page 169
- show, on page 169
- show bfd-neighbor, on page 170
- show bgp-global, on page 170
- show bgp-kernel-route, on page 170
- show bgp-neighbors, on page 171
- show bgp-route-summary, on page 171
- show bgp-routes, on page 171
- show config-error info, on page 172
- show diagnostics info, on page 172
- show edr, on page 172
- show endpoint all, on page 172
- show endpoint info, on page 173
- show geo-maintenance-mode, on page 173

- [show georeplication](#), on page 173
- [show l2tp-tunnel](#), on page 174
- [show l2tp-tunnel filter](#), on page 174
- [show local-interface-status](#), on page 175
- [show peers all](#), on page 175
- [show radius](#), on page 176
- [show radius acct-server](#), on page 176
- [show radius auth-server](#), on page 176
- [show radius-dyn-auth](#), on page 176
- [show radius-dyn-auth clients](#), on page 177
- [show resources info](#), on page 177
- [show role](#), on page 177
- [show rpc all](#), on page 177
- [show running-status info](#), on page 178
- [show sessions](#), on page 178
- [show sessions affinity](#), on page 178
- [show sessions commit-pending](#), on page 178
- [show subscriber](#), on page 179
- [show subscriber](#), on page 179
- [show subscriber filter](#), on page 180
- [show subscriber opts](#), on page 184
- [show subscriber synchronize](#), on page 185
- [show test-radius accounting](#), on page 185
- [show test-radius authentication](#), on page 186
- [show-defaults](#), on page 188
- [smiuser](#), on page 188
- [subscriber](#), on page 189
- [subscriber route-synchronize](#), on page 190
- [subscriber session-synchronize](#), on page 190
- [subscriber session-synchronize-cp](#), on page 191
- [system](#), on page 191
- [terminal](#), on page 192
- [timestamp](#), on page 192
- [user-plane](#), on page 193
- [user-plane peer-address](#), on page 193
- [user-plane port-id](#), on page 193
- [who](#), on page 194

aaa

Configures AAA-based user management parameters.

Command Modes	Exec
---------------	------

Syntax Description

```
aaa { authentication { users list_of_local_users admin change-password
old-password user_password new-password user_password confirm-password
user_password } }
```

users list_of_local_users

Specify the user name.

Must be a string.

old-password user_password

Specify the user's current password.

Must be a string.

new-password user_password

Specify the user's new password.

Must be a string.

confirm-password user_password

Reenter the user's new password.

Must be a string.

Usage Guidelines

Use this command to configure the AAA based user management parameters.

cd

Configures the change directory command.

Command Modes

Exec

Syntax Description

```
cd directory.ssh
```

directory

Specify the directory path.

Must be an alphanumeric string.

Usage Guidelines

Use this command to configure the change directory command.

cdl clear

Configures the Cisco Common Data Layer (CDL) parameters to delete the database sessions.

Command Modes

Exec

cdl show sessions**Syntax Description**

```
cdl clear sessions [ db-name db_name | filter { condition { ends-with |
match | starts-with } key key_value } | map-id map_id ]
```

db-name db_name

Specifies the database name to be queried for deleting the data.

Must be a string of 1 to 16 characters.

key key_value

Specifies the query value.

Must be a string of 0 to 512 characters.

map-id map_id

Specifies the map ID to delete the data for a map.

Must be an integer in the range of 0-1024.

filter condition { ends-with | match | starts-with }

Specify the query expression to filter the results of query.

Usage Guidelines

Use this command to delete the CDL database sessions.

cdl show sessions

Configures the CDL parameters to display the session details.

Command Modes

Exec

Syntax Description

```
cdl show sessions count { detailed { db-name db_name | filter { condition
{ ends-with | match | starts-with } | key key_value } | limit limit | map-id
map_id } | summary { db-name db_name | filter { condition { ends-with |
match | starts-with } | key key_value } | limit limit | map-id map_id } }
```

count

Display the session count information.

detailed

Display the session details with data.

summary

Display the session details without data.

db-name db_name

Specifies the database name to be queried for displaying the session details.

Must be a string of 1 to 16 characters.

key *key_value*

Specifies the query value.

Must be a string of 0 to 512 characters.

map-id *map_id*

Specifies the map ID to display the data for a map.

Must be an integer in the range of 0-1024.

limit *limit*

Specifies the maximum number of records to display.

Must be an integer in the range of 1 to 500 characters.

filter condition { ends-with | match | starts-with }

Specify the query expression to filter the results of query.

Usage Guidelines

Use this command to display the session details.

cdl show status

Configures the CDL parameters to display the status of the database.

Command Modes

Exec

Syntax Description

cdl status db-name *db_name*

db-name *db_name*

Specifies the database name for displaying the corresponding status.

Must be a string of 1 to 16 characters.

Usage Guidelines

Use this command to display the status of the queried database.

clear l2tp-tunnel

Clears l2tp tunnel.

Command Modes

Exec

Syntax Description

clear l2tp tunnel { upf *upf_name* } [tunnel-type *tunnel_type* | tunnel-id *tunnel_id* | force]

clear subscriber**force**

Specify to force tunnel deletion, even if UP is down.

tunnel-id *tunnel_id*

Specify the tunnel ID.

Must be an integer in the range of 1-65535.

tunnel-type *tunnel_type*

Specify the tunnel type.

Must be one of the following:

- lac
- lns

upf *upf_name*

Specify name of the User Plane Function.

Must be a string of 1-64 characters.

Usage Guidelines

Use this command to clear l2tp tunnel.

clear subscriber

Clears BNG subscriber data.

Command Modes

Exec

Syntax Description

```
clear subscriber type [ upf upf_name | port-id upf_port_id | mac mac_address |
sublabel subscriber_label | up-subs-id up_subscriber_id | ipv4-pool ipv4_pool_name
| ipv6-addr-pool ipv6_address_pool_name | ipv6-pfx-pool ipv6_prefix_pool_name |
ipv4-range ipv4_address_range | ipv6-addr-range ipv6_address_range | ipv6-pfx-range
ipv6_prefix_range | ppp-type ppp_session_type | session-id session_id | tunnel-id
tunnel_id ]
```

force

Specify to force session deletion, even if UP is down.

ipv4-pool *ipv4_pool_name*

Specify name of the IPv4 address pool.

Must be a string of 1-64 characters.

ipv4-range *ipv4_address_range*

Specify the IPv4 address range in the format "poolName/start-ip".

Must be a string of 1-64 characters.

ipv6-addr-pool ipv6_address_pool_name

Specify name of the IPv6 address pool.

Must be a string of 1-64 characters.

ipv6-addr-range ipv6_address_range

Specify the IPv6 address range in the format "poolName/start-ip".

Must be a string of 1-64 characters.

ipv6-pfx-pool ipv6_prefix_pool_name

Specify name of the IPv6 prefix pool.

Must be a string of 1-64 characters.

ipv6-pfx-range ipv6_prefix_range

Specify the IPv6 prefix range in the format "poolName/start-pfx".

Must be a string of 1-64 characters.

mac mac_address

Specify the MAC address in the format "aabb.ccc.d.eeff".

Must be a string of 1-64 characters.

port-id upf_port_id

Specify port ID of the user plane function in the "upf/port-id" format.

Must be a string of 1-64 characters.

ppp-type ppp_session_type

Specify the PPP session type.

Must be one of the following:

- lac
- pta

session-id session_id

Specify the session ID information.

Must be a string of 1-64 characters.

sublabel subscriber_label

Specify the subscriber label.

clear subscriber

Must be a string of 1-64 characters.

tunnel-id *tunnel_id*

Specify the tunnel ID information.

Must be a string of 1-64 characters.

upf *upf_name*

Specify name of the user plane function.

Must be a string of 1-64 characters.

type

Specify the type.

Must be one of the following:

- **dhcp**
- **lns**
- **pppoe**
- **sessmgr**

Usage Guidelines

Use this command to clear BNG subscriber data.

clear subscriber

Clears subscriber data.

Command Modes

Exec

Syntax Description

```
clear subscriber { all | gr-instance gr_instance | imei imei_id | namespace
namespace | nf-service nf_service | supi supi_id | config_specific_options }
```

all

Specify to remove all subscriber data.

gr-instance *gr_instance*

Specify the subscribers from the GR instance.

imei *imei_id*

Specify the International Mobile Equipment Identity.

Must be a string of 15-16 characters.

namespace *namespace*

NOTE: This keyword is deprecated, use nf-service instead. Specifies the product namespace under which to search.

Default Value: cisco-mobile-infra:none.

nf-service *nf_service*

Specify the network function service under which to search.

Default Value: cisco-mobile-infra:none.

supi *supi_id*

Specify to remove subscriber data associated with the SUPI ID.

Must be a string of 1-63 characters.

Usage Guidelines	Use this command to clear subscriber data.
-------------------------	--

client http header

Configures HTTP header parameters.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	client http header user-agent <i>user_agent_header</i>
---------------------------	---

user-agent *user_agent_header*

Specify the user agent header.

Must be one of the following:

- **app-name**
- **cluster-name**
- **disable**

Default Value: app-name.

Usage Guidelines	Use this command to configure HTTP header parameters.
-------------------------	---

client http ping

Configures HTTP ping parameters.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	client http ping { [interval <i>ping_interval</i>] [timeout <i>ping_timeout</i>] }
---------------------------	---

client inbound interface**interval ping_interval**

Specify, in milliseconds, the time interval between two HTTP pings.

Must be an integer in the range of 0-30000.

Default Value: 10000.

timeout ping_timeout

Specify, in milliseconds, the ping timeout duration to detect if remote host is down.

Must be an integer in the range of 0-15000.

Default Value: 5000.

Usage Guidelines	Use this command to configure HTTP ping parameters.
-------------------------	---

client inbound interface

Configures inbound client interface parameters.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	client inbound interface <i>interface_name</i>
---------------------------	---

interface interface_name

Specify name of the interface. Must be one of the following: bfd, bgp, coa-nas, geo-external, geo-internal, gtpu, n4.

Usage Guidelines	Use this command to configure inbound client interface parameters. The CLI prompt changes to the Interface Configuration mode (config-interface-<interface_name>).
-------------------------	--

client inbound interface limit overload

Configures Overload configuration parameters.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	client inbound limit overload reject-code <i>response_code</i>
---------------------------	---

reject-code response_code

Specify the response code to be used when pending limit exceeds.

Must be an integer.

Usage Guidelines	Use this command to configure Overload configuration parameters.
-------------------------	--

client inbound interface limit pending

Configures pending request limit parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound limit pending request max_pending_request_limit`

request *max_pending_request_limit*

Specify the maximum pending request limit to allow.

Must be an integer.

Default Value: 10240.

Usage Guidelines Use this command to configure the pending request limit parameter.

client inbound limit overload

Configures Overload configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound limit overload reject-code response_code`

reject-code *response_code*

Specify the response code to be used when pending limit exceeds.

Must be an integer.

Usage Guidelines Use this command to configure Overload configuration parameters.

client inbound limit pending

Configures pending request limit parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description `client inbound limit pending request max_pending_request_limit`

request *max_pending_request_limit*

Specify the maximum pending request limit to allow.

Must be an integer.

Default Value: 10240.

client outbound host ping

Usage Guidelines Use this command to configure the pending request limit parameter.

client outbound host ping

Configures outbound host ping parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description `client outbound host ping { [backoff backoff_interval] [interval ping_interval] [timeout ping_timeout] }`

backoff *backoff_interval*

Specify, in milliseconds, the backoff time interval to wait when remote host is detected down before pinging again.

Must be an integer in the range of 0-3600000.

Default Value: 0.

interval *ping_interval*

Specify, in milliseconds, the time interval between two pings.

Must be an integer in the range of 0-30000.

Default Value: 0.

timeout *ping_timeout*

Specify the ping timeout duration, in milliseconds, to detect remote host down.

Must be an integer in the range of 0-15000.

Default Value: 0.

Usage Guidelines Use this command to configure outbound host ping parameter.

client outbound interface

Configures outbound client interface parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `client outbound interface interface_name`

interface *interface_name*

Specify the interface.

Usage Guidelines Use this command to configure outbound client interface parameters. The CLI prompt changes to the Interface Configuration mode (config-interface-<interface_name>).

client outbound interface host ping

Configures outbound host ping parameter.

Command Modes Exec > Global Configuration (config)

Syntax Description `client outbound host ping { [backoff backoff_interval] [interval ping_interval] [timeout ping_timeout] }`

backoff *backoff_interval*

Specify, in milliseconds, the backoff time interval to wait when remote host is detected down before pinging again.

Must be an integer in the range of 0-3600000.

Default Value: 0.

interval *ping_interval*

Specify, in milliseconds, the time interval between two pings.

Must be an integer in the range of 0-30000.

Default Value: 0.

timeout *ping_timeout*

Specify the ping timeout duration, in milliseconds, to detect remote host down.

Must be an integer in the range of 0-15000.

Default Value: 0.

Usage Guidelines Use this command to configure outbound host ping parameter.

client outbound interface limit consecutive failure

Configures consecutive failure configuration parameters.

Command Modes Exec > Global Configuration

Syntax Description `consecutive failure count failure_limit_count codes failure_codes`

codes *failure_codes*

Specify the list of failure codes to be considered, such as timeout, 503, etc.

Must be a string.

You can configure a maximum of 10 elements with this keyword.

client outbound interface limit pending**count consecutive_failure_count**

Specify the consecutive failure limit count to detect remote host as down.

Must be an integer.

Default Value: 0.

Usage Guidelines Use this command to configure consecutive failure configuration parameters.

client outbound interface limit pending

Configures pending limit configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description **client outbound limit pending response response_message_limit**

Command Modes Exec > Global Configuration (config) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **pending response response_message_limit**

response response_message_limit

Specify the pending response message limit to detect remote host as down.

Must be an integer.

Default Value: 1024.

Usage Guidelines Use this command to configure pending limit configuration.

client outbound limit consecutive failure

Configures consecutive failure configuration parameters.

Command Modes Exec > Global Configuration

Syntax Description **consecutive failure count failure_limit_count codes failure_codes**

codes failure_codes

Specify the list of failure codes to be considered, such as timeout, 503, etc.

Must be a string.

You can configure a maximum of 10 elements with this keyword.

count consecutive_failure_count

Specify the consecutive failure limit count to detect remote host as down.

Must be an integer.

Default Value: 0.

Usage Guidelines	Use this command to configure consecutive failure configuration parameters.
-------------------------	---

client outbound limit pending

Configures pending limit configuration.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	client outbound limit pending response response_message_limit
---------------------------	--

Command Modes	Exec > Global Configuration (config) > Interface Configuration (config-interface- <i>interface_name</i>)
----------------------	---

Syntax Description	pending response response_message_limit
---------------------------	--

response response_message_limit

Specify the pending response message limit to detect remote host as down.

Must be an integer.

Default Value: 1024.

Usage Guidelines	Use this command to configure pending limit configuration.
-------------------------	--

commit

Configures the commit parameters.

Command Modes	Exec
----------------------	------

Syntax Description	commit [abort { persist-id persist_id } confirm { persist-id persist_id } persist-id persist_id]
---------------------------	---

abort persist-id persist_id

Specify to abort commit. Specify the persistence ID for the commit operation.

Must be an integer.

confirm persist-id persist_id

Specify to confirm commit. Specify the persistence ID for the commit operation.

Must be an integer.

persist-id persist_id

Specify the persistence ID for the commit operation.

Must be an integer.

compare

Usage Guidelines Use this command to configure the commit parameters.

compare

CCompares the running configuration to another configuration or a file.

Command Modes Exec

Syntax Description **compare** **file** { *filename[.kube | .ssh/] | configuration* }

filename|.kube | .ssh/|

Specify the file name or the directory path of the file to be compared.

Must be a string.

configuration

Specify the desired configuration to be compared against.

Must be a string.

Usage Guidelines Use this command to compare the files.

config

Manipulates the software configuration information.

Command Modes Exec

Syntax Description **config** [**exclusive** | **no-confirm** | **shared** | **terminal**]

exclusive

Specify to enter the exclusive configuration mode.

no-confirm

Specify to apply the command without asking for confirmation.

shared

Specify to enter the shared configuration mode.

terminal

Specify to enter the terminal configuration mode.

Usage Guidelines Use this command to manipulate the software configuration information.

datastore dbs

Configures DBS parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `datastore dbs dbs_name endpoints endpoint_name port port_number`

dbs *dbs_name*

Specify name of the DBS.

Must be a string.

Usage Guidelines Use this command to configure the DBS parameters. The CLI prompt changes to the DBS Configuration mode (config-dbs-<dbs_name>).

datastore dbs endpoints

Configures endpoint parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `datastore session-db endpoints host_name port port_number`

Command Modes Exec > Global Configuration (config) > DBS Configuration (config-dbs-*dbs_name*)

Syntax Description `endpoints endpoint_name port port_number`

endpoints *endpoint_name*

Specify name of the endpoint host.

Must be a string.

port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure endpoint parameters.

datastore notification-ep

Configures notification endpoint parameters.

Command Modes Exec > Global Configuration (config)

datastore session-db

Syntax Description `datastore notification-ep { [host host_name] [port port_number] }`

host *host_name*

Specify name of the host.

Must be a string.

port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure notification endpoint parameters.

datastore session-db

Configures Session DB parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `datastore session-db endpoints endpoint_name port port_number`

Usage Guidelines Use this command to configure Session DB parameters.

datastore session-db endpoints

Configures endpoint parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `datastore session-db endpoints host_name port port_number`

Command Modes Exec > Global Configuration (config) > DBS Configuration (config-dbs-dbs_name)

Syntax Description `endpoints endpoint_name port port_number`

endpoints *endpoint_name*

Specify name of the endpoint host.

Must be a string.

port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure endpoint parameters.

deployment

Configures the product deployment parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description

```
deployment { app-name application_name | cluster-name cluster_name | dc-name
datacenter_name | logical-nf-instance-id logical_nf_instance_id | model
deployment_model }
```

app-name *application_name*

Specify name of the application.

Must be a string.

cluster-name *cluster_name*

Specify name of the cluster.

Must be a string.

dc-name *datacenter_name*

Specify name of the datacenter.

Must be a string.

logical-nf-instance-id *logical_nf_instance_id*

Specify the logical NF instance ID.

Must be an integer.

Default Value: 0.

model *deployment_model*

Specify the deployment model. Default: Large.

Must be one of the following:

- **small**

Usage Guidelines Use this command to configure product deployment parameters.

deployment resource

Configures the deployment CPU resource parameter.

Command Modes Exec > Global Configuration (config) > Deployment Configuration (config-deployment)

describe

Syntax Description **resource cpu** *cpu_size*

cpu *cpu_size*

Specify the CPU size in millicores.

Must be an integer in the range of 2000-1000000.

Default Value: 18000.

Usage Guidelines Use this command to configure the deployment CPU resource parameter.

describe

Displays the command information.

Command Modes Exec

Syntax Description **describe** *command*

command

Specify the command name to display detailed information about the command.

The command must be one of the following:

- aaa
- cd
- cdl
- commit
- compare
- config
- describe
- dump
- exit
- help
- history
- id
- idle-timeout
- ignore-leading-space
- job
- leaf-prompting

- **license**
- **logout**
- **monitor**
- **no**
- **paginate**
- **quit**
- **rem**
- **screen-length**
- **screen-width**
- **send**
- **show**
- **show-defaults**
- **smiuser**
- **system**
- **terminal**
- **timestamp**
- **who**

Usage Guidelines Use this command to display the command specific information.

dump transactionhistory

Creates dump of transaction history.

Command Modes Exec

Syntax Description **dump transactionhistory**

Usage Guidelines Use this command to create dump of transaction history.

edr

Configures EDR reporting parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **edr { [reporting reporting_status] [subscribers subscribers_edr_reporting] }**

edr edrsubscribers**reporting *reporting_status***

Specify to enable or disable EDR reporting.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines	Use this command to configure EDR parameters.
-------------------------	---

edr edrsubscribers

Configures subscriber EDR reporting.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	edr subscribers <i>subscribers_for_edr_reporting</i>
---------------------------	---

Syntax Description	edr reporting { enable disable } subscribers <i>subscribers_for_edr_reporting</i>
---------------------------	--

subscribers *subscribers_for_edr_reporting*

Specify the subscribers to enable EDR reporting. For example, imsi-123456789012345.

Must be a string.

You can configure a maximum of 10 elements with this keyword.

Usage Guidelines	Use this command to configure subscriber EDR reporting.
-------------------------	---

edr file files

Configures EDR file parameters.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	edr file { transaction transaction-collision } [reporting <i>reporting_status</i>] [verbose <i>verbosity_status</i>]
---------------------------	---

file { transaction | transaction-collision }

Specify name of the EDR file.

reporting *reporting_status*

Specify to enable or disable reporting of this file.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

verbose *verbosity_status*

Specify to enable or disable field description or long names in the file.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines

Use this command to configure EDR file parameters.

edr file files disable

Disables procedure IDs.

Command Modes

Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description

disable procedure-id *procedure_ids*

procedure-id *procedure_ids*

Specify the procedure ID value(s)/name(s).

Must be a string.

Usage Guidelines

Use this command to disable specific procedure IDs.

edr file files flush

Configures EDR file flush parameters.

Command Modes

Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description

flush interval *file_flush_interval*

interval *file_flush_interval*

Specify, in milliseconds, the file flush interval.

Must be an integer.

Default Value: 1000.

edr file files limit

Usage Guidelines Use this command to configure the EDR file flush parameters.

edr file files limit

Configures EDR file limit parameters.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description **limit { [count *max_files_to_preserve*] [size *max_single_file_size*] }**

count *max_files_to_preserve*

Specify the maximum number of files to be preserved.

Must be an integer.

Default Value: 10.

size *max_single_file_size*

Specify the maximum single file size limit in MB.

Must be an integer.

Default Value: 100.

Usage Guidelines Use this command to configure the EDR file limit parameters.

edr file files procedure-id disable-event-id

Disables transaction-level procedure ID configuration.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*)

Syntax Description **procedure-id *procedure_id***

procedure *procedure_id*

Specify the procedure ID value/name.

Must be a string.

Usage Guidelines Use this command to disable transaction-level procedure ID configuration.

edr file files procedure-id disable-event-id disable-inner disable

Disables event IDs.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*) > Procedure ID Configuration (config-procedure-id-*procedure_id*)

Syntax Description **disable event-id** *event_ids*

event-id *event_ids*

Specify the event ID value(s)/name(s).

Must be a string.

Usage Guidelines Use this command to disable event IDs.

edr file files procedure-id disable-event-id disable-inner event-id disable-field-id

Disables procedure-level event ID configuration.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*) > Procedure ID Configuration (config-procedure-id-*procedure_id*)

Syntax Description **event-id** *event_id*

event **event-id**

Specify the event ID value/name.

Must be a string.

Usage Guidelines Use this command to disable procedure-level event ID configuration.

edr file files procedure-id disable-event-id disable-inner event-id disable-field-id disable

Disables field IDs.

Command Modes Exec > Global Configuration (config) > EDR File Configuration (config-file-*edr_file*) > Procedure ID Configuration (config-procedure-id-*procedure_id*)

Syntax Description **disable field-id** *field_ids*

field-id *field_ids*

Specify the field ID value(s)/name(s).

Must be a string.

Usage Guidelines Use this command to disable field IDs.

exit

exit

Exits the current configuration mode and returns to the previous configuration mode.

Command Modes Exec

Syntax Description **exit**

Usage Guidelines Use this command to exit the current configuration mode and return to the previous configuration mode. When used in the Exec mode, exits the management session.

geo maintenance

Configures Geo Admin Controller to enable or disable maintenance mode.

Command Modes Exec

Syntax Description **geo maintenance mode { false | true }**

mode { false | true }

Specify whether to enable or disable maintenance mode. To enable, set to true.

Must be one of the following:

- **false**
- **true**

Default Value: false.

Usage Guidelines Use this command to configure Geo Admin Controller to enable or disable maintenance mode.

geo reset-role

Configures Geo Admin Controller for reset role.

Command Modes Exec

Syntax Description **geo reset-role { [instance-id *instance_id*] [role *new_role*] }**

instance-id *instance_id*

Specify the instance ID for geo command.

role *new_role*

Specify the new role for the specified site.

Usage Guidelines Use this command to configure Geo Admin Controller for reset role.

geo switch-role

Configures Geo Admin Controller for trigger failover.

Command Modes Exec

Syntax Description `geo switch-role { [fallback-interval fallback_interval] [instance-id instance_id] [role new_role] }`

fallback-interval *fallback_interval*

Specify, in seconds, the interval between notify failover and actual failover.

Must be a string.

instance-id *instance_id*

Specify the instance ID for geo command.

role *new_role*

Specify the new role for the specified site.

Usage Guidelines Performs instance role manipulation. Use this command to configure Geo Admin Controller for trigger failover.

geomonitor podmonitor pods

Configures configuration of pods to be monitored.

Command Modes Exec > Global Configuration (config)

Syntax Description `geomonitor podmonitor pods pod_name [[failedReplicaPercent failed_replica_precentage] [retryCount retry_count] [retryFailOverInterval retry_interval] [retryInterval retry_interval]]`

failedReplicaPercent *failed_replica_precentage*

Specify the percentage of failed replica after which GR failover will get triggered.

Must be an integer in the range of 10-100.

pods *pod_name*

Specify the name of the pod to be monitored.

Must be a string.

geomonitor remoteclustermonitor***retryCount retry_count***

Specify the counter value to retry if pod failed to ping after which pod is marked as down.

Must be an integer in the range of 1-10.

retryFailOverInterval retry_interval

Specify, in milliseconds, the retry interval if pod ping fails.

Must be an integer in the range of 200-10000.

retryInterval retry_interval

Specify, in milliseconds, the retry interval if pod ping is successful.

Must be an integer in the range of 200-10000.

Usage Guidelines

Use this command to configure configuration of pods to be monitored.

geomonitor remoteclustermonitor

Configures remote cluster monitoring parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
geomonitor remoteclustermonitor retryCount retry_count retryInterval
retry_interval
```

retryCount retry_count

Specify the retry count if remote cluster is not reachable. To disable, set to 0.

Must be an integer in the range of 0-10.

Default Value: 3.

retryInterval retry_interval

Specify, in milliseconds, the retry interval after which status of the remote site will be fetched.

Must be an integer in the range of 200-50000.

Default Value: 3000.

Usage Guidelines

Use this command to configure remote cluster monitoring parameters.

geomonitor trafficMonitor

Configures traffic monitoring configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
geomonitor trafficMonitor thresholdCount threshold_count thresholdInterval threshold_interval
```

thresholdCount threshold_count

Specify the number of calls received for standby instance. To disable, set to 0.

Must be an integer in the range of 0-10000.

Default Value: 0.

thresholdInterval threshold_interval

Specify, in milliseconds, the maximum duration window to hit the threshold count value.

Must be an integer in the range of 100-10000.

Default Value: 3000.

Usage Guidelines

Use this command to configure traffic monitoring configuration.

geomonitor vipmonitor

Configures VIP monitoring configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
geomonitor vipmonitor instance-id instance_id
```

Usage Guidelines

Use this command to configure VIP monitoring configuration.

geomonitor vipmonitor instance

Configures VIP monitoring parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
vipmonitor instance instance-id instance_id
```

instance-id instance_id

Specify the instance ID.

Must be an integer in the range of 1-8.

Usage Guidelines

Configuration of VIPs to be monitored. Use this command to configure the instance ID.

geomonitor vipmonitor instance vips

Configures VIP interface monitoring parameters.

Command Modes	Exec > Global Configuration (config)
Syntax Description	<pre>geomonitor vipmonitor instance instance_id vips vip_interface_name [retryCount retry_count retryFailOverInterval retry_interval retryInterval retry_interval vipIp vip_ip vipPort vip_port_number]</pre> <p>retryCount <i>retry_count</i> Specify the counter value to retry if VIP failed to ping after which VIP is marked as down. Must be an integer in the range of 1-10.</p> <p>retryFailOverInterval <i>retry_interval</i> Specify, in milliseconds, the retry interval if VIP failed to ping. Must be an integer in the range of 200-10000.</p> <p>retryInterval <i>retry_interval</i> Specify, in milliseconds, the retry interval if VIP pinged successfully. Must be an integer in the range of 200-10000.</p> <p>vipIp <i>vip_ip</i> Specify the IPv4 address. Must be a string.</p> <p>vipPort <i>vip_port_number</i> Specify the diagnostic port number. Must be an integer.</p> <p>vip_interface_name Specify name of the interface to monitor. Must be a string.</p>
Usage Guidelines	Use this command to configure VIP monitoring configuration.

helm

Configures Helm configuration parameters.

Command Modes	Exec > Global Configuration (config)
Syntax Description	<pre>helm default-repository default_repository_name</pre> <p>default-repository <i>default_repository_name</i> Specify the name of the default Helm repository.</p>

Usage Guidelines Use this command to configure Helm configuration parameters.

helm charts

Displays Helm release details.

Command Modes Exec > Global Configuration (config)

Syntax Description **charts**

Usage Guidelines Use this command to view Helm release details.

helm repository

Configures Helm repository parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **helm repository** *helm_repo_name* [[**access-token** *access_token*] [**password** *helm_repo_password*] [**url** *helm_repo_url*] [**username** *helm_repo_username*]]

access-token *helm_repo_access_token*

Specify the access token for the Helm repository.

Must be a string.

helm repository *helm_repo_name*

Specify the name of the Helm repository.

Must be a string.

password *helm_repo_password*

Specify the password for the Helm repository.

url *helm_repo_url*

Specify the URL for the Helm repository.

Must be a string.

username *helm_repo_username*

Specify the username for the Helm repository.

Must be a string.

Usage Guidelines Use this command to configure the Helm repository parameters.

help

Displays help information for a specified command.

Command Modes Exec

Syntax Description **help** *command*

command

Specify the command name to display the corresponding help information.

The command must be one of the following:

- aaa
- cd
- cdl
- commit
- compare
- config
- describe
- dump
- exit
- help
- history
- id
- idle-timeout
- ignore-leading-space
- job
- leaf-prompting
- license
- logout
- monitor
- no
- paginate
- quit
- rem

- **screen-length**
- **screen-width**
- **send**
- **show**
- **show-defaults**
- **smiuser**
- **system**
- **terminal**
- **timestamp**
- **who**

Usage Guidelines Use this command to view help information for a specified command.

history

Configures the command history cache size.

Command Modes Exec

Syntax Description **history** *history_size*

history_size

Specify the command history cache size.

Must be an integer in the range of 0-1000.

Usage Guidelines Use this command to configure the command history cache size.

id

Displays user ID information.

Command Modes Exec

Syntax Description **id**

Usage Guidelines Use this command to view the user ID information.

idle-timeout

idle-timeout

Configures the maximum duration a command can remain idle in seconds after which the system automatically terminates the connection.

Command Modes Exec

Syntax Description `idle-timeout duration`

duration

Specify the idle timeout duration in seconds.

Must be an integer in the range of 1-8192.

Usage Guidelines Use this command to configure the maximum duration a command can remain idle.

ignore-leading-space

Configures whether to ignore or consider the leading whitespace at the beginning of a command.

Command Modes Exec

Syntax Description `ignore-leading-space { false | true }`

{ false | true }

Specify false to ignore the leading whitespace, and true to consider it.

Must be either "false" or "true".

Usage Guidelines Use this command to configure whether to ignore or consider leading whitespace at the beginning of a command.

infra metrics experimental

Configures the experimental metrics version to be enabled.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra metrics experimental version experimental_metrics_version`

version experimental_metrics_version

Specify the experimental metrics version to be enabled.

Must be an integer in the range of 0-4.

Default Value: 0.

Usage Guidelines Use this command to configure the experimental metrics version to be enabled.

infra metrics verbose verboseLevels

Configures verbose configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra metrics verbose pod_type level verbose_level`

level *verbose_level*

Specify the default verbosity level.

Must be one of the following:

- **debug**
- **off**
- **production**
- **trace**

Default Value: trace.

pod_type

Specify the pod type.

Must be one of the following:

- **application**
- **load-balancer**
- **protocol**
- **service**

Usage Guidelines Use this command to configure verbose configuration parameters.

infra metrics verbose verboseLevels metrics metricsList

Configures metrics verbose level parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra metrics verbose pod_type metrics metrics_name granular-labels granular_labels level metrics_verbose_level`

infra transaction limit**granular-labels *granular_labels***

Specify the granular labels.

Must be a string.

level *metrics_verbose_level*

Specify the metrics verbosity level.

Must be one of the following:

- **debug**
- **off**
- **production**
- **trace**

Default Value: trace.

metrics *metrics_name*

Specify the name of the metrics.

Must be a string.

Usage Guidelines

Use this command to configure metrics verbose level parameters.

infra transaction limit

Configures the maximum stage limit per transaction.

Command Modes

Exec > Global Configuration (config)

Syntax Description

infra transaction limit stage *max_stage_limit*

stage *max_stage_limit*

Specify the maximum stage limit per transaction.

Must be an integer.

Default Value: 100.

Usage Guidelines

Use this command to configure the maximum stage limit per transaction.

infra transaction limit consecutive same

Configures the maximum consecutive stage limit per transaction.

Command Modes

Exec > Global Configuration (config)

Syntax Description `infra transaction limit consecutive same stage max_consecutive_stage_limit`

stage *max_consecutive_stage_limit*

Specify the maximum consecutive stage limit per transaction.

Must be an integer.

Default Value: 10.

Usage Guidelines Use this command to configure the maximum consecutive stage limit per transaction.

infra transaction loop

Configures the transaction loop detection parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra transaction loop detection detection_status`

detection *detection_status*

Specify to enable or disable loop detection.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines Use this command to configure the transaction loop detection parameter.

infra transaction loop category

Configures the loop category.

Command Modes Exec > Global Configuration (config)

Syntax Description `infra transaction loop category loop_category`

category *loop_category*

Specify the category.

Usage Guidelines Use this command to configure the loop category. The CLI prompt changes to the Loop Category Configuration mode(config-category-<category>).

infra transaction loop category threshold

infra transaction loop category threshold

Configures the loop detection interval parameter.

Command Modes Exec > Global Configuration (config) > Loop Category Configuration (config-category-*category*)

Syntax Description **threshold interval** *loop_detect_interval*

interval loop_detect_interval

Specify, in seconds, the loop detection interval.

Must be an integer.

Default Value: 5.

Usage Guidelines Use this command to configure the loop detection interval parameter.

infra transaction loop category threshold thresholds

Configures thresholds.

Command Modes Exec > Global Configuration (config) > Loop Category Configuration (config-category-*category*)

Syntax Description **thresholds** *threshold_level* [[**action** *threshold_action*] [**count** *max_transactions*]]

action threshold_action

Specify the action to take on threshold breach.

Must be one of the following:

- **kill-session**
- **log-event**
- **noop**

Default Value: noop.

count max_transactions

Specify the maximum number of transactions for the threshold interval.

Must be an integer.

Default Value: 100.

thresholds threshold_level

Specify the threshold level.

Must be one of the following:

- **high**
- **low**

Usage Guidelines	Use this command to configure thresholds.
-------------------------	---

instance instance-id

Configures instance ID of GR instance.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	instance instance-id <i>instance_id</i>
---------------------------	--

instance-id *instance_id*

Specify the instance ID.

Usage Guidelines	GR instance-specific parameters. Use this command to configure the instance ID of GR instance. The CLI prompt changes to the Instance ID Configuration mode (config-instance-id-< <i>instance_id</i> >).
-------------------------	--

instance instance-id endpoint ep

Configures endpoint parameters.

Command Modes	Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id- <i>instance_id</i>)
----------------------	--

Syntax Description	endpoint <i>endpoint_type</i> [[instancetype <i>ep_local_interface_type</i>] [loopbackEth <i>loopbackEth</i>] [loopbackPort <i>loopbackPort</i>] [nodes <i>node_replicas_for_resiliency</i>] [replicas <i>replicas_per_node</i>] [uri-scheme <i>uri_scheme</i>]]
---------------------------	---

certificate-name *certificate_alias_name*

Specify the alias name for the certificate.

endpoint *endpoint_type*

Specify the endpoint type. Must be one of the following: bgpspeaker, dhcp, geo, l2tp-tunnel, n4-protocol, nodemgr, pppoe, radius, sbi, sm, udp-proxy.

instancetype *ep_local_interface_type*

Specify the endpoint local interface type.

Must be one of the following:

- **Dual**
- **IPv4**

instance instance-id endpoint ep cpu

- **IPv6**

Default Value: IPv4.

internal-vip

Specify the internal VIP.

Must be a string of 1-128 characters.

loopbackEth *loopbackEth*

Specify the endpoint local interface name or host IP.

Must be a string.

loopbackPort *loopbackPort*

Specify the endpoint local port.

Must be an integer.

nodes *node_replicas_for_resiliency*

Specify the number of node replicas for resiliency.

Must be an integer.

Default Value: 1.

replicas *replicas_per_node*

Specify the number of replicas per node.

Must be an integer.

Default Value: 1.

uri-scheme *uri_scheme*

Specify the URI scheme.

Must be one of the following:

- **http**
- **https**

Default Value: http.

Usage Guidelines Use this command to configure endpoint parameters.

instance instance-id endpoint ep cpu

Configures K8 pod CPU configuration.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Syntax Description `cpu { [max-process max_parallel_os_threads] [request cpu_resource_request] }`

max-process *max_parallel_os_threads*

Specify the maximum parallel OS threads to use.

Must be an integer in the range of 1-32.

request *cpu_resource_request*

Specify the CPU resource request in millicores.

Must be an integer in the range of 100-1000000.

Usage Guidelines Use this command to configure K8 pod CPU configuration.

instance instance-id endpoint ep interface

Configures endpoint interfaces.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-service)

Syntax Description `interface interface_type [[instancetype ep_local_interface_type] [loopbackEth loopback_eth] [loopbackPort loopback_port_number] [uri-scheme uri_scheme]]`

certificate-name *certificate_alias_name*

Specify the alias name for certificate.

instancetype *ep_local_interface_type*

Specify the endpoint local interface type.

Must be one of the following:

- Dual
- IPv4
- IPv6

Default Value: IPv4.

interface *interface_type*

Specify the interface type.

instance instance-id endpoint ep interface dispatcher

loopbackEth *loopback_eth*

Specify the Loopback Eth pod interface.

Must be a string.

loopbackPort *loopback_port_number*

Specify the loopback port number.

Must be an integer.

uri-scheme *uri_scheme*

Specify the URI scheme.

Must be one of the following:

- **http**
- **https**

Default Value: http.

Usage Guidelines Use this command to configure endpoint interfaces.

instance instance-id endpoint ep interface dispatcher

Configures dispatcher queue support for the interface.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
dispatcher [ [ cache { false | true } ] [ capacity queue_capacity ] [ count dispatcher_queue_count ] [ expiry cache_entry_expiry_duration ] [ nonresponsive cache_entry_expiry_duration ] [ outbound { false | true } ] [ rate-limit queue_rate_limit ] [ threshold outstanding_requests ] ]
```

cache { false | true }

Specify whether to disable or enable retransmission cache support. To enable, set to false.

Must be one of the following:

- **false**
- **true**

Default Value: false.

capacity queue_capacity

Specify the capacity of each queue.

Must be an integer.

Default Value: 5000.

count dispatcher_queues_count

Specify the count of dispatcher queues.

Must be an integer.

Default Value: 0.

expiry expiry_duration

Specify the responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 60000.

nonresponsive nonresponsive_duration

Specify the not responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 30000.

outbound { false | true }

Specify whether to disable or enable queue support for outbound messages. To enable, set to false.

Must be one of the following:

- **false**
- **true**

Default Value: true.

rate-limit rate_limit

Specify the rate limit for each queue.

Must be an integer.

Default Value: 0.

threshold outstanding_requests

Specify the outstanding requests per queue cache.

Must be an integer.

Default Value: 30000.

```
instance instance-id endpoint ep interface internal base-port
```

Usage Guidelines Use this command to configure dispatcher queue support for the interface.

instance instance-id endpoint ep interface internal base-port

Configures base-port to start endpoint parameter.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
internal base-port start base_port_to_start_ep
```

start *base_port_to_start_ep*

Specify the base-port to start endpoint.

Must be an integer in the range of 1024-65535.

Usage Guidelines Use this command to configure the base-port to start endpoint parameter.

instance instance-id endpoint ep interface sla

Configures SLA parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
sla { [ response response_time ] [ procedure procedure_time ] }
```

procedure *procedure_time*

Specify, in milliseconds, the procedure time.

Must be an integer in the range of 1000-120000.

response *response_time*

Specify, in milliseconds, the response time.

Must be an integer in the range of 1000-180000.

Usage Guidelines Use this command to configure SLA parameters.

instance instance-id endpoint ep interface vip

Configures Virtual IP parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip-ip** *vip_ip_address* [[**offline**] [**vip-interface** *interface_name*] [**vip-port** *vip_port_number*]]

offline

Specify to mark the vip-ip as offline.

vip-interface *interface_name*

Specify the interface name to advertise BGP router.

Must be a string.

vip-ip *vip_ip_address*

Specify the IP address of the host.

Must be a string.

vip-port *vip_port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure Virtual IP parameters.

instance instance-id endpoint ep interface vip6

Configures VIP IP6 parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip6** **vip-ip6** *vip_ip6* [[**offline**] [**vip-ipv6-port** *port_number*]]

offline

Specify the VIP IP as offline.

vip-ip6 *vip_ip6*

Specify the host detail.

Must be a string.

vip-ipv6-port *port_number*

Specify the port number.

Must be an integer.

instance instance-id endpoint ep memory

Usage Guidelines Use this command to configure VIP IP6 parameters.

instance instance-id endpoint ep memory

Configures K8 pod memory configuration.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Syntax Description **memory { [limit *max_memory_resource*] [request *memory_resource_request*] }**

limit *max_memory_resource*

Specify the maximum memory resource in use in megabytes.

Must be an integer in the range of 100-200000.

request *memory_resource_request*

Specify the memory resource request in megabytes.

Must be an integer in the range of 100-200000.

Usage Guidelines Use this command to configure K8 pod memory configuration.

instance instance-id endpoint ep retransmission

Configures PFCP retransmission configuration.

Command Modes Exec > Global Configuration

Syntax Description **retransmission max-retry *max_retry* timeout *pfcp_retransmission_interval***

max-retry *max_retry*

Specify the maximum number of times PFCP request retry attempts. To disable retransmission, set to 0.

Must be an integer in the range of 0-1.

Default Value: 1.

timeout *pfcp_retransmission_interval*

Specify the PFCP retransmission interval in seconds.

Must be an integer in the range of 0-15.

Default Value: 15.

Usage Guidelines Use this command to configure PFCP retransmission configuration.

instance instance-id endpoint ep service

Configures VIP IPv6 parameters.

Command Modes Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id-*instance_id*) > Endpoint *endpoint_type* Configuration (config-endpoint-*endpoint_type*)

Syntax Description

service service-name *service_name*

Specify the service name.

Must be a string in the pattern [A-Za-z0-9-].*[0-9].*.

Usage Guidelines Use this command to configure VIP IPv6 parameters.

instance instance-id endpoint ep service interface

Configures endpoint interfaces.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service*)

Syntax Description

interface *interface_type* [[**instancetype** *ep_local_interface_type*] [**loopbackEth** *loopback_eth*] [**loopbackPort** *loopback_port_number*] [**uri-scheme** *uri_scheme*]]

certificate-name certificate_alias_name

Specify the alias name for certificate.

instancetype ep_local_interface_type

Specify the endpoint local interface type.

Must be one of the following:

- Dual
- IPv4
- IPv6

Default Value: IPv4.

interface *interface_type*

Specify the interface type.

```
instance instance-id endpoint ep service interface dispatcher
```

loopbackEth *loopback_eth*

Specify the Loopback Eth pod interface.

Must be a string.

loopbackPort *loopback_port_number*

Specify the loopback port number.

Must be an integer.

uri-scheme *uri_scheme*

Specify the URI scheme.

Must be one of the following:

- **http**
- **https**

Default Value: http.

Usage Guidelines

Use this command to configure endpoint interfaces.

instance instance-id endpoint ep service interface dispatcher

Configures dispatcher queue support for the interface.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
dispatcher [ [ cache { false | true } ] [ capacity queue_capacity ] [ count dispatcher_queue_count ] [ expiry cache_entry_expiry_duration ] [ nonresponsive cache_entry_expiry_duration ] [ outbound { false | true } ] [ rate-limit queue_rate_limit ] [ threshold outstanding_requests ] ]
```

cache { false | true }

Specify whether to disable or enable retransmission cache support. To enable, set to false.

Must be one of the following:

- **false**
- **true**

Default Value: false.

capacity queue_capacity

Specify the capacity of each queue.

Must be an integer.

Default Value: 5000.

count dispatcher_queues_count

Specify the count of dispatcher queues.

Must be an integer.

Default Value: 0.

expiry expiry_duration

Specify the responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 60000.

nonresponsive nonresponsive_duration

Specify the not responded cache entry expiry duration in milliseconds.

Must be an integer.

Default Value: 30000.

outbound { false | true }

Specify whether to disable or enable queue support for outbound messages. To enable, set to false.

Must be one of the following:

- **false**
- **true**

Default Value: true.

rate-limit rate_limit

Specify the rate limit for each queue.

Must be an integer.

Default Value: 0.

threshold outstanding_requests

Specify the outstanding requests per queue cache.

Must be an integer.

Default Value: 30000.

```
instance instance-id endpoint ep service interface internal base-port
```

Usage Guidelines Use this command to configure dispatcher queue support for the interface.

instance instance-id endpoint ep service interface internal base-port

Configures base-port to start endpoint parameter.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Service Configuration (config-service-*service_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
internal base-port start base_port_to_start_ep
```

start *base_port_to_start_ep*

Specify the base-port to start endpoint.

Must be an integer in the range of 1024-65535.

Usage Guidelines Use this command to configure the base-port to start endpoint parameter.

instance instance-id endpoint ep service interface overload-control client threshold critical

Configures the Overload Control Protection critical threshold parameter.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
overload-control threshold critical critical_threshold_limit action  
critical_threshold_action
```

Syntax Description

```
overload-control client threshold critical critical_threshold_limit action  
critical_threshold_action
```

action *critical_threshold_action*

Specify the action to be taken if the critical threshold is hit.

critical *critical_threshold_limit*

Specify the critical threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control protection's critical threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control client threshold high

Configures the Overload Control Protection high threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold high *high_threshold_limit* *action* *high_threshold_action*

Syntax Description

overload-control client threshold high *high_threshold_limit* *action* *high_threshold_action*

action high_threshold_action

Specify the action to be taken when high threshold limit is hit.

high high_threshold_limit

Specify the high threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection high threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control client threshold low

Configures the Overload Control Protection low threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold low *low_threshold_limit* *action* *low_threshold_action*

Syntax Description

overload-control client threshold low *low_threshold_limit* *action* *low_threshold_action*

action low_threshold_action

Specify the action to be taken when low threshold limit is hit.

```
instance instance-id endpoint ep service interface overload-control endpoint threshold critical
```

low low_threshold_limit

Specify the low threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection low threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control endpoint threshold critical

Configures the Overload Control Protection critical threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
overload-control threshold critical critical_threshold_limit action  
critical_threshold_action
```

Syntax Description

```
overload-control client threshold critical critical_threshold_limit action  
critical_threshold_action
```

action critical_threshold_action

Specify the action to be taken if the critical threshold is hit.

critical critical_threshold_limit

Specify the critical threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control protection's critical threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control endpoint threshold high

Configures the Overload Control Protection high threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

```
overload-control threshold high high_threshold_limit action high_threshold_action
```

Syntax Description

```
overload-control client threshold high high_threshold_limit action  
high_threshold_action
```

action high_threshold_action

Specify the action to be taken when high threshold limit is hit.

high high_threshold_limit

Specify the high threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection high threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control endpoint threshold low

Configures the Overload Control Protection low threshold parameter.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control threshold low low_threshold_limit action low_threshold_action

Syntax Description

overload-control client threshold low low_threshold_limit action low_threshold_action

action low_threshold_action

Specify the action to be taken when low threshold limit is hit.

low low_threshold_limit

Specify the low threshold limit for outstanding requests.

Must be an integer in the range of 10-100000.

Usage Guidelines

Use this command to configure the Overload Control Protection low threshold parameter. To configure threshold configuration per client, use the "overload-control client threshold ..." command.

instance instance-id endpoint ep service interface overload-control msg-type messageConfigs

Configures the message configuration parameters.

Command Modes

Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

overload-control msg-type message_type pending-request pending_requests queue-size queue_size rate-limit rate_limit reject-threshold reject_threshold

```
instance instance-id endpoint ep service interface sla
```

msg-type *message_type*

Specify the message type.

pending-request *pending_requests*

Specify the pending requests count in virtual queue.

Must be an integer.

queue-size *queue_size*

Specify the packet count or capacity of each virtual queue.

Must be an integer.

rate-limit *rate_limit*

Specify the rate limit for virtual queue.

Must be an integer.

reject-threshold *reject_threshold*

Specify the limit to reject incoming messages if this threshold percentage of pending requests are present.

Must be an integer.

Usage Guidelines

Use this command to configure the message configuration parameters.

instance instance-id endpoint ep service interface sla

Configures SLA parameters.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description

sla { [response *response_time*] [procedure *procedure_time*] }

procedure *procedure_time*

Specify, in milliseconds, the procedure time.

Must be an integer in the range of 1000-120000.

response *response_time*

Specify, in milliseconds, the response time.

Must be an integer in the range of 1000-180000.

Usage Guidelines

Use this command to configure SLA parameters.

instance instance-id endpoint ep service interface vip

Configures Virtual IP parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip-ip** *vip_ip_address* [[**offline**] [**vip-interface** *interface_name*] [**vip-port** *vip_port_number*]]

offline

Specify to mark the vip-ip as offline.

vip-interface *interface_name*

Specify the interface name to advertise BGP router.

Must be a string.

vip-ip *vip_ip_address*

Specify the IP address of the host.

Must be a string.

vip-port *vip_port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure Virtual IP parameters.

instance instance-id endpoint ep service interface vip6

Configures VIP IP6 parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_name*) > Interface Configuration (config-interface-*interface_name*)

Syntax Description **vip6** **vip-ip6** *vip_ip6* [[**offline**] [**vip-ipv6-port** *port_number*]]

offline

Specify the VIP IP as offline.

vip-ip6 *vip_ip6*

Specify the host detail.

Must be a string.

```
instance instance-id endpoint ep system-health-level crash
```

vip-ipv6-port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure VIP IP6 parameters.

instance instance-id endpoint ep system-health-level crash

Configures system health crash parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description **system-health-level crash { [cpu-percent *cpu_percentage*] [memory-in-mbs *memory*] [num-of-goroutine *goroutine_per_core*] }**

cpu-percent *cpu_percentage*

Specify the CPU percentage.

Must be an integer.

Default Value: 80.

memory-in-mbs *memory*

Specify the memory in MB.

Must be an integer.

Default Value: 2048.

num-of-goroutine *goroutine_per_core*

Specify the number of goroutine per core.

Must be an integer.

Default Value: 45000.

Usage Guidelines Use this command to configure system health crash parameters.

instance instance-id endpoint ep system-health-level critical

Configures system health critical parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description **critical { [cpu-percent *cpu_percent*] [memory-in-mbs *memory*] [num-of-goroutine *number_of_goroutine*] }**

cpu-percent *cpu_percentage*

Specify the CPU percentage.

Must be an integer.

Default Value: 60.

memory-in-mbs *memory*

Specify the memory in MB.

Must be an integer.

Default Value: 1024.

num-of-goroutine *number_of_goroutine*

Specify the number of goroutine per core.

Must be an integer.

Default Value: 35000.

Usage Guidelines

Use this command to configure system health critical parameters.

instance instance-id endpoint ep system-health-level warn

Configures system health warn parameters.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description

```
system-health-level warn { [ cpu-percent cpu_percentage ] [ memory-in-mbs memory ] [ num-of-goroutine number_of_goroutine ] }
```

cpu-percent *cpu_percentage*

Specify the CPU percentage.

Must be an integer.

Default Value: 50.

memory-in-mbs *memory*

Specify the memory in MBs.

Must be an integer.

Default Value: 512.

num-of-goroutine *goroutine_per_core*

Specify the number of goroutine per core.

Must be an integer.

instance instance-id endpoint ep vip

Default Value: 25000.

Usage Guidelines Use this command to configure system health warn parameters.

instance instance-id endpoint ep vip

Configures VIP parameters.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-id-*instance_id*) > Endpoint Configuration (config-endpoint-*endpoint_type*)

Syntax Description **vip-ip** *vip_ipv4_address* [[**offline**] [**vip-interface** *vip_interface_name*] [**vip-port** *port_number*]]

offline

Specify the VIP-IP as offline.

vip-interface *vip_interface_name*

Specify the interface name to advertise BGP router.

Must be a string.

vip-ip *vip_ipv4_address*

Specify the VIP IPv4 address.

Must be a string.

vip-port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure VIP parameters.

instance instance-id endpoint ep vip6

Configures VIP IPv6 parameters.

Command Modes Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id-*instance_id*) > Endpoint *endpoint_type* Configuration (config-endpoint-*endpoint_type*)

Syntax Description **vip-ipv6** *vip_ipv6_detail* [[**offline**] [**vip-ipv6-port** *vip_ipv6_port_number*]]

offline

Specify the VIP-IP as offline.

vip-ipv6-port *vip_ipv6_port_number*

Specify the port number.

Must be an integer.

vip-ipv6 *vip_ipv6_detail*

Specify the IPv6 detail.

Must be a string.

Usage Guidelines Use this command to configure VIP IPv6 parameters.

instances instance

Configures instance configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **instances instance** *instance_id* [[**cluster-id** *cluster_id*] [**system-id** *system_id*] [**slice-name** *slice_name*]]

cluster-id *cluster_id*

Specify the instance cluster ID.

Must be a string.

instance-id *instance_id*

Specify the instance ID.

Must be an integer in the range of 1-8.

slice-name *slice_name*

Specify the CDL slice name associated with instance ID.

Must be a string.

system-id *system_id*

Specify the instance system ID.

Must be a string.

Usage Guidelines Use this command to configure instance configuration parameters.

ipam instance

Configures IPAM instance parameters.

ipam instance address-pool

Command Modes Exec > Global Configuration (config)

Syntax Description **ipam instance *instance_id***

instance *instance_id*

Specify the instance ID.

Must be an integer in the range of 1-8.

Usage Guidelines Use this command to configure IPAM instance parameters. The CLI prompt changes to the Instance Configuration mode (config-instance-<*instance_id*>).

ipam instance address-pool

Configures IPAM address pools.

Command Modes Exec > Global Configuration (config) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **address-pool *pool_name* [**address-quarantine-qsize** *address_quarantine_queue_size* | **address-quarantine-timer** *address_quarantine_timer_interval* | **offline** | **static** | **vrf-name** *vrf_name*]**

address-pool *pool_name*

Specify name of the address pool.

Must be a string of 1-128 characters in the ipam-str pattern. For information on the ipam-str pattern, see the *Input Pattern Types* chapter.

address-quarantine-qsize *address_quarantine_queue_size*

Specify the maximum number of IPs to be held in quarantine queue per-dp, per-af, per-instance. By default, it is set to 0 (no limit).

Must be an integer.

address-quarantine-timer *address_quarantine_timer_interval*

Specify the address quarantine timer interval in seconds.

Must be an integer in the range of 4-3600.

Default Value: 4.

offline

Specify the pool as an offline pool.

vrf-name *vrf_name*

Specify name of the VRF.

Must be a string of 1-128 characters in the ipam-str pattern. For information on the ipam-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPAM address pools. The CLI prompt changes to the Address Pool Configuration mode (config-address-pool-<address_pool_name>).

ipam instance address-pool ipv4 address-range

Configures IPv4 address ranges.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv4 Configuration (config-ipv4)

Syntax Description

address-range *start_ipv4_address* *end_ipv4_address* [**offline**] [**default-gateway ip_address**]

default-gateway ip_address

Specify the default gateway IP address for static pool.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

offline

Specify the IPv4 address range as offline.

end_ipv4_address

Specify the end address of the IPv4 address range.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

start_ipv4_address

Specify the start address of the IPv4 address range.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPv4 address ranges.

ipam instance address-pool ipv4 prefix-range

Configures IPv4 prefix range.

Command Modes

Exec > Global Configuration (config) > Instance Configuration (config-instance-id-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name)

ipam instance address-pool ipv4 split-size

Syntax Description **ipv4 prefix-range range** *prefix_value prefix_length* [**offline**] [**default-gateway ip_address**]

default-gateway ip_address

Specify the default gateway IP address for static pool.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

length prefix_length

Specify the IPv4 prefix length.

Must be an integer in the range of 1-31.

offline

Specify the IPv4 prefix range as offline.

prefix_value

Specify the IPv4 prefix.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure IPv4 prefix range.

ipam instance address-pool ipv4 split-size

Configures chunk split size parameters.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description **split-size** [[**no-split**] [**per-cache** *number_of_addresses*] [**per-dp** *number_of_addresses*]]

no-split

Specify not to split the address range into smaller chunks.

per-cache number_of_addresses

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

per-dp number_of_addresses

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

Usage Guidelines

Use this command to configure chunk split size parameters. The CLI prompt changes to the Split Size Configuration mode (config-split-size).

ipam instance address-pool ipv4 threshold

Configures pool thresholds.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv4 Configuration (config-ipv4)

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description

threshold upper-threshold upper_threshold

upper-threshold upper_threshold

Specify the upper threshold value in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines

Use this command to configure pool thresholds.

ipam instance address-pool ipv6 address-ranges address-range

Configures IPv6 address ranges.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Syntax Description

address-range start_ipv6_address end_ipv6_address [offline]

ipam instance address-pool ipv6 address-ranges prefix-range

offline

Specify the IPv6 address range as offline.

end_ipv6_address

Specify the end address of the IPv6 address range.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

start_ipv6_address

Specify the start address of the IPv6 address range.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPv6 address ranges.

ipam instance address-pool ipv6 address-ranges prefix-range

Configures IPv6 prefix range.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Syntax Description

prefix-range range prefix_value prefix_length [offline]

length prefix_length

Specify the IPv6 prefix length.

Must be an integer in the range of 96-127.

prefix_value

Specify the IPv6 prefix.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure IPv6 prefix range.

ipam instance address-pool ipv6 address-ranges split-size

Configures chunk split size parameters.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description `split-size [[no-split] [per-cache number_of_addresses] [per-dp number_of_addresses]]`

no-split

Specify not to split the address range into smaller chunks.

per-cache *number_of_addresses*

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

per-dp *number_of_addresses*

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

Usage Guidelines Use this command to configure chunk split size parameters. The CLI prompt changes to the Split Size Configuration mode (config-split-size).

ipam instance address-pool ipv6 address-ranges threshold

Configures pool thresholds.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description `threshold upper-threshold upper_threshold`

upper-threshold *upper_threshold*

Specify the upper threshold value in percentage.

ipam instance address-pool ipv6 prefix-ranges prefix-range

Must be an integer in the range of 1-100.

Usage Guidelines Use this command to configure pool thresholds.

ipam instance address-pool ipv6 prefix-ranges prefix-range

Configures IPv6 prefix ranges.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description **prefix-range** *prefix_value* **prefix-length** *prefix_length* [**offline**]

offline

Specify the IPv6 prefix range as offline.

prefix-length *prefix_length*

Specify the prefix length.

Must be an integer in the range of 1-63.

prefix-range *prefix_value*

Specify the IPv6 prefix range.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure IPv6 prefix ranges.

ipam instance address-pool ipv6 prefix-ranges split-size

Configures chunk split size parameters.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv4 Configuration (config-ipv4)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-instance_id) > Address Pool Configuration (config-address-pool-address_pool_name) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description

```
split-size [ [ no-split ] [ per-cache number_of_addresses ] [ per-dp number_of_addresses ] ]
```

no-split

Specify not to split the address range into smaller chunks.

per-cache *number_of_addresses*

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

per-dp *number_of_addresses*

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

Usage Guidelines

Use this command to configure chunk split size parameters. The CLI prompt changes to the Split Size Configuration mode (config-split-size).

ipam instance address-pool ipv6 prefix-ranges threshold

Configures pool thresholds.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv4 Configuration (config-ipv4)

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Address Ranges Configuration (config-address-ranges)

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*) > Address Pool Configuration (config-address-pool-*address_pool_name*) > IPv6 Configuration (config-ipv6) > Prefix Ranges Configuration (config-prefix-ranges)

Syntax Description

```
threshold upper-threshold upper_threshold
```

upper-threshold *upper_threshold*

Specify the upper threshold value in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines

Use this command to configure pool thresholds.

ipam instance address-pool static

Configures IPAM static pool parameters.

ipam instance min-dp-addr-size

Command Modes	Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance- <i>instance_id</i>) > Address Pool Configuration (config-address-pool- <i>address_pool_name</i>)
Syntax Description	<p>static enable user-plane <i>user_plane</i></p> <p>enable</p> <p>Specify to set pool as static.</p> <p>user-plane <i>user_plane</i></p> <p>Specify to associate user plane for this static pool.</p> <p>Must be a string of 1-128 characters in the ipam-str pattern. For information on the ipam-str pattern, see the <i>Input Pattern Types</i> chapter.</p>
Usage Guidelines	Use this command to configure IPAM static pool parameters.

ipam instance min-dp-addr-size

Configures the minimum number of addresses to reserve per UPF, per NM, per pool/tag.

Command Modes	Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance- <i>instance_id</i>)
Syntax Description	<p>min-dp-addr-size [[ipv4-addr <i>reserve_min_ipv4_address</i>] [ipv6-addr <i>reserve_min_ipv6_address</i>] [ipv6-prefix <i>reserve_min_ipv6_prefix</i>]]</p> <p>ipv4-addr <i>reserve_min_ipv4_address</i></p> <p>Specify the minimum number of IPv4 addresses to reserve.</p> <p>Must be an integer in the range of 16-262144.</p> <p>ipv6-addr <i>reserve_min_ipv6_address</i></p> <p>Specify the minimum number of IPv6 addresses to reserve.</p> <p>Must be an integer in the range of 32-262144.</p> <p>ipv6-prefix <i>reserve_min_ipv6_prefix</i></p> <p>Specify the minimum number of IPv6 prefix to reserve.</p> <p>Must be an integer in the range of 32-262144.</p>
Usage Guidelines	Use this command to configure the minimum number of addresses to reserve per UPF, per NM, per pool/tag.

ipam instance source

Configures pool-datastore source selection.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **source local**

local

Specify to use local address pool datastore.

Usage Guidelines Use this command to configure pool-datastore source selection.";

ipam instance source external ipam

Configures external IPAM server for pool information.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **source external ipam [host *ip_address* | port *port_number* | vendor *vendor_id*]**

host *ip_address*

Specify the IP address of the IPAM server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

port *port_number*

Specify the port number of the IPAM server.

Must be an integer in the range of 1-65535.

vendor *vendor_id*

Specify the IPAM server's vendor ID. Default: cisco.

Must be one of the following:

- cisco

Usage Guidelines Use this command to configure external IPAM server for pool information.

ipam instance threshold

Configures global upper thresholds.

ipam show dp

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Instance Configuration (config-instance-*instance_id*)

Syntax Description **threshold** [[**ipv4-addr** *ipv4_address_threshold*] [**ipv6-addr** *ipv6_address_threshold*] [**ipv6-prefix** *ipv6_prefix_threshold*]]

ipv4-addr *ipv4_address_threshold*

Specify the IPv4 address threshold in percentage.

Must be an integer in the range of 1-100.

ipv6-addr *ipv6_address_threshold*

Specify the IPv6 address threshold in percentage.

Must be an integer in the range of 1-100.

ipv6-prefix *ipv6_prefix_threshold*

Specify the IPv6 prefix threshold in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines Use this command to configure global upper thresholds.

ipam show dp

Displays IPAM data-plane allocations.

Command Modes Exec

Syntax Description **show ipam dp** [**dp-name** *dataplane_name*]

dp-name *dataplane_name*

Specify name of the dataplane.

Must be a string.

Usage Guidelines Use this command to view IPAM data-plane allocations.

ipam show dp-tag

Displays data-plane tag-related allocations.

Command Modes Exec

Syntax Description **show ipam dp-tag** *dp_tag*

dp-tag *dp_tag*

Specify the dataplane name with tag.

Must be a string.

Usage Guidelines

Use this command to view data-plane tag-related allocations. Tag represents DNN or PoolName based on NF.

ipam show ipam pool

Displays pool allocation information.

Command Modes

Exec

Syntax Description

show ipam pool *pool_name*

pool-name pool_name

Specify name of the pool.

Must be a string.

Usage Guidelines

Use this command to view pool allocation information.

job

Suspends the jobs that are running in the background.

Command Modes

Exec

Syntax Description

job stop *job_id*

job_id

Specify the job ID for suspending the corresponding job.

Must be an integer.

Usage Guidelines

Use this command to suspend the jobs that are running in the background.

k8 bng

Configures Tracing configuration parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

k8 bng [[coverage-build { false | true }] [datastore-endpoint *datastore_endpoint*] [etcd-endpoint *etcd_endpoint*]]

k8 bng tracing**coverage-build { false | true }**

Specify whether to disable or enable coverage build.

Must be one of the following:

- **false**
- **true**

Default Value: false.

datastore-endpoint *datastore_endpoint*

Specify the Datastore Endpoint configuration. For example, *hostname:port*.

Must be a string of 1-128 characters.

Default Value: datastore-ep-session:8882.

etcd-endpoint *etcd_endpoint*

Specify the Etcd Endpoint configuration. For example, *hostname:port*.

Must be a string of 1-128 characters.

Default Value: etcd:2379.

Usage Guidelines

Use this command to configure Tracing configuration parameters. The CLI prompt changes to the BNG Configuration mode (config-bng).

k8 bng tracing

Configures Tracing configuration parameters.

Command Modes

Exec > Global Configuration (config) > BNG Configuration (config-bng)

Syntax Description

```
tracing [ [ append-messages { false | true } ] [ enable ] [ enable-trace-percent tracing_percentage ] [ endpoint tracing_endpoint ] ]
```

append-messages { false | true }

Specify whether to append tracing messages.

Must be one of the following:

- **false**
- **true**

Default Value: true.

enable-trace-percent *tracing_percentage*

Specify the tracing percentage.

Must be an integer in the range of 0-100.

Default Value: 100.

enable

Specify to enable tracing.

endpoint *tracing_endpoint*

Specify the Tracing Endpoint configuration. For example, *hostname:port*.

Must be a string of 1-128 characters.

Default Value: jaeger-collector:9411.

Usage Guidelines

Use this command to configure Tracing configuration parameters. The CLI prompt changes to the Tracing Configuration mode (config-tracing).

k8 label pod-group-config

Configures K8 node affinity label pod group configuration.

Command Modes

Exec > Global Configuration (config)

Syntax Description

k8 label *pod_group* *key* *label_key* *value* *label_value*

key* *label_key

Specify the key for the label.

Must be a string.

value* *label_value

Specify the value for the label.

Must be a string.

pod_group

Specify the pod group for the VMs.

Must be one of the following:

- **cdl-layer**
- **oam-layer**
- **protocol-layer**
- **service-layer**

Usage Guidelines

Use this command to configure K8 node affinity label pod group configuration.

kubernetes

Configures Kubernetes parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description

```
k8s name k8s_cluster_name [ [ image-pull-secrets image_pull_secrets ] [ ingress-host-name ingress_host_name ] [ namespace k8s_namespace ] [ nf-name nf_name ] [ registry image_registry ] [ single-node { false | true } ] [ use-volume-claims { false | true } ] ]
```

image-pull-secrets *image_pull_secrets*

Specify the image pull secrets stored within K8s.

Must be a string.

ingress-host-name *ingress_host_name*

Specify the generic ingress host name.

Must be a string.

name *k8s_cluster_name*

Specify name of the K8s cluster.

Must be a string.

namespace *k8s_namespace*

Specify the K8s namespace for the network function.

Must be a string.

nf-name *nf_name*

Specify the NF deployed in this k8s namespace.

Must be a string.

registry *image_registry*

This keyword is deprecated.

Must be a string.

single-node { **false | **true** }**

Specify to enable or disable single node deployment.

Must be one of the following:

- **false**
- **true**

Default Value: false.

use-volume-claims { false | true }

Specify to enable or disable using volume claims when deploying.

Must be one of the following:

- **false**
- **true**

Default Value: false.

Usage Guidelines	Use this command to configure Kubernetes parameters.
-------------------------	--

kubernetes nodes

Configures list of k8s nodes.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	k8s nodes <i>k8s_node_name</i> [[node-type <i>node_type</i>] [worker-type <i>worker_type</i>]]
---------------------------	---

node-type *node_type*

Specify the K8s node type.

Must be a string.

worker-type *worker_type*

Specify the k8s worker type.

Must be a string.

k8s_node_name

Specify name of the K8s node.

Must be a string.

Usage Guidelines	Use this command to configure the list of k8s nodes.
-------------------------	--

leaf-prompting

Enables or disables automatic querying for leaf values.

Command Modes	Exec
----------------------	------

Syntax Description	leaf-prompting { false true }
---------------------------	--

license smart deregister

{ false | true }

Specify false to disable leaf prompting, and true to enable.

Must be either "false" or "true".

Usage Guidelines Use this command to automatically query for leaf values.

license smart deregister

Configures the license parameters for the VNF deregistration.

Command Modes Exec

Syntax Description **license smart deregister**

deregister

Specify to deregister the VNF for smart licensing.

Usage Guidelines Use this command to configure the license parameters for the VNF deregistration.

license smart register

Configures the license parameters for the VNF registration.

Command Modes Exec

Syntax Description **license smart register force idtoken token_id**

register

Specify to register the VNF for Smart Licensing.

force

Specify to enable the force registration of the agent.

idtoken token_id

Specify the ID token to register the agent with.

Must be an integer.

Usage Guidelines Use this command to configure the license parameters for the VNF registration.

license smart renew

Configures the license parameters for the VNF renewal.

Command Modes	Exec
Syntax Description	license smart renew { ID auth }
	renew Renew the smart agent IDs and authentication.
	ID Specify to renew the smart agent license registration information.

auth
Initiate the manual update of the license usage information with Cisco.

Usage Guidelines Use this command to configure the license parameters for the VNF renewal.

local-instance

Configures GR instance for current instance.

Command Modes	Exec > Global Configuration
Syntax Description	local-instance instance gr_instance_id
	instance gr_instance_id Specify the GR instance ID of current instance.

Usage Guidelines Use this command to configure GR instance for current instance.

logging async application enable

Enables async logging.

Command Modes	Exec > Global Configuration (config)
Syntax Description	logging async application enable buffer-size buffer_size
Syntax Description	logging async monitor-subscriber enable buffer-size buffer_size
Syntax Description	logging async tracing enable buffer-size buffer_size
Syntax Description	logging async transaction enable buffer-size buffer_size
	buffer-size buffer_size Specify the buffer size for async logging.

logging async monitor-subscriber enable

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging async monitor-subscriber enable

Enables async logging.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging async application enable buffer-size buffer_size`

Syntax Description `logging async monitor-subscriber enable buffer-size buffer_size`

Syntax Description `logging async tracing enable buffer-size buffer_size`

Syntax Description `logging async transaction enable buffer-size buffer_size`

buffer-size *buffer_size*

Specify the buffer size for async logging.

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging async tracing enable

Enables async logging.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging async application enable buffer-size buffer_size`

Syntax Description `logging async monitor-subscriber enable buffer-size buffer_size`

Syntax Description `logging async tracing enable buffer-size buffer_size`

Syntax Description `logging async transaction enable buffer-size buffer_size`

buffer-size *buffer_size*

Specify the buffer size for async logging.

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging async transaction enable

Enables async logging.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging async application enable buffer-size buffer_size`

Syntax Description `logging async monitor-subscriber enable buffer-size buffer_size`

Syntax Description `logging async tracing enable buffer-size buffer_size`

Syntax Description `logging async transaction enable buffer-size buffer_size`

buffer-size *buffer_size*

Specify the buffer size for async logging.

Must be an integer.

Usage Guidelines Use this command to enable async logging.

logging error

Configures error logging parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging error stack status`

stack *status*

Specify to enable or disable error stack.

Must be one of the following:

- **disable**
- **enable**

Default Value: enable.

Usage Guidelines Use this command to configure error logging parameters.

logging level

Configures the logging level.

Command Modes Exec > Global Configuration (config)

Syntax Description

```
logging level logging_level { [ application application_log_level ] [ monitor-subscriber monitor_subscriber_log_level ] [ tracing tracing_log_level ] [ transaction transaction_log_level ] }
```

application *application_log_level*

Specify the application logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

monitor-subscriber *monitor_subscriber_log_level*

Specify the monitor subscriber logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

tracing *tracing_log_level*

Specify the tracing logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

transaction transaction_log_level

Specify the transaction logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

Usage Guidelines Use this command to configure the logging level.

logging logger

Configures the log name.

Command Modes Exec > Global Configuration (config)

Syntax Description **logging name** *log_name*

name log_name

Specify the log name in "module.component.interface" format.

Must be a string.

Usage Guidelines Use this command to configure the log name.

logging logger level

Configures the logging level.

Command Modes Exec > Global Configuration (config)

Syntax Description **logging level** *logging_level* { [**application** *application_log_level*] [**monitor-subscriber** *monitor_subscriber_log_level*] [**tracing** *tracing_log_level*] [**transaction** *transaction_log_level*] }

application application_log_level

Specify the application logging level.

Must be one of the following:

- **debug**

logging logger level

- **error**
- **info**
- **off**
- **trace**
- **warn**

monitor-subscriber *monitor_subscriber_log_level*

Specify the monitor subscriber logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

tracing *tracing_log_level*

Specify the tracing logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

transaction *transaction_log_level*

Specify the transaction logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**

- **trace**
- **warn**

Usage Guidelines Use this command to configure the logging level.

logging transaction

Configures the transaction logging parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `logging transaction { duplicate | message | persist } { disable | enable }`

duplicate { enable | disable }

Specify whether to enable or disable duplicate logs in transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

max-file-size *max_file_size*

Specify the maximum transaction file size in MB.

Must be an integer in the range of 1-10000.

Default Value: 50.

max-rotation *max_rotations*

Specify the maximum number of file rotations.

Must be an integer in the range of 2-1000.

Default Value: 10.

message { enable | disable }

Specify whether to enable or disable messages in transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

logout**`persist{ enable | disable }`**

Specify whether to enable or disable file-based transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines	Use this command to configure the transaction logging parameters.
-------------------------	---

logout

Logout a specific session or a specific user from all sessions.

Command Modes	Exec
----------------------	------

Syntax Description	<code>logout [session session_id user user_name]</code>
---------------------------	--

`session session_id`

Specify the session ID from the possible completion options.

Must be a string.

`user user_name`

Specify the user name or the user process from the possible completion options.

Must be a string.

Usage Guidelines	Use this command to log out a specific session or a specific user from all sessions.
-------------------------	--

monitor protocol

Configures the SMF to monitor the protocol.

Command Modes	Exec
----------------------	------

Syntax Description	<code>monitor protocol interface interface_name [capture-duration duration]</code>
---------------------------	---

`interface interface_name`

Specify the name of interface on which PCAP is captured.

Must be a string.

`capture-duration duration`

Specify the duration, in seconds, during which PCAP is captured. The default value is 300 seconds.

Must be an integer.

Usage Guidelines	Use this command to monitor the protocol.
-------------------------	---

monitor subscriber

Configures the SMF to monitor the subscribers.

Command Modes	Exec
----------------------	------

Syntax Description	<code>monitor subscriber supi <i>supi</i> [capture-duration <i>duration</i>] subscriber-dump filename <i>file_name</i> subscriber-list</code>
---------------------------	---

supi *supi*

Specify the subscriber identifier.

Must be a string.

capture-duration *duration*

Specify the duration, in seconds, during which PCAP is captured. The default value is 300 seconds.

Must be an integer.

filename *file_name*

Specify the path of the file name to be dumped.

Must be a string.

Usage Guidelines	Use this command to monitor the subscribers.
-------------------------	--

nf-tls ca-certificates

Configure CA certificate parameters.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	<code>nf-tls ca-certificates <i>cert_alias_name</i> cert-data <i>cert_data</i></code>
---------------------------	---

ca-certificates *cert_alias_name*

Specify the alias name of the certificate.

Must be a string.

cert-data *cert_data*

Specify the certificate data in PEM format.

Must be a string.

nf-tls certificate-status

Usage Guidelines Configures TLS keystore configuration for interfaces. Use this command to configure CA certificate parameters.

nf-tls certificate-status

Displays certificate status information.

Command Modes Exec

Syntax Description **show nf-tls certificate-status**

Usage Guidelines Use this command to view certificate status information.

nf-tls certificates

Configures certificate parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **nf-tls certificates cert_alias_name cert-data cert_data private-key private_key**

cert-data cert_data

Specify the certificate data in PEM format.

Must be a string.

certificates cert_alias_name

Specify the alias name of the certificate.

Must be a string.

private-key private_key

Specify the certificate private key in PEM format.

Must be a string.

Usage Guidelines Configures TLS keystore configuration for interfaces. Use this command to configure certificate parameters.

no

Restores the command history cache size to its default setting. See the [history](#) command.

Command Modes Exec

Syntax Description **no history**

Usage Guidelines	Use this command to configure the command history cache size to its default setting. For more details, see the history command.
-------------------------	---

paginate

Configures whether or not to paginate CLI command output.

Command Modes	Exec
----------------------	------

Syntax Description	<code>paginate { false true }</code>
---------------------------	--

{ false | true }

Specify false to disable paginating CLI command output, and true to enable.

Must be either "false" or "true".

Usage Guidelines	Use this command to paginate the command output.
-------------------------	--

profile aaa

Configures AAA profiles.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	<code>profile aaa aaa_profile_name</code>
---------------------------	---

aaa_profile_name

Specify name of the AAA profile.

Must be a string of 1-128 characters.

Usage Guidelines	Use this command to configure AAA profiles. Enters the AAA Profile Configuration mode (config-aaa-aaa_<profile_name>).
-------------------------	--

profile aaa accounting

Configures accounting configuration parameters.

Command Modes	Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name)
----------------------	--

Syntax Description	<code>accounting method-order method_list_order</code>
---------------------------	--

method-order method_list_order

Specify the method list order.

Must be one of the following:

profile aaa authentication

- **radius**

-Or-

Must be a string of 1-128 characters.

You can configure a maximum of three elements with this keyword.

Usage Guidelines	Use this command to configure accounting configuration parameters.
-------------------------	--

profile aaa authentication

Configures authentication parameters.

Command Modes	Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name)
----------------------	--

Syntax Description	authentication method-order method_list_order
---------------------------	--

method-order method_list_order

Specify the method list order.

Must be one of the following:

- **radius**

-Or-

Must be a string of 1-128 characters.

You can configure a maximum of three elements with this keyword.

Usage Guidelines	Use this command to configure authentication parameters.
-------------------------	--

profile aaa authorization

Configures authorization parameters.

Command Modes	Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name)
----------------------	--

Syntax Description	authorization [password default_password]
---------------------------	--

password default_password

Specify the default password.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines	Use this command to configure AAA authorization parameters. The CLI prompt changes to the Authorization Configuration mode (config-authorization).
-------------------------	--

profile aaa authorization type subscriber

Configures authorization type subscriber.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name) > Authorization Configuration (config-authorization)

Syntax Description **type subscriber method-order** *method_list_order*

method-order *method_list_order*

Specify the method list order.

Must be one of the following:

- **radius**

-Or-

Must be a string of 1-128 characters.

You can configure a maximum of three elements with this keyword.

Usage Guidelines Use this command to configure authorization type subscriber.

profile aaa authorization username

Configures the default user name.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name) > Authorization Configuration (config-authorization)

Syntax Description **username { format attribute_format | identifier identifier_type | value user_name }**

format attribute_format

Specify the attribute format.

identifier identifier_type

Specify the identifier type.

Must be one of the following:

- **addr**
- **circuit-id-tag**
- **client-mac-address-custom1**
- **client-mac-address-custom2**

profile aaa authorization username

- **client-mac-address-ietf**
- **client-mac-address-raw**
- **client-mac-address**
- **dhcp-client-id-spl**
- **dhcp-client-id**
- **dhcp-user-class**
- **dhcp-vendor-class**
- **dhcpv4-client-id-spl**
- **dhcpv4-vendor-class**
- **dhcpv6-client-id-ent-ident**
- **dhcpv6-interface-id**
- **dhcpv6-vendor-class-string**
- **inner-vlan-id**
- **outer-vlan-id**
- **physical-adapter**
- **physical-chassis**
- **physical-port**
- **physical-slot**
- **physical-subslot**
- **port-type**
- **pppoe-session-id**
- **remote-id-tag**
- **service-name**
- **user-plane**
- **username**

value *user_name*

Specify the user name.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the default user name.

profile attribute-format

Configures AAA attribute templates.

Command Modes Exec > Global Configuration (config)

Syntax Description `profile attribute-format profile_name [format-order attributes format-string format_string]`

format-order *attributes*

Specify the ordered list of attributes.

Must be one of the following:

- **addr**
- **circuit-id-tag**
- **client-mac-address-custom1**
- **client-mac-address-custom2**
- **client-mac-address-ietf**
- **client-mac-address-raw**
- **client-mac-address**
- **dhcp-client-id-spl**
- **dhcp-client-id**
- **dhcp-user-class**
- **dhcp-vendor-class**
- **dhcpv4-client-id-spl**
- **dhcpv4-vendor-class**
- **dhcpv6-client-id-ent-ident**
- **dhcpv6-interface-id**
- **dhcpv6-vendor-class-string**
- **inner-vlan-id**
- **outer-vlan-id**
- **physical-adapter**
- **physical-chassis**
- **physical-port**
- **physical-slot**

profile coa

- **physical-subslot**
- **port-type**
- **pppoe-session-id**
- **remote-id-tag**
- **service-name**
- **user-plane**
- **username**

-Or-

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of 32 elements with this keyword.

format-string format_string

Specify the format pattern. For example, %sdelimiter%*sdelimiter*%s.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

profile_name

Specify name of the profile.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure AAA attribute templates. The CLI prompt changes to the Attribute Format Configuration mode (config-attribute-format-<name>).

profile coa

Configures RADIUS Dynamic-author/COA parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

profile coa [server-key *server_shared_secret_key*]

server-key server_shared_secret_key

Specify the COA server shared secret key.

Must be a string.

Usage Guidelines

Use this command to configure RADIUS Dynamic-author/COA parameters. The CLI prompt changes to the COA Profile Configuration mode (config-coa).

profile coa client

Configures RADIUS COA client parameters.

Command Modes Exec > Global Configuration (config) > COA Profile Configuration (config-coa)

Syntax Description **client** *client_ip_address* **server-key** *client_shared_secret_key*

server-key *client_shared_secret_key*

Specify the client shared secret key.

Must be a string.

client_ip_address

Specify the IP address of the client.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure RADIUS COA client parameters.

profile dhcp

Configures DHCP profile.

Command Modes Exec > Global Configuration (config)

Syntax Description **profile** **dhcp** *dhcp_profile_name*

dhcp *dhcp_profile_name*

Specify name of the DHCP profile.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure DHCP profiles. Enters the DHCP Profile Configuration mode (config-dhcp-<profile_name>).

profile dhcp ipv4

Configures DHCP IPv4 parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-*profile_name*)

profile dhcp ipv4 class**Syntax Description** **ipv4 [mode *dhcp_mode*]****mode *dhcp_mode***

Specify the DHCP server or proxy mode.

Must be one of the following:

- proxy
- server

Default Value: server.

Usage Guidelines Use this command to configure DHCP IPv4 parameters. Enters the DHCP IPv4 Configuration mode (config-ipv4).

profile dhcp ipv4 class

Configures DHCP IPv4 class configuration parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4)**Syntax Description** **class *dhcp_class_name******dhcp_class_name***

Specify name of the DHCP class.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure DHCP IPv4 class configuration parameters. Enters the DHCP Class Configuration mode.

profile dhcp ipv4 class matches

Configures the list of match values.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name)**Syntax Description** **matches [match-type *match_type*]*****match-type* *match_type***

Specify to match any or match all.

Must be one of the following:

- all

- **any**

Usage Guidelines Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile dhcp ipv4 class matches match

Configures match key and value.

Command Modes Exec > Global Configuration (config) > DHCP Configuration (config-dhcp-profile_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Syntax Description **match** *match_key* { **ascii** *ascii_string* | **hex** *hex_string* }

ascii ascii_string

Specify the ASCII strings.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

hex hex_string

Specify the hexadecimal string.

Must be a string of 1-128 characters.

You can configure a maximum of eight elements with this keyword.

match match_key

Specify the match key.

Must be one of the following:

- **dhcpv4-circuit-id**
- **dhcpv4-remote-id**
- **dhcpv4-user-class**
- **dhcpv4-vendor-class**

Usage Guidelines Use this command to configure match key and value.

profile dhcp ipv4 class server

Configures DHCP server mode parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4)

profile dhcp ipv4 class server

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name)
Syntax Description	<pre>server [boot-filename boot_file_name dns-servers ip_address domain-name domain_name netbios-name-server ip_address next-server ip_address ntp-servers ntp_servers pool-name pool_name]</pre> <p>boot-filename <i>boot_file_name</i> Specify name of the boot file. Must be a string of 1-128 characters.</p> <p>dns-servers <i>ip_address</i> Specify the DNS server IP addresses. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter. You can configure a maximum of eight elements with this keyword.</p> <p>domain-name <i>domain_name</i> Specify the domain name. Must be a string of 1-128 characters.</p> <p>netbios-name-server <i>ip_address</i> Specify the NetBIOS name server IP addresses. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter. You can configure a maximum of eight elements with this keyword.</p> <p>next-server <i>ip_address</i> Specify the TFTP server IP address to be used by the client. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter.</p> <p>ntp-servers <i>ntp_servers</i> Specify the NTP servers. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter. You can configure a maximum of eight elements with this keyword.</p> <p>pool-name <i>pool_name</i> Specify name of the pool. Must be a string of 1-128 characters.</p>

Usage Guidelines	Use this command to configure the DHCP server mode parameters. Enters the DHCP Server Configuration mode.
-------------------------	---

profile dhcp ipv4 class server hold-time

Configures the hold time.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)
----------------------	---

Syntax Description	hold-time minutes hold_time_minutes
---------------------------	--

minutes hold_time_minutes

Specify the hold time in minutes.

Must be an integer in the range of 1-59.

Usage Guidelines	Use this command to configure the hold time in minutes.
-------------------------	---

profile dhcp ipv4 class server lease

Configures DHCP Server Lease parameters.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)
----------------------	---

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)
----------------------	---

Syntax Description	lease { [days days] [hours hours] [minutes minutes] }
---------------------------	--

days days

Specify the number of days.

Must be an integer in the range of 0-365.

hours hours

Specify the hours.

Must be an integer in the range of 0-23.

minutes minutes

Specify the minutes.

Must be an integer in the range of 0-59.

profile dhcp ipv4 class server netbios-node-type

Usage Guidelines Use this command to configure the DHCP Server Lease parameters.

profile dhcp ipv4 class server netbios-node-type

Configures NetBIOS node type.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description `netbios-name-server { broadcast-node | hexadecimal hex_number | hybrid-node | mixed-node | peer-to-peer-node }`

broadcast-node

Specify broadcast node.

hexadecimal hex_number

Specify the hexadecimal number.

Must be a string of 2 characters.

hybrid-node

Specify hybrid node.

mixed-node

Specify mixed node.

peer-to-peer-node

Specify peer-to-peer node.

Usage Guidelines Use this command to configure the NetBIOS node type.

profile dhcp ipv4 class server option-codes

Configures the OptionCode table.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description	option-codes
---------------------------	---------------------

Usage Guidelines	Use this command to configure the OptionCode table. Enters the Option Codes Configuration mode (config-option-codes).
-------------------------	---

profile dhcp ipv4 class server option-codes option-code

Configures a DHCP option code.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)
----------------------	--

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)
----------------------	--

Syntax Description	option-code <i>dhcp_option_code</i> [ascii-string <i>ascii_string</i> force-insert { false true } hex-string <i>hex_string</i> ip-address <i>ip_address</i>]
---------------------------	---

ascii-string *ascii_string*

Specify the ASCII string.

Must be a string of 1-128 characters.

force-insert { **false** | **true** }

Specify whether to force insert this option.

Must be one of the following:

- **false**
- **true**

hex-string *hex_string*

Specify the hexadecimal string.

Must be a string of 1-128 characters in the pattern ([0-9a-fA-F]{2}([0-9a-fA-F]{2}))?.

ip-address *ip_address*

Specify the server's IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

option-code *dhcp_option_code*

Specify the DHCP option code.

profile dhcp ipv4 class server static-ip-key

Must be an integer in the range of 0-255.

Usage Guidelines

Use this command to configure a DHCP option code. Enters the Option Code Configuration mode.

profile dhcp ipv4 class server static-ip-key

Configures the Static IP Key.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Syntax Description

static-ip-key identifier identifier_type

identifier identifier_type

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines

Use this command to configure the Static IP Key. The CLI prompt changes to the Static IP Key Configuration mode (config-static-ip-key).

profile dhcp ipv4 server

Configures DHCP server mode parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name)

Syntax Description

server [boot-filename boot_file_name | dns-servers ip_address | domain-name domain_name | netbios-name-server ip_address | next-server ip_address | ntp-servers ntp_servers | pool-name pool_name]

boot-filename boot_file_name

Specify name of the boot file.

Must be a string of 1-128 characters.

dns-servers ip_address

Specify the DNS server IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

domain-name *domain_name*

Specify the domain name.

Must be a string of 1-128 characters.

netbios-name-server *ip_address*

Specify the NetBIOS name server IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

next-server *ip_address*

Specify the TFTP server IP address to be used by the client.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

ntp-servers *ntp_servers*

Specify the NTP servers.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

pool-name *pool_name*

Specify name of the pool.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure the DHCP server mode parameters. Enters the DHCP Server Configuration mode.

profile dhcp ipv4 server hold-time

Configures the hold time.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Syntax Description

hold-time minutes *hold_time_minutes*

minutes *hold_time_minutes*

Specify the hold time in minutes.

profile dhcp ipv4 server lease

Must be an integer in the range of 1-59.

Usage Guidelines	Use this command to configure the hold time in minutes.
-------------------------	---

profile dhcp ipv4 server lease

Configures DHCP Server Lease parameters.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)
Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description	lease { [days days] [hours hours] [minutes minutes] }
---------------------------	--

days days

Specify the number of days.

Must be an integer in the range of 0-365.

hours hours

Specify the hours.

Must be an integer in the range of 0-23.

minutes minutes

Specify the minutes.

Must be an integer in the range of 0-59.

Usage Guidelines	Use this command to configure the DHCP Server Lease parameters.
-------------------------	---

profile dhcp ipv4 server netbios-node-type

Configures NetBIOS node type.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)
Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description	netbios-name-server { broadcast-node hexadecimal hex_number hybrid-node mixed-node peer-to-peer-node }
---------------------------	---

broadcast-node

Specify broadcast node.

hexadecimal hex_number

Specify the hexadecimal number.

Must be a string of 2 characters.

hybrid-node

Specify hybrid node.

mixed-node

Specify mixed node.

peer-to-peer-node

Specify peer-to-peer node.

Usage Guidelines

Use this command to configure the NetBIOS node type.

profile dhcp ipv4 server option-codes

Configures the OptionCode table.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description

option-codes

Usage Guidelines

Use this command to configure the OptionCode table. Enters the Option Codes Configuration mode (config-option-codes).

profile dhcp ipv4 server option-codes option-code

Configures a DHCP option code.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

```
profile dhcp ipv4 server static-ip-key
```

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

Syntax Description `option-code dhcp_option_code [ascii-string ascii_string | force-insert { false | true } | hex-string hex_string | ip-address ip_address]`

ascii-string *ascii_string*

Specify the ASCII string.

Must be a string of 1-128 characters.

force-insert{ false | true }

Specify whether to force insert this option.

Must be one of the following:

- **false**

- **true**

hex-string *hex_string*

Specify the hexadecimal string.

Must be a string of 1-128 characters in the pattern ([0-9a-fA-F]{2}([0-9a-fA-F]{2})*)?.

ip-address *ip_address*

Specify the server's IP addresses.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

option-code *dhcp_option_code*

Specify the DHCP option code.

Must be an integer in the range of 0-255.

Usage Guidelines Use this command to configure a DHCP option code. Enters the Option Code Configuration mode.

profile dhcp ipv4 server static-ip-key

Configures the Static IP Key.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > IPv4 Configuration (config-ipv4) > Server Configuration Mode (config-server)

Syntax Description `static-ip-key identifier identifier_type`

identifier *identifier_type*

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines

Use this command to configure the Static IP Key. The CLI prompt changes to the Static IP Key Configuration mode (config-static-ip-key).

profile dhcp ipv6

Configures DHCP IPv6 parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name)

Syntax Description

ipv6 [mode *dhcp_mode*]

mode *dhcp_mode*

Specify the DHCP mode server or proxy.

Must be one of the following:

- **proxy**
- **server**

Default Value: server.

Usage Guidelines

Use this command to configure DHCP IPv6 parameters. Enters the DHCP IPv6 Configuration mode.

profile dhcp ipv6 class

Configures DHCP IPv6 class configuration parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description

class *dhcp_class_name*

dhcp_class_name

Specify name of the DHCP class.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure DHCP IPv6 class configuration parameters.

profile dhcp ipv6 class server

profile dhcp ipv6 class server

Configures DHCP server mode parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name)

Syntax Description

```
server { aftr-name aftr_name | dns-servers ip_address | domain-name domain_name
          | iana-pool-name iana_pool_name | iapd-pool-name iapd_pool_name | preference
          server_preference | rapid-commit }
```

aftr-name *aftr_name*

Specify name of the Address Family Transition Router (AFTR).

Must be a string of 1-128 characters.

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

domain-name *domain_name*

Specify the domain name.

Must be a string of 1-128 characters.

iana-pool-name *iana_pool_name*

Specify name of the IANA pool.

Must be a string of 1-128 characters.

iapd-pool-name *iapd_pool_name*

Specify name of the IAPD pool.

Must be a string of 1-128 characters.

preference *server_preference*

Specify the DHCP server preference.

Must be an integer in the range of 1-255.

rapid-commit

Specify to allow rapid commit.

Usage Guidelines	Use this command to configure the DHCP server mode parameters.
-------------------------	--

profile dhcp ipv6 class server hold-time

Configures the hold time.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)
----------------------	--

Syntax Description	hold-time minutes hold_time_minutes
---------------------------	--

minutes hold_time_minutes

Specify the hold time in minutes.

Must be an integer in the range of 1-59.

Usage Guidelines	Use this command to configure the hold time in minutes.
-------------------------	---

profile dhcp ipv6 class server lease

Configures the lease parameters.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Server Configuration Mode (config-server)
----------------------	--

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)
----------------------	--

Syntax Description	lease { [days days] [hours hours] [minutes minutes] }
---------------------------	--

days days

Specify the number of days.

Must be an integer in the range of 0-365.

hours hours

Specify the hours.

Must be an integer in the range of 0-23.

minutes minutes

Specify the minutes.

profile dhcp ipv6 class server static-ip-key

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure lease parameters.

profile dhcp ipv6 class server static-ip-key

Configures the Static IP Key.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description **static-ip-key identifier identifier_type**

identifier identifier_type

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines Use this command to configure the Static IP Key.

profile dhcp ipv6 server

Configures DHCP server mode parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name)

Syntax Description **server { aftr-name aftr_name | dns-servers ip_address | domain-name domain_name | iana-pool-name iana_pool_name | iapd-pool-name iapd_pool_name | preference server_preference | rapid-commit }**

aftr-name aftr_name

Specify name of the Address Family Transition Router (AFTR).

Must be a string of 1-128 characters.

dns-servers ip_address

Specify the DNS server IP addresses.

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

domain-name *domain_name*

Specify the domain name.

Must be a string of 1-128 characters.

iana-pool-name *iana_pool_name*

Specify name of the IANA pool.

Must be a string of 1-128 characters.

iapd-pool-name *iapd_pool_name*

Specify name of the IAPD pool.

Must be a string of 1-128 characters.

preference *server_preference*

Specify the DHCP server preference.

Must be an integer in the range of 1-255.

rapid-commit

Specify to allow rapid commit.

Usage Guidelines

Use this command to configure the DHCP server mode parameters.

profile dhcp ipv6 server hold-time

Configures the hold time.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile-name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description

hold-time minutes *hold_time_minutes*

minutes *hold_time_minutes*

Specify the hold time in minutes.

Must be an integer in the range of 1-59.

Usage Guidelines

Use this command to configure the hold time in minutes.

profile dhcp ipv6 server lease

Configures the lease parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile-name) > DHCP IPv6 Configuration (config-ipv6) > Server Configuration Mode (config-server)

profile dhcp ipv6 server static-ip-key

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6) > Class Configuration (config-class-class_name) > Server Configuration Mode (config-server)

Syntax Description **lease { [days days] [hours hours] [minutes minutes] }**

days days

Specify the number of days.

Must be an integer in the range of 0-365.

hours hours

Specify the hours.

Must be an integer in the range of 0-23.

minutes minutes

Specify the minutes.

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure lease parameters.

profile dhcp ipv6 server static-ip-key

Configures the Static IP Key.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description **static-ip-key identifier identifier_type**

identifier identifier_type

Specify the identifier type.

Must be one of the following:

- **client-mac-address**

Usage Guidelines Use this command to configure the Static IP Key.

profile feature-template

Configures feature template profile.

Command Modes Exec > Global Configuration (config)

Syntax Description

feature-template *feature_template_name* [[**vrf-name** *vrf_name*] [**httpr-policy** *httpr_policy_name*]]

feature-template *feature_template_name*

Specify name of the feature template.

Must be a string of 1-128 characters.

httpr-policy *httpr_policy_name*

Specify name of the PBR HTTPR policy.

Must be a string of 1-128 characters.

vrf-name *vrf_name*

Specify name of the VRF.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure feature template profiles. The CLI prompt changes to the Feature Template Configuration mode (config-feature-template-<template_name>)

profile feature-template ipv4

Configures IPv4 features.

Command Modes

Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*)

Syntax Description

ipv4 [**mtu** *maximum_transmission_unit* | **ingress-acl** *ingress_ipv4_acl_name* | **egress-acl** *egress_ipv4_acl_name* | **disable-unreachables**]

disable-unreachables

Specify to disable sending ICMP Unreachable messages.

egress-acl *egress_ipv4_acl_name*

Specify name of the egress IPV4 ACL.

Must be a string of 1-128 characters.

ingress-acl *ingress_ipv4_acl_name*

Specify name of the ingress IPV4 ACL.

Must be a string of 1-128 characters.

mtu *maximum_transmission_unit*

Specify the Maximum Transmission Unit in bytes.

Must be an integer in the range of 68-65535.

profile feature-template ipv4 verify-unicast-source

Usage Guidelines

Use this command to configure IPv4 features. The CLI prompt changes to the IPv4 Configuration mode (config-ipv4).

profile feature-template ipv4 verify-unicast-source

Enables per-packet validation for unicast.

Command Modes

Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > IPv4 Configuration (config-ipv4)

Syntax Description

verify-unicast-source reachable-via-rx

reachable-via-rx

Specify the source is reachable via interface on which packet was received.

Usage Guidelines

Use this command to enable per-packet validation for unicast.

profile feature-template ipv6

Configures IPv6 features.

Command Modes

Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*)

Syntax Description

ipv6 [[egress-acl *egress_ipv6_acl_name*] [ingress-acl *ingress_ipv6_acl_name*] [mtu *maximum_transmission_unit*]]

disable-unreachables

Specify to disable sending ICMP Unreachable messages.

egress-acl *egress_ipv6_acl_name*

Specify name of the egress IPV6 ACL.

Must be a string of 1-128 characters.

ingress-acl *ingress_ipv6_acl_name*

Specify name of the ingress IPV6 ACL.

Must be a string of 1-128 characters.

mtu *maximum_transmission_unit*

Specify the Maximum Transmission Unit in bytes.

Must be an integer in the range of 1280-65535.

Usage Guidelines	Use this command to configure IPv6 features. The CLI prompt changes to the IPv6 Configuration mode (config-ipv6).
-------------------------	---

profile feature-template ipv6 verify-unicast-source

Configures per packet validation for unicast.

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>) > IPv6 Configuration (config-ipv6)
----------------------	---

Syntax Description	verify-unicast-source [reachable-via-rx]
---------------------------	---

reachable-via-rx

Specify source is reachable via interface on which packet was received.

Usage Guidelines	Use this command to configure per packet validation for unicast.
-------------------------	--

profile feature-template ppp

Configures the PPP authentication parameters.

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>)
----------------------	--

Syntax Description	ppp authentication <i>authentication_method</i> [[max-bad-auth <i>max_auth_failures</i>] [max-configure <i>max_configure</i>] [max-failure <i>max_conf_naks</i>] [service-type <i>service_type</i>]]
---------------------------	---

authentication *authentication_method*

Specify the authentication method.

Must be one of the following:

- **chap**
- **pap**

You can configure a maximum of two elements with this keyword.

max-bad-auth *max_auth_failures*

Specify the maximum authentication failures to allow.

Must be an integer in the range of 0-10.

max-configure *max_configure*

Specify the maximum conf-reqs to send without response.

Must be an integer in the range of 1-10.

```
profile feature-template ppp chap
```

max-failure *max_conf_naks*

Specify the maximum conf-naks to receive.

Must be an integer in the range of 1-5.

service-type *service_type*

Specify the service type.

Must be one of the following:

- **outbound**

Usage Guidelines

Use this command to configure the PPP authentication parameters. The CLI prompt changes to the PPP Configuration mode (config-ppp).

profile feature-template ppp chap

Configures CHAP parameters.

Command Modes

Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description

```
chap hostname chap_host_name password chap_password
```

hostname *chap_host_name*

Specify the CHAP host name.

Must be a string of 1-128 characters of 1-128 characters.

password *chap_password*

Specify the CHAP password.

Must be a string.

Usage Guidelines

Use this command to configure CHAP parameters.

profile feature-template ppp ipcp

Configures PPP IPCP negotiation parameters.

Command Modes

Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description

```
ipcp [ peer-address-pool peer_address_pool_name ]
```

peer-address-pool *peer_address_pool_name*

Specify name of the peer-address pool.

Must be a string of 1-128 characters of 1-128 characters.

Usage Guidelines	Use this command to configure PPP IPCP negotiation parameters.
-------------------------	--

profile feature-template ppp ipcp dns

Configures DNS address to be used for peer.

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>) > PPP Configuration (config-ppp)
----------------------	---

Syntax Description	ipcp dns primary-address <i>primary_address</i> secondary-address <i>secondary_address</i>
---------------------------	---

primary-address *primary_address*

Specify the primary address. The first address is considered as Primary and second address as Secondary.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

secondary-address *secondary_address*

Specify the secondary address.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines	Use this command to configure DNS address to be used for peer.
-------------------------	--

profile feature-template ppp ipcp renegotiation

Configures renegotiation parameters.

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>) > PPP Configuration (config-ppp)
----------------------	---

Syntax Description	ipcp renegotiation ignore
---------------------------	----------------------------------

ignore

Specify to ignore attempts by the peer to renegotiate LCP.

Usage Guidelines	Use this command to configure renegotiation parameters.
-------------------------	---

profile feature-template ppp ipcp wins

Configures WINS address to be used for peer.

profile feature-template ppp ipv6cp renegotiation

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>) > PPP Configuration (config-ppp)
Syntax Description	<p>ipcp wins primary-address <i>primary_ip_address</i> secondary-address <i>secondary_ip_address</i></p> <p>primary-address <i>primary_ip_address</i> Specify the primary address. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter.</p> <p>secondary-address <i>secondary_ip_address</i> Specify the secondary address. Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the <i>Input Pattern Types</i> chapter.</p>
Usage Guidelines	Use this command to configure WINS address to be used for peer.

profile feature-template ppp ipv6cp renegotiation

Configures renegotiation parameters.

Command Modes	Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template- <i>template_name</i>) > PPP Configuration (config-ppp)
Syntax Description	<p>ipv6cp renegotiation ignore</p> <p>ignore Specify to ignore attempts by the peer to renegotiate LCP.</p>
Usage Guidelines	Use this command to configure renegotiation parameters.

profile feature-template ppp keepalive

Configures PPP Keepalive parameters.

Command Modes	Exec > Global Configuration
Syntax Description	<p>keepalive { disable interval <i>keepalive_interval</i> retry <i>keepalive_retries</i> }</p> <p>disable Specify to disable PPP keepalive.</p> <p>interval <i>keepalive_interval</i> Specify the keepalive interval in minutes.</p>

Must be an integer in the range of 10-120.

retry *keepalive_retries*

Specify the number of keepalive retries.

Must be an integer in the range of 1-255.

Usage Guidelines

Use this command to configure PPP Keepalive parameters.

profile feature-template ppp lcp delay

Configures the time to delay before starting active LCP negotiations.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **delay seconds *delay_value* milliseconds *delay_value***

milliseconds *delay_value*

Specify the delay value in milliseconds.

Must be an integer in the range of 0-70000000.

seconds *delay_value*

Specify the delay value in seconds.

Must be an integer in the range of 0-255.

Usage Guidelines Configures LCP global configuration parameters. Use this command to configure the time to delay before starting active LCP negotiations.

profile feature-template ppp lcp renegotiation

Configures LCP renegotiation.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **lcp renegotiation ignore**

ignore

Specify to ignore attempts by the peer to renegotiate LCP.

Usage Guidelines Use this command to configure LCP renegotiation.

profile feature-template ppp pap

profile feature-template ppp pap

Configures PAP parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **pap accept-null-password**

accept-null-password

Specify to accept null-password.

Usage Guidelines Use this command to configure PAP parameters.

profile feature-template ppp timeout

Configures PPP timeout parameters.

Command Modes Exec > Global Configuration (config) > Endpoint N4 Protocol Configuration (config-endpoint-n4-protocol)

Syntax Description **retransmission timeout total_auth_complete_time [retry max_response_time]**

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **timeout { [authentication total_auth_complete_time] [retry max_response_time] }**

authentication total_auth_complete_time

Specify the total time to allow for authentication to complete.

Must be an integer in the range of 3-30.

retry max_response_time

Specify the maximum time to wait for a response to a Conf-Req in seconds.

Must be an integer in the range of 1-10.

Usage Guidelines Use this command to configure PPP timeout parameters.

profile feature-template ppp timeout absolute

Configures the absolute timeout period for a PPP session.

Command Modes Exec > Global Configuration (config) > Feature Template Configuration (config-feature-template-*template_name*) > PPP Configuration (config-ppp)

Syntax Description **timeout absolute minutes** *timeout_minutes*

minutes *timeout_minutes*

Specify the timeout period in minutes.

Must be an integer in the range of 0-70000000.

Usage Guidelines Use this command to configure the absolute timeout period for a PPP session.

profile feature-template qos

Configures QoS input policy parameters.

Command Modes Exec > Global Configuration (config) > Feature Template QoS Profile Configuration (config-feature-template-qos)

Syntax Description **qos { [**in-policy** *in_policy_name*] [**out-policy** *out_policy_name*] [**merge-level** *merge_level*] }**

in-policy *in_policy_name*

Specify name of the QOS input policy.

Must be a string of 1-128 characters.

merge-level *merge_level*

Specify the merge level. To disable merge, set to 0. To enable merge and set the level, set to a value greater than 0.

Must be an integer.

out-policy *out_policy_name*

Specify name of the QOS output policy.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure QoS input policy parameters. The CLI prompt changes to the QoS Configuration mode (config-qos).

profile feature-template service-accounting

Configures service accounting parameters.

Command Modes Exec > Global Configuration (config) > Feature Template QoS Profile Configuration (config-feature-template-qos)

profile feature-template session-accounting

Syntax Description **service-accounting enable [[aaa-profile *aaa_profile_name*] [periodic-interval *interim_interval*]]**

aaa-profile *aaa_profile_name*

Specify the AAA profile to use for service accounting.

enable

Specify to enable service accounting.

periodic-interval *interim_interval*

Specify the interim interval in seconds.

Must be an integer in the range of 60-4320000.

Usage Guidelines Use this command to configure service accounting parameters. The CLI prompt changes to the Service Accounting Configuration mode (config-service-accounting).

profile feature-template session-accounting

Configures session accounting parameters.

Command Modes Exec > Global Configuration (config) > Feature Template QoS Profile Configuration (config-feature-template-qos)

Syntax Description **session-accounting enable [[aaa-profile *aaa_profile_name*] [periodic-interval *interim_interval*] [dual-stack-delay *dual_stack_delay_wait*]]**

aaa-profile *aaa_profile_name*

Specify the AAA profile to use for session accounting.

dual-stack-delay *dual_stack_delay_wait*

Specify the dual stack set delay wait in seconds.

Must be an integer in the range of 1-30.

enable

Specify to enable session accounting.

periodic-interval *interim_interval*

Specify the interim interval in seconds.

Must be an integer in the range of 60-4320000.

Usage Guidelines Use this command to configure session accounting parameters. The CLI prompt changes to the Session Accounting Configuration mode (config-session-accounting).

profile l2tp

Configures L2TP subscriber profiles.

Command Modes Exec > Global Configuration (config)

Syntax Description

```
profile l2tp l2tp_profile_name [ [ authentication ] [ force-lcp-renegotiation ]
    ] [ congestion-control ] [ dsl-info-forwarding ] [ encrypt-avp ] [
    hello-interval hello_message_interval ] [ hostname host_name ] [ mode config_mode
    ] [ mtu mtu_for_lcp_negotiation ] [ password tunnel_auth_password ] [ receive-window
    receive_window_size ] [ rx-connect-speed rx_connect_speed ] [
    tunnel-load-balancing method ] [ tx-connect-speed tx_connect_speed ] [ vrf
    vrf_name ] ]
```

authentication

Specify to authenticate the L2TP tunnel.

congestion-control

Specify to enable L2TP Congestion Control.

dsl-info-forwarding

Specify to forward DSL Line Info attributes.

encrypt-avp

Specify to hide AVPs in outgoing control messages.

force-lcp-renegotiation

Specify to force LCP and Auth renegotiation.

hello-interval hello_message_interval

Specify the hello message interval in seconds.

Must be an integer in the range of 10-1000.

hostname host_name

Specify the local host name of the tunnel.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

mode config_mode

Specify the LAC/LNS config mode.

Must be one of the following:

- **lac**: Configures an LAC to request the establishment of an L2TP tunnel to an LNS.

profile l2tp

- **lns**: Configures an LNS to accept requests from LAC to establish L2TP tunnel.

mtu mtu_for_lcp_negotiation

Specify the MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

password tunnel_auth_password

Specify the password for tunnel authentication.

Must be a string.

receive-window receive_window_size

Specify the receive window size for the tunnel.

Must be an integer in the range of 1-5000.

Default Value: 256.

rx-connect-speed rx_connect_speed

Specify the Rx connect speed in kbps.

Must be an integer in the range of 9-100000000.

tunnel-load-balancing method

Specify the Tunnel Load Balancing method.

Must be one of the following:

- **equal**: Equal load sharing.
- **weighted**: Weighted load sharing.

tx-connect-speed tx_connect_speed

Specify the Tx connect speed in kbps.

Must be an integer in the range of 9-100000000.

vrf vrf_name

Specify the VRF of the tunnel.

Must be a string of 1-128 characters.

l2tp_profile_name

Specify the name of the L2TP profile.

Must be a string of 1-128 characters.

Usage Guidelines	Use this command to configure L2TP subscriber profiles. This command enters the L2TP Profile Configuration mode (config-l2tp-<profile_name>).
-------------------------	---

profile l2tp domain

Configures domain matching.

Command Modes	Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp- <i>profile_name</i>)
----------------------	---

Syntax Description	domain <i>domain_name</i> tun-assign-id <i>tunnel_id</i>
---------------------------	--

tun-assign-id *tunnel_id*

Specify the domain name with tunnel ID.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

domain_name

Specify the domain name.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines	Use this command to configure domain matching.
-------------------------	--

You can configure a maximum of 16 elements with this command.

profile l2tp ip-tos

Configures IP ToS value for tunneled traffic.

Command Modes	Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp- <i>profile_name</i>)
----------------------	---

Syntax Description	ip-tos <i>value</i> { <i>service_type</i> reflect }
---------------------------	---

reflect

Specify to reflect IP payload ToS on tunnel.

value service_type

Specify the type of service value.

Must be an integer in the range of 1-255.

Usage Guidelines	Use this command to configure IP ToS value for tunneled traffic.
-------------------------	--

profile l2tp ipv4

profile l2tp ipv4

Configures IPv4 settings for tunnel.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **ipv4 { [df-bit df_bit_state] [source source_ip_address] }**

df-bit *df_bit_state*

Specify the DF Bit parameter.

Must be one of the following:

- **reflect**: Reflects df bit from inner IP header.
- **set**: Configures df bit.

source *source_ip_address*

Specify the source IP address of the tunnel.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure IPv4 settings for tunnel.

profile l2tp ipv4 destination

Configures destination address of tunnel.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **destination dest-ip *dest_ip_address* weight *weight***

dest-ip *dest_ip_address*

Specify the IP address of the destination.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

weight *weight*

Specify the weight for Weighted Load Balancing method.

Must be an integer in the range of 1-65535.

Default Value: 1.

Usage Guidelines Use this command to configure destination address of tunnel.

You can configure a maximum of 64 elements with this command.

profile l2tp retransmit initial

Configures SCCRQ retransmission timeout settings.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **retransmit retries max_retries**

retries max_retries

Specify the maximum number of retries for SCCRQ packets.

Must be an integer in the range of 1-1000.

Default Value: 2.

Usage Guidelines Configures Control message retransmission parameters. Use this command to configure SCCRQ retransmission timeout settings.

profile l2tp retransmit initial timeout

Configures retransmission timeout parameters.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **retransmit timeout max max_timeout min min_timeout**

max max_timeout

Specify the max timeout duration in seconds.

Must be an integer in the range of 1-8.

Default Value: 8.

min min_timeout

Specify the min timeout duration in seconds.

Must be an integer in the range of 1-8.

Default Value: 1.

Usage Guidelines Use this command to configure retransmission timeout parameters.

profile l2tp retransmit timeout

Configures Control packet retransmission timeout parameters.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

profile l2tp tcp

Syntax Description **timeout max max_timeout min min_timeout**

max max_timeout

Specify the maximum timeout duration in seconds.

Must be an integer in the range of 1-32.

Default Value: 8.

min min_timeout

Specify the minimum timeout duration in seconds.

Must be an integer in the range of 1-8.

Default Value: 1.

Usage Guidelines Use this command to configure Control packet retransmission timeout parameters.

profile l2tp tcp

Configures TCP settings.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **tcp adjust-mss mss_value**

adjust-mss mss_value

Specify to adjust the MSS value of TCP SYN packets. Specify the MSS value in bytes.

Must be an integer in the range of 500-1500.

Usage Guidelines Use this command to configure TCP settings.

profile l2tp terminate-from

Configures the host name of the remote peer to accept tunnels.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **profile terminate-from hostname remote_host_name**

hostname remote_host_name

Specify the remote host name.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the host name of the remote peer to accept tunnels.

You can configure a maximum of 16 elements with this command.

profile l2tp tunnel

Configures tunnel parameters.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **tunnel session-limit session_limit**

session-limit session_limit

Specify the maximum number of L2TP sessions per tunnel.

Must be an integer in the range of 1-64000.

Usage Guidelines Use this command to configure tunnel parameters.

profile l2tp tunnel timeout

Configures tunnel deletion after timeout.

Command Modes Exec > Global Configuration (config) > L2TP Profile Configuration (config-l2tp-profile_name)

Syntax Description **tunnel timeout no-session no_session_timeout**

no-session no_session_timeout

Specify the no-session timeout value in seconds.

Must be an integer in the range of 1-86400.

Usage Guidelines Use this command to configure tunnel deletion after timeout.

profile pppoe

Configures PPPOE Subscriber profile.

Command Modes Exec > Global Configuration (config)

Syntax Description **profile pppoe pppoe_profile_name [[ac-cookie ac_cookie] [ac-name ac_name] [ctrl-pkt-priority priority] [mtu pado_delay] [mtu pppoe_mtua] [service-name pppoe_service_names] [service-selection-disable { false | true }] [timeout-completion session_completion_timeout]]**

ac-cookie ac_cookie

Specify the AC-Cookie to use in PADO packets.

profile pppoe

Must be a string of 1-128 characters.

ac-name *ac_name*

Specify the the AC-Name to use in PADO packets.

Must be a string of 1-128 characters.

ctrl-pkt-priority *priority*

Specify the CoS bits to use in PADx packets.

Must be an integer in the range of 0-7.

Default Value: 0.

mtu *pppoe_mtu*

Specify the PPPoE MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

pppoe *pppoe_profile_name*

Specify the name of the PPPOE profile.

Must be a string of 1-128 characters.

service-name *pppoe_service_names*

Specify the supported PPPoE service names. You can simultaneously configure multiple service names.

Must be a string of 1-128 characters.

service-selection-disable { false | true }

Specify to disable or enable the advertising of extra service names in PADO packets.

Must be one of the following:

- **false**
- **true**

Default Value: false.

timeout-completion *session_completion_timeout*

Specify the maximum wait time for session to be completed.

Must be an integer in the range of 3-600.

Default Value: 180.

Usage Guidelines

Use this command to configure PPPOE Subscriber profiles. The CLI prompt changes to the PPPOE Profile Configuration mode (config-pppoe-<profile_name>).

profile pppoe max-payload

Configures a range for the ppp-max payload tag value.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description **max-payload** { [**deny**] | [**maximum** *maximum_payload_value*] [**minimum** *minimum_payload_value*] }

deny

Specify to deny the PPP-max payload value.

maximum *maximum_payload_value*

Specify the maximum payload value.

Must be an integer in the range of 1-40000.

Default Value: 1500.

minimum *minimum_payload_value*

Specify the minimum value for the payload.

Must be an integer in the range of 1-40000.

Default Value: 1492.

Usage Guidelines Use this command to configure a range for the ppp-max payload tag value.

profile pppoe session-limit circuit-id

Configures the maximum number of sessions allowed per Circuit-ID.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description **session-limit** **circuit-id** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per Circuit-ID.

profile pppoe session-limit mac

profile pppoe session-limit mac

Configures the maximum number of sessions allowed per peer MAC address.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description **session-limit mac** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per peer MAC address.

profile pppoe session-limit max

Configures the maximum number of sessions allowed under the PPPoE profile.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description **session-limit max** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed under the PPPoE profile.

profile pppoe session-limit outer-vlan

Configures the maximum number of sessions allowed per outer-vlan, per access interface.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration mode (config-pppoe-profile_name)

Syntax Description `session-limit outer-vlan value [threshold threshold_count]`

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value

Specify the value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per outer-vlan, per access interface.

profile radius

Configures RADIUS client parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `profile radius [[algorithm radius_server_selection_algorithm] [deadtime dead_time] [max-retry max_retry] [timeout retransmit_timeout_duration]]`

algorithm *radius_server_selection_algorithm*

Specify the algorithm for selecting RADIUS server.

Must be one of the following:

- **first-server**: Highest priority first.
- **round-robin**: Round-robin.

deadtime *dead_time*

Specify the time to elapse, in minutes, between RADIUS server marked unreachable and when connection can be re-attempted.

Must be an integer in the range of 0-65535.

max-retry *max_retry*

Specify the maximum number of times the system must attempt retry with the RADIUS server.

Must be an integer in the range of 0-65535.

timeout *retransmit_timeout_duration*

Specify the time duration to wait for response from the RADIUS server before retransmitting.

Must be an integer in the range of 1-65535.

profile radius accounting**Usage Guidelines**

Use this command to configure RADIUS client parameters. The CLI prompt changes to the RADIUS Configuration mode (config-radius).

profile radius accounting

Configures RADIUS accounting parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius)

Syntax Description

```
accounting [ [ algorithm radius_server_selection_algorithm ] [ deadtime dead_time ]
[ max-retry max_retry ] [ timeout retransmit_timeout_duration ] ]
```

algorithm radius_server_selection_algorithm

Specify the algorithm for selecting RADIUS server.

Must be one of the following:

- **first-server**: Highest priority first.
- **round-robin**: Round-robin.

deadtime dead_time

Specify the time to elapse, in minutes, between RADIUS server marked unreachable and when connection can be re-attempted.

Must be an integer in the range of 0-65535.

max-retry max_retry

Specify the maximum number of times the system must attempt retry with the RADIUS server.

Must be an integer in the range of 0-65535.

timeout retransmit_timeout_duration

Specify the time duration to wait for response from the RADIUS server before retransmitting.

Must be an integer in the range of 1-65535.

Usage Guidelines

Use this command to configure RADIUS accounting parameters. The CLI prompt changes to the Accounting Configuration mode (config-accounting).

profile radius accounting attribute

Configures the AAA attribute parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description

```
attribute [ [ nas-identifier nas_identifier ] [ nas-ip nas_ip_address ] ]
```

nas-identifier nas_identifier

Specify the attribute name by which the system will be identified in Access-Request messages.

Must be a string of 1-128 characters of 1-32 characters.

nas-ip nas_ip_address

Specify the IP address of the AAA NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the AAA attribute parameters. The CLI prompt changes to the Attribute Configuration mode (config-attribute).

profile radius accounting attribute called-station-id

Configures the AAA called-station-id attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

`called-station-id { format-name format_name | value }`

format-name format_name

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA called-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the AAA called-station-id attribute.

profile radius accounting attribute called-station-id format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

profile radius accounting attribute calling-station-id

Syntax Description **called-station-id format-name** *format_name* [**nas-port-type** *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting attribute calling-station-id

Configures the AAA calling-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **calling-station-id { format-name** *format_name* **| value }**

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA calling-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA calling-station-id attribute.

profile radius accounting attribute calling-station-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **called-station-id format-name** *format_name* [**nas-port-type** *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting attribute nas-identifier-format

Configures the AAA nas-identifier-format attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

nas-identifier-format format-name *format_name*

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure the AAA nas-identifier-format attribute.

profile radius accounting attribute nas-identifier-format format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

called-station-id format-name *format_name* [nas-port-type *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

profile radius accounting attribute nas-port

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting attribute nas-port

Configures the AAA nas-port attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

nas-port { value | format-e format_e_value }

format-e format_e_value

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLUVQ]*).

value

Specify value of the nas-port attribute.

Must be an integer in the range of 1-maximum.

Usage Guidelines

Use this command to configure the AAA nas-port attribute.

profile radius accounting attribute nas-port format-e-list

Configures the AAA nas-port attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

format-e-list nas-port-type nas_port_type_value format-e format_e_value

format-e format_e_value

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLVQ]*).

nas-port-type nas_port_type_value

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines

Use this command to configure the AAA nas-port attribute.

profile radius accounting attribute nas-port-id

Configures the AAA nas-port-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **nas-port-id { value | format-name format_name }**

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify value of the AAA nas-port-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA nas-port-id attribute.

profile radius accounting attribute nas-port-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **called-station-id *format-name format_name* [nas-port-type *nas_port_type*]**

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius accounting detect-dead-server

profile radius accounting detect-dead-server

Configures parameters to detect a dead RADIUS server.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description **detect-dead-server response-timeout *response_timeout_duration***

response-timeout *response_timeout_duration*

Specify the time duration, in seconds, for a response from the RADIUS server to mark it as unreachable.
Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure parameters to detect a dead RADIUS server.

profile radius attribute

Configures the AAA attribute parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description **attribute [[nas-identifier *nas_identifier*] [nas-ip *nas_ip_address*]]**

nas-identifier *nas_identifier*

Specify the attribute name by which the system will be identified in Access-Request messages.
Must be a string of 1-128 characters of 1-32 characters.

nas-ip *nas_ip_address*

Specify the IP address of the AAA NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA attribute parameters. The CLI prompt changes to the Attribute Configuration mode (config-attribute).

profile radius attribute called-station-id

Configures the AAA called-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **called-station-id { format-name format_name | value }**

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA called-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA called-station-id attribute.

profile radius attribute called-station-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **called-station-id *format-name format_name* [nas-port-type *nas_port_type*]**

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute calling-station-id

Configures the AAA calling-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

profile radius attribute calling-station-id format

Syntax Description

calling-station-id { format-name *format_name* | value }

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify the value of the AAA calling-station-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines

Use this command to configure the AAA calling-station-id attribute.

profile radius attribute calling-station-id format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

called-station-id format-name *format_name* [nas-port-type *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute nas-identifier-format

Configures the AAA nas-identifier-format attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

nas-identifier-format format-name *format_name*

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure the AAA nas-identifier-format attribute.

profile radius attribute nas-identifier-format format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

called-station-id *format-name* *format_name* [**nas-port-type *nas_port_type*]**

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute nas-port

Configures the AAA nas-port attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description

nas-port { *value* | **format-e *format_e_value* }**

format-e *format_e_value*

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLUVQ]*).

value

Specify value of the nas-port attribute.

Must be an integer in the range of 1-maximum.

profile radius attribute nas-port format-e-list

Usage Guidelines Use this command to configure the AAA nas-port attribute.

profile radius attribute nas-port format-e-list

Configures the AAA nas-port attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **format-e-list nas-port-type nas_port_type_value format-e format_e_value**

format-e format_e_value

Specify the attribute format-e value.

Must be a string of 32 characters in the pattern ([01FSAPRiLVQ]*).

nas-port-type nas_port_type_value

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure the AAA nas-port attribute.

profile radius attribute nas-port-id

Configures the AAA nas-port-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **nas-port-id { value | format-name format_name }**

format-name format_name

Specify the attribute format name.

Must be a string of 1-128 characters.

value

Specify value of the AAA nas-port-id attribute.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the AAA nas-port-id attribute.

profile radius attribute nas-port-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting) > Attribute Configuration (config-attribute)

Syntax Description **called-station-id** **format-name** *format_name* [**nas-port-type** *nas_port_type*]

format-name *format_name*

Specify the attribute format name.

Must be a string of 1-128 characters.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer in the range of 0-44.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius detect-dead-server

Configures parameters to detect a dead RADIUS server.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Accounting Configuration (config-accounting)

Syntax Description **detect-dead-server** **response-timeout** *response_timeout_duration*

response-timeout *response_timeout_duration*

Specify the time duration, in seconds, for a response from the RADIUS server to mark it as unreachable.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure parameters to detect a dead RADIUS server.

profile radius server

Configures RADIUS external server parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Configuration (config-radius)

Syntax Description **server** *radius_server_ip_address* *radius_server_port_number* [[**priority** *radius_server_priority*] [**secret** *radius_server_secret*] [**type** *server_type*]]

profile radius server-group***priority radius_server_priority***

Specify the priority of the RADIUS server.

Must be an integer in the range of 1-100.

secret radius_server_secret

Specify the secret of the RADIUS server.

Must be a string.

type server_type

Specify the server type.

Must be one of the following:

- **acct**
- **auth**

Default Value: auth.

radius_server_ip_address

Specify the IP address of the RADIUS server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

radius_server_port_number

Specify the port number of the RADIUS server.

Must be an integer in the range of 1-65535.

Usage Guidelines

Use this command to configure RADIUS external server parameters. The CLI prompt changes to the Server Configuration mode (config-server-<ip_address>/<port_number>).

profile radius server-group

Configures association of RADIUS servers to groups.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius)

Syntax Description

server-group *server_group_name*

server_group_name

Specify the name of the RADIUS server group.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to associate RADIUS servers to groups. The CLI prompt changes to the Server Group Configuration mode (config-server-group-<group_name>).

profile radius server-group server

Configures RADIUS server information.

Command Modes

Exec > Global Configuration (config) > RADIUS Configuration (config-radius) > Server Group Configuration (config-server-group-<group_name>)

Syntax Description

server *radius_server_type radius_server_ip_address radius_port_number*

radius_port_number

Specify the port number of the RADIUS server.

radius_server_ip_address

Specify IP address of the RADIUS server.

radius_server_type

Specify the server type.

Must be one of the following:

- **acct**: Server used for accounting requests.
- **auth**: Server is used for authentication/authorization requests.

Usage Guidelines

Use this command to configure RADIUS server information.

profile server-group

Configures AAA custom server groups.

Command Modes

Exec > Global Configuration (config)

Syntax Description

profile server-group *aaa_server_group_name* [**radius-group** *radius_server_group_name*]

radius-group radius_server_group_name

Specify name of the RADIUS server group.

aaa_server_group_name

Specify name of the AAA server group.

profile subscriber

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure AAA custom server groups. The CLI prompt changes to the Server Group Configuration mode (config-server-group-<group_name>).

profile subscriber

Configures subscriber profiles.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
profile subscriber subscriber_profile_name [ activate-feature-templates template_names | apply-all-class | dhcp-profile dhcp_profile_name | l2tp-profile l2tp_profile_name | pppoe-profile pppoe_profile_name | session-type session_type ]
```

activate-feature-templates *template_names*

Specify the list of feature templates to activate.

You can configure a maximum of eight elements with this keyword.

apply-all-class

Specify to apply all classes if enabled.

dhcp-profile *dhcp_profile_name*

Specify name of the DHCP-FSOL profile.

l2tp-profile *l2tp_profile_name*

Specify to associate L2TP-FSOL profile.

pppoe-profile *pppoe_profile_name*

Specify name of the PPPOE-FSOL profile.

session-type *session_type*

Specify the allowed session type.

Must be one of the following:

- **ipv4**
- **ipv4v6**
- **ipv6**

Default Value: ipv4v6.

subscriber *subscriber_profile_name*

Specify name of the subscriber profile.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure subscriber profiles. The CLI prompt changes to the Subscriber Configuration mode (config-subscriber-<profile_name>).

profile subscriber aaa

Configures AAA operations.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)

Syntax Description

aaa aaa_option aaa_profile_name

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

aaa_profile_name

Specify name of the AAA profile.

Usage Guidelines

Use this command to configure AAA operations.

profile subscriber class

Configures subscriber classification parameters.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name)

profile subscriber class aaa

Syntax Description **class** *class_name* [**activate-feature-templates** *feature_template_names*]

activate-feature-templates *feature_template_names*

Specify the list of feature template names to activate.

You can configure a maximum of eight elements with this keyword.

class *class_name*

Specify name of the class.

Must be a string of 1-128 characters.

Usage Guidelines

Use this command to configure subscriber classification parameters. The CLI prompt changes to the Class Configuration mode (config-class-<class_name>).

profile subscriber class aaa

Configures AAA operations.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)

Syntax Description

aaa *aaa_option profile_name*

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

profile_name

Specify the name of the AAA profile for authentication.

Usage Guidelines

Use this command to configure AAA operations.

profile subscriber class matches

Configures the list of match values.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)

Syntax Description **matches** [**match-type** *match_type*]

match-type *match_type*

Specify the match type.

Must be one of the following:

- **all**
- **any**

Usage Guidelines Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile subscriber class matches match

Configures Match Key and value.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Syntax Description **match** *match_key* { **type** *match_protocol* | **ascii** *ascii_string* | **regex** *regex_string* }

ascii *ascii_string*

Specify the ASCII string.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

match *match_key*

Specify the match key.

Must be one of the following:

- **circuit-id**
- **protocol**

profile subscriber event

- **remote-id**
- **source-mac**
- **username**

regex *regex_string*

Specify the regular expression string.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

type *match_protocol*

Specify the match protocol.

Must be one of the following:

- **dhcp**
- **ppp**

You can configure a maximum of two elements with this keyword.

Usage Guidelines

Use this command to configure Match Key and value.

profile subscriber event

Configures subscriber events.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name)

Syntax Description

```
event event_name [ activate-feature-templates template_names | apply-all-class
| deactivate-feature-templates template_names ]
```

activate-feature-templates *template_names*

Specify the list of feature templates to activate.

You can configure a maximum of eight elements with this keyword.

apply-all-class

Specify to apply all classes if enabled.

deactivate-feature-templates *template_names*

Specify the list of feature templates to deactivate.

You can configure a maximum of eight elements with this keyword.

event event_name

Specify name of the event.

Must be one of the following:

- **session-activate**

Usage Guidelines Use this command to configure subscriber events.

profile subscriber event aaa

Configures AAA operations.

Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)
Syntax Description	<p>aaa aaa_option aaa_profile_name</p> <p>aaa_option</p> <p>Specify the AAA option.</p> <p>Must be one of the following:</p> <ul style="list-style-type: none"> • authenticate • authorize

aaa_profile_name

Specify name of the AAA profile.

Usage Guidelines Use this command to configure AAA operations.

profile subscriber event class

Configures subscriber classification.

Command Modes	Exec > Global Configuration
----------------------	-----------------------------

profile subscriber event class aaa

Syntax Description

```
class { class-name class_name | deactivate-feature-templates template_names |
activate-feature-templates template_names }
```

activate-feature-templates *template_names*

Specify the list of feature template names to activate.

You can configure a maximum of eight elements with this keyword.

class-name *class_name*

Specify name of the class.

Must be a string of 1-128 characters.

deactivate-feature-templates *template_names*

Specify the list of feature template names to deactivate.

You can configure a maximum of eight elements with this keyword.

Usage Guidelines

Use this command to configure subscriber classification.

profile subscriber event class aaa

Configures AAA operations.

Command Modes

Exec > Global Configuration

Syntax Description

```
aaa { aaa-option aaa_option | profile profile_name }
```

aaa-option *aaa_option*

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

profile *profile_name*

Specify the AAA profile name for authentication.

Usage Guidelines

Use this command to configure AAA operations.

profile subscriber event class matches

Configures the list of match values.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)

Syntax Description **matches** [**match-type** *match_type*]

match-type *match_type*

Specify the match type.

Must be one of the following:

- **all**
- **any**

Usage Guidelines Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile subscriber event class matches match

Configures Match Key and value.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Syntax Description **match** *match_key* { **type** *match_protocol* | **ascii** *ascii_string* | **regex** *regex_string* }

ascii *ascii_string*

Specify the ASCII string.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

match *match_key*

Specify the match key.

Must be one of the following:

- **circuit-id**
- **protocol**

quit

- **remote-id**
- **source-mac**
- **username**

regex regex_string

Specify the regular expression string.

Must be a string in the bng-special-str pattern. For information on the bng-special-str pattern, see the *Input Pattern Types* chapter.

You can configure a maximum of eight elements with this keyword.

type match_protocol

Specify the match protocol.

Must be one of the following:

- **dhcp**
- **ppp**

You can configure a maximum of two elements with this keyword.

Usage Guidelines

Use this command to configure Match Key and value.

quit

Exits the management session.

Command Modes

Exec

Syntax Description

quit

Usage Guidelines

Use this command to exit the management session.

rcm switchover

Configures Redundancy and Configuration Manager (RCM) switchover operation.

Command Modes

Exec

Syntax Description

rcm switchover source ip_address destination ip_address

source ip_address

Specify the source IP address.

Must be an IP address.

destination ip_address

Specify the destination IP address.

Must be an IP address.

Usage Guidelines	Use this command to configure RCM switchover operation.
-------------------------	---

reconcile ipam

Reconciles IPAM data with CDL records.

Command Modes	Exec
----------------------	------

Syntax Description	reconcile ipam
---------------------------	-----------------------

Usage Guidelines	Use this reconcile IPAM data with CDL records.
-------------------------	--

resource pod

Configures Pod resource parameter.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	resource pod podtype pod_type
---------------------------	--------------------------------------

gomaxproc go_max_procedure_cores

Specify the Go Lang max procedure cores.

Must be an integer in the range of 1-48.

podtype pod_type

Specify the pod type.

Usage Guidelines	Use this command to configure Pod resource parameter. The CLI prompt changes to the Pod Resource Configuration mode (config-resource-<pod_type>).
-------------------------	---

resource pod cpu

Configures CPU resource request parameter.

Command Modes	Exec > Global Configuration (config) > Pod Resource Configuration (config-resource-pod_type)
----------------------	--

Syntax Description	cpu request cpu_resource_request limit cpu_resource_limit
---------------------------	--

resource pod labels***limit cpu_resource_limit***

Specify the CPU resource limit in milicores.

Must be an integer in the range of 100-1000000.

request cpu_resource_request

Specify the CPU resource request in milicores.

Must be an integer in the range of 100-1000000.

Usage Guidelines Use this command to configure CPU resource request parameter.

resource pod labels

Configures K8 Node Affinity label configuration.

Command Modes Exec > Global Configuration (config) > Pod Resource Configuration (config-resource-pod_type)

Syntax Description **labels key label_key value label_value**

key label_key

Specify the key for the label.

Must be a string.

value label_value

Specify the value for the label.

Must be a string.

Usage Guidelines Use this command to configure K8 Node affinity label configuration.

resource pod memory

Configures memory resource requests and limit configuration.

Command Modes Exec > Global Configuration (config) > Pod Resource Configuration (config-resource-pod_type)

Syntax Description **memory request memory_resource_request limit memory_resource_limit**

limit memory_resource_limit

Specify the memory resource limit in megabytes.

Must be an integer in the range of 100-200000.

request memory_resource_request

Specify the memory resource request in megabytes.

Must be an integer in the range of 100-200000.

Usage Guidelines	Use this command to configure memory resource requests and limit configuration.
-------------------------	---

router bfd instance instance-id

Configures Multi-Hop BFD configuration.

Command Modes	Exec > Global Configuration (config)
----------------------	--------------------------------------

Syntax Description	router bfd instance instance-id <i>instance_id</i>
---------------------------	---

instance-id *instance_id*

Specify the instance ID.

Usage Guidelines	Use this command to configure Multi-Hop BFD configuration. The CLI prompt changes to the Instance ID Configuration mode (config-instance-id-<instance_id>).
-------------------------	---

router bfd instance instance-id interface-list

Configures monitor interface list configuration.

Command Modes	Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id- <i>instance_id</i>)
----------------------	--

Syntax Description	router monitor-interface interface-list interface <i>interface_to_monitor</i>
---------------------------	--

gateway-ip *gateway_ip_address*

Specify IP address of the gateway.

Must be a string.

interface *interface_to_monitor*

Specify the interface to monitor.

Must be a string.

Usage Guidelines	Use this command to configure monitor interface list configuration. The CLI prompt changes to the Instance ID Interface Configuration mode (config-instance-id-<interface_name>).
-------------------------	---

router bfd instance instance-id interface-list neighbors

Configures neighbor details.

Command Modes	Exec > Global Configuration (config) > Instance ID Configuration (config-instance-id- <i>instance_id</i>) > Instance ID Interface Configuration (config-instance-id- <i>interface_name</i>)
----------------------	---

router bgplist

Syntax Description **neighbor** *neighbor_ip_address*

neighbor *neighbor_ip_address*

Specify IP address of the neighbor.

Must be a string.

Usage Guidelines Use this command to configure neighbor details.

router bgplist

Configures BGP speaker configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description **router bgp** *bgp* [**learnDefaultRoute** { **false** | **true** } | **loopbackBFDPort** *bfd_local_port_number* | **loopbackPort** *bgp_local_port_number*]

bgp *bgp*

Specify the BGP.

Must be an integer.

learnDefaultRoute { **false** | **true** }

Specify whether to enable or disable learning default route and adding it in kernel space.

Must be one of the following:

- **false**
- **true**

Default Value: false.

loopbackBFDPort *bfd_local_port_number*

Specify the BFD local port number.

Must be an integer.

Default Value: 3784.

loopbackPort *bgp_local_port_number*

Specify the BGP local port number.

Must be an integer.

Default Value: 179.

Usage Guidelines Use this command to configure the BGP speaker configuration.

router bgplist bfd

Configures BFD configuration.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router)

Syntax Description `bfd { interval bfd_interval | min_rx bfd_min_rx | multiplier bfd_interval_multiplier }`

interval *bfd_interval*

Specify, in microseconds, the BFD interval.

Must be an integer.

Default Value: 250000.

min_rx *bfd_min_rx*

Specify, in microseconds, the BFD minimum RX.

Must be an integer.

Default Value: 250000.

multiplier *bfd_interval_multiplier*

Specify the BFD interval multiplier.

Must be an integer.

Default Value: 3.

Usage Guidelines Use this command to configure the BFD configuration.

router bgplist interfaceList

Configures bonding interface configuration.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router)

Syntax Description `interface bgp_local_interface`

interface *bgp_local_interface*

Specify the BGP local interface.

Must be a string.

Usage Guidelines Use this command to configure the bonding interface configuration.

router bgplist interfaceList bondingInterfaces

router bgplist interfaceList bondingInterfaces

Configures bonding interface configuration.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router) > Router Interface Configuration (config-router-interface)

Syntax Description **bondingInterface** *linked_bonding_interface*

bondingInterface *linked_bonding_interface*

Specify the linked bonding interface.

Must be a string.

Usage Guidelines Use this command to configure the bonding interface configuration.

router bgplist interfaceList neighbors

Configures neighbor parameters.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router) > Router Interface Configuration (config-router-interface)

Syntax Description **neighbor** *neighbor_ip_address* [**fail-over** *failover_type* | **remote-as** *remote_as_number*]

fail-over *failover_type*

Specify the failover type.

Must be one of the following:

- **bfd**

neighbor *neighbor_ip_address*

Specify the IP address of the neighbor.

Must be a string.

remote-as *remote_as_number*

Specify the Autonomous System (AS) number of the BGP neighbor.

Must be an integer.

Default Value: 65000.

Usage Guidelines Use this command to configure the neighbor parameters.

router bgplist policies

Configures policy parameters.

Command Modes Exec > Global Configuration (config) > Router Configuration (config-router-router)

Syntax Description

```
policy-name policy_name [ as-path-set as_path_set | gateWay gateway_address |
interface interface | ip-prefix ip_prefix | isStaticRoute { false | true } |
mask-range mask_range | modifySourceIp { false | true } ]
```

as-path-set *as_path_set*

Specify the Autonomous System (AS) path set.

Must be a string.

gateWay *gateway_address*

Specify the gateway address.

Must be a string.

interface *interface*

Specify the interface to set as source ip.

Must be a string.

ip-prefix *ip_prefix*

Specify the IP prefix.

Must be a string.

isStaticRoute { false | true }

Specify whether to enable or disable adding static route into kernel space.

Must be one of the following:

- **false**
- **true**

Default Value: false.

mask-range *mask_range*

Specify the mask range.

Must be a string.

modifySourceIp { false | true }

Specify whether to enable or disable modifying source IP of incoming route.

router monitor-interface interface-list

Must be one of the following:

- **false**
- **true**

Default Value: false.

policy-name *policy_name*

Specify name of the policy.

Must be a string.

source-prefix *source_ip_prefix*

Specify the source IP prefix.

Must be a string.

Usage Guidelines Use this command to configure the policy parameters.

router monitor-interface interface-list

Configures monitor interface list configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description **router monitor-interface interface-list interface *interface_to_monitor* linked-interface *linked_interface_to_monitor***

interface *interface_to_monitor*

Specify the interface to monitor.

Must be a string.

linked-interface *linked_interface_to_monitor*

Specify the linked interface to monitor.

Must be a string.

Usage Guidelines Use this command to configure monitor interface list configuration.

screen-length

Configures the number of rows of text that the terminal screen displays.

Command Modes Exec

Syntax Description **screen-length *number_of_rows***

number_of_rows

Specify the number of rows that the terminal screen displays.

Must be an integer.

Usage Guidelines	Use this command to set the number of rows that the terminal screen displays.
-------------------------	---

screen-width

Configures the number of columns that the terminal screen displays.

Command Modes	Exec
----------------------	------

Syntax Description	screen-width <i>number_of_columns</i>
---------------------------	--

number_of_columns

Specify the number of columns that the terminal screen displays.

Must be an integer.

Usage Guidelines	Use this command to set the number of columns that the terminal screen displays.
-------------------------	--

send

Sends messages to the terminal of a specific user or all users.

Command Modes	Exec
----------------------	------

Syntax Description	send <i>user message</i>
---------------------------	---------------------------------

user

Specify the user to whom the message must be sent.

Must be a string. Select from the possible completion options.

message

Specify the message that must be sent.

Must be a string.

Usage Guidelines	Use this command to send messages to the terminal of a specific user or to all users.
-------------------------	---

show

Displays the system information.

show bfd-neigbor

Command Modes	Exec
Syntax Description	show system_component system_component Specify the component to view the information. Must be a string. Select from the possible completion options.
Usage Guidelines	Use this command to view the system information.

show bfd-neigbor

Displays BFD status of neighbors.

Command Modes	Exec
Syntax Description	show bfd-neigbor [ip ip_address] ip ip_address Specify the IP address of the neighbor. Must be a string.
Usage Guidelines	Use this command to view BFD status of neighbors.

show bgp-global

Displays BGP global configuration.

Command Modes	Exec
Syntax Description	show bgp-global
Usage Guidelines	Use this command to view BGP global configuration.

show bgp-kernel-route

Displays BGP kernel-configured routes.

Command Modes	Exec
Syntax Description	show bgp-kernel-route [application { false true }] application { false true } Specify whether to display application added routes.

Must be one of the following:

- false
- true

Default Value: false.

Usage Guidelines	Use this command to view BGP kernel-configured routes.
-------------------------	--

show bgp-neighbors

Displays BGP neighbor's status.

Command Modes	Exec
----------------------	------

Syntax Description	show bgp-neighbors [ip ip_address]
---------------------------	---

ip ip_address

Specify the IP address of the neighbor.

Must be a string.

Usage Guidelines	Use this command to view BGP neighbor's status.
-------------------------	---

show bgp-route-summary

Displays BGP route summary.

Command Modes	Exec
----------------------	------

Syntax Description	show bgp-route-summary
---------------------------	-------------------------------

Usage Guidelines	Use this command to view BGP route summary.
-------------------------	---

show bgp-routes

Displays BGP routes information.

Command Modes	Exec
----------------------	------

Syntax Description	show bgp-routes
---------------------------	------------------------

Usage Guidelines	Use this command to view BGP routes information.
-------------------------	--

show config-error info

show config-error info

Displays configuration error information.

Command Modes Exec

Syntax Description `show config-error [info]`

Usage Guidelines Use this command to view configuration error information.

show diagnostics info

Displays diagnostics information.

Command Modes Exec

Syntax Description `show diagnostics [info]`

Usage Guidelines Use this command to view diagnostics information.

show edr

Displays EDR Transaction Procedure Event fields.

Command Modes Exec

Syntax Description `show edr { [event transaction_procedure_event] [transaction-procedure transaction_procedure] }`

event transaction_procedure_event

Specify the transaction procedure event name/id/all.

Must be a string.

transaction-procedure transaction_procedure

Specify the transaction procedure's name, ID, or all.

Must be a string.

Usage Guidelines Use this command to view EDR Transaction Procedure Event fields.

show endpoint all

Displays endpoint status.

Command Modes	Exec
Syntax Description	show endpoint [all]
Usage Guidelines	Use this command to view the status of endpoints.

show endpoint info

Displays endpoint information.

Command Modes	Exec
Syntax Description	show endpoint info
Usage Guidelines	Use this command to view endpoint information.

show geo-maintenance-mode

Indicates whether maintenance mode is enabled or disabled.

Command Modes	Exec
Syntax Description	show geo-maintenance-mode
Usage Guidelines	Use this command to view whether maintenance mode is enabled or disabled.

show georeplication

Displays ETCD/Cache checksum.

Command Modes	Exec
Syntax Description	show georeplication checksum instance-id <i>instance_id</i>
	checksum
	Specify checksum.
	instance-id <i>instance_id</i>
	Specify the instance ID for which checksum will be displayed.
	Must be a string.
Usage Guidelines	Use this command to view ETCD/Cache checksum.

show l2tp-tunnel

show l2tp-tunnel

Show L2TP tunnel information.

Command Modes Exec

Syntax Description `show l2tp-tunnel [count tunnels_count | detail]`

count *tunnels_count*

Specify the number of tunnels.

detail

Specify to display detailed information.

Usage Guidelines Use this command to view L2TP tunnel information.

show l2tp-tunnel filter

Show L2TP tunnel information for additional filters.

Command Modes Exec

Syntax Description `show l2tp-tunnel filter { destination-addr destination_address | source-addr source_address | state state_info | tunnel-id l2tp_tunnel_id | tunnel-type tunnel_type | tunnelAssignmentID tunnel_assignment_id | upf upf_info }`

destination-addr *destination_address*

Specify the IP address of the tunnel destination.

Must be a string.

source-addr *source_address*

Specify the IP address of the tunnel source.

Must be a string.

state *state_info*

Specify the state information.

Must be one of the following:

- **complete**
- **incomplete**

tunnel-id *l2tp_tunnel_id*

Specify the L2TP tunnel ID.

Must be an integer in the range of 1-65535.

tunnel-type *tunnel_type*

Specify the tunnel type.

Must be one of the following:

- lac
- lns

tunnelAssignmentID *tunnel_assignment_id*

Specify assignment ID of the tunnel.

Must be a string.

upf *upf_info*

Specify the UPF.

Must be a string.

Usage Guidelines	Use this command to view L2TP tunnel information for additional filters.
-------------------------	--

show local-interface-status

Displays status of local interface.

Command Modes	Exec
----------------------	------

Syntax Description	show local-interface-status interface <i>local_interface_name</i>
---------------------------	--

interface *local_interface_name*

Specify name of the local interface.

Must be a string.

Usage Guidelines	Use this command to view status of local interface .
-------------------------	--

show peers all

Displays peer information.

Command Modes	Exec
----------------------	------

Syntax Description	show peers [all]
---------------------------	---------------------------

show radius

Usage Guidelines Use this command to view peer information.

show radius

Displays RADIUS client data.

Command Modes Exec

Syntax Description **show radius**

Usage Guidelines Use this command to view RADIUS client data.

show radius acct-server

Displays RADIUS accounting server data.

Command Modes Exec

Syntax Description **show radius acct-server [ip_port]**

ip_port

Specify the ip_address:port_number of the RADIUS server.

Must be a string.

Usage Guidelines Use this command to view RADIUS accounting server data.

show radius auth-server

Displays RADIUS authentication server data.

Command Modes Exec

Syntax Description **show radius auth-server [ip_port]**

ip_port

Specify the ip_address:port_number of the RADIUS server.

Must be a string.

Usage Guidelines Use this command to view RADIUS authentication server data.

show radius-dyn-auth

Displays RADIUS dynamic-author data.

Command Modes	Exec
Syntax Description	show radius radius-dyn-auth
Usage Guidelines	Use this command to view RADIUS dynamic-author data.

show radius-dyn-auth clients

Displays RADIUS dynamic-author information.

Command Modes	Exec
Syntax Description	show radius dynauth clients
Usage Guidelines	Use this command to view RADIUS dynamic-author information.

show resources info

Displays resource information.

Command Modes	Exec
Syntax Description	show resources [info]
Usage Guidelines	Use this command to view information about the configured resources.

show role

Displays current role for the specified instance.

Command Modes	Exec
Syntax Description	show role instance-id <i>instance_id</i> <i>instance-id instance_id</i> Specify the instance ID for which role must be displayed.
Usage Guidelines	Use this command to view current role for the specified instance.

show rpc all

Displays RPC configuration information.

Command Modes	Exec
----------------------	------

show running-status info

Syntax Description `show rpc [all]`

Usage Guidelines Use this command to view RPC configuration information.

show running-status info

Displays the system's current status information.

Command Modes Exec

Syntax Description `show running-status [info]`

Usage Guidelines Use this command to view the system's current status information.

show sessions

Displays pending session commits in the database.

Command Modes Exec

Syntax Description `show sessions`

Usage Guidelines Use this command to view pending session commits in the database.

show sessions affinity

Displays the affinity count per instance.

Command Modes Exec

Syntax Description `show sessions affinity`

Usage Guidelines Use this command to view the affinity count per instance.

show sessions commit-pending

Displays all pending session commits.

Command Modes Exec

Syntax Description `show sessions commit-pending`

Usage Guidelines Use this command to view all pending session commits.

show subscriber

Displays subscriber information.

Command Modes Exec

Syntax Description `show subscriber { all | supi supi_id }`

all

Specify all SUPIs or IMEIs.

gr-instance *gr_instance*

Specify the network function service under which to search.

imei *imei_id*

Specify the International Mobile Equipment Identity.

Must be a string of 15-16 characters.

namespace *namespace*

NOTE: This keyword is deprecated, use nf-service instead. Specify the product namespace under which to search.

Default Value: cisco-mobile-infra:none.

nf-service *nf_service*

Specify the network function service under which to search.

Default Value: cisco-mobile-infra:none.

supi *supi_id*

Specify the subscriber's SUPI ID.

Must be a string.

Usage Guidelines

Use this command to view summary and detailed subscriber information for all subscribers or specific subscribers based on SUPI, IMEI, or all.

show subscriber

Shows BNG subscriber data.

Command Modes Exec

Syntax Description `show subscriber type [count | detail | sublabel subscriber_label]`

show subscriber filter**acct-sess-id *accounting_session_id***

Specify the accounting session ID.

Must be a string of 1-64 characters.

count

Specify to display the number of sessions.

debug

Specify debug information.

detail

Specify to display detailed information.

sublabel *subscriber_label*

Specify the subscriber label.

Must be a string of 1-64 characters.

type

Specify the type.

Must be one of the following:

- **dhcp**: DHCP information.
- **lns**: Lns information.
- **pppoe**: PPPoE information.
- **session**: SessionManager information.

Usage Guidelines

Use this command to view BNG subscriber data.

show subscriber filter

Configures additional filters.

Command Modes

Exec

Syntax Description

```
show subscriber type filter [ afi address_family | iana-state-bound
iana_bound_state | iapd-state-bound iapd_bound_state | ipv4-addr ipv4_address |
ipv4-pool ipv4_pool_name | ipv4-range ipv4_address_range | ipv4-state-bound
ipv4_bound_state | ipv6-addr ipv6_address | ipv6-addr-pool ipv6_address_pool_name |
ipv6-addr-range ipv6_address_range | ipv6-pfx ipv6_prefix | ipv6-pfx-pool
ipv6_prefix_pool | ipv6-pfx-range ipv6_prefix_range | mac mac_address | port-id
upf_port_id | state session_state | up-subs-id up_subscriber_id | upf upf_name |
upmgr sm_up_info | username session_user_name | vrf vrf_name ]
```

afi address_family

Specify the address family.

Must be one of the following:

- **dual**: Dual-Stack sessions.
- **ipv4**: IPv4-only sessions.
- **ipv6**: IPv6-only sessions.
- **pending**: Inflight sessions (applicable for SessMgr).

feat-template feature_template_profile_name

Specify name of the feature-template profile.

Must be a string.

iana-state-bound iana_bound_state

Specify the IANA bound state.

Must be one of the following:

- **iana-state-bound**

iapd-state-bound iapd_bound_state

Specify the IAPD bound state.

Must be one of the following:

- **iapd-state-bound**

ipv4-addr ipv4_address

Specify the IPv4 address in the format "pool-name/ipv4-addr".

Must be a string.

ipv4-pool ipv4_pool_name

Specify name of the IPv4 pool.

Must be a string.

ipv4-range ipv4_address_range

Specify the IPv4 address range in the format "poolName/start-ip".

Must be a string.

ipv4-state-bound ipv4_bound_state

Specify the IPv4 bound state.

Must be one of the following:

show subscriber filter

- **ipv4-state-bound**

ipv6-addr-pool *ipv6_address_pool_name*

Specify name of the IPv6 address pool.

Must be a string.

ipv6-addr-range *ipv6_address_range*

Specify the IPv6 address range in the format "*poolName/start-ip*".

Must be a string.

ipv6-addr *ipv6_address*

Specify the IPv6 address in the format "*pool-name/ipv6-addr*".

Must be a string.

ipv6-pfx-pool *ipv6_prefix_pool*

Specify name of the IPv6 prefix pool.

Must be a string.

ipv6-pfx-range *ipv6_prefix_range*

Specify the IPv6 prefix range in the format "*poolName/start-pfx*".

Must be a string.

ipv6-pfx *ipv6_prefix*

Specify the IPv6 prefix in the format "*pool-name/ipv6-pfx*".

Must be a string.

mac *mac_address*

Specify the MAC address in the "aabb.ccc.d.eeff" format.

Must be a string.

port-id *upf_port_id*

Specify the user plane function port ID in the format "*upf/portid*".

Must be a string.

ppp-type *ppp_session_type*

Specify the PPP session type.

Must be one of the following:

- **lac**

- **pta**: PPPoE PTA subscriber.

session-id *session_id*

Specify the L2TP session ID.

Must be an integer in the range of 1-65535.

sesstype *session_type*

Specify the SM subscriber session type.

Must be one of the following:

- **ipoe**: IPOE subscribers.
- **lac**
- **lns**
- **ppp**: PPP subscribers.

smstate *sm_session_state*

Specify the state of the SM session.

Must be one of the following:

- **created**
- **deleted**
- **established**

smupstate *smup_session_state*

Specify the state of the SMUP session.

Must be one of the following:

- **smUpSessionCreated**
- **smUpSessionDeleted**
- **smUpSessionWait4SmCreate**

state *session_state*

Specify the session state.

Must be one of the following:

- **complete**: Specify the state is complete.
- **incomplete**: Specify the state is incomplete.

show subscriber opts**tunnel-dest-addr *tunnel_dest_address***

Specify the L2TP tunnel destination address.

Must be a string.

tunnel-id *tunnel_id*

Specify the L2TP tunnel ID.

Must be an integer in the range of 1-65535.

up-subs-id *up_subscriber_id*

Specify the UP subscriber ID.

Must be a string.

upf *upf_name*

Specify name of the user plane function.

Must be a string.

username *session_user_name*

Specify the user name of the session.

Must be a string.

Usage Guidelines Use this command to configure additional filters.

show subscriber opts

Configures command output modifiers.

Command Modes	Exec
----------------------	------

Syntax Description	detail
---------------------------	---------------

Syntax Description	count
---------------------------	--------------

count

Displays count of number of sessions.

detail

Displays detailed information.

Usage Guidelines Use this command to configure output modifiers.

show subscriber synchronize

Synchronize info.

Command Modes Exec

Syntax Description `show subscriber synchronize upf upf_info`

Syntax Description `show subscriber synchronize-cp upf upf_info`

synchronise-cp

Specify to synchronise CP information.

Must be one of the following:

- **synchronize-cp**

synchronise

Specify to synchronise UP information.

Must be one of the following:

- **synchronize**

upf upf_info

Specify UPF information.

Must be a string of 1-64 characters.

Usage Guidelines Use this command to synchronise info.

show test-radius accounting

Tests RADIUS accounting server function.

Command Modes Exec

Syntax Description `test-radius accounting { all [[client-nas nas_ip_address] [username user_name]] | server server_ip_address { [client-nas nas_ip_address] port server_port_number [username user_name] } | server-group [[client-nas nas_ip_address] [username user_name]] }`

all

Specify to test all configured servers.

Must be one of the following:

- **all**

show test-radius authentication**client-nas nas_ip_address**

Specify the IP address of the client NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

port server_port_number

Specify the RADIUS server port number.

Must be an integer in the range of 1-65535.

server-group server_group_name

Specify name of the sever group.

Must be a string of 1-64 characters.

server server_ip_address

Specify IP address of the RADIUS server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

username user_name

Specify the user name.

Must be a string of 1-64 characters.

Default Value: test.

Usage Guidelines

Use this command to test RADIUS accounting server function.

show test-radius authentication

Tests RADIUS authentication server.

Command Modes

Exec

Syntax Description

```
test-radius authentication { all [ [ client-nas nas_ip_address ] [ password user_password ] [ username user_name ] ] | server server_ip_address { [ client-nas nas_ip_address ] [ password user_password ] port server_port_number [ username
```

```
user_name ] } | server-group [ [ client-nas nas_ip_address ] [ password  
user_password ] [ username user_name ] ] }
```

all

Specify to test all configured servers.

Must be one of the following:

- **all**

client-nas nas_ip_address

Specify the IP address of the client NAS.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

password user_password

Specify the password for user with authentication verified.

Must be a string of 1-64 characters.

Default Value: test.

port server_port_number

Specify the RADIUS server port number.

Must be an integer in the range of 1-65535.

server-group server_group_name

Specify name of the sever group.

Must be a string of 1-64 characters.

server server_ip_address

Specify IP address of the RADIUS server.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

-Or-

Must be a string in the ipv6-address pattern. For information on the ipv6-address pattern, see the *Input Pattern Types* chapter.

username user_name

Specify the user name.

show-defaults

Must be a string of 1-64 characters.

Default Value: test.

Usage Guidelines	Use this command to test RADIUS authentication server.
-------------------------	--

show-defaults

Displays the default configuration.

Command Modes	Exec
----------------------	------

Syntax Description	show-defaults { false true }
---------------------------	---------------------------------------

{ false | true }

Specify whether to display or hide the default values. To display, select true. Otherwise, select false.

Must be either "false" or "true".

Usage Guidelines	Use this command to view the default configuration.
-------------------------	---

smiuser

Configures the Subscriber Microservices Infrastructure (SMI) user account parameters.

Command Modes	Exec
----------------------	------

Syntax Description	smiuser { add-group groupname group_name add-user { username username password password } change-password { username username current_password current_password new_password new_password confirm_password new_password password_expire_days expire_days } change-self-password { current_password current_password new_password new_password confirm_password new_password password_expire_days expire_days } delete-group groupname group_name delete-user username username unassign-user-group { groupname groupname_pam username username_pam } update-password-length length password_length }
---------------------------	---

username username

Specify the username.

Must be a string.

password password

Specify the user password.

Must be a string.

confirm_password *new_password*

Confirm the new password.

Must be a string.

current_password *current_password*

Specify the current password.

Must be a string.

new_password *new_password*

Specify the new password.

Must be a string.

password_expire_days *expire_days*

Specify the number of days before the password expires.

Must be an integer.

groupname *group_name*

Specify the group name.

Must be a string.

groupname *groupname_pam*

Specify the group name in PAM.

Must be a string.

username *username_pam*

Specify the user name in PAM.

Must be a string.

length *password_length*

Specify the minimum password length.

Must be an integer.

Usage Guidelines

Use this command to configure the smiuser parameters.

subscriber

Configures subscriber parameters.

Command Modes

Exec > Global Configuration (config)

subscriber route-synchronize

Syntax Description **subscriber event-trace-disable**

Usage Guidelines Use this command to configure subscriber parameters.

subscriber route-synchronize

Synchronizes routes to UPF.

Command Modes Exec

Syntax Description **subscriber route-synchronize upf user_plane_name**

upf user_plane_name

Specify name of the user plane function.

Must be a string of 1-64 characters.

Usage Guidelines Use this command to synchronize routes to UPF.

subscriber session-synchronize

Synchronizes sessions to UPF.

Command Modes Exec

Syntax Description **subscriber session-synchronize upf user_plane_name [abort | timeout sla_timeout]**

abort

Specify to abort synchronization.

timeout sla_timeout

Specify the SLA timeout duration in seconds.

Must be an integer in the range of 10-1800.

upf user_plane_name

Specify name of the user plane function.

Must be a string of 1-64 characters.

Usage Guidelines Use this command to synchronize sessions to UPF.

subscriber session-synchronize-cp

Synchronizes sessions on CP.

Command Modes	Exec
----------------------	------

Syntax Description	<code>subscriber session-synchronize-cp upf user_plane_name [abort timeout timeout_value tps tps]</code>
---------------------------	--

abort

Specify to abort synchronization.

timeout *timeout_value*

Specify the timeout duration in minutes.

Must be an integer in the range of 2-100.

tps *tps*

Specify the TPS.

Must be an integer in the range of 40-4000.

upf *user_plane_name*

Specify name of the user plane function.

Must be a string of 1-64 characters.

Usage Guidelines	Use this command to synchronize sessions on CP.
-------------------------	---

system

Configures the NF's system operations.

Command Modes	Exec
----------------------	------

Syntax Description	<code>system { ops-center stop synch { start stop } upgrade uuid-override new-uuid <i>uuid_value</i> }</code>
---------------------------	---

ops-center stop

Stop the synching of configuration.

synch { start | stop }

Starts or stops the synching of configuration,

upgrade

Initiates the upgrade of a product.

uuid-override new-uuid *uuid_value*

Change the Universally Unique Identifier (UUID) to a new value.

Must be a string.

Usage Guidelines

Use this command to display the NF's system operations.

terminal

Configures the type of terminal.

Command Modes

Exec

Syntax Description

terminal *terminal_type*

terminal_type

Specify the terminal type.

Must be one of the following:

- ansi
- generic
- linux
- vt100
- xterm

Usage Guidelines

Use this command to configure the terminal type.

timestamp

Configures the timestamp parameters.

Command Modes

Exec

Syntax Description

timestamp { disable | enable }

{ disable | enable }

Enable or disable the timestamp display.

Usage Guidelines

Use this command to configure the timestamp.

user-plane

Configures the userplane configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description `user-plane userplane_name [[offline] [subscriber-profile subscriber_profile]]`

offline

Specify as offline.

subscriber-profile *subscriber_profile*

Specify the Subscriber Profile to associate at current level.

user-plane *userplane_name*

Specify name of the userplane.

Must be a string of 1-128 characters.

Usage Guidelines Use this command to configure the userplane configuration. The CLI prompt changes to the Userplane Configuration mode (config-user-plane-<userplane_name>).

user-plane peer-address

Configures the userplane IP address.

Command Modes Exec > Global Configuration > Userplane Configuration (config-user-plane-*userplane_name*)

Syntax Description `peer-address ipv4 ipv4_address`

ipv4 *ipv4_address*

Specify the IPv4 address.

Must be a string in the ipv4-address pattern. For information on the ipv4-address pattern, see the *Input Pattern Types* chapter.

Usage Guidelines Use this command to configure the userplane IP address.

user-plane port-id

Configures Port Identifier parameter.

Command Modes Exec > Global Configuration > Userplane Configuration (config-user-plane-*userplane_name*)

who

Syntax Description **port-id** *port_id* [**subscriber-profile** *subscriber_profile*]

port-id *port_id*

Specify the port identifier.

Must be a string of 1-128 characters.

subscriber-profile *subscriber_profile*

Specify the Subscriber Profile to associate to the Port Identifier level.

Usage Guidelines

Use this command to configure the Port Identifier parameter. The CLI prompt changes to the Port ID Configuration mode (config-port-id-<port_id>).

who

Displays information on currently logged on users.

Command Modes Exec

Syntax Description **who**

Usage Guidelines

Use this command to view information on currently logged on users. The command output displays the Session, User, Context, From (IP address), Protocol, Date, and Mode information.