



# cnBNG Installation and Configuration

---

- Feature Summary and Revision History, on page 1
- Feature Description, on page 2
- Installing cnBNG and Accessing BNG Ops Center, on page 3
- Mapping Pods with Node Labels, on page 18
- High Availability Support on BareMetal Server, on page 19
- cnBNG CNF Deployment on AIO BareMetal Server, on page 19
- cnBNG Cluster Deployment Using Inception Server, on page 27
- cnBNG Cluster Deployment Support on Red Hat OpenShift, on page 34
- Maintenance Operation Procedure (MOP) for cnBNG Node Scaling, on page 36

## Feature Summary and Revision History

### Summary Data

*Table 1: Summary Data*

Applicable Product(s) or Functional Area	cnBNG
Applicable Platform(s)	SMI
Feature Default Setting	Disabled - Configuration Required
Related Changes in this Release	Not Applicable
Related Documentation	Not Applicable

### Revision History

*Table 2: Revision History*

Revision Details	Release
Introduced support for cnBNG cluster deployment on Red Hat OpenShift.	2025.01.0

Revision Details	Release
Introduced Maintenance Operation Procedure (MOP) for cnBNG Node Scaling.	2024.03.0
Introduced support for cnBNG Cluster Deployment Using Inception Server.	2023.04.0
Introduced support for the cnBNG CNF Deployment on AIO BareMetal Server.	2022.02.0
cnBNG CP deployment on bare metal server is supported (with support for IPoE, PPPoE, LAC and LNS call models and High Availability) and fully qualified in this release.	2022.01.0
First introduced.	2021.01.0

## Feature Description

This chapter describes cnBNG installation and configuration using the Ultra Cloud Core Subscriber Microservices Infrastructure (SMI) Cluster Manager and the BNG Operations (Ops) Center. The BNG Ops Center is based on the ConfD command line interface (CLI).

To install the SMI Cluster Manager, refer to the "Deploying the SMI Cluster Manager on VMware vCenter" section in the *Ultra Cloud Core Subscriber Microservices Infrastructure - Deployment Guide*.

The SMI Ops Center is the platform to install the cnBNG cluster with the offline or online repository. It is mandatory to install the SMI Ops Center to set up and access the BNG Ops Center.



**Note**


To access the offline or online repository, contact your Cisco Account Manager or representative to get access to the offline or online repository.

## BNG Ops Center

The BNG Ops Center is a system-level infrastructure that provides the following functionality:

- A user interface to trigger a deployment of microservices with the flexibility of providing variable helm chart parameters to control the scale and properties of Kubernetes objects (deployment, pod, services, and so on) associated with the deployment.
- A user interface to push application-specific configuration to one or more microservices through Kubernetes configuration maps.
- A user interface to issue application-specific execution commands (such as show and clear commands). These commands:
  - Invoke some APIs in application-specific pods
  - Display the information returned on the user interface application

The following figure shows a sample of the web-based CLI presented to the user.



```

Username: admin
Warning: Permanently added '[localhost]:2024' (RSA) to the list of known hosts.
admin@localhost's password:
Welcome to the bng CLI on unknown
Copyright © 2016-2020, Cisco Systems, Inc.
All rights reserved.

admin connected from 127.0.0.1 using ssh on ops-center-bng-ops-center-88bb45476f-62jvw
Warning!!! Your password will expire in 9 days!

[unknown] bng# show running-config
helm default-repository bng-master
helm repository bng-lac
  access-token mgidutur:AKCp5ekcbPU5s1ifdwNvxqXjSchQKweH87sDlXxe9JktjKbpg6Yj9xufvMn9djkAy8UpZlo
  url      https://engcl-maven-master.cisco.com/artifactory/smi-fuse-internal-snapshot/mobile-cnat-bng/bng-products/dev-bng-lacIns/
exit
helm repository bng-master
  access-token mgidutur:AKCp5ekcbPU5s1ifdwNvxqXjSchQKweH87sDlXxe9JktjKbpg6Yj9xufvMn9djkAy8UpZlo
  url      https://engcl-maven-master.cisco.com/artifactory/smi-fuse-internal-snapshot/mobile-cnat-bng/bng-products/master/
exit
k8s name      unknown
k8s namespace  bng
k8s nf-name   bng
k8s registry  dockerhub.cisco.com/smi-fuse-docker-internal
k8s single-node true
k8s use-volume-claims false
k8s ingress-host-name 10.84.102.189.nip.io
aaa authentication users user admin
  uid      117
  gid      117
  password $1$K7Evtecp$MFHm3TJHzJNcfn1mHspMb1
  ssh_keydir /tmp/admin/.ssh
  homedir  /tmp/admin
exit
aaa ios level_0
  prompt "User "
exit
aaa ios level_15
  prompt "User "

```

The BNG Ops Center allows you to configure features such as licensing, REST endpoint, and CDL.

For information on how to deploy BNG Ops Center on bare metal servers (currently Cisco UCS-C servers) environment, see "Operating the SMI Cluster Manager on Bare Metal" section in the *Ultra Cloud Core Subscriber Microservices Infrastructure — Operations Guide*.

## Installing cnBNG and Accessing BNG Ops Center

This section describes how to install cnBNG and access the BNG Ops Center.

The Ultra Cloud Core SMI platform is responsible for setting up and managing the Cloud Native Broadband Network Gateway application.

## Prerequisites

Before installing cnBNG on the SMI layer in an offline environment:

- Ensure that the SMI Cluster Manager all-in-one (AIO) is installed. This helps orchestrate the K8s Cluster and load the image.
- Ensure that all SMI K8s cluster nodes are in Ready state.
- Run the SMI synchronization operation for the BNG Ops Center and Cloud Native Common Execution Environment (CN-CEE).

For CEE installation, refer to the *Ultra Cloud Core Common Execution Environment- Configuration and Administration Guide*.

- Ensure that the local repositories, which host the product offline TAR ball version, is installed.

## System Requirements

Feature	Description
Disk Space	2 x 800 GB SSD (RAID 1) or equivalent input/output operations per second (IOPS) and redundancy.
Hardware	<ul style="list-style-type: none"> <li>High-performance x86 64-bit chipset</li> <li>CPU performance Passmark benchmark of 13K rating per chip and 1,365 rating per thread, or better</li> <li>VMware ESXi-compatible</li> </ul> <p><b>Note</b> The following is recommended:</p> <ul style="list-style-type: none"> <li>Cisco UCSM5 series blade servers to achieve the best performance.</li> <li>All the host servers should be UCSC-C240-M5SX or UCSC-C220-M5SX.</li> <li>All the UCS systems should have SSD storage type.</li> <li>UCS C240M5 servers for better performance and to avoid infrastructure issues.</li> </ul>
Platform	VMware ESXi and VMware vCenter versions 6.5 and 6.7 <p><b>Note</b> SMI Cluster Manager support is qualified on the preceding platforms.</p>
Memory	<ul style="list-style-type: none"> <li>At least DDR3-1600 or better than 1600 MT/s</li> <li>ECC</li> </ul>
Deployment Requirement	Hardware oversubscription, network saturation, or CPU oversubscription reduces application performance and productivity. The Cisco Ultra Cloud Core Subscriber Microservices Infrastructure detects and takes action when infrastructure requirements are not met.

## Installing cnBNG in an Offline Environment

Using the SMI Cluster Manager, download the offline TAR ball of the cnBNG, the host and its charts, and corresponding images in the local registries. The SMI Cluster Manager supports the deployment of the BNG Ops Center and all the applications and services associated with it. This section describes the procedures involved in installing cnBNG in an offline environment using the SMI Cluster Manager.

To install cnBNG, complete the following steps:

- Download the TAR ball from the URL.

```
software-packages download URL
```

**Example:**

```
SMI Cluster Manager# software-packages download
http://<ipv4address>:<port_number>/packages/bng-2021-02-1.tar
```

2. Verify whether the TAR balls are loaded.

```
software-packages list
```

**Example:**

```
BNG Cluster Manager# software-packages list
[ bng-2021-02-1 ]
[ sample ]
```

3. Configure the necessary SMI Ops Center parameters in the cluster to install cnBNG.

```
config
  cluster cluster_name
    ops-centers app_name instance_name
      repository url
      netconf-ip ipv4_address
      netconf-port port
      ssh-ip ipv4_address
      ssh-port port
      ingress-hostname <ipv4_address>.<customer_specific_domain_name>
      initial-boot-parameters use-volume-claims true/false
      initial-boot-parameters first-boot-password password
      initial-boot-parameters auto-deploy true/false
      initial-boot-parameters single-node true/false
      initial-boot-parameters image-pull-secrets
    exit
  exit
```

**Example:**

```
SMI Cluster Manager# config
Entering configuration mode terminal
SMI Cluster Manager(config)# clusters cnbng-smi-cluster-01
SMI Cluster Manager(config-clusters-cnbng-smi-cluster-01)# ops-centers bng bng
SMI Cluster Manager(config-ops-centers-bng/bng)# repository
https://charts.10.10.105.50.nip.io/bng-2021.02.1
SMI Cluster Manager(config-ops-centers-bng/bng)# ingress-hostname 10.10.105.34.nip.io
SMI Cluster Manager(config-ops-centers-bng/bng)# initial-boot-parameters use-volume-claims
true
SMI Cluster Manager(config-ops-centers-bng/bng)# initial-boot-parameters
first-boot-password test123
SMI Cluster Manager(config-ops-centers-bng/bng)# initial-boot-parameters auto-deploy
false
SMI Cluster Manager(config-ops-centers-bng/bng)# initial-boot-parameters single-node
false
SMI Cluster Manager(config-ops-centers-bng/bng)# exit
SMI Cluster Manager(config-clusters-cnbng-smi-cluster-01)# exit
SMI Cluster Manager(config)#
```

4. Configure the secrets, if your local registry contains secrets.

```
config
  cluster cluster_name
    secrets docker-registry secret_name
      docker-server server_name
      docker-username username
      docker-password password
```

```

docker-email email
namespace k8s namespace
commit
exit
exit

```

**Example:**

```

SMI Cluster Manager# config
SMI Cluster Manager(config)# clusters test2
SMI Cluster Manager(config-clusters-test2)# secrets docker-registry sec1
SMI Cluster Manager(config-docker-registry-sec1)# docker-server serv1
SMI Cluster Manager(config-docker-registry-sec1)# docker-username user1
SMI Cluster Manager(config-docker-registry-sec1)# docker-password Cisco@123
SMI Cluster Manager(config-docker-registry-sec1)# docker-email reg@cisco.com
SMI Cluster Manager(config-docker-registry-sec1)# bng bng
SMI Cluster Manager(config-docker-registry-sec1)# exit
SMI Cluster Manager(config-clusters-test2)# exit
SMI Cluster Manager(config)#

```

**5.** Run the cluster synchronization.

```
clusters cluster_name actions sync run
```

**Example:**

```
SMI Cluster Manager# clusters cnbng-smi-cluster-01 actions sync run
```

**Notes:**

- **software-packages download** *url*—Specifies the software packages to be downloaded through HTTP/HTTPS.
- **software-packages list**—Specifies the list of available software packages.
- **ops-centers** *app\_name instance\_name*—Specifies the BNG Ops Center and instance. *app\_name* is the application name. *instance\_name* is the name of the instance.
- **repository** *url*—Specifies the local registry URL for downloading the charts.
- **netconf-ip** *ipv4\_address*—Specifies the BNG Ops Center netconf IPv4 address.
- **netconf-port** *port*—Specifies the BNG Ops Center netconf port number.
- **ssh-ip** *ipv4\_address*—Specifies the SSH IPv4 address for the BNG Ops Center.
- **ssh-port** *port*—Specifies the SSH port number for the BNG Ops Center.
- **ingress-hostname** <*ipv4\_address*>.<*customer\_specific\_domain\_name*>—Specifies the ingress hostname to be set to the BNG Ops Center. <*customer\_specific\_domain\_name*> specifies the domain name of the customer.
- **initial-boot-parameters**—Specifies the initial boot parameters for deploying the helm charts.
  - **use-volume-claims** *true/false*—Specifies the usage of persistent volumes. Set this option to True to use persistent volumes. The default value is true.
  - **first-boot-password** *password*—Specifies the first boot password for the product's Ops Center.
  - **auto-deploy** *true/false*—Auto deploys all the services of the product. Set this option to false to deploy only the product's Ops Center.

- **single-node** *true/false*—Specifies the product deployment on a single node. Set this option to false for multi node deployments.
- **image-pull-secrets**—Specifies the docker registry secret name to be used.
- **secrets docker-registry** *secret\_name*—Specifies the secret name for your docker registry.
  - **docker-server** *server\_name*—Specifies the docker server name.
  - **docker-username** *username*—Specifies the docker registry user name.
  - **docker-password** *password*—Specifies the docker registry password.
  - **docker-email** *email*—Specifies the docker registry email.
  - **namespace** *namespace*—Specifies the docker registry namespace.

## Verifying the cnBNG Installation

Verify the status of the cnBNG installation deployment through the cnBNG CLI. To verify, use the following commands:

1. Log in to the cnBNG product CLI.
2. Verify whether the charts are loaded in the specific instance (verify the namespace).

**show helm charts**

**Example:**

```
bng# show helm charts
CHART      INSTANCE      STATUS      VERSION      REVISION      RELEASE      NAMESPACE
-----
infra-charts - DEPLOYED 0.0.6-rel-2021-01-0073-210208130850-fac5207 1 bng-bng-infra-charts
  bng-bng
oam-pod - DEPLOYED 0.1.2-rel-2021-01-0144-210122165946-fcb74ed 1 bng-bng-oam-pod bng-bng
bng-dashboard - DEPLOYED 0.0.1-rel-2021-01-0039-210122165311-0d542be 1
  bng-bng-bng-dashboard bng-bng
etcd-cluster - DEPLOYED 0.7.0-0-7-0060-210203074532-f118407 1 bng-bng-etcd-cluster bng-bng
ngn-datastore - DEPLOYED 1.3.0-1-3-0782-210125161812-f50a892 1 bng-bng-ngn-datastore
  bng-bng
```

3. Verify the status of the system.

**show system status**

**Example:**

```
bng# show system status
system status deployed true
system status percent-ready 100.0
```

### Notes:

- **show helm charts**—Displays the helm release details.
- **show system status**—Displays the status of the system.

# Accessing BNG Ops Center

You can connect to the BNG Ops Center through SSH.

```
ssh admin@ops_center_pod_ip -p 2024
```

## Day 0 Configuration

To view the Day 0 configuration, run the following command.

```
show running-config
```

The following is a sample Day 0 configuration:

```
luser@cnbng-smi-cluster-master1:~$ kubectl get svc -n bng-bng | grep ops-center-bng-bng-ops-center
NAME                      TYPE      CLUSTER-IP      EXTERNAL-IP      PORT(S)
ops-center-bng-bng-ops-center   ClusterIP  10.96.151.115  <none>
8008/TCP,8080/TCP,2024/TCP,2022/TCP,7681/TCP  7m37s
luser@cnbng-smi-cluster-master1:~$ ssh admin@10.96.151.115 -p 2024
Warning: Permanently added '[10.96.151.115]:2024' (RSA) to the list of known hosts.
admin@10.96.151.115's password:

Welcome to the bng CLI on cnbng-smi-cluster/bng
Copyright © 2016-2020, Cisco Systems, Inc.
All rights reserved.

admin connected from 192.202.0.1 using ssh on ops-center-bng-bng-ops-center-7bdd4cc48-fmb61
[cnbng-smi-cluster/bng] bng# show running-config
system mode running
helm default-repository base-repos
helm repository base-repos
url
https://engci-maven-master.cisco.com/artifactory/smi-fuse-internal-snapshot/mobile-cnat-bng/bng-products/master/
username <username>
password <password>
exit
k8s name      cnbng-smi-cluster
k8s namespace  bng-bng
k8s nf-name    bng
k8s registry   dockerhub.cisco.com/smi-fuse-docker-internal
k8s single-node false
k8s use-volume-claims true
k8s ingress-host-name 192.0.2.2.nip.io
aaa authentication users user admin
  uid      1117
  gid      1117
  password $1$EmkQjvc0$o8K5tXmUzN1.drQgCL0A2/
  ssh_keydir /tmp/admin/.ssh
  homedir   /tmp/admin
  exit
aaa ios level 0
prompt "\h> "
exit
aaa ios level 15
prompt "\h# "
exit
aaa ios privilege exec
level 0
  command action
  exit
  command autowizard
```

```
exit
command enable
exit
command exit
exit
command help
exit
command startup
exit
exit
level 15
  command configure
  exit
exit
exit
nacm write-default deny
nacm groups group admin
user-name [ admin ]
exit
nacm rule-list admin
group [ admin ]
rule any-access
  action permit
exit
exit
nacm rule-list confd-api-manager
group [ confd-api-manager ]
rule any-access
  action permit
exit
exit
nacm rule-list ops-center-security
group [ * ]
rule change-self-password
  module-name      ops-center-security
  path            /smiuser/change-self-password
  access-operations exec
  action          permit
exit
rule smiuser
  module-name      ops-center-security
  path            /smiuser
  access-operations exec
  action          deny
exit
exit

deployment
  app-name      BNG
  cluster-name Local
  dc-name       DC
exit
k8 bng
  etcd-endpoint      etcd:2379
  datastore-endpoint datastore-ep-session:8882
  tracing
    enable
    enable-trace-percent 30
    append-messages      true
    endpoint             jaeger-collector:9411
  exit
exit
k8 label protocol-layer key smi.cisco.com/node-type value protocol
exit
k8 label service-layer key smi.cisco.com/node-type value service
```

```

exit
k8 label cdl-layer key smi.cisco.com/node-type value session
exit
k8 label oam-layer key smi.cisco.com/node-type value oam
exit
instances instance 1
  system-id DC
  cluster-id Local
  slice-name 1
exit
local-instance instance 1
system mode shutdown
helm default-repository base-repos
helm repository base-repos
  url
  https://engci-maven-master.cisco.com/artifactory/smi-fuse-internal-snapshot/mobile-cnat-bng/bng-products/master/

  username smf-deployer.gen
  password ***
exit
k8s name      svi-cn-bng-tb3
k8s namespace  bng-bng
k8s nf-name    bng
k8s registry   dockerhub.cisco.com/smi-fuse-docker-internal
k8s single-node false
k8s use-volume-claims true
k8s ingress-host-name 10.81.103.86.nip.io
aaa authentication users user admin
  uid      1117
  gid      1117
  password $1$vDWeJvJm$v46wiBWqdOj7eWgoPoZZE/
  ssh_keydir /tmp/admin/.ssh
  homedir   /tmp/admin
exit
aaa ios level 0
  prompt "\h> "
exit
aaa ios level 15
  prompt "\h# "
exit
aaa ios privilege exec
  level 0
    command action
    exit
  command autowizard
  exit
  command enable
  exit
  command exit
  exit
  command help
  exit
  command startup
  exit
  exit
  level 15
    command configure
    exit
  exit
  exit
nacm write-default deny
nacm groups group admin
  user-name [ admin ]
exit

```

```
nacm rule-list admin
  group [ admin ]
    rule any-access
      action permit
    exit
  exit
nacm rule-list confd-api-manager
  group [ confd-api-manager ]
    rule any-access
      action permit
    exit
  exit
nacm rule-list ops-center-security
  group [ * ]
    rule change-self-password
      module-name      ops-center-security
      path            /smiuser/change-self-password
      access-operations exec
      action          permit
    exit
    rule smiuser
      module-name      ops-center-security
      path            /smiuser
      access-operations exec
      action          deny
    exit
  exit
```

## CP and UP Service Configuration

The CP service requires the basic configuration to process the API calls.



**Note** For information about the User Plane service configuration, refer to the *Cloud Native BNG User Plane Configuration Guide for Cisco ASR 9000 Series Routers, IOS XR Release 7.3.x*

### Configuring the CP

The CP configuration is provided using the Ops Center infrastructure.

The following is a sample CP configuration:

```
ipam
  instance 1
    source local
    address-pool <dummy-pool-1>
      vrf-name default
      ipv4
        split-size
          per-cache 8192
          per-dp    8192
        exit
        address-range 10.0.0.1 10.10.255.255
      exit
      ipv6
        address-ranges
          split-size
            per-cache 8192
            per-dp    8192
```

```

        exit
        address-range 2001:DB8::1 2001:DB8::ff00
    exit
    prefix-ranges
        split-size
            per-cache 8192
            per-dp    1024
        exit
        prefix-length 56
        prefix-range 2001:db0:: length 40
    exit
    exit
    address-pool dummy-pool2
    vrf-name default
    ipv6
        prefix-ranges
            split-size
                per-cache 8192
                per-dp    1024
            exit
            prefix-range 2001:DB8:: length 48
        exit
    exit
    exit
    address-pool slaac-radius
    vrf-name default
    ipv6
        prefix-ranges
            split-size
                per-cache 8192
                per-dp    1024
            exit
            prefix-range 2001:DB8:: length 48
        exit
    exit
    exit
    address-pool static-dummy-pool2
    vrf-name default
    static enable user-plane dummy-asr9k-1
    ipv6
        prefix-ranges
            split-size
                no-split
            exit
            prefix-range 2001:DB8:: length 48
        exit
    exit
    exit
    exit
    cdl node-type session
    cdl logging default-log-level error
    cdl datastore session
        slice-names [ 1 ]
    endpoint replica 2
    endpoint settings slot-timeout-ms 750
    index replica 2
    index map 1
    slot replica 2
    slot map 2
    slot notification limit 300
    exit
    cdl kafka replica 1

```

```
!
profile dhcp dummy-dhcp-server1
  ipv4
    mode server
    server
      pool-name  dummy-pool-1
      dns-servers [ network-dns ]
      lease days 1
      lease hours 2
      lease minutes 3
    exit
  exit
  ipv6
    mode server
    server
      iana-pool-name dummy-pool-1
      iapd-pool-name dummy-pool-1
      lease days 10
      lease hours 0
      lease minutes 4
    exit
  exit
profile pppoe pppoe-prof
  mtu 1500
  ctrl-pkt-priority 7
  service-selection-disable true
  max-payload minimum 1492 maximum 1540
  session-limit max 64000 threshold 60000
exit
profile pppoe ppp1
  mtu 1492
exit
profile aaa dummy-aaa-prof
  authentication
    method-order [ dummy-ser-grp ]
  exit
  authorization
    type subscriber method-order [ dummy-ser-grp ]
    username identifier client-mac-address
    password <any-password>
  exit
  accounting
    method-order [ dummy-ser-grp ]
  exit
exit
profile server-group dummy-ser-grp
  radius-group dummy-ser-grp
exit
profile attribute-format attr1
  format-order [ client-mac-address ]
exit
profile attribute-format attr2
  format-order [ addr ]
exit
profile attribute-format attr3
  format-order [ username ]
exit
profile subscriber dummy-subs-prof
  dhcp-profile           dummy-dhcp-server1
  pppoe-profile          ppp1
  session-type            ipv4v6
  activate-feature-templates [ svc1 VOICE TV ]
  aaa authorize dummy-aaa-prof
```

```

exit
profile feature-template VOICE
qos
  in-policy  VOICE_INGRESS
  out-policy  VOICE_EGRESS
  merge-level 40
exit
exit
profile feature-template APPS
  httpr-policy ACCESS-PBR
exit
profile feature-template TV
qos
  in-policy  TV_INGRESS
  out-policy  TV_EGRESS
  merge-level 50
exit
exit
profile feature-template svc1
  vrf-name default
  ipv4
    mtu          1492
    disable-unreachables
    verify-unicast-source reachable-via-rx
  exit
  ipv6
    mtu          1492
    ingress-acl    ipv6-acl-in-1
    egress-acl    ipv6-acl-out-1
    disable-unreachables
    verify-unicast-source reachable-via-rx
  exit
  session-accounting
    enable
    aaa-profile    dummy-aaa-prof
    periodic-interval 1800
  exit
exit
!
profile feature-template HSI_100M_5MQ
qos
  in-policy  HSI_UPLOAD_RATE_100MB_IN
  out-policy  HSI_DOWNLOAD_RATE_100MB_OUT
  merge-level 30
exit
service-accounting
enable
  aaa-profile    aaa-profil
  periodic-interval 120
exit
exit
profile feature-template HSI_100M_30MQ
qos
  in-policy  HSI_UPLOAD_RATE_100MB_IN
  out-policy  HSI_DOWNLOAD_RATE_100MB_OUT
  merge-level 30
exit
service-accounting
enable
  aaa-profile    dummy-aaa-prof
  periodic-interval 1800
exit
exit
profile radius

```

```
algorithm first-server
deadtime 2
detect-dead-server response-timeout 30
max-retry 3
timeout 5
server 10.1.2.3 1812
  type auth
  secret <password>
  priority 1
exit

server 2001::10:1:36:121 1812
  type auth
  secret cisco
  priority 1
exit
server 10.1.2.3 1813
  type acct
  secret <password>
  priority 1
exit
server 2001::10:1:36:121 1813
  type acct
  secret cisco
  priority 1
exit
attribute
  nas-identifier CISCO-BNG
  nas-ip <209.165.201.1>
  nas-ipv6 2001::250:56ff:fe95:658
  nas-ip user-plane-ip
  instance 1
  exit
exit
accounting
  attribute
    nas-ip <209.165.201.1>
    nas-ipv6 2001::10:1:7:95
  exit
exit
server-group dummy-ser-grp
  server auth 10.1.2.3 1812
  exit
  server acct 10.1.2.3 1813
  exit
  server auth 2001::10:1:36:121 1812
  exit
  server acct 2001::10:1:36:121 1813
  exit
  exit
exit
profile coa
  client 10.1.2.3
  server-key <password>
exit
client 2001::10:1:36:111
  server-key cisco
exit
user-plane
  instance 1
  user-plane dummy-asr9k-1
    peer-address ipv4 209.165.201.3
    subscriber-profile dummy-subs-prof
  exit
```

```

user-plane dummy-asr9k-2
  peer-address ipv4 209.165.201.2
  subscriber-profile dummy-subs-prof
  exit
exit
instance instance-id 1
  endpoint sm
    replicas 1
  exit
  endpoint l2tp-tunnel
    replicas 1
  exit
  endpoint nodemgr
    replicas 1
  exit
  endpoint n4-protocol
    replicas 1
    retransmission max-retry 1
  exit
  endpoint dhcp
    replicas 1
  exit
  endpoint pppoe
    replicas 1
  exit
  endpoint radius
    interface coa-nas
      vip-ip <209.165.201.1> vip-port 2000
      vip-ipv6 2001::10:1:39:191 vip-ipv6-port 2000
    exit
  exit
  endpoint udp-proxy
    vip-ip <209.165.201.1>
    vip-ipv6 2001::10:1:39.192
    interface n4
      sla response 180000
    exit
    interface gtpu
      sla response 180000
    exit
  exit
  exit
logging level application error
logging level transaction error
logging level tracing error
logging name infra.affinity_cache.core level application off
logging name infra.application.core level application off
logging name infra.bgipcstream.core level application off
logging name infra.cache_client.core level application off
logging name infra.cdl_update_queue.core level application off
logging name infra.config.core level application off
logging name infra.diagnostic.core level application off
logging name infra.diagnostics.core level application off
logging name infra.dpd.core level application off
logging name infra.ds_client.core level application off
logging name infra.edr.core level application off
logging name infra.heap_dump.core level application off
logging name infra.ipc_action.core level application off
logging name infra.ipcstream.core level application off
logging name infra.memory_cache.core level application off
logging name infra.message_trace.core level application off
logging name infra.resource_monitor.core level application off
logging name infra.resource_monitor_load_factor.core level application off

```

```

logging name infra.rest_server.core level application off
logging name infra.session_cache.core level application off
logging name infra.topology.core level application off
logging name infra.topology_lease.core level application off
logging name infra.transaction.core level application off
logging name infra.virtual_msg_queue.core level application off
logging name infra.vrf_etcd_update.core level application off
deployment
  app-name      BNG
  cluster-name  Local
  dc-name       DC
exit
k8 bng
  etcd-endpoint      etcd:2379
  datastore-endpoint datastore-ep-session:8882
  tracing
    enable
    enable-trace-percent 30
    append-messages      true
    endpoint             jaeger-collector:9411
exit
k8 label protocol-layer key smi.cisco.com/proto-type value protocol
exit
k8 label service-layer key smi.cisco.com/svc-type value service
exit
k8 label cdl-layer key smi.cisco.com/sess-type value cdl-node
exit
k8 label oam-layer key smi.cisco.com/node-type value oam
exit
resource cache-pod
  gomaxproc 8
exit
instances instance 1
  system-id  DC
  cluster-id Local
  slice-name 1
exit
local-instance instance 1
system mode <shutdown or running>
commit
end

```

## Configuring the UP

The following is a sample UP configuration:

```

user-plane
  instance 1
    user-plane dummy-asr9k-1
      peer-address ipv4 209.165.201.3
      subscriber-profile dummy-subs-prof
    exit
    user-plane dummy-asr9k-2
      peer-address ipv4 209.165.201.2
      subscriber-profile dummy-subs-prof
    exit
  exit
exit

```

## Loading Day1 Configuration

To load the Day 1 configuration for cnBNG, run the following command:

```
ssh admin@ops_center_pod_ip -p 2024 < Day1config.cli
```



**Note** The **day1config.cli** file contains the necessary parameters required for the Day 1 configuration.

Alternatively, you can copy the configuration and paste it in the BNG Ops Center CLI to load the Day 1 configuration.

```
config
<Paste the Day 1 configuration here>
commit
exit
```

### Day1config.cli

The **day1config.cli** file contains the Day 1 configuration for cnBNG. For a sample day1 configuration, see [Configuring the CP, on page 11](#).

## Mapping Pods with Node Labels

### Prerequisites

- Ensure that the node labels are according to the pod deployment layout.
- Ensure that the external VIPs are according to the requirement of NF.
- Enable Istio for pod to pod traffic load balancing.

Node Labels are key and value pairs that are attached to nodes at cluster synchronization. Each node can have a set of key and value labels defined. Each key must be unique for a node. With labels, users can map their NF pods onto nodes in a loosely coupled manner.



### Important

- The pod-level labeling configuration is applicable only when the cnBNG CP is deployed on a bare metal server.
- Ensure to configure the node label on the SMI cluster deployer before mapping the pods. Following is the sample command for master-1 labeling:

```
[cndp-clpnc-cm-cm-primary] SMI Cluster Deployer (config-nodes-master-1)# k8s node-labels
smi.cisco.com/svc-type bng-node
```

To map the pods with node labels, use the following sample configuration:

```
config
  k8 label protocol-layer key label_key value label_value
  k8 label service-layer key label_key value label_value
  k8 label cdl-layer key label_key value label_value
  k8 label oam-layer key label_key value label_value
end
```

Following is an example configuration of pod to node-label mapping:

```

k8 label protocol-layer key smi.cisco.com/node-type value bng-proto
exit
k8 label service-layer key vm-type value bng-svc
exit
k8 label cdl-layer key smi.cisco.com/node-type value bng-cdl
exit
k8 label oam-layer key smi.cisco.com/node-type value oam
exit

```

## High Availability Support on BareMetal Server

High Availability on cnBNG CP is validated on BareMetal server deployment. For more information about High Availability, see [High Availability and CP Reconciliation](#).

## cnBNG CNF Deployment on AIO BareMetal Server

The cnBNG CNF Deployment on AIO BareMetal Server explains the process of onboarding a cnBNG Cloud Native Function (CNF) on the Cloud Native Deployment Platform (CNDP) on the BareMetal all-in-one (AIO) Kubernetes (K8s) cluster.

In the AIO deployment, all the management VMs are hosted on a different UCS server, however, this depends on the deployment strategy.


The cnBNG CNF is hosted on another UCS server referred as AIO server. During installation, the Cluster Manager (CM) accesses the AIO via the Cisco Integrated Management Controller (IMC) interface and adds the respective image and SMI packages to complete the installation.



**Note**

The management VMs are the Inception, Cluster Manager, and RADIUS servers.


*Figure 1: Logical Topology for cnBNG CNF Deployment on AIO BareMetal Server*



522506

## BareMetal CNDP AIO Bring-Up Procedure


The CNDP is a 'SMI Bare-Metal'. The Cluster Manager uses REST APIs (instead of VIM APIs) of the management cards, which are on the servers, to create a set of Linux servers and then loads the K8s software.



Before installing network functions (NF) on the Cluster Manager, the common containerized software from SMI is installed. For example, monitoring and logging. The SMI NFs include their own common containerized software.

## BareMetal CNDP AIO Bring-Up Procedure

The following figure illustrates the step-by-step process that is required to bring up the cnBNG CNF on K8s AIO server.



For more information about the Inception, Cluster Manager, and All-in-One server installation, see the "SMI Cluster Manager - Deployment" chapter of the [Ultra Cloud Core Subscriber Microservices Infrastructure - Deployment Guide](#).

## Limitations and Restrictions

The cnBNG CNF Deployment on AIO BareMetal Server has the following limitations and restrictions:

- Simulated User Planes (UPs) are used in the characterisation activity.
- ASR 9000 routers will be used in the topology based on availability in future releases.
- Actual customer profile must be validated before deployment.

## Implementing cnBNG CP Validation with CNDP

Implementing cnBNG CP Validation with CNDP involves the following procedures.

- Prerequisites
- Instantiating and Provisioning Inception Server Instance
- Installing the Cluster Manager Node
- Deploying the All-in-One Cluster
- Integrating RADIUS and UP with the AIO BareMetal Server

## Prerequisites


The following sections detail the prerequisites for deploying the cnBNG CNF on the AIO BareMetal Server.

### Instantiating and Provisioning Inception Server Instance

The Inception server is used to deploy the CM for CNDP deployment. It is an Ubuntu 18.04 based VM installed with additional packages such as, docker, docker-compose, and its dependencies. The offline tar ball for the CNDP CM is installed on this instance and configured to deploy the CNDP CM nodes.

The following section presents the procedure on how to bring up an Inception server instance on a VM.

Figure 2: CNDP Inception VM



- The inception server is an Ubuntu 18.04 platform (VM or Host) brought up using SMI base image iso.
- To instantiate CNDP CM, the CNDP CM offline tar ball is downloaded to the inception server platform.
- Using this, CNDP CM nodes can be instantiated in Standalone or HA pair.

522227

Before beginning the configuration of the Inception server, verify that all the dependent packages such as docker, docker-compose are installed on the VM. This is a prerequisite before loading the tar ball to configure and deploy the CM. If the SMI Base-ISO is used for installing Inception server, the packages are preinstalled.

## Installing Cluster Manager Node

The Cluster Manager (CM) handles the installation and upgrade of the Kubernetes (K8s) cluster and associated infrastructure. In this deployment, the Inception server launches two machines that use DRBD to replicate the state to provide High Availability (HA) of the CM. This section covers the bring up procedure of the CM in standalone mode.

For High Availability CM deployment, see the "SMI Cluster Manager - Deployment" chapter of the [Ultra Cloud Core Subscriber Microservices Infrastructure - Deployment Guide](#).

### Configuring the Cluster Manager - Single Instance

Configure the single instance of the CM:

1. Login to the Ops Center CLI of the Inception server. Use the following steps to install and configure the CM.

Use the IP address of the Inception server to login.

```
ssh admin@<ip_address> -p 2022    (or)
https://cli.smi-deployer.<ip_address>.nip.io
```

2. Configure the Inception server cluster deployer to install the CM.



**Note** Ensure the following before configuring the CM.

- All the passwords must be typed manually because copying and pasting the encrypted passwords from the configuration throws an error during validation
- Private key and public key must be generated in the Inception VM and copied. Both the keys must match the keys present in the Inception VM. Use the **ssh-keygen** command in the Inception VM and follow the prompts to generate the keys.
- Private key and public key are multiline commands. For instance, after typing **node-defaults ssh-connection- private-key**, press Enter to paste the keys.

For the Inception configuration, see the "SMI Cluster Manager - Deployment" chapter of the [Ultra Cloud Core Subscriber Microservices Infrastructure - Deployment Guide](#).



**Note** Modify IPs, password, keys , username , cluster-name, and CNF name based on the specified configurations.

## Installing the All-in-One Cluster

This section provides the detailed steps to deploy the CNDP AIO (K8s) cluster from the CM node. It also specifies the CLI that is used on the CM to configure and perform a cluster synchronization operation.

### Configuring the AIO Cluster

This section describes the procedure to configure and deploy the CNDP AIO cluster from the CM using the CLI method.

1. Login to the CM Ops Center and load the SMI cluster, cnBNG, CEE, and Ops Center node configurations. Multiline configuration for private key must be pasted separately.  

```
ssh admin@<ip_address> -p 2022
```
2. Update the Sha256 value, which was generated for the software from the previous step, in the configuration for the respective software under the sha256 section.



**Note**

- All the passwords must be typed manually because copying and pasting the encrypted passwords from the configuration throws an error during validation
- Private key and public key must be generated in the CM and copied in. Both the keys must match the keys present in the CM. Use the **ssh-keygen** command in the Inception VM and follow the prompts to generate the keys.

3. Before running cluster synchronization, enable detail logging using the following configuration.

```
clusters <cluster_name>
configuration restrict-logging false exit
```

4. From the SMI cluster configuration, configure the Software CNF repository to use the cnBNG image, CEE, and include the sha256 checksum as generated previously and provide the path of the image.

For more information, see the "SMI Cluster Manager - Deployment" chapter of the [Ultra Cloud Core Subscriber Microservices Infrastructure - Deployment Guide](#).

```
[inception] SMI Cluster Deployer# show running-config
software cnf <cnf_software_version>c
  url      <repo_url>
  user     <user_name>
  password <password>
  sha256   <SHA256_hash_key>
exit
```

Example:

```
Cluster Manager# config
Cluster Manager(config)# software cnf <example=cm-2020-02-0-i06>
Cluster Manager(config)# url <repo_url>
Cluster Manager(config)#user <username>
Cluster Manager(config)#password "<password>"
Cluster Manager(config)#sha256 <sha256_key>
Cluster Manager(config)#exit
```

In this deployment model, a single AIO node is deployed.

From a CM configuration perspective, the AIO node definition, corresponding Ops Center CEE and cnBNG instances are defined as part of a single AIO cluster.

The following configuration snippet shows the sample configuration for a cluster from the cluster manager

```
config
  software cnf <cnf_software_version>
  url <repo_url>
  user <user_name>
  password <password>
  sha256 <SHA256_hash_key>
  exit
environments bare-metal
  ucs-server
  exit
clusters <cluster_name> #For example, cndp-testbed
  environment bare-metal
  addons ingress bind-ip-address <IPv4address>
  addons cpu-partitioner enabled
  configuration allow-insecure-registry true
  node-defaults ssh-username <username>
  node-defaults ssh-connection-private-key
    "-----BEGIN OPENSSH PRIVATE KEY-----\n<SSH_private_key>\n-----END OPENSSH PRIVATE KEY-----\n"
  node-defaults initial-boot default-user <username>
  node-defaults initial-boot default-user-ssh-public-key
    "<SSH_Public_Key>"
  node-defaults initial-boot default-user-password #For example, Csco123#
  node-defaults os proxy https-proxy <proxy_server_url>
  node-defaults os proxy no-proxy <proxy_server_url>/IPv4address>
  node-defaults os ntp enabled
  node-defaults os ntp servers <ntp_server>
  exit
  node-defaults initial-boot netplan ethernets <interface_name> #For example, en0
    dhcp4 false
    dhcp6 false
    gateway4 <IPv4address>
    nameservers search <nameserver>
```

```
nameservers addresses <IPv4addresses>
exit
node-defaults initial-boot netplan ethernets eno2 # same like eno1 other interfaces to
be configured
  dhcp4 false
  dhcp6 false
exit
node-defaults initial-boot netplan ethernets eno5
  dhcp4 false
  dhcp6 false
exit
node-defaults initial-boot netplan ethernets eno6
  dhcp4 false
  dhcp6 false
exit
node-defaults initial-boot netplan ethernets enp216s0f0
  dhcp4 false
  dhcp6 false
exit
node-defaults initial-boot netplan ethernets enp216s0f1
  dhcp4 false
  dhcp6 false
exit
node-defaults initial-boot netplan ethernets enp94s0f0
  dhcp4 false
  dhcp6 false
exit
node-defaults initial-boot netplan ethernets enp94s0f1
  dhcp4 false
  dhcp6 false
exit
node-defaults initial-boot netplan vlans <vlan_name> #For example, vlan309
  dhcp4 false
  dhcp6 false
  id   <vlan_id> #For example, 309
  link eno6
exit
node-defaults initial-boot netplan vlans <vlan_name> #For example, vlan310
  dhcp4 false
  dhcp6 false
  id   <vlan_id> #For example, 310
  link eno6
exit
node-defaults initial-boot netplan vlans <vlan_name> #For example, vlan311
  dhcp4 false
  dhcp6 false
  id   <vlan_id> #For example, 311
  link enp94s0f0
exit
node-defaults ucs-server cimc user admin
node-defaults ucs-server cimc storage-adaptor create-virtual-drive true
node-defaults ucs-server cimc remote-management sol enabled
node-defaults ucs-server cimc remote-management sol baud-rate 115200
node-defaults ucs-server cimc remote-management sol comport com0
node-defaults ucs-server cimc remote-management sol ssh-port 2400
node-defaults ucs-server cimc networking ntp enabled
node-defaults ucs-server cimc networking ntp servers <example: ntp.server1.com>
exit
node-defaults ucs-server cimc networking ntp servers <example: ntp.server2.com>
exit
node-defaults os ntp enabled
node-defaults os ntp servers <example: ntp.server1.com>
exit
node-defaults os ntp servers <example: ntp.server1.com>
```

```

exit

nodes <aio> #For example it can be master or aio
k8s node-type master
k8s ssh-ip <IPv4address>
k8s node-ip <IPv4address>
k8s node-labels disktype ssd
exit
k8s node-labels smi.cisco.com/node-type oam
exit
ucs-server cimc user admin
ucs-server cimc password <IPv4address> #this CIMCI address of the AIO UCS SERVER
ucs-server cimc ip-address 10.81.103.117
initial-boot netplan ethernets eno1
addresses [ <IPv4address-mgmt>/24 ]
gateway4 <gateway-address>
exit
initial-boot netplan vlans vlan309
addresses [ <IPv4address-k8s>/24 ]
exit
initial-boot netplan vlans vlan310
addresses [ <IPv4address-SMI>/24 ]
exit
initial-boot netplan vlans vlan311
addresses [ <IPv4address-services>/24 ]
exit
exit

```

Each CNF provides a Confd based Ops Center CLI to configure and manage the CNF pods. There is a separate Ops Center required for each CNF deployed on the AIO node.

The following is the Ops Center configuration for the AIO node, which has the Ops Center configuration for CEE and CNF.

```

ops-centers bng bng
repository <url> or offline-tarball
username <username>
password <password>
ingress-hostname <ip-address>.nip.io
initial-boot-parameters use-volume-claims false
initial-boot-parameters first-boot-password <password>
initial-boot-parameters auto-deploy false
initial-boot-parameters single-node true
exit
ops-centers cee cee
repository-local cee-release-build
sync-default-repository true
netconf-ip <ip-address>
netconf-port 2024
ssh-ip <ip-address>
ssh-port 2022
ingress-hostname <ip-address>.nip.io
initial-boot-parameters use-volume-claims true
initial-boot-parameters first-boot-password <password>
initial-boot-parameters auto-deploy true
initial-boot-parameters single-node true
exit
exit

```



**Note** To bring the network function NF at the AIO K8 cluster, always use the “initial-boot-parameters single-node true” option.

- Run the cluster synchronization to deploy the cluster, cnBNG, and CEE Ops Centers

```
clusters cndp-cm actions sync run debug true
```

The cluster synchronization operation takes approximately 45 minutes to complete.

- Monitor the cluster synchronization operation using the following command.

```
monitor sync-logs cndp-cm
```


After cluster synchronization is completed, a message is shown indicating a successful cluster synchronization.

## Integrating RADIUS and UP with the AIO BareMetal Server

The RADIUS and UP are part of the services network and therefore should be part of the same network. If they are not in the same VLAN, then the necessary routing should be available to have reachability between them.

The AIO services interface is also part of the services VLAN, which has routable reachability between AIO UDP proxy interface, RADIUS, and the User Plane function (UPF).

*Figure 3: Logical Network Connectivity*



## cnBNG Cluster Deployment Using Inception Server

You can now deploy the cnBNG cluster using the Inception server alone. You do not require the SMI Cluster Manager, which was previously used along with the Inception server to deploy the cnBNG cluster. This enhancement can help you save on hardware resources (servers).

# Installing Inception Server on Baremetal

The procedure to install the Inception server on baremetal is as follows:

1. Clear a Boot drive.
2. Create a virtual drive from unused physical drives.
3. Install Base ISO image.
4. Configure User and Network Parameters.
5. Install Inception Server.
6. Deploy SMI Cluster.
7. Add images to Inception Server.
8. Create SSH keys.
9. Add SMI Cluster Deployer configuration.

## Clear a Boot Drive

You must clean up the server storage before installing the Base ISO image. To clear the boot drive configurations on the Cisco Integrated Management Controller (CIMC) server, perform the following steps:

1. Log in to the CIMC Web UI using admin privileges.
2. In the **Navigation** pane, click the **Storage** menu.
3. On the **Storage** menu, click the appropriate LSI MegaRAID or Host Bus Adapter (HBA) controller. In the **RAID Controller** area, the **Controller Info** tab is displayed by default.
4. In the **Actions** area, click **Clear Boot Drive**.



**Note** The **Clear Boot Drive** option is enabled only if the server was used previously. If the server is new, this option is disabled.

5. Click **OK** to confirm.

## Create Virtual Drive from Unused Physical Drives

1. Log in to the CIMC Web UI using admin privileges.
2. On the **Storage** menu, click the appropriate LSI MegaRAID or HBA controller.
3. In the **Actions** area, click **Create Virtual Drive from Unused Physical Drives**. The **Create Virtual Drive from Unused Physical Drives** dialog box appears.
4. In the **Create Virtual Drive from Unused Physical Drives** dialog box, select **1** from the **RAID Level** drop-down list.
5. In the **Create Drive Groups** area, choose one or more physical drives to include in the group.

Use the >> button to add the drives to the **Drive Groups** table. Use the << button to remove physical drives from the drive group.

**Note**

- The size of the smallest physical drive in the drive group defines the maximum size used for all the physical drives. To ensure maximum use of space for all physical drives, it is recommended that the size of all the drives in the drive group are similar.
- CIMC manages only RAID controllers and not Host Bus Adapters (HBAs) attached to the server.
- You must have multiple drive groups available to create virtual drives (VDs) for certain RAID levels. While creating drives for these RAID levels, the create drive option is available only if the required number of drives are selected.

6. In the **Virtual Drive Properties** area, update the following properties:

Name	Description
<b>Virtual Drive Name</b> field	The name of the new virtual drive you want to create.
<b>Read Policy</b> drop-down list	The read-ahead cache mode.
<b>Cache Policy</b> drop-down list	The cache policy used for buffering reads.
<b>Strip Size</b> drop-down list	The size of each strip, in MB.
<b>Write Policy</b> drop-down list	This can be one of the following <ul style="list-style-type: none"> <li>• <b>Write Through</b>— Data is written through the cache and to the physical drives. Performance is improved, because subsequent reads of that data can be satisfied from the cache.</li> <li>• <b>Write Back</b>— Data is stored in the cache, and is only written to the physical drives when space in the cache is needed. Virtual drives requesting this policy fall back to <b>Write Through</b> caching when the BBU cannot guarantee the safety of the cache in the event of a power failure.</li> <li>• <b>Write Back Bad BBU</b>—With this policy, write caching remains <b>Write Back</b> even if the battery backup unit is defective or discharged.</li> </ul>
<b>Disk Cache Policy</b> drop-down list	This can be one of the following <ul style="list-style-type: none"> <li>• <b>Unchanged</b>— The disk cache policy is unchanged.</li> <li>• <b>Enabled</b>— Allows IO caching on the disk.</li> <li>• <b>Disabled</b>— Disallows disk caching.</li> </ul>
<b>Access Policy</b> drop-down list	This can be one of the following <ul style="list-style-type: none"> <li>• <b>Read Write</b>— Enables host to perform read-write on the VD.</li> <li>• <b>Read Only</b>— Host can only read from the VD.</li> <li>• <b>Blocked</b>— Host can neither read nor write to the VD.</li> </ul>

Name	Description
Size field	The size of the virtual drive (VD) you want to create. Enter a value and select one of the following units: <ul style="list-style-type: none"> <li>• MB</li> <li>• GB</li> <li>• TB</li> </ul>

7. Click **Create Virtual Drive**.
8. After the virtual drive is created, click the **Virtual Drive Info** tab. In the **Virtual Drives** area, choose the drive from which the controller must boot, and then click **Set as Boot Drive**.
9. Click **OK** to confirm.

## Install Base ISO image

Perform the following steps to install the Base ISO image.

1. Log in to the CIMC Web UI using admin privileges.
2. Click the **Virtual KVM** tab.
3. In the **Actions** area, click **Launch KVM Console**.
4. Click the **Virtual Media** menu, and click **Activate Virtual Devices**. A virtual media session is activated, and that allows you to attach a drive or image file from your local computer or network.
5. Click the **Virtual Media** menu again, and select **Map CD/DVD**. You can map a CD or a DVD image from your local machine and map the drive to the image.
6. Browse, and select the Base ISO image from the image folder.
7. From the tool bar, click the **Host Power** link. Select **Power Cycle** from the drop-down list. The chosen server is powered on with the mapped Base ISO image.
8. From the tool bar, click **Launch KVM**. The **KVM Console** opens in a separate window.
9. Once you see the login prompt and other options, press the **F6** function key.
10. On the boot menu, select the CIMC based vKVM-Mapped option to which the Base ISO image is mapped.

The server boots with the required ISO image.

11. Using CIMC, you can also configure the order in which the server attempts to boot from the available boot device types.
  - a. Click the **Compute** menu.
  - b. In the **BIOS** tab, click the **Configure Boot Order** tab. **Configure Boot Order** dialog box appears.
  - c. In the **Configure Boot Order** dialog box, you can select the order of boot, and click **Save Changes**.

12. Power cycle the server to trigger the Base ISO installation. You can view the installation status in the KVM console.

## Configure User and Network Parameters

Before installing the Inception server you must configure the user and network parameters.

To configure the network and static IP addressing:

1. Login with the default *cloud-init* credentials.



**Note** You must change the password immediately after logging in.

2. Update the network configuration in `/etc/netplan/50-cloud-init.yaml` file.

The following is a sample network configuration:

```
network:
  ethernets:
    eno1:
      addresses:
        - 10.0.0.20/8
      dhcp4: false
      gateway4: 10.197.209.193
      nameservers:
        addresses:
          - 10.104.128.236
          - 10.163.128.140
          - 10.37.142.73
  version: 2
```

3. Run the following command to apply the configuration:

```
sudo netplan apply
```

4. To preserve hostname or make the hostname persistent after reboot, you must edit the cloud configuration file:

```
sudo vi /etc/cloud/cloud.cfg
```

Set **preserve\_hostname: true**

5. Modify the hostname.

```
sudo hostnamectl set-hostname hostname
sudo vi /etc/hosts
127.0.0.1 hostname
```

## Install Inception Server

Perform the following steps to install the Inception server:

1. Copy the SMI offline package to the images folder.

Example:

```
cloud-user@cnbng4-cxbgl:/data/software/images$ pwd /data/software/images
cloud-user@cnbng4-cxbgl:/data/software/images$
```

- Untar the the downloaded file.

Example:

```
cloud-user@cnbng4-cxbgl:/data/software/images$ tar -xvf
cluster-deployer-2023.01.1.i18.tar
```

- Navigate to the deployer-inception folder which has the required charts and docker files.

Example:

```
cd /data/deployer-inception/
```

- Run the following command to install the Inception server.

Example:

```
sudo ./deploy --external-ip external_ipaddress --first-boot-password
first_boot_password
```



**Note**

The *external\_ipaddress* is the management IP address of the inception server.

## Deploy SMI Cluster

Perform the following steps to deploy the SMI cluster:

- Log in to the cluster using the following:

```
ssh admin@<ip_address> -p 2022
```

- Add the cluster level configurations for one or more K8s clusters.

## Add Images to Inception Server

- Fetch the offline tarball for SMI, cnBNG, & CEE and save it to the /data/software/images folder. You can fetch the tarball either from the artifactory or copy it securely through the **scp** or **winSCP** command.
- Untar the offline tarball, and copy the tar file to the respective path.

Example:

```
root@cnbng-inception:/data/downloads# tar -xvzf bng.2020.04.m0.i37.SSA.tgz ./
./bng.2020.04.m0.i37.tar.SSA.README
./CNBNG_DEV_KEY-CCO_DEV.cer
./trca.cer
./Innerspace_DEV.cer ./cisco_x509_verify_dev.py ./bng.2020.04.m0.i37.tar.signature.SSA
./bng.2020.04.m0.i37.tar
```

- Generate **sha256** checksum for the images and verify them with artifactory checksum.

Example:

```
cloud-user@cnbng4-cxbgl:/data/software/images$ sudo sha256sum bng.2020.04.m0.i37.tar
2e4fe956daf4afa13909d6fa89be5e727b9e4c03619436ecd04805045b780c0b bng.2020.04.m0.i37.tar
cloud-user@cnbng4-cxbgl:/data/software/images$ sudo sha256sum cee-2023.01.1.i18.tar
320e61f56976a2c107fa489a2a12d16301671f28212ec5b7d902b608d2e6ab80 cee-2023.01.1.i18.tar
```

```
cloud-user@cnbng4-cxbgl:/data/software/images$ sudo sha256sum cluster-deployer-2023.01.1.i18.tar
929dd80a840483f65a9f4afa314144f0f544e3bee23703214c03c831465ae707 cluster-deployer-2023.01.1.i18.tar
```

4. Add the images to Inception deployer cluster configuration. The inception deployer uses cnBNG & CEE images from the provided file path to bring up cnBNG control plane & CEE ops-center.

Example:

```
software cnf cnbng
url file:///data/software/images/bng.2020.04.m0.i37.tar
sha256 2e4fe956daf4afa13909d6fa89be5e727b9e4c03619436ecd04805045b780c0b
exit
software cnf cee-2023.01.1.i18
url file:///data/software/images/cee-2023.01.1.i18.tar
sha256 320e61f56976a2c107fa489a2a12d16301671f28212ec5b7d902b608d2e6ab80
exit
software host-profile bios-ht-25
url file:///data/software/images/ht.tgz
sha256 aa7e240f2b785a8c8d6b7cd6f79fe162584dc01b7e9d32a068be7f6e5055f664
exit
environments bare-metal
ucs-server
exit
!
```

## Generate SSH Keys

Generate SSH public and private keys.

Example:

```
cloud-user@inception-28:~$ ssh-keygen -t rsa
Generating public/private rsa key pair.
Enter file in which to save the key (/root/.ssh/id_rsa):
Created directory '/root/.ssh'.
Enter passphrase (empty for no passphrase):
Enter same passphrase again:
Your identification has been saved in /root/.ssh/id_rsa.
Your public key has been saved in /root/.ssh/id_rsa.pub.
The key fingerprint is:
SHA256:YQ3OfuEinrurnkkF1LW/vBDu5Zkti8zMt8dfIxpgYIE ubuntu@nfs-server-cn-svi
The key's randomart image is:
+---[RSA 2048]---+
| .+o . |
| .E = o |
| . + = o |
| o = o . |
| + S o |
| + * = |
| . = +... . o |
| . O *o=oo o . |
| .=. @+B=o.. |
+---[SHA256]---+
cloud-user@inception-28:~/.ssh$ ls -ltr ~/ssh/*id*
-rw----- 1 cloud-user cloud-user 577 Jan 19 2023 /home/cloud-user/.ssh/id_rsa.pub
-rw----- 1 cloud-user cloud-user 2484 Jan 19 2023 /home/cloud-user/.ssh/id_rsa
```

## Add SMI Cluster Deployer Configuration

Perform the following steps to add the SMI Cluster Deployer configurations:

1. Log in to the SMI cluster deployer.

Example:

```
cloud-user@incep.on-28:~$ ssh admin@127.0.0.1 -p 2022
admin@127.0.0.1's password:
Welcome to the Cisco SMI Cluster Deployer on inception-28
Copyright © 2016-2020, Cisco Systems, Inc.
All rights reserved.
admin connected from 10.0.1.1 using ssh on c0993db6451a
```

2. Add SSH-keys to the Inception Manager.

Example:

```
clusters <cluster_name>
environment bare-metal
node-defaults initial-boot default-user-ssh-public-key
"<SSH_Public_Key>"
node-defaults ssh-connection-private-key
"-----BEGIN OPENSSH PRIVATE KEY-----
<SSH_Private_Key>
-----END OPENSSH PRIVATE KEY-----\n"
CNTRL+D
```

3. Add CNF to clusters.

You can either download CNF images from online repositories, web servers, or local servers, or copy the tarball images to the Inception server folder and configure the folder path.

4. You can verify the configuration using the following command:

```
SMI Cluster Deployer# show running-config
software cnf cee-2023.01.1.i18
url file:///data/software/images/cee-2023.01.1.i18.tar
sha256 320e61f56976a2c107fa489a2a12d16301671f28212ec5b7d902b608d2e6ab80
exit
software cnf cnbng
url file:///data/software/images/bng-dev-private.tar
sha256 2e4fe956daf4afa13909d6fa89be5e727b9e4c03619436ecd04805045b780c0b
exit
software host-profile bios-ht-25
url file:///data/software/images/ht.tgz
sha256 aa7e240f2b785a8c8d6b7cd6f79fe162584dc01b7e9d32a068be7f6e5055f664
exit
```

## cnBNG Cluster Deployment Support on Red Hat OpenShift

Starting with Release 2025.01, the cnBNG control-plane can also be deployed on a Red Hat OpenShift cluster.

### Supported Functionalities:

The following functionalities are supported:

- OpenShift Container Platform (OCP) versions 4.16 and 4.17 are supported.
- Single Node OpenShift (SNO) is supported.
- Both cnBNG Standalone and CP-GR are supported.
- Only IPOE is supported.

- Compatible with IPv4-only and dual-stack configurations.

### Requirements:

The following software versions are required:

- CEE version: 2025.01 or above
- cnBNG-CP version: 2025.01.0 or above

### Monitoring and Management:

The following monitoring and management functionalities are available:

- Monitoring dashboards are available via CEE.
- Local storage support is provided through CEE.
- Cisco TAC debug support is available through CEE.
- Log and metric forwarding capabilities are provided via CEE.

### ISTIO:

ISTIO is not supported.



**Note** This guide does not cover the installation of the OpenShift cluster or the setup of Helm and the Docker registry.

### Set Up the cnBNG Application on an OCP Cluster

After installing the OpenShift Container Platform (OCP) cluster, follow these steps to set up the cnBNG application:

1. Add the hostname to the `/etc/hosts` file.
2. Assign the necessary node labels.
3. Execute the following command to enable support for external IP addresses:  

```
oc patch network cluster --type merge -p '{ "spec": { "externalIP": { "policy": "allow", "allowedCIDRs": ["0.0.0.0/0", "::/0"] }}}'
```
4. Add Helm and Docker repositories for the BNG and CEE charts.
5. Install the **cee-ops-center** and **bng-ops-center** charts using the specified inputs.

Ensure that your configuration includes the following global settings:

```
global:
  registry: <docker-registry>
  istio: false
  singleNode: true
  useVolumeClaims: true
  caasModel: "openshift"
  pathBasedIngress: false
  smiNfMonitoring: true
  smiPlatformMonitoring: true
  ingressHostname: <ingress>
  imagePullPolicy: IfNotPresent
```

```
imagePullSecrets:
  - name: <secret-name>
networkPolicy:
  enabled: false
```

The CLI commands for `bng-ops-center` and `cee-ops-center` are consistent with CNDP, allowing you to enable additional functionalities using the same setup.

# Maintenance Operation Procedure (MOP) for cnBNG Node Scaling

The current solution for a cnBNG Control Plane consists of two racks working together to provide high availability. Each rack contains four Kubernetes (K8s) clusters and is in the process of scaling up to a fifth Kubernetes cluster.

This MOP outlines the steps to scale a cnBNG Control Plane deployment from Half-Rack to Full-Rack.

The procedure includes

- adding new servers
- scaling up Kubernetes (K8s) clusters
- scaling up CDL, and
- scaling up services.

## Before you begin

Perform these steps prior to the actual maintenance window.

- Generate configuration files for K8s node scale up.
  - Prepare and review the config change payload for scaling up each cluster.
  - Verify that label configuration is in line with the current pod.
  - Load and merge change payload files into the Deployer configuration and perform a commit dry-run.
  - Verify that all changes are as per the expectation.
  - Exit Deployer config mode without issuing a commit.



### Note

Actual commits are done during the maintenance window.

**Estimated Time for Procedure**

Time for	Time taken
Adding new servers	1 day
Wiring up the new servers	
Configure the switches	
Scale up – Rack1 – CDL+Service	90m
Scale up – Rack2 – CDL+Service	90m
Scale up – CDL	60 ~ 90m

**Software Used**

Software For	Software Version
cnBNG	CNBNG-2024.03.0

**Adding and Wiring New Servers**

1. Update the firmware.

Ensure that new servers have the same firmware version as existing nodes.



**Note** This step should be done prior to the actual maintenance window before racking the servers in the pod.

2. Install and wire servers.

- Install new servers in the same rack as existing servers.
- Wire servers using available ports in current switches.

3. Power up servers.

4. Verify that there are no existing boot or virtual disks on these new servers.

5. Ensure that disks appear as Unconfigured-good.

6. Check the CIMC IP addresses of these new servers for connectivity.

7. Configure switch ports.

- Configure leaf switch ports for new servers.

Use the same configuration as other leaf ports connected to existing worker nodes.

- Verify from the ClusterManager Linux shell that you can ping CIMC IP addresses of new nodes.

**Scale Up Kubernetes Cluster**

You must scale up the Kubernetes cluster in each rack of the pod.

Follow these steps to scale up the Kubernetes cluster:

1. Perform a planned GR switchover to move all cnBNG instances to the RackInService as primary.



**Note** RackInService refers to the rack hosting all primary GR instances of all cnBNGs in the pod.

2. Reset states of cnBNG GR instances in STANDBY\_ERROR state to STANDBY state in RackBeingScaled.



**Note** RackBeingScaled refers to the rack undergoing K8s node scaling.

3. Verify that all GR instances in RackInService are in PRIMARY state and those in RackBeingScaled are in STANDBY state.
4. Set geo-maintenance mode in all cnBNGs in both RackBeingScaled and RackInService.
5. Shut down all cnBNGs in RackBeingScaled.
6. Add the configuration in Deployer via CLI or NSO load merge config change payload files to scale up RackBeingScaled.

See the section "K8s Cluster scale-up config example" for example configuration.

7. Manually add networks in the netplan on the new server.

- Command: **sudo vi /etc/netplan/50-cloud-init.yaml**
- Apply: **sudo netplan apply**



**Note** If the server is new, you don't have to add netplan manually. If you are reusing a server, write a netplan manually.

8. [Optional] If you are reusing an existing server, reset it using the CLI command:

- **kubeadm reset --force**
- Clean up (delete) the virtual drive by logging into the CIMC of that server.

9. Issue a cluster sync to scale up RackBeingScaled.

- Command: **clusters svi-cnbng-gr-tb1 actions sync run debug true**

10. Monitor the cluster sync progress by logging into the Cluster Manager.

11. Verify if all nodes in the K8s cluster in RackBeingScaled are in ready state.

12. Verify if all pods in the K8s cluster in RackBeingScaled are in good running state.

13. Start up all cnBNGs in RackBeingScaled.

14. Verify if the added nodes appear in the cnBNG Ops Center configurations.

15. Verify if both GR instances of all cnBNGs in RackBeingScaled are in STANDBY state.
16. Unset geo-maintenance mode in all cnBNGs in both RackBeingScaled and RackInService

**Post-Requirements:**

Repeat this procedure to scale up K8s cluster in each rack of the Pod.

**Scale Up CDL**

Follow these steps to scale up the CDL:

1. Verify that all cnBNGs in the pod are in good state.
2. Update CDL Grafana dashboard to monitor the total number of index keys that have been rebalanced.
  - **Query:** `sum(index_rebalanced_keys_total{namespace=\"$namespace\"}) by (cdl_slice, shardId, pod)`
  - **Legend:** `irkt-{ {cdl_slice} }-{ {shardId} }-{ {pod} }`

**Note**

CDL rebalancing happens once the CDL rebalance query is issued.

3. Make rack-1 as ACTIVE and rack-2 as STANDBY.
  - a. Unset geo maintenance mode in all cnBNGs in both racks (if previously set).
  - b. Make both GR instances of all cnBNGs in Rack1 PRIMARY.
  - c. Make both GR instances of all cnBNGs in Rack2 STANDBY.
  - d. Set geo maintenance mode in all cnBNGs in both racks.
4. Add configuration changes to Rack2 (STANDBY)
  - a. Shut down all cnBNGs in Rack2.
  - b. Add configuration changes to all cnBNGs in Rack2 (see "*CDL Configuration changes*" section).
  - c. Start up all cnBNGs in Rack2.
5. Verify the cnBNG State
  - Ensure that all cnBNGs are in good state.
  - Both GR instances in all cnBNGs in Rack2 should be in STANDBY state.
  - Both GR instances in all cnBNGs in Rack1 should be in PRIMARY state.
6. Verify CDL indices and slots sync
  - a. Verify if CDL indices and slots in Rack2 can sync with remote peers (may take ~15 mins).
7. Switch rack states
  - Unset geo maintenance mode in all cnBNGs in both racks.

- Make both GR instances of all cnBNGs in Rack2 PRIMARY.
- Make both GR instances of all cnBNGs in Rack1 STANDBY.
- Set geo maintenance mode in all cnBNGs in both racks.

8. Add configuration changes to Rack1 (STANDBY)
  - a. Shut down all cnBNGs in Rack1.
  - b. Add configuration changes to all cnBNGs in Rack1 (see "*CDL Configuration changes*" section).
  - c. Start up all cnBNGs in Rack1.
9. Verify the state of all cnBNGs.
  - Ensure that all cnBNGs are in good state.
  - Both GR instances in all cnBNGs in Rack1 should be in STANDBY state.
  - Both GR instances in all cnBNGs in Rack2 should be in PRIMARY state.
10. Verify if CDL indices and slots in Rack1 can sync with remote peers (may take ~15 mins).
11. Trigger CDL index rebalancing.
  - Issue the following command in all cnBNGs in the current STANDBY rack:  
**cdl rebalance-index run**
12. Verify CDL index rebalancing completion.
  - a. Monitor progress with the following command in the STANDBY rack cnBNG:  
**cdl rebalance-index status**
  - b. Validate rebalancing with the following command in the STANDBY rack cnBNG:  
**cdl rebalance-index validate**
13. Remove CDL scale up mode configuration:
 

```
config
  cdl datastore session
  no mode
  commit
end
```
14. Unset Geo maintenance mode in all cnBNGs in both racks.
15. Initiate GR switchovers
 

Switch all cnBNGs in the pod to ACTIVE-ACTIVE mode.
16. Verify that all cnBNGs are operating in sunny day mode.

### Scale Up Services

You can now scale up cnBNG Services.



**Note** There is no restriction to always scale up Cluster1 before Cluster2. You can scale up any cluster first, depending on the existing role set on the cluster.

Follow these steps to scale up cnBNG services:

1. Make Rack-1 Active and Rack-2 Standby
  - Unset geo maintenance mode in all cnBNGs in both racks (if previously set).
  - Make both GR instances of all cnBNGs in Rack1 PRIMARY.
  - Make both GR instances of all cnBNGs in Rack2 STANDBY.
  - Set geo maintenance mode in all cnBNGs in both racks.
2. Add configuration changes in Rack-2 (STANDBY).
  - a. Shut down all cnBNGs in Rack2.
  - b. Add the configuration changes to all cnBNGs in Rack2 (see the "Service scaleup config changes" section).
  - c. Start up all cnBNGs in Rack2.
3. Verify the cnBNG state.
  - Ensure that all cnBNGs are in good state.
  - Both GR instances in all cnBNGs in Rack2 should be in STANDBY state.
  - Both GR instances in all cnBNGs in Rack1 should be in PRIMARY state.
4. Verify that the scale-up configuration changes are applied (may take approximately 15 mins).
5. Make Rack-2 active and Rack-1 standby
  - a. Unset geo maintenance mode in all cnBNGs in both racks.
  - b. Make both GR instances of all cnBNGs in Rack2 PRIMARY.
  - c. Make both GR instances of all cnBNGs in Rack1 STANDBY.
  - d. Set Geo maintenance mode in all cnBNGs in both racks.
6. Add configuration changes in Rack-1 (STANDBY)
  - a. Shutdown all cnBNGs in Rack1.
  - b. Add the configuration changes to all cnBNGs in Rack1 (see "Service Scale up Configuration" section).
  - c. Start up all cnBNGs in Rack1.
7. Verify the cnBNG State.
  - Ensure that all cnBNGs are in good state.

- Both GR instances in all cnBNGs in Rack1 should be in STANDBY state.
- Both GR instances in all cnBNGs in Rack2 should be in PRIMARY state.

8. Verify that the scale-up configuration changes are applied (may take ~15 mins).
9. Remove the geo maintenance mode in both clusters.
10. Move both CP-GR clusters to their original state.

### Configuration Examples

#### K8s Cluster Scale Up:

Scale up configurations for both the servers are available in the following combinations:

- Node Scaling for Service only
- Node Scaling for CDL only
- Node Scaling for both CDL and Service

#### Node Scaling for Service Only

Cluster1 Node5 Deployer Configuration	Cluster2 Node5 Deployer Configuration
<pre> clusters svi-cnbng-gr-tbl nodes server-5 host-profile bng-ht-sysctl-enable k8s node-type worker k8s ssh-ip 1.1.111.15 k8s ssh-ipv6 2002:4888:1:1::111:15 k8s node-ip 1.1.111.15 k8s node-ipv6 2002:4888:1:1::111:15 k8s node-labels smi.cisco.com/svc-type service exit ucs-server cimc ip-address 10.81.103.78 initial-boot netplan vlans bd0.mgmt.3103 addresses [ 10.81.103.119/24 ] gateway4 10.81.103.1 exit initial-boot netplan vlans bd1.k8s.111 addresses [ 1.1.111.15/24 2002:4888:1:1::111:15/112 ] routes 203.203.203.50/32 1.1.111.1 exit routes 2002:4888:203:203::203:50/128 2002:4888:1:1::111:1 exit initial-boot netplan vlans bd1.inttcp.104 dhcp4 false dhcp6 false addresses [ 1.1.104.15/24 2002:4888:1:1::104:15/112 ] id 104 link bd1 routes 2.2.104.0/24 1.1.104.1 exit routes 2002:4888:2:2::104:0/112 2002:4888:1:1::104:1 exit os tuned enabled exit exit </pre>	<pre> clusters svi-cnbng-gr-tb2 nodes server-5 host-profile bng-ht-sysctl-enable k8s node-type worker k8s ssh-ip 2.2.112.15 k8s ssh-ipv6 2002:4888:2:2::112:15 k8s node-ip 2.2.112.15 k8s node-ipv6 2002:4888:2:2::112:15 k8s node-labels smi.cisco.com/svc-type service exit ucs-server cimc ip-address 10.81.103.58 initial-boot netplan vlans bd0.mgmt.3103 addresses [ 10.81.103.68/24 ] gateway4 10.81.103.1 exit initial-boot netplan vlans bd1.inttcp.104 dhcp4 false dhcp6 false addresses [ 2.2.104.15/24 2002:4888:2:2::104:15/112 ] id 104 link bd1 routes 1.1.104.0/24 2.2.104.1 exit routes 2002:4888:1:1::104:0/112 2002:4888:2:2::104:1 exit initial-boot netplan vlans bd1.k8s.112 addresses [ 2.2.112.15/24 2002:4888:2:2::112:15/112 ] routes 203.203.203.50/32 2.2.112.1 exit routes 2002:4888:203:203::203:50/112 2002:4888:2:2::112:1 exit os tuned enabled exit exit </pre>

### Node Scaling for CDL Only

Cluster1 Node5 Deployer Configuration	Cluster2 Node5 Deployer Configuration
<pre> clusters svi-cnbng-gr-tb1 nodes server-5 host-profile bng-ht-sysctl-enable k8s node-type worker k8s ssh-ip 1.1.111.15 k8s ssh-ipv6 2002:4888:1:1::111:15 k8s node-ip 1.1.111.15 k8s node-ipv6 2002:4888:1:1::111:15 k8s node-labels smi.cisco.com/sess-type cdl-node exit ucs-server cimc ip-address 10.81.103.78 initial-boot netplan vlans bd0.mgmt.3103 addresses [ 10.81.103.119/24 ] gateway4 10.81.103.1 exit initial-boot netplan vlans bd1.cdl.103 dhcp4 false dhcp6 false addresses [ 1.1.103.15/24 2002:4888:1:1::103:15/112 ] id 103 link bd1 routes 2.2.103.0/24 1.1.103.1 exit routes 2002:4888:2:2::103:0/112 2002:4888:1:1::103:1 exit exit initial-boot netplan vlans bd1.k8s.111 addresses [ 1.1.111.15/24 2002:4888:1:1::111:15/112 ] routes 203.203.203.50/32 1.1.111.1 exit routes 2002:4888:203:203::203:50/128 2002:4888:1:1::111:1 exit exit os tuned enabled exit exit </pre>	<pre> clusters svi-cnbng-gr-tb2 nodes server-5 host-profile bng-ht-sysctl-enable k8s node-type worker k8s ssh-ip 2.2.112.15 k8s ssh-ipv6 2002:4888:2:2::112:15 k8s node-ip 2.2.112.15 k8s node-ipv6 2002:4888:2:2::112:15 k8s node-labels smi.cisco.com/sess-type cdl-node exit ucs-server cimc ip-address 10.81.103.58 initial-boot netplan vlans bd0.mgmt.3103 addresses [ 10.81.103.85/24 ] gateway4 10.81.103.1 exit initial-boot netplan vlans bd1.cdl.103 dhcp4 false dhcp6 false addresses [ 2.2.103.15/24 2002:4888:2:2::103:15/112 ] id 103 link bd1 routes 1.1.103.0/24 2.2.103.1 exit routes 2002:4888:1:1::103:0/112 2002:4888:2:2::103:1 exit exit initial-boot netplan vlans bd1.k8s.112 addresses [ 2.2.112.15/24 2002:4888:2:2::112:15/112 ] routes 203.203.203.50/32 2.2.112.1 exit routes 2002:4888:203:203::203:50/112 2002:4888:2:2::112:1 exit exit os tuned enabled exit exit </pre>

### Node Scaling for both CDL and Services

Cluster1 Node5 Deployer configuration	Cluster2 Node5 Deployer configuration
---------------------------------------	---------------------------------------

<pre> clusters svi-cnbng-gr-tb1 nodes server-5   host-profile bng-ht-enable   k8s node-type worker   k8s ssh-ip 1.1.111.15   k8s ssh-ipv6 2002:4888:1:1::111:15   k8s node-ip 1.1.111.15   k8s node-ipv6 2002:4888:1:1::111:15   k8s node-labels smi.cisco.com/sess-type cdl-node   exit   k8s node-labels smi.cisco.com/svc-type service   exit   ucs-server cimc ip-address 10.81.103.78   initial-boot netplan vlans bd0.mgmt.3103     addresses [ 10.81.103.119/24 ]     gateway4 10.81.103.1   exit   initial-boot netplan vlans bd1.inttcp.104     dhcp4 false     dhcp6 false     addresses [ 1.1.104.15/24 2002:4888:1:1::104:15/112 ]     id 104     link bd1     routes 2.2.104.0/24 1.1.104.1   exit   routes 2002:4888:2:2::104:0/112 2002:4888:1:1::104:1   exit   exit   initial-boot netplan vlans bd1.cdl.103     dhcp4 false     dhcp6 false     addresses [ 1.1.103.15/24 2002:4888:1:1::103:15/112 ]     id 103     link bd1     routes 2.2.103.0/24 1.1.103.1   exit   routes 2002:4888:2:2::103:0/112 2002:4888:1:1::103:1   exit   exit   initial-boot netplan vlans bd1.k8s.111     addresses [ 1.1.111.15/24 2002:4888:1:1::111:15/112 ]     routes 203.203.203.50/32 1.1.111.1   exit   routes 2002:4888:203:203::203:50/128 2002:4888:1:1::111:1   exit   exit   os tuned enabled   exit exit </pre>	<pre> clusters svi-cnbng-gr-tb2 nodes server-5   host-profile bng-ht-enable   k8s node-type worker   k8s ssh-ip 2.2.112.15   k8s ssh-ipv6 2002:4888:2:2::112:15   k8s node-ip 2.2.112.15   k8s node-ipv6 2002:4888:2:2::112:15   k8s node-labels smi.cisco.com/sess-type cdl-node   exit   k8s node-labels smi.cisco.com/svc-type service   exit   ucs-server cimc ip-address 10.81.103.58   initial-boot netplan vlans bd0.mgmt.3103     addresses [ 10.81.103.85/24 ]     gateway4 10.81.103.1   exit   initial-boot netplan vlans bd1.inttcp.104     dhcp4 false     dhcp6 false     addresses [ 2.2.104.15/24 2002:4888:2:2::104:15/112 ]     id 104     link bd1     routes 1.1.104.0/24 2.2.104.1   exit   routes 2002:4888:1:1::104:0/112 2002:4888:2:2::104:1   exit   exit   initial-boot netplan vlans bd1.cdl.103     dhcp4 false     dhcp6 false     addresses [ 2.2.103.15/24 2002:4888:2:2::103:15/112 ]     id 103     link bd1     routes 1.1.103.0/24 2.2.103.1   exit   routes 2002:4888:1:1::103:0/112 2002:4888:2:2::103:1   exit   exit   initial-boot netplan vlans bd1.k8s.112     addresses [ 2.2.112.15/24 2002:4888:2:2::112:15/112 ]     routes 203.203.203.50/32 2.2.112.1   exit   routes 2002:4888:203:203::203:50/112 2002:4888:2:2::112:1   exit   exit   os tuned enabled   exit exit </pre>
--	---

## CDL Configuration Changes

CDL Scale-up Configuration on Cluster1	CDL Scale-up Configuration on Cluster2
--	--

CDL Scale-up Configuration on Cluster1	CDL Scale-up Configuration on Cluster2
<pre> cdl datastore session   label-config session   geo-remote-site [ 2 ] <b>mode scale-up</b>   slice-names [ 1 2 ]   overload-protection disable true   endpoint go-max-procs 16 <b>endpoint replica 3</b>   endpoint copies-per-node 2   endpoint settings slot-timeout-ms 750   endpoint external-ip 1.1.103.100   endpoint external-ipv6 2002:4888:1:1::103:100    endpoint external-port 8882   index go-max-procs 8   index replica 2 <b>index prev-map-count 2</b> <b>index map 3</b>   features instance-aware-notification enable   true   features instance-aware-notification   system-id 1     slice-names [ 1 ]     exit   features instance-aware-notification   system-id 2     slice-names [ 2 ]     exit     slot go-max-procs 8     slot replica 2 <b>slot map 6</b>     slot notification limit      1500     slot notification     max-concurrent-bulk-notifications 20     exit      cdl label-config session       endpoint key smi.cisco.com/sess-type       endpoint value cdl-node       slot map 1         key   smi.cisco.com/sess-type         value cdl-node       exit       slot map 2         key   smi.cisco.com/sess-type         value cdl-node       exit       slot map 3         key   smi.cisco.com/sess-type         value cdl-node       exit       slot map 4         key   smi.cisco.com/sess-type         value cdl-node       exit <b>slot map 5</b>         key   smi.cisco.com/sess-type         value cdl-node       exit <b>slot map 6</b>         key   smi.cisco.com/sess-type       </pre>	<pre> cdl datastore session   label-config session   geo-remote-site [ 1 ] <b>mode scale-up</b>   slice-names [ 1 2 ]   overload-protection disable true   endpoint go-max-procs 16 <b>endpoint replica 3</b>   endpoint copies-per-node 2   endpoint settings slot-timeout-ms 750   endpoint external-ip 2.2.103.100   endpoint external-ipv6 2002:4888:2:2::103:100    endpoint external-port 8882   index go-max-procs 8   index replica 2 <b>index prev-map-count 2</b> <b>index map 3</b>   features instance-aware-notification enable   true   features instance-aware-notification   system-id 1     slice-names [ 1 ]     exit   features instance-aware-notification   system-id 2     slice-names [ 2 ]     exit     slot go-max-procs 8     slot replica 2 <b>slot map 6</b>     slot notification limit      1500     slot notification     max-concurrent-bulk-notifications 20     exit      cdl label-config session       endpoint key smi.cisco.com/sess-type       endpoint value cdl-node       slot map 1         key   smi.cisco.com/sess-type         value cdl-node       exit       slot map 2         key   smi.cisco.com/sess-type         value cdl-node       exit       slot map 3         key   smi.cisco.com/sess-type         value cdl-node       exit       slot map 4         key   smi.cisco.com/sess-type         value cdl-node       exit <b>slot map 5</b>         key   smi.cisco.com/sess-type         value cdl-node       exit <b>slot map 6</b>         key   smi.cisco.com/sess-type       </pre>

CDL Scale-up Configuration on Cluster1	CDL Scale-up Configuration on Cluster2
<pre> value cdl-node exit index map 1 key smi.cisco.com/sess-type value cdl-node exit index map 2 key smi.cisco.com/sess-type value cdl-node exit <b>index map 3</b> key smi.cisco.com/sess-type value cdl-node <b>exit</b> <b>exit</b> </pre>	<pre> value cdl-node exit index map 1 key smi.cisco.com/sess-type value cdl-node exit index map 2 key smi.cisco.com/sess-type value cdl-node exit <b>index map 3</b> key smi.cisco.com/sess-type value cdl-node <b>exit</b> <b>exit</b> </pre>

The commands that are required for node scaling are highlighted.

### Service Scale up Configuration

Scaling up services by increasing replica counts and nodes is supported. Reducing replicas and nodes is not supported and it will impact the system.

Existing Configuration	Service Scale Up Configuration in Both Clusters
<pre> instance instance-id 1 endpoint dhcp replicas 4 nodes 2 exit exit endpoint sm replicas 6 nodes 2 exit exit  instance instance-id 2 endpoint dhcp replicas 4 nodes 2 exit exit endpoint sm replicas 6 nodes 2 exit exit </pre>	<pre> instance instance-id 1 endpoint dhcp replicas 4 <b>nodes 3</b> exit exit endpoint sm replicas 6 <b>nodes 3</b> exit exit  instance instance-id 2 endpoint dhcp replicas 4 <b>nodes 3</b> exit exit endpoint sm replicas 6 <b>nodes 3</b> exit exit </pre>