



# Fabric Management Commands

---

This chapters provides details for the fabric management commands.

- [show asic-errors SFE, on page 2](#)
- [show controller fabric plane , on page 4](#)
- [show controller sfe driver rack, on page 6](#)
- [show controller sfe statistics, on page 8](#)
- [show platform, on page 11](#)

# show asic-errors SFE

To display asic errors for the Switch Fabric Element (SFE), use the **show asic-errors SFE** command in the Administration EXEC mode.

**show asic-errors SFE** *element-id* **location** *location-id*

## Syntax Description

*element-id* SFE instance ID

*location-id* Location ID of RP

## Command Default

None

## Command Modes

Administration EXEC

## Command History

Release	Modification
Release 5.2.4	This command was first introduced.
Release 6.0.1	The <b>SFE</b> keyword was added.

## Usage Guidelines

You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
sfe	read

## Example

This example show how to use the **show asic-errors SFE** command:

```
sysadmin-vm:0_RP0# show asic-errors SFE 0 all location 0/RP0
Wed Apr 20 06:31:49.555 UTC
all location 0/RP0
*****
*                               *
*           Instance:0         *
*                               *
*                               *
*           Single Bit Errors   *
*                               *
*                               *
*           Multiple Bit Errors *
*                               *
*                               *
*           Parity Errors       *
*                               *
*****
```

```

*****
*                               Barrier Errors                               *
*****
*                               Unexpected Errors                           *
*****
*                               Link Errors                                *
*****
NCS-4000, , 0/RP0, sfe[0]
Name       : RTP.General_Interrupt_Register.LinkIntegrityChangedInt
Leaf ID    : 0x20026029
Error count : 1
Last clearing : Tue Apr 19 19:03:45 2016
Last N errors : 1
-----
First N errors.
@Time, Error-Data
-----
Apr 19 19:03:45.595144:      Name Address      Value
                        Link_Integrity_Vector 0x000001a8 0x00000000000000000e070707000000
-----
NCS-4000, , 0/RP0, sfe[0]
Name       : RTP.General_Interrupt_Register.UnicastTableChangedInt
Leaf ID    : 0x2002602a
Error count : 4
Last clearing : Tue Apr 19 19:03:42 2016
Last N errors : 4

```

# show controller fabric plane

To display the details about the fabric plane, use the **show controller fabric plane** command in the Administration EXEC mode.

**show controller fabric plane** { **all** | **plane-id** } [ **statistics** ]  
[ **brief** | **detail** ]

<b>Syntax Description</b>	<b>plane-id</b>	Displays details of the selected plane number. Range is from 0 to 3.
	<b>all</b>	Displays information about all the system fabric planes.
	<b>statistics</b>	Displays plane statistics.
	<b>brief</b>	Displays brief information about the system fabric plane or plane statistics.
	<b>detail</b>	Displays detailed information about the system fabric plane or plane statistics.

**Command Default** None

**Command Modes** Administration EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.
	Release 6.0.1	The display output has been modified to show the plane mode details.

**Usage Guidelines** You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sfe	read

## Example

This example shows how to use the **show controller fabric plane** command:

```
sysadmin-vm:0_RP0# show controller fabric plane all
```

```
Plane Admin Plane  Plane  up->dn  up->mcast
Id      State State  Mode    counter  counter
-----
0       UP    UP     SC      0        0
1       UP    UP     SC      0        0
```

```
2      UP      UP      SC      0      0
3      UP      UP      SC      0      0
```

Field	Description
Plane ID	Plane ID number.
Admin State	Admin status of the plane (up or down).
Plane State	Plane status (shut or unshut).
Plane Mode	Plane mode indicates single chassis or multi-chassis system.
up-dn counter	Plane counter.
up-mcast counter	Counter to indicate the if any of the links are down.

# show controller sfe driver rack

To display the Switch Fabric Element (SFE) driver information, use the **show controller sfe driver rack** command in the Administration EXEC mode.

**show controller sfe driver rack** *rack-id*

<b>Syntax Description</b>	<i>rack-id</i> The ID of the rack whose details need to be displayed.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Administration EXEC
----------------------	---------------------

<b>Command History</b>	<table border="1"> <tr> <th>Release</th> <th>Modification</th> </tr> <tr> <td>Release 5.2.4</td> <td>This command was first introduced.</td> </tr> <tr> <td>Release 6.0.1</td> <td>The output has been modified to show the Asic Class details.</td> </tr> </table>	Release	Modification	Release 5.2.4	This command was first introduced.	Release 6.0.1	The output has been modified to show the Asic Class details.
Release	Modification						
Release 5.2.4	This command was first introduced.						
Release 6.0.1	The output has been modified to show the Asic Class details.						

<b>Usage Guidelines</b>	You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	--

<b>Task ID</b>	<table border="1"> <tr> <th>Task ID</th> <th>Operation</th> </tr> <tr> <td>sfe</td> <td>read</td> </tr> </table>	Task ID	Operation	sfe	read
Task ID	Operation				
sfe	read				

## Example

This example shows how to use the **show controller sfe driver rack** command:

```
sysadmin-vm:0_RP# show controller sfe driver rack 0
SFE Driver information
=====

Driver Version: 1      (1.1)

Functional role: Active,   ISSU role: NA
Rack: 0/RP0, Type: lcc, Number: 0, IP Address: 192.0.44.1
Startup time       : 2016 Feb 11 13:58:55.646
Availability Masks :
    Card: 0xF      Asic: 0x1C71C7      Exp Asic: 0x1C71C7
Unicast/Multicast (ratio) : 0
+-----+
|Process | Connection | Registration| Connection | DLL      |
|/Lib    | status    | status      | requests   | registration |
+-----+
| PM      | Active    | n/a         |            | 1| n/a      |
| PL-LOCAL| Active    | Active      |            | 1| n/a      |
+-----+
```

```

| FSDB      | Active    | Active    |          | 1 | n/a      |
| FGID      | Active    | Active    |          | 1 | n/a      |
| CM         | Active    | Active    |          | 1 | n/a      |
| CCC        | Active    | n/a       |          | 1 | n/a      |
| GASPP      | n/a       | n/a       |          | n/a | No      |
| CIH        | n/a       | n/a       |          | n/a | Yes     |
+-----+

```

Asics :

HP - HotPlug event, PON - Power ON reset, WB - Warm Boot, A - All  
 HR - Hard Reset, DC - Disconnect signal, DL - Download

```

+-----+
| Asic inst. | card | HP | Asic | Asic | Admin | plane | Fgid | Asic State | DC | Last | PON | HR |
| (R/S/A)   | pwr |   | type | class | /Oper | /grp | DL   |           |   | init | (#) | (#) |
+-----+
| 0/FC0/0   | UP  | 1 | s123 | FE3600 | UP/UP | 0/A | DONE | NRML       | 0 | PON  | 1  | 0 |
| 0/FC0/1   | UP  | 1 | s123 | FE3600 | UP/UP | 0/A | DONE | NRML       | 0 | PON  | 1  | 0 |
| 0/FC0/2   | UP  | 1 | s123 | FE3600 | UP/UP | 0/A | DONE | NRML       | 0 | PON  | 1  | 0 |
| 0/FC0/0   | UP  | 1 | s123 | FE1600 | UP/UP | 0/A | DONE | NRML       | 0 | PON  | 1  | 0 |
| 0/FC0/1   | UP  | 1 | s123 | FE1600 | UP/UP | 0/A | DONE | NRML       | 0 | PON  | 1  | 0 |
| 0/FC0/2   | UP  | 1 | s123 | FE1600 | UP/UP | 0/A | DONE | NRML       | 0 | PON  | 1  | 0 |
+-----+

```

Field	Description
Process / Lib	External process name
Connection Status	State of SFE connection with external process(es)
Registration Status	State of SFE registration with external process(es)
Connection Requests	SFE connection request numbers with external process
DLL registration	DLL registration status
Asic inst. R/S/A	Asic instance number (Rack/ slot/ asic format)
Card PWRD	Card power status
HP	Hot plug attach status
Asic type	SFE mode - s13, s123, s2
Asic Class	SFE asic type - FE3600, FE1600
Admin/ Oper	Admin operation status from FSDB
Plane/ grp	Plane number
Fgid/ DL	FGID download status (Empty/ Done)
Asic State	Status of the ASIC
DC	Disconnect Status
Last init	Last Initialization Type - WB, PON, HPON
PON	Power or reset counters
HR	Hard reset counters

# show controller sfe statistics

To display the Switch Fabric Element (SFE) statistics, use the **show controller sfe statistics** command in the Administration EXEC mode.

**show controller sfe statistics** **asic-type** [**FE3200** | **FE1600**] **block** *block-stats* **instance** { **asic-instance** | **all** } **location** { *node-id* | **all** }

<b>Syntax Description</b>	<b>asic-type</b>	Type of FE (FE1600 or 3200).
	<b>block</b> <i>block-stats</i>	SFE block type. The possible options are: <ul style="list-style-type: none"> <li>• CCS statistics - valid for FE1600 and FE3200</li> <li>• DCH statistics - valid for FE1600 and FE3200</li> <li>• DCL statistics - valid for FE1600 and FE3200</li> <li>• DCM statistics - valid for FE3200</li> <li>• DCMA statistics - valid for FE1600</li> <li>• ECI statistics - valid for FE1600</li> <li>• FMAC statistics - valid for FE1600</li> <li>• FSRD statistics - valid for FE3200</li> <li>• MESH statistics - valid for FE3200</li> <li>• RTP statistics - valid for FE1600 and FE3200</li> </ul>
	<b>instance</b>	Indicates an instance.
	<b>asic-instance</b>	Displays statistics for a specific ASIC.
	<b>all</b>	Displays statistics for all asics or nodes.
	<b>location</b>	Specifies the target location; the node-id is expressed in the R/S/I/P format.
<b>Command Default</b>	None	
<b>Command Modes</b>	Administration EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0.0	This command was first introduced.
	Release 6.0.1	The <b>asic-type</b> keyword was added.



**Usage Guidelines**

You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Operation
sfe	read

**Example**

This example shows how to use the **show controller sfe statistics** command:

```

sysadmin-vm:0_RP0# show controller sfe statistics asic-type FE1600 block DCH instance 0
location 0/FC0
Wed Apr 20 06:40:33.225 UTC
DCH statistics:
-----
DCH0 FifoDiscardCounterP: 0
DCH0 DCHReordDiscardCounterP: 6
DCH0 FifoDiscardCounterS: 0
DCH0 DCHReordDiscardCounterS: 6
DCH0 UnreachDestCntP: 0
DCH0 UnreachDestCntS: 0
DCH0 DchDroppedLowMulCntP: 0
DCH0 DchDroppedLowMulCntS: 0
DCH0 ErrorFilterCntAP: 0
DCH0 ErrorFilterCntBP: 0
DCH0 ErrorFilterCntAS: 0
DCH0 ErrorFilterCntBS: 0
DCH0 DropLowPriCntP: 0
DCH0 DropLowPriCntS: 0
DCH0 Ecc_1bErrCnt: 0
DCH0 Ecc_2bErrCnt: 0
DCH0 ParityErrCnt: 0
DCH1 FifoDiscardCounterP: 0
DCH1 DCHReordDiscardCounterP: 18
DCH1 FifoDiscardCounterS: 0
DCH1 DCHReordDiscardCounterS: 18
DCH1 UnreachDestCntP: 0
DCH1 UnreachDestCntS: 0
DCH1 DchDroppedLowMulCntP: 0
DCH1 DchDroppedLowMulCntS: 0
DCH1 ErrorFilterCntAP: 0
DCH1 ErrorFilterCntBP: 0
DCH1 ErrorFilterCntAS: 0
DCH1 ErrorFilterCntBS: 0
DCH1 DropLowPriCntP: 0
DCH1 DropLowPriCntS: 0
DCH1 Ecc_1bErrCnt: 0
DCH1 Ecc_2bErrCnt: 0
DCH1 ParityErrCnt: 0
DCH2 FifoDiscardCounterP: 0
DCH2 DCHReordDiscardCounterP: 0
DCH2 FifoDiscardCounterS: 0
DCH2 DCHReordDiscardCounterS: 0
DCH2 UnreachDestCntP: 0
DCH2 UnreachDestCntS: 0
DCH2 DchDroppedLowMulCntP: 0
DCH2 DchDroppedLowMulCntS: 0

```

## show controller sfe statistics

```

DCH2 ErrorFilterCntAP: 0
DCH2 ErrorFilterCntBP: 0
DCH2 ErrorFilterCntAS: 0
DCH2 ErrorFilterCntBS: 0
DCH2 DropLowPriCntP: 0
DCH2 DropLowPriCntS: 0
DCH2 Ecc_1bErrCnt: 0
DCH2 Ecc_2bErrCnt: 0
DCH2 ParityErrCnt: 0
DCH3 FifoDiscardCounterP: 0
DCH3 DCHReordDiscardCounterP: 0
DCH3 FifoDiscardCounterS: 0
DCH3 DCHReordDiscardCounterS: 0
DCH3 UnreachDestCntP: 0
DCH3 UnreachDestCntS: 0
DCH3 DchDroppedLowMulCntP: 0
DCH3 DchDroppedLowMulCntS: 0
DCH3 ErrorFilterCntAP: 0
DCH3 ErrorFilterCntBP: 0
DCH3 ErrorFilterCntAS: 0
DCH3 ErrorFilterCntBS: 0
DCH3 DropLowPriCntP: 0
DCH3 DropLowPriCntS: 0
DCH3 Ecc_1bErrCnt: 0
DCH3 Ecc_2bErrCnt: 0
DCH3 ParityErrCnt: 0

```

# show platform

To display information and status for each node in the system, use the **show platform** command in EXEC mode or Administration EXEC mode.

**show platform** [ **node-id** ]

<b>Syntax Description</b>	<b>node-id</b> Node for which information needs to be displayed. Node-id needs to be entered in R/S/I/P format.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC or Admin EXEC				
<b>Command History</b>	<b>Release</b> <b>Modification</b>				
	Release 5.2.4 This command was introduced.				
	Release 6.0.1 The display output has been modified to display additional details for line cards.				
<b>Usage Guidelines</b>	<p>You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The show platform command provides a summary of the nodes in the system, including node type and status.</p>				
<b>Task ID</b>	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>system</td><td>read</td></tr> </table>	Task ID	Operation	system	read
Task ID	Operation				
system	read				

## Example

This example shows how to use the **show platform** command:

```
RP/0/RP1:router # show platform
```

Node	Type	State	Config state
0/0/CPU0	NCS4K-2H10T-OP-KS	IOS XR RUN	NSHUT
0/1/CPU0	NCS4K-2H10T-OP-KS	IOS XR RUN	NSHUT
0/2/CPU0	NCS4K-20T-O-S	IOS XR RUN	NSHUT
0/4/CPU0	NCS4K-2H-O-K	IOS XR RUN	NSHUT
0/5/CPU0	NCS4K-2H10T-OP-KS	IOS XR RUN	NSHUT
0/6/CPU0	NCS4K-20T-O-S	IOS XR RUN	NSHUT
0/8/CPU0	NCS4K-20T-O-S	IOS XR RUN	NSHUT
0/9/CPU0	NCS4K-2H10T-OP-KS	IOS XR RUN	NSHUT
0/10/CPU0	NCS4K-20T-O-S	IOS XR RUN	NSHUT
0/11/CPU0	NCS4K-20T-O-S	IOS XR RUN	NSHUT
0/12/CPU0	NCS4K-2H-O-K	IOS XR RUN	NSHUT
0/13/CPU0	NCS4K-20T-O-S	IOS XR RUN	NSHUT
0/15/CPU0	NCS4K-20T-O-S	IOS XR RUN	NSHUT
0/RP0/CPU0	NCS4K-RP	IOS XR RUN	NSHUT

## show platform

0/RP1/CPU0	NCS4K-RP	IOS XR RUN	NSHUT
0/FC0	NCS4016-FC2-M	OPERATIONAL	NSHUT
0/FC1	NCS4016-FC2-M	OPERATIONAL	NSHUT
0/FC2	NCS4016-FC2-M	OPERATIONAL	NSHUT
0/FC3	NCS4016-FC2-M	OPERATIONAL	NSHUT
0/FT0	NCS4K-FTA	FAILED	NSHUT
0/FT1	NCS4K-FTA	FAILED	NSHUT
0/PT1	NCS4K-AC-PEM	OPERATIONAL	NSHUT
0/EC0	NCS4K-ECU	OPERATIONAL	NSHUT