

Frequency Synchronization Commands

This chapter describes the Cisco IOS XR frequency synchronization commands that are used to distribute precision frequency around a network.

- Enabling Frequency Synchronization, on page 2
- clear Frequency Synchronization esmc statistics, on page 3
- clear Frequency Synchronization wait-to-restore, on page 4
- log selection, on page 5
- priority (Frequency Synchronization), on page 6
- quality itu-t option, on page 7
- quality receive, on page 8
- quality transmit, on page 11
- selection input, on page 14
- clock-interface, on page 15
- show Frequency Synchronization configuration-errors, on page 16
- show frequency synchronization interfaces, on page 17
- show frequency synchronization clock-interfaces, on page 19
- show controllers slice-control all location, on page 22
- show controllers timing controller, on page 23
- show frequency synchronization interfaces brief, on page 25
- show Frequency Synchronization selection, on page 26
- show Frequency Synchronization selection back-trace, on page 30
- show Frequency Synchronization selection forward-trace, on page 31
- show running-config frequency synchronization, on page 32
- ssm disable, on page 33
- wait-to-restore, on page 34

Enabling Frequency Synchronization

To enable Frequency Synchronization globally on the router and to configure Frequency Synchronization options for a controller or interface, use the **frequency synchronization** command in the appropriate configuration mode. To disable Frequency Synchronization, use the **no** form of this command.

frequency synchronization no frequency synchronization

Syntax Description	This command has no	keywords	or arguments.
--------------------	---------------------	----------	---------------

Command Default Disabled

Command Modes Global configuration (config)

Interface configuration (config-interface)

 Command History
 Release
 Modification

 Release
 This command was introduced.

 6.1.42
 This command was introduced.

Usage Guidelines When you configure Frequency Synchronization in global configuration mode, the default clocking is configured for Internal Oscillator. Line timing is used only if Frequency Synchronization is enabled on Line interfaces.

```
Task ID Task ID Operations
```

ethernet-services execute

Examples

The following example shows how to enable Frequency Synchronization in global configuration:

```
RP/0/RP0:hostname# config
RP/0/RP0:hostname(config)# frequency synchronization
RP/0/RP0:hostname(config-freqsync)# commit
```

The following example shows how to enable Frequency Synchronization on an Ethernet interface:

```
RP/0/RP0:hostname# config
RP/0/RP0:hostname(config)# interface tenGigE 0/5/0/0
RP/0/RP0:hostname(config-if)# frequency synchronization
RP/0/RP0:hostname(config-if-freqsync)# commit
```

L

clear Frequency Synchronization esmc statistics

To clear the Ethernet Synchronization Messaging Channel (ESMC) statistics, use the **clear frequency** synchronization esmc statistics command in EXEC mode.

clear frequency synchronization esmc statistics interface {interface | all | summary location {node-id | all}}

Syntax Description *interface* The command can be restricted to clear the ESMC statistics for a particular interface by specifying the interface.

node-id The output can be restricted to clear the ESMC statistics for a particular node by specifying the location. The *node-id* argument is entered in the *rack/slot/module* notation.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 6.1.42	This command was introduced.

 Task ID
 Operations

 ethernet-services
 execute

Examples

The following example shows how to clear the ESMC statistics on specific interface: :

RP/0/RP0:hostname# clear frequency synchronization esmc statistics interface tenGigE0/1/0/1

clear Frequency Synchronization wait-to-restore

To clear the Frequency Synchronization wait-to-restore timer, use the **clear frequency synchronization wait-to-restore** command in EXEC mode.

clear frequency synchronization wait-to-restore {**all** | {**frequency synchronization** *port-num* **location** *node-id*} | **interface** {*type interface-path-id* | **all**}}

Syntax Description	all		Clears all wait-to-restore timers.
	interface t	ype interface-path-id	Clears the wait-to-restore timers for a specific interface or all interfaces.
Command Default	No default b	behavior or values	
Command Modes	EXEC		
Command History	Release	Modification	
	Release 6.1.42	This command was introduc	ed.
Task ID	Task ID	Operations	
	ethernet-ser	vices execute	
Examples	The following specific interest of the specific interest of the specific interest of the specific interest of the specific specific interest of the specific		the Frequency Synchronization wait-to-restore timer on

RP/0/RP0:ios# clear frequency synchronization wait-to-restore interface tenGigE0/1/0/1

log selection

To enable logging of changes or errors to Frequency Synchronization, use the **log selection** command in Frequency Synchronization configuration mode. To disable logging, use the **no** form of this command.

 $\begin{array}{ll} log & selection & \{changes \mid errors\} \\ no & log & selection \end{array}$

Syntax Description	-	ogs every time ther gs.	e is a change to the	ne selected source, including any logs that the errors keyword
		ogs only when the urce is the interna		e frequency sources, or when the only available frequency
Command Default	No default b	behavior or values		
Command Modes	Frequency S	Synchronization co	onfiguration	
Command History	Release	Modification		-
	Release 6.1.42	This command	l was introduced.	-
Task ID	Task ID	Operations		
	ethernet-ser	vices execute		
Examples	This examp	le shows how to en	nable logging of	changes to Frequency Synchronization:
	RP/0/RP0:i RP/0/RP0:i	os(config)# con os(config)# fre os(config-freqs os(config-freqs	quency synchro ync)# log sele	

priority (Frequency Synchronization)

To configure the priority of the frequency source on an interface, use the **priority** command in the Interface Frequency Synchronization configuration mode. To return the priority to the default value, use the no form of this command.

priority *priority-value* **no priority** *priority-value*

Syntax Descriptionpriority-valuePriority of the frequency source. The priority is used to select between sources with the same
Quality Level (QL). The range is 1 (highest priority) to 254 (lowest priority).

Command Modes Interface Frequency Synchronization configuration

 Command History
 Release
 Modification

 Release
 This command was introduced.

 6.1.42
 This command was introduced.

Task ID Task ID Operations

100

ethernet-services execute

Examples

Command Default

The following example shows how to configure the Frequency Synchronization priority on an interface:

RP/0/RP0:ios(config)# config RP/0/RP0:ios(config)# interface tenGigE 0/1/0/1 RP/0/RP0:ios(config-if)# frequency synchronization RP/0/RP0:ios(config-if-freqsync)# priority 150 RP/0/RP0:ios(config-if-freqsync)# commit

quality itu-t option

To configure the quality level (QL) options, use the **quality itu-t option** command in Frequency Synchronization configuration mode. To return to the default levels, use the **no** form of this command.

```
quality itu-t option \{1 \mid 2 \text{ generation } \{1 \mid 2\}\} no quality
```

Syntax Description		ion Specifies the quality level for the router. Valid options are:
,	$\{1 \mid 2\}$	 I—ITU-T QL option 1, which uses the PRC, SSU-A, SSU-B, SEC and DNU qualitievels.
		• 2 generation 1—ITU-T QL option 2 generation 1, which uses the PRS, STU, ST2 ST3, SMC, ST4, RES and DUS quality levels.
		• 2 generation 2—ITU-T QL option 2, generation 2, which uses the PRS, STU, ST2 ST3 TNC, ST3E, SMC, ST4, PROV and DUS quality levels.
command Default	ITU-T option	1
Command Modes	Frequency Syn	nchronization configuration
-	Note The QL sl	hould match with what is configured in global option.
Command History	Release	Modification
	Release 6.1.42	This command was introduced.
Jsage Guidelines		gured with the quality itu-t option command must match the QL specified in the quality quality receive commands configured in interface Frequency Synchronization configuration
ask ID	Task ID	Operations
	ethernet-servic	es execute
Examples	The following	example shows how to configure the ITU-T QL options:
	RP/0/RP0:ios	<pre>#config (config) # frequency synchronization (config-freqsync) # quality itu-t option 1 (config-freqsync) # commit</pre>

quality receive

To configure all the Synchronization Status Message (SSM) quality levels (QLs) for the frequency source from the receive interface, use the **quality receive** command in the appropriate Frequency Synchronization mode. To return to the default levels, use the no form of this command.

 $\begin{array}{l} \textbf{quality receive itu-t option} \hspace{0.1 cm} \{ \hspace{0.1 cm} \textbf{lowest} \hspace{0.1 cm} ql \hspace{0.1 cm} [\hspace{0.1 cm} \textbf{highest} \hspace{0.1 cm} ql] \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{highest} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} option \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} \textbf{exact} \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} ql \hspace{0.1 cm} ql \hspace{0.1 cm} | \hspace{0.1 cm} ql \hspace{0.1$

no quality receive

Syntax Description	ql-option	Quality Level (QL) options.
		Valid values are:
		• 1—ITU-T Option 1
		• 2 generation 1—ITU-T Option 2 Generation 1
		• 2 generation 2—ITU-T Option 2 Generation 2
	ql	Quality Level (QL) value.
		For line interfaces and clock interface with SSM support, any of the following combinations of QL values can be specified to modify the QL value received via SSM:
		• If the exact keyword is used and the received or default QL is not DNU, then this value is used (rather than the received/default QL).
		• If the lowest keyword is used and the received QL is a lower quality than this, then the received QL value is ignored and DNU is used instead.
		• If the highest keyword is used and the received QL is higher quality than this, then the received QL value is ignored and this value is used instead.
		• If the lowest and highest keywords are used, the behavior is as above. The maximum QL must be at least as high quality as the minimum QL.
		Valid QL values for ITU-T Option 1 are:
		• PRC
		• SSU-A
		• SSU-B
		• SEC
		• DNU
		Valid QL values for ITU-T Option 2 Generation 1 are:
		• PRS
		• STU
		• ST2
		• ST3
		• SMC
		• ST4
		• RES
		• DUS

	Valid QL values for ITU-T Option 2 Generation 2 are:
	• PRS
	• STU
	• ST2
	• TNC
	• ST3E
	• ST3
	• SMC
	• ST4
	• PROV
	• DUS
Command Default	QL is unmodified.
Command Modes	Interface Frequency Synchronization
	Note Quality configuration should match with what is configured in global option.
Command History	Release Modification
	Release This command was introduced. 6.1.42
Usage Guidelines	In cases where the clock interface supports SSM but it is not always enabled, all options are available.
	Note If SSM is disabled, only the exact QL option is available.
Task ID	Task ID Operations
	ethernet-services execute
Examples	The following examples shows how to configure all the SSM quality levels for the frequency source from the receive interface:
	<pre>RP/0/RP0:ios# config RP/0/RP0:ios(config)# int tenGigE0/2/0/7 RP/0/RP0:ios(config-if)# frequency synchronization RP/0/RP0:ios(config-if-freqsync)# quality receive exact itu-t option 1 PRC RP/0/RP0:ios(config-if-freqsync)# commit</pre>
	RP/0/RP0:ios# config RP/0/RP0:ios(config)# clock-interface Rack0-Bits0-In

RP/0/RP0:ios(config-clock-if)# port-parameters etsi bits-input el fas ami
RP/0/RP0:ios(config-clock-if)# frequency synchronization
RP/0/RP0:ios(config-clk-freqsync)# selection input
RP/0/RP0:ios(config-clk-freqsync)# wait-to-restore 0
RP/0/RP0:ios(config-clk-freqsync)# quality receive highest itu-t option 1 PRC
RP/0/RP0:ios(config-clk-freqsync)# commit

quality transmit

To configure all the Synchronization Status Message (SSM) quality levels for the frequency source from the transmit interface, use the **quality transmit** command in the appropriate Frequency Synchronization mode. To return to the default levels, use the **no** form of this command.

quality transmit itu-t option { lowest ql-option ql [highest ql] | highest ql-option ql | exact ql-option ql] no quality transmit

Syntax Description	al-option	Quality Level (QL) ITU-T options.
	1 1	Valid values are:
		 1—ITU-T Option 1 2 generation 1—ITU-T Option 2 Generation 1 2 generation 2—ITU-T Option 2 Generation 2
	ql	Quality Level (QL) value.
		For line interfaces with SSM support, any of the following combinations of QL values can be specified to modify the QL value received via SSM:
		• If the exact keyword is used and the received or default QL is not DNU, then this value is used (rather than the received/default QL).
		• If the lowest keyword is used and the received QL is a lower quality than this, then the received QL value is ignored and DNU is used instead.
		• If the highest keyword is used and the received QL is higher quality than this, then the received QL value is ignored and this value is used instead.
		• If the lowest and highest keywords are used, the behavior is as above. The maximum QL must be at least as high quality as the minimum QL.
		Valid QL values for ITU-T Option 1 are:
		• PRC
		• SSU-A
		• SSU-B
		• SEC
		• DNU
		Valid QL values for ITU-T Option 2 Generation 1 are:
		• PRS
		• STU
		• ST2
		• ST3
		• SMC
		• ST4
		• RES
		• DUS

I

	Val	lid QL values for ITU-T Option 2 Generation 2 are:
		• PRS
		• STU
		• ST2
		• TNC
		• ST3E
		• ST3
		• SMC
		• ST4
		• PROV
		• DUS
Command Default	The QL is uni	modified
Command Modes	Interface Free	quency Synchronization
	Note Quality of	configuration should match with what is configurad in global antion
	Note Quality (configuration should match with what is configured in global option.
Command History	Release	Modification
	Release 6.1.42	This command was introduced.
Usage Guidelines	If the interfac	e is the selected source, DNU is always sent regardless of this configuration.
<u>j</u>	This configur	ation has no effect when SSM is disabled.
	•	
		k interfaces that do not support SSM, only the lowest QL can be specified. In this case, rather than DNU, the output is squelched, and no signal is sent.
Task ID	Task ID	Operations
	ethernet-servi	ices execute
Examples		g examples show how to configure all the SSM quality levels for the frequency source smit interface:
	RP/0/RP0:ios	s# config s(config)# int tenGigE0/2/0/7 s(config-if)# frequency synchronization s(config-if-freqsync)# quality transmit exact itu-t option 2 generation 1 PRS

RP/0/RP0:ios# config RP/0/RP0:ios(config)# clock-interface Rack0-Bits0-Out RP/0/RP0:ios(config-clock-if)# port-parameters etsi bits-input el fas ami RP/0/RP0:ios(config-clock-if)# frequency synchronization RP/0/RP0:ios(config-clk-freqsync)# quality transmit highest itu-t option 1 PRC RP/0/RP0:ios(config-clk-freqsync)# commit

selection input

To configure an interface so that it is available as a timing source for selection by the system, use the **selection input** command in the appropriate Frequency Synchronization configuration mode. To remove the interface as an available timing source, use the **no** form of this command.

-	Note At a tim	ne, only two configured lin	e interfaces participate in frequency synchronization.
	selection in no selectior	-	
Syntax Description	This comma	nd has no keywords or arg	uments.
Command Default	Disabled		
Command Modes	Interface Fre	equency Synchronization co	onfiguration
Command History	Release	Modification	
	Release 6.1.42	This command was intro	oduced.
Task ID	Task ID	Operations	
	ethernet-serv	vices execute	
Examples		ng example shows how to c by the system:	onfigure an interface so that it is available as a timing source
	RP/0/RP0:hc RP/0/RP0:hc RP/0/RP0:hc	ostname# config ostname(config)# interf ostname(config-if)# fre ostname(config-if-freqs ostname(config-if-freqs	equency synchronization sync)# selection input

L

clock-interface

To configure a clock controller, use the **clock-interface** command in the config mode. To delete the controller, use the no form of this command.

```
clock-interface [ Rack0-Bits0-In | Rack0-Bits0-Out | Rack0-Bits1-In | Rack0-Bits1-Out ]
port-parameters [ Interface Type ] [ bits-input | bits-output ] [ BITS mode]
```

Following are valid port-parameter commands:

Syntax Description	Interface Type	Type of clock interface. Valid	values are ANSI and ETSI.	
	BITS mode	BITS mode.		
Command Default	None.			
Command Modes	Config mode			
Command History	Release	Modification		
	Release 6.1.42	This command was introduced.		
Examples	The following	example shows how to configure	e a clock interface:	
	RP/0/RP0:hos	<pre>tname# configure tname(config)# clock-interfa tname(config-Optics)# port-</pre>		tput el crc-4 sa4 a

RP/0/RP0:hostname(config-Optics) # commit

show Frequency Synchronization configuration-errors

To display information about any configuration inconsistencies that are detected, but that are not rejected by verification, use the **show frequency synchronization configuration-errors** command in EXEC mode.

 * The QL that is configured is from a different QL option set than is configured globally.

show frequency synchronization configuration-errors [location node-id] **Syntax Description** location Location of the card, specified by node-id. node-id The output can be restricted to a particular node by specifying the location. The node-id argument is entered in the rack/slot/module notation. No default behavior or values **Command Default** EXEC **Command Modes Command History** Modification Release Release This command was introduced. 6.1.42 Task ID Task ID Operations ethernet-services execute Examples This example shows the normal output for the show frequency synchronization configuration-errors command: RP/0/RP0:hostname # show frequency synchronization configuration-errors Thu Jan 19 09:55:42.779 UTC Node 0/RP0: _____ interface TenGigE0/13/0/7 frequency synchronization quality transmit exact itu-t option 2 generation 1 PRS

show frequency synchronization interfaces

To show the Frequency Synchronization information for all interfaces or for a specific interface, use the **show frequency synchronization interfaces** command in EXEC mode.

show frequency synchronization interfaces {**brief** | **summary** [**location** *node-id*] | *type interface-path-id*}

Syntax Description	brief		Displa	ys brief int	formation for all interfaces.
	summary [location node-id]			ry information for all notes or a specific node. ment is entered in the <i>rack/slot/module</i> notation
	type interfa	ce-path-id	Displa	ys informa	tion for a specific interface.
Command Default	No default b	ehavior or values			
Command Modes	EXEC				
Command History	Release	Modification			
	Release 6.1.42	This command was	s introduced.		
		0			
Task ID	Task ID	Operations			
Task ID		vices execute			
	ethernet-serv	vices execute	lisplay output fo	r the show i	frequency synchronization interfaces
	ethernet-serv The followin command: RP/0/RP0:hd Interface I Wait-to-r SSM Enab Input: Down - Support Output: Selecte Effect:	wices execute ag example shows the d pstname#show freque FortyGigE0/7/0/2 (urestore time 0 minu	ency synchroni inknown) ites selection		
	ethernet-serv The followin command: RP/0/RP0:hd Interface I Wait-to-1 SSM Enabl Input: Down - Support Output: Selecte Effect: Next sele	vices execute ag example shows the d ostname#show freque FortyGigE0/7/0/2 (ur restore time 0 minu led not assigned for so ts frequency ed source: None ive QL: DNU	ency synchroni inknown) ites selection _ING_SEL		
	ethernet-serv The followin command: RP/0/RP0:hd Interface I Wait-to-r SSM Enabl Input: Down - Support Output: Selecte Effect: Next sele The output in	vices execute ag example shows the d ostname#show freque FortyGigE0/7/0/2 (ur restore time 0 minuled not assigned for s ts frequency ed source: None ive QL: DNU ection points: LC7_	ency synchroni inknown) ites selection ING_SEL OWS:	zation ir	nterfaces
Task ID Examples	ethernet-serv The followin command: RP/0/RP0:hd Interface I Wait-to-r SSM Enab: Input: Down - Support Output: Selecte Effect: Next sele The output in RP/0/RP0:hd Flags: > - d	vices execute ag example shows the d ostname#show freque FortyGigE0/7/0/2 (ur restore time 0 minuled not assigned for so ts frequency ed source: None ive QL: DNU ection points: LC7_ n brief mode is as follows ostname#show freque	ency synchroni inknown) ates selection ING_SEL ows: ency synchroni D - Down	zation ir	nterfaces

				===		
>S	TenGigE0/2/0/7	ST3	ST3	100	PRS	TenGigE0/13/0/7
>S	TenGigE0/2/0/8	ST3	ST3	100	PRS	TenGigE0/13/0/7
>	TenGigE0/13/0/5	PRS	Fail	100	PRS	TenGigE0/13/0/7
>	TenGigE0/13/0/6	PRS	Fail	100	PRS	TenGigE0/13/0/7
>S	TenGigE0/13/0/7	PRS	PRS	100	DUS	TenGigE0/13/0/7
>S	TenGigE0/13/0/8	ST3	ST3	100	PRS	TenGigE0/13/0/7
D	HundredGigE0/13/0/0	Fail	Fail	100	PRS	TenGigE0/13/0/7

The output in summary mode is as follows, for each node:

RP/0/RP0:hostname#show frequency synchronization summary

1 Ethernet interfaces in Synchronous mode, 0 assigned for selection, 1 with SSM enabled

ESMC SSMs	Total	Information	Event	DNU/DUS
Sent:	23236	23168	68	200
Received:	23164	23162	2	19364

show frequency synchronization clock-interfaces

To display the frequency synchronization information for all clock-interfaces or for a specific node, use the **show frequency synchronization clock-interfaces** command in EXEC mode.

show frequency synchronization clock-interface [brief] [location node-id]

Syntax Description	brief		Displays summary information for all clock interfaces.			
	location node-id		(Optional) Displays information for a specific interface. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.			
Command Default	No default b	behavior or values				
Command Modes	EXEC					
Command History	Release	Modification				
	Release 6.1.42	This command was introdu	ced.			
ask ID	Task ID	Operations				
	ethernet-ser	vices execute				
	sonet-sdh	execute				
	RP/0/RP0:h		nchronization clock-interfaces			
	Wait-t SSM su Input:	==== rface Sync0 (Down: NONE) o-restore time 5 minutes pported and enabled - not assigned for select	lion			
	Last Supp Output Next sel Clock in Wait-t	received QL: None orts frequency is disabled ection points: T0_SEL terface Sync1 (Down: NONE) o-restore time 0 minutes pported and enabled				

```
Clock interface Sync2 (Down: NONE)
 Wait-to-restore time 5 minutes
  SSM supported and enabled
 Input:
   Down - not assigned for selection
   Last received QL: None
   Supports frequency
 Output is disabled
Next selection points: T0_SEL
Clock interface Sync3 (Down: NONE)
  Wait-to-restore time 0 minutes
 SSM supported and enabled
 Input is disabled
 Output:
   Selected source: None
   Effective QL: DNU
Next selection points: None
Clock interface Internal0 (Up)
 Assigned as input for selection
  Input:
   Default QL: None
   Effective QL: Failed, Priority: 255, Time-of-day Priority 255
   Supports frequency
Next selection points: T0_SEL T4_SEL
```

The output in brief mode is as follows:

RP/0/RP0:hostname#show frequency synchronization clock-interfaces brief

Flags:	> - Up d - SSM Disabled	-	Down Output	squelched	S - Assigned for selection L - Looped back
Node 0/	RP0:				
	======				
Fl	Clock Interface	QLrcv	QLuse	Pri QLsnd	Output driven by
=====			=====	=== ======	
D	Sync0	None	Fail	100 n/a	n/a
D	Sync1	n/a	n/a	n/a DNU	None
D	Sync2	None	Fail	100 n/a	n/a
D	Sync3	n/a	n/a	n/a DNU	None
DS	Internal0	n/a	Fail	255 n/a	n/a

The output for particular location is as follows:

RP/0/RP0:hostname#show frequency synchronization clock-interfaces location 0/RP0

Input is disabled Output: Selected source: None Effective QL: DNU Next selection points: None Clock interface Sync2 (Unknown state) Wait-to-restore time 5 minutes SSM supported and enabled Input: Down - not assigned for selection Last received QL: None Supports frequency Output is disabled Next selection points: TO SEL Clock interface Sync3 (Unknown state) Wait-to-restore time 5 minutes SSM supported and enabled Input is disabled Output: Selected source: None Effective QL: DNU Next selection points: None Clock interface Internal0 (Unknown state) Assigned as input for selection Input: Default QL: None Effective QL: Failed, Priority: 255, Time-of-day Priority 255 Supports frequency Next selection points: T0_SEL T4_SEL

show controllers slice-control all location

To display the clock source information for the LC, use the **show controllers slice-control all location** command in EXEC mode.

show controllers slice-control all location <LC location>

Command Default	No default	No default behavior or values				
Command Modes	EXEC	EXEC				
Command History	Release	Modification				
	Release 5.2.4	This command was introduced.				

Examples

The following example shows the display output for the **show controllers slice-control all location** command:

Thu Mar 22 14:36:42.68 CARD 0 IS OFFLINE CARD 1 IS OFFLINE CARD 3 IS OFFLINE CARD 8 IS OFFLINE CARD 10 IS OFFLINE CARD 11 IS OFFLINE CARD 12 IS OFFLINE CARD 13 IS OFFLINE CARD 14 IS OFFLINE	how controllers slice-control all location 0/LC1 5 IST
Slice Controller Conte	ext: 2
Inserted	
Physical Slot number	
Logical slot number	: 2 : 5408a5 (BOARD_TYPE_SCAPA_1x100GE_CPAK_10x10GE)
Slice oper state	: 5408d5 (BOARD_TIPE_SCAPA_IXIUUGE_CPAK_IUXIUGE)
Bao Version	
Hotplug status	
PCI Bar Address	
	: c9
PLLs locked	
PLLs Init Status	
PLLs Reset Status	
Clock Status	
	: External (RPO)

show controllers timing controller

To display the summary of the timing controller configuration, use the show controllers timing controller { clock | te-port} command in EXEC mode.

show controllers timing controller clock show controllers timing controller te-port

	11 5					
Syntax Description	clock D	Displays the clock i	nterface settings.			
	te-port D	Displays the te inte	erface settings.	-		
Command Default	No default b	behavior or values				
Command Modes	EXEC					
Command History	Release	Modification				
	Release 6.5.25	This comman	d was updated for	r Multi Chassis.		
	Release 6.1.42	This comman	d was introduced	1.		
Task ID	Task ID	Operations				
	ethernet-ser	vices execute				
Examples	The followi command:	ng example show	s the display outp	out for the show c	ontrollers timing cont	roller clock
Examples	command:			out for the show c		roller clock
Examples	command: RP/0/RP0:h	ostname# show co				roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo	ostname# show co	ontrollers timi	ing controller	clock	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo	ostname# show co				roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo	ostname# show co ock-Setting: Port 0 : No	ontrollers timi Port 1	ing controller of Port 2	clock Port 3	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode Framing	ostname# show co ock-Setting: Port 0 : No : - : -	Port 1 Yes	ing controller of Port 2 No	clock Port 3 Yes	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode	ostname# show co ock-Setting: Port 0 : No : - : -	Port 1 Yes E1	ing controller of Port 2 No -	Port 3 Yes El	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode Framing Linecoding Submode	Nostname# show co nck-Setting: Port 0 : No : - : - : - : -	Port 1 Yes E1 CRC4	ing controller Port 2 No - -	Port 3 Yes E1 CRC4	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode Framing Linecoding Submode Shutdown	Nostname# show co Nock-Setting: Port 0 : No : - : - : - : No	Port 1 Yes E1 CRC4 AMI Sa4 No	Port 2 No - - No No No	Port 3 Yes E1 CRC4 AMI Sa4 No	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode Framing Linecoding Submode Shutdown Direction	Nostname# show co Nock-Setting: Port 0 : No : - : - : - : No : RX	Port 1 Yes E1 CRC4 AMI Sa4 No TX	Port 2 No - - No RX	Port 3 Yes E1 CRC4 AMI Sa4 No TX	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode Framing Linecoding Submode Shutdown Direction QL Option	Nostname# show co Nock-Setting: Port 0 : No : - : - : - : No : RX	Port 1 Yes E1 CRC4 AMI Sa4 No TX O1	Port 2 No - - No No No	Port 3 Yes E1 CRC4 AMI Sa4 No TX O1	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode Framing Linecoding Submode Shutdown Direction	Nostname# show co Nock-Setting: Port 0 : No : - : - : - : No : RX	Port 1 Yes E1 CRC4 AMI Sa4 No TX O1 -	Port 2 No - - No RX	Port 3 Yes E1 CRC4 AMI Sa4 No TX O1 -	roller clock
Examples	command: RP/0/RP0:h SYNCEC Clo Config BITS Mode Framing Linecoding Submode Shutdown Direction QL Option	Nostname# show co Nock-Setting: Port 0 : No : - : - : - : No : RX : O1	Port 1 Yes E1 CRC4 AMI Sa4 No TX O1	Fort 2 No - - No RX Ol	Port 3 Yes E1 CRC4 AMI Sa4 No TX O1	roller clock

Examples

The following example shows the display output for the show controllers timing controller te-port command:

 $\texttt{RP/2/RP0:MC_FLT+4+1}\#$ show controllers timing controller te-port Thu Mar 22 11:43:01.307 IST

FSYNCDIR TE-Port Setting: Rack 0

FSYNC Mastership Rack 0: TE0-E TE state : FORWARDING Rx Signal: No Link : Good PeerRack : 1 PeerPort : TE0-W DELAY(ns): 240	TE1-E	TE0-W FORWARDING No Good 3 TE0-E 235	TE1-W FORWARDING No Good 3 TE1-E 240
FSYNCDIR TE-Port Setting	: Rack 1		
FSYNC Mastership Rack 1: TE0-E TE state : FORWARDING Rx Signal: No Link : Good PeerRack : 2 PeerPort : TE0-W DELAY(ns): 235	TE1-E	TEO-W MASTER Yes Good O TEO-E 240	TE1-W BACKUP Yes Good 0 TE1-E 240
FSYNCDIR TE-Port Setting	: Rack 2		
FSYNC Mastership Rack 2: TE0-E TE state : ALTERNATE Rx Signal: Yes Link : Good PeerRack : 3 PeerPort : TE0-W DELAY(ns): 240	SLAVE TE1-E ALTERNATE Yes Good 3 TE1-W 235	TE0-W MASTER Yes Good 1 TE0-E 240	TE1-W BACKUP Yes Good 1 TE1-E 240

FSYNCDIR TE-Port Setting: Rack 3

FSYNC Mast	ership Rack 3: S	SLAVE		
	ΓE0-E	TE1-E	TE0-W	TE1-W
TE state :	MASTER	BACKUP	ALTERNATE	ALTERNATE
Rx Signal:	Yes	Yes	Yes	Yes
Link :	Good	Good	Good	Good
PeerRack :	0	0	2	2
PeerPort :	TE0-W	TE1-W	TE0-E	TE1-E
DELAY(ns):	235	240	240	235

show frequency synchronization interfaces brief

To display frequency synchronization interface details, use the **show frequency synchronization interfaces brief** command in the appropriate mode.

show frequency synchronization interfaces brief

Syntax Description	brief Displays the brief interface information.							
Command Default	No default behavior or values							
Command Modes	System Admin EXEC							
Command History	Release	Modification						
	Release 6.1.42	This command was introduced.						

Usage Guidelines

Example

None

This example shows how to use the show frequency synchronization interfaces brief command:

RP/0/RP0:MC OTN#show frequency synchronization interfaces brief

Thu 1	Mar 22 14:42:52.032 IST					
Flags	s: > - Up	D - D0	own			S - Assigned for selection
	d - SSM Disabled	x - Pe	eer tin	ned d	out	i – Init state
	s - Output squelched					
Fl	Interface	QLrcv	QLuse	Pri	QLsnd	Output driven by
				===		
>	TenGigE0/9/0/2	DNU	n/a	100	PRC	Rack2-Bits0-In
>S	TenGigE0/9/0/8	PRC	PRC	200	PRC	Rack2-Bits0-In
>S	TenGigE2/4/0/2	SSU-A	SSU-A	100	PRC	Rack2-Bits0-In
>S	FortyGigE2/15/0/6	PRC	PRC	10	PRC	Rack2-Bits0-In

show Frequency Synchronization selection

To display the Frequency Synchronization selection information for all selection points or for a specific node, use the **show frequency synchronization selection** command in EXEC mode.

show frequency synchronization selection {location node-id}

Syntax Description	location node-idDisplays information for a specific node on the router. The node-id argument is entered in the rack/slot/module notation.					
Command Default	No default b	ehavior or values				
Command Modes	EXEC					
Command History	Release	Modification				
	Release 6.1.42	This command wa	is introduced.			
Usage Guidelines	The show fr timing source		ation selection command shows	the statu	s of th	e timing stream from the
Task ID	Task ID	Operations				
	ethernet-ser	vices execute				
	Node 0/RP0	:	y synchronization selection	L		
	Last pro Next sel SPA sc Node s Chassi Router Uses fre	point: T0_SEL (4 i grammed 00:05:34 a ection points oped : None coped : T4_SEL s scoped: None scoped : None quency selection local line interf	go, and selection made 00:0	-	Pri	Status
	1 Sync2 TenGi TenGi	[0/RP0] gE0/7/0/9/4 gE0/13/0/0/6 nal0 [0/RP0]	<pre>=</pre>	PRS PRS STU	100 100	====== Locked Available Available Available
	Last pro	grammed 00:05:22 a ection points	nputs, 1 selected) go, and selection made 00:0	5:18 agc		

```
Node scoped : None
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
 Used for local clock interface output
 S Input
                            Last Selection Point
                                                        QL Pri Status
 _____
 1 Sync2 [0/RP0]
                             0/RPO TO SEL 1
                                                       PRS
                                                             99 Locked
                                                        ST3 255 Available
    Internal0 [0/RP0]
                             n/a
Selection point: LCO ING SEL (0 inputs, 0 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
Selection point: LC1 ING SEL (0 inputs, 0 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
Node scoped : T0_SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
Selection point: LC2 ING SEL (0 inputs, 0 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
Selection point: LC3 ING SEL (0 inputs, 0 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
Selection point: LC4 ING SEL (0 inputs, 0 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
Node scoped : TO_SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
Selection point: LC5 ING SEL (0 inputs, 0 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
```

```
Selection point: LC6 ING SEL (0 inputs, 0 selected)
  Last programmed 00:05:36 ago, and selection made 00:05:36 ago
  Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
    Router scoped : None
  Uses frequency selection
Selection point: LC7_ING_SEL (1 inputs, 1 selected)
  Last programmed 00:05:36 ago, and selection made 00:05:35 ago
  Next selection points
   SPA scoped : None
Node scoped : T0_SEL
   Chassis scoped: None
   Router scoped : None
  Uses frequency selection
  S Input
                               Last Selection Point
                                                            QL Pri Status
  __ _____ ____ ____ ____ ____ ____ _____
                                                                      _____
                                                          PRS 100 Available
  1 TenGigE0/7/0/9/4
                               n/a
Selection point: LC8_ING_SEL (0 inputs, 0 selected)
  Last programmed 00:05:36 ago, and selection made 00:05:36 ago
  Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
  Uses frequency selection
Selection point: LC9 ING SEL (0 inputs, 0 selected)
  Last programmed 00:05:36 ago, and selection made 00:05:36 ago
  Next selection points
   SPA scoped : None
Node scoped : TO_SEL
   Chassis scoped: None
   Router scoped : None
  Uses frequency selection
Selection point: LC10 ING SEL (0 inputs, 0 selected)
  Last programmed 00:\overline{0}5:36 ago, and selection made 00:05:36 ago
  Next selection points
   SPA scoped : None
Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
  Uses frequency selection
Selection point: LC11_ING_SEL (0 inputs, 0 selected)
  Last programmed 00:05:36 ago, and selection made 00:05:36 ago
  Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
  Uses frequency selection
Selection point: LC12 ING SEL (0 inputs, 0 selected)
  Last programmed 00:05:36 ago, and selection made 00:05:36 ago
  Next selection points
   SPA scoped : None
Node scoped : TO_SEL
   Chassis scoped: None
   Router scoped : None
```

```
Uses frequency selection
Selection point: LC13_ING_SEL (2 inputs, 1 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:34 ago
 Next selection points
   SPA scoped : None
Node scoped : TO_SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
 S Input
                             Last Selection Point
                                                       QL Pri Status
 STU 100 Available
 1 TenGigE0/13/0/0/6
                            n/a
                                                       STU 100 Available
    TenGigE0/13/0/8
                            n/a
Selection point: LC14 ING SEL (0 inputs, 0 selected)
 Last programmed 00:\overline{0}5:3\overline{6} ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
   Node scoped : TO SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
Selection point: LC15 ING SEL (0 inputs, 0 selected)
 Last programmed 00:05:36 ago, and selection made 00:05:36 ago
 Next selection points
   SPA scoped : None
Node scoped : TO_SEL
   Chassis scoped: None
   Router scoped : None
 Uses frequency selection
```

show Frequency Synchronization selection back-trace

To display the path that was followed by the clock source that is being used to drive a particular interface use the **show frequency synchronization selection back-trace** command in EXEC mode.

show frequency synchronization selection back-trace {*port-num* | **interface** *type interface-path-id* | *node-id*}

Syntax Description interface type interface-path-id Displays the path to the specified interface.

Command Default None

Command Modes

 Command History
 Release
 Modification

 Release
 This command was introduced.

 6.1.42

Usage Guidelines The **show frequency synchronization selection back-trace** command displays the trace from the specified target interface, back to the clock source being used to drive it. The display includes the selection points that are being hit along the way.

Task ID Task ID Operation

EXEC

ethernet-services read

This example shows sample output from the **show frequency synchronization selection back-trace** command:

```
RP/0/RP0:ios# show frequency synchronization selection back-trace interface TenGigE0/7/0/9/1
Selected Source: TenGigE0/7/0/9/1
Selection Points:
    0/RP0 T0_SEL
    0/RP0 LC7_ING_SEL
```

show Frequency Synchronization selection forward-trace

To display the path that was recovered from a particular interface, use the **show frequency synchronization selection forward-trace**

show frequency synchronization selection forward-trace {*port-nu* | **interface** *type interface-path-id* | *node-id*}

Syntax Description interface type interface-path-id Displays the path to the specified interface.

Command Default None

Command Modes

Command HistoryReleaseModificationReleaseThis command was introduced.6.1.42

Usage Guidelines The show frequency synchronization selection forward-trace command displays the trace from the specified interface, out to all selection points that receive the clock from the interface, and from any interfaces that are potentially being driven by this clock source.

Task ID Task ID Operation

EXEC

ethernet-services read

This example shows sample output from the **show frequency synchronization selection forward-trace** command:

RP/0/RP0:ios#show frequency synchronization selection forward-trace interface TenGigE0/7/0/9/1
0/RP0 LC7_ING_SEL
0/RP0 T0_SEL
0/RP0 T4_SEL
Sync0 [0/RP0]
Sync1 [0/RP0]
Sync2 [0/RP0]
Sync3 [0/RP0]
TenGigE0/10/0/9/
TenGigE0/7/0/9/1

show running-config frequency synchronization

To display the current operating configuration information for frequency synchronization, use the **show running-config frequency synchronization** command in EXEC mode.

show	running-config	frequency	synchronization
------	----------------	-----------	-----------------

Command Default	No default behavior or values		
Command Modes	EXEC		
Command History	Release	Modification	
	Release 6.1.42	This command was introduced.	

Examples

The following example shows the display output for the **show running-config frequency synchronization** command:

RP/2/RP0:MC_FLT+4+1# show running-config frequency synchronization Thu Mar 22 11:33:30.986 IST frequency synchronization clock-interface timing-mode system

ssm disable

To disable Synchronization Status Messaging (SSM) on an interface, use the **ssm disable** command in the appropriate Frequency Synchronization configuration mode. To return SSM to the default value of enabled, use the **no** form of this command.

ssm disable no ssm disable

Command Default	Enabled		
Command Modes	Interface Frequency Synchronization configuration		
Command History	Release	Modification	
	Release 6.1.42	This comman	d was introduced.
Usage Guidelines	For Frequency Synchronization interfaces, the ssm disable command disables sending ESMC packets, and ignores any received ESMC packets.		
	The received QL value that is used if SSM is disabled depends on the option:		
	 Option Option		
Task ID	Task ID	Operations	
	ethernet-ser	vices execute	
Examples	The following example shows how to disable SSM on an interface:		
	RP/0/RP0:i RP/0/RP0:i RP/0/RP0:i	os(config-if)# os(config-if-fi	<pre>terface tenGigE 0/1/0/1 frequency synchronization reqsync)# ssm disable reqsync)# commit</pre>

wait-to-restore

To configure the wait-to-restore time for Frequency Synchronization on an interface, use the **wait-to-restore** command in the appropriate Frequency Synchronization configuration mode. To return the wait-to-restore time to the default value, use the **no** form of this command.

wait-to-restore minutes no wait-to-restore minutes

Syntax Description *minutes* The delay time (in minutes) between when an interface comes up and when it is used for synchronization. The range is 0 to 12.

Command Default There is a 5-minute delay for Frequency Synchronization after an interface comes up.

Command Modes Interface Frequency Synchronization (config-if-freqsync)

 Command History
 Release
 Modification

 Release
 This command was introduced.

 6.1.42
 This command was introduced.

Task ID Task ID Operations

ethernet-services execute

Examples

The following example shows how to configure the wait-to-restore time for Frequency Synchronization on an interface:

```
RP/0/RP0:ios # config
RP/0/RP0:ios(config)# interface tenGigE0/1/0/1
RP/0/RP0:ios(config-if)# frequency synchronization
RP/0/RP0:ios(config-if-freqsync)# wait-to-restore 0
RP/0/RP0:ios(config-if-freqsync)# commit
```