



Process and Memory Management Commands

This chapter describes the Cisco IOS XR software commands used to manage processes and memory.

For more information about using the process and memory management commands to perform troubleshooting tasks, see .

- [clear context](#), on page 2
- [dumpcore](#), on page 3
- [exception coresize](#), on page 6
- [exception filepath](#), on page 8
- [exception pakmem](#), on page 11
- [exception sparse](#), on page 13
- [exception sprsize](#), on page 15
- [follow](#), on page 17
- [monitor threads](#), on page 19
- [process](#), on page 23
- [process mandatory](#), on page 25
- [show context](#), on page 27
- [show dll](#), on page 30
- [show exception](#), on page 33
- [show memory](#), on page 35
- [show memory compare](#), on page 37
- [show memory heap](#), on page 40
- [show processes](#), on page 41

clear context

To clear core dump context information, use the **clear context** command in the appropriate mode.

clear context location {*node-id* | **all**}

Syntax Description	location { <i>node-id</i> all }	(Optional) Clears core dump context information for a specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the all keyword to indicate all nodes.
---------------------------	---	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 5.0.0	This command was introduced.
	Release 3.9.0	No modification.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use the **clear context** command to clear core dump context information. If you do not specify a node with the **location** *node-id* keyword and argument, this command clears core dump context information for all nodes.

Use the **show context** command to display core dump context information.

Task ID	Task ID	Operations
	diag	execute

The following example shows how to clear core dump context information:

```
RP/0/RP0/CPU0:router# clear context
```

Related Topics

[show context](#), on page 27

dumpcore

To manually generate a core dump, use the **dumpcore** command in XR EXEC mode or System Admin EXEC mode.

dumpcore {**running** | **suspended**} *job-id* **location** *node-id*

Syntax Description		
running		Generates a core dump for a running process.
suspended		Suspends a process, generates a core dump for the process, and resumes the process.
<i>job-id</i>		Process instance identifier.
location <i>node-id</i>		Generates a core dump for a process running on the specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation.

Command Default No default behavior or values

Command Modes System Admin EXEC mode
XR EXEC mode

Command History	Release	Modification
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.

Usage Guidelines When a process crashes on the Cisco IOS XR software, a core dump file of the event is written to a designated destination without bringing down the router. Upon receiving notification that a process has terminated abnormally, the Cisco IOS XR software then respawns the crashed process. Core dump files are used by Cisco Technical Support Center engineers and development engineers to debug the Cisco IOS XR software.

Core dumps can be generated manually for a process, even when a process has not crashed. Two modes exist to generate a core dump manually:

- **running** —Generates a core dump for a running process. This mode can be used to generate a core dump on a critical process (a process whose suspension could have a negative impact on the performance of the router) because the core dump file is generated independently, that is, the process continues to run as the core dump file is being generated.
- **suspended** —Suspends a process, generates a core dump for the process, and resumes the process. Whenever the process is suspended, this mode ensures data consistency in the core dump file.

Core dump files contain the following information about a crashed process:

- Register information
- Thread status information
- Process status information
- Selected memory segments

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF , a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.



Note By default, full core dumps are created irrespective of the **exception sparse** configuration. If there is not enough free shared memory available, then the core dump process fails.

Task ID	Task ID	Operations
	diag	read, write

The following example shows how to generate a core dump in suspended mode for the process instance 52:

```
RP/0/RP0/CPU0:router# dumpcore suspended 52

RP/0/RP0/CPU0:Sep 22 01:40:26.982 : sysmgr[71]: process in stop/continue state 4104
RP/0/RP0/CPU0:Sep 22 01:40:26.989 : dumper[54]: %DUMPER-4-CORE_INFO : Core for pid = 4104
(pkg/bin/devc-conaux) requested by pkg/bin/dumper_gen@node0_RP0_CPU0
RP/0/RP0/CPU0:Sep 22 01:40:26.993 : dumper[54]: %DUMPER-6-SPARSE_CORE_DUMP :
Sparse core dump as configured dump sparse for all
RP/0/RP0/CPU0:Sep 22 01:40:26.995 : dumper[54]: %DUMPER-7-DLL_INFO_HEAD : DLL path
Text addr. Text size Data addr. Data size Version
RP/0/RP0/CPU0:Sep 22 01:40:26.996 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libplatform.dll 0xfc0d5000 0x0000a914 0xfc0e0000 0x00002000 0
RP/0/RP0/CPU0:Sep 22 01:40:26.996 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysmgr.dll 0xfc0e2000 0x0000ab48 0xfc0c295c 0x00000368 0
RP/0/RP0/CPU0:Sep 22 01:40:26.997 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libinfra.dll 0xfc0ed000 0x00032de0 0xfc120000 0x00000c90 0
RP/0/RP0/CPU0:Sep 22 01:40:26.997 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libbios.dll 0xfc121000 0x0002c4bc 0xfc14e000 0x00002000 0
RP/0/RP0/CPU0:Sep 22 01:40:26.997 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libc.dll 0xfc150000 0x00077ae0 0xfc1c8000 0x00002000 0
RP/0/RP0/CPU0:Sep 22 01:40:26.998 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsyslog.dll 0xfc1d2000 0x0000530c 0xfc120c90 0x00000308 0
RP/0/RP0/CPU0:Sep 22 01:40:26.998 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libbackplane.dll 0xfc1d8000 0x0000134c 0xfc0c2e4c 0x000000a8 0
RP/0/RP0/CPU0:Sep 22 01:40:26.999 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libnodeid.dll 0xfc1e5000 0x00009114 0xfc1e41a8 0x00000208 0
RP/0/RP0/CPU0:Sep 22 01:40:26.999 : dumper[54]: %DUMPER-7-DLL_INFO :
```

```

/pkg/lib/libttyserver.dll 0xfc1f1000 0x0003dfcc 0xfc22f000 0x00002000 0
RP/0/RP0/CPU0Sep 22 01:40:27.000 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttytrace.dll 0xfc236000 0x00004024 0xfc1e44b8 0x000001c8 0
RP/0/RP0/CPU0Sep 22 01:40:27.000 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libdebug.dll 0xfc23b000 0x0000ef64 0xfc1e4680 0x00000550 0
RP/0/RP0/CPU0Sep 22 01:40:27.001 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_procfs_util.dll 0xfc24a000 0x00004e2c 0xfc1e4bd0 0x000002a8 0
RP/0/RP0/CPU0Sep 22 01:40:27.001 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysdb.dll 0xfc24f000 0x000452e0 0xfc295000 0x00000758 0
RP/0/RP0/CPU0Sep 22 01:40:27.001 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysdbutils.dll 0xfc296000 0x0000ae08 0xfc295758 0x000003ec 0
RP/0/RP0/CPU0Sep 22 01:40:27.002 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_tty_svr_error.dll 0xfc2a1000 0x0000172c 0xfc1e4e78 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.002 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_tty_error.dll 0xfc2a3000 0x00001610 0xfc1e4f00 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.003 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libwd_evm.dll 0xfc2a5000 0x0000481c 0xfc295b44 0x00000188 0
RP/0/RP0/CPU0Sep 22 01:40:27.003 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttydb.dll 0xfc2aa000 0x000051dc 0xfc295ccc 0x00000188 0
RP/0/RP0/CPU0Sep 22 01:40:27.004 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttydb_error.dll 0xfc23a024 0x00000f0c 0xfc295e54 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.004 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/librs232.dll 0xfc2b0000 0x00009c28 0xfc2ba000 0x00000470 0
RP/0/RP0/CPU0Sep 22 01:40:27.005 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_rs232_error.dll 0xfc2bb000 0x00000f8c 0xfc295edc 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.005 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libst16550.dll 0xfc2bc000 0x000008ed4 0xfc2ba470 0x00000430 0
RP/0/RP0/CPU0Sep 22 01:40:27.006 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libconaux.dll 0xfc2c5000 0x00001dc0 0xfc2ba8a0 0x000001a8 0
RP/0/RP0/CPU0Sep 22 01:40:27.006 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/lib_conaux_error.dll 0xfc1ee114 0x00000e78 0xfc295f64 0x00000088 0
RP/0/RP0/CPU0Sep 22 01:40:27.007 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttyutil.dll 0xfc2c7000 0x00003078 0xfc2baa48 0x00000168 0
RP/0/RP0/CPU0Sep 22 01:40:27.007 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libbag.dll 0xfc431000 0x0000ee98 0xfc40cc94 0x00000368 0
RP/0/RP0/CPU0Sep 22 01:40:27.008 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libchkpt.dll 0xfc474000 0x0002ecf8 0xfc4a3000 0x00000950 0
RP/0/RP0/CPU0Sep 22 01:40:27.008 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libsysdbbackend.dll 0xfc8ed000 0x0000997c 0xfc8d3aa8 0x0000028c 0
RP/0/RP0/CPU0Sep 22 01:40:27.008 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttygmtconnection.dll 0xfce85000 0x00004208 0xfce8a000 0x00000468
0
RP/0/RP0/CPU0Sep 22 01:40:27.009 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttygmt.dll 0xfcea4000 0x0000e944 0xfce8abf0 0x000003c8 0
RP/0/RP0/CPU0Sep 22 01:40:27.009 : dumper[54]: %DUMPER-7-DLL_INFO :
/pkg/lib/libttynmspc.dll 0xfcec7000 0x00004a70 0xfcec6644 0x000002c8 0
RP/0/RP0/CPU0Sep 22 01:40:28.396 : dumper[54]: %DUMPER-5-CORE_FILE_NAME :
Core for process pkg/bin/devc-conaux at harddisk:/coredump/devc-conaux.by.
dumper_gen.sparse.20040922-014027.node0_RP0_CPU0.ppc.Z
RP/0/RP0/CPU0Sep 22 01:40:32.309 : dumper[54]: %DUMPER-5-DUMP_SUCCESS : Core dump success

```

exception coresize

Halts the creation of the core file beyond the configured core file size limit.

exception coresize *size*
no exception coresize

Syntax Description	<p>coresize <i>size</i> Defines the maximum limit of the core file size beyond which the core file creation is halted and only the stack trace output is printed on the screen.</p> <p>The core file size limit can range from 1 to 4095 MB.</p>
---------------------------	---

Command Default	This command has no default behavior.
------------------------	---------------------------------------

Command Modes	Global configuration
----------------------	----------------------

Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.1.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.1.1	This command was introduced.
Release	Modification				
Release 5.1.1	This command was introduced.				

Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p>
-------------------------	--

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF , a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.



Note	By default, full core dumps are created irrespective of the exception sparse configuration. If there is not enough free shared memory available, then the core dump process fails.
-------------	---

Task ID	Task ID	Operations
	diag	read, write

The following example shows how you can disable the creation of core dump files by specifying the limit for core file size.

```
RP/0/RP0/CPU0:router(config)# exception coresize 1024  
RP/0/RP0/CPU0:router(config)# commit
```

exception filepath

To modify core dump settings, use the **exception filepath** command in the appropriate configuration mode. To remove the configuration, use the **no** form of this command.

exception filepath *filepath-name*
noexception filepath *filepath-name*

Syntax Description

filepath-name Local file system or network protocol, followed by the directory path. All local file systems are supported. The following network protocols are supported: TFTP and FTP.

Command Default

If you do not specify the order of preference for the destination of core dump files using the **choice preference** keyword and argument, the default preference is the primary location or 1.

Core dump files are sent compressed.

The default file naming convention used for core dump files is described in [Table 1: Default Core Dump File Naming Convention Description, on page 9](#).

Command Modes

XR Config

Command History

Release	Modification
Release 5.0.0	This command was introduced.
Release 3.9.0	No modification.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **exception filepath** command to modify core dump settings, such as the destination file path to store core dump files, file compression, and the filename appended to core dumps.

Up to three user-defined locations may be configured as the preferred destinations for core dump files:

- Primary location—The primary destination for core dump files. Enter the **choice** keyword and a value of **1** (that is, **choice 1**) for the *preference* argument to specify a destination as the primary location for core dump files.
- Secondary location—The secondary fallback choice for the destination for core dump files, if the primary location is unavailable (for example, if the hard disk is set as the primary location and the hard disk fails). Enter the **choice** keyword and a value of **2** (that is, **choice 2**) for the *preference* argument to specify a destination as the secondary location for core dump files.
- Tertiary location—The tertiary fallback choice as the destination for core dump files, if the primary and secondary locations fail. Enter the **choice** keyword and a value of 3 (that is, **choice 3**) for the *preference* argument to specify a destination as the tertiary location for core dump files.

When specifying a destination for a core dump file, you can specify an absolute file path on a local file system or on a network server. The following network protocols are supported: TFTP and FTP.

In addition to the three preferred destinations that can be configured, Cisco IOS XR software provides three default fallback destinations for core dump files in the event that user-defined locations are unavailable.

The default fallback destinations are:



Note If a default destination is a boot device, the core dump file is not sent to that destination.

We recommend that you configure at least one preferred destination for core dump files as a preventive measure if the default fallback paths are unavailable. Configuring at least one preferred destination also ensures that core dump files are archived because the default fallback destinations store only the first and last core dump files for a crashed process.



Note Cisco IOS XR software does not save a core file on a local storage device if the size of the core dump file creates a low-memory condition.

By default, Cisco IOS XR software assigns filenames to core dump files according to the following format:

process [.by. *requester* |.abort][.sparse]. *date-time* . *node* . *processor-type* [.Z]

For example:

```
packet.by.dumper_gen.20040921-024800.node0_RP0_CPU0.ppc.Z
```

[Table 1: Default Core Dump File Naming Convention Description, on page 9](#) describes the default core dump file naming convention.

Table 1: Default Core Dump File Naming Convention Description

Field	Description
<i>process</i>	Name of the process that generated the core dump.
.by. <i>requester</i> .abort	If the core dump was generated because of a request by a process (requester), the core filename contains the string “.by. <i>requester</i> ” where the <i>requester</i> variable is the name or process ID (PID) of the process that requested the core dump. If the core dump was due to a self-generated abort call request, the core filename contains the string “.abort” instead of the name of the requester.
.sparse	If a sparse core dump was generated instead of a full core dump, “sparse” appears in the core dump filename.
. <i>date-time</i>	Date and time the dumper process was called by the process manager to generate the core dump. The <i>.date-time</i> time-stamp variable is expressed in the <i>yyyy.mm.dd-hh.mm.ss</i> format. Including the time stamp in the filename uniquely identifies the core dump filename.
. <i>node</i>	Node ID, expressed in the <i>rack / slot</i> notation, where the process that generated the core dump was running.
. <i>processor-type</i>	Type of processor (mips or ppc).

Field	Description
.Z	If the core dump was sent compressed, the filename contains the .Z suffix.

You can modify the default naming convention by specifying a filename to be appended to core dump files with the optional **filename** *filename* keyword and argument and by specifying a lower and higher limit ranges of values to be appended to core dump filenames with the *lower-limit* and *higher-limit* arguments, respectively. The filename that you specify for the *filename* argument is appended to the core dump file and the lower and higher limit ranges of core dump files to be sent to a specified destination before the filenames are recycled. Valid values for the *lower-limit* argument are 0 to 4. Valid values for the *higher-limit* argument are 5 to 64. A hyphen (-) must immediately follow the *lower-limit* argument. In addition, to uniquely identify each core dump file, a value is appended to each core dump file, beginning with the lower-limit value specified with the *lower-limit* argument and continuing until the higher-limit value specified with the *higher-limit* argument has been reached. When the configured higher-limit value has been reached, Cisco IOS XR software begins to recycle the values appended to core dump files, beginning with the lower-limit value.

Task ID

Task ID	Operations
diag	read, write

The following example shows how to use the command:

```
RP/0/RP1/CPU0:Linkwood(config)#exception filepath f1
```

Related Topics

- [exception pakmem](#), on page 11
- [exception sparse](#), on page 13
- [exception sprsize](#), on page 15
- [show exception](#), on page 33

exception pakmem

To configure the collection of packet memory information in core dump files, use the **exception pakmem** command in administration configuration mode or in global configuration mode. To remove the configuration, use the **no** form of this command.

```
exception pakmem {on | off}
no exception pakmem {on | off}
```

Syntax Description	on Enables the collection of packet memory information in core dump files.
	off Disables the collection of packet memory information in core dump files.

Command Default	Packet memory information is not included in core dump files.
------------------------	---

Command Modes	Administration configuration Global configuration
----------------------	--

Command History	Release	Modification
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use the **exception pakmem** command with the **on** keyword to configure the collection of packet memory information in core dump files. Cisco Technical Support Center engineers and development engineers use packet memory information to debug packet memory issues related to a process.



Caution	Including packet memory information in core dump files significantly increases the amount of data generated in the core dump file, which may delay the restart time for the process.
----------------	--

Task ID	Task ID	Operations
	diag	read, write

The following example shows how to configure core dumps to include packet memory information:

```
RP/0/RP0/CPU0:router(config)# exception pakmem on
```

Related Topics

[exception filepath](#), on page 8

[exception sparse](#), on page 13

[exception sprsize](#), on page 15

[show exception](#), on page 33

exception sparse

To enable or disable sparse core dumps, use the **exception sparse** command in administration configuration mode or in global configuration mode. To remove the configuration, use the **no** form of this command.

```
exception sparse {on | off}
no exception sparse
```

Syntax Description

on Enables sparse core dumps.

off Disables sparse core dumps

Command Default

Sparse core dumps are disabled.

Command Modes

Administration configuration

Global configuration

Command History

Release	Modification
Release 3.9.0	No modification.
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **exception sparse** command to reduce the amount of data generated in the core dump file. Sparse core dumps reduce the amount of time required to generate the core dump file because only referenced data is generated in the core file (at the cost of lost information in the core file). Reducing the time required to generate core dump files corresponds to faster process restart times.



Note Use the **exception sparse off** command in administration configuration mode to get a complete coredump of the transient processes on the RP.

Sparse core dumps contain the following information about crashed processes:

- Register information for all threads, and any memory pages referenced in these register values
- Stack information for all threads, and any memory pages referenced in these threads
- All memory pages referenced by a loaded dynamic loadable library (DLL) data section, if the final program counter falls in a DLL data section
- Any user-specified marker pages from the lib_dumper_marker DLL

The **exception sparse** command dumps memory pages based on trigger addresses found in the previously listed dump information, according to the following criteria:

- If the trigger address in the memory page is in the beginning 128 bytes of the memory page, the previous memory page in the continuous address region is dumped also.
- If the trigger address in the memory page is in the final 128 bytes of the memory page, the next memory page in the continuous address region is dumped also.
- In all other instances, only the memory page that includes the trigger address is dumped.

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF, a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.



Note By default, full core dumps are created irrespective of the **exception sparse** configuration. If there is not enough free shared memory available, then the core dump process fails.

Task ID	Task ID	Operations
	diag	read, write

The following example shows how to enable sparse core dumps:

```
RP/0/RP0/CPU0:router(config)# exception sparse on
```

Related Topics

- [exception filepath](#), on page 8
- [exception pakmem](#), on page 11
- [exception sprsize](#), on page 15
- [show exception](#), on page 33

exception sprsize

To specify the maximum file size for core dumps, use the **exception sprsize** command in administration configuration mode or in global configuration mode. To remove the configuration, use the **no** form of this command.

exception sprsize *megabytes*
no exception sprsize

Syntax Description	<i>megabytes</i> Size in megabytes (MB).						
Command Default	<i>megabytes</i> : 192						
Command Modes	Administration configuration Global configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.0</td> <td>No modification.</td> </tr> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.0	No modification.	Release 5.0.0	This command was introduced.
Release	Modification						
Release 3.9.0	No modification.						
Release 5.0.0	This command was introduced.						

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **exception sprsize** command to specify the maximum file size for core dumps. The maximum file size configured for the *megabytes* argument is used with the configuration set for the [exception sparse, on page 13](#) command to determine whether or not to generate a sparse core dump file. If sparse core dumps are disabled and a core dump file is predicted to exceed the default value (192 MB) uncompressed or the value specified for the *megabytes* argument uncompressed, a sparse core dump file is generated. If sparse core dumps are enabled, a sparse core dump file is generated, regardless of the size of the core dump file.

The following scenarios are applicable for creating full or sparse core dumps:

- Without the **exception sparse** configuration or exception sparse OFF, and default core size (4095 MB), a full core is created till the core size. Beyond this, only stack trace is collected.
- With non-default core size and without the **exception sparse** configuration, or exception sparse OFF , a full core is created until the core size limit is reached. Beyond the core size limit, only the stack trace is collected.
- With the exception sparse ON and default core size (4095 MB), a full core is created until the sparse size limit is reached, and a sparse core is created thereafter till the core size. Beyond this, only stack trace is collected.
- With non-default core size and with the exception sparse ON, a full core is created until the sparse size limit is reached. Beyond the sparse size limit, only the stack trace is collected.



Note By default, full core dumps are created irrespective of the **exception sparse** configuration. If there is not enough free shared memory available, then the core dump process fails.

Task ID	Task ID	Operations
	diag	read, write

The following example shows how to set the file size of sparse core dumps to 300 MB:

```
RP/0/RP0/CPU0:router(config)# exception sprsize 300
```

Related Topics

[exception sparse](#), on page 13

follow

To unobtrusively debug a live process or a live thread in a process, use the **follow process** command in XR EXEC mode System Admin EXEC mode.

follow process [*{pid | location node-id}*]

Syntax Description	<i>pid</i>	Follows the process with the process ID (PID) specified for the <i>pid</i> argument.
	location <i>node-id</i>	Follows the target process on the designated node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation.
Command Default	Entering the follow process command without any keyword displays the stack information of the live processes with all the threads, heap memory usage, and register values.	
Command Modes	XR EXEC mode System Admin EXEC mode	
Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use this command to unintrusively debug a live process or a live thread in a process. This command is particularly useful for debugging deadlock and livelock conditions, for examining the contents of a memory location or a variable in a process to determine the cause of a corruption issue, or in investigating issues where a thread is stuck spinning in a loop. A livelock condition is one that occurs when two or more processes continually change their state in response to changes in the other processes.

The following actions can be specified with this command:

- Follow all live threads of a given process or a given thread of a process and print stack trace in a format similar to core dump output.
- Display register values and status information of the target process.

Take a snapshot of the execution path of a thread asynchronously to investigate performance-related issues by specifying a high number of iterations with a zero delay.

Task ID	Task ID	Operations
	basic-services	read

This example shows how to use the **follow process** command:

```
sysadmin-vm:0_RP0# follow process 1 location 0/RP0
```

```
Location : 0/RP0
```

```
*****
```

```
2013-09-20 01:57:30
```

```
Text address      Size      Library name
-----
00007f4b8a66c000 48 r-x--   libnss_files-2.12.so
00007f4b8a879000 1444 r-x--   libc-2.12.so
00007f4b8abec000 48 r-x--   libpci.so
00007f4b8adf9000 32 r-x--   librt-2.12.so
00007f4b8b002000 248 r-x--   libdbus-1.so.3.4.0
00007f4b8b241000 96 r-x--   libpthread-2.12.so
00007f4b8b45e000 128 r-x--   ld-2.12.so
-----
#0 0x00007f4b8a955c83 in select+0x13 from /lib64/libc-2.12.so
#1 0x000000000041f974 in ?? () from /sbin/init
#2 0x0000000000404b9d in ?? () from /sbin/init
#3 0x00007f4b8a897cce in __libc_start_main+0xfe from /lib64/libc-2.12.so
#4 0x0000000000404659 in ?? () from /sbin/init
```

Related Topics

[monitor threads](#), on page 19

[show processes](#), on page 41

monitor threads

To display auto-updating statistics on threads in a full-screen mode, use the **monitor threads** command in XR EXEC mode.

monitor threads [**dumbtty**] [**iteration** *number*] [**location** *node-id*]

Syntax Description	Parameter	Description
	dumbtty	(Optional) Displays the output of the command as if on a dumb terminal (the screen is not refreshed).
	iteration <i>number</i>	(Optional) Number of times the statistics display is to be updated, in the range from 0 to 4294967295.
	location <i>node-id</i>	(Optional) Displays the output from the command from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.

Command Default When all keywords are omitted, the **monitor threads** command displays the first ten threads for the local node, sorted in descending order by the time used. The display is cleared and updated every 5 seconds until you quit the command.

Command Modes XR EXEC

Command History	Release	Modification
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **monitor threads** command to show the top ten threads based on CPU usage. The display refreshes every 10 seconds.

- To change the parameters displayed by the **monitor threads** command, enter one of the key commands described in [Table 2: Interactive Display Commands for the monitor threads Command, on page 20](#).
- To terminate the display and return to the system prompt, enter the **q** key.
- To list the interactive commands, type **?** during the display.

[Table 2: Interactive Display Commands for the monitor threads Command, on page 20](#) describes the available interactive display commands.

Table 2: Interactive Display Commands for the monitor threads Command

Command	Description
?	Displays the available interactive commands.
d	Changes the delay interval between updates.
k	Kills a process.
l	Refreshes the screen.
n	Changes the number of threads to be displayed.
q	Quits the interactive display and returns the prompt to EXEC mode.

Task ID	Task ID	Operations
	basic-services	execute

The following example shows sample output from the **monitor threads** command:

```
RP/0/RP0/CPU0:router# monitor threads

195 processes; 628 threads;
CPU states: 98.2% idle, 0.9% user, 0.7% kernel
Memory: 2048M total, 1576M avail, page size 4K

  JID   TID  LAST_CPU  PRI  STATE  HH:MM:SS    CPU  COMMAND
    1    12    1         10  Rcv    0:00:09    0.42%  procnto-600-smp-cisco-instr
    1    25    1         10  Run    0:00:30    0.36%  procnto-600-smp-cisco-instr
  342    1    1         19  Rcv    0:00:07    0.20%  wdsysmon
    52    5    0         21  Rcv    0:00:03    0.15%  devc-conaux
    52    3    1         18  Rcv    0:00:02    0.07%  devc-conaux
532670  1    0         10  Rply   0:00:00    0.07%  top
    293   6    0         55  Rcv    0:00:06    0.03%  shelfmgr
    55    8    0         10  Rcv    0:00:02    0.03%  eth_server
   315   3    0         10  Rcv    0:00:11    0.03%  sysdb_svr_local
    55    7    0         55  Rcv    0:00:11    0.02%  eth_server
```

The following example shows sample output from the **monitor threads** command using the optional **location** keyword:

```
RP/0/RP0/CPU0:router# monitor threads location 0/RP0/CPU0

Computing times...195 processes; 628 threads;
CPU states: 95.1% idle, 2.7% user, 2.0% kernel
Memory: 2048M total, 1576M avail, page size 4K

  JID   TID  LAST_CPU  PRI  STATE  HH:MM:SS    CPU  COMMAND
    1    25    0         10  Run    0:00:32    2.08%  procnto-600-smp-cisco-instr
  265    5    0         10  SigW   0:00:09    0.89%  packet
  279    1    1         10  Rcv    0:00:00    0.65%  qsm
557246  1    0         10  Rply   0:00:00    0.51%  top
    293   5    1         55  Rcv    0:00:01    0.07%  shelfmgr
   180  13    1         10  Rcv    0:00:02    0.07%  gsp
   315   3    0         10  Rcv    0:00:12    0.07%  sysdb_svr_local
```

```

55      7      1      55 Rcv      0:00:12      0.04% eth_server
180     1      0      10 Rcv      0:00:01      0.04% gsp
298     9      0      10 Rcv      0:00:01      0.04% snmpd

```

[Table 3: monitor threads Field Descriptions, on page 21](#) describes the significant fields shown in the display.

Table 3: monitor threads Field Descriptions

Field	Description
JID	Job ID.
TIDS	Thread ID.
LAST_CPU	Number of open channels.
PRI	Priority level of the thread.
STATE	State of the thread.
HH:MM:SS	Run time of process since last restart.
CPU	Percentage of CPU used by process thread.
COMMAND	Process name.

Using Interactive Commands

When the **n** or **d** interactive command is used, the **monitor threads** command prompts for a number appropriate to the specific interactive command. The following example shows sample output from the **monitor threads** command using the interactive **n** command after the first display cycle to change the number of threads:

```

RP/0/RP0/CPU0:router# monitor threads

Computing times... 87 processes; 249 threads;
CPU states: 84.8% idle, 4.2% user, 10.9% kernel
Memory: 256M total, 175M avail, page size 4K

   JID   TID  PRI  STATE  HH:MM:SS      CPU  COMMAND
   ---   ---  ---  ---    ---:---:---   ---  ---
    1     6   10  Run    0:00:10     10.92% kernel
553049   1   10  Rply   0:00:00      4.20% top
    58    3   10  Rcv    0:00:24      0.00% sysdsbvr
    1     3   10  Rcv    0:00:21      0.00% kernel
    69    1   10  Rcv    0:00:20      0.00% wdsysmon
    1     5   10  Rcv    0:00:20      0.00% kernel
   159    2   10  Rcv    0:00:05      0.00% qnet
   160    1   10  Rcv    0:00:05      0.00% netio
   157    1   10  NSlp   0:00:04      0.00% envmon_periodic
   160    9   10  Intr   0:00:04      0.00% netio

n

Enter number of threads to display: 3
Please enter a number between 5 and 40
Enter number of threads to display: 8

```

```
87 processes; 249 threads;
CPU states: 95.3% idle, 2.9% user, 1.7% kernel
Memory: 256M total, 175M avail, page size 4K
```

JID	TID	PRI	STATE	HH:MM:SS	CPU	COMMAND
1	6	10	Run	0:00:11	1.76%	kernel
69	1	10	Rcv	0:00:20	1.11%	wdsysmon
58	3	10	Rcv	0:00:24	0.40%	sysdsbr
157	1	10	NSlp	0:00:04	0.23%	envmon_periodic
159	19	10	Rcv	0:00:02	0.20%	qnet
553049	1	10	Rply	0:00:00	0.20%	top
159	12	10	Rcv	0:00:03	0.13%	qnet
160	1	10	Rcv	0:00:05	0.10%	netio

When a number outside the acceptable range is entered, the acceptable range is displayed:

```
Please enter a number between 5 and 40
Enter number of threads to display:
```

Related Topics

[monitor processes](#)

process

To terminate or restart a process, use the **process** command in the System Admin EXEC mode.

```
process {crash | restart} executable-name {IID location node-id | location node-id}
```

Syntax Description		
crash		Ends a process. All active services hosted by the process that have high availability enabled are switched off and the process restarts.
restart		Restarts a process.
<i>executable-name</i>		Executable name of the process to be crashed or restarted. Supplying an executable name for the <i>executable-name</i> argument performs the action for all the simultaneously running instances of the process, if applicable.
<i>IID</i>		Process instance ID of the process to be crashed or restarted. Supplying a process ID for the <i>IID</i> argument performs the action for only the process instance associated with the process ID.
location <i>node-id</i>		Crashes or restarts a process on the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.

Command Default None

Command Modes System Admin EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Under normal circumstances, processes are started and restarted automatically by the operating system as required. If a process crashes, it is automatically restarted.

Use this command to manually stop or restart individual processes.



Caution Manually stopping or restarting a process can seriously impact the operation of a router. Use these commands only under the direction of a Cisco Technical Support representative.

process restart

The **process restart** command restarts a process, such as a process that is not functioning optimally.

Task ID	Task ID	Operations
	root-lr	execute

This example shows how to restart a process:

```
sysadmin-vm:0_RP0# process restart syslogd_helper location 0/3
```

```
proc-action-status User root (127.0.0.1) requested restart for process syslogd_helper(0)
at 0/3 'Sending signal 15 to process syslogd_helper(IID 0) pid=1801'
```

Related Topics

[process mandatory](#), on page 25

[show processes](#), on page 41

process mandatory

To set the mandatory reboot options for a process, use the **process mandatory** command in the appropriate mode.

process mandatory

process mandatory {**on** | **off**} {*executable-name**job-id*} **location** *node-id*

process mandatory toggle

process mandatory toggle {*executable-name**job-id*} **location** *node-id*

Syntax Description		
on		Turns on mandatory process attribute.
off		Turns off the mandatory process attribute. The process is not considered mandatory.
toggle		Toggles a mandatory process attribute.
<i>executable-name</i>		Executable name of the process to be terminated. Specifying an executable name for the <i>executable-name</i> argument terminates the process and all the simultaneously running copies, if applicable.
<i>job-id</i>		Job ID associated with the process to be terminated. Terminates only the process associated with the job ID.
location <i>node-id</i>		Sets the mandatory settings for a process on a designated node. The node-id argument is expressed in the <i>rack/slot</i> notation.

Command Default No default behavior or values

Command Modes XR EXEC

Command History	Release	Modification
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If a process unexpectedly goes down, the following action occurs based on whether the process is considered mandatory.

- If the process is mandatory and the process cannot be restarted, the node automatically reboots.
- If the process is not mandatory and cannot be restarted, it stays down and the node does not reboot.

Task ID	Task ID	Operations
	root-lr	execute

The following example shows how to turn on a mandatory attribute. In this example, the mandatory attribute is turned on for the `media_ether_config_di` process.

```
RP/0/RP0/CPU0:router# process mandatory on media_ether_config_di
```

The following example shows how to turn the reboot option on. In this example, the router is set to reboot the node if a mandatory process goes down and cannot be restarted.

```
RP/0/RP0/CPU0:router# process mandatory reboot enable
```

```
RP/0/0/CPU0:Mar 19 19:28:10 : sysmgr[71]: %SYSMGR-4-MANDATORY_REBOOT_ENABLE :
mandatory reboot option enabled by request
```

The following example shows how to turn off the reboot option. In this example, the router is set *not* to reboot the node if a mandatory process goes down and cannot be restarted. In this case, the mandatory process is restarted, but the node is not rebooted.

```
RP/0/RP0/CPU0:router# process mandatory reboot disable
```

```
RP/0/0/CPU0:Mar 19 19:31:20 : sysmgr[71]: %SYSMGR-4-MANDATORY_REBOOT_OVERRIDE
: mandatory reboot option overridden by request
```

Related Topics

[show processes](#), on page 41

show context

To display core dump context information, use the **show context** command in

XR EXEC

mode.

show context [{*coredump-occurrence* | **clear**}] [**location** {*node-id* | **all**}]

Syntax Description

<i>coredump-occurrence</i>	(Optional) Core dump context information to be displayed based on the occurrence of the core dump. Valid values are 1 to 10.
clear	(Optional) Clears the current context information.
location { <i>node-id</i> all }	Displays core dump information that occurred on the designated node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. The all keyword specifies to display information for all nodes.

Command Default

If no *coredump-occurrence* value is specified, core dump context information for all core dumps is displayed.

Command Modes

XR EXEC

Command History

Release	Modification
Release 3.9.0	No modification.
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show context** command to display core dump context information. This command displays context information for the last ten core dumps. Cisco Technical Support Center engineers and development engineers use this command for post-analysis in the debugging of processes.

Use the [clear context, on page 2](#) command to clear core dump context information.

Task ID

Task ID	Operations
diag	read

The following example shows sample output from the **show context** command:

```
RP/0/RP0/CPU0:router# show context
```

```
Crashed pid = 20502 (pkg/bin/mbi-hello)
Crash time: Thu Mar 25, 2004: 19:34:14
```

```
Core for process at disk0:/mbi-hello.20040325-193414.node0_RP0_CPU0
```

```
Stack Trace
#0 0xfc117c9c
#1 0xfc104348
#2 0xfc104154
#3 0xfc107578
#4 0xfc107734
#5 0x482009e4

Registers info
      r0      r1      r2      r3
R0  0000000e 481ffa80 4820c0b8 00000003
      r4      r5      r6      r7
R4  481ffb18 00000001 481ffa88 48200434
      r8      r9      r10     r11
R8  00000000 00000001 00000000 fc17ac58
      r12     r13     r14     r15
R12 481ffb08 4820c080 481ffc10 00000001
      r16     r17     r18     r19
R16 481ffc24 481ffc2c 481ffc4 00000000
      r20     r21     r22     r23
R20 00398020 00000000 481ffb6c 4820a484
      r24     r25     r26     r27
R24 00000000 00000001 4820efe0 481ffb88
      r28     r29     r30     r31
R28 00000001 481ffb18 4820ef08 00000001
      cnt     lr      msr     pc
R32 fc168d58 fc104348 0000d932 fc117c9c
      cnd     xer
R36 24000022 00000004
```

DLL Info

```
DLL path  Text addr.  Text size  Data addr.  Data size  Version
/pkg/lib/libinfra.dll 0xfc0f6000 0x00032698 0xfc0f5268 0x00000cb4
```

The following example shows sample output from the **show context** command. The output displays information about a core dump from a process that has not crashed.

```
RP/0/RP0/CPU0:router# show context
```

```
node:      node0_RP0_CPU0
-----
```

```
Crashed pid = 28703 (pkg/bin/packet)
Crash time: Tue Sep 21, 2004: 02:48:00
Core for process at harddisk:/packet.by.dumper_gen.20040921-024800.node0_RP0_CPU0.ppc.Z
```

[Table 4: show context Field Descriptions, on page 28](#) describes the significant fields shown in the display.

Table 4: show context Field Descriptions

Field	Description
Crashed pid	Process ID (PID) of the crashed process followed by the executable path.
Crash time	Time and date the crash occurred.
Core for process at	File path to the core dump file.

Field	Description
Stack Trace	Stack trace information.
Registers Info	Register information related to crashed threads.
DLL Info	Dynamically loadable library (DLL) information used to decode the stack trace.

Related Topics

[clear context](#), on page 2

show dll

To display dynamically loadable library (DLL) information, use the **show dll** command in administration EXEC mode or in EXEC

XR EXEC

mode.

show dll [{**jobid** *job-id* [**virtual**] | [**symbol**]**address** *virtual-address* | **dllname** *dll-virtual-path* | **memory** | **virtual**}] [**location** *node-id*]

Syntax Description		
jobid <i>job-id</i>		(Optional) Displays DLL information for the specified job identifier.
virtual		(Optional) Displays the virtual path of DLLs. The virtual path is expressed in the /pkg/lib/library-name.dll format where the library name is the name of the DLL followed by the .dll suffix.
symbol		(Optional) Displays the symbol at the virtual address specified for the <i>virtual-address</i> argument.
address <i>virtual-address</i>		(Optional) Displays the DLL that is mapped at the virtual address specified for the <i>virtual-address</i> argument.
dllname <i>dll-virtual-path</i>		(Optional) Displays the process IDs (PIDs) of the process that have downloaded the DLL specified for the <i>dll-virtual-path</i> argument.
memory		(Optional) Displays a summary of DLL memory usage.
location <i>node-id</i>		(Optional) Displays DLLs for the specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation.

Command Default No default behavior or values

Command Modes EXEC, Administration EXEC
XR EXEC

Command History	Release	Modification
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	basic-services	read

The following example shows sample output from the **show dll** command. In this example, the output displays all the DLLs loaded on the router.

```
RP/0/RP0/CPU0:router# show dll
```

DLL path	Text VA	Text Sz	Data VA	Data Sz	Refcount
/lib/libui.dll	0xfc000000	0x00007000	0xfc007000	0x00001000	1
/disk0/-base-0.48.0/lib/liblogin.dll	0xfc008000	0x00006000	0xfc00e000	0x00001000	1
/mbi/lib/libbanner.dll	0xfc00f000	0x00003000	0xfc012000	0x00001000	1
/disk0/-base-0.48.0/lib/libaaav2.dll	0xfc013000	0x0000f000	0xfc022000	0x00001000	1
/disk0/-base-0.48.0/lib/libaaatty.dll	0xfc023000	0x00004000	0xfc027000	0x00001000	1
/mbi/lib/libtermcap.dll	0xfc028000	0x00003000	0xfc02b000	0x00001000	1
/mbi/lib/lib_show_dll.dll	0xfc02c000	0x00004000	0xfc030000	0x00001000	1
/mbi/lib/libihplatform.dll	0xfc0bf2d4	0x00000c18	0xfc1e4f88	0x00000068	1
/lib/libovl.dll	0xfc0c8000	0x0000c3b0	0xfc0c21f0	0x0000076c	23
/disk0/-admin-0.48.0/lib/libfqm_ltrace_util_common.dll	0xfc0d43b0	0x00000bfc	0xfc391f7c	0x00000068	1
/lib/libplatform.dll	0xfc0d5000	0x0000aa88	0xfc0e0000	0x00002000	165
/lib/libsystemgr.dll	0xfc0e2000	0x0000ab48	0xfc0c295c	0x00000368	166
/lib/libinfra.dll	0xfc0ed000	0x0003284c	0xfc120000	0x00000c70	169
/lib/libbios.dll	0xfc121000	0x0002c4bc	0xfc14e000	0x00002000	166
/lib/libc.dll	0xfc150000	0x00077ae0	0xfc1c8000	0x00002000	175
/mbi/lib/libltrace.dll	0xfc1ca000	0x00007f5c	0xfc0c2cc4	0x00000188	96
/lib/libsyslog.dll	0xfc1d2000	0x0000530c	0xfc120c70	0x00000308	129
/disk0/-base-0.48.0/lib/liblpts_ifib_platform.dll	0xfc1d730c	0x00000cc8	0xfcef4000	0x00000068	1
/lib/libbackplane.dll	0xfc1d8000	0x0000134c	0xfc0c2e4c	0x000000a8	163
/disk0/-base-0.48.0/lib/libipv6_platform_client.dll	0xfc1d934c	0x00000c48	0xfcef4f8c	0x00000068	1
/mbi/lib/libpkgfs_node.dll	0xfc1da000	0x000092d4	0xfc1e4000	0x000001a8	3

The following example shows sample output from the **show dll** command with the optional **jobid** keyword and argument:

```
RP/0/RP0/CPU0:router# show dll jobid 186
```

DLLs mapped by PID 86111					
DLL path	Text VA	Text Sz	Data VA	Data Sz	Refcount
/lib/libovl.dll	0xfc0c8000	0x0000c3b0	0xfc0c21f0	0x0000076c	23
/lib/libplatform.dll	0xfc0d5000	0x0000aa88	0xfc0e0000	0x00002000	165
/lib/libsystemgr.dll	0xfc0e2000	0x0000ab48	0xfc0c295c	0x00000368	167
/lib/libinfra.dll	0xfc0ed000	0x0003284c	0xfc120000	0x00000c70	169
/lib/libbios.dll	0xfc121000	0x0002c4bc	0xfc14e000	0x00002000	166
/lib/libc.dll	0xfc150000	0x00077ae0	0xfc1c8000	0x00002000	175
/mbi/lib/libltrace.dll	0xfc1ca000	0x00007f5c	0xfc0c2cc4	0x00000188	96
/lib/libsyslog.dll	0xfc1d2000	0x0000530c	0xfc120c70	0x00000308	129
/lib/libbackplane.dll	0xfc1d8000	0x0000134c	0xfc0c2e4c	0x000000a8	163
/lib/libnodeid.dll	0xfc1e5000	0x000091fc	0xfc1e41a8	0x00000208	163
/mbi/lib/libinst_mem.dll	0xfc232000	0x000044f8	0xfc1e43b0	0x00000108	4
/lib/libdebug.dll	0xfc23c000	0x0000ef64	0xfc1e4680	0x00000550	159

Table 5: **show dll** Field Descriptions, on page 32 describes the significant fields shown in the display.

Table 5: show dll Field Descriptions

Field	Description
DLL path	Physical path of the DLL on the router.
Text VA	Virtual address of the text segment of the DLL.
Text Sz	Size of the text segment of the DLL.
Data VA	Virtual address of the data segment of the DLL.
Data Sz	Size of the data segment of the DLL.
Refcount	Number of clients using the DLL.

The following example shows sample output from the **show dll** command with the optional **dllname** *dll-virtual-path* keyword and optional argument:

```
RP/0/RP0/CPU0:router# show dll dllname /pkg/lib/libinst_mem.dll

PID:      4102  Refcount: 1
PID:      4105  Refcount: 1
PID:      24600 Refcount: 1
PID:      86111 Refcount: 1
```

[Table 6: show dll dllname Field Descriptions, on page 32](#) describes the significant fields shown in the display.

Table 6: show dll dllname Field Descriptions

Field	Description
PID:	Process ID of the process.
Refcount	Number of references to the DLL by the process.

The following example shows sample **show dll** output from the command with the optional **memory** keyword:

```
RP/0/RP0/CPU0:router# show dll memory
-----
Total DLL Text - 14778896 bytes  Total DLL Data - 12688500 bytes
Total DLL Memory - 27467396 bytes
```

show exception

To display the configured core dump settings, use the **show exception** command in

XR EXEC

mode.

show exception [**core-options** [**process** *process-name*] **location** *node-id*]

Syntax Description	core-options	(Optional) Displays process core option values.
	process <i>process-name</i>	(Optional) Specifies the process for which to display the information.
	location <i>node-id</i>	(Optional) Displays configured settings for a specified node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation.

Command Default None

Command Modes XR EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.
	Release 3.9.0	Support for the core-options keyword was added.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show exception** command to display the configured core dump settings. The output from this command displays the core dump settings configured with the following commands:

- [exception filepath, on page 8](#)
- [exception pakmem, on page 11](#)
- [exception sparse, on page 13](#)
- [exception sprsize, on page 15](#)

Task ID	Task ID	Operations
	diag	read

The following example shows sample output from the **show exception** command with the **location** keyword. All processes for the specified node are displayed.

```
RP/0/RP0/CPU0:router# show excep core-options location 0/rp0/cpu0
```

```
Mon Nov 30 01:31:31.391 PST
```

```

Process
    Options
attach_server:
    TEXT SHAREDMEM MAINMEM
attachd:
    TEXT SHAREDMEM MAINMEM
ksh-aux:
    TEXT SHAREDMEM MAINMEM
bcm_logger:
    TEXT SHAREDMEM MAINMEM
devf-scrp:
    TEXT SHAREDMEM MAINMEM
bfm_server:
    TEXT SHAREDMEM MAINMEM
ksh:
    TEXT SHAREDMEM MAINMEM
dllmgr:
    COPY
dumper:
    TEXT SHAREDMEM MAINMEM
eth_server:
    COPY SPARSE
inflator:
    TEXT SHAREDMEM MAINMEM
insthelper:
    TEXT SHAREDMEM MAINMEM
mbi-hello:
    TEXT SHAREDMEM MAINMEM
cat:
    TEXT SHAREDMEM MAINMEM
mq:
    COPY
mqueue:
    TEXT SHAREDMEM MAINMEM
nname:
    TEXT SHAREDMEM MAINMEM
nvram:
    TEXT SHAREDMEM MAINMEM
--More--

```

The following example shows sample output from the **show exception** command for a specific process:

```

RP/0/RP0/CPU0:router# show excep core-options process upgrade_daemon location 0/6/cpu0

Mon Nov 30 01:32:20.207 PST
Process
    Options
upgrade_daemon:
    TEXT SHAREDMEM MAINMEM

```

Related Topics

- [exception filepath](#), on page 8
- [exception pakmem](#), on page 11
- [exception sparse](#), on page 13
- [exception sprsize](#), on page 15

show memory

To display the available physical memory and memory usage information of processes on the router, use the **show memory** command in System Admin EXEC and XR EXEC mode.

show memory [{**location** *node-id* | **pid** *pid* [**location** *node-id*] | **summary** [**location** *node-id*]}]

Syntax Description		
	location <i>node-id</i>	Displays the available physical memory from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.
	pid <i>pid</i>	Displays memory usage of the specified process.
	summary	Displays a summary of the physical memory and memory usage information.

Command Default None

Command Modes System Admin EXEC
XR EXEC

Command History	Release	Modification
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.

Usage Guidelines To display detailed memory information for the entire router, enter the **show memory** command without any parameters.

Task ID	Task ID	Operations
	basic-services	read

This example shows how to display the output of the **show memory location** command:

```

sysadmin-vm:0_RP0#show memory location 0/RP0
Tue Aug 20 00:49:41.649 UTC
*****

Location : 0/RP0
*****

Tue Aug 20 00:49:41 UTC 2013
l: /sbin/init
Address          Kbytes    RSS      Anon   Locked Mode   Mapping
0000000000400000    204      -      -      -  r-x--  init
0000000000632000     4       -      -      -  rw---  init
    
```

Address - Memory Address
Kbytes - Memory Size
RSS - Resident Set Size (portion of mem in RAM)
Anon - Non-shared Anonymous
Locked - locked memory
Mode - Read/Write/Executable mode
Mapping - process Mapping

Related Topics

[show memory heap](#), on page 40

[show processes](#), on page 41

show memory compare

To display details about heap memory usage for all processes on the router at different moments in time and compare the results, use the **show memory compare** command in System Admin EXEC and XR EXEC mode.

show memory compare {start | end | report}

Syntax Description

start	Takes the initial snapshot of heap memory usage for all processes on the router and sends the report to a temporary file named /tmp/memcmp_start.out.
end	Takes the second snapshot of heap memory usage for all processes on the router and sends the report to a temporary file named /tmp/memcmp_end.out. This snapshot is compared with the initial snapshot when displaying the heap memory usage comparison report.
report	Displays the heap memory comparison report, comparing heap memory usage between the two snapshots of heap memory usage.

Command Default

None

Command Modes

System Admin EXEC

XR EXEC

Command History

Release	Modification
Release 3.9.0	No modification.
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **show memory compare** command to display details about the heap memory usage of all processes on the router at different moments in time and compare the results. This command is useful for detecting patterns of memory usage during events such as restarting processes or configuring interfaces.

Use the following steps to create and compare memory snapshots:

1. Enter the **show memory compare** command with the **start** keyword to take the initial snapshot of heap memory usage for all processes on the router.
2. Perform the test you want to analyze.
3. Enter the **show memory compare** command with the **end** keyword to take the snapshot of heap memory usage to be compared with the initial snapshot.
4. Enter the **show memory compare** command with the **report** keyword to display the heap memory usage comparison report.

Task ID

Task ID	Operations
basic-services	read

This example shows sample output from the **show memory compare** command with the **report** keyword:

```
sysadmin-vm:0_RP0# show memory compare start
Tue Aug 20 11:50:45.860 UTC
sysadmin-vm:0_RP0# show memory compare end
Tue Aug 20 11:50:57.311 UTC
sysadmin-vm:0_RP0# show memory compare report
```

PID	NAME	MEM BEFORE	MEM AFTER	DIFFERENCE	MALLOCS
21416	malloc_dump	34731	34731	0	0
21414	sh	39652	39640	-12	0
21411	show_memory_common	984	984	0	0
8340	ntpd	69033	69033	0	0
5172	inst_mgr	1800118	1800118	0	0
5166	fsdbagg	14907247	14907247	0	0
5175	fsdb_server	15475470	15475470	0	0
5177	led_mgr	3347339	3347339	0	0
5176	envmon_ui	889094	889094	0	0
5169	esdma	8954927	8954927	0	0
5164	fit_mgbl	952067	952067	0	0
5174	fab_fgid_service	9014924	9014924	0	0
5173	confd_helper	8018190	8018190	0	0
5171	debug_agent	8146830	8146830	0	0
5170	gasp_mgbl	1285020	1285020	0	0
5168	ael_mgbl	787101	787101	0	0
5165	fpdserv	1149685	1149685	0	0
5167	ssh_key_server	661086	661086	0	0
2052	sfe_driver	35005323	35005323	0	0
2066	zen	5083246	5083246	0	0
2017	ccc_driver	8872747	8882315	9568	1
2053	shelf_mgr	30666121	30666121	0	0
2031	esd	6335087	6334783	-304	-2
2049	sdr_mgr	4366258	4366258	0	0
2025	dumper	616144	616144	0	0
2035	inst_agent	1820469	1820469	0	0
2062	syslogd_relay	657904	657904	0	0
2030	envmon	7853186	7853330	144	2
2041	ntp_helper	701348	701348	0	0
2539	ssh	202441	202441	0	0
2015	bios_fpd	2950893	2950893	0	0
2042	obfl_mgr	2686006	2686006	0	0
2018	cm	13755230	13755230	0	0
2047	obfl_show	686286	686286	0	0
2024	ds	7826821	7826821	0	0
2060	syslogd_helper	912664	912664	0	0
2014	aaad	804327	804327	0	0
2019	debug_client	577975	577975	0	0
2016	calv_alarm_mgr	2077250	2077250	0	0
2065	wdmon	3557984	3558056	72	1
2064	vm_manager	3149588	3149588	0	0
2037	mlap	1520260	1520260	0	0
2056	ssh_key_client	612824	612824	0	0
2055	ship_server	778066	778066	0	0
2063	timezone_config	711110	711110	0	0
1744	pm	7875584	7875584	0	0

Table 7: show memory compare report Field Descriptions

Field	Description
PID	Process ID.
name	Process name.
mem before	Heap memory usage at start (in bytes).
mem after	Heap memory usage at end (in bytes).
difference	Difference in heap memory usage (in bytes).
mallocs	Number of unfreed allocations made during the test period.
restarted	Indicates if the process was restarted during the test period.

Related Topics

[show memory heap](#), on page 40

[show processes](#), on page 41

show memory heap

To display information about the heap space for a process, use the **show memory heap** command in System Admin EXEC and XR EXEC mode.

show memory heap *pid*

Syntax Description	<i>pid</i>	Process ID
Command Default	None	
Command Modes	System Admin EXEC XR EXEC	
Command History	Release	Modification
	Release 3.9.0	No modification.
	Release 5.0.0	This command was introduced.
Task ID	Task ID	Operations
	basic-services	read

This example shows the sample output from the **show memory heap** command:

```

sysadmin-vm:0_RP0#show memory heap 1933
Tue Aug 20 01:06:11.282 UTC

statistics (1933:vm_manager)

Global data:
current usage:          3147787 bytes
Wrapper uses:           109560 bytes (hash:32728)
total high wm:         7342424 bytes
current objs:           2401 entry
malloc_db/malloc:       79946 times / 79946 times
calloc_db/calloc:       1067 times / 1067 times
realloc_db/realloc:     26342 times / 26342 times
realloc_null:           25644 times
realloc_db_miss :       0 times
realloc_relocate:       39 times
free_db/free:           104256 times / 104722 times
free_null:              466 times
free_db_miss:           0 times
error:                  0 times

```

Related Topics

[show memory](#), on page 35

show processes

To display information about active processes, use the **show processes** command in System Admin EXEC mode.

```
show processes {process-name [{detail|run}] location node-id|location node-id} | aborts location
node-id | all location node-id | blocked [{PID | extended | location node-id}] | family [{PID | location
node-id}] | files [{PID | details | location node-id}] | location [{all/node-id}] | mandatory location
node-id | memory [{PID | location node-id}] | services {service-name | active | all | run | standby}
location node-id | signal [{PID | location node-id}] | startup location node-id | threadname [{PID |
location node-id}]}
```

Syntax Description		
<i>process-name</i>		Name of the executable.
detail		Displays detailed information of the process.
run		Displays information of running processes.
location <i>node-id</i>		Displays information about the active processes from a designated node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.
aborts		Displays process abort information.
all		Displays summary process information for all processes.
blocked		Displays details about reply, send, and mutex blocked processes.
<i>PID</i>		Displays process ID.
extended		Displays blocked processes in detail.
family		Displays the process session and family information.
files		Displays information about open files and open communication channels.
mandatory		Displays process data for mandatory processes.
memory		Displays information about the text, data, and stack usage for processes.
services <i>service name</i>		Displays service data for processes.
active		Displays active services data.
standby		Displays standby services data.
signal		Displays the signal options for blocked, pending, ignored, and queued signals.

show processes

startup Displays process data for processes created at startup.

threadname Displays thread names.

Command Default None

Command Modes System Admin EXEC

Command History

Release	Modification
Release 3.9.0	No modification.
Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show processes** command to display process level information across the system.

Task ID

Task ID	Operations
basic-services	read

The **show processes** command with the **memory** keyword displays details of memory usage for a given process as shown in the following example:

```
sysadmin-vm:0_RP0# show process memory
```

PID	Text	Data	Stack	Dynamic	Process
1	204 KB	204 KB	136 KB	14932 KB	init
12680	16 KB	48 KB	136 KB	3852 KB	sleep
12747	32 KB	8432 KB	136 KB	24776 KB	cmdptywrapper
12751	12 KB	8508 KB	136 KB	74040 KB	show_processes_
12754	724 KB	8456 KB	136 KB	25832 KB	sh
1299	724 KB	208 KB	136 KB	11280 KB	oom.sh
1305	724 KB	208 KB	136 KB	11280 KB	oom.sh
1443	476 KB	540 KB	136 KB	14984 KB	dhclient
1486	28 KB	188 KB	136 KB	6104 KB	syslogd
1490	20 KB	3056 KB	136 KB	6864 KB	klogd
1545	224 KB	204 KB	136 KB	13172 KB	lldpad
1557	308 KB	204 KB	136 KB	12844 KB	dbus-daemon
1588	412 KB	444 KB	136 KB	23252 KB	sshd
1593	412 KB	444 KB	136 KB	23252 KB	sshd
1602	192 KB	372 KB	136 KB	11120 KB	xinetd
1618	40 KB	692 KB	524 KB	7008 KB	crond
1630	792 KB	49720 KB	136 KB	83164 KB	libvirtd
1711	116 KB	636 KB	136 KB	4540 KB	udev
1712	116 KB	636 KB	136 KB	4540 KB	udev
1722	324 KB	16164 KB	136 KB	148164 KB	pm

Table 8: show processes memory Field Descriptions

Field	Description
PID	Process ID.

Field	Description
Text	Size of text region (process executable).
Data	Size of data region (initialized and uninitialized variables).
Stack	Size of process stack.
Dynamic	Size of dynamically allocated memory.
Process	Process name.

Related Topics

[monitor processes](#)

[monitor threads](#), on page 19

show processes