



## Platform Settings

---

- [Setting the Date and Time, on page 1](#)
- [Configuring SSH, on page 8](#)
- [Configuring TLS, on page 12](#)
- [Configuring Telnet, on page 14](#)
- [Configuring SNMP, on page 15](#)
- [Configuring HTTPS, on page 25](#)
- [Configuring AAA, on page 38](#)
- [Verifying Remote AAA Server Configurations, on page 61](#)
- [Configuring Syslog, on page 63](#)
- [Configuring DNS Servers, on page 65](#)
- [Enable FIPS Mode, on page 66](#)
- [Enable Common Criteria Mode, on page 67](#)
- [Configure the IP Access List, on page 68](#)
- [Add a MAC Pool Prefix and View MAC Addresses for Container Instance Interfaces, on page 69](#)
- [Add a Resource Profile for Container Instances, on page 71](#)
- [Configure a Network Control Policy, on page 74](#)
- [Configure the Chassis URL, on page 77](#)
- [Modifying Weak Key Exchange Algorithms, on page 78](#)
- [Register the Chassis with the Firepower Management Center for Health Monitoring, on page 79](#)

## Setting the Date and Time

Use the CLI commands described below to configure the network time protocol (NTP) on the system, to set the date and time manually, or to view the current system time.

NTP settings are automatically synced between the Firepower 4100/9300 chassis and any logical devices installed on the chassis.



---

**Note** If you are deploying Firepower Threat Defense on the Firepower 4100/9300 chassis, you must configure NTP on the Firepower 4100/9300 chassis so that Smart Licensing will work properly and to ensure proper timestamps on device registrations. You should use the same NTP server for both the Firepower 4100/9300 chassis and the FMC, but note that you cannot use FMC as the NTP server for the Firepower 4100/9300 chassis.

---

If you are using NTP, you can view the overall synchronization status on the **Current Time** tab, or you can view the synchronization status for each configured NTP server by looking at the Server Status field in the **NTP Server** table on the **Time Synchronization** tab. If the system is unable to synchronize with a particular NTP server, you can hover over the information icon next to the Server Status for more information.

## Viewing the Configured Date and Time

### Procedure

---

**Step 1** Connect to the FXOS CLI (see [Accessing the FXOS CLI](#)).

**Step 2** To view the configured time zone:

```
Firepower-chassis# show timezone
```

**Step 3** To view the configured date and time:

```
Firepower-chassis# show clock
```

---

### Example

The following example shows how to display the configured time zone and current system date and time:

```
Firepower-chassis# show timezone
Timezone: America/Chicago
Firepower-chassis# show clock
Thu Jun  2 12:40:42 CDT 2016
Firepower-chassis#
```

## Setting the Time Zone

### Procedure

---

**Step 1** Enter system mode:

```
Firepower-chassis# scope system
```

**Step 2** Enter system services mode:

```
Firepower-chassis /system # scope services
```

**Step 3** Set the time zone:

```
Firepower-chassis /system/services # set timezone
```

At this point, you are prompted to enter a number corresponding to your continent, country, and time zone region. Enter the appropriate information at each prompt.

When you have finished specifying the location information, you are prompted to confirm that the correct time zone information is being set. Enter **1** (yes) to confirm, or **2** (no) to cancel the operation.

**Step 4** To view the configured time zone:  
 Firepower-chassis /system/services # **top**  
 Firepower-chassis# **show timezone**

### Example

The following example configures the time zone to the Pacific time zone region, commits the transaction, and displays the configured time zone:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # set timezone
Please identify a location so that time zone rules can be set correctly.
Please select a continent or ocean.
1) Africa                4) Arctic Ocean        7) Australia            10) Pacific Ocean
2) Americas              5) Asia                 8) Europe
3) Antarctica            6) Atlantic Ocean      9) Indian Ocean
#? 2
Please select a country.
 1) Anguilla              28) Haiti
 2) Antigua & Barbuda    29) Honduras
 3) Argentina            30) Jamaica
 4) Aruba                 31) Martinique
 5) Bahamas              32) Mexico
 6) Barbados             33) Montserrat
 7) Belize               34) Nicaragua
 8) Bolivia              35) Panama
 9) Brazil               36) Paraguay
10) Canada               37) Peru
11) Caribbean Netherlands 38) Puerto Rico
12) Cayman Islands      39) St Barthelemy
13) Chile               40) St Kitts & Nevis
14) Colombia            41) St Lucia
15) Costa Rica          42) St Maarten (Dutch part)
16) Cuba                43) St Martin (French part)
17) Curacao             44) St Pierre & Miquelon
18) Dominica            45) St Vincent
19) Dominican Republic 46) Suriname
20) Ecuador             47) Trinidad & Tobago
21) El Salvador         48) Turks & Caicos Is
22) French Guiana       49) United States
23) Greenland           50) Uruguay
24) Grenada             51) Venezuela
25) Guadeloupe          52) Virgin Islands (UK)
26) Guatemala           53) Virgin Islands (US)
27) Guyana
#? 49
Please select one of the following time zone regions.
 1) Eastern Time
 2) Eastern Time - Michigan - most locations
 3) Eastern Time - Kentucky - Louisville area
 4) Eastern Time - Kentucky - Wayne County
 5) Eastern Time - Indiana - most locations
 6) Eastern Time - Indiana - Daviess, Dubois, Knox & Martin Counties
```

```

7) Eastern Time - Indiana - Pulaski County
8) Eastern Time - Indiana - Crawford County
9) Eastern Time - Indiana - Pike County
10) Eastern Time - Indiana - Switzerland County
11) Central Time
12) Central Time - Indiana - Perry County
13) Central Time - Indiana - Starke County
14) Central Time - Michigan - Dickinson, Gogebic, Iron & Menominee Counties
15) Central Time - North Dakota - Oliver County
16) Central Time - North Dakota - Morton County (except Mandan area)
17) Central Time - North Dakota - Mercer County
18) Mountain Time
19) Mountain Time - south Idaho & east Oregon
20) Mountain Standard Time - Arizona (except Navajo)
21) Pacific Time
22) Pacific Standard Time - Annette Island, Alaska
23) Alaska Time
24) Alaska Time - Alaska panhandle
25) Alaska Time - southeast Alaska panhandle
26) Alaska Time - Alaska panhandle neck
27) Alaska Time - west Alaska
28) Aleutian Islands
29) Hawaii
#? 21

```

The following information has been given:

```

United States
Pacific Time

```

```

Therefore timezone 'America/Los_Angeles' will be set.
Local time is now:      Wed Jun 24 07:39:25 PDT 2015.
Universal Time is now:  Wed Jun 24 14:39:25 UTC 2015.
Is the above information OK?
1) Yes
2) No
#? 1
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services # top
Firepower-chassis# show timezone
Timezone: America/Los_Angeles (Pacific Time)
Firepower-chassis#

```

## Setting the Date and Time Using NTP

NTP is used to implement a hierarchical system of servers that provide a precisely synchronized time among network systems. This kind of accuracy is required for time-sensitive operations, such as validating CRLs, which include a precise time stamp. You can configure up to four NTP servers.

**Note**

- FXOS uses NTP version 3.
- If the stratum value of an external NTP server is 13 or greater, FXOS rejects the NTP server and the server will be marked as failed. Thus, synchronization between the application instance and the NTP server is not possible on the FXOS chassis.

If you have set up your own NTP server, you can find its stratum value in the `/etc/ntp.conf` file on the server. If the NTP server has stratum value of 13 or greater you can either change the stratum value in the `ntp.conf` file and restart the server or use a different NTP server (for example: `pool.ntp.org`). Once the NTP server stratum value is configured less than 13, you must remove the NTP server configuration and add it back on FXOS chassis to resync the application instance with NTP server.

**Before you begin**

If you use a hostname for the NTP server, you must configure a DNS server. See [Configuring DNS Servers, on page 65](#).

**Procedure**

- 
- Step 1** Enter system mode:  
Firepower-chassis# **scope system**
- Step 2** Enter system services mode:  
Firepower-chassis /system # **scope services**
- Step 3** Configure the system to use the NTP server with the specified hostname, IPv4, or IPv6 address:  
Firepower-chassis /system/services # **create ntp-server** {hostname | ip-addr | ip6-addr}
- Step 4** (Optional) Configure NTP authentication.  
Only SHA1 is supported for NTP server authentication. Obtain the key ID and value from the NTP server. For example, to generate the SHA1 key on NTP server Version 4.2.8p8 or later with OpenSSL installed, enter the **ntp-keygen -M** command, and then view the key ID and value in the `ntp.keys` file. The key is used to tell both the client and server which value to use when computing the message digest.
- Set the SHA1 Key ID.  
**set ntp-sha1-key-id** *key\_id*
  - Set the SHA1 Key String.  
**set ntp-sha1-key-string**  
You are prompted for the key string.
  - Exit ntp-server mode.  
**exit**
  - Enable NTP authentication.  
**enable ntp-authentication**

**Example:**

```
firepower /system/services/ntp-server* # set ntp-sha1-key-string 11
firepower /system/services/ntp-server* # set ntp-sha1-key-string
NTP SHA-1 key string: 7092334a7809ab9873124c08123df9097097fe72
firepower /system/services/ntp-server* # exit
firepower /system/services* # enable authentication
```

**Step 5** Commit the transaction to the system configuration:

```
Firepower-chassis /system/services # commit-buffer
```

**Step 6** To view the synchronization status for all configured NTP servers:

```
Firepower-chassis /system/services # show ntp-server
```

**Step 7** To view the synchronization status for a specific NTP server:

```
Firepower-chassis /system/services # scope ntp-server {hostname | ip-addr | ip6-addr}
```

```
Firepower-chassis /system/services/ntp-server # show detail
```

**Example**

The following example configures an NTP server with the IP address 192.168.200.101 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create ntp-server 192.168.200.101
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

The following example configures an NTP server with the IPv6 address 4001::6 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create ntp-server 4001::6
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

## Deleting an NTP Server

**Procedure**

**Step 1** Enter system mode:

```
Firepower-chassis# scope system
```

**Step 2** Enter system services mode:

```
Firepower-chassis /system # scope services
```

**Step 3** Delete the NTP server with the specified hostname, IPv4, or IPv6 address:

```
Firepower-chassis /system/services # delete ntp-server {hostname | ip-addr | ip6-addr}
```

**Step 4** Commit the transaction to the system configuration:

```
Firepower-chassis /system/services # commit-buffer
```

### Example

The following example deletes the NTP server with the IP address 192.168.200.101 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # delete ntp-server 192.168.200.101
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

The following example deletes the NTP server with the IPv6 address 4001::6 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # delete ntp-server 4001::6
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

## Setting the Date and Time Manually

This section describes how to set the date and time manually on the chassis. System clock modifications take effect on the chassis immediately. Note that after you manually set the chassis date and time, it could take some time for the change to be reflected in the installed logical device(s).



**Note** If the system clock is currently being synchronized with an NTP server, you will not be able to set the date and time manually.

### Procedure

**Step 1** Enter system mode:

```
Firepower-chassis# scope system
```

**Step 2** Enter system services mode:

```
Firepower-chassis /system # scope services
```

**Step 3** Configure the system clock:

```
Firepower-chassis /system/services # set clock month day year hour min sec
```

For month, use the first three digits of the month. Hours must be entered using the 24-hour format, where 7 pm would be entered as 19.

System clock modifications take effect immediately. You do not need to commit the buffer.

**Example**

The following example configures the system clock:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # set clock jun 24 2015 15 27 00
Firepower-chassis /system/services #
```

## Configuring SSH

The following procedure describes how to enable or disable SSH access to the chassis, how to enable the FXOS chassis as an SSH client, and how to configure the various algorithms used by SSH for encryption, key exchange, and message authentication for both the SSH server and SSH client.

SSH is enabled by default.

**Procedure****Step 1** Enter system mode:

```
Firepower-chassis # scope system
```

**Step 2** Enter system services mode:

```
Firepower-chassis /system # scope services
```

**Step 3** To configure SSH access to the chassis, do one of the following:

- To allow SSH access to the chassis, enter the following command:  

```
Firepower-chassis /system/services # enable ssh-server
```
- To disallow SSH access to the chassis, enter the following command:  

```
Firepower-chassis /system/services # disable ssh-server
```

**Step 4** Configure encryption algorithms for the server:

```
Firepower-chassis /system/services # set ssh-server encrypt-algorithm encrypt_algorithm
```

**Example:**

```
Firepower /system/services # set ssh-server encrypt-algorithm ?
  3des-cbc      3des Cbc
```



```

aes128-cbc  Aes128 Cbc
aes128-ctr  Aes128 Ctr
aes192-cbc  Aes192 Cbc
aes192-ctr  Aes192 Ctr
aes256-cbc  Aes256 Cbc
aes256-ctr  Aes256 Ctr

```

**Example:****Note**

- The following encryption algorithms are not supported in Common Criteria mode:
  - 3des-cbc
  - chacha20-poly1305@openssh.com
- chacha20-poly1305@openssh.com is not supported in FIPS. If FIPS mode is enabled on the FXOS chassis, you cannot use chacha20-poly1305@openssh.com as an encryption algorithm.
- The following encryption algorithms are not enabled by default:

```

aes128-cbc
aes192-cbc
aes256-cbc

```

**Step 5**

Configure the server Diffie-Hellman (DH) key exchange algorithms:

```
Firepower-chassis /system/services # set ssh-server kex-algorithm
```

**Example:**

```

Firepower /system/services # set ssh-server kex-algorithm
diffie-hellman-group1-sha1  Diffie Hellman Group1 Sha1
diffie-hellman-group14-sha1 Diffie Hellman Group14 Sha1

```

The DH key exchange provides a shared secret that cannot be determined by either party alone. The key exchange is combined with a signature and the host key to provide host authentication. This key-exchange method provides explicit server authentication. For more information about using DH key-exchange methods, see RFC 4253.

**Note**

- The following key exchange algorithms are not supported in Common Criteria mode:
  - diffie-hellman-group14-sha256
  - curve25519-sha256
  - curve25519-sha256@libssh.org
- The following key exchange algorithms are not supported in FIPS mode:
  - curve25519-sha256
  - curve25519-sha256@libssh.org

**Step 6**

Set the server mac algorithms:

```
Firepower-chassis /system/services # set ssh-server mac-algorithm
```

**Example:**

```
Firepower /system/services # set ssh-server mac-algorithm
  hmac-shal      Hmac Shal
  hmac-shal-160  Hmac Shal 160
  hmac-shal-96   Hmac Shal 96
  hmac-sha2-256  Hmac Sha2 256
  hmac-sha2-512  Hmac Sha2 512
```

**Step 7** For the server host key, enter the modulus size for the RSA key pairs.

The modulus value (in bits) is in multiples of 8 from 1024 to 2048. The larger the key modulus size you specify, the longer it takes to generate an RSA key pair. We recommend a value of 2048.

```
Firepower-chassis /system/services # set ssh-server host-key rsa modulus_value
```

**Example:**

```
Firepower /system/services # set ssh-server host-key rsa ?
<1024-2048> Enter number of bits (in multiples of 8)
Firepower /system/services # set ssh-server host-key rsa 2048
```

**Step 8** For the server volume rekey limit, set the amount of traffic in KB allowed over the connection before FXOS disconnects from the session:

```
Firepower-chassis /system/services # set ssh-server rekey-limit volume KB_of_Traffic
```

**Example:**

```
Firepower /system/services # set /system/services # set ssh-server rekey-limit volume ?
100-4194303 Max volume limit in KB
```

**Step 9** For the server time rekey limit, set the number of minutes that an SSH session can be idle before FXOS disconnects the session:

```
Firepower-chassis /system/services # set ssh-server rekey-limit time minutes
```

**Example:**

```
Firepower /system/services # set /system/services # set ssh-server rekey-limit time ?
10-1440 Max time limit in Minutes
```

**Step 10** Commit the transaction to the system configuration:

```
Firepower /system/services # commit-buffer
```

**Step 11** Configure strict host keycheck, to control SSH host key checking:

```
Firepower /system/services # ssh-client stricthostkeycheck enable/disable/prompt
```

**Example:**

```
Firepower /system/services # set ssh-client stricthostkeycheck enable
```

- **enable**-The connection is rejected if the host key is not already in the FXOS known hosts file. You must manually add hosts at the FXOS CLI using the **enter ssh-host** command in the system/services scope.
- **prompt**-You are prompted to accept or reject the host key if it is not already stored on the chassis.
- **disable**-(The default) The chassis accepts the host key automatically if it was not stored before.

**Step 12** Configure encryption algorithms for the client:

```
Firepower-chassis /system/services # set ssh-client encrypt-algorithm encrypt_algorithm
```

**Example:**

```
Firepower /system/services # set ssh-client encrypt-algorithm ?
3des-cbc      3des Cbc
aes128-cbc    Aes128 Cbc
aes128-ctr    Aes128 Ctr
aes192-cbc    Aes192 Cbc
aes192-ctr    Aes192 Ctr
aes256-cbc    Aes256 Cbc
aes256-ctr    Aes256 Ctr
```

- Note**
- 3des-cbc is not supported in Common Criteria. If Common Criteria mode is enabled on the FXOS chassis, you cannot use 3des-cbc as an encryption algorithm.
  - The following encryption algorithms are not enabled by default:

```
aes128-cbc
aes192-cbc
aes265-cbc
```

**Step 13** Configure the client Diffie-Hellman (DH) key exchange algorithms:

```
Firepower-chassis /system/services # set ssh-client kex-algorithm
```

**Example:**

```
Firepower /system/services # set ssh-client kex-algorithm
curve25519-sha256          curve25519-sha256
curve25519-sha256_libssh_org curve25519-sha256@libssh.org
diffie-hellman-group14-sha1 diffie-hellman-group14-sha1
diffie-hellman-group14-sha256 diffie-hellman-group14-sha256
ecdh-sha2-nistp256         ecdh-sha2-nistp256
ecdh-sha2-nistp384         ecdh-sha2-nistp384
ecdh-sha2-nistp521         ecdh-sha2-nistp521
```

The DH key exchange provides a shared secret that cannot be determined by either party alone. The key exchange is combined with a signature and the host key to provide host authentication. This key-exchange method provides explicit server authentication. For more information about using DH key-exchange methods, see RFC 4253.

**Step 14** Set the client mac algorithms:

```
Firepower-chassis /system/services # set ssh-client mac-algorithm
```

**Example:**

```
Firepower /system/services # set ssh-client mac-algorithm
hmac-sha1      Hmac Sha1
hmac-sha1-160  Hmac Sha1 160
hmac-sha1-96   Hmac Sha1 96
hmac-sha2-256  Hmac Sha2 256
hmac-sha2-512  Hmac Sha2 512
```

**Step 15** For the client host key, enter the modulus size for the RSA key pairs.

The modulus value (in bits) is in multiples of 8 from 1024 to 2048. The larger the key modulus size you specify, the longer it takes to generate an RSA key pair. We recommend a value of 2048.

```
Firepower-chassis /system/services # set ssh-client host-key rsa modulus_value
```

**Example:**

```
Firepower /system/services # set ssh-client host-key rsa ?
<1024-2048> Enter number of bits (in multiples of 8)
Firepower /system/services # set ssh-client host-key rsa 2048
```

**Step 16** For the client volume rekey limit, set the amount of traffic in KB allowed over the connection before FXOS disconnects from the session:

```
Firepower-chassis /system/services # set ssh-client rekey-limit volume KB_of_Traffic
```

**Example:**

```
Firepower /system/services # set /system/services # set ssh-client rekey-limit volume ?
100-4194303 Max volume limit in KB
```

**Step 17** For the client time rekey limit, set the number of minutes that an SSH session can be idle before FXOS disconnects the session:

```
Firepower-chassis /system/services # set ssh-client rekey-limit time minutes
```

**Example:**

```
Firepower /system/services # set /system/services # set ssh-client rekey-limit time ?
10-1440 Max time limit in Minutes
```

**Step 18** Commit the transaction to the system configuration:

```
Firepower /system/services # commit-buffer
```

---

**Example**

The following example enables SSH access to the chassis and commits the transaction:

```
Firepower# scope system
Firepower /system # scope services
Firepower /system/services # enable ssh-server
Firepower /system/services* # commit-buffer
Firepower /system/services #
```

## Configuring TLS

The Transport Layer Security (TLS) protocol provides privacy and data integrity between two communicating applications. You can use the FXOS CLI to configure the minimum TLS version allowed when the FXOS chassis communicates with external devices. Newer TLS versions provide more secure communications, older TLS versions allow for backward compatibility with older applications.

For example, if the minimum TLS version configured on your FXOS chassis is v1.1, and a client browser is configured to only run v1.0, then the client will not be able to open a connection with the FXOS Chassis Manager via HTTPS. As such, peer applications and LDAP servers must be configured appropriately.

This procedure shows how to configure and view the minimum version of TLS allowed for communication between FXOS chassis and an external device.



**Note**

- As of the FXOS 2.3(1) release, the default minimum TLS version for the FXOS chassis is v1.1.

## Procedure

---

**Step 1** Enter system mode:

```
Firepower-chassis# scope system
```

**Step 2** View the TLS version options available to your system:

```
Firepower-chassis /system # set services tls-ver
```

**Example:**

```
Firepower-chassis /system #
Firepower-chassis /system # set services tls-ver
    v1_0  v1.0
    v1_1  v1.1
    v1_2  v1.2
```

**Step 3** Set the minimum TLS version:

```
Firepower-chassis /system # set services tls-ver version
```

**Example:**

```
Firepower-chassis /system #
Firepower-chassis /system # set services tls-ver v1_2
```

**Step 4** Commit the configuration:

```
Firepower-chassis /system # commit-buffer
```

**Step 5** Show the minimum TLS version configured on your system:

```
Firepower-chassis /system # scope services
```

```
Firepower-chassis /system/services # show
```

**Example:**

```
Firepower-chassis /system/services # show
Name: ssh
    Admin State: Enabled
    Port: 22
Kex Algo: Diffie Hellman Group1 Sha1,Diffie Hellman Group14 Sha1
Mac Algo: Hmac Sha1,Hmac Sha1 96,Hmac Sha2 512,Hmac Sha2 256
Encrypt Algo: 3des Cbc,Aes256 Cbc,Aes128 Cbc,Aes192 Cbc,Aes256 Ctr,Aes128 Ctr,Aes192 Ctr
Auth Algo: Rsa
    Host Key Size: 2048
Volume: None Time: None
Name: telnet
    Admin State: Disabled
    Port: 23
Name: https
    Admin State: Enabled
    Port: 443
    Operational port: 443
    Key Ring: default
    Cipher suite mode: Medium Strength
    Cipher suite: ALL:!ADH:!EXPORT40:!EXPORT56:!LOW:!RC4:!MD5:!IDEA:+HIGH:+MEDIUM:+EXP:+eNULL
    Https authentication type: Cert Auth
    Crl mode: Relaxed
```

```
TLS:
  TLS version: v1.2
```

---

## Configuring Telnet

The following procedure describes how to enable or disable Telnet access to the chassis. Telnet is disabled by default.



**Note** Telnet configuration is currently only available using the CLI.

---

### Procedure

---

- Step 1** Enter system mode:  
Firepower-chassis # **scope system**
- Step 2** Enter system services mode:  
Firepower-chassis /system # **scope services**
- Step 3** To configure Telnet access to the chassis, do one of the following:
- To allow Telnet access to the chassis, enter the following command:  
Firepower-chassis /system/services # **enable telnet-server**
  - To disallow Telnet access to the chassis, enter the following command:  
Firepower-chassis /system/services # **disable telnet-server**
- Step 4** Commit the transaction to the system configuration:  
Firepower /system/services # **commit-buffer**
- 

### Example

The following example enables Telnet and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /services # enable telnet-server
Firepower-chassis /services* # commit-buffer
Firepower-chassis /services #
```

# Configuring SNMP

This section describes how to configure the Simple Network Management Protocol (SNMP) on the chassis. See the following topics for more information:

## About SNMP

The Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a message format for communication between SNMP managers and agents. SNMP provides a standardized framework and a common language used for the monitoring and management of devices in a network.

The SNMP framework consists of three parts:

- An SNMP manager—The system used to control and monitor the activities of network devices using SNMP.
- An SNMP agent—The software component within the chassis that maintains the data for the chassis and reports the data, as needed, to the SNMP manager. The chassis includes the agent and a collection of MIBs. To enable the SNMP agent and create the relationship between the manager and agent, enable and configure SNMP in the Firepower Chassis Manager or the FXOS CLI.
- A managed information base (MIB)—The collection of managed objects on the SNMP agent.

The chassis supports SNMPv1, SNMPv2c and SNMPv3. Both SNMPv1 and SNMPv2c use a community-based form of security. SNMP is defined in the following:

- RFC 3410 (<http://tools.ietf.org/html/rfc3410>)
- RFC 3411 (<http://tools.ietf.org/html/rfc3411>)
- RFC 3412 (<http://tools.ietf.org/html/rfc3412>)
- RFC 3413 (<http://tools.ietf.org/html/rfc3413>)
- RFC 3414 (<http://tools.ietf.org/html/rfc3414>)
- RFC 3415 (<http://tools.ietf.org/html/rfc3415>)
- RFC 3416 (<http://tools.ietf.org/html/rfc3416>)
- RFC 3417 (<http://tools.ietf.org/html/rfc3417>)
- RFC 3418 (<http://tools.ietf.org/html/rfc3418>)
- RFC 3584 (<http://tools.ietf.org/html/rfc3584>)

**Note**

Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.

## SNMP Notifications

A key feature of SNMP is the ability to generate notifications from an SNMP agent. These notifications do not require that requests be sent from the SNMP manager. Notifications can indicate improper user authentication, restarts, the closing of a connection, loss of connection to a neighbor router, or other significant events.

The chassis generates SNMP notifications as either traps or informs. Traps are less reliable than informs because the SNMP manager does not send any acknowledgment when it receives a trap, and the chassis cannot determine if the trap was received. An SNMP manager that receives an inform request acknowledges the message with an SNMP response protocol data unit (PDU). If the chassis does not receive the PDU, it can send the inform request again.

However, informs are available only with SNMPv2c, which is considered insecure, and is not recommended.




---

**Note** The ifindex order on the interface that uses SNMP does not change after you reboot the FXOS. However, the index number on the FXOS disk usage OID changes when you reboot the FXOS.

---

## SNMP Security Levels and Privileges

SNMPv1, SNMPv2c, and SNMPv3 each represent a different security model. The security model combines with the selected security level to determine the security mechanism applied when the SNMP message is processed.

The security level determines the privileges required to view the message associated with an SNMP trap. The privilege level determines whether the message needs to be protected from disclosure or authenticated. The supported security level depends upon which security model is implemented. SNMP security levels support one or more of the following privileges:

- noAuthNoPriv—No authentication or encryption
- authNoPriv—Authentication but no encryption
- authPriv—Authentication and encryption

SNMPv3 provides for both security models and security levels. A security model is an authentication strategy that is set up for a user and the role in which the user resides. A security level is the permitted level of security within a security model. A combination of a security model and a security level determines which security mechanism is employed when handling an SNMP packet.

## Supported Combinations of SNMP Security Models and Levels

The following table identifies what the combinations of security models and levels mean.

*Table 1: SNMP Security Models and Levels*

Model	Level	Authentication	Encryption	What Happens
v1	noAuthNoPriv	Community string	No	Uses a community string match for authentication.



Model	Level	Authentication	Encryption	What Happens
v2c	noAuthNoPriv	Community string	No	Uses a community string match for authentication.
v3	noAuthNoPriv	Username	No	Uses a username match for authentication.  <b>Note</b> While you can configure it, FXOS does not support use of <code>noAuthNoPriv</code> with SNMP version 3.
v3	authNoPriv	HMAC-SHA	No	Provides authentication based on the HMAC Secure Hash Algorithm (SHA).
v3	authPriv	HMAC-SHA	DES	Provides authentication based on the HMAC-SHA algorithm. Provides Data Encryption Standard (DES) 56-bit encryption in addition to authentication based on the Cipher Block Chaining (CBC) DES (DES-56) standard.

## SNMPv3 Security Features

SNMPv3 provides secure access to devices by a combination of authenticating and encrypting frames over the network. SNMPv3 authorizes management operations only by configured users and encrypts SNMP messages. The SNMPv3 User-Based Security Model (USM) refers to SNMP message-level security and offers the following services:

- Message integrity—Ensures that messages have not been altered or destroyed in an unauthorized manner and that data sequences have not been altered to an extent greater than can occur non-maliciously.
- Message origin authentication—Ensures that the claimed identity of the user on whose behalf received data was originated is confirmed.
- Message confidentiality and encryption—Ensures that information is not made available or disclosed to unauthorized individuals, entities, or processes.

## SNMP Support

The chassis provides the following support for SNMP:

### Support for MIBs

The chassis supports read-only access to MIBs.

For information about the specific MIBs available and where you can obtain them, see the [Cisco FXOS MIB Reference Guide](#).

### Authentication Protocol for SNMPv3 Users

The chassis supports the HMAC-SHA-96 (SHA) authentication protocol for SNMPv3 users.

### AES Privacy Protocol for SNMPv3 Users

The chassis uses Advanced Encryption Standard (AES) as one of the privacy protocols for SNMPv3 message encryption and conforms with RFC 3826.

The privacy password, or `priv` option, offers a choice of DES or 128-bit AES encryption for SNMP security encryption. If you enable AES-128 configuration and include a privacy password for an SNMPv3 user, the chassis uses the privacy password to generate a 128-bit AES key. The AES privacy password can have a minimum of eight characters. If the passphrases are specified in clear text, you can specify a maximum of 64 characters.

## Enabling SNMP and Configuring SNMP Properties

### Procedure

- 
- Step 1** Enter scope mode:  
Firepower-chassis# **scope ssa**
- Step 2** Enter show app-instance to identify the slot ID, the application name, and the identifier of the application instance.  
Firepower-chassis# **show app-instance**
- Step 3** Enter monitoring mode:  
Firepower-chassis# **scope monitoring**
- Step 4** (Optional) Enter SNMP admin app instance mode for ASA and FTD devices:  
Firepower-chassis /monitoring # **set snmp adminappinstance slot 1 appname ftd id ftd1 enable yes**  
You must specify the slot number, app name, id, and set the enable to **Yes** or **No**, to specify the target blade app instance.  
**Important** After configuring SNMP unification, wait for 5 minutes before you proceed with SNMP polling.
- Step 5** (Optional) Enter SNMP community mode:  
Firepower-chassis /monitoring # **set snmp community**  
After you enter the **set snmp community** command, you are prompted to enter the SNMP community name.  
When you specify an SNMP community name, you are also automatically enabling SNMP versions 1 and 2c for polling requests from the SNMP remote manager.  
**Note** Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.
- Step 6** Specify the SNMP community name; this community name is used as a SNMP password. The community name can be any alphanumeric string up to 32 characters.  
Firepower-chassis /monitoring # **Enter a snmp community:** *community-name*

There can be only one community name; however, you can use **set snmp community** to overwrite the existing name. To delete an existing community name (also disabling SNMP versions 1 and 2c for polling requests from the SNMP remote manager), enter **set snmp community** but do not type a community string; that is, simply press **Enter** again. After you commit the buffer, **show snmp** output will include the line `Is Community Set: No`.

**Step 7** Specify the system contact person responsible for SNMP. The system contact name can be any alphanumeric string up to 255 characters, such as an email address or name and telephone number.

```
Firepower-chassis /monitoring # set snmp syscontact system-contact-name
```

**Step 8** Specify the location of the host on which the SNMP agent (server) runs. The system location name can be any alphanumeric string up to 512 characters.

```
Firepower-chassis /monitoring # set snmp syslocation system-location-name
```

**Step 9** Commit the transaction to the system configuration:

```
Firepower-chassis /monitoring # commit-buffer
```

### Example

The following example enables SNMP, configures an SNMP community named `SnmpCommSystem2`, configures a system contact named `contactperson`, configures a contact location named `systemlocation`, and commits the transaction:

```
Firepower-chassis# scope ssa
Firepower-chassis# show app-instance
App Name   Identifier Slot ID   Admin State Oper State   Running Version Startup Version
Deploy Type Turbo Mode Profile Name Cluster State   Cluster Role
-----
ftd        ftd1        1           Enabled   Online           7.2.0.82       7.2.0.82
Native     No                               Not Applicable None
Firepower-chassis# scope monitoring

Firepower-chassis /monitoring # set snmp adminappinstance slot 1 appname ftd id ftd1 enable
yes
Firepower-chassis /monitoring* # set snmp community
Enter a snmp community: SnmpCommSystem2
Firepower-chassis /monitoring* # set snmp syscontact contactperson1
Firepower-chassis /monitoring* # set snmp syslocation systemlocation
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

### What to do next

Create SNMP traps and users.

## Creating an SNMP Trap

The following procedure describes how to create SNMP traps.




---

**Note** You can define up to eight SNMP traps.

---

### Procedure

---

**Step 1** Enter monitoring mode:

```
Firepower-chassis# scope monitoring
```

**Step 2** Enable SNMP:

```
Firepower-chassis /monitoring # enable snmp
```

**Step 3** Create an SNMP trap with the specified host name, IPv4 address, or IPv6 address.

```
Firepower-chassis /monitoring # create snmp-trap {hostname | ip-addr | ip6-addr}
```

**Step 4** Specify the SNMP community string, or version 3 user name, to be used with the SNMP trap:

```
Firepower-chassis /monitoring/snmp-trap # set community community-name
```

Specifies the SNMPv1/v2c community string, or the SNMPv3 user name, to permit access to the trap destination. You are queried for the community name after you enter this command. The name can be up to 32 characters with no spaces; the name is not displayed as you type.

**Step 5** Specify the port to be used for the SNMP trap:

```
Firepower-chassis /monitoring/snmp-trap # set port port-num
```

**Step 6** Specify the SNMP version and model used for the trap:

```
Firepower-chassis /monitoring/snmp-trap # set version {v1 | v2c | v3}
```

**Note** Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.

**Step 7** (Optional) Specify the type of trap to send.

```
Firepower-chassis /monitoring/snmp-trap # set notificationtype {traps | informs}
```

This can be:

- **traps** if you select v2c or v3 for the version.
- **informs** if you select v2c for the version.

**Note** An inform notification can be sent only if you select v2c for the version.

**Step 8** (Optional) If you select v3 for the version, specify the privilege associated with the trap:

```
Firepower-chassis /monitoring/snmp-trap # set v3privilege {auth | noauth | priv}
```

This can be:

- **auth**—Authentication but no encryption.

- **noauth**—No authentication or encryption. Note that while you can specify it, FXOS does not support this security level with SNMPv3.
- **priv**—Authentication and encryption.

**Step 9** Commit the transaction to the system configuration:

```
Firepower-chassis /monitoring/snmp-trap # commit-buffer
```

### Example

The following example enables SNMP, creates an SNMP trap using an IPv4 address, specifies that the trap will use the `SnmCommSystem2` community on port 2, sets the version to v3, sets the notification type to traps, sets the v3 privilege to priv, and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # enable snmp
Firepower-chassis /monitoring* # create snmp-trap 192.168.100.112
Firepower-chassis /monitoring/snmp-trap* # set community SnmCommSystem2
Firepower-chassis /monitoring/snmp-trap* # set port 2
Firepower-chassis /monitoring/snmp-trap* # set version v3
Firepower-chassis /monitoring/snmp-trap* # set notificationtype traps
Firepower-chassis /monitoring/snmp-trap* # set v3privilege priv
Firepower-chassis /monitoring/snmp-trap* # commit-buffer
Firepower-chassis /monitoring/snmp-trap #
```

The following example enables SNMP, creates an SNMP trap using an IPv6 address, specifies that the trap will use the `SnmCommSystem3` community on port 2, sets the version to v3, sets the notification type to traps, sets the v3 privilege to priv, and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # enable snmp
Firepower-chassis /monitoring* # create snmp-trap 2001::1
Firepower-chassis /monitoring/snmp-trap* # set community SnmCommSystem3
Firepower-chassis /monitoring/snmp-trap* # set port 2
Firepower-chassis /monitoring/snmp-trap* # set version v3
Firepower-chassis /monitoring/snmp-trap* # set notificationtype traps
Firepower-chassis /monitoring/snmp-trap* # set v3privilege priv
Firepower-chassis /monitoring/snmp-trap* # commit-buffer
Firepower-chassis /monitoring/snmp-trap #
```

## Deleting an SNMP Trap

### Procedure

- Step 1** Enter monitoring mode:
- ```
Firepower-chassis# scope monitoring
```
- Step 2** Delete the SNMP trap with the specified hostname or IP address:

```
Firepower-chassis /monitoring # delete snmp-trap {hostname | ip-addr}
```

**Step 3** Commit the transaction to the system configuration:

```
Firepower-chassis /monitoring # commit-buffer
```

---

### Example

The following example deletes the SNMP trap at IP address 192.168.100.112 and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # delete snmp-trap 192.168.100.112
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

## Creating an SNMPv3 User

### Procedure

---

**Step 1** Enter monitoring mode:

```
Firepower-chassis# scope monitoring
```

**Step 2** Enable SNMP:

```
Firepower-chassis /monitoring # enable snmp
```

**Step 3** Create an SNMPv3 user:

```
Firepower-chassis /monitoring # create snmp-user user-name
```

After you enter the **create snmp-user** command, you are prompted to enter a password.

The FXOS rejects any password that does not meet the following requirements:

- Must contain a minimum of 8 characters and a maximum of 80 characters.
- Must contain only letters, numbers, and the following characters:  

```
~!@#%^&*()_+{ }[]\|:;'"<>./
```
- Must not contain the following symbols: \$ (dollar sign), ? (question mark), or = (equals sign).
- Must contain at least five different characters.
- Must not contain too many consecutively incrementing or decrementing numbers or letters. For example, the string "12345" has four such characters, and the string "ZYXW" has three. If the total number of such characters exceeds a certain limit (typically more than around 4-6 such occurrences), the simplicity check will fail.

**Note** The consecutively incrementing or decrementing character count is not reset when non-incrementing or decrementing characters are used in between. For example, abcd&!21 will fail the password check, but abcd&!25, will not.

- Step 4** Specify the use of SHA authentication:  
 Firepower-chassis /monitoring/snmp-user # **set auth** [sha | sha224 | sha256 | sha358}
- Step 5** Enable or disable the use of AES-128 encryption:  
 Firepower-chassis /monitoring/snmp-user # **set aes-128** {no | yes}  
 By default, AES-128 encryption is disabled.  
 SNMPv3 does not support DES. If you leave AES-128 disabled, no privacy encryption will be done and any configured privacy password will have no effect.
- Note** You cannot poll SNMPv3 FXOS device from certain NMS monitoring applications when SNMPv3 with Authpriv (DES) is enabled. If you upgrade the device from a version that supported using DES previously, you must recreate the users using AES to poll the SNMPv3 FXOS device.
- Step 6** Specify the user password:  
 Firepower-chassis /monitoring/snmp-user # **set password**  
 After you enter the **set password** command, you are prompted to enter and confirm the password.
- Step 7** Commit the transaction to the system configuration:  
 Firepower-chassis /monitoring/snmp-user # **commit-buffer**

---

### Example

The following example enables SNMP, creates an SNMPv3 user named snmp-user14, enables AES-128 encryption, sets the password and privacy password, and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # enable snmp
Firepower-chassis /monitoring* # create snmp-user snmp-user14
Password:
Firepower-chassis /monitoring/snmp-user* # set aes-128 yes
Firepower-chassis /monitoring/snmp-user* # set priv-password
Enter a password:
Confirm the password:
Firepower-chassis /monitoring/snmp-user* # commit-buffer
Firepower-chassis /monitoring/snmp-user #
```

## Deleting an SNMPv3 User

---

### Procedure

- Step 1** Enter monitoring mode:  
 Firepower-chassis# **scope monitoring**
- Step 2** Delete the specified SNMPv3 user:  
 Firepower-chassis /monitoring # **delete snmp-user** *user-name*

- Step 3** Commit the transaction to the system configuration:  
Firepower-chassis /monitoring # **commit-buffer**

### Example

The following example deletes the SNMPv3 user named snmp-user14 and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # delete snmp-user snmp-user14
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

## Viewing Current SNMP Settings

Use the following CLI commands to display current SNMP settings, users and traps.



**Note** The ifIndex order on the interface of FXOS that uses SNMP does not change after you reboot the FXOS.

### Procedure

- Step 1** Enter monitoring mode:  
firepower# **scope monitoring**
- Step 2** Display the current SNMP settings:  
firepower/monitoring # **show snmp**
- ```
Name: snmp
Admin State: Enabled
Port: 161
Is Community Set: Yes
Sys Contact: R_Admin
Sys Location:
```
- Step 3** List the currently defined SNMPv3 users:  
firepower/monitoring # **show snmp-user**
- ```
SNMPv3 User:
Name                               Authentication type
-----
snmp-user1                          Sha
testuser                             Sha
snmp-user2                          Sha
```
- Step 4** List the currently defined SNMP traps:  
firepower/monitoring # **show snmp-trap**



```
SNMP Trap:
```

| SNMP Trap      | Port | Community | Version | V3 Privilege | Notification Type |
|----------------|------|-----------|---------|--------------|-------------------|
| trap1_informs  | 162  | ****      | V2c     | Noauth       | Informs           |
| 192.168.10.100 | 162  | ****      | V3      | Noauth       | Traps             |

### Example

This example shows how to display detailed information about a specific SNMPv3 user:

```
firepower /monitoring # show snmp-user snmp-user1 detail

SNMPv3 User:
  Name: snmp-user1
  Authentication type: Sha
  Password: ****
  Privacy password: ****
  Use AES-128: Yes
firepower /monitoring #
```

## Configuring HTTPS

This section describes how to configure HTTPS on the Firepower 4100/9300 chassis.



**Note** You can change the HTTPS port using Firepower Chassis Manager or the FXOS CLI. All other HTTPS configuration can only be done using the FXOS CLI.

## Certificates, Key Rings, and Trusted Points

HTTPS uses components of the Public Key Infrastructure (PKI) to establish secure communications between two devices, such as a client's browser and the Firepower 4100/9300 chassis.

### Encryption Keys and Key Rings

Each PKI device holds a pair of asymmetric Rivest-Shamir-Adleman (RSA) encryption keys, one kept private and one made public, stored in an internal key ring. A message encrypted with either key can be decrypted with the other key. To send an encrypted message, the sender encrypts the message with the receiver's public key, and the receiver decrypts the message using its own private key. A sender can also prove its ownership of a public key by encrypting (also called 'signing') a known message with its own private key. If a receiver can successfully decrypt the message using the public key in question, the sender's possession of the corresponding private key is proven. Encryption keys can vary in length, with typical lengths from 512 bits to 2048 bits. In general, a longer key is more secure than a shorter key. FXOS provides a default key ring with an initial 2048-bit key pair, and allows you to create additional key rings.

The default key ring certificate must be manually regenerated if the cluster name changes or the certificate expires.

## Certificates

To prepare for secure communications, two devices first exchange their digital certificates. A certificate is a file containing a device's public key along with signed information about the device's identity. To merely support encrypted communications, a device can generate its own key pair and its own self-signed certificate. When a remote user connects to a device that presents a self-signed certificate, the user has no easy method to verify the identity of the device, and the user's browser will initially display an authentication warning. By default, FXOS contains a built-in self-signed certificate containing the public key from the default key ring.

## Trusted Points

To provide stronger authentication for FXOS, you can obtain and install a third-party certificate from a trusted source, or trusted point, that affirms the identity of your device. The third-party certificate is signed by the issuing trusted point, which can be a root certificate authority (CA) or an intermediate CA or trust anchor that is part of a trust chain that leads to a root CA. To obtain a new certificate, you must generate a certificate request through FXOS and submit the request to a trusted point.




---

**Important** The certificate must be in Base64 encoded X.509 (CER) format.

---

## Creating a Key Ring

FXOS supports a maximum of 8 key rings, including the default key ring.

### Procedure

---

- Step 1** Enter security mode:  
Firepower-chassis # **scope security**
  - Step 2** Create and name the key ring:  
Firepower-chassis # **create keyring** *keyring-name*
  - Step 3** Set the SSL key length in bits:  
Firepower-chassis # **set modulus** {**mod1024** | **mod1536** | **mod2048** | **mod512**}
  - Step 4** Commit the transaction:  
Firepower-chassis # **commit-buffer**
- 

### Example

The following example creates a keyring with a key size of 1024 bits:

```
Firepower-chassis# scope security
Firepower-chassis /security # create keyring kr220
Firepower-chassis /security/keyring* # set modulus mod1024
Firepower-chassis /security/keyring* # commit-buffer
Firepower-chassis /security/keyring #
```

### What to do next

Create a certificate request for this key ring.

## Regenerating the Default Key Ring

The default key ring certificate must be manually regenerated if the cluster name changes or the certificate expires.



---

**Note** The default keyring is only used by FCM on FXOS.

---

### Procedure

---

- Step 1** Enter security mode:  
Firepower-chassis # **scope security**
- Step 2** Enter key ring security mode for the default key ring:  
Firepower-chassis /security # **scope keyring default**
- Step 3** Regenerate the default key ring:  
Firepower-chassis /security/keyring # **set regenerate yes**
- Step 4** Commit the transaction:  
Firepower-chassis # **commit-buffer**
- 

### Example

The following example regenerates the default key ring:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope keyring default
Firepower-chassis /security/keyring* # set regenerate yes
Firepower-chassis /security/keyring* # commit-buffer
Firepower-chassis /security/keyring #
```

## Creating a Certificate Request for a Key Ring

### Creating a Certificate Request for a Key Ring with Basic Options

#### Procedure

---

- Step 1** Enter security mode:

- Firepower-chassis # **scope security**
- Step 2** Enter configuration mode for the key ring:  
Firepower-chassis /security # **scope keyring** *keyring-name*
- Step 3** Create a certificate request using the IPv4 or IPv6 address specified, or the name of the fabric interconnect. You are prompted to enter a password for the certificate request.  
Firepower-chassis /security/keyring # **create certreq** {**ip** [*ipv4-addr* | *ipv6-v6*] **subject-name** *name*}
- Step 4** Commit the transaction:  
Firepower-chassis /security/keyring/certreq # **commit-buffer**
- Step 5** Display the certificate request, which you can copy and send to a trust anchor or certificate authority:  
Firepower-chassis /security/keyring # **show certreq**
- 

### Example

The following example creates and displays a certificate request with an IPv4 address for a key ring, with basic options:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope keyring kr220
Firepower-chassis /security/keyring # create certreq ip 192.168.200.123 subject-name sjc04
Certificate request password:
Confirm certificate request password:
Firepower-chassis /security/keyring* # commit-buffer
Firepower-chassis /security/keyring # show certreq
Certificate request subject name: sjc04
Certificate request ip address: 192.168.200.123
Certificate request e-mail name:
Certificate request country name:
State, province or county (full name):
Locality (eg, city):
Organization name (eg, company):
Organization Unit name (eg, section):
Request:
-----BEGIN CERTIFICATE REQUEST-----
MIIBfTCB5wIBADARMQ8wDQYDVQQDEwZzYW1jMDQwZ8wDQYJKoZIhvcNAQEBBQAD
gY0AMIGJAoGBALpKn1t8qMZO4UGqILKFXQQc2c8b/vW2rnRF80PhKbhghLAlYZ1F
JqcYEG5Yl1+vgohLBTd45s0GC8m4RTLJWHo4SwccAUXQ5Zngf45YtXlWsywUWV4
0re/zgTk/WCd56RfOBvWR2Dtztu2pGA14sd761zLxt29K7R8mzj6CAUVAgMBAAGg
LTArBgkqhkiG9w0BCQ4xHjAcMBoGA1UdEQEB/wQQMA6CBnNhbWMwNiECsEiXjAN
BgkqhkiG9w0BAQQFAAOBgQCcsxN0qUHYGFoQw56RwQueLTNPnrndqUwuZHU003Teg
nhsyu4satpyiPqVV9viKZ+spvc6x5PWicTWgHhH8BimOb/0OKuG8kwfIGGsED1Av
TTYvUP+BZ9OFiPbRIA718S+V8ndXrlHejiQGx1DNqoN+odCXPC5kjoXD01ZTL09H
BA==
-----END CERTIFICATE REQUEST-----

Firepower-chassis /security/keyring #
```

**What to do next**

- Copy the text of the certificate request, including the BEGIN and END lines, and save it in a file. Send the file with the certificate request to a trust anchor or certificate authority to obtain a certificate for the key ring.
- Create a trusted point and set the certificate chain for the certificate of trust received from the trust anchor.

**Creating a Certificate Request for a Key Ring with Advanced Options****Procedure**

- 
- Step 1** Enter security mode:  
Firepower-chassis # **scope security**
- Step 2** Enter configuration mode for the key ring:  
Firepower-chassis /security # **scope keyring** *keyring-name*
- Step 3** Create a certificate request:  
Firepower-chassis /security/keyring # **create certreq**
- Step 4** Specify the country code of the country in which the company resides:  
Firepower-chassis /security/keyring/certreq\* # **set country** *country name*
- Step 5** Specify the Domain Name Server (DNS) address associated with the request:  
Firepower-chassis /security/keyring/certreq\* # **set dns** *DNS Name*
- Step 6** Specify the email address associated with the certificate request:  
Firepower-chassis /security/keyring/certreq\* # **set e-mail** *E-mail name*
- Step 7** Specify the IP address of the Firepower 4100/9300 chassis:  
Firepower-chassis /security/keyring/certreq\* # **set ip** {*certificate request ip-address/certificate request ip6-address* }
- Step 8** Specify the city or town in which the company requesting the certificate is headquartered:  
Firepower-chassis /security/keyring/certreq\* # **set locality** *locality name (eg, city)*
- Step 9** Specify the organization requesting the certificate:  
Firepower-chassis /security/keyring/certreq\* # **set org-name** *organization name*
- Step 10** Specify the organizational unit:  
Firepower-chassis /security/keyring/certreq\* # **set org-unit-name** *organizational unit name*
- Step 11** Specify an optional password for the certificate request:  
Firepower-chassis /security/keyring/certreq\* # **set password** *certificate request password*
- Step 12** Specify the state or province in which the company requesting the certificate is headquartered:

- Firepower-chassis /security/keyring/certreq\* # **set state** *state, province or county*
- Step 13** Specify the fully qualified domain name of the Firepower 4100/9300 chassis:  
Firepower-chassis /security/keyring/certreq\* # **set subject-name** *certificate request name*
- Step 14** Commit the transaction:  
Firepower-chassis /security/keyring/certreq # **commit-buffer**
- Step 15** Display the certificate request, which you can copy and send to a trust anchor or certificate authority:  
Firepower-chassis /security/keyring # **show certreq**

### Example



- Note** We recommend not to commit buffer with a "set dns" or "set subject-name" without FQDN for releases earlier than 2.7. If you try to create a certification requirement with a DNS or subject name that is not a FQDN, it will throw an error.

The following example creates and displays a certificate request with an IPv4 address for a key ring, with advanced options:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope keyring kr220
Firepower-chassis /security/keyring # create certreq
Firepower-chassis /security/keyring/certreq* # set "ip 192.168.200.123"
Firepower-chassis /security/keyring/certreq* # set subject-name "sjc04"
Firepower-chassis /security/keyring/certreq* # set country "US"
Firepower-chassis /security/keyring/certreq* # set dns "bg1-samc-15A"
Firepower-chassis /security/keyring/certreq* # set email "test@cisco.com"
Firepower-chassis /security/keyring/certreq* # set locality "new york city"
Firepower-chassis /security/keyring/certreq* # set org-name "Cisco Systems"
Firepower-chassis /security/keyring/certreq* # set org-unit-name "Testing"
Firepower-chassis /security/keyring/certreq* # set state "new york"
Firepower-chassis /security/keyring/certreq* # commit-buffer
Firepower-chassis /security/keyring/certreq # show certreq
Certificate request subject name: sjc04
Certificate request ip address: 192.168.200.123
Certificate request e-mail name: test@cisco.com
Certificate request country name: US
State, province or county (full name): New York
Locality name (eg, city): new york city
Organization name (eg, company): Cisco
Organization Unit name (eg, section): Testing
Request:
-----BEGIN CERTIFICATE REQUEST-----
MIIBfTCB5wIBADARMQ8wDQYDVQQDEwZzYW1jMDQwZ8wDQYJKoZIhvcNAQEBBQAD
gY0AMIGJAoGBALpKn1t8qMZO4UGqILKFXQQc2c8b/vW2rnRF80PhKbhghLAlYZ1F
JqcYEG5Yl1+vgohLBTd45s0GC8m4RTLJWHo4SwccAUXQ5Zngf45YtXlWsyLwUWV4
0re/zgTk/WCd56RfOBvWR2Dtztu2pGA14sd761zLxt29K7R8mzj6CAUVAgMBAAGg
LTArBgkqhkiG9w0BCQ4xHjAcMBoGA1UdEQEB/wQQMA6CBnNhbWwMwNiECSEiXjAN
BgkqhkiG9w0BAQQFAAOBgQCsxN0qUHYGFoQw56RwQueLTNPnrndqUwuZHU003Teg
nhsyu4satpyiPqVV9viKZ+spvc6x5PWIcTWgHhH8BimOb/0OKuG8kwfIGGsEDLAv
TTYvUP+BZ9OFiPbRIA718S+V8ndXr1HejiQGx1DNqoN+odCXPc5kjoXD01zTL09H
BA==
```

```
-----END CERTIFICATE REQUEST-----
```

```
Firepower-chassis /security/keyring/certreq #
```

### What to do next

- Copy the text of the certificate request, including the BEGIN and END lines, and save it in a file. Send the file with the certificate request to a trust anchor or certificate authority to obtain a certificate for the key ring.
- Create a trusted point and set the certificate chain for the certificate of trust received from the trust anchor.

## Creating a Trusted Point

### Procedure

- 
- Step 1** Enter security mode:
- ```
Firepower-chassis # scope security
```
- Step 2** Create a trusted point:
- ```
Firepower-chassis /security # create trustpoint name
```
- Step 3** Specify certificate information for this trusted point:
- ```
Firepower-chassis /security/trustpoint # set certchain [certchain]
```
- If you do not specify certificate information in the command, you are prompted to enter a certificate or a list of trustpoints defining a certification path to the root certificate authority (CA). On the next line following your input, type **ENDOFBUF** to finish.
- Important** The certificate must be in Base64 encoded X.509 (CER) format.
- Step 4** Commit the transaction:
- ```
Firepower-chassis /security/trustpoint # commit-buffer
```
- 

### Example

The following example creates a trusted point and provides a certificate for the trusted point:

```
Firepower-chassis# scope security
Firepower-chassis /security # create trustpoint tPoint10
Firepower-chassis /security/trustpoint* # set certchain
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Trustpoint Certificate Chain:
> -----BEGIN CERTIFICATE-----
> MIIDMCCApmgAwIBAgIBADANBgkqhkiG9w0BAQQFADB0MQswCQYDVQQGEwJVUzEL
> BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGxlIEluYy4xEzARBGNVBAsT
> ClRlc3Qgr3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
> 9w0BCQEQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
```

```

> AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCcYU
> ZgAMivYCsKgb/6CjQtsofvtrmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBNKOND1
> GMbkPayV1Qjbg4MD2dx2+H8EH3LMtdZrgKvPxPTE+bf5wZVNAgMBAAGgJTAjBgkq
> hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
> gYEAG61CaJoJaVMhzC190306Mg51zq1zXcz75+VFj2I6rH9asckCl3mkOVx5gJU
> Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtlvWvfhevskV0j6
> jtcEMyZ+f7+3yh421ido3n04MIGeBgNVHSMEgZYwgZOAFL1njtcEMyZ+f7+3yh42
> 1ido3n04oXikdjB0MQswCQYDVQGEwJVUzELMAkGAlUECBMCQ0ExFDASBgNVBAcT
> C1NhbnRhIENsYXJhMRswGQYDVQQKEsJodW92YSBTeXN0ZW1zIEluYy4xFDASBgNV
> BAsTC0VuZ2luZWVyaW5nMQ8wDQYDVQQDEwZ0ZXN0Q0GCAwDAYDVR0TBAUwAwEB
> /zANBgkqhkiG9w0BAQQFAAOBgQAhWaRwXNR6B4g6Lsnr+fptHv+WVhB5fKqGQqXc
> wR4pYiO4z42/j9Ijenh75tCKMhW51az8copP1EBmOcyuhf5C6vasrenn1ddkkYt4
> PR0vxGc40whuiozBolesmsmjBbedUCwQgdFDWhDIZJwK5+N3x/kfa2EHU6id1avt
> 4YL5Jg==
> -----END CERTIFICATE-----
> ENDOFBUF
Firepower-chassis /security/trustpoint* # commit-buffer
Firepower-chassis /security/trustpoint #

```

### What to do next

Obtain a key ring certificate from the trust anchor or certificate authority and import it into the key ring.

## Importing a Certificate into a Key Ring

### Before you begin

- Configure a trusted point that contains the certificate chain for the key ring certificate.
- Obtain a key ring certificate from a trust anchor or certificate authority.



**Note** If you change the certificate in a key ring that has already been configured on HTTPS, you must restart HTTPS in order for the new certificate to take effect. For more information, see: [Restarting HTTPS, on page 36](#).

### Procedure

- 
- Step 1** Enter security mode:  
Firepower-chassis # **scope security**
- Step 2** Enter configuration mode for the key ring that will receive the certificate:  
Firepower-chassis /security # **scope keyring** *keyring-name*
- Step 3** Specify the trusted point for the trust anchor or certificate authority from which the key ring certificate was obtained:  
Firepower-chassis /security/keyring # **set trustpoint** *name*
- Step 4** Launch a dialog for entering and uploading the key ring certificate:  
Firepower-chassis /security/keyring # **set cert**



At the prompt, paste the certificate text that you received from the trust anchor or certificate authority. On the next line following the certificate, type **ENDOFBUF** to complete the certificate input.

**Important** The certificate must be in Base64 encoded X.509 (CER) format.

**Step 5** Commit the transaction:

```
Firepower-chassis /security/keyring # commit-buffer
```

### Example

The following example specifies the trust point and imports a certificate into a key ring:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope keyring kr220
Firepower-chassis /security/keyring # set trustpoint tPoint10
Firepower-chassis /security/keyring* # set cert
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Keyring certificate:
> -----BEGIN CERTIFICATE-----
> MIIB/zCCAwwCAQAwgZkxCzAJBgNVBAYTA1VITMqswCQYDVQQIEwJDQTEVMBMGA1UE
> BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGxlIEluYy4xEzARBgNVBAst
> ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
> 9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
> AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCCyU
> ZgAMivYCsKgb/6CjQtsofvtrmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgd4VBNKOND1
> GMbkPayV1QjbG4MD2dx2+H8EH3LMtdZrgKvPxPTE+bf5wZVNAGMBAAGgJTAjBgkq
> hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
> gYEAG61CaJoJaVMhzC190306Mg51zq1zXcz75+VFj2I6rH9asckCld3mkOVx5gJU
> Ptt5CVQpNgNLdvbDPSSxretysOhqHmp9+CLv8FDuy1CDYfuaLtv1WvfhevskV0j6
> mK3Ku+YiORnv6DhxrOoqau8r/hyI/L4317IPN1HhOi3oha4=
> -----END CERTIFICATE-----
> ENDOFBUF
Firepower-chassis /security/keyring* # commit-buffer
Firepower-chassis /security/keyring #
```

### What to do next

Configure your HTTPS service with the key ring.

## Configuring HTTPS



### Caution

After you complete the HTTPS configuration, including changing the port and key ring to be used by HTTPS, all current HTTP and HTTPS sessions are closed without warning as soon as you save or commit the transaction.

### Procedure

**Step 1** Enter system mode:

```
Firepower-chassis# scope system
```

- Step 2** Enter system services mode:  
Firepower-chassis /system # **scope services**
- Step 3** Enable the HTTPS service:  
Firepower-chassis /system/services # **enable https**
- Step 4** (Optional) Specify the port to be used for the HTTPS connection:  
Firepower-chassis /system/services # **set https port** *port-num*
- Step 5** (Optional) Specify the name of the key ring you created for HTTPS:  
Firepower-chassis /system/services # **set https keyring** *keyring-name*
- Step 6** (Optional) Specify the level of Cipher Suite security used by the domain:  
Firepower-chassis /system/services # **set https cipher-suite-mode** *cipher-suite-mode*  
*cipher-suite-mode* can be one of the following keywords:
- **high-strength**
  - **medium-strength**
  - **low-strength**
  - **custom**—Allows you to specify a user-defined Cipher Suite specification string.
- Step 7** (Optional) If **cipher-suite-mode** is set to **custom**, specify a custom level of Cipher Suite security for the domain:  
Firepower-chassis /system/services # **set https cipher-suite** *cipher-suite-spec-string*  
*cipher-suite-spec-string* can contain up to 256 characters and must conform to the OpenSSL Cipher Suite specifications. You cannot use any spaces or special characters except ! (exclamation point), + (plus sign), - (hyphen), and : (colon). For details, see [http://httpd.apache.org/docs/2.0/mod/mod\\_ssl.html#ssliphersuite](http://httpd.apache.org/docs/2.0/mod/mod_ssl.html#ssliphersuite).  
For example, the medium strength specification string FXOS uses as the default is:  
**ALL : !ADH : !EXPORT56 : !LOW : RC4+RSA : +HIGH : +MEDIUM : +EXP : +eNULL**
- Note** This option is ignored if **cipher-suite-mode** is set to anything other than **custom**.
- Step 8** (Optional) Enable or disable the certificate revocation list check:  
**set revoke-policy** { *relaxed* | *strict* }
- Step 9** Commit the transaction to the system configuration:  
Firepower-chassis /system/services # **commit-buffer**

---

### Example

The following example enables HTTPS, sets the port number to 443, sets the key ring name to kring7984, sets the Cipher Suite security level to high, and commits the transaction:

```

Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # enable https
Firepower-chassis /system/services* # set https port 443
Warning: When committed, this closes all the web sessions.
Firepower-chassis /system/services* # set https keyring kring7984
Firepower-chassis /system/services* # set https cipher-suite-mode high
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #

```

## Changing the HTTPS Port

The HTTPS service is enabled on port 443 by default. You cannot disable HTTPS, but you can change the port to use for HTTPS connections.

### Procedure

- 
- Step 1** Enter system mode:
- ```
Firepower-chassis # scope system
```
- Step 2** Enter system services mode:
- ```
Firepower-chassis /system # scope services
```
- Step 3** Specify the port to use for HTTPS connections:
- ```
Firepower-chassis /system/services # set https port port-number
```
- Specify an integer between 1 and 65535 for *port-number*. HTTPS is enabled on port 443 by default.
- Step 4** Commit the transaction to the system configuration:
- ```
Firepower /system/services # commit-buffer
```
- After changing the HTTPS port, all current HTTPS sessions are closed. Users will need to log back in to the Firepower Chassis Manager using the new port as follows:
- ```
https://<chassis_mgmt_ip_address>:<chassis_mgmt_port>
```
- where *<chassis\_mgmt\_ip\_address>* is the IP address or host name of the chassis that you entered during initial configuration and *<chassis\_mgmt\_port>* is the HTTPS port you have just configured.
- 

### Example

The following example sets the HTTPS port number to 443 and commits the transaction:

```

Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # set https port 444
Warning: When committed, this closes all the web sessions.
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #

```

## Restarting HTTPS

If you change the certificate in a key ring that has already been configured on HTTPS, you must restart HTTPS in order for the new certificate to take effect. Use the following procedure to reset HTTPS with an updated keyring.

### Procedure

---

- Step 1** Enter system mode:  
Firepower-chassis# **scope system**
- Step 2** Enter system services mode:  
Firepower-chassis /system # **scope services**
- Step 3** Set the HTTPS key ring back to its default value:  
Firepower-chassis /system/services # **set https keyring default**
- Step 4** Commit the transaction to the system configuration:  
Firepower-chassis /system/services # **commit-buffer**
- Step 5** Wait five seconds.
- Step 6** Set HTTPS with the key ring you created:  
Firepower-chassis /system/services # **set https keyring** *keyring-name*
- Step 7** Commit the transaction to the system configuration:  
Firepower-chassis /system/services # **commit-buffer**
- 

## Deleting a Key Ring

### Procedure

---

- Step 1** Enter security mode:  
Firepower-chassis # **scope security**
- Step 2** Delete the named key ring:  
Firepower-chassis /security # **delete keyring** *name*
- Step 3** Commits the transaction:  
Firepower-chassis /security # **commit-buffer**
-

### Example

The following example deletes a key ring:

```
Firepower-chassis# scope security
Firepower-chassis /security # delete keyring key10
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

## Deleting a Trusted Point

### Before you begin

Ensure that the trusted point is not used by a key ring.

### Procedure

---

- Step 1** Enters security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Delete the named trusted point:
- ```
Firepower-chassis /security # delete trustpoint name
```
- Step 3** Commits the transaction:
- ```
Firepower-chassis /security # commit-buffer
```
- 

### Example

The following example deletes a trusted point:

```
Firepower-chassis# scope security
Firepower-chassis /security # delete trustpoint tPoint10
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

## Disabling HTTPS

### Procedure

---

- Step 1** Enter system mode:
- ```
Firepower-chassis# scope system
```
- Step 2** Enter system services mode:

```
Firepower-chassis /system # scope services
```

**Step 3** Disable the HTTPS service:

```
Firepower-chassis /system/services # disable https
```

**Step 4** Commit the transaction to the system configuration:

```
Firepower-chassis /system/services # commit-buffer
```

### Example

The following example disables HTTPS and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # disable https
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

## Configuring AAA

This section describes authentication, authorization, and accounting. See the following topics for more information:

### About AAA

Authentication, Authorization and Accounting (AAA) is a set of services for controlling access to network resources, enforcing policies, assessing usage, and providing the information necessary to bill for services. Authentication identifies the user. Authorization implements policies that determine which resources and services an authenticated user may access. Accounting keeps track of time and data resources that are used for billing and analysis. These processes are considered important for effective network management and security.

#### Authentication

Authentication provides a way to identify each user, typically by having the user enter a valid user name and valid password before access is granted. The AAA server compares the user's provided credentials with user credentials stored in a database. If the credentials are matched, the user is permitted access to the network. If the credentials do not match, authentication fails and network access is denied.

You can configure the Firepower 4100/9300 chassis to authenticate administrative connections to the chassis, including the following sessions:

- HTTPS
- SSH
- Serial console

## Authorization

Authorization is the process of enforcing policies: determining what types of activities, resources, or services each user is permitted to access. After authentication, a user may be authorized for different types of access or activity.

## Accounting

Accounting measures the resources a user consumes during access, which may include the amount of system time or the amount of data that a user has sent or received during a session. Accounting is carried out through the logging of session statistics and usage information, which is used for authorization control, billing, trend analysis, resource utilization, and capacity planning activities.

## Interaction Between Authentication, Authorization, and Accounting

You can use authentication alone, or with authorization and accounting. Authorization always requires a user to be authenticated first. You can use accounting alone, or with authentication and authorization.

## Supported Types of Authentication

FXOS supports the following types of user Authentication:

- **Remote** – The following network AAA services are supported:
  - LDAP
  - RADIUS
  - TACACS+
  - Single Sign-On (SSO)
  
- **Local** – The chassis maintains a local database that you can populate with user profiles. You can use this local database instead of AAA servers to provide user authentication, authorization, and accounting.

## User Roles

FXOS supports local and remote Authorization in the form of user-role assignment. The roles that can be assigned are:

- **Admin** – Complete read-and-write access to the entire system. The default admin account is assigned this role by default and it cannot be changed.
- **AAA Administrator** – Read-and-write access to users, roles, and AAA configuration. Read access to the rest of the system.
- **Operations** – Read-and-write access to NTP configuration, Smart Call Home configuration for Smart Licensing, and system logs, including syslog servers and faults. Read access to the rest of the system.
- **Read-Only** – Read-only access to system configuration with no privileges to modify the system state.

See [User Management](#) for more information about local users and role assignments.

## Setting Up AAA

These steps provide a basic outline for setting up Authentication, Authorization and Accounting (AAA) on a Firepower 4100/9300 appliance.

1. Configure the desired type(s) of user authentication:
  - **Local** – User definitions and local authentication are part of [User Management](#).
  - **Remote** – Configuring remote AAA server access is part of Platform Settings, specifically:
    - [Configuring LDAP Providers, on page 40](#)
    - [Configuring RADIUS Providers, on page 45](#)
    - [Configuring TACACS+ Providers, on page 48](#)
    - [Configuring Single Sign-On \(SSO\), on page 51](#)




---

**Note** If you will be using remote AAA servers, be sure to enable and configure AAA services on the remote servers before configuring remote AAA server access on the chassis.

---

2. Specify the default authentication method—this also is part of [User Management](#).




---

**Note** If Default Authentication and Console Authentication are both set to use the same remote authentication protocol (RADIUS, TACACS+, or LDAP), you cannot change certain aspects of that server's configuration (for example, deleting that server, or changing its order of assignment) without updating these user settings.

---

## Configuring LDAP Providers

### Configuring Properties for LDAP Providers

The properties that you configure in this task are the default settings for all provider connections of this type. If an individual provider includes a setting for any of these properties, the FXOS uses that setting and ignores the default setting.

If you are using Active Directory as your LDAP server, create a user account in the Active Directory server to bind with the FXOS. This account should be given a non-expiring password.

#### Procedure

---

- Step 1** Enter security mode:  
Firepower-chassis# **scope security**
- Step 2** Enter security LDAP mode:  
Firepower-chassis /security # **scope ldap**



- Step 3** Restrict database searches to records that contain the specified attribute:  
Firepower-chassis /security/ldap # **set attribute** *attribute*
- Step 4** Restrict database searches to records that contain the specified distinguished name:  
Firepower-chassis /security/ldap # **set basedn** *distinguished-name*
- Step 5** Restrict database searches to records that contain the specified filter:  
Firepower-chassis /security/ldap # **set filter** *filter*  
where *filter* is the filter attribute to use with your LDAP server, for example *cn=\$userid* or *sAMAccountName=\$userid*. The filter must include *\$userid*.
- Step 6** Set the amount of time the system will wait for a response from the LDAP server before noting the server as down:  
Firepower-chassis /security/ldap # **set timeout** *seconds*
- Step 7** Commit the transaction to the system configuration:  
Firepower-chassis /security/ldap # **commit-buffer**

---

### Example

The following example sets the LDAP attribute to CiscoAvPair, the base distinguished name to "DC=cisco-firepower-aaa3,DC=qalab,DC=com", the filter to sAMAccountName=\$userid, and the timeout interval to 5 seconds, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope ldap
Firepower-chassis /security/ldap # set attribute CiscoAvPair
Firepower-chassis /security/ldap* # set basedn "DC=cisco-firepower-aaa3,DC=qalab,DC=com"
Firepower-chassis /security/ldap* # set filter sAMAccountName=$userid
Firepower-chassis /security/ldap* # set timeout 5
Firepower-chassis /security/ldap* # commit-buffer
Firepower-chassis /security/ldap #
```




---

**Note** User login will fail if the DN for an LDAP user exceeds 255 characters.

---

### What to do next

Create an LDAP provider.

## Creating an LDAP Provider

Follow these steps to define and configure a LDAP provider—that is, a specific remote server providing LDAP-based AAA services for this appliance.




---

**Note** The FXOS supports a maximum of 16 LDAP providers.

---

### Before you begin

If you are using Active Directory as your LDAP server, create a user account in the Active Directory server to bind with the FXOS. This account should be given a non-expiring password.

### Procedure

---

- Step 1** Enter security mode:  
Firepower-chassis# **scope security**
- Step 2** Enter security LDAP mode:  
Firepower-chassis /security # **scope ldap**
- Step 3** Create an LDAP server instance and enter security LDAP server mode:  
Firepower-chassis /security/ldap # **create server** *server-name*  
If SSL is enabled, the *server-name*, typically an IP address or FQDN, must exactly match a Common Name (CN) in the LDAP server's security certificate. Unless an IP address is specified, a DNS server must be configured.
- Step 4** (Optional) Set an LDAP attribute that stores the values for the user roles and locales:  
Firepower-chassis /security/ldap/server # **set attribute** *attr-name*  
This property is always a name-value pair. The system queries the user record for the value that matches this attribute name.  
This value is required unless a default attribute has been set for LDAP providers.
- Step 5** (Optional) Set the specific distinguished name in the LDAP hierarchy where the server should begin a search when a remote user logs in and the system attempts to get the user's DN based on their user name:  
Firepower-chassis /security/ldap/server # **set basedn** *basedn-name*  
The length of the base DN can be a maximum of 255 characters minus the length of CN=username, where username identifies the remote user attempting to access Firepower Chassis Manager or the FXOS CLI using LDAP authentication.  
This value is required unless a default base DN has been set for LDAP providers.
- Step 6** (Optional) Set the distinguished name (DN) for an LDAP database account that has read and search permissions for all objects under the base DN:  
Firepower-chassis /security/ldap/server # **set binddn** *binddn-name*  
The maximum supported string length is 255 ASCII characters.
- Step 7** (Optional) Restrict the LDAP search to user names that match the defined filter.  
Firepower-chassis /security/ldap/server # **set filter** *filter-value*

where *filter-value* is the filter attribute to use with your LDAP server; for example *cn=\$userid* or *sAMAccountName=\$userid*. The filter must include *\$userid*.

This value is required unless a default filter has been set for LDAP providers.

- Step 8** Specify the password for the LDAP database account specified for Bind DN:  
Firepower-chassis /security/ldap/server # **set password**  
To set the password, press **Enter** after typing the **set password** command and enter the key value at the prompt.  
You can enter any standard ASCII characters except for space, § (section sign), ? (question mark), or = (equal sign).
- Step 9** (Optional) Specify the order in which the FXOS uses this provider to authenticate users:  
Firepower-chassis /security/ldap/server # **set order** *order-num*
- Step 10** (Optional) Specify the port used to communicate with the LDAP server. The standard port number is 389.  
Firepower-chassis /security/ldap/server # **set port** *port-num*
- Step 11** Enable or disable the use of encryption when communicating with the LDAP server:  
Firepower-chassis /security/ldap/server # **set ssl** {**yes** | **no**}  
The options are as follows:
- **yes** —Encryption is required. If encryption cannot be negotiated, the connection fails.
  - **no** —Encryption is disabled. Authentication information is sent as clear text.
- LDAP uses STARTTLS. This allows encrypted communication using port 389.
- Step 12** Specify the length of time in seconds the system will spend trying to contact the LDAP database before it times out:  
Firepower-chassis /security/ldap/server # **set timeout** *timeout-num*  
Enter an integer from 1 to 60 seconds, or enter 0 (zero) to use the global timeout value specified for LDAP providers. The default is 30 seconds.
- Step 13** Specify the vendor that is providing the LDAP provider or server details:  
Firepower-chassis /security/ldap/server # **set vendor** {*ms-ad* | *openldap*}  
The options are as follows:
- **ms-ad**—LDAP provider is Microsoft Active Directory.
  - **openldap**—LDAP provider is not Microsoft Active Directory.
- Step 14** (Optional) Enable the certification revocation list check:  
Firepower-chassis /security/ldap/server # **set revoke-policy** {*strict* | *relaxed*}  
**Note** This configuration only takes effect if the SSL connection is enabled.
- Step 15** Commit the transaction to the system configuration:

```
Firepower-chassis /security/ldap/server # commit-buffer
```

---

### Example

The following example creates an LDAP server instance named 10.193.169.246, configures the binddn, password, order, port, SSL settings, vendor attribute, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope ldap
Firepower-chassis /security/ldap* # create server 10.193.169.246
Firepower-chassis /security/ldap/server* # set binddn
"cn=Administrator,cn=Users,DC=cisco-firepower-aaa3,DC=qalab,DC=com"
Firepower-chassis /security/ldap/server* # set password
Enter the password:
Confirm the password:
Firepower-chassis /security/ldap/server* # set order 2
Firepower-chassis /security/ldap/server* # set port 389
Firepower-chassis /security/ldap/server* # set ssl yes
Firepower-chassis /security/ldap/server* # set timeout 30
Firepower-chassis /security/ldap/server* # set vendor ms-ad
Firepower-chassis /security/ldap/server* # commit-buffer
Firepower-chassis /security/ldap/server #
```

The following example creates an LDAP server instance named 12:31:71:1231:45b1:0011:011:900, configures the binddn, password, order, port, SSL settings, vendor attribute, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope ldap
Firepower-chassis /security/ldap* # create server 12:31:71:1231:45b1:0011:011:900
Firepower-chassis /security/ldap/server* # set binddn
"cn=Administrator,cn=Users,DC=cisco-firepower-aaa3,DC=qalab,DC=com"
Firepower-chassis /security/ldap/server* # set password
Enter the password:
Confirm the password:
Firepower-chassis /security/ldap/server* # set order 1
Firepower-chassis /security/ldap/server* # set port 389
Firepower-chassis /security/ldap/server* # set ssl yes
Firepower-chassis /security/ldap/server* # set timeout 45
Firepower-chassis /security/ldap/server* # set vendor ms-ad
Firepower-chassis /security/ldap/server* # commit-buffer
Firepower-chassis /security/ldap/server #
```

## Deleting an LDAP Provider

### Procedure

---

- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security LDAP mode:
- ```
Firepower-chassis /security # scope ldap
```

- Step 3** Delete the specified server:
- ```
Firepower-chassis /security/ldap # delete server serv-name
```
- Step 4** Commit the transaction to the system configuration:
- ```
Firepower-chassis /security/ldap # commit-buffer
```
- 

### Example

The following example deletes the LDAP server called ldap1 and commits the transaction:

```
Firepower-chassis# scope security  
Firepower-chassis /security # scope ldap  
Firepower-chassis /security/ldap # delete server ldap1  
Firepower-chassis /security/ldap* # commit-buffer  
Firepower-chassis /security/ldap #
```

## Configuring RADIUS Providers

### Configuring Properties for RADIUS Providers

The properties that you configure in this task are the default settings for all provider connections of this type. If an individual provider includes a setting for any of these properties, the FXOS uses that setting and ignores this default setting.

### Procedure

---

- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security RADIUS mode:
- ```
Firepower-chassis /security # scope radius
```
- Step 3** (Optional) Specify the number of times to retry contacting the RADIUS server before noting the server as down:
- ```
Firepower-chassis /security/radius # set retries retry-num
```
- Step 4** (Optional) Set the amount of time the system will wait for a response from the RADIUS server before noting the server as down:
- ```
Firepower-chassis /security/radius # set timeout seconds
```
- Step 5** Commit the transaction to the system configuration:
- ```
Firepower-chassis /security/radius # commit-buffer
```
-

### Example

The following example sets the RADIUS retries to 4, sets the timeout interval to 30 seconds, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope radius
Firepower-chassis /security/radius # set retries 4
Firepower-chassis /security/radius* # set timeout 30
Firepower-chassis /security/radius* # commit-buffer
Firepower-chassis /security/radius #
```

### What to do next

Create a RADIUS provider.

## Creating a RADIUS Provider

Follow these steps to define and configure a RADIUS provider—that is, a specific remote server providing RADIUS-based AAA services for this appliance.




---

**Note** The FXOS supports a maximum of 16 RADIUS providers.

---

### Procedure

- 
- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security RADIUS mode:
- ```
Firepower-chassis /security # scope radius
```
- Step 3** Create a RADIUS server instance and enter security RADIUS server mode:
- ```
Firepower-chassis /security/radius # create server server-name
```
- Step 4** (Optional) Specify the port used to communicate with the RADIUS server.
- ```
Firepower-chassis /security/radius/server # set authport authport-num
```
- Step 5** Set the RADIUS server key:
- ```
Firepower-chassis /security/radius/server # set key
```
- To set the key value, press **Enter** after typing the **set key** command and enter the key value at the prompt. You can enter any standard ASCII characters except for space, \$ (section sign), ? (question mark), or = (equal sign).
- Step 6** (Optional) Specify when in the order this server will be tried:
- ```
Firepower-chassis /security/radius/server # set order order-num
```

**Step 7** (Optional) Set the number of times to retry communicating with the RADIUS server before noting the server as down:

```
Firepower-chassis /security/radius/server # set retries retry-num
```

**Step 8** Specify the length of time in seconds the system will wait for a response from the RADIUS server before noting the server as down:

```
Firepower-chassis /security/radius/server # set timeout seconds
```

**Tip** It is recommended that you configure a higher **Timeout** value if you select two-factor authentication for RADIUS providers.

**Step 9** Commit the transaction to the system configuration:

```
Firepower-chassis /security/radius/server # commit-buffer
```

### Example

The following example creates a server instance named `radiuserv7`, sets the authentication port to 5858, sets the key to `radiuskey321`, sets the order to 2, sets the retries to 4, sets the timeout to 30, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope radius
Firepower-chassis /security/radius # create server radiusserv7
Firepower-chassis /security/radius/server* # set authport 5858
Firepower-chassis /security/radius/server* # set key
Enter the key: radiuskey321
Confirm the key: radiuskey321
Firepower-chassis /security/radius/server* # set order 2
Firepower-chassis /security/radius/server* # set retries 4
Firepower-chassis /security/radius/server* # set timeout 30
Firepower-chassis /security/radius/server* # commit-buffer
Firepower-chassis /security/radius/server #
```

## Deleting a RADIUS Provider

### Procedure

**Step 1** Enter security mode:

```
Firepower-chassis# scope security
```

**Step 2** Enter security RADIUS mode:

```
Firepower-chassis /security # scope RADIUS
```

**Step 3** Delete the specified server:

```
Firepower-chassis /security/radius # delete server serv-name
```

**Step 4** Commit the transaction to the system configuration:

```
Firepower-chassis /security/radius # commit-buffer
```

---

### Example

The following example deletes the RADIUS server called radius1 and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope radius
Firepower-chassis /security/radius # delete server radius1
Firepower-chassis /security/radius* # commit-buffer
Firepower-chassis /security/radius #
```

## Configuring TACACS+ Providers

### Configuring Properties for TACACS+ Providers

The properties that you configure in this task are default settings for all provider connections of this type. If an individual provider configuration includes a setting for any of these properties, the FXOS uses that setting and ignores this default setting.




---

**Note** The FXOS chassis does not support command accounting for the Terminal Access Controller Access-Control System Plus (TACACS+) protocol.

---

### Procedure

---

- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security TACACS+ mode:
- ```
Firepower-chassis /security # scope tacacs
```
- Step 3** (Optional) Set the amount of time the system will wait for a response from the TACACS+ server before noting the server as down:
- ```
Firepower-chassis /security/tacacs # set timeout seconds
```
- Enter an integer from 1 to 60 seconds. The default value is 5 seconds.
- Step 4** Commit the transaction to the system configuration:
- ```
Firepower-chassis /security/tacacs # commit-buffer
```
- 

### Example

The following example sets the TACACS+ timeout interval to 45 seconds and commits the transaction:



```

Firepower-chassis# scope security
Firepower-chassis /security # scope tacacs
Firepower-chassis /security/tacacs # set timeout 45
Firepower-chassis /security/tacacs* # commit-buffer
Firepower-chassis /security/tacacs #

```

### What to do next

Create a TACACS+ provider.

## Creating a TACACS+ Provider

Follow these steps to define and configure a TACACS+ provider—that is, a specific remote server providing TACACS-based AAA services for this appliance.




---

**Note** The FXOS supports a maximum of 16 TACACS+ providers.

---

### Procedure

- 
- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security TACACS+ mode:
- ```
Firepower-chassis /security # scope tacacs
```
- Step 3** Create a TACACS+ server instance and enter security TACACS+ server mode:
- ```
Firepower-chassis /security/tacacs # create server server-name
```
- Step 4** Specify the TACACS+ server key:
- ```
Firepower-chassis /security/tacacs/server # set key
```
- To set the key value, press **Enter** after typing the **set key** command and enter the key value at the prompt. You can enter any standard ASCII characters except for space, § (section sign), ? (question mark), or = (equal sign).
- Step 5** (Optional) Specify when in the order this server will be tried:
- ```
Firepower-chassis /security/tacacs/server # set order order-num
```
- Step 6** Specify the time interval that the system will wait for a response from the TACACS+ server before noting the server as down:
- ```
Firepower-chassis /security/tacacs/server # set timeout seconds
```
- Tip** It is recommended that you configure a higher timeout value if you select two-factor authentication for TACACS+ providers.
- Step 7** (Optional) Specify the port used to communicate with the TACACS+ server:
- ```
Firepower-chassis /security/tacacs/server # set port port-num
```

- Step 8** Commit the transaction to the system configuration:  
Firepower-chassis /security/tacacs/server # **commit-buffer**

---

### Example

The following example creates a server instance named tacacsserv680, sets the key to tacacskey321, sets the order to 4, sets the authentication port to 5859, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope tacacs
Firepower-chassis /security/tacacs # create server tacacsserv680
Firepower-chassis /security/tacacs/server* # set key
Enter the key: tacacskey321
Confirm the key: tacacskey321
Firepower-chassis /security/tacacs/server* # set order 4
Firepower-chassis /security/tacacs/server* # set port 5859
Firepower-chassis /security/tacacs/server* # commit-buffer
Firepower-chassis /security/tacacs/server #
```

## Deleting a TACACS+ Provider

---

### Procedure

- Step 1** Enter security mode:  
Firepower-chassis# **scope security**
- Step 2** Enter security TACACS+ mode:  
Firepower-chassis /security # **scope tacacs**
- Step 3** Delete the specified server:  
Firepower-chassis /security/tacacs # **delete server** *serv-name*
- Step 4** Commit the transaction to the system configuration:  
Firepower-chassis /security/tacacs # **commit-buffer**

---

### Example

The following example deletes the TACACS+ server called tacacs1 and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope tacacs
Firepower-chassis /security/tacacs # delete server tacacs1
Firepower-chassis /security/tacacs* # commit-buffer
Firepower-chassis /security/tacacs #
```

## Configuring Single Sign-On (SSO)

A Firepower Chassis Manager configured for SSO presents a link for single sign-on on the Login page. Users configured for SSO access click on this link and are redirected to the IdP for authentication and authorization, rather than supplying a username and password on the Firepower Chassis Manager Login page. Once successfully authenticated by the IdP, SSO users are redirected back to the Firepower Chassis Manager web interface and logged in. All the communication between the Firepower Chassis Manager and the IdP to accomplish this takes place using the browser as an intermediary; as a result, the Firepower Chassis Manager does not require a network connection to directly access the identity provider.

The Firepower Chassis Manager supports SSO using any SSO provider conforming to the Security Assertion Markup Language (SAML) 2.0 open standard for authentication and authorization.

The Firepower Chassis Manager web interface offers configuration options for the following SSO providers:

- Okta
- OneLogin
- Azure
- PingID's PingOne for Customers cloud solution
- Cisco SSO
- Other

### Configure Single Sign-On with Okta

Use these instructions at the Okta Classic UI Admin Console to create a Firepower Chassis Manager service provider application within Okta and assign users to that application. You should be familiar with SAML SSO concepts and the Okta admin console. This documentation does not describe all the Okta functions you need to establish a fully functional SSO org; for instance, to create users, or to import user definitions from another user management application, see the Okta documentation.

#### Before you begin

- Familiarize yourself with the SSO federation and its users and groups.
- Create user accounts in your Okta org if necessary.

#### Procedure

---

**Step 1** From the Okta Classic UI Admin Console, create a service provider application for the Firepower Chassis Manager. Configure the Firepower Chassis Manager application with the following selections:

- Select `web` for the **Platform**.
- Select `SAML 2.0` for the **Sign on method**.
- Provide a **Single sign on URL**.

This is the Firepower Chassis Manager URL to which the browser sends information on behalf of the IdP.

Append the string `saml/acs` to the Firepower Chassis Manager login URL. For example:  
`https://ExampleFCM/saml/acs.`

- Enable **Use this for Recipient URL and Destination URL**.

- Enter an **Audience URI (SP Entity ID)**.

Append the string `/saml/metadata` to the login URL. For example: `https://ExampleFCM/saml/metadata.`

- For **Name ID Format**, choose `Unspecified`.

**Step 2** Add a new attribute to the default Okta user profile:

- For **Data type** choose `string`.
- For **Variable name**, add string `role`.

**Step 3** Assign Okta user to Firepower Chassis Manager.

**Step 4** For user assigned to the Firepower Chassis Manager service provider application using this profile, assign a value to the user role attribute you have just created. You can select **admin read-only** or **read-only** based on your requirements.

**Note** If attribute role is not specified, Firepower Chassis Manager will take default role as read-only and the user will not be able to perform any edit action in Firepower Chassis Manager.

**Step 5** Export the Identity Provider Metadata from Okta to your local system and take a note of the following values from the XML file:

- **Identity Provider Single Sign-On (SSO) URL:** Given as `SingleSignOnService Location` in Identity Provider Metadata XML file.
- **Identity Provider Issuer:** Given as `Entity ID` in Identity Provider Metadata XML file.
- **X.509 Certificate:** Given as `x509Certificate` in Identity Provider Metadata XML file.

**Note** These values are necessary in order to configure the Okta IDP provider in the Firepower Chassis Manager.

---

### What to do next

- Enable Single Sign-On on Firepower Chassis Manager, see [Enable/Disable Single Sign-On on Firepower Chassis Manager, on page 59](#).
- Configure SSO Provider in Firepower Chassis Manager, see [Configure SSO Provider on the Firepower Chassis Manager, on page 60](#).

## Configure Single Sign-On with OneLogin

Use these instructions at the OneLogin Admin Portal to create a Firepower Chassis Manager service provider application within OneLogin and assign users to that application. You should be familiar with SAML SSO concepts and the OneLogin Admin Portal. This documentation does not describe all the OneLogin functions you need to establish a fully functional SSO org; for instance, to create users, or to import user definitions from another user management application, see the OneLogin documentation.

### Before you begin

- Familiarize yourself with the SSO federation and its users and groups.
- Create user accounts in your OneLogin org if necessary.

### Procedure

- 
- Step 1** Create the Firepower Chassis Manager service provider application using the **SAML Test Connector (Advanced)** as its basis.
- Step 2** Configure the application with the following settings:
- For the **Audience (Entity ID)**, append the string `/saml/metadata` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/metadata`.
  - For **Recipient**, append the string `/saml/acs` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/acs`.
  - For **ACS (Consumer) URL Validator**, enter an expression that OneLogin uses to confirm it is using the correct Firepower Chassis Manager URL. You can create a simple validator by using the ACS URL and altering it as follows:
    - Append a `^` to the beginning of the ACS URL.
    - Append a `$` to the end of the ACS URL.
    - Insert a `\` preceding every `/` and `?` within the ACS URL.
- For example, for the ACS URL `https://ExampleFCM/saml/acs`, an appropriate URL validator would be `^https://ExampleFCM\saml\acs$`.
- For **ACS (Consumer) URL**, append the string `/saml/acs` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/acs`.
  - For **Login URL**, append the string `/saml/acs` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/acs`.
  - For the **SAML Initiator**, choose `Service Provider`.
- Step 3** Assign OneLogin user to Firepower Chassis Manager.
- Step 4** For user assigned to the Firepower Chassis Manager service provider application using this profile, assign a value to the user role attribute you have just created.
- Note** If attribute role is not specified, Firepower Chassis Manager will take default role as read-only and the user will not be able to perform any edit action in Firepower Chassis Manager.
- Step 5** Export the SAML XML metadata from OneLogin to your local system and take a note of the following values from the XML file:
- **Identity Provider Single Sign-On (SSO) URL:** Given as `SAML 2.0 Endpoint (HTTP)` in SAML XML metadata file.
  - **Identity Provider Issuer:** Given as `Issuer URL` in SAML XML metadata file.

- **X.509 Certificate:** Given as `x509Certificate` in SAML XML metadata file.

**Note** These values are necessary in order to configure the OneLogin IDP provider in the Firepower Chassis Manager.

---

### What to do next

- Enable Single Sign-On on Firepower Chassis Manager, see [Enable/Disable Single Sign-On on Firepower Chassis Manager, on page 59](#).
- Configure SSO Provider in Firepower Chassis Manager, see [Configure SSO Provider on the Firepower Chassis Manager, on page 60](#).

## Configure Single Sign-On with Azure AD

Use the Azure Active Directory Portal to create a Firepower Chassis Manager service provider application within your Azure Active Directory tenant and establish basic configuration settings.

### Before you begin

- Familiarize yourself with the Azure tenant and its users and groups.
- Create user accounts in your Azure tenant org if necessary.

### Procedure

---

- Step 1** Create the Firepower Chassis Manager service provider application using the Azure AD SAML Toolkit as its basis.
- Step 2** Configure the application with the following settings for **Basic SAML Configuration**:
- For the **Identifier (Entity ID)** append the string `/saml/metadata` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/metadata`.
  - For the **Reply URL (Assertion Consumer Service URL)** append the string `/saml/acs` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/acs`.
  - For the **Sign on URL** append the string `/saml/acs` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/acs`.
- Step 3** Edit the **Unique User Identifier Name (Name ID)** claim for the application to force the username for sign-on at the Firepower Chassis Manager to be the email address associated with the user account:
- For **Source** choose `Attribute`.
  - For **Source attribute**: Choose `user.mail`.
- Step 4** Generate a certificate to secure SSO on the Firepower Chassis Manager. Use the following options for the certificate:
- Select Sign SAML Response and Assertion for the Signing Option.

- Select SHA-256 for the Signing Algorithm.

**Step 5** Download the Base-64 version of the certificate to your local computer; you need add the contents as **X.509 Certificate** when you configure Azure SSO at the Firepower Chassis Manager web interface.

**Step 6** In the SAML-based Sign-on information for the application, note the following values:

- **Login URL:**
- **Azure AD Identifier**

You will need these values when you configure Azure SSO at the Firepower Chassis Manager web interface.

**Note** The identity provider's single sign-on URL is the Login URL, and the identity provider's issuer is the Azure AD Identifier.

**Step 7** Assign Azure user to Firepower Chassis Manager.

**Step 8** For user assigned to the Firepower Chassis Manager service provider application using this profile, assign a value to the user role attribute you have just created.

**Note** If attribute role is not specified, Firepower Chassis Manager will take default role as read-only and the user will not be able to perform any edit action in Firepower Chassis Manager.

---

### What to do next

- Enable Single Sign-On on Firepower Chassis Manager, see [Enable/Disable Single Sign-On on Firepower Chassis Manager, on page 59](#).
- Configure SSO Provider in Firepower Chassis Manager, see [Configure SSO Provider on the Firepower Chassis Manager, on page 60](#).

## Configure Single Sign-On with PingID

Use the PingOne for Customers Administrator Console to create a Firepower Chassis Manager service provider application within your PingOne for Customers environment and establish basic configuration settings. This documentation does not describe all the PingOne for Customers functions you need to establish a fully functional SSO environment; for instance, to create users see the PingOne for Customers documentation.

### Before you begin

- Familiarize yourself with your PingOne for Customers environment and its users.
- Create additional users if necessary.

### Procedure

---

**Step 1** Use the PingOne for Customer Administrator Console to create the application in your environment using these settings:

- Choose the **Web App** application type.

- Choose the **SAML** connection type.

**Step 2** Configure the application with the following settings for the SAML Connection:

- For the **ACS URL**, append the string `/sam/acs` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/acs`.
- For the **Signing Certificate**, choose Sign Assertion & Response.
- For the **Signing Algorithm** choose RSA\_SHA256.
- For the **Entity ID**, append the string `/saml/metadata` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/metadata`.
- For the **SLO Binding** select HTTP POST.
- For the **Assertion Validity Duration** enter 300.

**Step 3** In the SAMLConnection information for the application, note the following values:

- **Single Sign-On Service**
- **Issuer ID**

You will need these values when you configure SSO using PingID's PingOne for Customers product at the Firepower Chassis Manager web interface.

**Step 4** For **SAML ATTRIBUTES**, make the following selections for a single required attribute:

- **PINGONE USER ATTRIBUTE:** `Email Address`
- **APPLICATION ATTRIBUTE:** `saml_subject`

**Step 5** Download the signing certificate in X509 PEM (`.crt`) format and save it to your local computer.

You will need these cert when you configure SSO using PingID's PingOne for Customers product at the Firepower Chassis Manager web interface.

**Step 6** Enable the application.

---

### What to do next

- Enable Single Sign-On on Firepower Chassis Manager, see [Enable/Disable Single Sign-On on Firepower Chassis Manager, on page 59](#).
- Configure SSO Provider in Firepower Chassis Manager, see [Configure SSO Provider on the Firepower Chassis Manager, on page 60](#).

## Configure Single Sign-On with Cisco SSO

Duo Single Sign-On is a cloud-hosted single sign-on solution (SSO) solution which can act as a SAML 2.0 identity provider that secures access to Firepower Chassis Manager with your existing directory credentials. Duo Single Sign-On allows you to use either Active Directory domains and SAML Identity Provider as a first-factor authentication source. For SSO, Duo uses SAML authentication from Firepower Chassis Manager



to an identity provider. You can configure your SAML 2.0 identity provider and Firepower Chassis Manager on Duo using the below steps.

For configuring SSO using Active Directory, see [Single Sign-On using Active Directory](#).

### Before you begin

- Familiarize yourself with the SSO federation and its users and groups.
- A Duo Admin account with the **Owner** role to enable the feature.
- Active Directory or a SAML identity provider that can be used as your primary authentication source for Duo Single Sign-On.

### Procedure

---

- Step 1** On the "Single Sign-On Configuration" page scroll down to **Configure your SAML Identity Provider**. This is the Duo Single Sign-On metadata information you need to provide to your SAML identity provider application to configure Duo Single Sign-On as a service provider.
- Step 2** In the "SAML Certificates" section of the properties page of your SAML provider application, click **Download** next to **Certificate (Base64)**. You will need this certificate file.
- Step 3** Configure the Firepower Chassis Manager on the Service Provider page with the following settings:
- For the **Entity ID**, append the string `/saml/metadata` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/metadata`.
  - For **Assertion Consumer Service (ACS) URL**, append the string `/saml/acs` to the login URL. For example Firepower Chassis Manager: `https://ExampleFCM/saml/acs`.
  - For **Service Provider Login URL**, append the string `/saml/acs` to the Firepower Chassis Manager login URL. For example: `https://ExampleFCM/saml/acs`.
  - For **Certificate**, upload the certificate downloaded from your SAML service provider application.
- Step 4** Click on **Download Certificate**. This is the X.509 Certificate that you need to add while configuring Cisco SSO on Firepower Chassis Manager.
- For **Identity Provider Single Sign-On (SSO) URL** and **Identity Provider Issuer**, use the details from Duo Single Sign-On metadata information page.
- 

### What to do next

- Enable Single Sign-On on Firepower Chassis Manager, see [Enable/Disable Single Sign-On on Firepower Chassis Manager, on page 59](#).
- Configure SSO Provider in Firepower Chassis Manager, see [Configure SSO Provider on the Firepower Chassis Manager, on page 60](#).

## Configure Single Sign-On with Any SAML 2.0-Compliant SSO Provider

Generally SSO providers require that you configure a service provider application at the IdP for each federated application. All IdPs that support SAML 2.0 SSO need the same configuration information for service provider applications, but some IdP's automatically generate some configuration settings for you, while others require that you configure all settings yourself.

### Before you begin

- Familiarize yourself with the SSO federation and its users and groups.
- Confirm your IdP account has the necessary permissions to perform this task.
- Create user accounts and/or groups in your SSO federation if necessary.

### Procedure

---

- Step 1** Create a new service provider application at the IdP.
- Step 2** Configure values required by the IdP. Be sure to include the fields listed below, required to support SAML 2.0 SSO functionality with the Firepower Chassis Manager. (Because different SSO service providers use different terminology for SAML concepts, this list provides alternate names for these fields to help you find the right settings in the IdP application.):
- Service Provider Entity ID, Service Provider Identifier, Audience URI: A globally unique name for the service provider (the Firepower Chassis Manager), formatted as a URL. To create this, append the string `/saml/metadata` to the Firepower Chassis Manager login URL, such as `https://ExampleFCC/saml/metadata`.
  - Single Sign on URL, Recipient URL, Assertion Consumer Service URL: The service provider (Firepower Chassis Manager) address to which the browser sends information on behalf of the IdP. To create this, append the string `saml/acs` to the Firepower Chassis Manager login URL, such as `https://ExampleFCM/saml/acs`.
  - X.509 Certificate: Certificate to secure communications between the Firepower Chassis Manager and the IdP. Some IdP's may automatically generate the certificate, and some may require that you explicitly generate it using the IDP interface.
- Step 3** (Optional if you are assigning groups to the application) Assign individual users to the Firepower Chassis Manager application.
- Step 4** At the IdP, create or designate an attribute to be sent to the Firepower Chassis Manager to contain role mapping information for each user sign-in. This may be a user attribute or a different attribute that obtains its value from a source such as user or group definitions maintained by the IdP or a third party user management application.
- Step 5** (Optional) Some IdP's provide the ability to generate a SAML XML metadata file containing the information you have configured in this task formatted to comply with SAML 2.0 standards. You can take a note of the required values and use them while configuring the IDP on the Firepower Chassis Manager
-

**What to do next**

- Enable Single Sign-On on Firepower Chassis Manager, see [Enable/Disable Single Sign-On on Firepower Chassis Manager, on page 59](#).
- Configure SSO Provider in Firepower Chassis Manager, see [Configure SSO Provider on the Firepower Chassis Manager, on page 60](#).

**Enable/Disable Single Sign-On on Firepower Chassis Manager****Before you begin**

- At the SAML SSO management application, configure a service provider application for the Firepower Chassis Manager and assign users or groups to the service provider application:
  - To configure a Firepower Chassis Manager service provider application for Okta, see [Configure Single Sign-On with Okta, on page 51](#).
  - To configure a Firepower Chassis Manager service provider application for OneLogin, see [Configure Single Sign-On with OneLogin, on page 52](#).
  - To configure a Firepower Chassis Manager service provider application for Azure, see [Configure Single Sign-On with Azure AD, on page 54](#).
  - To configure a Firepower Chassis Manager service provider application for PingID's PingOne for Customers cloud solution, see [Configure Single Sign-On with PingID, on page 55](#).
  - To configure a Firepower Chassis Manager service provider application for any SAML 2.0-compliant SSO provider, see [Configure Single Sign-On with Any SAML 2.0-Compliant SSO Provider, on page 58](#).

**Procedure**

- 
- Step 1** Enter security mode:  
Firepower-chassis# **scope security**
- Step 2** Enter security SSO mode:  
Firepower-chassis /security # **scope sso**
- Step 3** (Optional) To enable Single Sign-On (SSO) access to the chassis:  
Firepower-chassis /security/sso # **set sso-enabled yes**
- Step 4** (Optional) To disable Single Sign-On (SSO) access to the chassis:  
Firepower-chassis /security/sso # **set sso-enabled no**
- Step 5** Commit the transaction to the system configuration:  
Firepower-chassis /security/sso # **commit-buffer**
-

**Example**

The following example disables the Single Sign-On (SSO) access to the chassis:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope sso
Firepower-chassis /security/sso # set sso-enabled no
Firepower-chassis /security/sso # show
SSO:
  SSO Enabled
  -----
  No
```

**What to do next**

Configure an SSO provider.

**Configure SSO Provider on the Firepower Chassis Manager****Before you begin**

- Create a Firepower Chassis Manager service provider application at the SSO service provider and retrieve the values for configuring the service provider in Firepower Chassis Manager.
- Enable single sign-on; see [Enable/Disable Single Sign-On on Firepower Chassis Manager, on page 59](#).

**Procedure**


---

**Step 1** Create the server object:

```
Firepower-chassis/security/sso # create server serv-name
```

**Step 2** Set Identity Provider Single Sign-On URL:

```
Firepower-chassis /security/sso/server* # set identity-provider-sso-url service provider url
```

**Step 3** Set Identity Provider Issuer:

```
Firepower-chassis /security/sso/server* # set identity-provider-issuer issuer url
```

**Step 4** Set X.509 Certificate:

```
Firepower-chassis /security/sso/server* # set identity-provider-certificate identity provider certificate
```

**Step 5** Commit the transaction to the system configuration:

```
Firepower-chassis /security/sso/server* # commit-buffer
```

---

**Example**

The following example shows how to configure Single Sign-On with Okta:

```

Firepower-chassis /security/sso # create server okta
Firepower-chassis /security/sso/server* # set identity-provider-issuer
http://www.okta.com/exk7izkmfcxyzxTdWs775d7
Firepower-chassis /security/sso/server* # set identity-provider-sso-url
https://dev-5060426.okta.com/app/dev-5060426_fcmtb11_1/exk7izkmfcxTxyzdWs775d7/sso/saml
Firepower-chassis /security/sso/server* # set identity-provider-certificate
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
cert:
>MIIDpjCCAo6gAwIBAgIGAYTmk32oMA0GCSqGSIb3DQEBCwUAMIGTMQswCQYDVQQGEwJVUzETMBEG
A1UECAwKQ2FsxyzaWZvcn5pYTEWMBQGA1UEBwwNU2FuIEZy
YW5jaXNjbzENMAsGA1UECgwET2t0YTEU
MBIGA1UECwwLU1NPUHJvdmlkZXIxFDASBgNVBAMMC2Rldi01MDYwNDI2M>RwwGgYJKoZIhvcNAQkB
FglpbmZvQG9rdGEuY29tMB4XDTIyMTIwNjA4MzQzNloXDT
XqtsMn3ZLHS1WFCa6x jISz82ITkPS44R0PeVBCh5DTLtkkSv+1HXo=>>ENDOFBUF

Firepower-chassis /security/sso/server* # commit-buffer

```

## Deleting an SSO Provider

### Procedure

- 
- |               |   |
|---------------|---|
| <b>Step 1</b> | Enter security mode:<br>Firepower-chassis# <b>scope security</b>  |
| <b>Step 2</b> | Enter security LDAP mode:<br>Firepower-chassis /security # <b>scope sso</b>                                   |
| <b>Step 3</b> | Delete the specified server:<br>Firepower-chassis /security/sso # <b>delete server</b> <i>serv-name</i>       |
| <b>Step 4</b> | Commit the transaction to the system configuration:<br>Firepower-chassis /security/sso # <b>commit-buffer</b> |
- 

### Example

The following example deletes the SSO provider server called okta and commits the transaction:

```

Firepower-chassis# scope security
Firepower-chassis /security # scope sso
Firepower-chassis /security/sso # delete server okta
Firepower-chassis /security/sso* # commit-buffer
Firepower-chassis /security/sso #

```

## Verifying Remote AAA Server Configurations

The following sections describe how to use the FXOS CLI to determine the current configuration for the various remote AAA servers.

### Determining Current FXOS Authentication Configuration

The following example shows you how to use the **show authentication** command to determine the current FXOS authentication settings. In this example, LDAP is the default mode of authentication.

```
firepower# scope security
firepower /security # show authentication
Console authentication: Local
Operational Console authentication: Local
Default authentication: Ldap
Operational Default authentication: Ldap
Role Policy For Remote Users: Assign Default Role
firepower /security #
```

### Determining Current LDAP Configuration

The following example shows you how to use the **show server detail** command in ldap mode to determine the current LDAP configuration settings.

```
firepower# scope security
firepower /security # scope ldap
firepower /security/ldap # show server detail

LDAP server:
  Hostname, FQDN or IP address: 10.48.53.132
  Descr:
  Order: 1
  DN to search and read: CN=cisco,CN=Users,DC=fxosldapuser,DC=lab
  Password:
  Port: 389
  SSL: No
  Key:
  Cipher Suite Mode: Medium Strength
  Cipher Suite:
ALL:!DH:!RS:!S:!C:!G:A:!DH:!S:!C:!G:A:!DH:!S:!C:!G:A:!DH:!S:!C:!G:A:!DH:!S:!C:!G:A:!DH:!S:!C:!G:A:!DH:!S:!C:!G:A:!DH:!S:!C:!G:A:!DH:!S:!C:!G:A
  CRL: Relaxed
  Basedn: CN=Users,DC=fxosldapuser,DC=lab
  User profile attribute: CiscoAVPair
  Filter: cn=$userid
  Timeout: 30
  Ldap Vendor: MS AD
firepower /security/ldap #
```

### Determining Current RADIUS Configuration

The following example shows you how to use the **show server detail** command in radius mode to determine the current RADIUS configuration settings.

```
firepower# scope security
firepower /security # scope radius
firepower /security/radius # show server detail

RADIUS server:
  Hostname, FQDN or IP address: 10.48.17.199
  Descr:
  Order: 1
  Auth Port: 1812
  Key: ****
  Timeout: 5
  Retries: 1
```

```
firepower /security/radius #
```

### Determining Current TACACS+ Configuration

The following example shows you how to use the **show server detail** command in tacacs mode to determine the current TACACS+ configuration settings.

```
firepower# scope security
firepower /security # scope tacacs
firepower /security/tacacs # show server detail

TACACS+ server:
  Hostname, FQDN or IP address: 10.48.17.199
  Descr:
  Order: 1
  Port: 49
  Key: ****
  Timeout: 5
firepower /security/tacacs #
```

## Configuring Syslog

System logging is a method of collecting messages from devices to a server running a syslog daemon. Logging to a central syslog server helps in aggregation of logs and alerts. A syslog service accepts messages and stores them in files, or prints them according to a simple configuration file. This form of logging provides protected long-term storage for logs. Logs are useful both in routine troubleshooting and in incident handling.

### Procedure

- 
- Step 1** Enter monitoring mode:
- ```
Firepower-chassis# scope monitoring
```
- Step 2** Enable or disable the sending of syslogs to the console:
- ```
Firepower-chassis /monitoring # {enable | disable} syslog console
```
- Step 3** (Optional) Select the lowest message level that you want displayed. If syslogs are enabled, the system displays that level and above on the console. The level options are listed in order of decreasing urgency. The default level is Critical.
- ```
Firepower-chassis /monitoring # set syslog console level {emergencies | alerts | critical}
```
- Step 4** Enable or disable the monitoring of syslog information by the operating system:
- ```
Firepower-chassis /monitoring # {enable | disable} syslog monitor
```
- Step 5** (Optional) Select the lowest message level that you want displayed. If the monitor state is enabled, the system displays that level and above. The level options are listed in order of decreasing urgency. The default level is Critical.
- ```
Firepower-chassis /monitoring # set syslog monitor level {emergencies | alerts | critical | errors | warnings | notifications | information | debugging}
```

**Note** Messages at levels below Critical are displayed on the terminal monitor only if you have entered the **terminal monitor** command.

**Step 6** Enable or disable the writing of syslog information to a syslog file:

```
Firepower-chassis /monitoring # {enable | disable} syslog file
```

**Step 7** Specify the name of the file in which the messages are logged. Up to 16 characters are allowed in the file name.

```
Firepower-chassis /monitoring # set syslog file name filename
```

**Step 8** (Optional) Select the lowest message level that you want stored to a file. If the file state is enabled, the system stores that level and above in the syslog file. The level options are listed in order of decreasing urgency. The default level is Critical.

```
Firepower-chassis /monitoring # set syslog file level {emergencies | alerts | critical | errors | warnings | notifications | information | debugging}
```

**Step 9** (Optional) Specify the maximum file size, in bytes, before the system begins to write over the oldest messages with the newest ones. The range is 4096 to 4194304 bytes.

```
Firepower-chassis /monitoring # set syslog file size filesize
```

**Step 10** Configure sending of syslog messages to up to three external syslog servers:

a) Enable or disable the sending of syslog messages to up to three external syslog servers:

```
Firepower-chassis /monitoring # {enable | disable} syslog remote-destination {server-1 | server-2 | server-3}
```

b) (Optional) Select the lowest message level that you want stored to the external log. If the remote-destination is enabled, the system sends that level and above to the external server. The level options are listed in order of decreasing urgency. The default level is Critical.

```
Firepower-chassis /monitoring # set syslog remote-destination {server-1 | server-2 | server-3} level {emergencies | alerts | critical | errors | warnings | notifications | information | debugging}
```

c) Specify the hostname or IP address of the specified remote syslog server. Up to 256 characters are allowed in the hostname.

```
Firepower-chassis /monitoring # set syslog remote-destination {server-1 | server-2 | server-3} hostname hostname
```

d) (Optional) Specify the facility level contained in the syslog messages sent to the specified remote syslog server.

```
Firepower-chassis /monitoring # set syslog remote-destination {server-1 | server-2 | server-3} facility {local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7}
```

**Step 11** Configure the local sources. Enter the following command for each of the local sources you want to enable or disable:

```
Firepower-chassis /monitoring # {enable | disable} syslog source {audits | events | faults}
```

This can be one of the following:

- **audits**—Enables or disables the logging of all audit log events.
- **events**—Enables or disables the logging of all system events.



- **faults**—Enables or disables the logging of all system faults.

**Step 12** Commit the transaction:

```
Firepower-chassis /monitoring # commit-buffer
```

### Example

This example shows how to enable the storage of syslog messages in a local file and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # disable syslog console
Firepower-chassis /monitoring* # disable syslog monitor
Firepower-chassis /monitoring* # enable syslog file
Firepower-chassis /monitoring* # set syslog file name SysMsgsFirepower
Firepower-chassis /monitoring* # set syslog file level notifications
Firepower-chassis /monitoring* # set syslog file size 4194304
Firepower-chassis /monitoring* # disable syslog remote-destination server-1
Firepower-chassis /monitoring* # disable syslog remote-destination server-2
Firepower-chassis /monitoring* # disable syslog remote-destination server-3
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

## Configuring DNS Servers

You need to specify a DNS server if the system requires resolution of host names to IP addresses. For example, you cannot use a name such as `www.cisco.com` when you are configuring a setting on the chassis if you do not configure a DNS server. You would need to use the IP address of the server, which can be either an IPv4 or an IPv6 address. You can configure up to four DNS servers.



**Note** When you configure multiple DNS servers, the system searches for the servers only in any random order. If a local management command requires DNS server lookup, it can only search for three DNS servers in random order.

### Procedure

**Step 1** Enter system mode:

```
Firepower-chassis # scope system
```

**Step 2** Enter system services mode:

```
Firepower-chassis /system # scope services
```

**Step 3** To create or delete a DNS server, enter the appropriate command as follows:

- To configure the system to use a DNS server with the specified IPv4 or IPv6 address:

```
Firepower-chassis /system/services # create dns {ip-addr | ip6-addr}
```

- To delete a DNS server with the specified IPv4 or IPv6 address:

```
Firepower-chassis /system/services # delete dns {ip-addr | ip6-addr}
```

**Step 4** Commit the transaction to the system configuration:

```
Firepower /system/services # commit-buffer
```

### Example

The following example configures a DNS server with the IPv4 address 192.168.200.105 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create dns 192.168.200.105
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

The following example configures a DNS server with the IPv6 address 2001:db8::22:F376:FF3B:AB3F and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create dns 2001:db8::22:F376:FF3B:AB3F
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

The following example deletes the DNS server with the IP address 192.168.200.105 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # delete dns 192.168.200.105
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

## Enable FIPS Mode

Perform these steps to enable FIPS mode on your Firepower 4100/9300 chassis.

### Procedure

**Step 1** From the FXOS CLI, enter the security mode:

```
scope security
```

**Step 2** Enable FIPS mode:

**enable fips-mode**

**Step 3** Commit the configuration:

**commit-buffer**

**Step 4** Reboot the system:

**connect local-mgmt**

**reboot**

---

When the FIPS Mode is enabled, it limits the key sizes and the algorithms allowed. The MIO uses CiscoSSL and the FIPS Object Module (FOM) for its cryptographic needs. It makes FIPS validation easier compared to ASA's proprietary cryptographic library implementation and HW acceleration.

#### What to do next

Prior to FXOS release 2.0.1, the existing SSH host key created during first-time setup of a device was hard coded to 1024 bits. To comply with FIPS and Common Criteria certification requirements, you must destroy this old host key and generate a new one using the procedure detailed in [Generate theSSH Host Key](#). If you do not perform these additional steps, you will not be able to connect to the Supervisor using SSH after the device has rebooted with FIPS mode enabled. If you performed initial setup using FXOS 2.0.1 or later, you do not have to generate a new host key.

## Enable Common Criteria Mode

Perform these steps to enable Common Criteria mode on your Firepower 4100/9300 chassis.

#### Procedure

---

**Step 1** From the FXOS CLI, enter the security mode:

**scope security**

**Step 2** Enable Common Criteria mode:

**enable cc-mode**

**Step 3** Commit the configuration:

**commit-buffer**

**Step 4** Reboot the system:

**connect local-mgmt**

**reboot**

---

Common Criteria is an international standard for computer security. CC focuses on certificates, auditing, logging, passwords, TLS, SSH, etc. It essentially assumes FIPS compliance. Similar to FIPS, Cisco contracts with NIST accredited lab vendors to perform testing and submission to NIAP.

When the CC Mode is enabled, it limits the list of algorithms, cipher suites, and features that are needed to be supported. The MIO is evaluated against the Network Device Collaborative Protection Profile (NDcPP). CiscoSSL can only enforce part of the requirements most of which are covered in the [CC compliance guide](#).

### What to do next

Prior to FXOS release 2.0.1, the existing SSH host key created during first-time setup of a device was hard coded to 1024 bits. To comply with FIPS and Common Criteria certification requirements, you must destroy this old host key and generate a new one using the procedure detailed in [Generate the SSH Host Key](#). If you do not perform these additional steps, you will not be able to connect to the Supervisor using SSH after the device has rebooted with Common Criteria mode enabled. If you performed initial setup using FXOS 2.0.1 or later, you do not have to generate a new host key.

## Configure the IP Access List

By default, the Firepower 4100/9300 chassis denies all access to the local web server. You must configure your IP Access List with a list of allowed services for each of your IP blocks.

The IP Access List supports the following protocols:

- HTTPS
- SNMP
- SSH

For each block of IP addresses (v4 or v6), up to 100 different subnets can be configured for each service. A subnet of 0 and a prefix of 0 allows unrestricted access to a service.

### Procedure

---

**Step 1** From the FXOS CLI, enter the services mode:

```
scope system
```

```
scope services
```

**Step 2** Create an IP block for the services you want to enable access for:

For IPv4:

```
create ip-block ip prefix [0-32] [http | snmp | ssh]
```

For IPv6:

```
create ipv6-block ip prefix [0-128] [http | snmp | ssh]
```

---

### Example

The following example shows how to create, enter, and verify an IPv4 address block to provide SSH access:

```
firepower # scope system
firepower /system # scope services
firepower /system/services # enter ip-block 192.168.200.101 32 ssh
firepower /system/services/ip-block* # commit-buffer
firepower /system/services/ip-block # up
firepower /system/services # show ip-block
```

Permitted IP Block:

| IP Address      | Prefix Length | Protocol |
|-----------------|---------------|----------|
| 0.0.0.0         | 0             | https    |
| 0.0.0.0         | 0             | snmp     |
| 0.0.0.0         | 0             | ssh      |
| 192.168.200.101 | 32            | ssh      |

```
firepower /system/services #
```

The following example shows how to create, enter and verify an IPv6 address block to provide SSH access::

```
firepower # scope system
firepower /system # scope services
firepower /system/services # create ipv6-block 2001:DB8:1::1 64 ssh
firepower /system/services/ipv6-block* # commit-buffer
firepower /system/services/ipv6-block # up
firepower /system/services # show ipv6-block
```

Permitted IPv6 Block:

| IPv6 Address  | Prefix Length | Protocol |
|---------------|---------------|----------|
| ::            | 0             | https    |
| ::            | 0             | snmp     |
| ::            | 0             | ssh      |
| 2001:DB8:1::1 | 64            | ssh      |

```
firepower /system/services #
```

## Add a MAC Pool Prefix and View MAC Addresses for Container Instance Interfaces

The FXOS chassis automatically generates MAC addresses for container instance interfaces, and guarantees that a shared interface in each instance uses a unique MAC address. The FXOS chassis generates the MAC address using the following format:

A2xx.yyzz.zzzz

Where xx.yy is a user-defined prefix or a system-defined prefix, and zz.zzzz is an internal counter generated by the chassis. The system-defined prefix matches the lower 2 bytes of the first MAC address in the burned-in MAC address pool that is programmed into the IDPROM. Use **connect fxos**, then **show module** to view the MAC address pool. For example, if the range of MAC addresses shown for module 1 is b0aa.772f.f0b0 to b0aa.772f.f0bf, then the system prefix will be f0b0.

See [Automatic MAC Addresses for Container Instance Interfaces](#) for more information.

This procedure describes how to view the MAC addresses and how to optionally define the prefix used in generation.




---

**Note** If you change the MAC address prefix after you deploy logical devices, you may experience traffic interruption.

---

### Procedure

---

**Step 1** Enter Security Services mode, and then Auto MAC pool mode.

**scope ssa**

**scope auto-macpool**

**Example:**

```
Firepower# scope ssa
Firepower /ssa # scope auto-macpool
Firepower /ssa/auto-macpool #
```

**Step 2** Set the MAC address prefix used in generating the MAC addresses.

**set prefix prefix**

- *prefix*—Enter a decimal value between 1 and 65535. This prefix is converted to a four-digit hexadecimal number, and used as part of the MAC address.

For an example of how the prefix is used, if you set a prefix of 77, then the chassis converts 77 into the hexadecimal value 004D (yyxx). When used in the MAC address, the prefix is reversed (xxyy) to match the chassis native form:

**A24D.00zz.zzzz**

For a prefix of 1009 (03F1), the MAC address is:

**A2F1.03zz.zzzz**

**Example:**

```
Firepower /ssa/auto-macpool # set prefix 65
Firepower /ssa/auto-macpool* #
```

**Step 3** Save the configuration.

**commit-buffer**

**Example:**

```
Firepower /ssa/auto-macpool* # commit-buffer
Firepower /ssa/auto-macpool #
```

**Step 4** View MAC address assignments.

**show mac-address****Example:**

```
Firepower /ssa/auto-macpool # show mac-address
Mac Address Item:
  Mac Address          Owner Profile          Owner Name
  -----
A2:46:C4:00:00:1E    ftd13                  Port-channel14
A2:46:C4:00:00:20    ftd14                  Port-channel15
A2:46:C4:00:01:7B    ftd1                   Ethernet1/3
A2:46:C4:00:01:7C    ftd12                  Port-channel11
A2:46:C4:00:01:7D    ftd13                  Port-channel14
A2:46:C4:00:01:7E    ftd14                  Port-channel15
A2:46:C4:00:01:7F    ftd1                   Ethernet1/2
A2:46:C4:00:01:80    ftd12                  Ethernet1/2
A2:46:C4:00:01:81    ftd13                  Ethernet1/2
A2:46:C4:00:01:82    ftd14                  Ethernet1/2
A2:46:C4:00:01:83    ftd2                   Ethernet3/1/4
A2:46:C4:00:01:84    ftd2                   Ethernet3/1/1
A2:46:C4:00:01:85    ftd2                   Ethernet3/1/3
A2:46:C4:00:01:86    ftd2                   Ethernet3/1/2
A2:46:C4:00:01:87    ftd2                   Ethernet1/2
A2:46:C4:00:01:88    ftd1                   Port-channel21
A2:46:C4:00:01:89    ftd1                   Ethernet1/8
```

**Example**

The following example sets the MAC prefix to 33.

```
Firepower# scope ssa
Firepower /ssa # scope auto-macpool
Firepower /ssa/auto-macpool # set prefix 33
Firepower /ssa/auto-macpool* # commit-buffer
Firepower /ssa/auto-macpool #
```

## Add a Resource Profile for Container Instances

To specify resource usage per container instance, create one or more resource profiles. When you deploy the logical device/application instance, you specify the resource profile that you want to use. The resource profile sets the number of CPU cores; RAM is dynamically allocated according to the number of cores, and disk space is set to 40 GB per instance.

- The minimum number of cores is 6.



**Note** Instances with a smaller number of cores might experience relatively higher CPU utilization than those with larger numbers of cores. Instances with a smaller number of cores are more sensitive to traffic load changes. If you experience traffic drops, try assigning more cores.

- You can assign cores as an even number (6, 8, 10, 12, 14 etc.) up to the maximum.
- The maximum number of cores available depends on the security module/chassis model; see [Requirements and Prerequisites for Container Instances](#).

The chassis includes a default resource profile called "Default-Small," which includes the minimum number of cores. You can change the definition of this profile, and even delete it if it is not in use. Note that this profile is created when the chassis reloads and no other profile exists on the system.

You cannot change the resource profile settings if it is currently in use. You must disable any instances that use it, then change the resource profile, and finally reenable the instance. If you resize instances in an established High Availability pair or cluster, then you should make all members the same size as soon as possible.

If you change the resource profile settings after you add the Firepower Threat Defense instance to the FMC, then update the inventory for each unit on the FMC **Devices > Device Management > Device > System > Inventory** dialog box.

## Procedure

---

**Step 1** Enter Security Services mode.

**scope ssa**

**Example:**

```
Firepower# scope ssa
Firepower /ssa #
```

**Step 2** Create the resource profile.

**enter resource-profile *name***

- *name*—Sets the name of the profile between 1 and 64 characters. Note that you cannot change the name of this profile after you add it.

**Example:**

```
Firepower /ssa # enter resource-profile gold
Firepower /ssa/resource-profile* #
```

**Step 3** Enter a description.

**set description *description***

- *description*—Sets the description of the profile up to 510 characters. Use quotes (") around phrases with spaces.

**Example:**

```
Firepower /ssa/resource-profile* # set description "highest level"
```

**Step 4** Set the number of CPU cores.

**set cpu-core-count *cores***



- *cores*—Sets the number of cores for the profile, between 6 and the maximum, depending on your chassis, as an even number.

**Example:**

```
Firepower /ssa/resource-profile* # set cpu-core-count 14
```

**Step 5** Save the configuration.

**commit-buffer****Example:**

```
Firepower /ssa/resource-profile* # commit-buffer
Firepower /ssa/resource-profile #
```

**Step 6** View resource profile assignments from security services mode.

**show resource-profile user-defined****Example:**

```
Firepower /ssa # show resource-profile user-defined
Profile Name      Is In Use  CPU Logical Core Count  Description
-----
bronze            No         6                        low end device
gold              No         14                       highest
silver            No         10                       mid-level
```

**Step 7** View resource usage for the security module/engine slot.

**show monitor detail****Example:**

```
Firepower /ssa # scope slot 1
Firepower /ssa/slot # show monitor detail
Monitor:
  OS Version:
  CPU Total Load 1 min Avg: 18.959999
  CPU Total Load 5 min Avg: 19.080000
  CPU Total Load 15 min Avg: 19.059999
  Memory Total (MB): 252835
  Memory Free (MB): 200098
  Memory Used (MB): 52738
  CPU Cores Total: 72
  CPU Cores Available: 30
  Memory App Total (MB): 226897
  Memory App Available (MB): 97245
  Data Disk Total (MB): 1587858
  Data Disk Available (MB): 1391250
  Secondary Disk Total (MB): 0
  Secondary Disk Available (MB): 0
  Disk File System Count: 7
  Blade Uptime:
  Last Updated Timestamp: 2018-05-23T14:26:06.132
```

**Step 8** View resource allocation for the application instance.

**show resource detail****Example:**

```

Firepower /ssa # scope slot 1
Firepower /ssa/slot # enter app-instance ftd ftd1
Firepower /ssa/slot/app-instance # show resource detail
Resource:
  Allocated Core NR: 10
  Allocated RAM (MB): 32413
  Allocated Data Disk (MB): 49152
  Allocated Binary Disk (MB): 3907
  Allocated Secondary Disk (MB): 0

```

**Example**

The following example adds three resource profiles.

```

Firepower# scope ssa
Firepower /ssa # enter resource-profile basic
Firepower /ssa/resource-profile* # set description "lowest level"
Firepower /ssa/resource-profile* # set cpu-core-count 6
Firepower /ssa/resource-profile* # exit
Firepower /ssa # enter resource-profile standard
Firepower /ssa/resource-profile* # set description "middle level"
Firepower /ssa/resource-profile* # set cpu-core-count 10
Firepower /ssa/resource-profile* # exit
Firepower /ssa # enter resource-profile advanced
Firepower /ssa/resource-profile* # set description "highest level"
Firepower /ssa/resource-profile* # set cpu-core-count 12
Firepower /ssa/resource-profile* # commit-buffer
Firepower /ssa/resource-profile #

```

## Configure a Network Control Policy

To permit the discovery of non-Cisco devices, FXOS supports the *Link Layer Discovery Protocol (LLDP)*, a vendor-neutral device discovery protocol that is defined in the IEEE 802.1ab standard. LLDP allows network devices to advertise information about themselves to other devices on the network. This protocol runs over the data-link layer, which allows two systems running different network layer protocols to learn about each other.

LLDP is a one-way protocol that transmits information about the capabilities and current status of a device and its interfaces. LLDP devices use the protocol to solicit information only from other LLDP devices.

To enable this functionality on your FXOS chassis, you can configure a network control policy, which specifies LLDP transmission and receiving behavior. Once a network control policy is created, it needs to be assigned to an interface. You can enable LLDP on any front interface, including fixed ports, EPM ports, port channels, and break out ports.



- Note**
- LLDP is not configurable on dedicated management ports.
  - Internal backplane ports that connect to the blade have LLDP enabled by default, with no option to disable. All other ports have LLDP disabled by default.

## Procedure

- Step 1** Enter the organization scope.
- scope org**
- Example:**
- ```
Firepower # scope org
```
- Step 2** Create and enable the network control policy.
- create nw-ctrl-policy nw-policy**
- Example:**
- ```
Firepower /org # create nw-ctrl-policy nw-policy
```
- Step 3** Enable LLDP.
- enable lldp {receive | transmit}**
- Example:**
- ```
Firepower /org/nw-ctrl-policy* # enable lldp receive
Firepower /org/nw-ctrl-policy* # disable lldp transmit
```
- Step 4** Commit the configuration:
- commit-buffer**
- Example:**
- ```
Firepower /eth-uplink/fabric/interface* # commit-buffer
Firepower /eth-uplink/fabric/interface #
```
- Step 5** Specify whether to enable or disable LLDP for receiving/transmitting.
- enable lldp receive/transmit**
- commit-buffer**
- Example:**
- ```
Firepower /org/nw-ctrl-policy* # enable lldp receive
Firepower /org/nw-ctrl-policy* # disable lldp transmit
Firepower /org/nw-ctrl-policy* # commit-buffer
```

```
Firepower /org/nw-ctrl-policy* # enable lldp receive
Firepower /org/nw-ctrl-policy* # disable lldp transmit
Firepower /org/nw-ctrl-policy* # commit-buffer
```

**Step 6** Use the following commands to apply the network control policy to an interface.

a) Enter the interface:

**scope eth-uplink**

**scope fabric a**

**scope interface *interface\_id***

```
Firepower # scope eth-uplink
Firepower /eth-uplink # scope fabric a
Firepower /eth-uplink/fabric # enter interface Ethernet3/1
```

b) Set the network control policy:

**set nw-ctrl-policy *nw-policy***

**commit-buffer**

```
Firepower /eth-uplink/fabric/interface # set nw-ctrl-policy nw-policy
Firepower /eth-uplink/fabric/interface* # commit-buffer
MIO-5 /eth-uplink/fabric/interface # show detail
```

c) View the change:

**show detail**

```
Firepower /eth-uplink/fabric/interface # show detail
Interface:
  Port Name: Ethernet3/1
  User Label:
  Port Type: Data
  Admin State: Enabled
  Oper State: Sfp Not Present
  State Reason: Unknown
  flow control policy: default
  Auto negotiation: No
  Admin Speed: 100 Gbps
  Oper Speed: 100 Gbps
  Admin Duplex: Full Duplex
  Oper Duplex: Full Duplex
  Ethernet Link Profile name: default
  Oper Ethernet Link Profile name: fabric/lan/eth-link-prof-default
  Uddl Oper State: Admin Disabled
  Inline Pair Admin State: Enabled
  Inline Pair Peer Port Name:
  Allowed Vlan: All
  Network Control Policy: nw-policy
  Current Task:
```

d) Commit the configuration:

**commit-buffer**

**Example:**

```
Firepower /eth-uplink/fabric/interface* # commit-buffer
Firepower /eth-uplink/fabric/interface #
```

---

## Configure the Chassis URL

You can specify a management URL so that you can easily open Firepower Chassis Manager for an Firepower Threat Defense instance directly from FMC. If you do not specify a chassis management URL, the chassis name is used instead.

If you change the chassis URL settings after you add the Firepower Threat Defense instance to the FMC, then update the inventory for each unit on the **Devices > Device Management > Device > System > Inventory** dialog box.

### Procedure

---

**Step 1** Enter the system mode:

**scope system**

**Example:**

```
Firepower# scope system
Firepower /system #
```

**Step 2** To configure a new chassis name:

**set name *chassis\_name***

- *chassis\_name*—Sets the name of the chassis between 1 and 60 characters.

**Example:**

```
Firepower /system # set name Firepower_chassis
```

**Step 3** To configure the management URL:

**set mgmt-url *management\_url***

- *management\_url*—Sets the URL that FMC should use to connect to an Firepower Threat Defense instance within Firepower Chassis Manager. The URL must start with `https://`. If you do not specify a chassis management URL, the chassis name is used instead.

**Example:**

```
Firepower /system # set mgmt-url https://192.168.1.55
```

**Step 4** Save the configuration.

**commit-buffer****Example:**

```
Firepower /system* # commit-buffer
Firepower /system #
```

**Step 5** View configuration settings.

**show detail****Example:**

```
Firepower_chassis /system # show detail

Systems:
  Name: Firepower_chassis
  Mode: Stand Alone
  System IP Address: 192.168.1.10
  System IPv6 Address: ::
  System Owner:
  System Site:
  Description for System:
  Chassis Mgmt URL: https://192.168.1.55
```

---

## Modifying Weak Key Exchange Algorithms

You can mitigate the weak key exchange algorithms used on the equipment by:

- [Setting FIPS/CC Mode](#)
- [Setting Cipher Suite](#)

### Setting FIPS/CC Mode

#### Procedure

---

**Step 1** From the FXOS CLI, enter the security mode:

```
scope security
```

**Step 2** Enable FIPS mode:

```
enable fips-mode
```

**Step 3** Commit the configuration:

```
commit-buffer
```

---

## Setting Cipher Suite

### Procedure

---

- Step 1** Enter system mode:  
Firepower-chassis# **scope system**
- Step 2** Enter system services mode:  
Firepower-chassis /system # **scope services**
- Step 3** View the HTTPS service:  
Firepower-chassis /system/services # **show https**
- Step 4** Set the Cipher Suite mode:  
Firepower-chassis /system/services # **set https cipher-suite-mode custom**
- Step 5** Set the Cipher Suite string  
Firepower-chassis /system/services # set https cipher-suite \*\*\*\*\*
- Step 6** Commit the settings to the system configuration:  
Firepower-chassis /system/services # **commit-buffer**
- 

## Register the Chassis with the Firepower Management Center for Health Monitoring

You can monitor the chassis in the FMC for chassis-level health alerts. The management center and the chassis share a separate management connection through the chassis MGMT interface. To monitor chassis-level health alerts in the FMC, you must manually configure the FMC as manager on the chassis, and then register the chassis in the FMC.

To configure the FMC on the chassis, perform the following steps.

### Procedure

---

- Step 1** Configure the FMC.
- create device-manager** *manager\_name* **hostname** {*hostname* | *ipv4\_address* | *ipv6\_address*} [**nat-id** *nat\_id*]
- You are prompted for the registration key.
- You can enter this command from any scope. This command is accepted immediately without using **commit-buffer**.

- **hostname** *{hostname | ipv4\_address | ipv6\_address}*—Specifies either the FQDN or IP address of the FMC. At least one of the devices, either the FMC or the chassis, must have a reachable IP address to establish the two-way, TLS-1.3-encrypted communication channel between the two devices. If you do not specify a **hostname**, then the chassis must have a reachable IP address or hostname and you must specify the **nat-id**.
- **nat-id** *nat\_id*—Specifies a unique, one-time string of your choice that you will also specify on the FMC when you register the chassis when one side does not specify a reachable IP address or hostname. It is required if you do not specify a **hostname**, however we recommend that you always set the NAT ID even when you specify a hostname or IP address. The NAT ID must not exceed 37 characters. Valid characters include alphanumeric characters (A–Z, a–z, 0–9) and the hyphen (-). This ID cannot be used for any other devices registering to the FMC.
- **Registration Key:** *reg\_key*—You will be prompted for a one-time registration key of your choice that you will also specify on the FMC when you register the chassis. The registration key must not exceed 37 characters. Valid characters include alphanumeric characters (A–Z, a–z, 0–9) and the hyphen (-).

**Step 2** (Optional) To view the configured FMC details, use **show device-manager**.

### Example

```
Firepower# create device-manager FMC1 hostname 10.10.4.133 nat-id 93002
Registration key: Impala67
tb-05 /device-manager #
tb-05 /device-manager # show device-manager

Device manager:
  Name: FMC1
  Hostname: 10.10.4.133
  NAT id:93002
  Registration key:Impala67
  Reg State: Pending
  Error Msg:
```



**Note** You can delete the FMC in chassis only when the registration state is **Pending** and not **Completed**. If you try to delete the FMC in chassis after the successful registration of chassis in the FMC, it will throw an error message.

### What to do next

Register the chassis in the FMC. For detailed steps, see [Management center device configuration guide](#).